

手柄说明书

尊敬的用户，
非常感谢您选用此款 安卓游戏手柄。请在使用前，仔细阅读本手册，以便正确操作使用，更好地发挥产品优越性能。本手册中的说明是设备的默认设置；本手册中的所有图片、陈述及文字信息仅供参考，请以实际产品为准。如有内容更新恕不另行通知。这些更新会重新编入新版手册中，本公司保留最终解释权。可用功能和附加服务可能因设备、软件或服务提供而而异，如有印刷错误或翻译失误恕不广大用户谅解。

一、产品概述

- 该产品主要用于安卓系统的手机、平板、电视、TV BOX，或苹果系统的手机、平板等带蓝牙功能的设备，通过 HID 协议方式来进行数据传输。
- 该手柄由15个数字按键（UP、DOWN、LEFT、RIGHT、A、B、X、Y、L1(R)、R1(RB)、L3、R3、SELECT、START、HOME)、两个模拟按键 L2(LT)、R2(RT)和两个模拟 3D 摇杆组成。

二、手柄模式4指示灯

Gamepad 模式： 操控模式： 新游模式： IOS 模式：

三、通用说明

- 通用平台
 - (1) 安卓设备（系统版本 4.2 以上）
 - (2) 苹果设备（系统版本 IOS6.0 以上）
 - (3) 可适配通过 MINI 蓝牙接收器实现支持 PC/PC360/PS3 主机功能扩展；PC、PC360 支持 Windows XP 以上的系统。

2. 连接方式

通过蓝牙无线技术连接。

四、操作说明

1. 安卓 Gamepad 模式

按住 X 键+HOME 键 1S，进入手柄模式对码连接，此时手柄上 4 个模式灯快闪，搜索设备名 Gamepad，点击设备名连接，蓝牙配对连接上后 LED1 模式灯常亮此时为 Gamepad 模式。

2. 新游 (NewGame) 模式

按住 Y 键+HOME 键 1S，进入新游模式对码连接，此时手柄上 4 个模式灯快闪，搜索设备名 Newgamepad N1，点击设备名连接，蓝牙配对连接上后 LED3 模式灯常亮此时为新游模式。

备注：新游模式只支持在苹果系统设备下使用，请下载安装支持苹果系统的新游平台（www.newgame.com）。

3. IOS (iCade)模式

按住 B 键+HOME 键 1S，进入 IOS(iCade)模式对码连接，此时手柄上 4 个模式灯快闪，搜索设备名 Gamepad，点击设备名连接，蓝牙配对连接上后 LED4 模式灯常亮此时则为 IOS (iCade)模式。

备注：在使用 IOS (iCade)模式时，输入法要设置到纯英文键盘下面；操控模式不支持鼠标。

4. 操控模式（鼠标+多媒体）

工作在 Gamepad，新建模 IOS(iCade)模式时，以上三种模式状态下通过短按 HOME 键都可以切换到操控模式（鼠标+多媒体）LED2 模式灯常亮。

5. LED 指示：

手柄共有 4 个 LED 灯，作为充电、低电、模式、蓝牙配对指示灯。

6. MINI接收头配对方式

- 若与接收头配对，则先按住SELECT 键再按 HOME 键开机后松开按键则很快就能配对连接上。
- 通过接收头与 PC 连接时 LED1 模式灯常亮，支持 PC 模式手柄功能。
- PC360 手柄功能切换，在 PC 模式下，同时按住 SELECT 键和 START 键 4 秒左右手柄 LED3 模式灯常亮则表示已切换到 PC360 手柄模式。
- 通过接收头与 PS3 主机连接时，可自动识别为一个 PS3 功能手柄实现支持 PS3 主机，此时四个模式灯可作为通道指示灯功能。

7. 自动回连

- 安卓/苹果设备蓝牙开启，手柄关闭；按HOME键启动手柄，可使手柄与设备重新建立连接。
- 安卓/苹果蓝牙关闭，手柄开启；重新打开设备蓝牙，可使手柄与设备重新建立连接。
- 安卓/苹果蓝牙关闭，手柄关闭；按 NI 键启动手柄，重新打开设备蓝牙，可使手柄与设备重新建立连接。

备注：以上三种状态手柄与设备必须成功配对过，且设备端的 配对信息还保留，则数秒后手柄将自动连上安卓/苹果设备，默认在关机前使用的模式，对应的模式灯常亮；若设备端的配对信息已经删除，则指示灯慢闪会持续1分钟左右手柄将自动关机。

8. 重置手柄

当手柄出现异常的时候如按键错乱，死机，无法连接等情况可以尝试重置手柄。重置方式：用细长物品插入手柄背部的 Reset 小孔，按下 Reset 键即可重置手柄状态。

五、手柄开关机/充电/睡眠

- 开关手柄：按手柄HOME键1秒即可开机，长按HOME键5秒直至手柄指示灯熄灭。
- 当低电量时当前模式指示灯闪烁，此时通过USB连接充电到指示灯常亮时表示手柄充满电。
- 在关机状态下直接充电时四个模式灯同时慢闪充满时四个模式灯常亮。
- 在配对状态下，超过 1 分钟，未眠成功，手柄自动关机。
- 在联机状态下，手柄超过10分钟无动作，手柄自动关机。

六、手柄各模式按键功能对照表

手柄符号	Gamepad 模式	操控模式	新游模式	IOS 模式	描述备注
A	返回键	音量减		H / R	
B		下一曲		U / F	
X	确认键	上一曲		Y / T	
Y		音量加		X / N	
十字方向_UP	POV_UP			W / E	
十字方向_RIGHT	POV_RIGHT	无功能		D / C	
十字方向_DOWN	POV_DOWN			X / Z	
十字方向_LEFT	POV_LEFT			A / Q	
L1 (LB)		L1 鼠标左键		I / M	
R1(RB)	L2(LT)	L2 鼠标右键		J / P	
		R2 音乐播放键		I / 2	
SELECT		菜单键		O / G	
START	HOME 键	HOME 键		L / V	
HOME	MODE	MODE		-	
左摇杆 UP	YUP			W / E	
左摇杆 DOWN	YDOWN			X / Z	
左摇杆 LEFT	X-LEFT			A / Q	
左摇杆 RIGHT	X-RIGHT			D / C	
右摇杆 UP				A	
右摇杆 DOWN				34	
右摇杆 LEFT				34	
右摇杆 RIGHT				34	
模式指示灯状态	LED1	LED2	LED3	LED4	

七、推荐游戏平台

请下载一个游戏模拟器(如小鸡模拟器<http://www.xiaoj1001.com>或葡萄游戏模拟器 <http://www.putaogame.com>)KO电玩城，棉花糖等安卓模拟器并安装在安卓设备上,打开游戏模拟器并下载安装好里面的游戏即可体验游戏。因安卓系统为开放性平台,各游戏厂家设计标准不统一,会导致手柄不能能使用全部游戏，敬请见谅。

Instruction Manual

Dear Customer :

Thank you very much for choosing the Android game controller! Please carefully read this manual for correct operation, and better display product superior performance before use it. The instructions in this manual are based on default setting of the device. All pictures in this manual, representations and text information are for reference only! Subject to the actual product please, if there are updates. These updates will be reintegrated into the new version manual, Available features and additional services may vary by device, software or service provider to another.

一、Description:

- The product is mainly used in the following Bluetooth devices:
 - Android system: smart phone, tablet, TV, TV box.
 - IOS system : mobile phone, tablet.
- Through the HID protocol method for data transmission.
- There are 15 digital buttons (UP、DOWN、LEFT、RIGHT、A、B、X、Y、L1(LB)、R1(RB)、L3、R3、SELECT、START、HOME), and 2 analog buttons (L2(LT)、R2(RT)) and 2 simulated 3D sticks on the controller.

二、Controller mode & indicator

Android Gamepad mode :

Control mode :

NewGame mode :

IOS mode :

三、Application

- Platform
 - (1) Android device (Android version 3.2 or above)
 - (2) IOS device (IOS version 6.0 or above)
 - (3) Support for PC/PC360/PS3 console function extension with a mini Bluetooth receiver, compatible with Windows XP or above system for PC、PC360.
- Connecting method:
 - Connecting via Bluetooth technology.

四、Operation Instruction

1. Android Gamepad mode

Press X+HOME keys 1 seconds, it going to Gamepad mode code connection, four mode lights on the controller flash quickly then, and search for the device, find "Gamepad" and select it for connection. After the Bluetooth pairing connected, LED1 light on for Gamepad mode.

2. NewGame mode

Press Y+HOME keys 1 seconds, it going to NewGame mode code connection, four mode lights on the controller flash quickly then, and search for the device, find "Newgamepad N1", and select it for connection. After the Bluetooth pairing connected, LED3 light on for NewGame mode.

Note: NewGame mode only support in Apple system device, please download and install support Apple system Platform (www.newgame.com) .

3. IOS (iCade) mode

Press B+HOME keys 1 seconds, it going to IOS mode code connection, four mode lights on the controller flash quickly then, and search for the device, find "Gamepad" and select it for connection. After the Bluetooth pairing connected, LED4 light on for IOS mode.

Note: In using IOS mode, set up keyboard aspect mode to English.

N0 : 2429

永恒荣-安卓中性说明书-CTP

K 2016-04-28

六、Controller Mode/Button/Function Table :

Controller Symbo	Android	Control	NewGame	Ios	Remark
A		Vol -		H / R	
B	Return Button	Next		U / F	
X	Enter Button	Left		Y / T	
Y		Vol +		X / N	
CROSS_UP	POV_UP			W / E	
CROSS_RIGHT	POV_RIGHT	NO Function		D / C	
CROSS_DOWN	POV_DOWN			X / Z	
CROSS_LEFT	POV_LEFT			A / Q	
L1(LB)		L1 Mouse Left Button		I / M	
R1(RB)	L2(LT)	NO Function		L2 Music Play	[/]
R2(RT)		R1 Mouse Right Button		K / P	
		R2 Music Play Button		I / 2	
SELECT	Menu Key	Back		O / G	
START	HOME	HOME		L / V	
HOME	MODE	MODE		-	
Left Stick UP	YUP			W / E	
Left Stick DOWN	YDOWN	UP/DOWN/LEFT/		X / Z	
Left Stick LEFT	X-LEFT	RIGHT Stick big		A / Q	
Left Stick RIGHT	X-RIGHT	range		D / C	
Right Stick UP				34	
Right Stick DOWN		UP/DOWN/LEFT/		-	
Right Stick LEFT	NO Function	RIGHT Stick small range		34	
Right Stick RIGHT				34	
Mode Indicator	LED1	LED2	LED3	LED4	

七、Recommended Gaming Platform

Please download a Android game APP (such as chicken emulator, www.xiaoj1001.com, or PuTao Games emulator, www.putaogame.com) and install it on the device, and open the APP for play games. Because Android is an open platform, the game developer standards are not unified, it'll cause the controller not be able to play all games, your understanding will be appreciated!

PCC ID:AWFSZANDROIDBC

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.