

WAVE PTX™
TWO-WAY RADIO



TLK 110 Portable Radio User Guide

DECEMBER 2022

© 2022 Motorola Solutions, Inc. All rights reserved



MN009326A01-AA

Contents

Legal and Support.....	6
Intellectual Property and Regulatory Notices.....	6
Legal and Compliance Statements.....	7
Supplier's Declaration of Conformity.....	7
Industry Canada WLAN Statement.....	8
Important Safety Information.....	8
Notice to Users (FCC and Industry Canada).....	9
Warranty and Service Support.....	9
Batteries and Chargers Warranty.....	9
The Workmanship Warranty.....	9
The Capacity Warranty.....	9
Limited Warranty.....	9
MOTOROLA SOLUTIONS COMMUNICATION PRODUCTS.....	9
I. WHAT THIS WARRANTY COVERS AND FOR HOW LONG:.....	9
II. GENERAL PROVISIONS.....	10
III. STATE LAW RIGHTS:.....	10
IV. HOW TO GET WARRANTY SERVICE.....	10
V. WHAT THIS WARRANTY DOES NOT COVER.....	10
VI. PATENT AND SOFTWARE PROVISIONS.....	11
VII. GOVERNING LAW.....	11
Chapter 1: Read Me First.....	12
1.1 Software Version.....	13
Chapter 2: Radio Care.....	14
Chapter 3: Radio Overview.....	15
3.1 Programmable Buttons.....	16
3.1.1 Assignable Radio Functions.....	16
Chapter 4: Getting Started.....	18
4.1 Inserting a SIM Card.....	18
4.2 Attaching the Battery.....	18
4.3 Charging the Battery.....	18
4.4 Attaching or Detaching the Antenna.....	19
Attaching the Antenna.....	19
Detaching the Antenna.....	19
4.5 Turning the Radio On or Off.....	19
4.6 Adjusting the Volume.....	19

4.7 Activating the Preconfigured Wi-Fi Access Point (PWAP).....	20
4.8 Selecting Talkgroups and Area Talkgroups.....	20
Chapter 5: Home Screen Overview.....	22
5.1 Status Indicators.....	22
5.1.1 Status Icons.....	22
5.1.2 Battery Capacity.....	24
5.1.3 LED Indicators.....	25
Chapter 6: Types of Radio Calls.....	27
6.1 Making Calls on the Radio.....	28
6.2 Receiving and Responding to Calls.....	28
Chapter 7: Instant Personal Alert.....	30
7.1 Sending IPA.....	30
7.2 Receiving and Viewing IPA.....	30
7.3 Clearing IPA Status List.....	31
Chapter 8: Voice Operating Transmission.....	32
8.1 Setting the Voice Operating Transmission.....	32
Chapter 9: Emergency Operations.....	33
9.1 Declaring Emergency.....	33
9.2 Canceling Emergency.....	33
9.3 Receiving and Responding to Emergency Alerts.....	34
9.4 Receiving and Responding to Emergency Calls.....	34
9.5 Clearing Emergency Alert List.....	35
Chapter 10: Man Down (Fall Alert).....	36
Chapter 11: Lone Worker.....	37
Chapter 12: Location.....	38
12.1 Turning Location On or Off.....	38
Turning Location On.....	38
Turning Location Off.....	38
Chapter 13: Noise Reduction.....	39
13.1 Turning Noise Reduction On or Off.....	39
Turning Noise Reduction On.....	39
Turning Noise Reduction Off.....	39
Chapter 14: Fast Scroll Talkgroup List.....	40
14.1 Accessing Fast Scroll Talkgroup List.....	40
Chapter 15: Contact List.....	41
15.1 Accessing Contact List.....	41
Chapter 16: Supervisory Override.....	42

Chapter 17: Menu	43
17.1 Accessing Menu	44
Chapter 18: Turning the Cellular On or Off	45
Turning the Cellular On	45
Turning the Cellular Off	45
Chapter 19: Turning the Wi-Fi On or Off	46
Turning the Wi-Fi On	46
Turning the Wi-Fi Off	46
Chapter 20: Turning DND On or Off	47
Turning DND On	47
Turning DND Off	47
Chapter 21: Turning Voice Announcement On or Off	48
Turning Voice Announcement On	48
Turning Voice Announcement Off	48
Chapter 22: Turning Alert Tones On or Off	49
Turning Alert Tones On	49
Turning Alert Tones Off	49
Chapter 23: Adjusting Display Brightness	50
Chapter 24: Bluetooth	51
24.1 Turning the Bluetooth On or Off	51
Turning the Bluetooth On	51
Turning the Bluetooth Off	51
24.2 Searching and Connecting to Bluetooth Devices	51
24.3 Clearing Bluetooth Pairing	52
Chapter 25: Scan	53
25.1 Turning Scan On or Off	53
Turning Scan On	53
Turning Scan Off	53
Chapter 26: Radio Stun	54
Chapter 27: Radio Kill	55
Chapter 28: User Disabled or Suspended	56
Chapter 29: Ambient Listening	57
Chapter 30: Keylock	58
30.1 Enabling and Disabling Keylock	58
Enabling Keylock	58
Disabling Keylock	58
Chapter 31: Turning the Mute Mode On or Off	59

Turning the Mute Mode On.....	59
Turning the Mute Mode Off.....	59
Chapter 32: Authorized Accessories List.....	60

Legal and Support

Intellectual Property and Regulatory Notices

Copyrights

The Motorola Solutions products described in this document may include copyrighted Motorola Solutions computer programs. Laws in the United States and other countries preserve for Motorola Solutions certain exclusive rights for copyrighted computer programs. Accordingly, any copyrighted Motorola Solutions computer programs contained in the Motorola Solutions products described in this document may not be copied or reproduced in any manner without the express written permission of Motorola Solutions.

No part of this document may be reproduced, transmitted, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, without the prior written permission of Motorola Solutions, Inc.

Trademarks

MOTOROLA, MOTO, MOTOROLA SOLUTIONS, and the Stylized M Logo are trademarks or registered trademarks of Motorola Trademark Holdings, LLC and are used under license. All other trademarks are the property of their respective owners.

License Rights

The purchase of Motorola Solutions products shall not be deemed to grant either directly or by implication, estoppel or otherwise, any license under the copyrights, patents or patent applications of Motorola Solutions, except for the normal non-exclusive, royalty-free license to use that arises by operation of law in the sale of a product.

Open Source Content

This product may contain Open Source software used under license. Refer to the product installation media for full Open Source Legal Notices and Attribution content.

European Union (EU) and United Kingdom (UK) Waste of Electrical and Electronic Equipment (WEEE) Directive



The European Union's WEEE directive and the UK's WEEE regulation require that products sold into EU countries and the UK must have the crossed-out wheeled bin label on the product (or the package in some cases). As defined by the WEEE directive, this crossed-out wheeled bin label means that customers and end-users in EU and UK countries should not dispose of electronic and electrical equipment or accessories in household waste.

Customers or end-users in EU and UK countries should contact their local equipment supplier representative or service centre for information about the waste collection system in their country.

Disclaimer

Please note that certain features, facilities, and capabilities described in this document may not be applicable to or licensed for use on a specific system, or may be dependent upon the characteristics of a specific mobile subscriber unit or configuration of certain parameters. Please refer to your Motorola Solutions contact for further information.

© 2022 Motorola Solutions, Inc. All Rights Reserved

Legal and Compliance Statements

Supplier's Declaration of Conformity

Supplier's Declaration of Conformity

Per FCC CFR 47 Part 2 Section 2.1077(a)



Responsible Party

Name: Motorola Solutions, Inc.

Address: 2000 Progress Pkwy, Schaumburg, IL. 60196

Phone Number: 1-800-927-2744

Hereby declares that the product:

Model Name: **TLK 110**

conforms to the following regulations:

FCC Part 15, subpart B, section 15.107(a), 15.107(d), and section 15.109(a)

Class B Digital Device

As a personal computer peripheral, this device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1 This device may not cause harmful interference, and
- 2 This device must accept any interference received, including interference that may cause undesired operation.



NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio or TV technician for help.

For country code selection usage (WLAN devices)



NOTE: The country code selection is for non-US model only and is not available to all US models. Per FCC regulation, all Wi-Fi products marketed in the US must be fixed to US operation channels only.

Industry Canada WLAN Statement



CAUTION:

- 1 The device for operation in the band 5150–5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems.
- 2 The maximum antenna gain permitted for devices in the bands 5250–5350 MHz and 5470–5725 MHz shall be such that the equipment still complies with the e.i.r.p. limit.
- 3 The maximum antenna gain permitted for devices in the band 5752–5850 MHz shall be such that the equipment still complies with e.i.r.p. limits specified for point-to-point and non-point-to-point operation as appropriate.
- 4 The worst case tilt angle(s) necessary to remain compliant with the e.i.r.p. elevation mask requirement set forth in Section 6.2.2 (3) shall be clearly indicated.
- 5 User should also be advised that high-power radars are allocated as primary users (i.e. priority users) of the bands 5250–5350 MHz and 5650–5850 MHz and that these radars could cause interference and/or damage to LE-LAN devices.

Important Safety Information



CAUTION:

This radio is designed to meet General Population usage. Before using the radio, read the RF Energy Exposure and Product Safety Guide that comes with the radio. This guide contains operating instructions for safe usage, RF energy awareness, and control for compliance with applicable standards and regulations.

Any modification to this device, not expressly authorized by Motorola Solutions, may void the user's authority to operate this device.

For Japan, the device is restricted to indoor use only when operating in the 5150 to 5350 MHz frequency range, except for transmission with 5.2 GHz High Power Data Communication System base Station or Relay Station.

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

This radio transmitter has been approved by Industry Canada to operate with Motorola Solutions-approved antenna with the maximum permissible gain and required antenna impedance for each antenna type indicated. Antenna types not included in this list, having a gain greater than the maximum gain indicated for that type, are strictly prohibited for use with this device.

This radio transmitter 109U-89FT7166 has been approved by Innovation, Science and Economic Development Canada to operate with the antenna types listed in [Authorized Accessories List on page 60](#), with the maximum permissible gain indicated. Antenna types not included in the list that have a gain greater than the maximum gain indicated for any type listed are strictly prohibited for use with this device.

Notice to Users (FCC and Industry Canada)

This device complies with Part 15 of the FCC rules and Industry Canada's license-exempt RSS's per the following conditions:

- This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation.
- Changes or modifications made to this device, not expressly approved by Motorola Solutions, could void the authority of the user to operate this equipment.

Warranty and Service Support

Batteries and Chargers Warranty

The Workmanship Warranty

The workmanship warranty guarantees against defects in workmanship under normal use and service.

TLK 110 Batteries	12 Months
-------------------	-----------

The Capacity Warranty

The capacity warranty guarantees 80% of the rated capacity for the warranty duration.

Lithium-Ion (Li-Ion) Batteries	12 Months
--------------------------------	-----------

Limited Warranty

MOTOROLA SOLUTIONS COMMUNICATION PRODUCTS

I. WHAT THIS WARRANTY COVERS AND FOR HOW LONG:

Motorola Solutions, Inc. ("Motorola Solutions") warrants the Motorola Solutions manufactured Communication Products listed below ("Product") against defects in material and workmanship under normal use and service for a period of time from the date of purchase as scheduled below:

Portable Radio	1 Year
Product Accessories	1 Year

Motorola Solutions, at its option, will at no charge either repair the Product (with new or reconditioned parts), replace it (with a new or reconditioned Product), or refund the purchase price of the Product during the warranty period provided it is returned in accordance with the terms of this warranty. Replaced parts or boards are warranted for the balance of the original applicable warranty period. All replaced parts of Product shall become the property of Motorola Solutions.

This express limited warranty is extended by Motorola Solutions to the original end user purchaser only and is not assignable or transferable to any other party. This is the complete warranty for the Product manufactured by Motorola Solutions. Motorola Solutions assumes no obligations or liability for additions or modifications to this warranty unless made in writing and signed by an officer of Motorola Solutions.

Unless made in a separate agreement between Motorola Solutions and the original end user purchaser, Motorola Solutions does not warrant the installation, maintenance or service of the Product.

Motorola Solutions cannot be responsible in any way for any ancillary equipment not furnished by Motorola Solutions which is attached to or used in connection with the Product, or for operation of the Product with any ancillary equipment, and all such equipment is expressly excluded from this warranty. Because each system which may use the Product is unique, Motorola Solutions disclaims liability for range, coverage, or operation of the system as a whole under this warranty.

II. GENERAL PROVISIONS

This warranty sets forth the full extent of Motorola Solutions responsibilities regarding the Product. Repair, replacement or refund of the purchase price, at Motorola Solutions option, is the exclusive remedy. THIS WARRANTY IS GIVEN IN LIEU OF ALL OTHER EXPRESS WARRANTIES. IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION, IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY. IN NO EVENT SHALL MOTOROLA SOLUTIONS BE LIABLE FOR DAMAGES IN EXCESS OF THE PURCHASE PRICE OF THE PRODUCT, FOR ANY LOSS OF USE, LOSS OF TIME, INCONVENIENCE, COMMERCIAL LOSS, LOST PROFITS OR SAVINGS OR OTHER INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE SUCH PRODUCT, TO THE FULL EXTENT SUCH MAY BE DISCLAIMED BY LAW.

III. STATE LAW RIGHTS:

SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES OR LIMITATION ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION OR EXCLUSIONS MAY NOT APPLY.

This warranty gives specific legal rights, and there may be other rights which may vary from state to state.

IV. HOW TO GET WARRANTY SERVICE

You must provide proof of purchase (bearing the date of purchase and Product item serial number) in order to receive warranty service and, also, deliver or send the Product item, transportation and insurance prepaid, to an authorized warranty service location. Warranty service will be provided by Motorola Solutions through one of its authorized warranty service locations. If you first contact the company which sold you the Product (for example, dealer or communication service provider), it can facilitate your obtaining warranty service. You can also call Motorola Solutions at 1-800-927-2744.

V. WHAT THIS WARRANTY DOES NOT COVER

- 1** Defects or damage resulting from use of the Product in other than its normal and customary manner.
- 2** Defects or damage from misuse, accident, water, or neglect.
- 3** Defects or damage from improper testing, operation, maintenance, installation, alteration, modification, or adjustment.
- 4** Breakage or damage to antennas unless caused directly by defects in material workmanship.
- 5** A Product subjected to unauthorized Product modifications, disassembles or repairs (including, without limitation, the addition to the Product of non-Motorola Solutions supplied equipment) which adversely affect performance of the Product or interfere with Motorola Solutions normal warranty inspection and testing of the Product to verify any warranty claim.
- 6** Product which has had the serial number removed or made illegible.

- 7 Rechargeable batteries if:
 - any of the seals on the battery enclosure of cells are broken or show evidence of tampering.
 - the damage or defect is caused by charging or using the battery in equipment or service other than the Product for which it is specified.
- 8 Freight costs to the repair depot.
- 9 A Product which, due to illegal or unauthorized alteration of the software/firmware in the Product, does not function in accordance with Motorola Solutions published specifications or the FCC certification labeling in effect for the Product at the time the Product was initially distributed from Motorola Solutions.
- 10 Scratches or other cosmetic damage to Product surfaces that does not affect the operation of the Product.
- 11 Normal and customary wear and tear.

VI. PATENT AND SOFTWARE PROVISIONS

Motorola Solutions will defend, at its own expense, any suit brought against the end user purchaser to the extent that it is based on a claim that the Product or parts infringe a United States patent, and Motorola Solutions will pay those costs and damages finally awarded against the end user purchaser in any such suit which are attributable to any such claim, but such defense and payments are conditioned on the following:

- 1 Motorola Solutions will be notified promptly in writing by such purchaser of any notice of such claim,
- 2 Motorola Solutions will have sole control of the defense of such suit and all negotiations for its settlement or compromise, and
- 3 Should the Product or parts become, or in Motorola Solutions opinion be likely to become, the subject of a claim of infringement of a United States patent, that such purchaser will permit Motorola Solutions, at its option and expense, either to procure for such purchaser the right to continue using the Product or parts or to replace or modify the same so that it becomes non-infringing or to grant such purchaser a credit for the Product or parts as depreciated and accept its return. The depreciation will be an equal amount per year over the lifetime of the Product or parts as established by Motorola Solutions.

Motorola Solutions will have no liability with respect to any claim of patent infringement which is based upon the combination of the Product or parts furnished hereunder with software, apparatus or devices not furnished by Motorola Solutions, nor will Motorola Solutions have any liability for the use of ancillary equipment or software not furnished by Motorola Solutions which is attached to or used in connection with the Product. The foregoing states the entire liability of Motorola Solutions with respect to infringement of patents by the Product or any parts thereof.

Laws in the United States and other countries preserve for Motorola Solutions certain exclusive rights for copyrighted Motorola Solutions software such as the exclusive rights to reproduce in copies and distribute copies of such Motorola Solutions software. Motorola Solutions software may be used in only the Product in which the software was originally embodied and such software in such Product may not be replaced, copied, distributed, modified in any way, or used to produce any derivative thereof. No other use including, without limitation, alteration, modification, reproduction, distribution, or reverse engineering of such Motorola Solutions software or exercise of rights in such Motorola Solutions software is permitted. No license is granted by implication, estoppel or otherwise under Motorola Solutions patent rights or copyrights.

VII. GOVERNING LAW

This Warranty is governed by the laws of the State of Illinois, U.S.A.

Chapter 1

Read Me First

This user guide covers the basic operations of the radio models offered in your region.

Notations Used in This Manual

Throughout the text in this publication, you notice the use of **Warning**, **Caution**, and **Notice**. These notations are used to emphasize that safety hazards exist, and the care that must be taken or observed.



WARNING: An operational procedure, practice, or condition, and so on, which may result in injury or death if not carefully observed.



CAUTION: An operational procedure, practice, or condition, and so on, which may result in damage to the equipment if not carefully observed.



NOTE: An operational procedure, practice, or condition, and so on, which is essential to emphasize.

Special Notations

The following special notations are used throughout the text to highlight certain information or items:

Table 1: Special Notations

Example	Description
Menu key or PTT button	Bold words indicate a name of a key, button, or soft menu item.
Your radio shows Bluetooth On.	Typewriter words indicate the MMI strings or messages displayed on your radio.
<required ID>	The courier, bold, italic, and angle brackets indicate user input.
Setup→Tone→All Tones	Bold words with the arrow in between indicate the navigation structure in the menu items.

Feature and Service Availability

Your dealer or administrator may have customized your radio for your specific needs.



NOTE: Not all features in the manual are available in your radio. Contact your dealer or administrator for more information.

You can consult your dealer or system administrator about the following:

- What are the functions of each button?
- Which optional accessories may suit your needs?
- What are the best radio usage practices for effective communication?
- What maintenance procedures promote longer radio life?

1.1

Software Version

All the features described in the following sections are supported by the software version **R01.00.00** or later.

Contact your dealer or administrator for more information.

Chapter 2

Radio Care

This section describes the basic handling precaution of the radio.

Table 2: IP Specification

IP Specification	Description
IP67	Allows your radio to withstand adverse field conditions such as being submersed in water between 15 cm and 1 m for 30 minutes or dust tight for 2–8 hours.

- If your radio has been submersed in water, shake your radio well to remove any water that may be trapped inside the speaker grille and microphone port. Trapped water could cause decreased audio performance.
- If your radio's battery contact area has been exposed to water, clean and dry battery contacts on both your radio and the battery before attaching the battery to radio. The residual water could short-circuit the radio.
- If your radio has been submersed in a corrosive substance (for example, saltwater), rinse radio and battery in fresh water then dry radio and battery.
- To clean the exterior surfaces of your radio, use a diluted solution of mild dishwashing detergent and fresh water (for example, one teaspoon of detergent to one gallon of water).
- Never poke the vent (hole) located on the radio chassis below the battery contact. This vent allows for pressure equalization in the radio. Doing so may create a leak path into radio and your radio's submersibility may be lost.
- Never obstruct or cover the vent, even with a label.
- Ensure that no oily substances come in contact with the vent.
- Your radio with antenna attached properly is designed to be submersible to a maximum depth of 1 m (3.28 ft) and a maximum submersion time of 30 minutes. Exceeding either maximum limit or use without antenna may result in damage to your radio.
- When cleaning your radio, do not use a high-pressure jet spray on radio as this will exceed the 1 m depth pressure and may cause water to leak into your radio.

Chapter 3

Radio Overview

This chapter explains the buttons and default functions of your radio.



Table 3: Radio Overview

Label	Name	Description
1	Emergency Button	To turn the Emergency Operations on and off.
2	Talkgroup Scroll Rocker	Press: Scroll to next talkgroup in the list. Press and hold: If there are more than 16 talkgroups, fast scroll is enabled.

Label	Name	Description
3	LED Status Indicator	Red, green, and amber light-emitting diodes indicate operating status.
4	Power button	Turn the radio on and off.
5	Push-to-Talk (PTT) button	Press or press and hold to execute voice operations.
6	Menu/Programmable button	Press: Access Menu mode. Press and hold: Access Programmable Function.
7	Volume Up and Volume Down buttons	Increase and decrease the volume level.
8	Charging Contacts	For charging purposes.
9	Liquid Crystal Display (LCD)	132 x 36 display resolutions provides visual information about many radio features

3.1

Programmable Buttons

You can program the programmable buttons as shortcuts to specific radio functions through WAVE portal.

Depending on the duration of a button press, the programmable buttons function differently.

3.1.1

Assignable Radio Functions

The following radio functions can be assigned to the programmable buttons by your dealer.



NOTE: Not all programmable buttons are listed in the following list. Refer to the portal for more information.

Alert Tones

Allows you to toggle the Alert Tones on and off.

Bluetooth

Allows you to toggle the Bluetooth on and off.

Cellular

Allows you to toggle the Cellular on and off.

Contact List

Allows you to directly access the Contact List.

Do Not Disturb (DND)

Allows you to toggle between on and off.

Keypad Lock

Allows you to toggle the keypad to lock or unlock.

Location

Allows you to toggle the Location on and off.

Mute/Unmute

Allows you to turn Mute Mode on or off.

Menu

Allows you to access the menu features.

Noise Reduction

Allows you to toggle the Noise Reduction to on or off.

Scan

Allows you to toggle the Scan on and off.

Voice Announcements

Allows you to toggle Voice Announcements on and off.

Wi-Fi

Allows you to toggle the Wi-Fi on and off.

Chapter 4

Getting Started

This chapter provides instructions on how to prepare your radio for use.

4.1

Inserting a SIM Card

Prerequisites: Turn off your radio.

Procedure:

- 1 Remove the battery.
- 2 Lift the SIM card slot cover.
- 3 With the contacts facing down, align the card notched end first and slide the SIM card into the slot.



NOTE:

Depending on your radio model, if your radio has the SIM card slot, you can insert the SIM card as instructed. At any time, peeling off the radio label voids the warranty.

4.2

Attaching the Battery

Procedure:

- 1 Align the battery contacts with the contacts inside the battery compartment.
 - a Insert the contact side of the battery first.
 - b Gently push the battery into place.
- 2 Attach the battery cover by aligning it in place and slide the battery latch until it snaps into place.
- 3 Slide the battery latch into lock position.

4.3

Charging the Battery

Your radio is powered by a Lithium-Ion (Li-Ion) battery.

Prerequisites: Turn off your radio when charging.

Procedure:

- To comply with warranty terms and avoid damages, charge the battery using a Motorola Solutions charger exactly as described in the charger user guide.
- Charge a new battery 4 to 5 hours before initial use for best performance.

Batteries charge best at room temperature.



NOTE: All Motorola Solutions chargers can charge only Motorola Solutions authorized batteries.

4.4

Attaching or Detaching the Antenna

Attaching the Antenna

Procedure:

- 1 Set the antenna in the receptacle.
- 2 Turn the antenna clockwise.



CAUTION: To prevent damages, only use the authorized antenna for [TLK 110 antennas](#).

Detaching the Antenna

Procedure:

- 1 Turn the antenna counterclockwise.
- 2 Remove the antenna from the receptacle.

4.5

Turning the Radio On or Off

Procedure:

Press and hold the **Power** button.

If your radio turns on, your radio shows the following indications:

- The green LED illuminates.
- The home screen lights up.

If your radio turns off, your radio shows the following indications:

- A tone sounds.
- The display shows `Powering off`

4.6

Adjusting the Volume

Procedure:

- 1 Perform one of the following actions:
 - To increase the volume level, press the **Volume Up** button.
 - To decrease the volume level, press the **Volume Down** button.



NOTE:

- The maximum volume level through the internal speaker or a wired accessory is 10. The maximum volume is increased to 15 if a Bluetooth accessory is attached.
- For PMLN8191, 1-Wire Enhanced Clear Tube Earpiece, the display shows a safety warning message if you attempt to increase the volume from 9 to 10.

4.7

Activating the Preconfigured Wi-Fi Access Point (PWAP)

This feature provides a temporary Wi-Fi connection for the radio to download the configurations from the portal. Instead of the manual configuration through the Maintenance Mode Web Server, you can use the preconfigured Wi-Fi access point for initial Wi-Fi connection.

Prerequisites:

Ensure your radio is in the User Mode and has no internet connection.



NOTE: The following are the preconfigured Wi-Fi Access Point settings supported by the radio.

SSID	Password
WaveRadio	RadioManagement

Procedure:

To connect to the PWAP, press the **Menu/ Programmable** button and **Volume Up** button simultaneously.

If the radio successfully connects to the PWAP, your radio shows the following indications:

- A positive tone sounds.
- The display shows `PWAP` for 2 seconds.

Radio downloads the provisioned Wi-Fi Settings from the server and overwrites the preconfigured Wi-Fi setting.



NOTE: The preconfigured Wi-Fi setting is cleared when the radio is rebooted or when the Wi-Fi is disabled.

4.8

Selecting Talkgroups and Area Talkgroups

Procedure:

- 1 From the Home screen, perform one of the following actions:

Option	Actions
Selecting the previous or next talkgroup	Press Talkgroup Scroll Rocker .
Fast scrolling the talkgroup list	Press and hold Talkgroup Scroll Rocker until you reach the required talkgroup.
Selecting the required area talkgroup	a By using the Talkgroup Scroll Rocker , scroll past the talkgroup list or beginning of the talkgroup list.

Option	Actions
	b At the area talkgroup list, select the required area talkgroup.  NOTE: If you scroll past the talkgroup list, the area talkgroup list is arranged alphabetically. If you scroll past the beginning of the talkgroup list, the area talkgroup is arranged in a reverse alphabetical order.

If you have reached the end of the talkgroup and area talkgroup list, and enter the beginning of the list again, your radio shows the following indications:

- A tone sounds.
- The display shows the first talkgroup.

If selecting a talkgroup or an area talkgroup is unsuccessful, your radio shows the following indications:

- A negative indicator tone sounds.
- The display shows the previous talkgroup.
- The voice announcement sounds.

Chapter 5

Home Screen Overview



Table 4: Home Screen Overview

Label	Name	Description
1	Status Bar	Status icons appear in the status bar to provide your radio status and feature notifications.
2	Alphanumeric Display ¹	Displays Talkgroup errors, trunking statuses, and call states. Supports the following screen patterns: • Static • Scroll In • Alternate

5.1

Status Indicators

Status Indicators explain the Icons, battery capacity information, and LED indicators used in your radio.

5.1.1

Status Icons

These icons appear at the status bar to provide radio-specific information or status.

Icon	Name	Description
 to 	Cellular Network Strength	Your radio is connected to a cellular network. The number of bars represents the signal strength of the cellular network.
	Cellular Network Not Connected	Your radio is not connected to a cellular network.

¹ This product is equipped with RICOH Bitmap Font which produced and sold by RICOH Industrial Solutions Inc.

Icon	Name	Description
	Cellular Network Unavailable	Cellular Network is not available.
	Wi-Fi Network Strength	Your radio is connected to a Wi-Fi network. The number of bars represents the signal strength of the Wi-Fi network.
	Wi-Fi Network Not Connected	Your radio is not connected to a Wi-Fi network.
	Wi-Fi Network Unavailable	Wi-Fi Network is not available.
	SIM Status	SIM card is not inserted or detected.
	Emergency	Your radio is in Emergency mode.
	Instant Personal Alert (IPA)	Your radio is receiving Instant Personal Alert (IPA).
	Do Not Disturb (DND)	Your radio is in Do Not Disturb (DND) status.
	Area Based Talkgroup	Area Based Talkgroup feature is enabled.
	Scan	Scan feature is enabled.
	Mute	Mute is enabled and speaker is muted.
	Bluetooth	The Bluetooth feature is enabled. A dot appears next to Bluetooth icon when a remote Bluetooth device is connected.
		
	Location	Location is enabled and its signal is available.
	Software Status	Software is available when the display shows a check mark icon. Your radio is downloading software when the display shows a downward arrow icon.

Icon	Name	Description
		
	Diagnostics Log Status	Logs are available when the display shows a check mark icon. Your radio is currently uploading logs when the display shows an upward arrow.
		
	Voice Operating Transmission (VOX)	Voice Operating Transmission (VOX) feature is enabled.
	Man Down/Lone Worker	Man Down/Lone Worker feature is enabled.
 to 	Battery Status	The number of bars shown indicates the charge remaining in the battery.
	Battery Charge	Battery is charging when lightning icon displayed.
	Language Change	Your radio is switching the language.

5.1.2

Battery Capacity

The following table provides the battery capacity information of your radio. Icons and LED Indication appear when you press Power/Info button.

Table 5: Battery Capacity

Icon	LED Indication	Voice Announcement	Description
	Charging LED is shown	—	Battery charging
	● Solid green	Battery high	80%–100% capacity
	● Solid red	Battery medium	60%–80% capacity
	● Solid red	Battery medium	25%–60% capacity
	● Solid red	Battery low	5%–25% capacity

Icon	LED Indication	Voice Announcement	Description
	 Blinking red	Battery very low	Less than 5% capacity

5.1.3

LED Indicators

The LED Indicators show the operational status of your radio.

Table 6: LED Indications

Indication	Status
Solid Red	- Indicates the following radio battery levels: - High - Medium - Low
Blinking Red	- The radio has moved out of range and receives no network connection. - The radio is in Man Down mode. - The radio is in Lone Worker respond duration. - The user account is disabled or suspended. - Indicates radio battery level when battery is critically low.
Solid Yellow	The radio declares an Emergency Alert.
Blinking Yellow	- The radio is scanning for activity. - The radio is receiving a Call Alert. - The radio is receiving a declared or canceled Emergency alert. - The radio has not cleared all Emergency or Instant Personal Alerts received from the list.
Slow Blinking Yellow	The radio is receiving an Instant Personal Alert.
Solid Green	- The radio is powering up. - The radio is transmitting. - Indicates full battery capacity when the radio is charging. - The radio is in an Emergency Group/Private call. - The radio is Ambient Listening.
Blinking Green	- The radio is receiving a call. - The radio enters a call-hang time. - The radio is sending an Instant Personal Alert. - The radio enters Area Based Talkgroup. - The radio is receiving an Emergency Group/Private call.

Indication	Status
Blinking Green and Yellow	Radio is in Do Not Disturb (DND) mode.

Chapter 6

Types of Radio Calls

There are several ways that you can make a call with your radio depending on the types of calls and system available on your radio.

Table 7: Types of Radio Calls

Call Type	Description
Group Call	A Group Call is a point-to-multipoint call operation. Your radio must be configured as a member of the group for you to communicate with each other.
Private Call	A Private Call is a call from an individual radio to another individual radio. You can set up a Private Call after performing a radio presence check or call immediately.
Broadcast Call	A Broadcast Call is a one-way voice call from any user to an entire talkgroup. The Broadcast Call feature allows only the call initiating user to transmit to the talkgroup, while the recipients of the call cannot respond.
Area Based Talkgroup Call	When you enter a geographic area, you are able to view, and hear the notifications for the talkgroup area in that geofence. The Area Based Talkgroup is added to the Area Based Talkgroup List in alphabetical order. Once you are added to the Area Based Talkgroup List, your radio receives calls from both Area Based Talkgroup and the Talkgroup I before you enter into the Area Based Talkgroup zone. You can navigate through the Talkgroup Channel List and into the Area Based Talkgroup List. The Talkgroup Number is not displayed when you are in the Area Based Talkgroup. When you are in the Area Based Talkgroup, your radio shows the following indications. • The green LED blinks. • The display shows the talkgroup alias. • The voice announcement sounds. When you are exiting the Area Based Talkgroup, your radio shows the following indications. • The display shows the talkgroup alias. • The voice announcement sounds. If you are in a call when you are exiting the Area Talkgroup, the call continues without dropping. When the call is finally ended, your radio then exit the Area Based Talkgroup.

6.1

Making Calls on the Radio

Procedure:

- 1 Perform one of the following actions:
 - To make a group call, an area based talkgroup call, or a broadcast call, select the **<required Talkgroup>** using the **Talkgroup Scroll Rocker**.
 - To make a private call, from the menu, select **Contacts List**→**<required Contact>**.
- 2 To call, press and hold the **PTT** button.

For broadcast call, the display shows a countdown from 3, 2, and 1.

If the **PTT** button is released before the countdown completes, the call is not initiated.

- 3 Wait for the Talk Permit Tone to end, and speak into the microphone.



NOTE: If the recipient is busy or the server is synchronizing, the Talk Prohibit Tone sounds until the **PTT** button is released.

- 4 To listen, release the **PTT** button.



NOTE: This step is not applicable for broadcast call.

For group call or area based talkgroup call, your radio shows the following indications when entering hang time.

- The green LED blinks.
- The display shows the talkgroup name.

For private call, your radio shows the following indications when entering hang time.

- The green LED blinks.
- The display shows `Private Call`.

- 5 To end a private call, perform one of the following actions.
 - Wait for the private call hang time to expire.
 - Press and hold the **Menu/Programmable** button.

6.2

Receiving and Responding to Calls

When you receive calls, your radio shows the following indications:

- A tone sounds.
- The green LED blinks.
- Your radio unmute and the incoming call sound through the speaker.
- For group call, the display shows Talkgroup number followed by the caller alias.

- For private call, broadcast call, and area based talkgroup call, the display shows the caller alias.



NOTE: For Broadcast Call, you are not allowed to Talkback. If you attempt to talkback, the Talkback Prohibit tone sounds when the **PTT** button is pressed.

Procedure:

Perform one of the following actions:

Option	Actions
Responding to calls	a Press and hold the PTT button. b Wait for the Talk Permit Tone to end, and speak into the microphone. c To listen, release the PTT button.
Rejecting a private call	Press and hold the Menu/Programmable button.

Chapter 7

Instant Personal Alert

Instant Personal Alert (IPA) is a notification that you can send to a contact that is busy or unable to reply to a group or private call.

When you received an IPA, your radio sounds a tone and displays an icon and the sender alias.

The IPA received is stored in the IPA Status List and allows you to view and reply at any time. When multiple IPAs are received, the latest IPA will appear at the top of the list. The IPA Status List can store up to nine alerts.

An IPA can be received from contacts outside your Contact List.

If you have a private call with the sender of the IPA, then the IPA is automatically cleared.

7.1

Sending IPA

Procedure:

- 1 From the menu, select **Contact List**→<*required alias*>.
- 2 To send IPA, press and hold the **Menu/Programmable**.

If your IPA is sent, your radio shows the following indications:

- A tone sounds.
- Your screen displays `Alert Sent`.

If your IPA is not sent, your radio shows the following indications:

- A tone sounds.
- Your screen displays `Alert Failed`.

7.2

Receiving and Viewing IPA

When you receive an IPA during idle mode, your radio shows the following indications:

- The IPA is added to the IPA Status List.
- A tone sounds.
- The amber LED blinks until IPA is cleared.
- The display shows the IPA icon and alias.

When you receive an IPA during a call, your radio shows the following indications:

- The IPA is added to the IPA Status List.
- A tone sounds.
- The amber LED blinks until IPA is cleared.
- The display shows the IPA icon and alias.
- There are no visible/audible indicators while the call is in progress.

- After the call, the LED indicator flashes if the IPA has the highest priority at the time.



NOTE:

If you receive multiple IPAs from the same contact, there will only be one entry in the IPA list with the latest IPA at the top.

If you receive an IPA from someone not in your Contacts List, ? is displayed before their alias.

Procedure:

- 1 To view the IPA list, from the menu, select **Instant Personal Alert List**.
- 2 Scroll through the IPA list using **Talkgroup Scroll Rocker** or **Volume Up and Volume Down**.



NOTE: The IPA list consists up to nine IPA entries.

When the list is reaching the end or the beginning, a tone sounds.

7.3

Clearing IPA Status List

Procedure:

Perform one of the following actions:

- From the **Contact list** or **IPA list**, select the contact that you want to clear and press and hold the **PTT** button to make a call.
- In the IPA Status List, press and hold the **Menu/Programmable** button on the contact that you want to clear.
- Power cycle your radio to clear all the IPAs.

When all IPAs are cleared, your radio shows the following indications:

- The LED indicator stops blinking.
- The IPA list will no longer be displayed.

Chapter 8

Voice Operating Transmission

Voice Operating Transmission (VOX) allows you to initiate hands-free voice-activated calls on a programmed Talkgroup. When your VOX-capable accessory detects voice, your radio automatically transmits for a programmed period.

VOX is unable to initiate hands-free voice-activated calls if your radio is connected to any Bluetooth accessories.



NOTE: VOX does not support internal microphone, Bluetooth accessories, or wired radio speaker microphone. VOX is only supported on VOX capable wired earpiece accessories.

8.1

Setting the Voice Operating Transmission

Procedure:

- 1 From the menu, select **VOX**.
- 2 Perform one of the following actions:
 - To enable VOX, select **On**.
 - To disable VOX, select **Off**.

Chapter 9

Emergency Operations

Emergency Alert are used to indicate critical situations. You can initiate an Emergency Alert at any time even when there is activity on the current Talkgroup.

During the Emergency mode, any call launched is declared as Emergency Call.

9.1

Declaring Emergency

Procedure:

To declare emergency locally, press and hold the **Emergency** button.

The display shows a countdown from 3, 2, 1, and `Declaring...` with increasing tone. You can release the Emergency button during the countdown to stop the process.



NOTE: You can also declare an Emergency remotely by an authorized user through WAVE APP or a dispatcher but there is no countdown on display if done remotely.

If Emergency is declared successfully, your radio shows the following indications:

- The Emergency tone sounds.
- The amber LED illuminates.
- The display shows `Emergency`.



NOTE: When the display flashes the Emergency icon, you are only allowed to view the info screen, volume control, make an emergency call and exit the emergency mode.

If Emergency fails to declare, your radio returns to the previous screen.

9.2

Cancelling Emergency

Procedure:

To cancel emergency locally, press and hold the **Emergency** button.

The display shows a countdown from 3, 2, 1, and `Cancelling...` with increasing tone. You can release the Emergency button during the countdown to stop the process.



NOTE:

- You can also cancel an Emergency remotely by an authorized user through WAVE APP or a dispatcher but there is no countdown on display if done remotely.
- Your radio can be configured that only an authorized user can exit emergency mode.

If Emergency is canceled successfully, your radio shows the following indications:

- The Emergency tone sounds.
- Returns to the previously selected Talkgroup.
- Voice Announcement sounds.

If Emergency cancellation fails, your radio shows the following indications:

- The Emergency tone sounds.
- The amber LED illuminates.
- The display shows `Emergency`

9.3

Receiving and Responding to Emergency Alerts

When you receive a Declared-Emergency Alert, your radio shows the following indications:

- The Emergency tone sounds.
- The amber LED blinks for 2 seconds.
- The display shows the Declared-Emergency Alert icon and the initiator's alias.



NOTE: The alert has a higher priority compare to making or receiving call.

When you receive a Cancelled-Emergency Alert, your radio shows the following indications:

- The Emergency tone sounds.
- The amber LED blinks until all Emergency Alerts are cleared from the Emergency Alert List.
- The display shows the Cancelled-Emergency Alert icon and the initiator's alias.



NOTE: The alert has a higher priority compare to making or receiving call.

Procedure:

- 1 From the menu, select **Emergency Alert List**.
- 2 To select the required Emergency Alert alias, press the **Volume Up** or **Volume Down** button.
- 3 Press **PTT** button to initiate a call.

9.4

Receiving and Responding to Emergency Calls

When you receive a Emergency Call, your radio shows the following indications:

- The Emergency tone sounds.
- The green LED illuminates
- For Group Call, the display shows the Group Name, Emergency Call icon in front of the caller alias for 2 seconds, and then scroll to Caller Alias.
- For Private Call, the display shows the Emergency Call icon and the initiator's alias.
- For Private Call, the display shows the display call type, Emergency Call icon in front of the caller alias for 2 seconds, and then scroll to Caller Alias.



NOTE: The Emergency Call has a higher priority compared to Talkgroup Call and Private Call.

Procedure:

- 1 To respond to the Emergency Call, press and hold the **PTT** button.
- 2 Wait for the Talk Permit Tone to end, and speak into the microphone.
- 3 To listen, release the **PTT** button.

9.5

Clearing Emergency Alert List

An Emergency Alert in the Emergency Alert List is cleared automatically when a corresponding Cancelled-Emergency Alert is received and if you power cycle your radio.

Procedure:

Press and hold the **Menu/Programmable** button on the Emergency Alert Alias.

- A tone sounds.
- Voice Announcement sounds.

When all Emergency Alerts clears, your radio shows the following indications:

- The amber LED extinguishes.
- Emergency Alert List icon disappears from the status bar.

Chapter 10

Man Down (Fall Alert)

The Man Down feature (henceforth known as Fall Alert) enables your radio to alert others when you are in danger.

If your radio tilts at a specified angle, is stationary for a time, or tilts and is stationary, it prompts an Alert Tone. If you do not respond to the prompt before the predefined reminder timer expires, your radio automatically sends an Emergency Alarm or Emergency Call, skipping the 3 seconds countdown.

To prevent your radio from sending an Emergency Alarm or Emergency Call, you can take the following measures:

- For Tilt Alarm, you must restore the radio to the vertical position. You may configure the threshold for the tilt angle detection of the radio to 30°, 45°, or 60°, with the default angle setting as 45°.
- For No Movement Alarm, you must move your radio. You may configure the threshold to high, medium, or low sensitivity, with the default setting set to medium sensitivity.
- For Tilt and No Movement Alarm, you must restore the radio to the vertical position or move it. Both threshold settings for Tilt and No Movement will take effect for the Tilt and No Movement Alarm. Either thresholds may trigger the man down event.

If any of the configured thresholds are exceeded consistently for the default pre-alarm timer duration of 100 seconds, your radio shows the following indications.

- A tone sounds.
- The red LED blinks for the default alarm timer duration of 10 seconds.



NOTE: Both the pre-alarm timer and the alarm timer are configurable by using the Wave OnCloud (WoC) portal from 1 to 3600 seconds.

Chapter 11

Lone Worker

This feature prompts an emergency if there is no user activity (button press or Talkgroup selector activation) for a predefined time.

When there is no user activity for a predefined time, your radio pre-warns you using an audio and LED indicator once the inactivity timer expires.

You can press any button and the timer for lone worker resets.

If there is no acknowledgment from you before the predefined reminder timer expires, your radio initiates an emergency condition, skipping the 3 seconds countdown.

Chapter 12

Location

The Global Navigation Satellite System (GNSS) integrates information from the Global Positioning System (GPS), Global Navigation Satellite System (GLONASS), BeiDou Navigation Satellite System, and Galileo to determine the approximate geographical location of your radio.

12.1

Turning Location On or Off

Turning Location On

Procedure:

- 1 From the menu, select **Location**.
- 2 To turn on Location, press the **Volume Up** button.

If Location successfully turns on, your radio shows the following indications:

- The voice announcement sounds.
- The display shows a positive mini notice.

Turning Location Off

Procedure:

- 1 From the menu, select **Location**.
- 2 To turn off Location, press the **Volume Down** button.

If Location successfully turns off, your radio shows the following indications:

- The voice announcement sounds.
- The display shows a negative mini notice.

Chapter 13

Noise Reduction

Noise Reduction feature reduces the effect of surrounding noise that affects the clarity of the intended audio for transmission.

13.1

Turning Noise Reduction On or Off

Turning Noise Reduction On

Procedure:

- 1 From the menu, select **Audio NR**.
- 2 To turn on Noise Reduction, press the **Volume Up** button.

If Noise Reduction successfully turns on, your radio shows the following indications:

- The Voice Announcement sounds.
- The display shows a positive mini notice.

Turning Noise Reduction Off

Procedure:

- 1 From the menu, select **Audio NR**.
- 2 To turn off Noise Reduction, press the **Volume Down** button.

If Noise Reduction successfully turns off, your radio shows the following indications:

- The Voice Announcement sounds.
- The display shows a negative mini notice.

Chapter 14

Fast Scroll Talkgroup List

A talkgroup list has a maximum of 96 channels.

The order of the channels are in numerical order. You can press and hold on the **Talkgroup Scroll Rocker** to perform the fast scroll. After the second channel, you can fast scroll the channels with an increment of 10.

Example: For example, if your radio has 93 channels, the increment channel change is **CH 80→CH 90→CH 93→CH 1→CH 10→Ch 20**.

14.1

Accessing Fast Scroll Talkgroup List

Procedure:

Press and hold the **Talkgroup Scroll Rocker**.

Chapter 15

Contact List

A contact name is no more than 30 alphanumeric characters and the displayed in an alphabetical order.

The contact list only supports user that are available and set to Do Not Disturb (DND). If the contact is offline, it will be hidden from the list.



NOTE: Contact your dealer for more information on the configuration.

15.1

Accessing Contact List

Procedure:

- 1 Press and hold the **Menu/Programmable** button.
- 2 For fast scroll, perform one of the following actions:
 - Press and hold the **Talkgroup Scroll Rocker**.
 - Press and hold the **Volume Up** or **Volume Down** button.

Chapter 16

Supervisory Override

Supervisory Override allows a supervisor to interrupt during an ongoing call except for Private Call and immediately start a supervisory call.

If the user is receiving or transmitting a call and the current ongoing call is interrupted by a supervisory call, your radio unmutes to the supervisory call and display the alias of the supervisor.



NOTE: Contact your dealer or administrator for more information on the configuration.

Chapter 17

Menu

You are able to access the menu through the **Menu/Programmable** button.

The following are the available features in the Menu.

Table 8: List of Features

Feature	Description
Emergency Alert List	Allows you to view and delete received emergency alerts.
Instant Personal Alert List	Allows you to view and delete received instant personal alerts.
Time	Allows you to view the local time.
Contact List	Allows you to access the contact list.
All Alert Tones	Allows you to enable and disable All Alert Tones.
Display Brightness	Allows you to adjust the display brightness on your radio.
Voice Announcements	Allows you to enable and disable the Voice Announcements.
Do Not Disturb (DND)	Allows you to change the mode of your radio from available to "do not disturb".
	 NOTE: When DND is enabled, you will not be able to receive any group call, quick group call, or private call.
Scan	Allows you to enable and disable the Scan feature.
Location	Allows you to enable and disable the Global Positioning System (GPS) feature.
Bluetooth	Allows you to enable and disable the Bluetooth.
Bluetooth Pairing	Allows you to enable and disable the Bluetooth.
Wi-Fi	Allows you to enable and disable the Wi-Fi modems.
Cellular	Allows you to enable and disable the Cellular modems.
Mute	Allows you to mute and unmute your radio.
Keylock	Allows you to lock the Talkgroup Scroll Rocker and limit the functions of the Power button and Menu/Programmable button.
VOX	Allows you to enable and disable the VOX feature.
Mandown	Allows you to enable and disable the Mandown feature.
Lone Worker	Allows you to enable and disable the Lone Worker feature.
Noise Reduction	Allows you to enable and disable the Noise Reduction feature.
Radio Name	Allows you to view your radio name.
Serial Number	Allows you to view the serial number.

17.1

Accessing Menu

Procedure:

- 1 Press the **Menu/Programmable** button.
- 2 To navigate through the menu, press the **Menu/Programmable** button.

Chapter 18

Turning the Cellular On or Off

Turning the Cellular On

Procedure:

From the menu, select **Cellular**.

If Wi-Fi turns on, your radio shows the following indications:

- The display shows a positive mini notice.
- The voice announcement sounds.

Turning the Cellular Off

Procedure:

From the menu, select **Cellular**.

If Wi-Fi turns on, your radio shows the following indications:

- The display shows a negative mini notice.
- The voice announcement sounds.

Chapter 19

Turning the Wi-Fi On or Off

Turning the Wi-Fi On

Procedure:

From the menu, select **Wi-Fi**.

If Wi-Fi turns on, your radio shows the following indications:

- The display shows a positive mini notice.
- The voice announcement sounds.

Turning the Wi-Fi Off

Procedure:

From the menu, select **Wi-Fi**.

If Wi-Fi turns off, your radio shows the following indications:

- The display shows a negative mini notice.
- The voice announcement sounds.

Chapter 20

Turning DND On or Off

Turning DND On

Procedure:

- 1 From the menu, select **Do Not Disturb (DND)**.
- 2 To turn on DND, press the **Volume Up** button.

If DND turns on, your radio shows the following indications:

- The red and amber LED blinks.
- The display shows a positive mini notice.
- The voice announcement sounds.

Turning DND Off

Procedure:

- 1 From the menu, select **Do Not Disturb (DND)**.
- 2 To turn off DND, press the **Volume Down** button.

If DND turns off, your radio shows the following indications:

- The display shows a negative mini notice.
- The voice announcement sounds.

Chapter 21

Turning Voice Announcement On or Off

Turning Voice Announcement On

Procedure:

- 1 From the menu, select **Announcement**.
- 2 To turn on Voice Announcement, press the **Volume Up** button.

If Voice Announcement successfully turns on, your radio shows the following indications:

- The display shows a positive mini notice.
- The Voice Announcement sounds.

Turning Voice Announcement Off

Procedure:

- 1 From the menu, select **Announcement**.
- 2 To turn off Voice Announcement, press the **Volume Down** button.

If Voice Announcement successfully turns off, your radio shows the following indications:

- The display shows a negative mini notice.
- The Voice Announcement sounds.

Chapter 22

Turning Alert Tones On or Off

Turning Alert Tones On

Procedure:

- 1 From the menu, select **Alert Tones**.
- 2 To turn on Alert Tones, press the **Volume Up** button.

If Alert Tones successfully turns on, your radio shows the following indications:

- The display shows a positive mini notice.
- The Voice Announcement sounds.

Turning Alert Tones Off

Procedure:

- 1 From the menu, select **Alert Tones**.
- 2 To turn off Alert Tones, press the **Volume Down** button.

If Alert Tones successfully turns off, your radio shows the following indications:

- The display shows a negative mini notice.
- The Voice Announcement sounds.

Chapter 23

Adjusting Display Brightness

Procedure:

- 1 From the menu, select **Brightness**.
- 2 Select the preferred brightness level ranging from **0** to **8**.

If brightness level is selected, your radio shows the following indications:

- The display shows brightness level.
- The Voice Announcement sounds.



NOTE:

The radio backlight turns off in idle mode. You can press the **Power button** or any other buttons to turn on the backlight.

Chapter 24

Bluetooth

This feature allows you to use your radio with a Bluetooth-enabled accessory through a Bluetooth connection. Your radio supports both Motorola Solutions and Commercially available Off-The-Shelf (COTS) Bluetooth-enabled accessory.

Bluetooth operates within a range of 10 m (32 ft) line of sight. This is an unobstructed path between your radio and your Bluetooth-enabled accessory. For high degree of reliability, Motorola Solutions recommends to not separate the radio and the accessory.

At the fringe areas of reception, both voice and tone quality start to sound "garbled" or "broken". To correct this problem, position your radio and Bluetooth-enabled accessory closer to each other (within the 10 m defined range) to re-establish clear audio reception. The Bluetooth function of your radio has maximum power of 2.5 mW (4 dBm) at the 10 m range.

Your radio can support up to three simultaneous Bluetooth connections with Bluetooth-enabled accessory of unique types. For example, a headset, a scanner, a sensor device, and a PTT-Only Device (POD). Multiple connections with Bluetooth-enabled accessory of the same type are not supported.

Refer to the user manual of your respective Bluetooth-enabled accessories for more details on the full capabilities of your Bluetooth-enabled accessory.

24.1

Turning the Bluetooth On or Off

Turning the Bluetooth On

Procedure:

From the menu, select **Bluetooth**.

If the Bluetooth is enabled, your radio shows the following indications:

- The display shows a positive mini notice.
- The voice announcement sounds.

Turning the Bluetooth Off

Procedure:

From the menu, select **Bluetooth**.

If the Bluetooth is disabled, your radio shows the following indications:

- The display shows a negative mini notice.
- The voice announcement sounds.

24.2

Searching and Connecting to Bluetooth Devices

Prerequisites:

- Ensure the Bluetooth mode is on.
- If required, update the Bluetooth accessory list in Wave OnCloud (WoC) portal.

Procedure:

From the menu, select **Bluetooth Pairing Status**.

Your radio shows the following indications:

- The display shows `Bluetooth Searching`.
- The voice announcement sounds.

If the Bluetooth device is connected to the radio, your radio shows the following indications:

- A positive tone sound.
- The display shows a positive mini notice.
- The voice announcement sounds.



NOTE:

If the connected Bluetooth device is out of range or tuned off, your radio shows the following indications:

- A negative tone sounds.
- The display returns to `Bluetooth Searching`.

24.3

Clearing Bluetooth Pairing

Procedure:

- 1 From the menu, select **Bluetooth Pairing Status**.
- 2 Scroll through the Bluetooth list using **Volume Up** or **Volume Down** buttons.
- 3 On the selected device, press and hold the **Menu/Programmable** button to clear the pairing.

If the request is successful, a positive tone sounds.

If the request is unsuccessful, a negative tone sounds.

Chapter 25

Scan

Scan allows your radio to monitor multiple Talkgroups in the programmed scan list to look for an active Talkgroup.

When in the scan mode, the system preempts an ongoing low-priority talkgroup call. Your radio unmutes to the high-priority talkgroup call. You respond to the active talkgroup when you press the **PTT** button during the programmed period (hang time) of an ongoing call from your scan list.

Pressing the **PTT** button when the radio is not in a call causes the radio to start a call on the last selected talkgroup.



NOTE: If the DND mode is enabled during the scan mode, your radio prioritizes the DND mode.

25.1

Turning Scan On or Off

Turning Scan On

Procedure:

- 1 From the menu, select **Scan**
- 2 To turn Scan on, press the **Volume Up** button.

If Scan is on, your radio shows the following indications:

- The amber LED blinks.
- The display shows a positive mini notice.
- The voice announcement sounds.

Turning Scan Off

Procedure:

To turn Scan off, press the **Volume Down** button.

If Scan is off, your radio shows the following indications:

- The display shows a negative mini notice.
- The voice announcement sounds.

Chapter 26

Radio Stun

Radio Stun indicates that your radio is disabled.

When your radio is in Radio Stun mode, all the buttons except for **Power**, **Volume Up**, and **Volume Down** buttons are disabled. All voice activity and LED indications are disabled as well.

When your radio is in Radio Stun mode, the following radio activities occur:

- Man Down feature is disabled.
- Lone Worker feature is disabled.
- Instant Personal Alert List is cleared.
- Emergency Alert List is cleared.

In powered on state, your radio displays `Radio Stun`.

Chapter 27

Radio Kill

Radio Kill indicates that your radio is permanently disabled.

In a normal Operation mode, when your radio receive a kill command, your radio turns off.

While in Kill mode, User Interface (UI) is not available on your radio and you are not able to turn on your radio. Your radio can only be re-activated by Motorola Solutions.

Contact your dealer for more information.

Chapter 28

User Disabled or Suspended

User Disabled or Suspended indicates that your account is disabled or suspended. When your account is disabled or suspended, you are not able to log in to the PTT server.

Your account can be disabled through the WAVE OnCloud portal or the authorized user.

If your account is disabled or suspended, your radio shows the following indications.

- A tone sounds.
- The red LED blinks.
- The display shows `User Disabled`.

The **Power**, **Menu/Programmable**, and **Volume Up and Down** buttons still works normally.

If you press the **PTT** button, your radio tries to log in to the PTT server. If your radio is able to connect to the PTT server, it will bring you to the normal login screen, else it will bring you back to the `User Disabled` screen.

Chapter 29

Ambient Listening

Ambient listening allows you to listen to the ambient audio of your radio during idle mode.

When you start ambient listening, your radio shows the following indications:

- A tone sounds.
- The solid green LED illuminates.
- The display shows **Listening** and the caller alias.

Ambient listening stops when call is initiated or received.

If the Voice Operating Transmission (VOX) feature is enabled when ambient listening is active, the VOX feature is temporarily disabled and is only re-enabled once the ambient listening ends.

Chapter 30

Keylock

Keylock allows you to lock the **Talkgroup Scroll Rocker** and limits the functions of the **Power** and **Menu/Programmable** button.

30.1

Enabling and Disabling Keylock

Enabling Keylock

Procedure:

From the menu, select **Keylock**.

When keylock is enabled, the following radio activities occur:

- The display shows a positive mini notice.
- The **Talkgroup Scroll Rocker** is locked.
- The **Menu/Programmable** button will only function if programmed to access Menu or Keylock.
- The **Volume Up** and **Volume Down** buttons function as usual.
- The **PTT** and **Emergency** buttons function as usual.

Disabling Keylock

Procedure:

To disable keylock, perform one of the following actions.

- Press the **Menu/Programmable Button**→**Volume Up**.
- Press the **Menu/Programmable Button**→**Volume Down**.

The display shows a negative mini notice.

Chapter 31

Turning the Mute Mode On or Off

Turning the Mute Mode On

Procedure:

From the menu, select **Mute**.

If the Mute mode is enabled, your radio shows the following indications:

- The display shows a positive mini notice.
- The voice announcement sounds.
- The radio stores the previous set volume.

Turning the Mute Mode Off

Procedure:

Perform one of the following actions:

- From the menu, select **Mute**.
- Press the **Volume Up** or **Volume Down** buttons.
- Press and hold the **Volume Up** or **Volume Down** buttons.

If the Mute mode is disabled, your radio shows the following indications:

- The display shows a negative mini notice.
- The voice announcement sounds.
- The radio volume restores to the previously set volume.

Chapter 32

Authorized Accessories List

Motorola Solutions provides the following approved accessories to improve the productivity of your digital portable two-way radio.

Table 9: Antenna

Part Number	Description
32012144001	Gray Antenna ID Band, Pack of 10 units
32012144002	Yellow Antenna ID Band, Pack of 10 units
32012144003	Green Antenna ID Band, Pack of 10 units
32012144004	Blue Antenna ID Band, Pack of 10 units
32012144005	Purple Antenna ID Band, Pack of 10 units
HKAN4005_	Antenna (North America)
HKAN4006_	Antenna (International)

Table 10: Battery

Part Number	Description
PMNN4578_	Li-Ion 2500 mAh Battery

Table 11: Carry Devices

Part Number	Description
PMLN6074_	Nylon Wrist Strap
PMLN7128_	Heavy-Duty Swivel Belt Clip
PMLN8439_	Swivel Carry Holster

Table 12: Chargers

Part Number	Description
PMKN4294_	USB-C to USB-A Cable
PS000150A31	USB-A, 1.5 A Power Supply Wall Charger, USA/Japan
PS000150A32	USB-A, 1.5 A Power Supply Wall Charger, Europe
PS000150A33	USB-A, 1.5 A Power Supply Wall Charger, United Kingdom/Hong Kong
PS000150A34	USB-A, 1.5 A Power Supply Wall Charger, Australia/New Zealand
PS000150A35	USB-A, 1.5 A Power Supply Wall Charger, Argentina
PS000150A37	USB-A, 1.5 A Power Supply Wall Charger, Korea
PS000150A38	USB-A, 1.5 A Power Supply Wall Charger, Brazil

Table 13: Earbuds and Earpieces

Part Number	Description
PMLN7156_	Earbud with In-line Mic/Push-To-Talk (PTT), MagOne
PMLN7159_	Adjustable D-Style with In-Line Mic and PTT
PMLN7189_	Swivel Earpiece with In-line Microphone and PTT
PMLN7157_	2-Wire with Transparent Tube, Black
PMLN7158_	1-Wire Surveillance Earpiece, In-Line Mic, and PTT
PMLN8191_	1-Wire Enhanced Clear Tube Earpiece, 2.5 mm Single Pin, Angled
PMMN4127_	Operational Critical Wireless Remote Speaker Mic WM500
PMLN7560_	Receive Only Earpiece with Translucent Tube
PMLN8123_	EP910W Operational Critical Wireless Earpiece PTT
PMLN8298_	WP300 Wireless Bluetooth Control PTT Pod
PMLN8077_	Over-the-Ear Earpiece, Single Pin
PMLN8125_	Over-the-Ear Earpiece, Single Pin, Short Cord
PMLN8190_	1-Wire Enhanced Clear Tube Earpiece, 2.5 mm Single Pin, Straight
5080384F72	Replacement Foam Plug-ins
RLN6282_	Replacement Ear Tips
RLN6242_	Quick Disconnect Acoustic Tube

Table 14: Remote Speaker Microphones

Part Number	Description
PMMN4125_	RM250 Remote Speaker Microphone

Table 15: Miscellaneous Accessories

Part Number	Description
HKLN4690_	Battery Door

© 2022 Motorola Solutions, Inc. Tous droits réservés

Déclarations juridiques et de conformité

Déclaration de conformité du fournisseur

Déclaration de conformité du fournisseur

Règlement CFR 47, partie 2, section 2.1077(a) de la FCC



Partie responsable

Nom : Motorola Solutions, Inc.

Adresse : 2000 Progress Pkwy, Schaumburg, IL. 60196

Numéro de téléphone : 1 800 927-2744

Déclare par les présentes que le produit :

Nom du modèle : **TLK 110**

est conforme aux réglementations suivantes :

Partie 15, sous-partie B, section 15.107(a), 15.107(d) et section 15.109(a) des règlements de la FCC

Appareil numérique de classe B

En tant que périphérique d'ordinateur personnel, cet appareil est conforme aux dispositions de la partie 15 des règlements de la FCC. Son utilisation est assujettie aux deux conditions suivantes :

- 1 Cet appareil ne doit pas causer d'interférence nuisible; et

- 2 Cet appareil doit accepter toute interférence reçue, y compris les interférences pouvant entraîner un fonctionnement indésirable.



REMARQUE :

Cet équipement a fait l'objet de tests et a été déclaré conforme aux limites établies pour un appareil numérique de classe B, conformément à la section 15 des règlements de la FCC. Ces limites sont fixées afin d'offrir une protection suffisante contre des interférences nuisibles dans une installation résidentielle. Cet équipement génère, utilise et peut émettre de l'énergie de radiofréquence et, s'il n'est pas installé ou utilisé conformément aux instructions, il peut provoquer un brouillage nuisible aux communications radio. Cependant, il est impossible de garantir qu'il n'y aura aucune interférence dans une installation particulière.

Si cet appareil cause une interférence nuisible à la réception de la radio ou de la télévision, ce qui peut être déterminé en éteignant et en allumant l'appareil, vous êtes encouragé à remédier à la situation en prenant une ou plusieurs des mesures suivantes :

- Réorienter ou déplacer l'antenne réceptrice.
- Augmenter la distance entre l'équipement et le récepteur.
- Brancher l'appareil dans une autre prise sur un circuit différent de celui du récepteur.
- Consulter le distributeur ou un technicien de radio ou de télévision chevronné pour obtenir de l'aide.

Pour un usage en fonction de la sélection du code de pays (appareils WLAN)



REMARQUE :

La sélection du code de pays est pour les modèles non É.-U. seulement et n'est pas disponible sur tous les modèles américains. Conformément à la réglementation de la FCC, tous les produits Wi-Fi commercialisés aux États-Unis doivent être fixés sur des canaux fonctionnant aux États-Unis uniquement.

Consignes de sécurité importantes

ATTENTION!

Cet appareil est conçu pour l'utilisation par le grand public. Avant d'utiliser l'appareil, lisez le guide Exposition aux radiofréquences et sécurité du produit inclus avec l'appareil. Ce guide contient d'importantes instructions de fonctionnement pour une utilisation sécuritaire et des informations sur l'exposition aux radiofréquences, dans le but d'assurer votre conformité aux normes et règlements en vigueur.

Toute modification apportée à cet appareil sans l'autorisation explicite de Motorola Solutions peut annuler l'autorisation d'utiliser l'appareil.

Pour le Japon, l'appareil ne peut être utilisé qu'à l'intérieur, dans la plage de fréquences de 5 150 à 5 350 GHz, sauf pour la transmission avec la station de base du système de communication de données haute puissance de 5,2 GHz ou la station de relais.

Selon la réglementation d'Industrie Canada, l'émetteur de cet appareil ne peut être utilisé qu'avec une antenne dont le type et le gain maximal (ou minimal) sont approuvés par Industrie Canada pour cet émetteur. Afin de limiter les interférences de l'appareil pour les autres utilisateurs, le type et le gain de l'antenne doivent être choisis de façon à ce que la puissance isotrope rayonnée équivalente (p.i.r.e) ne soit pas plus forte qu'il ne le faut pour établir la communication.

L'émetteur de cet appareil a été approuvé par Industrie Canada pour utilisation avec une antenne approuvée par Motorola Solutions offrant le gain maximal autorisé et l'impédance requise pour le type d'antenne indiqué. Il est strictement interdit d'utiliser avec cet appareil tout type d'antenne ne figurant pas dans cette liste et présentant un gain supérieur au maximum indiqué pour le type.

Le présent émetteur radio 109U-89FT7166 a été approuvé par Innovation, Sciences et Développement économique Canada pour fonctionner avec les types d'antenne énumérés dans la liste des accessoires autorisés et ayant un gain admissible maximal. Les types d'antenne non inclus dans cette liste, et dont le gain est supérieur au gain maximal indiqué pour tout type figurant sur la liste, sont strictement interdits pour l'exploitation de l'émetteur.

Déclaration relative au WLAN (Industrie Canada)



MISE EN GARDE :

- 1 L'appareil fonctionnant dans la bande 5 150 à 5 250 MHz est uniquement destiné à une utilisation à l'intérieur afin de limiter les risques d'interférences avec les systèmes mobiles satellites dans un canal commun.
- 2 Pour les dispositifs munis d'antennes amovibles, le gain maximal d'antenne permis pour les dispositifs utilisant les bandes de 5 250 à 5 350 MHz et de 5 470 à 5 725 MHz doit être conforme à la limite de puissance isotrope rayonnée équivalente (p.i.r.e).
- 3 Pour les dispositifs munis d'antennes amovibles, le gain maximal d'antenne permis pour les dispositifs utilisant la bande de 5 752 à 5 850 MHz doit être conforme à la limite de p.i.r.e spécifiée pour l'exploitation point à point et l'exploitation non point à point, selon le cas.
- 4 Les pires angles d'inclinaison nécessaires pour rester conforme à l'exigence de p.i.r.e applicable au masque d'élévation, et énoncée à la section 6.2.2 (3), doivent être clairement indiqués.
- 5 Les utilisateurs devraient aussi être avisés, d'une part, que les utilisateurs de radars de haute puissance sont désignés utilisateurs principaux (c.-à-d., qu'ils ont la priorité) des bandes de 5 250 à 5 350 MHz et de 5650 à 5 850 MHz et, d'autre part, que ces radars pourraient causer du brouillage ou des dommages aux dispositifs de RL-EL.

Avis aux utilisateurs (FCC et Industrie Canada)

Cet appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence et à la partie 15 des règlements de la FCC, en vertu des conditions suivantes :

- Cet appareil ne doit pas causer d'interférence nuisible.
- Cet appareil doit accepter toute interférence reçue, y compris les interférences pouvant entraîner un fonctionnement indésirable.
- Toute modification apportée à cet appareil sans l'autorisation explicite de Motorola Solutions peut annuler l'autorisation d'utiliser cet appareil.