

**PRELIMINARY 7/24/03****Product
Summary**

Model No. 60-XXX

The Node Repeater reduces wireless traffic and extends the range of GE Interlogix wireless systems. It receives signals from GE Interlogix 319.5MHz sensors, then retransmits them if necessary. The Node Repeater incorporates a 900MHz transmitter for increased range.

The Repeater allows enrollment of up to 128 sensors. Only enrolled sensors are monitored and repeated. Sensors are enrolled into the Node Repeater using either a personal computer interface or a pair of on-board DIP switches.

Power is supplied to the Node Repeater via a 16.5VAC Class 2 transformer. A 12V lead acid battery provides backup power.

Repeater Features:

- Regular supervisory reports to the panel
- A tamper switch that causes an alarm transmission if the cover is removed.
- A tamper switch that causes an alarm transmission if the unit is removed from the wall.
- Antenna tamper monitoring, causing an alarm transmission if the antennas are cut.
- Dual receive antennas, which provides improved reception through spatial diversity.
- Receiver jam detection, with an alarm transmission if jam is detected.
- Sensor enrollment using either a PC or DIP switch interface.
- Support for a rechargeable lead acid backup battery.
- Battery monitoring, with an alarm transmission if the battery is low.
- AC power monitoring, with an alarm transmission if the power has failed for more than 15 minutes.
- Encryption of sensitive data.

Compatibility

- All GE Interlogix 80-bit sensors at 319.5MHz
- GE Interlogix Learn Mode panic sensors at 319.5MHz

Tools and Accessories Needed**Included with Repeater**

- • Mounting screws and anchors
- • Antenna shrouds
- • Battery cables
- • Multi-Purpose Housing (60-928)

Not Included with Repeater

- • Phillips screwdriver
- • Small standard screwdriver
- • 2-conductor, 12–18 gauge, stranded wire
- • Backup battery (optional) such as the Panasonic LCD 12V1.3P rechargeable battery
- • RF Sniffer (60-401, optional)

Overview of Repeater Components Operation

DIP Switches

There are two DIP switches in the lower left corner of the board. These switches are used for enrollment and deletion of sensors. The following table shows the modes of operation based on switch settings, with 0 = Off and 1 = On. These modes are discussed further in the section on enrollment below.

Table 1: Dip Switch Settings

SW 1

SW 2

Mode

0

0

Normal Operation

0

1

Delete Individual Sensor

1

0

Enroll Individual Sensor

1

1

Delete All Sensors

LED Indications

The purpose of the LEDs is to describe certain actions of the repeater. Tables 1 and 2 describe all possible LED indications.

Table 2: Green LED Indications

Green LED Indication

On

Repeater is powered up and passed self tests

Off

Repeater is not powered or failed to power up successfully

Short Blink Off

Repeater received a packet from a sensor

Table 3: Red LED Indications

Dip Switches

1,2 Setting

Red LED

Indication

Any

On

Node is not configured. Enrollment of sensors is prohibited.

00

Off
 No Activity
 00
 Short Blink
 On
 Repeater received a packet from an enrolled sensor
 01
 Off
 No Activity
 01
 Long Blink
 On
 Repeater received an enrollment-type packet from an enrolled sensor and has deleted that sensor from memory.
 10
 Off
 No Activity
 10
 Long Blink
 On
 Repeater received an enrollment-type packet from an unenrolled sensor and has enrolled that sensor into memory.
 11
 Constant
 Blinking
 DIP switches are set to “delete all” mode, but repeater is awaiting a press and release of the tamper switch before it does the deletion.
 11
 Long Blink
 On
 Repeater has detected a press and release of the tamper switch and deleted all sensors from memory

Installation Overview

There are two basic installation methods, depending on whether the enrollment of sensors is to be done using a personal computer (PC) or the DIP switches. Note that a PC is required for initial configuration regardless of the method of sensor enrollment. The following are the basic steps of each method. The steps are described more fully in later sections.

Installation using a PC

1. Mount the repeater board in the enclosure.

2. Assemble the antenna shrouds and snap into place.
3. Connect the AC transformer leads and power the board.
4. Connect the USB cable from the PC to the repeater board.
5. Using the PC software, perform the initial configuration of the repeater.
6. Use the PC software to enter enrollment mode. Enroll the desired sensors into the repeater.
7. Mount the repeater in its final location.
8. Connect the AC transformer leads and power the board.
9. Connect the battery (if applicable).
10. Install the tamper switch.
11. Mount the enrolled sensors in their final locations.
12. Test the communication between the repeater and the base station receiver.
13. Test the communication between the enrolled sensors and the repeater.

Installation Using the On-board DIP Switches

1. Mount the repeater board in the enclosure.
2. Assemble the antenna shrouds and snap into place.
3. Connect the AC transformer leads and power the board.
4. Connect the USB cable from the PC to the repeater board.
5. Using the PC software, perform the initial configuration of the repeater.
6. Mount the repeater in its final location.
7. Connect the AC transformer leads and power the board.
8. Connect the battery (if applicable).
9. Install the tamper switch.
10. Use the DIP switches to enter Enrollment Mode. Enroll the desired sensors into
11. the repeater.
12. Set the DIP switches back to Normal Mode.
13. Mount the enrolled sensors in their final locations.
14. Test the communication between the repeater and the base station receiver.
15. Test the communication between the enrolled sensors and the repeater.

Mounting the Repeater

For complete mounting instructions see the Multi-Purpose Housing Installation Instructions (Part No. 466-1959).

Mounting Guidelines

- The repeater may need to be temporarily mounted and tested in several locations before being permanently mounted. It is important to ensure that all enrolled sensors are received properly by the repeater when they are in their final locations. See section Testing the Repeater Receiver for instructions on verifying the communication between the sensors and the repeater.
- Select a location with access to power.
- Select a location with as much clearance between the repeater and large metal objects as possible.

Connecting the Antenna Shrouds to the Repeater

- Assemble each of the 3-piece plastic antenna shrouds
- Place one black o-ring in each of the antenna shroud receptacles on top of the chassis.
- Slide each shroud over the antenna wire and gently snap into place on the chassis.

Installing the Tamper Switch

For instructions on installing the tamper switch, see the Multi-Purpose Housing Installation Instructions (Part No. 466-1959).

Powering the Repeater

See the “Specifications” section for transformer requirements. Connect the AC transformer leads to the outer two terminals of the 5-terminal block. These terminals are marked “16VAC”. A 12 VDC lead acid battery, such as the Panasonic LCR12V1.3P, may be installed as a backup power source. Connect the backup battery to the spade lugs.



Warning

There is a risk of explosion if an incorrect type of battery is installed. Observe polarity when installing a new battery. Installing the battery backward may cause damage to the repeater. Dispose of used batteries according to the manufacturer’s instructions and local government authorities.

Initial Configuration

The repeater requires an initial configuration, via personal computer, before enrollment of sensors may take place. The Node Number, Default Sensor Supervisory Timeout, and other constants are set during this configuration. Configuration is required regardless of whether the enrollment of sensors is to be done with the PC or the DIP switches.

Enrolling Sensors into the Repeater

Sensors may be enrolled into the repeater by either the PC method or the DIP switch method. The only difference lies in the method of putting the repeater in enrollment mode and verifying the successful enrollment of a sensor. In the PC method, the computer interface is used for control and feedback. In the DIP switch method, the switches are used for control (see Table 1) and the red LED is used for feedback (see Table 3).

1. Put the repeater in enrollment mode via the PC or the DIP switches.
2. Send an enrollment packet from the desired sensor. The method for sending the enrollment packet varies depending on the type of sensor; see the installation instructions for each sensor for more information.
3. Verify that the enrollment packet was received by the repeater and that the sensor was enrolled, either through the PC interface or via the red LED.
4. Repeat until all sensors have been enrolled.

Deleting Sensors from the Repeater

Sensors may be deleted from the repeater by either the PC method or the DIP switch method.

PC Method

With the PC method, the desired sensors are deleted using the PC interface. The repeater is updated via the USB connection. There is no need to transmit with the sensor. See the documentation for the PC software for more information.

DIP Switch Method

With the DIP switch method, the switches are used to put the repeater in one of two delete modes (see Table 1). This allows the user to either delete individual sensors or delete all sensors. The red LED is used for confirmation (see Table 3).

To delete individual sensors:

1. Put the repeater in individual delete mode via the DIP switches.
2. Send an enrollment packet from the desired sensor (the “enrollment” packet is used for both deletion as well as enrollment). The method for sending the enrollment packet varies depending on the type of sensor; see the installation instructions for each sensor for more information.
3. Verify that the packet was received by the repeater and that the sensor was deleted by watching for a long flash on the red LED.

4. Repeat for each sensor to be deleted.

To delete all enrolled sensors:

1. Put the repeater in delete all mode via the DIP switches.
2. Verify that the red LED is blinking.
3. Press and release the tamper switch.
4. Verify one long flash on the red LED, signaling successful deletion of all sensors.

Testing the Repeater Transmitter

After the repeater is temporarily mounted, perform a test to determine whether or not the signals sent by this repeater are received by the base station.

Note

This test requires two people. One person must activate (trip) the repeater transmitter while another person observes the base station LED.

Hold down the tamper switch of the repeater for 5 seconds and release it. The LED of the base station should flash 14-16 times. If the repeater passes the test, continue with installation.

If the repeater fails this test, it is too far from the base station and must be relocated. Move the repeater to a new location, then perform another test. Continue until the repeater passes this test.

Testing the Repeater Receiver

This test checks the communication link between a sensor and the repeater that will re-transmit its signal.

Note

This test requires two people. One person must activate (trip) the sensor while another person observes the repeater LED.

To perform a repeater reception test:

1. Take the cover off this repeater so you can observe the LED.
2. Cause each sensor to transmit and count packets received.
 - For sensors with a tamper switch, remove the cover from the sensor to cause an alarm transmission. The repeater LED should flash 7-8 times (indicating reception of the alarm signal).
 - For sensors without a tamper switch, activate via normal means. The repeater LED should flash 7-8 times.
 - For panic buttons, hold down the button for 5 seconds and release it. The repeater LED should flash 14-16 times.
 - For touchpads, hold down an emergency button for 5 seconds, then release it. The repeater LED should flash 7-8 times.
3. If any one of the sensors fails this test, relocate the repeater and repeat both the Repeater Transmitter

Specifications

Compatibility:CA1230

GE Interlogix SAW and Crystal 80-bit sensors and touchpads

at 319.5 MHz.

GE Interlogix SAW and Crystal Learn Mode panic sensors at 319.5 MHz.

Power Requirements:16.5 VAC, 50 Hz, 500mA.

A rechargeable 12 V lead-acid backup battery is optional.

Dimensions:6.82 in (17.32 cm) x 6.50 in (16.51 cm) x 2.00 in (5.08 cm)
(W x H x D),

excluding antenna.

Notices Manufacturer's Name:GE Interlogix
Manufacturer's Address:2266 North 2nd Street
North St. Paul, MN, USA 55109
Product Identification:Product: Node Repeater
Model Number: TBD
Brand: GE Interlogix

Notices

FCC Part 15 Information to the User

This device complies with parts 15 of the FCC rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by GE Interlogix can void the user's authority to operate the equipment.



GE Interlogix

© 2002 GE Interlogix. SuperBus is a registered trademark of GE Interlogix. Concord is a trademark of GE Interlogix. All other trademarks are properties of their owners.

All rights reserved.

2266 Second Street North
North Saint Paul, Minnesota 55109
Technical Support: 800-777-2624
Fax: 651-779-4890