

APPENDIX 5
USERS MANUAL

USERS MANUAL FOLLOW THIS SHEET

USERS MANUAL
FCC ID: BBOFRS300

APPENDIX 5

Cobra®

microTALK™

Cobra Electronics Corporation
6500 West Cortland Street
Chicago, IL 60707

If You Think You Need Service

For technical assistance, please call our Automated Help Desk which can assist you by answering the most frequently asked questions about Cobra products.

(773) 889-3087

24 hours a day, 7 days a week.
A Consumer Service Representative can be reached through this same number 8:00 am - 8:00 pm, Monday through Friday, CST.

Technical assistance is also available on-line in the Frequently Asked Questions (FAQ) section at www.cobraelec.com or by e-mail to productinfo@cobraelec.com

If you think you need service call 1.773.889.3087

"If your product should require factory service please call Cobra first before sending your unit in. This will ensure the fastest turn-around time on your repair."

You may be asked to send your unit to the Cobra factory. It will be necessary to furnish the following in order to have the product serviced and returned.

1. For Warranty Repair include some form of proof-of-purchase, such as a mechanical reproduction or carbon or a sales receipt. If you send the original receipt it cannot be returned.
2. Send the entire product.
3. Enclose a description of what is happening with the unit. Include a typed or clearly print name and address of where the unit is to be returned.
4. Pack unit securely to prevent damage in transit. If possible, use the original packing material.
5. Ship prepaid and insured by way of a traceable carrier such as United Parcel Service (UPS) or First Class Mail. To avoid loss in transit to: Cobra Factory Service, Cobra Electronics Corporation, 6500 W. Cortland St., Chicago, IL 60707.
6. If the unit is in warranty upon receipt of your unit it will either be repaired or exchanged depending on the model. Please allow approximately 3 to 4 weeks before contacting us for status. If the unit is out of warranty a letter will automatically be sent informing you of the repair charge or replacement charge. If you have any questions, please call 1.773.889.3087 for assistance.


Cobra Electronics Corp. © 1998

Printed in Thailand

Part No. 480-280-P-001

Operating Instructions for your Cobra MicroTalk 3

Family Radio Service 2 Way Radio



"Ingenious Products for Easier Communication."

The Family Radio Service Story

The Family Radio Service Story

Ever wish you could talk to someone who wasn't within earshot? Like contacting ski partners back at the lodge? Or letting a friend know how to find you in a busy mall? Cobra's MicroTalk 3 is a great way for friends or family to increase their fun—and safety—by staying in touch while on the go.



The FCC (Federal Communications Commission) has created 14 license free frequency bands, or channels, called Family Radio Service (FRS) frequencies. All of these 14 channels are easily accessed on your Cobra FRS radio. These channels are in the UHF (Ultra High Frequency) band which means great penetration through buildings, thick forests, hills, and other dense structures. They are also FM (Frequency Modulation) signals which means crystal clear reception even in crowded noisy environments.

FCC Warnings

Replacement or substitution of transistors, regular diodes or other parts of a unique nature, with parts other than those recommended by Cobra, may cause a violation of the technical regulations of part 95 of the FCC Rules, or violation of Type Acceptance requirements of Part 2 of the Rules.

Included with your MicroTalk 3

- 1 Removable Belt Clip
- 2 Wrist Strap



A1

How to Use Your Cobra *microTALK³* 2-Way Radio

Contents

Features	1
The FRS Story	A1
FCC Warnings	
Included Accessories	A2
Controls & Indicators	A3
Our Thanks to You	A3
Customer Support	A3
Operating Your MicroTalk 3	
Battery Installation	2
LCD Display	4
Turning On	5
Auto Battery Power Saver	5
Select Main Channel (1-14)	6
Select CTCSS Subchannel (00-38)	7
Battery Low	9
Calling Another Party	10
Talking To Another Party	12
Talk Confirmation Tone	14
Listening For Another Party	14
Auto Squelch	15
Maximum Range Extender	15
MicroTalk 3 Range	16
Making Life Easier And Safer	17
External Microphone/Speaker Jack	19
Advanced Features	20
Programming Memory Locations	22
Using Memory Locations	26
Scan Function	28
Private Call (Voice Scramble)	32
Ringer/Vibrate Modes	34
Tone Settings	38
Lock Function	40
Frequency Ranges	41
Caring for Your MicroTalk 3	42
MicroTalk 3 Specifications	44
Limited Two Year Warranty	46
Optional Accessories	47
Order Form	48
If You Think You Need Service	Back Cover

Features of This Product

- UHF FM Frequencies
- No License Required
- No Air Time Fees
- Up to 2 mile range
- 14 Main Channels
- 38 CTCSS Subchannels
- LCD Function Display
- Private Call Voice Scramble
- Talk Confirmation Tone
- Call/Ring Button
- Recharging Pads
- Retractable Antenna
- Auto Battery Saver Circuitry
- Auto Squelch
- 10 Memory Locations
- Full Channel/CTCSS Scan
- Lock Key
- Ring/Vibrate Notification
- Wrist Strap/Belt Clip
- Water Resistant

Operation



Operation

Battery Installation


Note
Batteries not included with Microtalk 3 2-way radio.

Install Batteries

1 Clear antenna.



2 Remove belt clip by (A.) pulling tab out and (B.) Sliding belt clip up and off unit.



3 Pull lock tab down and lift door up (towards you) to remove battery cover.

4 Insert four "AAA" batteries. Position batteries according to polarity markings.

Note
Always use high quality alkaline or NiMH batteries.
Incorrect positioning can damage both the batteries and the unit.

Only the Cobra NiMH battery (Part # FA-BP) pack can be recharged.


See Accessories on page 47
Charge ports for recharging NiMH (Nickel Metal Hydride) battery pack are located on back of unit.

Note
When batteries are low or need charging the BATT LOW indicator will blink. Replace alkaline batteries or recharge NiMH battery pack.

Operation

LCD Display


LCD Display



Operation

Turning On Your MicroTalk 3

Rotate ON - OFF Volume Control clockwise. An audible "tone" will indicate the unit is on and then the LCD will go through a 3 second self-test and then go to operational mode.



Operational Mode

Note

Whenever the unit is on you can receive communications.

Auto Battery Power Saver

Note

The Auto Battery Save Circuit does not affect the unit's ability to receive incoming transmissions.

Auto Battery Power Saver

Your MicroTalk 3 has a unique circuit designed to extend battery life. If there are no transmissions within 10 seconds, the unit will automatically switch to battery save mode.

flashing icon



The PWR Saver icon will flash.

Operation

Select Main Channel

Note


Units must be on same channel and subchannels to communicate.

Note

Channels 8-12 generally are less used and give better results for communications in most areas.

Note

Push and hold the   buttons for fast channel advance.




**PUSH &
RELEASE**

- 2 Select channel by pushing and releasing   buttons.


Select Main Channel (1-14)

- 1 Rotate ON - OFF Volume Control  clockwise. An audible "tone" will indicate the unit is on and then the LCD will go through a 3 second self-test and then go to operational mode.



**PUSH &
RELEASE**

- 2 Select main channel by pushing and releasing   buttons.



**PUSH &
RELEASE**

- 3 Push and release  button. Small numbers flash next to channel display on LCD.

continued

Operation

Select CTCSS Subchannel

Note

If you push and hold the  button, the LCD display will cycle through the different functions.

Note

To return to operational mode and not save your last setting push and release .

Note

CTCSS (Coded Tone Controlled Squelch System) is an advanced subcoding system that allows segmentation of a main channel.

Operation


Operation

Select CTCSS Subchannel

Select CTCSS Subchannel (00-38) continued


Note

Push and hold the   buttons for fast channel advance.



PUSH & RELEASE


- 4 Select subcode number by pushing and releasing   buttons.



PUSH & RELEASE

- 5 When desired code is displayed push and release  button. If key stroke tone is on, an audible tone will confirm your selection.

Battery Low



flashing icon

When in normal use the  icon may begin flashing. This is a warning to you that your batteries are getting low.

Replace alkaline batteries as soon as possible and/or recharge NiMH battery pack.

Note

When battery capacity is at the 1/4 level it is recommended that you replace alkaline batteries or recharge your NiMH (Nickel Metal Hydride) battery pack.

Only the Cobra NiMH battery (Part # FA-BP) pack can be recharged.


Note

NiMH rechargeable battery Pack (item #FA-BP) and 2 port desktop charger (item #FA-CH) are not included with this unit. See Accessories section on page 47.


Operation

Calling Another Party

To alert another party that you wish to communicate:




- 1 Turn on your MicroTalk 3 2-way radio. An audible "tone" will indicate the unit is on. The LCD will go through a 3 second self test and then to operational mode.



- 2 Place antenna in full upright position.

10


Operation



PUSH & RELEASE

- 3 Select desired channel by pushing and releasing Δ buttons.

Note
Both the calling and receiving units must be on same channel and subchannel for the call function to work.



PUSH & RELEASE

- 4 Push and release Δ button. The indicator icon will flash and the Δ icon will remain on for 3 seconds. The unit you are calling will hear a 2 second ring tone.

Note
Your incoming "call" audio ringing level is dependent on your unit's volume setting.

- 5 Wait for the party's response or proceed to "Talking To Another Party" section on next page.

11


Operation

Talking to Another Party


Note

Both units must be on same channel to communicate.


Talking To Another Party
To send your outgoing message:




- 1 Turn on your MicroTalk 3 2-way radio.
An audible "tone" will indicate the unit is on.
The LCD will go through a 3 second self test and then go to operational mode.




- 2 Place antenna in full upright position.




- 3 Push and hold [Mic] button.



- 4 The [A] icon will appear.



- 5 Hold mic about 2 inches from mouth. Speak in a normal voice.



- 6 Release button and listen for response.

Note

While PTT button is depressed you cannot receive incoming calls.

Note


When you release the PTT button, the person you are talking to will hear a tone indicating that it's ok to talk. See Talk Confirmation Tone section on page 14.

Operation

Operation

Talk Confirmation Tone

Talk Confirmation Tone





Your listener will hear an audible tone when you release the PTT button.

This alerts the other party that you are finished talking and it's OK for them to begin talking.

Listening For Another Party

Listening For Another Party

When finished talking:



RELEASE Listening mode.

Note

While PTT button is depressed you cannot receive incoming communications.

- 1 Release button to receive incoming transmissions.


Your MicroTalk 3 is always in listening mode when the PTT button is not pressed and you are not in function mode. See Advanced Features section on page 20.

Auto Squelch

Your MicroTalk 3 is equipped with Auto Squelch, which automatically shuts off weak transmissions and unwanted noise due to terrain conditions or if you have reached your range limit.

Maximum Range Extender

Auto squelch can be temporarily removed to allow all signals to enter by pressing the button (Maximum Range Extender).



PUSH & HOLD 1 SEC.

- 1 Push and hold the button for 1 second to allow all signals to enter.

Note

To learn more about the range of your MicroTalk 3, see MicroTalk 3 Range Section on page 16.


Range is dependent on battery condition and geographic territory.

MicroTalk 3 Range


MicroTalk 3 Range

MicroTalk 3 Range


Your MicroTalk 3 Radio has a range of up to 2 miles. This effective range can be shortened under some conditions.



1. Under flat, open conditions you will experience the MicroTalk's maximum range.



2. Range can be reduced by buildings and foliage in the path of the signal.



3. Range will be further reduced by dense foliage and hilly terrain.

To achieve maximum range the auto squelch can be overridden. Refer to Maximum Range Extender section on page 15.


Making Life Easier and Safer

MicroTalk 3 2-Way Radio Can Make Life Easier and Safer


MicroTalk 3 2-Way Radio Can Make Life Easier and Safer

As you become familiar with your MicroTalk 3 Radio you will find many of your own uses for the unit.

Some suggestions include:



1. Talking with fellow hikers.




2. Keeping track of the kids in a shopping mall.

continued


Making Life Easier and Safer

MicroTalk 3 2-Way Radio Can Make Life Easier and Safer


MicroTalk 3 2-Way Radio Can Make Life Easier and Safer *continued*




3. Communicating between basement and first, second or third floor.



4. Talking to a neighbor or a friend.



5. Checking on traveling companions in another car.



6. Agree on a meeting spot after an event.


External Microphone/Speaker Jack

External Microphone/ Speaker Jack


External Microphone/ Speaker Jack

Your MicroTalk 3 2-Way Radio can be fitted with an external microphone/speaker, (not included) freeing your hands for other tasks.

To attach the external microphone/speaker:



- 1 Open Mic/Spkr tab on top of unit.



- 2 Insert jack into the Mic/Spkr ports.

Note

External microphone/speaker (item #EA-500) is not included with this unit. See Accessories section on page 47 for available units.

Advanced Features

Advanced Features

Note

When using or programming functions, pushing and releasing the  button or the  button will save all entered information.

Note

To exit out of function mode and return to operational mode without saving entered information simply press the  button.


Advanced Features

Your MicroTalk 3 has many advanced features not found on other 2-way radios. These include:

- 10 Memory Storage Location and Recall
- Full Channel/Sub Channel Scan
- Private Call® (Voice Scramble)
- Ring/Vibrate Notification Modes
- Tone Indicator Settings
 - Key Stroke Tone
 - Talk Confirmation Tone
- Lock Key

Advanced Features

SCAN Scan Mode Indicator
PRIVATE Private Call Indicator



Note

If you push and hold the  button, the MicroTalk 3 will cycle through the different functions.

If, after 10 seconds no selection is made, the unit will return to operational mode.


Advanced Features

Programming Memory Locations


Programming Memory Locations

Your MicroTalk 3 has 10 memory (0-9) locations for storing your most frequently used channels.

- 1 Rotate ON - OFF Volume Control clockwise. An audible "tone" will indicate the unit is on and then the LCD will go through a 3 second self-test and then go to operational mode.




- 2 Push and release button until MEM icon and a memory location flashes.




- 3 Select memory location you wish to change by pushing and releasing buttons (Use MEM 6 for this example).

Advanced Features



- 4 Push and release button again. 14 MAIN CHANNEL will flash and only the MEM icon will remain flashing.



- 5 Select desired main channel you wish to store (1-14) by pushing and releasing buttons. (Use CHANNEL 12 for this example.)

Note

Once you enter memory mode you can talk and listen to any channel you select after programming is complete. See Using Memory Locations section on page 26.

continued

Advanced Features


Advanced Features

Programming Memory Locations

Note


Push and hold the  buttons for fast channel advance.

Programming Memory Locations continued



PUSH & RELEASE

- 6 Push and release  button which sets main channel in memory and moves to subchannel selection. The subchannel begins flashing. The MEMICON will remain flashing.



PUSH & RELEASE

- 7 Select desired subchannel you wish to store (00-38) by pushing and releasing   buttons. (Use SUBCHANNEL 38 for this example.)

Note

You can push and hold the  button to begin talking anytime.

Your MicroTalk 3 will stay in the subchannel section until you:

- A Push and hold  button to set memory location and stay in memory scan.
or...
B Push and release  button to return to operational mode.
or...
C Push and release  button to proceed to next function mode (Scan).

Note


If you push and hold the  button, the LCD display will cycle through the different functions.

Advanced Features

Using Memory Locations


Memory Channel Recall/Talk

To recall a channel in memory:



PUSH & RELEASE


- 1 Push and release button until **MEM** icon and a memory location flashes.



PUSH & RELEASE

- 2 Select desired memory location you wish to recall (0-9) by pushing and releasing buttons.


Advanced Features



- 3 Push and hold button and talk. Your radio will stay on this recalled location until you exit out of memory function mode.

- 4 Repeat step 2 for recalling other memory locations.

To exit the Memory Mode and return to Operational Mode:



PUSH & RELEASE

- 5 Push and release button.

Note

If function button is pushed while listening/talking, programming will begin. See Programming Memory Locations on page 27.


Advanced Features

Scan Function

Note
The MicroTalk 3 "zeros out"
the subchannels to allow
scanning of the main
channels.


Scan Function

- 1 Rotate ON - OFF Volume Control  clockwise. An audible "tone" will indicate the unit is on and then the LCD will go through a 3 second self-test and then go to operational mode.



- 2 Push and release  button until SCAN icon and 14 main channel flashes.

Advanced Features



- 3 Push and release  buttons and the unit will begin scanning the main channels.
- 4 Unit will continue to scan all main channels and stop, if an incoming transmission is detected.

Your MicroTalk 3 will pick it up for 10 seconds. Within 10 seconds you can:

- A Push and hold  button and talk. Your radio will return to operational mode on that channel.
- or... B Push and release  button to rescan the main channel.
- or... C Proceed to subchannel scan on next page.


continued

Advanced Features


Scan Function

Scan Function continued

To scan subchannels:



- 1 Push and release button and subchannel and scan icon will flash.




- 2 Push and release button and subchannel scanning begins and stops when an incoming transmission is detected.

Advanced Features

Your MicroTalk 3 will pick it up for 10 seconds. Within 10 seconds you can:

- A Push and hold button and talk. Your radio will return to operational mode on that channel.
- Of...
- B Push and release button to rescan the main channel.

To exit the Scan Mode and return to Operational Mode:



- 1 Push and release button.

Note

If you wish to proceed to the next function mode, push and release button (Private Call/Voice Scramble).


Advanced Features

Private Call (Voice Scramble)

Private Call ensures that no one can eavesdrop on your conversation.


To engage the Private Call function:

- 1 Rotate ON - OFF Volume Control  clockwise. An audible "tone" will indicate the unit is on and then the LCD will go through a 3 second self-test and then go to operational mode.



- 2 Push and release  button until PRIVATE icon flashes.

Advanced Features




- 3 Push and release  button until  icon is visible.

Note

When you push and hold the PTT button, the unit exits out to operational mode.

If, after 10 seconds no selection is made, the unit will return to operational mode.



- 4 Push and release  button. Unit will go to operational mode or push function button to proceed to next function.

Advanced Features


Advanced Features

Ringer/Vibrate Modes

Ringer/Vibrate Modes


Your Microtalk 3 will signal you that there is an incoming transmission with either a tone or a vibration or both. To set for Ringer/Vibrate:

- 1 Rotate ON - OFF Volume Control  clockwise. An audible "tone" will indicate the unit is on and then the LCD will go through a 3 second self-test and then go to operational mode.



PUSH & RELEASE

- 2 Push and release  button until  icon flashes.



PUSH & RELEASE

- 3 Push and release   buttons until  icon appears for ringer mode.

continued

Advanced Features

Advanced Features


Ringer/Vibrate Modes

Note

When you push and hold the PTT button, the unit exits out to operational mode.


If, after 10 seconds no selection is made, the unit will return to operational mode.

Ringer/Vibrate Modes continued




PUSH & RELEASE

- 4 Push and release  buttons again.  icon appears for vibrator mode.



PUSH & RELEASE

- 5 Push and release   buttons again and both   icons will be displayed for ringer/vibrate mode.



PUSH & RELEASE

- 6 After selecting the mode you desire push and release  button or  button to proceed to next function.

Note

Unit must be in operational mode to test ring/vibrate.

Ringer/Vibrate Test

To test the ringer/vibrate mode:

- 1 Turn on unit.
- 2 Push and hold  button.
- 3 Quickly push and release  button. Unit will ring, vibrate, or ring/vibrate for 5 seconds.

Advanced Features

Tone Settings

Tone Setting


The Key Stroke Tone and Talk Confirmation Tone can be temporarily turned on or off during the operation of your MicroTalk 3 2-Way Radio.

Key Stroke Tone Indicator BEEP


You will hear an audible tone when any button is pushed (except PTT button). You can turn the audible tone on or off by:

Note

The Key Stroke Tone and Talk Confirmation Tone can be temporarily turned on or off at any time while in operational mode.




- 1 Push and hold **PTT** button until **BEEP** icon disappears in the LCD display.



- 2 To return to the audible mode, push and hold **PTT** button until **BEEP** icon appears in the LCD display.


Advanced Features

Talk Confirmation Tone Indicator 
To temporarily eliminate the Talk Confirmation Tone:




PUSH & RELEASE

- 1 Push and release **PTT** button until  icon flashes.



PUSH & RELEASE

- 2 Push and release **PTT** button until **OFF** icon appears in the LCD display.



PUSH & HOLD

- 3 Push and hold **PTT** button.  icon will disappear or press and hold function key to proceed to next function.

Note

For more information see Talk Confirmation Tone section on page 14.

Note

To restore the Talk Confirmation Tone repeat steps 1-3 as shown to the left.

Note

When you push and hold the PTT button, the unit exits out to operational mode.

If, after 10 seconds no selection is made, the unit will return to operational mode.

Advanced Features

Lock Function


Note
Call button, Range Extender button and PTT button **do not lock and are fully operational** while the unit is locked.

The unit cannot lock while in function mode.

Lock Function

The purpose of the LOCK function is to lock most buttons to avoid accidental operation.

To engage the LOCK function:



- 1 Push and release button. icon flashes. Most buttons are locked.
- 2 To "unlock" push and release button again. Buttons are "unlocked" and icon disappears.

Frequency Range

The MicroTalk 3 unit represents one of the most advanced FM two-way radios used.

Frequency Ranges

FRS Channel	Channel Frequency In MHz
1	462.5625
2	462.5875
3	462.6125
4	462.6375
5	462.6625
6	462.6875
7	462.7125
8	467.5625
9	467.5875
10	467.6125
11	467.6375
12	467.6625
13	467.6875
14	467.7125

Caring for Your *microTALK*™ 3 Radio

Caring for Your MicroTalk 3 Radio


Note

Modifying or tampering with the radio's internal components can cause malfunction and will invalidate the warranty. If your radio is not performing as it should, please call Cobra at 773.889.3087. Do not return the unit to the retailer.


Caring for Your MicroTalk 3 Radio

The MicroTalk 3 2-Way Radio will give you years of service if cared for properly.


Here are some suggestions:




1. Handle unit gently.



2. Keep away from dust.



3. Never place the unit in water or in a moist place.



4. Avoid exposure to extreme temperatures.

microTALK³ Specifications

microTALK³ Specifications

I. GENERAL SPECIFICATIONS

A. GENERAL

CH=14 CHANNELS WITHIN 462-467 MHz

B. RECEIVER

	UNIT
1. SENSITIVITY FOR 12 DB SINAD FOR CALL SIG. DETECTION	uV 0.25 uV 0.2
2. MAX AUDIO OUTPUT @10% THD	MW 100
3. MAX. S/N RATIO @ 1mV RF INPUT	DB 45
4. SQUELCH	
a) SENS.	uV 0.2
b) ATTACK TIME	mS 120
c) CLOSING TIME	mS 200
5. AUDIO FREQUENCY RESP. @ 300 HZ @ 3000 HZ	DB -6 DB -6
6. SIGNAL DISPLACEMENT BW	+/-KHZ 5
7. ADJACENT CH. REJECTION	DB 55
8. INTERMODULATION REJECTION	DB 55
9. SPURIOUS RESPONSE REJECTION	DB 65

C. TRANSMITTER

	UNIT
1. EFFECTIVE RADIATED POWER	mW 500
2. CARRIER FREQ. STABILITY	HZ 500
3. MODULATION LIMITING	3.0 5.0
4. CARRIER ATTACK TIME	mS 80
5. AUDIO FREQUENCY RESPONSE @ 300 HZ @ 3000 HZ	DB -6 DB -6
6. AUDIO DISTORTION	% 3
7. HUM NOISE	DB 45
8. TRANSIENT FREQ. BEHAVIOR a) TX ON b) TX OFF	mS 30 mS 5

D. POWER SUPPLY

1. BATTERY LIFE (1:1.8 RATIO)	HR 24
2. BATTERY	V 4.8

Limited Two Year Warranty

COBRA ELECTRONICS CORPORATION warrants that its COBRA FRS Radios, and the component parts thereof, will be free of defects in workmanship and materials for period of two (2) years from the date of first consumer purchase.

This warranty may be enforced by the first consumer purchaser, provided that the product is utilized within the U.S.A.

COBRA will, without charge, repair or replace, at its option, defective FRS radios, products or component parts upon delivery to the COBRA Factory Service Department, accompanied by proof of the date of first consumer purchase, such as a duplicated copy of a sales receipt.

You must pay any initial shipping charges required to ship the product for warranty service, but the return charges will be at Cobra's expense, if the product is repaired or replaced under warranty.

Exclusions: This limited warranty does not apply; 1) to any product damaged by accident; 2) in the event of misuse or abuse of the product or as a result of unauthorized alterations or repairs; 3) if the serial number has been altered, defaced or removed; 4) if the owner of the product resides outside the U.S.A.

All implied warranties, including warranties of merchantability and fitness for a particular purpose are limited in duration to the length of this warranty. COBRA shall not be liable for any incidental, consequential or other damages; including, without limitation, damages resulting from loss of use or cost of installation.


Some states do not allow limitations on how long an implied warranty lasts and/or do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations may not apply to you.



**Cobra Electronics
Corporation**


6500 West Cortland Street
Chicago, Illinois 60707

Optional Accessories



(1) NIMH Rechargeable Battery Pack

High performance Nickel Metal Hydride battery pack for multiple recharging.
FA-BP \$29.95



2 Port Desktop Charger

(charges your MicroTalk Radio and (1) Nickel battery pack)
FA-CH \$24.95




Camouflage Cover Carrying Case

Durable nylon case perfect for your MicroTalk radio.
FA-CC \$19.95




Ear Bud Mic with PTT

Integrated speaker/mic adapter that fits in your ear. Includes shirt clip.
MA-EHM \$29.95




Lapel Microphone

Remote microphone/speaker connection.
CA-40 \$25.95



Replacement Belt Clip

FA-BC \$4.95



Vox Mic

VOX (Voice Operated Transmitter) adapter allows you hands free operation.
MA-VOX \$49.95

You Can Find These Fine Accessories At Your Local Cobra Dealer

If you wish, you can order directly from Cobra.

Order by phone

Call 1.773.889.3087

(Press 1 from the main menu) 8 a.m.-8 p.m. M-F CST.)

Order by mail or fax

Please fill out order form on next page, and mail/fax directly to Cobra.

Accessory Order Form

Item #	Description	Cost Ea.	Qty.	Amount
FA-BP	NIMH Rechargeable Battery Pack	\$29.95		
MA-EBM	Ear Bud Mic with PTT	\$29.95		
MA-VOX	Vox Mic	\$49.95		
FA-CH	2 Port Desktop Charger	\$24.95		
CA-40	Lapel Microphone	\$25.95		
FA-CC	Camouflage Cover Carrying Case	\$19.95		
FA-BC	Replacement Belt Clip	\$4.95		
Prices subject to change without notice.				
Tax Table				
Illinois residents add 7%				
Cook Co residents add 7.5% (7.25% total)				
Chicago residents add 1% (8.25% total)				
Indiana residents add 5%				
Michigan residents add 4%				
Minnesota residents add 6%				
Ohio residents add 6%				
Wisconsin residents add 5%				
Subtotal				
(Tax if applicable)				
Shipping/handling				\$4.00
Total				

For credit card orders fill out order form and fax to: 1.773.622.2269 or call 1.773.889.3087 (Press 1 from the main menu) 8:00 am - 8:00 pm, M-F, CST.

Make check or money order (no stamps) payable to:
Cobra Accessories Dept.
6500 West Cortland St. Chicago, IL 60707

Please print clearly

Name _____
Address (No P.O. Box) _____
City _____ State _____
Zip _____
Telephone (____) _____
Credit Card No. _____ Exp. Date _____
Customer Signature _____
Circle One: Visa MasterCard Discover

Allow 4 to 6 weeks for delivery Offer valid in Continental U.S. only