


Using the route menu

Planning a multipoint route

To build your route destination-by-destination, perform the following steps:

1. Press [] on the navigation view to access the navigation menu.
2. Press [Multipoint Route].
There is only one line in the list of route points, the starting point of the route, which is normally the current GPS position.
3. Press [Destination +] to select the destination. The "New Route to..." screen appears, where you can select the destination of the route the same way as described in the previous sections.
4. When the selected location appears on the map, press [Select as Destination] and the list returns. If needed, you can add further intermediate destinations.



5. To add more route points, press [Insert Waypoint +] or Press [Final Destination +] to change the final destination. The "Add to Route..." menu appears again, where you can select the new route point the same way as you have set the destination before.

Note

Press [] to optimise the whole route or the order of waypoints. You can also delete all the destinations.

6. When you have added all the route points, press [Calculate Route] > [Start Navigation].

Checking route information and alternatives

To get a map overview of the planned route and check different parameters of the planned route, perform the following steps:

1. Press [] on the navigation view to access the navigation menu.
2. In the navigation menu, Press [Route Summary].

Using the route menu


Editing the route

When navigation has already started, there are several ways to modify the planned route. You have the following options:


Setting a new starting point

For normal navigation, all routes are calculated from the current position. You can pause navigation to check future routes, simulate them or see their length in time and distance. Then you can set the starting point of the route to a location other than the current GPS position.

1. Press [☰] on the navigation view to access the navigation menu.
2. In the navigation menu, press [Multipoint Route].



3. Press [Current GPS Position] > [Set Starting Point] and confirm your action at the warning message.
4. Select the starting point of the route the same way you select a destination.



5. You can see the new starting point on the map. Press [Set Starting Point] and the multipoint route screen appears where you can continue adding a destination to your route.
6. Press [Calculate Route] to continue.

Adding an additional destination

To add a new intermediate destination to the planned route, perform one of the following actions:

- Press the map anywhere to browse it. After selecting the location on the map, press [⬆] > [Select as Waypoint] to add the selected location to your route as an intermediate destination. The other destinations of the route remain intact.
- Press [☰] on the navigation view and press [Multipoint Route]. Add a destination to your route as described on page 37.

Using the route menu

Modifying the list of destinations


To edit your route, perform the following steps:

1. Press [≡] on the navigation view to access the navigation menu.
2. In the navigation menu, press [Multipoint Route].
 - Press [↖] to delete all the destinations, or optimise the waypoints or the route.
 - Press the name of the intermediate destination to move it up or down in the list, to save the location or to delete it from the list.
 - If you have a route with at least one intermediate destination, you can delete the waypoint from the list right from the main menu. Press [Delete Waypoint], then confirm the deletion.


Saving the planned route

To save the planned route, perform the following steps:

1. Select a destination as described earlier and press [Select as Destination].



2. Press [↖] > [Save Route].



3. Type in a name and press [✓].

The route is saved and it is available in [New Route] > [Saved Routes].

Deleting the planned route

You have the following two options to delete the navigated route:


- Press [↖] to delete all the destinations, or optimise the waypoints or the route.
- In the navigation menu, press [Delete Route] or [Delete Waypoint]. If there are no waypoints, the planned route is deleted after a confirmation. If you have waypoints, you can choose to delete the whole route or only the next waypoint.

Using the route menu

Selecting a route alternative when planning the route

To select from different route alternatives or change the route planning method after you have selected a new destination, perform the following steps:

1. Select a destination as explained earlier and go to the route confirmation screen.



2. Press [Alternatives].
3. You can see the basic details of route alternatives. Press any of them to see it on the map.




4. To view more suggestions, press [More Results] and scroll down for other alternative routes with different route planning methods.
5. Select one of the route alternatives and press [Select] to return to the previous screen. Press [Start Navigation] to start your journey. The orange line now shows the new planned route.

Selecting a route alternative for an existing route

To recalculate the planned route with a different route planning method and to compare different route alternatives, perform the following steps:

1. Press [☰] on the navigation view to access the navigation menu.
2. You can access the list of route alternatives from the navigation menu in one of the following ways:
 - Press [Detours & Alternatives] > [Alternative Routes].
 - Press [Route Summary] > [Alternatives].
3. You can see the basic details of a few route alternatives. Press any of them to see it on the map.



Using the route menu


If there are suitable alternatives calculated with the route planning method that is selected in Route preferences (page 44), they are shown on top of the list. Routes with other route planning methods are shown at the bottom of the list.

4. Select one of the route alternatives and press [Select] to return to the previous screen. Press [Start Navigation] to start your journey. The orange line now shows the new planned route.

Pausing guidance

When you are driving a planned route but you do not need guidance for a certain part of the route, you can suspend it and continue when it is needed again.

In the navigation menu, press [⏸] to suspend guidance or press [▶] to resume guidance.




Setting for navigation


Saving a location

To add any location to the saved locations (the list of frequently used destinations), perform the following steps:

1. Select a destination as described before. It can be an address, a place, any location on the map, a previously used destination from history, and so on.
2. When the map appears with the selected location in the middle, press [↗].



3. Press [Save Location]. Using the keyboard, you can change the name offered for the Saved Location.



4. Press [✓] to save the location.


To add your home and work address to the saved locations, perform the following steps:

1. On the navigation view, press [☰] > [New Route] > [Saved Location].
2. Press [Home] or [Work]. Press [Yes] to confirm your selection.

Editing a saved location

To edit a location that you have already added as a Saved Location, perform the following steps:

1. On the navigation view, press [☰] > [New Route] > [Saved Location]. The list of Saved locations is displayed.



2. Press [↗] > [Edit].
3. Press the location you want to edit, press [Rename] and enter the name of the location on the keyboard.
4. Press [✓] > [Done].

Setting for navigation


Adding an alert point

You can save any map location as an alert point, for example a speed camera or a school zone.

Before using alert point, you have to set the [Alert Point Warnings] by pressing [☰] > [Settings] > [Warnings] > [Alert Points].

1. On the navigation view, select the alert point.
The red cursor [📍] appears there.

2. Press [⏏].




3. Scroll down the list and press [Add Alert Point].
4. Select the type of the alert point, the direction from which you expect the alert, and (if applicable) the speed limit for this alert point.
5. Press [Save] to save the location as a new alert point.

Running a simulation

To run a simulated navigation that demonstrates the planned route, perform the following steps:

1. Press [☰] on the navigation view to access the navigation menu.
2. In the navigation menu, press [Route Summary] > [⏏].



3. Press [Simulation]. The simulation starts from the starting point of the route and leads you through the whole planned route using a realistic speed.



- [▶]: Moves to the next section.
- [⏏/▶]: Pauses or plays the driving simulation.
- [◀]: Moves to the previous section.
- [1x/4x/8x/16x]: Sets the speed of driving simulation as [1x]/[4x]/[8x]/[16x].
- [X]: Ends the driving simulation.

Setting for navigation

Off-road navigation

This navigation calculates routes using the road network of the maps provided with the product.

Switching to off-road navigation


1. On the navigation view, press [] > [Settings] > [Route Preferences].
2. Press [Navigation Mode] > [Off-road].

Selecting the destination in off-road mode

Selecting a destination (waypoint or final destination) is the same as described in the previous sections. The only difference is that route points are linked to form a route with straight lines regardless of the road network and traffic regulations.

Useful information menu

The Useful Information menu provides various additional functions. It can be found in the navigation menu.




- [Where Am I]: Shows information on the current position (latitude, longitude, nearest town, next crossing street, and so on) or the last known position if GPS reception is not available.
- [Help Nearby]: Offers assistance near your current position. (Refer to the page 34)
- [GPS Information]: Shows the GPS Information screen with satellite position and signal strength information.
- [Dealer Info]: Shows a list of nearby dealership and service locations.

Setting for navigation

Settings menu

You can configure the navigation settings and modify the behaviour of the navigation by pressing [☰] > [Settings].



- [Route Preferences]: Select the road types used in route planning method, the navigation mode and road types for the route.
- [Sound]: Adjust the different sound volumes. [Master], [Voice], [Alerts], [Ding], [Voice Guidance], [Early Indication of Maneuvers] and [Verbosity Level].
- [Warnings]: Enable and set up warnings for speed limit, alert points (such as speed cameras) and road signs.

- [Navigation View]: Fine-tune the appearance of the navigation view or adjust how the software helps you navigate with different kinds of route-related information on the navigation view.
- [Regional]: Change the voice guidance language, the measurement units, the date, and formats, and customise the application for your local language.
- [Display]: Enable or disable menu animations.

Android Auto/Apple CarPlay – option

- ※ Android Auto and Apple CarPlay aren't available in some countries.

What is Android Auto/Apple CarPlay?

Securely access your mobile phone while driving. Various functions of your mobile phone are displayed on and operable from the screen of the multimedia device (e.g. navigation, making a call, listening to music etc.)

When connected, an Android Auto/Apple CarPlay icon appears on the screen. Available functions and operations may differ depending on the company model.

For more information, visit the Google or Apple website.

- Google: <http://support.google.com/androidauto/>
- Apple: <http://www.apple.com/ios/carplay/>

Cautions

- Android Auto is a registered trademark of Google Inc.
- Apple CarPlay is a registered trademark of Apple Inc.
- Android Auto and Apple CarPlay are unavailable if the phone OS is not the latest version or if the phone cannot be recognized due to a shutdown caused by a failure or defect in the device itself.

- Your phone may not be recognised if its battery is low. Charge your phone then try again.
- If your phone is shut down due to a defect in the device itself, reset your phone and try again.
- If the USB cable of the Android Auto/Apple CarPlay device is repeatedly disconnected and reconnected in a short period of time, the phone may malfunction. This can also cause a device failure.
- The device recognition time may differ depending on the device type and firmware/OS version.
- Using the USB cable that came with the phone is recommended. (Using a non-genuine product may cause noise or malfunction.)
- Normal operations cannot be guaranteed if the phone is arbitrarily manipulated while Android Auto/Apple CarPlay is active.
- Apple CarPlay cannot be run while making a call via Bluetooth.
- Android Auto or Apple CarPlay may not operate normally due to mobile phone issues.
- Carrier charges may apply when using Android Auto or Apple CarPlay.
- ※ Some features may not operate normally according to the version of iOS and Android.

- The following problems may occur due to phone-related issues:

[Android Auto]

- Intermittent black screens appear when entering Android Auto.
- Differentiation of phones that support Android Auto and those which do not, may not be possible.
- Black screens appear in some areas of the screen due to app errors.

[Apple CarPlay]

- Intermittent black screens appear when entering Apple CarPlay.
- Black screens appear in some areas of the screen due to app errors when navigating between screens in Apple CarPlay.
- The audio volume control may not operate depending on the status of connected phone. Apple CarPlay can control the volume on the head unit regardless of phone volume. Even if the phone volume is set to 0, the sound can be outputted by controlling the volume of head unit.
- The sound output of a call may be cut upon disconnecting Apple CarPlay during a call via Apple CarPlay.

- ※ If services do not work properly due to problems similar to the specified above, check your phone, and if necessary, reconnect your phone after restarting.

Android Auto/Apple CarPlay – option

Using Android Auto or Apple CarPlay

1. Make sure only genuine USB cables are used that were provided by the mobile phone's manufacturer.
2. Enter Android Auto /Apple CarPlay from the home screen or from the submenu [All menus].
3. Now the features such as navigation, music and phone are ready to be used.

NOTICE

- Before connecting your mobile phone, check whether Android Auto or Apple CarPlay is activated in the [Phone projection] menu.
- After connecting the mobile phone, the phone has to be unlocked and the disclaimers on the phone have to be accepted in order to launch Android Auto or Apple CarPlay.
- The screens and features displayed on the multimedia system correspond to the screens and features provided by Google or Apple. They are subject to changes according to the policy of the respective company.

NOTICE-Android Auto

- Bluetooth media features will be disabled when Android Auto is activated. After removing the USB cable, these features will be available again.
- If Android Auto is not activated even after a successful connection, follow these steps:
 - Check whether an error occurred on the phone.
 - Check whether Android Auto has been closed on the phone.
 - Check whether Android Auto is activated in the [Phone projection] menu.
- If Android Auto does not work normally even after a reconnection has been made, visit the Google website <http://support.google.com/androidauto/>

NOTICE-Apple CarPlay

- Bluetooth phone/media features will be disabled when Apple CarPlay is activated. After removing the USB cable, these features will be available again.
- If Apple CarPlay is not activated even after a successful connection, follow these steps:
 - Check whether Apple CarPlay is disabled in the iPhone's application settings.
 - Check whether Apple CarPlay is activated in the [Phone projection] menu.
- If Apple CarPlay does not work normally even after a reconnection has been made, visit the Apple website <http://www.apple.com/ios/carplay/>

Bluetooth® Wireless Technology

Before using the Bluetooth hands-free

What is Bluetooth Wireless Technology?

- Bluetooth Wireless Technology refers to a short-distance wireless networking technology which uses a 2402 MHz ~ 2480 MHz frequency to connect various devices within a certain distance.
- Supported within PCs, external devices, Bluetooth phones, PDAs, various electronic devices, and automotive environments, Bluetooth Wireless Technology is transmitted at high speeds without having to use a connector cable.
- Bluetooth hands-free refers to a device which allows the user to conveniently make phone calls with Bluetooth mobile phones through the system.
- The Bluetooth hands-free feature may not be supported in some mobile phones.

Precautions for safe driving

- Bluetooth hands-free is a feature that enables drivers to practice safe driving. Connecting the head unit with a Bluetooth phone allows the user to conveniently make calls, receive calls, and manage the phone book. Before using Bluetooth Wireless Technology, carefully read the contents of this owner's manual.

- Excessive use or operations while driving may lead to negligent driving practices and be the cause of accidents. Do not operate the device excessively while driving.
- Viewing the screen for prolonged periods of time is dangerous and may lead to accidents. When driving, view the screen only for short periods of time.

Cautions upon connecting Bluetooth phone

- Before connecting the head unit with the mobile phone, check to see that the mobile phone supports Bluetooth features.
- If you do not want automatic connection with your Bluetooth device, turn the Bluetooth feature off on the Bluetooth device.
- Park the vehicle when pairing the head unit with the mobile phone.
- Some Bluetooth features may occasionally not operate properly depending on the firmware version of your mobile phone. If such features can be operated after receiving a S/W upgrade from your mobile phone manufacturer, unpair all devices and pair again before use.

Pairing and connecting the unit and a Bluetooth phone

To use the Bluetooth feature, make sure the Bluetooth on your phone is turned on. Refer to your phone's user guide.

When no phones have been paired

1. Press [HOME] > [All menus] > [Phone]. Or press [VOLUME DOWN] on the steering wheel remote control.
 - [Cancel]: Cancels Bluetooth connection.
2. In your phone, initiate a search for Bluetooth devices. (The default vehicle name is HYUNDAI MOTORS.)
3. 1) If the SSP (Secure Simple Pairing) is not supported, enter the passkey on your Bluetooth device. (The default passkey is 0000.)
2) If the SSP (Secure Simple Pairing) is supported, press [Yes] on the pop-up screen of your Bluetooth device. (The pop-up screen may differ from the actual information of the Bluetooth device.)
4. Bluetooth device is connected.
The mobile phone contacts and the calling list are downloaded.
When the connection fails, a failure message is displayed on the screen.


Bluetooth® Wireless Technology

When a phone is already paired


1. Press [HOME] > [All menus] > [Phone]. Or press [PHONE] on the steering wheel remote control.
2. Press the device from the Bluetooth device list pop-up screen.
If you want to pair additional device, press [Add new]. Follow the steps 3-4 of “When no phones have been paired”.

When pairing additional device

- 1) When using [SETUP] button, press [SETUP] > [Bluetooth] > [Bluetooth connections].



- 2) When using [PHONE] button, press [PHONE].



2. 1) Select the device you want to connect.
2) If there is no device you want to connect, press [Add new].
3. In your phone, initiate a search for Bluetooth devices. (The default vehicle name is HYUNDAI MOTORS.)
4. 1) If the SSP (Secure Simple Pairing) is not supported, enter the passkey on your Bluetooth device. (The default passkey is 0000.)
2) If the SSP (Secure Simple Pairing) is supported, press [Yes] on the pop-up screen of your Bluetooth device. (The pop-up screen may differ from the actual information of the Bluetooth device.)

5. Bluetooth device is connected.

The mobile phone contacts and the calling list are downloaded.

When the connection fails, failure message is displayed on the screen.


Notes

- For safety reasons, pairing a Bluetooth phone is not possible when the vehicle is in motion. Park the vehicle in a safe location to pair a Bluetooth phone. It is possible to pair up to 5 mobile phones. In order to pair new phone, you must first delete one of the previously paired phones.
- Some functions may not be supported due to limited Bluetooth compatibility.
- When a Bluetooth device is connected, a new device cannot be paired.

Bluetooth® Wireless Technology

Disconnecting the connected phone

1. Press [SETUP] > [Bluetooth] > [Bluetooth connections].
2. Select the connected phone.



3. Press [Yes].


Note

If you want to connect the disconnected phone again, select the disconnected phone.

Deleting Bluetooth devices

If you do not need to use a phone any longer, you can delete it. Note that deleting a Bluetooth device will delete all calling list and contact entries.

1. Press [SETUP] > [Bluetooth] > [Bluetooth connections] > [Delete devices].



2. Select the desired devices, then press [Delete] > [Yes].
 - [Mark all]: Marks all items.
 - [Unmark all]: Unmarks all items.

Making a call by entering phone number

Connect your unit and Bluetooth phone before making a call.

1. Enter the phone number using the keypad on the phone screen.
2. Press [CALL] on the phone screen or [CALL] on the steering wheel remote control.

Note

If you press the wrong number, press [X] to delete one digit of the entered number.

Making a call by redialling

Press and hold [RECALL] on the phone screen or [RECALL] on the steering wheel remote control.

Note

Redialling is not possible when there is no number in the dialled calls list.

Bluetooth® Wireless Technology

Answering/Rejecting a call

1. If there is an incoming call, a pop-up message will appear.
2. Press [Accept] in the pop-up message or [↶] on the steering wheel remote control.

To reject a call, select [Reject] in the pop-up message or [↷] on the steering wheel remote control.


Notes

- If the Call-ID service is available, the caller's phone number is displayed.
- If caller's phone number is saved in the phone book, the caller's name is displayed on the unit.
- Upon receiving a call, the [Reject] function may not be supported in some mobile phones.

Switching call to the mobile phone

1. If you want to switch the call to the mobile phone while talking on the car hands-free, press [Use private] on the screen or press and hold [↶] on the steering wheel remote control.

As shown below, the call is switched to the mobile phone.



2. If you want to switch the call to the car hands-free while talking on the mobile phone, press [Use hands-free] on the screen or press and hold [↶] on the steering wheel remote control.


The call is switched to the car hands-free.

Ending a call

1. To end a call, press [End] on the phone screen or [↷] on the steering wheel remote control.
2. The call is ended.

Using the menu during a phone call

When making a call, you can use the following menu items.




Position	Description
1	Switches a voice call from the car hands-free to the mobile phone.
2	Ends a call.
3	Moves to a screen for entering ARS numbers.
4	Sets the microphone volume.
5	Displays the contacts list.

Bluetooth® Wireless Technology

Calling list

Making a call from calling list

1. Press [📞] on the phone screen.



2. Press [All], [Dialled], [Received], or [Missed].
 - [All]: Displays all calling list.
 - [Dialled]: Displays the outgoing calling list.
 - [Received]: Displays the incoming calling list.
 - [Missed]: Displays the missed calling list.
3. Press the entry you want to call.


Note

The calling list may not be saved in some mobile phones.

Downloading call history

You can download the call history information from your mobile phone.

1. Press [📞] on the phone screen.
2. Press [Menu] > [Download] > [Yes].



Notes


- Up to 50 received, dialled, and missed call history lists can be downloaded.
- The download feature may not be supported in some mobile phones. Check to see that the Bluetooth device supports the download feature.

Contacts

Making a call from contacts

1. Press [👤] on the phone screen.

The contacts are displayed on the screen.




2. Select the contact you want to call from the list of contacts.

Bluetooth® Wireless Technology

Downloading mobile phone contacts

You can download contacts from your mobile phone.

1. Press [👤] on the phone screen.
2. Press [Menu] > [Download] > [Yes].




Notes

- Upon downloading mobile phone contacts, the previous data is deleted.
- This feature may not be supported in some mobile phones.

Searching by name or number

You can search contacts for the name or number that you enter.

1. Press [👤] > [Menu] > [Search] on the phone screen.



2. Enter the name or number, then press [OK].
3. Select the contact you want to call.


Favourites

Calling favourites

If the phone number has already been stored in the favourites, it can be easily called by tapping on it.

First of all, add the phone number in the favourites. (Refer to the “Adding as a favourite” on page 53.)

1. Press [👤] on the phone screen.



<Favourites screen>


2. Select the desired favourite.

Bluetooth® Wireless Technology

Adding as a favourite

Up to 10 contacts can be added to favourites menu.

1. Press [] > [Add new] on the phone screen.



2. Select one of the contacts.




3. Press [] > [Close] > [].

Note

If the phone numbers have already been stored in the favourites, you can add or delete them by pressing [Menu] > [Edit].

Deleting favourites

1. Press [] on the phone screen.
2. Press [Menu] > [Delete items].



3. Select the desired item, then press [Delete] > [Yes].
 - [Mark all]: Marks all items.
 - [Unmark all]: Unmarks all items.


Phone settings

This menu describes phone settings.

1. Press [] on the phone screen.
2. For details, refer to the “Bluetooth” on page 56.

Settings


[Settings] menu overview



Sound

This menu is used to adjust the sound effects for the whole system. (It may vary depending on the type of vehicle.)

1. Press [SETUP] > [Sound].



2. Select the desired items.

- [Position]: This menu allows you to set the sound position. For example, you can set the sound close to the driver-seat so that the volume is relatively lower in the passenger or rear seats.
 - Drag and drop the dot to a desired place to adjust the sound position.
 - Press [↑]/[↓]/[←]/[→] to control the sound positioning.
 - Press [⊕] to concentrate the sound in the centre of the vehicle.

- [Equaliser]: This menu allows you to set the [BASS]/[MID]/[TREBLE].
 - Press [-]/[+] to control [BASS]/[MID]/[TREBLE] settings.
 - Drag the slide bar to control [BASS]/[MID]/[TREBLE] settings.
 - Press [Centre] to initialize the settings.
- [Volume ratio]:
 - [Navigation prioritised]: Lowering of all other audio volumes during playback of navigation prompts.
 - [Reverse warning priority]: Lowering of audio volumes when the shift lever is set to reverse.
 - [Volume limitation on startup]: If the audio volume is exceeding the defined maximum upon vehicle start, it is lowered accordingly.
- [Advanced]:
 - [SDVC]: This menu allows you to control automatically the audio volume according to the speed of the vehicle.
 - [Arkamys Sound Effect (option)]: This menu allows you to set the [Automatic volume control]/[Natural]/[Club]/[Lounge]/[Live].


Settings

- [Bass boost (option)]: This menu allows you to set a dynamic sound with maximised bass sound performance.
- [Default]: Resets the sound settings to factory default.
- [Beep]: This menu allows you to play a beep sound whenever you operate the touch screen. Press [Beep].

Display

This menu is used to change the display environment settings.

1. Press [SETUP] > [Display].



2. Select the desired items.
 - [Dimming]: Sets the display brightness according to mode changes.
 - [Auto-illumination]: Adjusts the brightness automatically according to surrounding brightness.

- [Daylight]: Always keeps the brightness high regardless of surrounding brightness.
- [Night]: Always keeps the brightness low regardless of surrounding brightness.
- [Brightness]:
 - Press [-]/[+] to set display brightness for daylight or night mode.
 - Drag the slide bar to control the display brightness settings.
 - Press [Centre] to initialize the settings.
- [Adjust]: This menu can be set in video mode.
 - Press [-]/[+] to control [Brightness]/[Contrast]/[Saturation] settings.
 - Drag the slide bar to control [Brightness]/[Contrast]/[Saturation] settings.
 - Press [Centre] to initialize the settings.
- [Ratio]: Sets the display ratio according to mode changes. This menu can be set in video mode.
 - [Normal]: Adjusts the screen to 4:3.
 - [Full]: Adjusts the screen to full screen display.
 - [Wide]: Adjusts the screen to 16:9.

- [Default]: Resets the display settings to factory default.
- [Display Off]: Press [Display Off] to turn the screen off. Press the screen itself again to turn the screen on.

Settings


Bluetooth

This menu describes Bluetooth phone settings.

Bluetooth connections

This menu is used to pair and connect the head unit and a Bluetooth phone.

Press [SETUP] > [Bluetooth] > [Bluetooth connections].




- 1 Paired device list: Displays the paired Bluetooth device list. When selecting from the list, the device is either connected or disconnected.
- 2 Bluetooth audio connection status: An icon appears when you make a Bluetooth audio connection.

- 3 Bluetooth hands-free connection status: An icon appears when you make a Bluetooth hands-free connection.
- 4 [Add new]: Registers a new Bluetooth device.
- 5 [Delete devices]: Moves to "Delete devices".
- 6 [Help]: Switches to the Bluetooth connection help screen.

Auto connection priority

If auto connection priority is turned on, a Bluetooth device will automatically be connected according to the option setting when the car ignition is turned on.

1. Press [SETUP] > [Bluetooth] > [Auto connection priority].



2. Select the desired items.

Note

If there is no phone selected, the previously connected phone will be automatically connected. If there are no previously connected phones, the system will try to connect to devices in the list in order.


Settings

System Bluetooth info

Vehicle name

You can change the Bluetooth device name of the vehicle.

1. Press [SETUP] > [Bluetooth] > [System Bluetooth info] > [Vehicle name].



2. Enter the desired name using the keypad, then press [OK].

Note

The default vehicle name is set to HYUNDAI MOTORS.

Passkey

You can change the passkey used for Bluetooth device authentication.

1. Press [SETUP] > [Bluetooth] > [System Bluetooth info] > [Passkey].



2. Enter the passkey using the keypad, then press [OK].

Note

The passkey is a 4-digit authentication code used for a Bluetooth connection between the mobile phone and car system. The default passkey is set to 0000.

Default


This menu is used to reset the Bluetooth settings to factory default.

Press [SETUP] > [Bluetooth] > [Default] > [Yes].

Phone projection

This menu describes phone projection settings.

1. Press [SETUP] > [Phone projection].



2. Press the desired items.

- [Android Auto]: If Android Auto is checked, you can use the functions of your Android device with a USB cable connected.
- [Apple CarPlay]: If Apple CarPlay is checked, you can use the functions of your iPhone with a USB cable connected.

Note


This [Phone projection] menu cannot be operated if any USB device, iPod or Android Auto/Apple CarPlay device has been connected to the system.

Settings

Custom button

You can assign a function to custom button.

1. Press [SETUP] > [Custom button].



2. Select the desired function.


Note

After setting a desired function, press and hold [**☆**] on the head unit to move to the [Custom button settings] menu.

Date/Time

This menu describes date and clock settings.

1. Press [SETUP] > [Date/Time].




2. Select the desired items.

- [GPS time]: Displays time according to the received GNSS (Global Navigation Satellite System) time.
- [24-hour]: Switches to 12 hour or 24 hour.
- [Daylight savings time]: Turns the daylight savings time on or off. When daylight savings time is turned on, the clock is moved forward one hour.

Language

This menu is used to set the language of the system.

1. Press [SETUP] > [Language].




2. Select the desired language.

Settings

Keyboard

This menu is used to configure the keyboard layout for each language.

1. Press [SETUP] > [Keyboard].
2. Select the keyboard type.




- [Default keyboard]: Select [Latin], or [Cyrillic].
- [Keyboard type]: Select [QWERTY], [QWERTZ], [AZERTY] or [ABCD].

Screensaver

This menu is used to select the screen displayed when the screen or power is turned off.

1. Press [SETUP] > [Screensaver].




2. Select the desired item.
 - [Digital]: The digital clock and date is displayed.
 - [Analogue]: The analogue clock and date is displayed.
 - [None]: Nothing is displayed.

Advanced

This menu describes advanced settings.

1. Press [SETUP] > [Advanced].



2. Select the desired items.
 - [Media change notifications]: If the box is checked, the notification pop-up for media information will be shown on the top of the screen, whenever a content changes.
 - [Steering whl mode button]: Selects the desired feature when you press [MODE] on the steering wheel to toggle media modes.
 - [Auto comfort control]: This menu allows you to set [Steering wheel warmer] or [Seat heating/vent].
 - [Steering wheel warmer]: If the box is checked, the steering wheel heating temperature will be adjusted automatically.
 - [Seat heating/vent]: If the box is checked, the driver's seat heat / ventilation will be controlled automatically.

Settings

System info

Version info

You can view software version and firmware version.

Press [SETUP] > [System info] > [Version info].

Update

For system's software security and new function addition, you need an update.

1. Press [SETUP] > [System info] > [Version info].



2. Insert the USB with latest file downloaded into the USB slot.
3. Press [Update] > [OK].

Once updating is completed, the system will automatically restart.

Notes

- This product requires regular updates for software corrections and new functions. Updating may require up to 10 min depending on the data size.
- Turning off the power or ejecting the USB during the update process may result in data loss.
- Please use only the USB that was included with the vehicle purchase.
- The use of a separately purchased USB may result in damage due to heat related deformation.
- Product malfunctions caused by the use of separately purchased USB shall not be covered within the product warranty.
- Repeatedly connecting/disconnecting the USB in a short period of time may cause damage to the device.

Default

This menu is used to reset all settings specified by the user.

1. Press [SETUP] > [System info] > [Default].
2. Press [Default] > [Yes].

Note

This [Default] menu cannot be operated if any USB device, iPod or Android Auto/Apple CarPlay device has been connected to the system.



Using rear view monitor – option

About rear view monitor

Rear view monitor is an option for the customers who selected the option.

Rear view monitor is parking guide system, when the ignition switch is on and a car start-up with being in R position of a transmission lever.

Notes

- Rear view monitor has an optical lens to secure wide view, so there is a little difference in the distance shown on the screen. For safety, make sure to check the rear, left, and right view by yourself.
- The colour of the parking guide line on the screen may differ from reality.



1	Driving direction lines (yellow)
2	These lines show the directions of the vehicle according to the steering angle.
3	Neutral direction lines (blue) These lines indicate your vehicle's expected path with the steering wheel in the neutral position. It can help you determine whether the vehicle is in the correct position in a parking space and prevent you from parking too close to the next vehicle.
4	Crash warning lines (red) These lines are to prevent a collision.

Before thinking there is a product defect

The current car position as shown on the navigation may differ from the actual position under the following conditions.

- When driving on Y-shaped roads with narrow angles the current position may be displayed in the opposite direction.
- Within city streets, the current position may be displayed on the opposite side or on an off-road position.
- When changing the zoom level from maximum to a different level, the current position may be displayed on a different road.
- If the vehicle is loaded onto a ferry or a car transport vehicle, the current position may be stalled on the last position prior to loading.
- When entering a road after passing an underground parking structure, building parking structure, or roads with many rotations.
- When driving in heavy traffic with frequent starts and stops.
- When driving under slippery conditions, such as heavy sand, snow, etc..
- When the tires have recently been replaced (Especially upon use of spare or studless tires).
- When using tires of improper size.

- When the tire pressure for the 4 tires are different.
- When the replacement tire is worn or used (Especially studless tires having passed a second season).
- When driving near high-rise buildings.
- When a roof carrier has been installed.
- When a long distance route is calculated while driving on an expressway, in such cases, continued driving will automatically enable the system to conduct map matching or use updated GNSS information to provide the current position (In such cases, up to several minutes may be required).

Correct route guidance may not occur due to search conditions or driving position. The following occurrences are not malfunctions:

- Guidance to go straight may be given while driving on a straight road.
- Guidance may not be given even when turning onto an intersection.
- There are certain intersections in which guidance may not occur.

- A route guidance signaling for a U-turn may occur in some no U-turn intersections.
- Route guidance signaling entrance into a no-entry zone may occur (no-entry zone, road under construction, etc.).
- Guidance may be given to a position that is not the actual destination if roads to reach the actual destination do not exist or are too narrow.
- Faulty voice guidance may be given if the vehicle breaks away from the designated route. (e.g. if a turn is made at an intersection while the navigation provided guidance to go straight.)

These situations may occur after conducting route calculation. The following occurrences are not malfunctions:

- Guidance may be given to a position differing from the current position when turning at an intersection.
- When driving in high speeds, route recalculation may take a longer period of time.

Before thinking there is a product defect

1. Errors which occur during the operation or installation of the device may be mistaken as a malfunction of the actual device.
2. If you are having problems with the device, try the suggestions listed below.
3. If the problems persist, contact your authorised Hyundai dealer.

Problem	Possible Cause
There are small red, blue, or green dots on the screen	Because the LCD is manufactured with technology requiring high point density, a pixel or lighting deficiency may occur within 0.01% of total pixels.
The sound or image is not working	• Has the switch for the vehicle been turned to [ACC] or [ON]? • Has the system been turned off?
The screen is being displayed but sound is not working	• Has the volume been set to a low level? • Has the volume been muted?
When the power is turned on, the corners of the screen are dark	• The display appearing somewhat dark after prolonged periods of use is normal with LCD panels. It is not a malfunction. • If the screen is very dark, contact your nearest authorised Hyundai dealer for assistance.
Sound is working from only one speaker	Are the positions of fader or balance sound controls adjusted to only one side?
The external device is not working	Is the external device connected with a standard connector cable?
When turning power on, the most recent mode screen is not displayed	Within modes that play files by reading external sources, such as USB, iPod, or Bluetooth® streaming mode, the most recently played mode screen prior to turning off power may not properly load. • If the corresponding device is not connected, the mode operated prior to the most recent mode will operate. • If the previous mode still cannot be properly played, the mode operated prior to that will operate.

Troubleshooting

Problem	Possible Cause	Countermeasure
The power does not turn on.	The fuse is disconnected.	• Replace with a suitable fuse. • If the fuse is disconnected again, please contact your authorised Hyundai dealer.
	Device is not properly connected.	Check to see that the device has been properly connected.
The system does not play.	The vehicle battery is low.	Charge the battery if the problem persists, contact your authorised Hyundai dealer.
The image colour/ tone quality is low.	The brightness, saturation, and contrast levels are not set properly.	Properly adjust the brightness, saturation, and contrast levels through display setup.
Sound does not work.	The volume level is set to the lowest level.	Adjust the volume level.
	The connection is not proper.	Check to see that the device has been properly connected.
	The device is currently fast-forwarding, rewinding, scanning, or playing in slow mode.	The sound will not work when the device is fast-forwarding, rewinding, scanning, or playing in slow mode.

Troubleshooting

Problem	Possible Cause	Countermeasure
The sound or image quality is low.	Vibration is occurring from where the conversion switch has been installed.	The sound may be short circuited and the image distorted if the device vibrates.
	Image colour/tone quality is low.	The device will return to normal once vibrations stop.
The USB does not work.	USB memory is damaged.	Please use after formatting the USB into FAT 16/32, exFAT or NTFS format.
	USB memory has been contaminated.	Remove any foreign substances on the contact surface of the USB memory and multimedia terminal.
	A separately purchased USB hub is being used.	Directly connect the USB memory with the multimedia terminal on the vehicle.
	A USB extension cable is being used.	Directly connect the USB memory with the multimedia terminal on the vehicle.
	A USB which is not a metal cover type USB memory is being used.	Use standard USB memory.
	An HDD type, CF, SD memory is being used.	Use standard USB memory.
	There are no music files which can be played.	Only MP3, WMA, OGG, FLAC and WAV file formats are supported. Please use only the supported music file formats.
The iPod is not recognised even though it has been connected.	There are no titles which can be played.	Use iTunes to download and save MP3 files into the iPod.
	The iPod firmware version has not been properly updated.	Use iTunes to update the firmware version and reconnect the iPod with the device.
	The iPod device does not recognise downloads.	Reset the iPod and reconnect with the device.

Trademarks and licenses

Bluetooth® Wireless Technology



The Bluetooth Wireless Technology word mark and logos are registered trademarks owned by Bluetooth Wireless Technology SIG, Inc.

iPod®

iPod® is a registered trademark of Apple Inc.

OPEN SOURCE SOFTWARE NOTICE

To obtain the source code under GPL, LGPL, MPL and other open source licenses, that is contained in this product, please visit <http://opensource.lge.com>.

In addition to the source code, all referred license terms, warranty disclaimers and copyright notices are available for download.

LG Electronics will also provide open source code to you on CD-ROM for a charge covering the cost of performing such distribution (such as the cost of media, shipping and handling) upon email request to opensource@lge.com. This offer is valid for three (3) years from the date on which you purchased the product.

DivX®



This DivX Certified® device can play DivX® HD video files (including .avi, .divx).

Download free software at www.divx.com to create, play and stream digital videos.

DivX®, DivX Certified® and associated logos are trademarks of DivX, LLC and are used under license.

Covered by one or more of the following U.S. patents: 8,731,369; 9,369,687; RE45,052.

Specification

Common	Power supply	DC 14.4 V
	Operating power	DC 9 V ~ DC 16 V
	Current consumption	Maximum 14 A
	Dark current	Maximum 1 mA
	Operating temperature	-20 °C ~ +65 °C
	Storage temperature	-30 °C ~ +75 °C
	Dimensions (Head unit)	320.9 mm (W) X 211.5 mm (H) X 208.9 mm (D)
	Weight (Head unit)	2.09 kg
Bluetooth	Supported profile	HFP 1.6, A2DP 1.2, AVRCP 1.5, PBAP 1.1
	Supported Bluetooth specification	3.0
	Frequency range	2402 MHz ~ 2480 MHz
	Output power (Max, Class2)	4.0 dBm
	Number of channels	79

Radio	AM	
	Tuning range	530 kHz ~ 1710 kHz
	Usable sensitivity	35 dBuV
	Signal-to-noise ratio	Minimum 45 dB
	FM	
	Tuning range	87.50 MHz ~ 107.90 MHz
	Usable sensitivity	10 dBuV
	Signal-to-noise ratio	Minimum 50 dB
TFT-LCD	Screen size	203.2 mm (8 inches) 176.4 (W) x 99.36 (H) mm (Active area)
	Resolution	384,000 pixel
	Operating method	TFT (Thin Film Transistor)
	Viewing angle	R/L/U/D 89 (Typ)
	Internal lighting	LED

- Designs and specifications are subject to change without prior notice.

LIMITED WARRANTY

ORIGINAL NAVIGATION HEAD UNIT SUPPLIED BY VEHICLE DEALER

Product :
Product No. :

WHAT THIS WARRANTY COVERS

1. Vehicle Dealer Shop ("Dealer") warrants to you that the Hardware will be free from defects in workmanship and materials under Normal use ("Defects") from the original date of the registration of the motor vehicle ("Warranty Period"). During the Warranty Period the Hardware will be repaired or replaced at DEALER's choice ("Limited Warranty") without charge to you for either parts or labor. This Limited Warranty covers the replacement of the head unit including of the Hardware only.

WHAT THIS WARRANTY DOES NOT COVER

2. The Limited Warranty does not apply to normal wear and tear, does not apply when the Hardware is opened or repaired by someone not authorized by DEALER and does not cover repair or replacement of any Hardware or part thereof damaged by: misuse, moisture, liquids, proximity or exposure to heat and accident, abuse, non-compliance with the instructions supplied with the Hardware, neglect or misapplication. The Limited Warranty does not cover physical damage to the surface of the Hardware. This Limited Warranty does not cover any software that may accompany or be installed on the Hardware. The Limited Warranty does not cover the installation, removal or maintenance of the Hardware or any costs related herewith.

HOW TO MAKE A WARRANTY CLAIM

3. In order to make a claim of a Defect, you must contact DEALER. If a defect arises and a valid claim under this Limited Warranty is received by DEALER after the first 3yr / 60,000km of the Warranty Period, DEALER is entitled to charge you for any reasonable shipping and handling costs made in connection with the repair or replacement of the Hardware. You must comply with any other return procedures stipulated by DEALER, if any.

DEALER LIMITED WARRANTY

YOUR LEGAL RIGHTS

4. Some countries may not allow the exclusion or limitation of damages. If any part of this Limited Warranty is held to be invalid or unenforceable, the remainder of the Limited Warranty shall nonetheless remain in full force and effect.
5. This Limited Warranty is the only express warranty made to you and is provided in place of any other express warranties or similar obligations (if any) created by any advertising, documentation, packaging, or other communications.
6. Except for the Limited Warranty and to the maximum extent permitted by applicable law, DEALER and its suppliers provide the Hardware "AS IS AND WITH ALL FAULTS", and hereby disclaim all other warranties and conditions, whether express, implied or statutory, including, but not limited to, any (if any) implied warranties, duties or conditions of satisfactory quality, of fitness for a particular purpose, of reliability or availability, of accuracy or completeness of responses, of results, of workmanlike effort, of lack of viruses, and of reasonable care and skill, all with regard to the Hardware, and the provision of or failure to provide support or other services, information, software, and related content through the Hardware or otherwise arising out of the use of the Hardware. Also, there is no warranty or condition of quiet enjoyment, quiet possession, or non-infringement with regard to the Hardware.
7. This Limited Warranty does not affect any legal rights under applicable national legislation governing the sale of consumer goods.
8. This Limited Warranty cannot be transferred to any other person.

LIMITATION OF LIABILITY

9. Neither DEALER nor its suppliers shall be liable to you or to any third party for any damages either direct, indirect, incidental, consequential or otherwise (including in each case, but not limited to, damages for the inability to use the equipment or access data, loss of data, loss of business, loss of profits, business interruption or the like) arising out of the use of or inability to use the Hardware even if DEALER has been advised of the possibility of such damages.
10. Notwithstanding any damages that you might incur for any reason whatsoever, the entire liability of DEALER and any of its suppliers shall be limited to the amount actually paid by you for the Hardware.
11. DEALER shall not be liable for
 - (I) any fraud on the part of its employees and/or agents; or
 - (II) any fraudulent misrepresentation on the part of its employees and/or agents.
12. Notwithstanding the above, neither party's liability for death or personal injury resulting from its own negligence shall be limited.

FCC Information to User

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution

Modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Compliance Information : This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

IMPORTANT NOTE:

FCC RF Radiation Exposure Statement:

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

P/N:MFLXXXXXXXXX (O/M)