


MACE Smart[★]

installation guide

2018-01-30 | v1.03 | 5286484



CONTENT

1	INTRODUCTION	3
1.1	MACE	3
1.2	FIRMWARE VERSIONS	3
2	INSTALLATION	4
2.1	SAFETY INSTRUCTION	4
2.2	MOUNTING INSTRUCTIONS	4
3	CONNECTIONS	6
3.1	POWER SUPPLY	6
3.2	COMMUNICATION	6
3.2.1	RS485	6
3.2.2	WIEGAND	7
3.2.3	MAGSTRIPE ISO7811/2	8
3.3	LED CONTROL	9
3.4	INPUTS	10
3.5	OUTPUTS	11
3.6	TAMPER SWITCH	12
3.7	NEDAP ANTENNA INTERFACE	12
4	READER CONFIGURATION	13
4.1	CONFIG SOFTWARE	13
4.2	OPTIONS	14
4.2.1	USER MODE	14
4.2.2	SEND CONFIG	14
4.2.3	READ CONFIG	14
4.2.4	SETUP BAUDRATE	14
4.2.5	SETUP OSDP DEVICE ADDRESS	14
4.2.6	RESET CONFIG	14
4.3	SETTINGS	15
4.3.1	GENERAL	15
4.3.2	LED/BUZZER	16
4.4	READER SETTINGS	17
4.4.1	BLE	17
4.4.2	NFC	19
4.4.3	QR-CODE	19
4.4.4	DESFIRE	20
4.4.5	MIFARE	21
4.4.6	OTHER ID TYPES	22
4.5	COMMUNICATION OUTPUT	23
4.5.1	SERIAL	23
4.5.2	WIEGAND/MAGSTRIPE	25
4.6	MISCELLANEOUS	29
4.6.1	FIRMWARE UPDATE	29
4.6.2	KEY UPDATE	29
A	TECHNICAL SPECIFICATIONS	30
B	PART NUMBERS	31
C	FCC AND ISCED DECLARATIONS	32
D	DISCLAIMER	33
E	DOCUMENT REVISION	34

1 INTRODUCTION

1.1 MACE

MACE is an acronym for Mobile Access Control Enabler. MACE is a platform consisting of readers, apps and a cloud based server that enables the use of smartphones to identify people.

The MACE Smart reader supports Bluetooth and NFC to identify virtual credentials from an iPhone or Android smartphone with the NEDAP MACE app installed.

MACE can be used in combination with any access control system or any other system that requires the swift identification of people, like parking management systems or registration systems.

Please remember to fill out the 'How to Order Guide' to prepare your MACE installation and order virtual MACE credentials that will be read by the MACE readers you plan to install.

1.2 FIRMWARE VERSIONS

The MACE Smart reader supports different firmware versions. Below an overview of the available firmware versions and their key features.

STANDARD firmware (MaceSmart_v1xx.nis):

- RS485 communication using CR/LF protocol
- Wiegand communication output
- Magstripe (clock & data) communication output
- LED and buzzer control automatic or remote through digital inputs.

OSDP firmware (MaceSmartOSDP_v1xx.nis):

- RS485 communication according to the SIA OSDP v2.1.6 standard
- Secure Channel Protocol supported
- LED and buzzer control through OSDP commands

Default the STANDARD firmware is installed.

Perform a firmware update using the MaceConfigTool software. See chapter 4.6.1.

The firmware update also allows to change from STANDARD to OSDP (or vice versa).

2 INSTALLATION

2.1 SAFETY INSTRUCTION

The following safety precautions should be observed during normal use, service and repair:

- The MACE Smart reader may only be installed and serviced by qualified service personnel.
- Disconnect the power supply before (dis)connecting any wires, MACE is NOT hot-swappable, so when making or changing connections, power must be switched OFF.
- The cable shield shall be connected with safety ground and the metal case of the external device(s).
- To be sure of safety, do not modify or add anything to the MACE Smart reader other than mentioned in this installation guide or indicated by NEDAP N.V.

2.2 MOUNTING INSTRUCTIONS

The MACE can be mounted to any surface, including directly to metal. See the picture below for details about the dimensions.




Figure 1: MACE dimensions (mm)

MACE SMART | INSTALLATION GUIDE

Installation

Mount the base-plate on the required location.

Make sure that the reader is positioned such that the screw hole is located at the bottom side of the reader.

Ensure that it is placed correctly covering the cable entry hole. Properly fix the base-plate into its position using the 2 screws. When mounting on a stone or concrete wall drill 5mm holes for the plugs. When mounting on wood, drill with 2.5mm.

Install the MACE Smart reader onto the base-plate:

- 1 Feed the cable through the cable entry hole and place connectors.
- 2 Attach the top of the MACE Smart reader onto the base-plate.
- 3 Fix the assembly using the screw on the bottom.




Figure 2: MACE installation

3 CONNECTIONS

See below an overview of the connections.

Nedap antenna interface	K1-6	K2-1	RS485 A (-)
Beeper_IN*	K1-5	K2-2	RS485 B (+)
Led_UL_IN*	K1-4	K2-3	Ground
Led_NA_IN*	K1-3	K2-4	Data-1 / Data
Ground	K1-2	K2-5	Data-0 / Clock
Power supply 12 - 24VDC	K1-1	K2-6	Tamper switch (normally closed)
		K2-7	Tamper switch (common)

3.1 POWER SUPPLY

The MACE Smart reader requires DC power supply in the range from 12 – 24V.

Maximum current consumption is 0.2A @ 12VDC, 0.1A @ 24VDC.

Connections:

K1-1	Power supply 12 - 24VDC
K1-2	Ground

3.2 COMMUNICATION

3.2.1 RS485

The MACE Smart reader has a RS485 interface for communication with a host system or to configure the reader settings. RS485 is a 2-wire half-duplex serial communication interface using balanced lines. STANDARD and OSDP protocol are available.

Connections:

K2-1	RS485 A (-)	Balanced RX/TX
K2-2	RS485 B (+)	Balanced RX/TR

For details about reader configuration see chapter 4.

Standard firmware:

Default RS485 communication baud rate is 115200. See chapter 4.2.4.

The RS485 output message format is described in chapter 4.5.1

OSDP firmware:

The OSDP protocol is implemented according to the SIA OSDP v2.1.6 standard including the Secure Channel Protocol. Default RS485 communication baud rate is 9600. This may be changed using the OSDP_COMSET command.

3.2.2 WIEGAND

The Wiegand and Magstripe ISO7811/2 (clock & data) interface share the same connections. This means that only Wiegand or Magstripe can be used and not both simultaneously.

Wiegand connections:

K2-5	D0
K2-4	D1
K2-3	Ground (0V)

Message format:

The Wiegand output format is determined by the programming format of the credential. MACE Wiegand credentials will automatically generate a Wiegand message. If the credential is not programmed in Wiegand format, you may configure the message output format as described in chapter 4.5.2.

Make sure to order the correct credential programming format if you want to use the Wiegand or Magstripe interface. See also the MACE how to order guide (HTOG) for more information.

Wiegand Timing

In the figure below the Wiegand protocol timing is specified.




Figure 3: Wiegand protocol timing

Timing constants:

T_{pi}	Pulse interval time	1msec
T_{pw}	Pulse width time	50μsec

OSDP firmware:

The OSDP firmware does not support the Wiegand interface!!!

3.2.3 MAGSTRIPE ISO7811/2

The Magstripe ISO78122/2 (clock & data) and Wiegand interface share the same connections. This means that only Wiegand or Magstripe can be used and not both simultaneously.

Magstripe connections:

K2-5	CLK
K2-4	DAT
K2-3	Ground (0V)

Message format:

The Magstripe output format is determined by the programming format of the credential. MACE Magstripe credentials will automatically generate a Magstripe message. If the credential is not programmed in Magstripe format, you may configure the message output format as described in chapter 4.5.2.

Make sure to order the correct credential programming format if you want to use the Wiegand or Magstripe interface. See also the MACE how to order guide (HTOG) for more information.

Magstripe Timing

The figure below shows the timing for one Magstripe character. Each bit consists out of one period low (220µsec) and two periods high (440µsec). The Data-signal is valid and stable on the falling edge of the Clock-signal.




Figure 4: Magstripe protocol timing one character

Timing constants:

Clock period	660µsec
Clock high	440µsec
Clock low	220µsec
Data pre-amble	16 clock periods
Data post-amble	16 clock periods

OSDP firmware:

The OSDP firmware does not support the Magstripe ISO7811/2 interface!!!

3.3 LED CONTROL

The built-in high intensity LED provides visual feedback that the tag has been read or authorized. The LED and buzzer can be controlled by the access control system.

Automatic mode:

Default the MACE reader will automatically control the LED.

During stand-by the LED will be BLUE and upon identification it will be GREEN.

These colors can be changed!

Remote control:

The LED and buzzer can be controlled remotely by a connected access control system by activating digital inputs (active low). See chapter 3 for connection details. Use MaceConfigTool software to setup the LED/buzzer control mode and configure the corresponding LED colors.

Color UL LED color when input Led_UL_IN active

Color NA LED color when input Led_NA_IN active

Color UL+NA LED color when both inputs Led_UL_IN and Led_NA_IN active

Color idle LED color when both inputs not active

Direct (serial cmd):

The LED and buzzer can only be controlled by serial commands.

OSDP firmware:

Use the OSDP_LED command to control the LED.

Automatic mode and Remote control are not supported.

3.4 INPUTS

The MACE reader has 3 digital inputs (active low).

Connect to ground to active the input. Leave unconnected otherwise.

Connections

RED/BLU	Input 0 - Led_UL_IN (active-low)
WHITE	Input 1 - Led_NA_IN (active-low)
BLUE	Input 2 - Beeper_IN (active-low)
BLACK	Ground
SHIELD	Shield connected to DC-ground

STANDARD firmware:

The digital inputs can be used to control the LED and buzzer. See chapter 3.3.

OSDP firmware:

The digital inputs are general purpose inputs.

Upon status change the reader will send input status report message OSDP_ISTATR.

The current input status can be requested by sending the input status report request message OSDP_ISTAT.

3.5 OUTPUTS

The MACE reader has 2 digital outputs. The function of the digital outputs is dependent upon the installed firmware version. See below.

STANDARD firmware:

The outputs are used for Wiegand or Magstripe communication. See respectively chapters 3.2.2 and 3.2.3

OSDP firmware:

The outputs are general purpose outputs. The outputs are open-collector and can be used to activate an external relay. Mind flyback diode.

Use the OSDP_OUT command to control the output state. The outputs allow for direct activation and deactivation plus timed operation (OSDP output control compliance level 3). The permanent command is volatile (does not transcend power cycles).

When the status of an output changes the reader will send an output status change report message OSDP_OSTATR.

Connections:

GRAY	Output 0 (D0/CLK)
PINK	Output 1 (D1/DAT)
BLACK	Ground (0V)
SHIELD	Shield connected to DC-ground

Output ratings:

Type	open collector (internal weak 5V pull-up resistor)
Max. voltage	+24 VDC
Max. current	200 mA

3.6 TAMPER SWITCH

An internal magnet provides tamper indication when the reader is dismounted. This contact may be connected to an external alarm system. The contacts are normally closed when the reader is in place.

Tamper switches of multiple readers can be connected in series.

Connections:

K2-6	Tamper switch (normally closed)
K2-7	Tamper switch (common)

Contact ratings:

Max. current 50 mA (0.5 Volt voltage drop)

Max. switching voltage +24 VDC

The tamper contact status is reported through OSDP_LSTATR event messages.

3.7 NEDAP ANTENNA INTERFACE

The Nedap antenna interface is used to connect the MACE reader to a TCC270 or to NEDAP AEOS access control hardware (e.g. AP1001).

Connections:

K1-6	Nedap antenna interface. Connect to ANT
K1-2	Ground. Connect to ANT GND

When using this connection the credentials must have the Nedap XS format!!!

OSDP firmware:

The OSDP firmware does not support the NEDAP antenna interface!!!

4 READER CONFIGURATION

The MACE readers can be configured easily using the MaceConfigTool software. This software tool can be downloaded from our partner portal

<https://portal.nedapidentification.com>.

Configuration allows to change:

- General settings.
- Reader settings; what to read and how.
- Communication output settings.

Some settings require expert knowledge. Leave settings unchanged, when their specific meaning is unclear.

It's always a good practice to save the configuration into a file for future reference or when requesting technical assistance from Nedap or its business partners.

4.1 CONFIG SOFTWARE

The MaceConfigTool software allows to configure all settings for the MACE reader. The software can interface with the reader using RS485.




Figure 5: MaceConfigTool software

Start the MaceConfigTool software and click CONNECT.

Select the following communication parameters and click OK.

- COM-port
- Baud rate
- Communication protocol (STANDARD or OSDP)
- Device address (only for OSDP)

When the connection is established, the software checks the MACE firmware version.

Check the ID List to see what is identified.

Check the Console to see the communication details. For details about the communication protocol refer to the firmware manual.

4.2 OPTIONS

The options menu gives access to various MACE reader configuration options.

4.2.1 USER MODE

Select user mode Simple or Advanced to adjust the user interface. User mode Nedap is intended to be used only when recommended by Nedap. Password is **mace**.

4.2.2 SEND CONFIG

Send configuration to reader.

This option will send all configuration settings to the reader and saves them into non-volatile memory of the reader. A message indicates that the configuration was sent successfully.

4.2.3 READ CONFIG

Read configuration from reader.

This option will read all* configuration settings from the reader. A message indicates that the configuration was read successfully.

* Security keys and passwords cannot be read from the reader.

4.2.4 SETUP BAUDRATE

Select the serial communication baud rate.

Possible selections are:

- 1200
- 2400
- 9600 (default OSDP)
- 19200
- 38400
- 57600
- 115200 (default STANDARD)

Click OK after changing the baud rate. Upon success the software will show a message and the baud rate in the software and reader have been changed. The new baud rate setting in the reader is saved to non-volatile memory.

Note that when using a separate interface converter, it may be required to update the baud rate setting in there as well.

4.2.5 SETUP OSDP DEVICE ADDRESS

Select the OSDP device address in range from 0 to 126. Default device address is 0.

4.2.6 RESET CONFIG

Reset configuration to factory defaults.

All settings will be reset to factory defaults. The reader will restart automatically afterwards.

4.3 SETTINGS

4.3.1 GENERAL

Hold time / repeat time

Set tag hold time. Default 1 sec. Max. 25 sec.

Enable 'repeat using hold-time interval' to repeat the communication output while the tag remains within read range.

Configuration password

Enter a configuration password to lock the configuration settings in the reader.

Without the password you cannot change any configuration settings. Please remember this password very carefully. By default the MACE reader has no configuration password.

*** Advanced user mode settings;

Nedap customer codes

The MACE reader is programmed with a customer code. Nedap tags or credentials may also have a customer code. Enable 'Read only if customer code is correct' to make the reader ignore tags that have an invalid customer code.

You may change the customer code(s) in the reader. You can configure up to 20 customer-codes in the MACE reader.

Identifiers without customer code

Other tags or credentials may not have a customer code. For example MIFARE DESFire cards or the MACE UID64. Enable or disable 'Allow reading ID-numbers without customer code'.

Heater

This setting is not used because the MACE Smart reader doesn't have a heater unit.

ID-source values

The MACE reader indicates on which source there was an identification. These ID-source identifier values are configurable by clicking on the link.

*** Nedap user mode settings;

Antenna modulation

This setting is only used for the Nedap antenna interface. See chapter 3.7. The setting defines how often the ID-number is sent on the antenna interface. Default settings is 30 cycles, which corresponds to ± 1 sec.

4.3.2 LED/BUZZER

LED and buzzer mode *

Automatic

MACE reader will automatically set the LED color and optionally beep upon identification. The LED color upon identification and during idle can be configured.

Remote (follow digital inputs)

The connected access control panel may control the LED and buzzer using the digital inputs. The corresponding LED colors can be configured. See chapter 3.3.

Direct (using serial commands)

The connected access control panel may control the LED and buzzer using commands on the serial interface. Details are described in the firmware manual.

LED brightness

Set LED brightness in range from 0 to 100%. Default 50%.

- * Using OSDP the LED and buzzer are controlled using the OSDP_LED and OSDP_BUZ commands. The Automatic mode and Remote control (follow digital inputs) settings are not supported.

4.4 READER SETTINGS

4.4.1 BLE

The MACE Bluetooth Low Energy (BLE) reader is a single mode Bluetooth Smart reader that complies with the Bluetooth Core specification 4.1. The Bluetooth reader implements the peripheral role.

Enable

Enable the MACE BLE module. This automatically starts the Bluetooth advertising.

Default bluetooth device name

Enable to have the default Bluetooth device name. This is recommended because the MACE app uses the Bluetooth device name for ranging purpose.

Ranging profile

Select ranging profile:

- P Proximity range (max $\pm$ 25 centimeter)
- S Short range (max $\pm$ 2 meter)
- M Medium range (max. $\pm$ 5 meter)
- L Long range (max $\pm$ 15 meter)

There is a lot of variation in performance of Bluetooth communication across the wide range of phones that are available today. Please take this into account when planning the commissioning and configuration of your application.

*** Advanced user mode settings;

Reader function

Select the reader function. This function is reserved for future use. It might trigger the MACE app to require user confirmation or pin verification.

Default M - MACE general purpose.

Reader sequence number

Used for MACE reader identification.

*** Nedap user mode settings;

Advertising interval

Default advertising interval is 100 msec.

TX power

Set TX power in dBm (default 8 dBm). Not each TX power setting is possible. The value will be rounded to the nearest possible TX power setting.

It is recommended to keep the highest possible TX power setting. This makes range checking more reliable.

TX correction

The TX correction (default 0 dBm) can be used for readers that are mounted on a location that affect the gain of the Bluetooth antenna.

Note:

Please be aware that, after changing the ranging profile it may take some time before the MACE app recognizes the update. When the ranging profile has been changed it may occur one or two times that the MACE app is still responding based on the prior settings.

The TX power and TX correction added together are sent within the advertisement data. They are used by the MACE app to implement range checking.

Set the TX correction to a positive value when the received signal is higher than expected. In other words; increasing the TX correction will result in a shorter range.

Note that smartphone specific corrections will be done by the MACE app.

Authentication

Bluetooth authentication should always remain enabled. The key will be diversified to ensure a unique security key per identifier.

4.4.2 NFC

Near Field Communication (NFC) is a wireless communication technique operating on 13 MHz. Read range is only few centimeters. NFC is currently not supported on Apple iOS. On Android at least version 4.4 (KitKat) is required.

Enable

Enable the MACE NFC reading.

*** Nedap user mode settings;

Application ID, file number, data length and offset

For MACE the following settings are required:

Application ID: A0000007151001

File number: 0

Data length: 0

Data offset: 0

Authentication

NFC authentication should always remain enabled. The key will be diversified to ensure a unique security key per identifier.

4.4.3 QR-CODE

These settings are not used because the MACE Smart reader does not have a barcode scanner.

4.4.4 DESFIRE

The MACE Smart reader features also a universal smartcard reader. It also supports reading MIFARE DESFire (EV1) cards.

*** Advanced user mode settings;

Enable

Enable to read custom MIFARE DESFire cards.

Data to read

Select to read the CSN (7-bytes) or DESFire file data.

Byte order

Select byte order normal or reversed.

For example CSN normal is = 04 6C 5E A2 BD 24 80

For example CSN reversed is = 80 24 BD A2 5E 6C 04

Application ID

Application ID. 6-digit hex. For example F12345.

File number

File number within range from 0 to 255.

Communication mode

Select Plain, MACed or Enciphered.

Data length and offset

Select the data length and offset in nibbles. Set data length and offset both to 0 (zero) to read the whole file. Nibbles are half bytes or digits.

For example file data is 0123456789ABCDEF.

Set data length to 3 and offset to 7.

This will result in the ID-number 789.

Encryption

Select the authentication/encryption method.

- None (skip authentication)

- Native DES/3DES

- ISO DES/3DES

- 3Key 3DES

- AES

Select the key number in range from 0 to 13.

Enter the read key. The length of the key depends upon the chosen encryption method.

Data conversion

Optionally select a data conversion option, for example BCD to HEX or HEX to BCD.

4.4.5 MIFARE

The MACE Smart reader features also a universal smartcard reader. It also supports reading Mifare Classic, Mifare Ultralight and Mifare Plus cards (SL3) cards.

*** Advanced user mode settings;

Enable

Enable to read custom Mifare cards.

Data to read

Select what to read from the Mifare card;

- CSN (can be 4-byte or 7-byte)

- Mifare Classic sector data

- Mifare Ultralight data

- Mifare Plus SL3

Byte order

Select byte order normal or reversed.

For example CSN normal is = A2 07 6E 43

For example CSN reversed is = 43 6E 07 A2

Sector number

Select sector using fixed sector number within range from 0 to 39.

MAD (Mifare Application Directory)

When using MAD the AID and MAD Key must be given.

MAD key for Mifare Classic is normally A0A1A2A3A4A5.

MAD key for Mifare Plus is normally A0A1A2A3A4A5A6A7 A0A1A2A3A4A5A6A7.

Block number

Block number to read data from. The block number must be in range from 0 to 3. For sectors 32 to 39 the block number can range from 0 to 15.

Page number

Mifare Ultralight page number to read data from. Must be in range from 0 to 15.

Read key

Select to use KeyA or KeyB for reading. Usually KeyA is used for reading.

Enter the read key. For Mifare Classic the key length is 6 bytes (12 hex digits).

For Mifare Plus SL3 the key length is 16 bytes (32 hex digits).

Data length and offset

Select the data length and offset in nibbles. Nibbles are half bytes or digits.

Each Mifare classic data block contains 16 bytes data = 32 nibbles.

For example sector data contains 1234500000000000000000000000000000.

Set data length to 5 and offset to 0.

This will result in the ID-number 12345.

Data conversion

Optionally select a data conversion option, for example BCD to HEX or HEX to BCD.

4.4.6 OTHER ID TYPES

The MACE Smart reader also support reading different RFID card types based upon 13 MHz. Enable the individual RFID card types as mentioned below.

The MACE Smart reader does not support reading PROX-LF (120/125 kHz) cards.

*** Advanced user mode settings;

MACE Card

Enable reading MACE Card.

HID iCLASS (UID only)

Enable reading HID iCLASS UID.

The HID iCLASS UID is the read-only 8-byte unique ID.

ISO15693

Enable reading ISO15693.

Different RFID cards comply with this standard, for example NXP ICODE SLI(X) and LEGIC Advant MP cards.

Reading the UID and/or multiple data blocks is supported.

The ISO15693 UID is the read-only 8-byte unique ID.

Read multiple blocks is supported for example by NXP ICODE SLI(X) cards.

Configure first block and number of blocks to read. Each block is 4 bytes.

4.5 COMMUNICATION OUTPUT

4.5.1 SERIAL

The serial communication output defines the format of the message that is transmitted upon identification. This serial output message format is used on the RS485 interface. See for interface connection details chapter 3.2.

STANDARD message format:

```
<prefix><id-source><id-type><id-number><suffix><cr><lf>
```

OSDP_RAW message format:

```
byte 0      Reader number (fixed value 0 = first reader)
byte 1      Format code (fixed value 0 = raw bit array)
byte 2/3    Bit count data length
byte 4/N    <id-source><id-type><id-number>
```

Prefix

Default prefix is '4005'. Can be any string of max. 10 characters.

Add ID-source

If enabled, the ID-source will be sent as a 2 digit code that identifies how the ID-number was read. The ID-source values can be changed. See chapter 4.3.1.

```
'00' PROX-LF (120/125 kHz)
'01' BLE
'02' NFC
'03' Barcode
'04' Smartcard (13 MHz)
'05' MIFARE
'06' DESFIRE
'07' ISO15693
'08' HID iCLASS
'09' MACE Card
```

Add ID-type

If enabled, the ID-type will be sent as a 2 digit code that identifies the programming format.

```
'00' RAW
'08' MACE UID64
'10' MACE UUID128
'45' EM4200
'4E' Nedap XS
'4F' Nedap RW80
'57' Wiegand
```

ID-number

Select to output the ID-number complete, left aligned or right aligned.

When left or right aligned specify the id-length and offset in bits.

Optionally convert the ID-number from hex to decimal.

Suffix

Default no prefix is used. Can be any string of max. 10 characters.

MACE SMART | INSTALLATION GUIDE

Reader configuration

Example:

MACE UID64 on BLE: '40050108B03BF925E6F04D34'<CR><LF>
'4005' = prefix
'01' = id-source BLE
'08' = id-type UID64
'B03BF925E6F04D34' = id-number

OSDP example:

MACE UID64 on BLE: 01, 08, B0, 3B, F9, 25, E6, F0, 4D, 34
01 = id-source BLE
08 = id-type UID64
B0, 3B, F9, 25, E6, F0, 4D, 34 = id-number

Prefix and suffix are not used.

4.5.2 WIEGAND/MAGSTRIPE

The Wiegand/Magstripe communication output defines the format of the Wiegand/Magstripe message that is transmitted upon identification.

Note that if the credential is already programmed in the Wiegand or Magstripe format these settings are not used. The Wiegand/Magstripe output settings are only used for ID-numbers that are not programmed in the Wiegand or Magstripe format.

The OSDP firmware does not output any Wiegand or Magstripe messages!!!

Unconfigured

Select unconfigured if the ID-numbers are already programmed in the Wiegand or Magstripe format or if the Wiegand/Magstripe interface is not used.

Wiegand

Select Wiegand to manually configure the Wiegand message output format.

Wiegand output message format:

```
<P1><prefix><id-src><facility-code><id-number><suffix><P2>
```

Parity

Enable add parity bits to add a leading and trailing parity bit to the Wiegand message. The leading parity bit (P1) is even calculated on the first half of the data bits. The trailing parity bit (P2) is odd calculated on the second half of the data bits. If the number of data bits used in the parity calculation is odd, then the center bit is used in both parity bit calculations.

Prefix

Constant prefix value. Max. 65,535 (16 bits).

ID-source

If enabled, the ID-source will be sent as an 8 bit code that identifies how the ID-number was read. The ID-source values can be changed. See chapter 4.3.1.

0	00000000	PROX-LF (120/125 kHz)
1	00000001	BLE
2	00000010	NFC
3	00000011	Barcode
4	00000100	Smartcard (13 MHz)
5	00000101	MIFARE
6	00000110	DESFIRE
7	00000111	ISO15693
8	00001000	HID iCLASS
9	00001001	MACE Card

Facility-code

Constant facility-code (or site-code) value. Max. 65,535 (16 bits).

ID-number

Select to output the ID-number complete, left aligned or right aligned.

When left or right aligned specify the ID-length and offset in bits.

MACE SMART | INSTALLATION GUIDE

Reader configuration

Convert BCD to binary

Enable to convert the BCD (decimal) ID-number to a binary value.

For example ID-number 987 = hex 3DB = b'11 1101 1011'.

Note that the conversion may reduce the amount of ID-number bits.

Conversion is only possible if ID-number before conversion is max. 80 bits.

When the ID-number is not in decimal, the result may be unexpected.

Suffix

Constant suffix value. Max. 65,535 (16 bits).

Wiegand configuration example:

The configuration shown below will generate a Wiegand 26-bit message with facility-code 10. The ID-number uses the 16 least significant bits (right aligned).

MACE UID64 B03BF925E6F04D34 → ID-number 0x4D34 = 19764.

Protocol
☐ Unconfigured (default)
☒ Wiegand
☐ Magstripe

ID number (N)

Right aligned

Length in bits

16

Offset in bits

0

☐ Convert BCD to binary

☒ Add leading and trailing parity bits (P)

☐ Add prefix (A)

☐ Add ID source 8 bits (B)

☒ Add facility-code (F)

Facility-code

10

Length in bits (max 16 bits)

8

☐ Add suffix (Z)

Wiegand 26-bit

P FFFFFFFF NNNNNNNNNNNNNNNN P

Figure 6: Example Wiegand 26-bit configuration

Magstripe

Select Magstripe to configure the Magstripe message output format.

Magstripe output message format:

```
<0xB><prefix><id-number><suffix><0xF><LRC>
```

Add start, stop-sentinel and LRC

According to the Magstripe ISO7811/2 standard the messages should begin with a start-sentinel (0xB) and finish with an stop-sentinel (0xF) and LRC checksum.

Add preamble and postamble clocks

If enabled the Magstripe output will generate 16 preamble clock cycles before the message and 16 postamble clock cycles afterwards.

Prefix

Constant prefix value transmitted before the ID-number. Max. 16 digits.

ID-number

Select to output the ID-number complete, left aligned or right aligned.

When left or right aligned specify the ID-length and offset in bits.

Convert to decimal

Enable to convert the ID-number to a decimal value. Default enabled because hexadecimal characters should be avoided within the ID-number. Hexadecimal characters are according to the ISO7811/2 standard reserved for message control.

Suffix

Constant suffix value transmitted after the ID-number. Max. 16 digits.

Reader configuration

Magstripe configuration example:

The configuration shown below will generate a Magstripe message. The ID-number uses the 6 least significant hex digits (right aligned) and they are converted to 8 decimal digits.

MACE UID64 B03BF925E6F04D34 → ID-number 0xF04D34 = 15.748.404.

After adding the start, stop-sentinel and LRC this results in message:

B15748404FB

Protocol
☐ Unconfigured (default)
☐ Wiegand
☒ Magstripe

ID number

Right aligned ▾

Length in digits
6

Offset in digits
0

☒ Convert to decimal

☒ Add start, stop-sentinel and LRC

☐ Add preamble and postamble clocks

Prefix (max 16 digits)

Suffix (max 4 digits)

Figure 7: Example Magstripe configuration

4.6 MISCELLANEOUS

4.6.1 FIRMWARE UPDATE

When the MaceConfigTool software is connected to a reader, it automatically checks the firmware version of the MACE Smart reader. If necessary the software recommends to perform a firmware update. A recent firmware version has been installed on your computer together with the software.

The firmware update can also be used to change from STANDARD to OSDP firmware (or vice versa).

Firmware update procedure:

- Start MaceConfigTool software.
- Connect with MACE reader.
- Go to FIRMWARE UPDATE.
- Select the firmware file (e.g. MaceSmart_v106.nis).
- Click Update and wait until completed.

When the firmware update is completed, the software will reconnect. Upon reconnect, make sure to select the correct protocol and baud rate setting. This might have been changed due to different firmware.

4.6.2 KEY UPDATE

The key update function updates the masterkey in the MACE Smart reader.

The MACE authentication keys (for BLE and NFC) are diversified to ensure a unique security key per credential. The diversification is done using a shared masterkey. The key update function updates the masterkey in the reader.

Important notice;

After the key update the reader will only read updated credentials.

Make sure to synchronize the update for readers and credentials (step 2 and 3).

Step 1. Start key update:

- Login to the MACE Admin Portal and start update masterkey.
- Download the encrypted masterkey update file (.nkey file).

Step 2. Key update procedure:

- Start MaceConfigTool software.
- Connect with MACE reader.
- Go to KEY UPDATE.
- Select the key update file (e.g. default.nkey).
- Click Update and wait until completed.


Step 3. Finish key update;

- Login to the MACE Admin Portal and finish update masterkey. This will update the credentials.

A TECHNICAL SPECIFICATIONS

Technical information	MACE Smart
Operating frequency	Bluetooth Low Energy 2.402 – 2.480 GHz NFC & smartcards: 13.56 MHz
Dimensions	100 x 50 x 22 mm [3.9 x 2 x 0.9 inch]
Weight	75 g [0.17 lbs]
Housing	Polycarbonate
Color	RAL7016
Protection	IP65 [approx.NEMA4x]
Detection range	Bluetooth Low Energy: configurable up to 25cm (proximity), 2m (short), 5m (medium) or 15m (long). NFC and smartcards: up to 5cm.
Supported RFID cards	ISO14443-3A, Mifare DESFire (EV1), Mifare Classic, Mifare Ultralight, Mifare Plus (SL3) ISO15693, HID iCLASS (UID only), MACE Card
Operating temperature	-30...+60°C (-22...+140°F)
Power	12 ... 24 VDC (from power-limited UL294 or UL603 Listed power source)
Current consumption	0.2A@12VDC, 0.1A@24VDC
Input	2 TTL digital inputs for LED control (RED/GREEN) 1 TTL digital input for beeper control
Tamper indication	Yes, magnetic tamper switch
Cable length	Wiegand 150 m [500 ft.] 22AWG RS485 1200 m [3950 ft.] when installed properly
Interfaces	RS485 interface. Please consult your representative for additional interfacing options.
Output	Wiegand, Magstripe (clock & data)
Compliance	Europe RE Directive 2014/53/EU USA: FCC Title 47 Part 15B and 15C Canada: ISED ICES-003 and RSS210
Certifications	Safety: EN60950-1 EMC: EN301489 Telecom: EN330 330 and EN300 328 Human Exposure assessment: ICNIRP Guidelines, EN62369 and EN50364 UL294
UL	UL294 6th ed. – outdoor usage

B PART NUMBERS

Readers	Part number	Description
	9565914	MACE Smart

C FCC AND ISED DECLARATIONS

FCC ID: CGDMACER1 and IC: 1444A-MACER1

FCC (15.19) and ISED Compliance statement

This device complies with part 15 of the FCC Rules and to RSS210 of Industry Canada. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning (15.21)

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Cet appareil se conforme aux normes RSS 210 exemptés de license du Industry Canada. L'opération est soumise aux deux conditions suivantes:

- (1) cet appareil ne doit causer aucune interférence, et
- (2) cet appareil doit accepter n'importe quelle interférence, y compris l'interférence qui peut causer une opération non prévue de cet appareil.

Les changements ou modifications n'ayant pas été expressément approuvés par la partie responsable de la conformité peuvent faire perdre à l'utilisateur l'autorisation de faire fonctionner le matériel.

FCC and ISED Radiation Exposure Statement

This equipment complies with FCC (OET Bulletin 65) and Canadian radiation exposure limits set forth in RSS-102 for a uncontrolled environment. This equipment should be installed and operated with a minimum distance of 3 mm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Cet équipement est conforme à RSS-102 limites énoncées pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec une distance minimale de 3 mm entre le radiateur et votre corps.

ISED EMC Declaration

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de Classe B est conforme à la norme Canadienne ICES-003.

FCC Information to the user (15.106(b))

Note: This equipment has been tested and found to comply with the limits for a class B digital devices, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does not cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- To ensure compliance with FCC regulations, use only the shielded interface cables provided with the product, or additional specified components or accessories that can be used with the installation of the product.

D DISCLAIMER

This information is furnished for guidance, and with no guarantee as to its accuracy or completeness; its publication conveys no license under any patent or other right, nor does the publisher assume liability for any consequence of its use; specifications and availability of goods mentioned in it are subject to change without notice; it is not to be reproduced in any way, in whole or in part, without the written consent of the publisher.

E DOCUMENT REVISION

Version	Date	Comment
1.03	2018-01-30	Updated technical specification and product photos
1.02	2017-12-20	Updated technical specification and tamper contact status report (OSDP)
1.01	2017-10-02	Added ISO15693 read multiple blocks
1.00	2017-09-13	Initial release

MACE SMART

Installation sheet


2018-01-25 | v1.02 | 5286573

INCLUDED MATERIALS

- 1 x MACE Smart reader
- 1 x Installation manual
- 1 x Plastic bag including:
 - 1 x Connector block 6P
 - 1 x Connector block 7P
 - 2 x Assembly screw M3x8 T10 (1x spare part)
 - 2 x Plug Nylon
 - 2 x Mounting screw K30x20 T10

ADDITIONAL REQUIREMENTS

- Drill
- Screwdriver torx T10
- Pliers (optionally)
- RS485-USB converter (optionally)
- Cable AWG 22-30 shielded (advised)



SAFETY INSTRUCTIONS

The following safety precautions should be observed during normal use, service and repair:

- The MACE Smart reader may only be installed and serviced by qualified service personnel.
- Disconnect the power supply before (dis)connecting any wires, MACE is NOT hot-swappable, so when making or changing connections, power must be switched OFF.
- The cable shield shall be connected with safety ground and the metal case of the external device(s).
- To be sure of safety, do not modify or add anything to the MACE Smart reader other than mentioned in this installation guide or indicated by NEDAP N.V.

CONFIGURATION

The MACE Smart reader can be configured easily using the MaceConfigTool software. This software tool can be downloaded from our partner portal <https://portal.nedapidentification.com>. Configuration allows to change general settings, reader settings (what to read and how) and communication output settings. It also allows updating or changing the firmware (e.g. STANDARD and OSDP). When your computer does not have an RS485 output, an RS485-USB converter can be used to connect with the MACE Smart reader.

Some settings require expert knowledge. Leave settings unchanged, when their specific meaning is unclear. Besides, it is always a good practice to save the configuration into a file for future reference or when requesting technical assistance from Nedap or its business partners.

MOUNTING INSTRUCTIONS

Please follow the next steps to properly mount the MACE Smart reader to a surface.

1. Position the reader

Make sure that the reader is positioned such that it is placed correctly covering the cable entry hole and that the screw hole is located at the bottom side of the reader.

2. Mount the wall-plate on the required location

The reader can be mounted to any surface, including directly to metal. The size of the holes that should be drilled depends on the material of your surface. Fix the wall-plate into its position using the two mounting screws attached and a torx T10 screwdriver.

Surface material	Size of holes	Use of plugs
Concrete or stone	5.0 mm (0.20 inch)	Yes
Wood	2.5 mm (0.10 inch)	No

3. Feed the cable through the cable entry hole and connect the cable

Connect the cable to the connector blocks attached according to the overview below.


Nedap antenna interface	K1-6	K2-1	RS485 A (-)
Beeper_IN*	K1-5	K2-2	RS485 B (+)
Led_UL_IN*	K1-4	K2-3	Ground
Led_NA_IN*	K1-3	K2-4	Data-1 / Data
Ground	K1-2	K2-5	Data-0 / Clock
Power supply 12 - 24VDC	K1-1	K2-6	Tamper switch (normally closed)
		K2-7	Tamper switch (common)

4. Place the connectors

Place the connectors over the pin headers at the backside of the reader. Make sure that the correct connector block is placed on the correct pin header (6P vs. 7P). Place the connectors such that the topside of the connectors (recognizable by the screws) remains visible after it has been placed on the reader.

5. Attach the MACE Smart reader onto the wall-plate

Attach the reader onto the wall-plate according to the three steps in the illustration. Finish with fixing the assembly using the assembly screw at the bottom and the torx T10 screwdriver.



INSTALL GUIDE

More information about the configuration and installation of the MACE Smart reader can be found in the MACE Smart Install Guide, available on our partner portal <https://portal.nedapidentification.com>.

TECHNICAL SUPPORT

For technical support, please call: +31 (0)544 471 222 or email support@nedapidentification.com.