




If you select **ETHERNET PORT 1** from the **WAN Port** drop-down arrow, the following screen will be displayed. Click **OK**.




If you click on **OK** in the preceding pop-up screen, the following screen will be displayed. Click on **OK**. If you click on **Cancel**, the change will not take effect.



If you clicked on **OK** in the preceding pop-up screen, the following pop-up screen will appear. The Router must be reset to allow the new configuration to take effect. Click on **OK**.



If you clicked on **OK** in the preceding screen, the following screen will be displayed. The Router will be reset and the new configuration will take effect.



After the Router has been reset, the DSL LED will be OFF. This is because the DSL transceiver has now been disabled. However, the **Power**, **Ethernet**, and **Wireless** LEDs will remain lit.

13.6.4 Editing the Router's VC Configuration

The following **VC 1 Configuration** screen will be displayed if you click on the **edit** button adjacent to any of the 'Enabled' protocols displayed in the **WAN Configuration** screen. (Note: The Protocol must be enabled before you can edit its VC configuration.) The **VC 1 Configuration** screen allows you to edit your virtual connection (VC). A virtual connection identifies a connection through the service provider's ATM network to your ISP. Unlike physical hardware connections, virtual connections are defined by data.

If you change any of the VC settings in the following screen, click the **Set VC** button to save the settings.

NOTE: If you experience any problems, please reset the Router via the external hardware reset button or via the procedure defined under the **Maintenance** menu in section 15.1. The actual information displayed in this screen may vary, depending on network connection established.

VC 1 Configuration

VPI

VCI

PCR

QoS

Protocol

Status Enabled

VC 1 - PPPoE Settings

IP Address

Gateway

DNS Primary

DNS Secondary

MRU Negotiation ☐

LCP Echo Disable ☐

LCP Echo Failures
"Must be between 1 and 30 inclusive."

LCP Echo Duration
"Must be between 5 and 300 seconds inclusive and greater or equal to Retry Duration."

LCP Echo Retry Duration
"Must be between 5 and 300 seconds inclusive."

Tunneling ☒ Enable ☐ Disable

[Help](#)

VC 1 Configuration	
VPI	This setting allows you to change your VPI (Virtual Path Indicator) value for a particular VC, which is defined by your Service Provider.
VCI	This setting allows you to change your VCI (Virtual Channel Indicator) value for a particular VC, which is defined by your Service Provider.
PCR	Factory Default = 100% Peak Cell Rate (PCR)-The maximum rate at which cells can be transmitted across a virtual circuit, specified in cells per second and defined by the interval between the transmission of the last bit of one cell and the first bit of the next. This value is a percentage of the current data rate. 100 allows this VC to use 100% of the available bandwidth. 80 allows this VC to use 80% of the available bandwidth.
QoS	Quality of Service, which is determined by your Service Provider. Possible Responses: CBR = Constant Bit Rate UBR = Unspecified Bit Rate VBR = Variable Bit Rate


Protocol	The Protocol for each VC, which is specified by your Service Provider. Possible Responses: PPPoA = Point to Point Protocol over ATM (Asynchronous Transfer Mode) PPPoE = Point to Point Protocol over Ethernet Bridge = Bridge Protocol Classical IPoA = Internet Protocol over ATM (Asynchronous Transfer Mode). This is an ATM encapsulation of the IP protocol.
Status	The protocol status.
VC x PPPoE Settings	
IP Address	Displays the IP network address that your modem is on.
Gateway	Displays the Router's IP address
DNS Primary	Provided by your Service Provider
DNS Secondary	Provided by your Service Provider
MRU Negotiation	Factory Default = DISABLED If ENABLED, the Maximum Received Unit (MRU) would enforce MRU negotiations. (NOTE: enable this option only at your Internet Service Provider's request.)
LCP Echo Disable	Factory Default = Enable If checked, this option will disable the modem LCP Echo transmissions.
LCP Echo Failures	Indicates number of continuous LCP echo non-responses received before the PPP session is terminated.
LCP Echo Retry Duration	The interval between LCP Echo transmissions with responses.
LCP Echo Retry Duration	The interval between LCP Echo after no response.
Tunneling	Factory Default = ENABLE If ENABLED, this option allows PPP traffic to be bridged to the WAN. This feature allows you to use a PPPoE shim on the host computer to connect to the Internet Service Provider, by bypassing the Router's capability to do this. NOTE: Tunneling is available in PPPoE mode only.

NOTE: The values for the IP Address, Gateway, DNS Primary, and DNS Secondary are all "Override of the value obtained from the PPP connection," They default to "0.0.0.0," in which case the override is ignored. Westell recommends that you do not change the values unless your Internet service provider instructs you to change them.


If you have made any changes to your VC settings, you need to save them. To save the new VC settings, click on **OK** when asked **Set this PPPoE VC configuration?** If you click on **cancel**, the new VC settings will not be saved.



If you clicked on **OK** in the preceding pop-up screen, the following pop-up screen will appear. The Router must be reset to allow the new configuration to take effect. Click **OK**.



If you clicked **OK** in the preceding screen, the following screen will be displayed. The Router will be reset and the new configuration will take effect.




After a brief delay, the home page will be displayed. Confirm that you have a DSL sync and that your PPP session displays **UP**. (Click on the **connect** button to establish a PPP session).

13.6.5 Configuring the Router's Protocol Settings for PPPoE Mode

If you are using Models 7400, 7401 select **Advanced WAN > VC** from the **Configuration** menu to configure the Router's protocol settings for **PPPoE** mode. If you are using Models 328W10, 328W11, select **Advanced WAN > WAN** from the **Configuration** menu to configure the Router's protocol settings for **PPPoE** mode.

The **VC Configuration** screen will be displayed. Next, click on the **edit** button adjacent to any of the existing 'Enabled' VC (Virtual Connection) protocols. (Note: The protocol status must display "Enable" to allow edits to its VC configuration.).

If you clicked **edit** in the **VC Configuration** screen, the following **VC 1 Configuration** screen will be displayed. Select **PPPoE** from the options listed in **Protocol** drop-down arrow. After you have made changes to **VC 1 Configuration** screen, click the **set VC** button.



VC 1 Configuration

VPI 0

VCI 35

PCR 100

QoS UBR

Protocol PPPoE

Status PPPoA
PPPoE
Bridge
Classical IPoA

IP Address

Gateway 0.0.0.0

DNS Primary 0.0.0.0

DNS Secondary 0.0.0.0

MRU Negotiation ☐

LCP Echo Disable ☐


LCP Echo Failures 6

"Must be between 1 and 30 inclusive."

LCP Echo Duration 60

"Must be between 5 and 300 seconds inclusive and greater or equal to Retry Duration."

If you click the **set VC** button, the following pop-up screen will be displayed. Click on **OK** in the pop-up screen. If you click on **Cancel**, the new settings will not be saved. After you click on **OK**, follow the instructions to reset the Router, as previously discussed in section 13.6.4.




13.6.6 Configuring the Router's Protocol Settings for Bridge Mode

If you are using Models 7400, 7401 select **Advanced WAN > VC** from the **Configuration** menu to configure the Router's protocol settings for **Bridge** mode. If you are using Models 328W10, 328W11, select **Advanced WAN > WAN** from the **Configuration** menu to configure the Router's protocol settings for **Bridge** mode.

The **VC Configuration** screen will be displayed. Next, click on the **edit** button adjacent to any of the existing 'Enabled' VC (Virtual Connection) protocols. (Note: The protocol status must display "Enable" to allow edits to its VC configuration.)

If you clicked **edit** in the **VC Configuration** screen, the following **VC 1 Configuration** screen will be displayed. Select **Bridge** from the options listed in **Protocol** drop-down arrow. Next, select a mode from the options listed in the **Mode** drop-down arrow, under **VC1 – Bridge Settings**. After you have made changes to **VC 1 Configuration** screen, click the **set VC** button.



VC 1 Configuration

VPI 0
VCI 35
PCR 100
QoS UBR
Protocol Bridge
Status Enabled

VC 1 - Bridge Settings


Mode Bridge

set VC

[Help](#)


VC 1 Configuration	
VPI	This setting allows you to change your VPI (Virtual Path Indicator) value for a particular VC, which is defined by your Service Provider.
VCI	This setting allows you to change your VCI (Virtual Channel Indicator) value for a particular VC, which is defined by your Service Provider.
PCR	Factory Default = 100% Peak Cell Rate (PCR)-The maximum rate at which cells can be transmitted across a virtual circuit, specified in cells per second and defined by the interval between the transmission of the last bit of one cell and the first bit of the next. This value is a percentage of the current data rate. 100 allows this VC to use 100% of the available bandwidth. 80 allows this VC to use 80% of the available bandwidth.
QoS	Quality of Service, which is determined by your Service Provider. Possible Response: CBR = Constant Bit Rate UBR = Unspecified Bit Rate VBR = Variable Bit Rate
Protocol	The Protocol for each VC, which is specified by your Service Provider. Possible Response: PPPoA = Point to Point Protocol over ATM (Asynchronous Transfer Mode) PPPoE = Point to Point Protocol over Ethernet Bridge = Bridge Protocol Classical IPoA = Internet Protocol over ATM (Asynchronous Transfer Mode). This is an ATM encapsulation of the IP protocol.
Status	The protocol status.
VC 1 Bridge Settings	
Mode	Bridge = A bridge is a layer 2 device that connects two segments of the same LAN that use the same protocol such as Ethernet. The modem does not have a WAN IP address in this mode. The client PC will typically get an IP address from a DHCP server in the network or the IP address can be assigned to the client PC statically.
	Routed Bridge = Routed Bridged Encapsulation (RBE) is the process by which a bridged segment is terminated on a routed interface. Specifically, the Router is routing on an IEEE 802.3 or Ethernet header carried over RFC 1483 bridged ATM. RBE was developed to address the known RFC1483 bridging issues, including broadcast storms and security. The modem will get a WAN IP address through DHCP or can be assigned statically. NAT will use the global address assigned to the modem.
	Proxy Bridge = Proxy Bridge is the process in which the modem acts as a proxy ARP agent for a local public subnet. The modem will be assigned an IP address from within that public subnet. The modem will direct all traffic to a Router, which is configured statically. The Router's address must not reside within Router's assigned public subnet. All traffic will be sent via the Router's MAC address. The LAN may also have a private NAT'ed network. NAT will use the global address assigned to the modem.
	VLAN Bridge = Assigns VLAN tags to individual data ports on the modem.

If you selected the **Routed Bridge** mode under **VC 1- Bridge Settings**, the following screen will be displayed. Enter the appropriate values in the fields and click on **set VC**.



VC 1 – Bridge Settings (Routed Bridge)	
Mode	The Mode you have selected to use with Bridge protocol.
DHCP Client	Selecting a radio button allows you to either Enable or Disable the DHCP Client.
IP Address	Displays the IP network address that your modem is on.
Subnet Mask	Displays the subnet mask, which determines if an IP address belongs to your local network.
Gateway	Displays the Router's IP gateway address.
DNS Primary	Provided by your Service Provider.
DNS Secondary	Provided by your Service Provider.

If you selected **Proxy Bridge** mode under **VC 1- Bridge Settings**, the following screen will be displayed. Enter the appropriate values in the fields and click on **set VC**.



VC 1 Configuration

VPI

VCI

PCR

QoS

Protocol

Status Enabled

VC 1 - Bridge Settings

Mode

Gateway


DNS Primary

DNS Secondary

[Help](#)

VC 1 - Bridge Settings (Proxy Bridge)	
Mode	The Mode you have selected to use with Bridge protocol.
Gateway	Displays the Router's IP address.
DNS Primary	Provided by your Service Provider.
DNS Secondary	Provided by your Service Provider.

If you selected **VLAN Bridge** under **VC 1- Bridge Settings**, the following screen will be displayed. Enter the appropriate values in the fields and click on **set VC**.



VC 1 Configuration

VPI

VCI

PCR

QoS

Protocol

Status Enabled

VC 1 - Bridge Settings

Mode

VLAN ID:


VLAN Priority:

VLAN on WAN ☐ Enable ☒ Disable

[Help](#)

VC 1 - Bridge Settings (VLAN Bridge)	
Mode	The Mode you have selected to use with Bridge protocol. VLAN is used to assign VLAN tags to individual data ports on the modem.
VLAN ID	Assigns a VLAN ID to the port.
VLAN Priority	This will set the VLAN priority for the port.
VLAN on WAN	Factory Default = DISABLE Selecting Enable allows VLAN tagging to occur according to the data port's configuration.

After you have configured the **VC 1 Configuration** screen, you must click the **set VC** button to save your VC settings.



VC 1 Configuration

VPI

VCI

PCR

QoS

Protocol

Status Enabled

VC 1 - Bridge Settings

Mode

DHCP Client ☐ Enable ☒ Disable

IP Address

Subnet Mask


Gateway

DNS Primary

DNS Secondary


[Help](#)

If you click the **set VC** button, the following pop-up screen will be displayed. Click on **OK** in the pop-up screen. If you click on **Cancel**, the new settings will not be saved. After you click on **OK**, follow the instructions to reset the Router, as previously discussed in section 13.6.4.




13.6.7 Configuring VC Protocol Settings for ETHERNET PORT 1 (Models 328W10 and 328W11 only)


To configure the Router's VC settings via the Ethernet UPLINK/E1 port, select **ETHERNET PORT 1** at the **WAN Port** drop-down arrow. By selecting **ETHERNET PORT 1**, you will disable the Router's DSL transceiver. This will enable the WAN Ethernet port and allow the WAN interface to use the UPLINK/E1 Port.




If you select **ETHERNET PORT 1**, the following pop-up will be displayed. Click on **OK**.




If you click on **OK**, the following pop-up screen will be displayed. Click on **OK**.




If you clicked on **OK** in the preceding pop-up screen, the following pop-up screen will be displayed. Click on **OK**.




If you clicked on **OK**, the following screen will be displayed. The Router will be reset and the new configuration will take effect.




After the Router has been reset, select **Advanced WAN > WAN** from the **Configuration** menu. The following screen will be displayed.



If you click **edit**, the following screen will be displayed. By using this screen, you can configure the WAN Ethernet port settings of your Router.




To configure the WAN Ethernet port for Routed Bridge protocol, select **ROUTED** from the **Protocol** drop-down arrow.



The screenshot shows the "WAN Ethernet Configuration" window in Microsoft Internet Explorer. The "Protocol" dropdown is set to "PPPoE", and the "Status" dropdown is set to "ROUTED". The "PPPoE Settings" section includes fields for "IP Address", "Gateway", "DNS Primary", and "DNS Secondary", all set to "0.0.0.0". There are checkboxes for "MRU Negotiation" and "LCP Echo Disable", both of which are unchecked. The "LCP Echo Failures" field is set to "6" with a note: "Must be between 1 and 30 inclusive." The "LCP Echo Duration" field is set to "60" with a note: "Must be between 5 and 300 seconds inclusive and greater or equal to Retry Duration." The "LCP Echo Retry Duration" field is set to "10" with a note: "Must be between 5 and 300 seconds inclusive." The "Tunneling" section has "Enable" selected. At the bottom are "set" and "cancel" buttons.

If you select **ROUTED**, the following screen will be displayed. Enter the appropriate values in the fields and click on **set**.




The screenshot shows the "WAN Ethernet Configuration" window in Microsoft Internet Explorer. The "Protocol" dropdown is set to "ROUTED", and the "Status" is "Enabled". The "Router Settings" section includes a "DHCP Client" section with "Enable" and "Disable" radio buttons, where "Disable" is selected. Below this are fields for "IP Address", "Subnet Mask", "Gateway", "DNS Primary", and "DNS Secondary", all set to "0.0.0.0". The "Subnet Mask" field is set to "255.255.255.255". At the bottom are "set" and "cancel" buttons, and a "Help" link.


If you clicked on **set**, the following pop-up screen will be displayed. Click on **OK**.




If you clicked on **OK** in the preceding pop-up screen, the following pop-up screen will appear. The Router must be reset to allow the new configuration to take effect. Click on **OK**.



If you clicked on **OK** in the preceding screen, the following screen will be displayed. The Router will be reset and the new configuration will take effect.



After the modem has been reset, the **WAN Configuration** screen will display **Routed Bridge** as the protocol for **ETHERNET PORT 1**.




13.6.8 QOS

The following settings will be displayed if you select **Advanced WAN > QOS** from the **Configuration** menu. If you change any settings in this screen, click on **save**. If you click on **reset**, this screen will refresh and display your previously saved QOS configuration.

IMPORTANT: If you are using Model 328W10 or 328W11 and the Router is configured for **ETHERNET PORT 1**, the **QOS** option will not be displayed in the **Advanced WAN** drop-down menu. You must configure the Router for **DSL ATM PORT** to access **QOS**. Refer to section 13.6.3.1 for details on enabling and disabling DSL ATM PORT and ETHERNET PORT 1.


NOTE: The QOS feature helps ensure data integrity in high-speed transmissions. QOS provides the capability to partition network traffic into multiple priority levels or classes of service. After packet classification, other QOS features can be utilized to assign the appropriate traffic handling policies including congestion management, bandwidth allocation, and delay bounds for each traffic class.



QOS Enable	Factory Default = DISABLED If this box is checked, Quality of Service (QOS) will be Enabled.
Turbo TCP Enable	Factory Default = DISABLED If this box is checked, Turbo TCP will be Enabled.
QOS Configuration	
QOS Filter Enable	Factory Default = DISABLED If this box is checked, this will Enable the QOS filter.


QOS Classification	This feature provides the capability to partition network traffic into multiple priority levels or classes of service. After packet classification, other QOS features can be utilized to assign the appropriate traffic handling policies including congestion management, bandwidth allocation, and delay bounds for each traffic class. Possible responses are: Best Effort (BE) Assured Forwarding (AF1) Assured Forwarding (AF2) Assured Forwarding (AF3) Assured Forwarding (AF4) Expedited Forwarding (EF) Network Control (NC)
Peak Information Rte (%)	The maximum allowed rate for this priority, expressed as a percentage of the DSL rate.
Committed Information Rate (%)	The committed rate for this priority, expressed as a percentage of the DSL rate.
Peak Burst Size	The interval in milliseconds for averaging the peak offered rate.
Committed Burst Size	The interval in milliseconds for averaging the committed offered rate.
Max Queue Size	The number of packets that can be queued for this priority.
Latency Measurements	
Latency Boundary	This configures the maximum latency boundary in milliseconds that a specific packet may be delayed by.
Latency Threshold (ms)	This setting configures the maximum latency boundary in milliseconds that a specific packet may be delayed by. Possible responses are: Boundary 1:0 ms Boundary 2:10 ms Boundary 3:30 ms Boundary 4:40 ms Boundary 5:100 ms Boundary 6:1000 ms Boundary 7:3000 ms
IP Fragmentation Enable	Factory Default = DISABLED If this box is checked, IP Fragmentation will be Enabled. If Enabled and packets larger than 1500 bytes total are received, they will be fragmented.
IP Fragment Size	This is the IP Packet Size. Possible responses are: 100, 148, 244, 292, 340, 388, or 436

If you made changes to the **QOS Configuration** and clicked on **save**, the following screen will be displayed. Click on **OK**. This will save your new QOS settings.



13.6.9 Route

The following settings will be displayed if you select **Advanced WAN > Route** from the **Configuration** menu. The Route table maintains the routes or paths of where specific types of data shall be routed across a network.



Route

IP Interfaces

Address	Subnet Mask	Name
127.0.0.1	255.0.0.0	lo0
192.168.1.1	255.255.255.0	eth0
10.16.90.8	255.255.255.255	mainPPP

Network Routing Table

Destination	Subnet Mask	Gateway	Interface	Metric	Rip
0.0.0.0	0.0.0.0	10.16.90.8	mainPPP	0	N/A
192.168.1.0	255.255.255.0	192.168.1.1	eth0	0	N/A

Host Routing Table

Destination	Gateway	Interface	Metric	Rip
10.16.90.8	127.0.0.1	lo0	0	N/A
127.0.0.1	127.0.0.1	lo0	0	N/A
192.168.1.1	127.0.0.1	lo0	0	N/A

Inactive Routes

Destination	Subnet Mask	Gateway	Interface	Metric	Rip
-------------	-------------	---------	-----------	--------	-----

Add Route

Destination:

Address: OR ☐ Host Route

Subnet Mask: OR ☐ LAN Gateway Address

Gateway: OR

Metric:

RIP Config:

☒ Save To Modem

To add a Route, enter a **Subnet Mask** address, or check the **Host Route** box. Click on the **add** button to establish a static route.

IP Interfaces	
IP Interfaces	The list of active interfaces on the modem and their IP and Subnet mask address. Eth0 is the local LAN interface. Lo0 is the loopback interface. MainPPP is the WAN interface
Address	The IP interface address.
Subnet Mask	The IP interface subnet address.
Name	The IP interface device name.
Network Routing Table	
Network Routing Table	The list of network routes. These can be either routes for directly connected interfaces or static routes.
Destination Address	The IP address or subnet of the Route.
Subnet Mask	If the Route is a network route, Subnet Mask is used to specify the subnet address. If the Route is a Host route, then the Host Route check box is used.
Gateway	Indicates where to send the packet if it matches this route.
Interface	Indicates where to send the packet if it matches this route.
Metric	The RIP metric to be assigned to this route if and when it is advertised using RIP.
RIP	Indicates whether a static route should be advertised via RIP.
Host Routing Table	
Host Routing Table	The list of host routes. A host route is an IP route with a 32-bit mask, indicating a single destination (as opposed to a subnet, which could match several destinations.)
Destination Address	The IP address or subnet of the Route.
Subnet Mask	If the Route is a network route, Subnet Mask is used to specify the subnet address. If the Route is a Host route, then the Host Route check box is used.
Gateway	Indicates where to send the packet if it matches this route.
Interface	Indicates where to send the packet if it matches this route.
Metric	The RIP metric to be assigned to this route if and when it is advertised using RIP.
RIP	Indicates whether a static route should be advertised via RIP.
Inactive Routes	
Inactive Routes	Static routes whose interface is currently not in service.
Destination Address	The IP address or subnet of the Route.
Subnet Mask	If the Route is a network route, Subnet Mask is used to specify the subnet address. If the Route is a Host route, then the Host Route check box is used.
Gateway	Indicates where to send the packet if it matches this route.
Interface	Indicates where to send the packet if it matches this route.
Metric	The RIP metric to be assigned to this route if and when it is advertised using RIP.
RIP	Indicates whether a static route should be advertised via RIP.
Add Route	
Add Route	This is used to add a new static route in the modem.
Destination Address	The IP address or subnet of the Route.
Subnet Mask/ Host Route	If the Route is a network route, Subnet Mask is used to specify the subnet address. If the Route is a Host route, then the Host Route check box is used.
Gateway/LAN Gateway IP Address	The interface to use for sending the packet, if it matches this route. (Only active Routers can be used to create a static route.)
Metric	The RIP metric to be assigned to this route if and when it is advertised using RIP.
RIP Conf	Determines whether or not to advertise the static route, using RIP. (RIP must also be enabled before the route will be advertised.)
Save to Modem	If checked, then the route will be made permanent by saving it to flash memory. If not checked, the route will disappear the next time the modem restarts.

13.6.10 RIP

The following details will be displayed if you select **Advanced WAN > RIP** from the **Configuration** menu. If you change any settings in this screen, click on **save**. If you click on **reset**, this screen will refresh and display your last saved RIP configuration.

RIP (Routing Interface Protocol) is a dynamic inter-network routing protocol primarily used in interior routing environments. A dynamic routing protocol, as opposed to a static routing protocol, automatically discovers routes and builds routing tables.



The screenshot displays the Westell RIP Configuration web interface. At the top, the Westell logo and tagline "Discover Better Broadband" are visible, along with a navigation menu containing "Home", "Status", "Configuration", "Maintenance", "Troubleshooting", and "Help". Below the navigation menu, a "RIP Configuration" tab is selected. The main configuration area is divided into two sections: "RIP Configuration" and "Advanced".

RIP Configuration Section:

- RIP Enable:** A checkbox that is currently unchecked.
- Interface Type:** A dropdown menu set to "LAN".
- Receive:** A dropdown menu set to "RIPv2".
- Transmit:** A dropdown menu set to "RIPv2".
- RIPv2 Authentication Mode:** A dropdown menu set to "None".


Advanced Section:

- Default Gateway:** A checkbox that is currently unchecked.
- Border Gateway Filtering:** A checkbox that is currently checked.
- RIP Timer Rate:** A text input field containing the value "1".
- RIP Supply Interval:** A text input field containing the value "30".
- RIP Expire Time:** A text input field containing the value "180".
- RIP Garbage Collection Time:** A text input field containing the value "300".

At the bottom of the configuration area, there are two buttons: "save" and "reset".

RIP Enable	Factory Default = DISABLED If this box is checked, RIP will be Enabled (turned ON).
RIP Configuration	
Interface Type	LAN: Select this if you are configuring RIP for the LAN side. WAN: Select this if you are configuring RIP for the WAN side. (WAN side is receive only.)
Receive	The version of RIP to be accepted. Possible responses are: None RIPv1 RIPv2 RIPv1 or RIPv2
Transmit	The version of RIP to be transmitted. (WAN side RIP never transmits) Possible responses are: None RIPv1 RIPv1 Compatible RIPv2
RIPv2 Authentication Mode	If using RIP V2, you must select the type of authentication to use. Possible responses are: None Clear Text MD5 (If MD5 authentication, the password)
Advanced	
Default Gateway	Factory Default = DISABLED If this box is check (Enabled), this feature will determine whether the modem advertises itself as the default Gateway (i.e., the default route)
Border Gateway Filtering	Factory Default = ENABLED If this box is unchecked (Disabled), the modem will not summarize subnets into a single route before advertising.
RIP Timer Rate	Indicates how often to update the local routing table.
RIP Supply Interval	Indicates how often to advertise routes to neighbors.
RIP Expire Time	Indicates how long routes received from neighbors become invalid, if no refresh of the route is received.
RIP Garbage Collection Time	Indicates how long to advertise invalid routes after they have expired.

If you change any settings in the **RIP Configuration** screen and clicke on **save**, the following screen will be displayed. Click on **OK** to save your new RIP settings.




14. SETTING UP ADVANCED SERVICE CONFIGURATION

You can set up additional Service Configuration options for the Router that allow you to enter the port forwarding and trigger ports ranges of your choice. Go to **Configuration** at the homepage menu and select **Services**.

When you click on **define custom service** in the **Service Configuration** screen, the **Custom Service** screen will guide you through the steps of creating an advanced NAT service entry via the **define custom service** button.


NOTE: Westell strongly recommends that you do not change any values in this section. If you experience any problems, please reset the Router via the external hardware reset button or the procedure defined under the **Maintenance** menu.



Port Forwarding Ranges of Ports	This option allows you to forward a range of WAN ports to an IP address on the LAN.
Trigger Ports	This option allows you to forward a range of ports to an IP address on the LAN only after specific outbound traffic.

14.1 Port Forwarding Ranges of Ports

To select **Port Forwarding Ranges of Ports**, click on **define custom service** from the **Service Configuration** screen, and then select **Port Forwarding Ranges of Ports** from the **Custom Service** screen. Click on **Next**. The **Port Range** screen will be displayed. Enter your values in the **Global Port Range** fields and click **next** to continue.



Custom Service

Set Up a Port Forwarding entry based on your specific ports

☒ Port Forwarding Ranges of Ports Forward a range of WAN ports to an IP address on the LAN
☐ Trigger Ports Forward a range of ports to an IP address on the LAN only after specific outbound traffic

next cancel

Port Range

Set Up a Port Forwarding range entry based on your specific ports

Service Name:
The above name will be saved as this Services description

Global Port Range: -


Base Host Port:

Protocol: ☒ TCP ☐ UDP

next back cancel

14.2 Adding Port Forwarding Ports

If you made changes in the **Port Range** screen and clicked on **next**, the following screen will be displayed. Click on **close** to accept the changes, or click on **add** to go back to **Port Range** screen and enter additional port range values. You can repeat this step for each range of ports that you want to add (up to 62 port forwarding ranges). When you are finished adding ports to the Global Port Range, you must click on **close** to accept the information you have entered and return to the **Service Configuration** screen.



Service Details

Service Name *My New Service
 Type: Port Forwarding

Port 1

Protocol: TCP
 Global Port(s): 2-20
 Base Host Port: 2

add



After clicking 'Close' you can enable your new service from the 'Service Name' select box.

close

Service Name	The NAT service for which you are configuring Port Forwarding.
Type	The type of NAT service configuration you selected.
Protocol	The type of Protocol that is used to run this NAT service. TCP- Transmission Control Protocol. UDP-User Datagram Protocol (UDP).
Local IP Address	If a static IP address has been assigned, it will be displayed here.
Base Host Port	The port on the WAN that will host the NAT service selected. Base Host Port is the first port that will be used for a specific service when configured for a range of ports.

14.3 Port Forwarding Trigger Ports

To select **Port Forwarding Trigger Ports**, click on **define custom service** from the **Service Configuration** screen, and then select **Trigger Ports** from the **Custom Service** screen. Click on **next**. The follow settings will be displayed in the **Trigger Ports** screen. Enter your values in the **Local 'Trigger' Port Range** fields and click on **next** to continue.

Service Name	The NAT service you selected.
Local Trigger Port Range	The local LAN side TCP/UDP port.
Global Port Range	The WAN side TCP/UDP port range.

14.4 Adding Local Trigger Ports

If you made changes in the **Local ‘Trigger’ Port Range** screen and clicked **next**, the following screen will be displayed. Click on **close** to accept the changes, or click on **add** to go back to the **Trigger Ports** screen and enter additional port range values. You can repeat this step for each port range that you want to add (up to 10 trigger ports). When you are finished adding ports to the Local ‘Trigger’ Port Range, you must click on **close** to accept the information you have entered and to return to the **Service Configuration** screen.




14.5 Static NAT

If you select **Services** from the **Configuration** menu, the following screen will be displayed, showing the **static NAT** button. Static NAT allows you to configure the Router to work with the special NAT services.

NOTE: When the Router is configured for Static NAT, any unsolicited packets arriving at the WAN would be forwarded to this device. This feature is used in cases where the user wants to host a server for a specific application.


STOP: Single Static IP must be disabled (if it has been enabled previously) before you enable **static NAT**. To disable Single Static IP, select **Single Static IP** from the **Configuration** menu. Next, click on the **disable** button, and then click on **OK** in the pop-up screens to allow the Router to be reset. As explained in section 13.1 (Single Static IP), you must reboot your computer after you enable or disable Single Static IP. After you have rebooted your computer, return to static NAT configuration screen by selecting **Services** from the **Configuration** menu and clicking on the **static NAT** button.




14.6 Enabling Static NAT

Before you enable static NAT, you must select **Default** from the **Current Profile** drop-down box. Static NAT must be configured for the Router's default account profile. After you select the default profile, click the **static NAT** button.


NOTE: In the following screen, the default account profile is labeled **Default**. However, if you have renamed the default account profile, you must select the profile name you created as the default profile.



If you click on the **static NAT** button in the **Service Configuration** screen, the following screen will be displayed. Select your device from the **Static NAT Device** drop-down arrow, or type the IP address of the device in the field labeled **IP Address**. Click on **enable**. This will automatically enable the Static NAT feature for that device.




If you click **enable**, the following Service Configuration screen will display. Static NAT is now enabled for the device you selected.




14.7 Disabling Static NAT

If you click on **static NAT** in the **Service Configuration** screen, the following screen will be displayed, select a device name from the **Static NAT Device** drop-down arrow, or type the IP address of the device in the field labeled **IP Address**. Click on **disable**. This will automatically disable the Static NAT feature for that device.



If you click **disable**, the following **Service Configuration** screen will be displayed. Static NAT is now disabled for the device you selected. (No device is displayed in the field adjacent to the **static Nat** button.)



Service Configuration

Current Profile: Default new edit

Service Name: Select a Service enable delete edit
* ' ' Denotes Custom Service

UPNP Enable ☐


Service Name	Service Mode	Host Device		
IPSEC ALG	Client	Dynamic	details	delete

* If your firewall is enabled, the firewall rules take precedence over the Services.

define custom service

static NAT

15. MAINTENANCE



15.1 Backup/Restore

The following settings will be displayed if you select **Backup/Restore** from the **Maintenance** menu.

NOTE: Backup settings are stored in a separate area of flash, not to an external backup source.




Current configuration becomes Backup Configuration	Select this button if you want to store all of the current configuration data such that it can be recalled later.
Backed up configuration becomes Current configuration	Select this button if you want to retrieve the last back up copy of all configuration parameters and make these values current.
Factory default becomes Current configuration	Select this button if you want set all user configurable parameters back to the factory default.

15.2 Firewall Log


The following settings will be displayed if you select **Firewall Log** from the **Maintenance** menu.

This screen is an advanced diagnostics screen. It alerts you of noteworthy information sent to the Router from the Internet. The screen can contain 1000 entries, but a maximum of 50 entries are displayed at a time. Once 1000 entries have been logged, the oldest entry is removed to make space for the new entries as they occur. The following settings are displayed.



Clear log	Selecting this button removes all entries from the log.
Printable/savable format	Selecting this button opens a new window that contains a list of all the logged packets that can be saved or printed.
Settings	Selecting this button opens a new window that contains configuration settings for selecting the information that you want logged.
Packet	The packet number.
Date	The number of days passed since that the packet was sent.
Time	The time that the packet was sent.
Direction/Source	The direction of transmission.
Rule/Reason	The internal rule that caused the logged event. The internal rule is set up under Firewall rules.
Alert	Displays a description of the logged event.

If you clicked on **details** in the **Firewall Log** screen, the **Packet Details** screen will be displayed. Click on **close**.



To clear the Firewall log, click **clear log** in the **Firewall Log** screen. The following pop-up screen will be displayed. Click **OK** when asked "Do you wish to clear the Firewall log file?" If you click **Cancel**, the firewall log will not be cleared.




To obtain a printable format of the Firewall Log, at the **Firewall Log** screen, click **Printable/Savable Format**. This will allow you to send a copy of the Firewall log to your designated printer.

15.3 Administrative Password

The following settings will be displayed if you select **Administrative Password** from the **Maintenance** menu. After you enter your data into the appropriate settings, click on **change**.

NOTE: If the Router is password protected and you are not an authorized user, you will not be able to change the values. (The Router cannot be configured unless the user is logged in.) Contact your network administrator for further instructions.




Enter Administrative Name NOTE: This changes the Systems Administrator password not the PPP password.	Type the name of your network administrative.
Enter Administrative Password	Type your network administrator's password.
Verify Administrative Password	Re-type your network administrator's password.

15.4 Remote Access

The following screen will appear if you select **Remote Access** from the **Maintenance** menu. To enable Remote Access, type in a password and click the **enable remote access** button.

NOTE: The password should be at least 4 characters long and should not exceed 32 characters. Do not type a blank space or asterisks in the Password field. The password is also case sensitive.



User Name	Displays your current User Name (Static field)
Password	Field for entering your password
Timeout	This is time the remote access session can be inactive before it will be disabled. The Timeout is ignored if Disable Timeout is enabled.
Disable Timeout	When this checkbox is checked, the remote access timeout will be disabled.
Enable Remote Access	When this checkbox is checked, and you are connected to the internet, remote access will be enabled. When this checkbox is NOT checked, remote access will be disabled.
Remote URL	Displays the IP address of the remote management Router.

The following screen shows a check mark in the **Enable Remote Access** box, and displays a message that the remote access is currently enabled. After 20 minutes of inactivity, or on reboot, remote access will be automatically disabled. To disable remote access, click the **Enable Remote Access** box to uncheck the box. Click **apply** to save the settings.



WESTELL
Discover Better Broadband

Home Status Configuration Maintenance Troubleshooting Help

Remote Access

Remote access is currently enabled. After 20 minutes of inactivity, or on reboot, remote access will be automatically disabled.

User Name: admin

Password: *****

Timeout: 20 Minutes

Disable Timeout: ☐

Enable Remote Access: ☒


Remote URL: http://172.26.3.166:2420/

apply

15.5 Update Device

The following screen will be displayed if you click on **Update Device** from the **Maintenance** menu. This screen is used to update the firmware that controls the operation of the Router. The updated firmware may be loaded from either a file that is located on your PC's hard drive or from update files stored on an Internet server.

NOTE: The configurable settings of your Router may be erased during the update process.




Click on the **check for web update** button in the **Update Device** screen to check the web for possible software updates. This screen will retrieve the software update file and display any available update information. You must be connected to the Internet to use this option.



NOTE: If you click on check for web update and the page returns a “page not found” message, this indicates that the software update file is not available. Go back to the previous screen to continue.

Click on the **web update now** button in the **Update Device** screen to download the software update file and automatically update the modem firmware if an update is available and applicable. You must be connected to the Internet to use this option.


If you click on the **settings** button in the **Update Device** screen, the following screen will appear. This screen displays the location of the software update file.



Click on the **local update now** button in the **Update Device** screen to select the upgrade file from your PC's hard drive. This screen allows you to upgrade the software on the Router. Click **Browse...** and go to the location where the upgrade file is stored.



Select the appropriate upgrade file from your browser. The file name will appear in the field labeled **Upgrade File**. Click on **upload file**.




Software Upgrade

*Click browse to select the upgrade file.
Then start the transfer by clicking the 'upload file' button.*

Upgrade File

[Help](#)

This screen shows that the file is being uploaded to the Router.



Software Upgrade


*Click browse to select the upgrade file.
Then start the transfer by clicking the 'upload file' button.*

Upgrade File


[Help](#)

Uploading File


The screens below show that the file upload has completed and that the Programming Flash is being erased to prepare the Flash storage area for upload of the new file. (Programming Flash is a temporary storage area for uploaded files.)



The screen below shows that the upload was successful. The Router will not reboot.




The following screen will be displayed as the Router is being reset.



After a brief delay, the home page will be displayed. Confirm that you have a DSL sync and that the PPP Status displays **UP**. (Click on the **reset** button to re-establish your PPP session.)


16. TROUBLESHOOTING

NOTE: If you are using Models 328W10 or 328W11, options in the **Troubleshooting** menu may or may not be displayed depending on the Router's WAN Configuration (DSL/ATM PORT or ETHERNET PORT 1). However, all menu options are displayed if the Router is configured for DSL/ATM PORT 1. The following sections provide further details on the Troubleshooting menu.



16.1 System Self Tests

The following settings will be displayed if you select **System Self Tests** from the **Troubleshooting** menu. Click on **test all** to run a diagnostic test on the Router's connection.



If you want to PING using the System Self Test screen (diagnostics page) shown above, enter your **DNS** or **IP** address in the fields provided and click on the **test** button. The System Self Test will run a diagnostic test that executes independent of firewall security settings. See the following table for test descriptions and possible responses.


If you want to PING using the MS-DOS (shell) window, first you will need to check your firewall security setting. (If you PING via DOS shell you are susceptible to firewall rules, as this PING is dependent upon the Router's firewall settings.) If your firewall is set to **Medium** or **High**, you will not be able to PING. You must set your firewall security setting to **Low** or **None**.

Connection/Status	
DSL	The Router checks the status of the DSL connection. Possible responses are: UP: The Router is operating correctly and has obtained synchronization with the opposing network device. DOWN: The Router is operating correctly, but has not synchronized with the opposing device.
PPPoE	Indicates that a PPPoE session is or is not established. Possible responses are: Session UP: A valid PPPoE session has been detected. No Session: Currently there is no active PPPoE session established. Initiating Session: A PPP session must be connected from the homepage screen.
PPP	Indicates that a PPPoE or PPPoA session must already be established. Possible responses are: Connection UP: The Router has established a connection No Connection: There is no PPP connection Initiating Connection: The PPP connection process has been initiated Connection Halted: A successful PPP connection was halted Cannot Connect: A PPP connection could not be made because of a PPPoE session failure. Authorization Failure: The user name or password is incorrect. Link Control Protocol Failed: Re-establish the session (from the home page).
Test Description / Test Results	
Self Test	Performs an integrity check of certain internal components of the Router.
PING ISP's Router	Performs an IP network check (i.e., an IP Ping) of the service provider's Router. This test verifies that the Router can exchange IP traffic with an entity on the other side of the DSL line. Possible responses are: Success: The Router has detected an IP Remote Router connection. No Response: The IP Remote Router does not answer the IP Ping. Could not test: The test could not be executed due to the Router's settings. Check your DSL sync or your PPP session. You must have both a DSL sync and a PPP connection established to execute a PING.
DNS	Performs a test to try to resolve the name of a particular host. The host name is entered in the input box. Possible responses are: Success: The Router has successfully obtained the resolved address. The IP address is shown below the host name input box.


	No Response: The Router has failed to obtain the resolved address. Host not found: The DNS Server was unable to find an address for the given host name. No data, enter host name: No host name is specified. Could not test: The test could not be executed due to the Router's settings. Check your DSL sync or your PPP session. You must have both a DSL sync and a PPP connection established to execute a PING.
IP Address	IP Address of the Host Name.
PING (via IP Address or Host Name)	Performs an IP connectivity check to a remote computer either within or beyond the Service Provider's network. You can PING a remote computer via the IP address or the DNS address. If your PING fails, try a different IP or DNS address. Possible responses are: Success: The Remote Host computer was detected. No Response: There was no response to the Ping from the remote computer. No name or address to PING: No host name or IP address was specified. Could not test: The test could not be executed due to the Router settings. Check your DSL sync or your PPP session. You must have both a DSL sync and a PPP connection established to execute a PING.
Trace	Determines the route taken to destination by sending Internet Control Message Protocol (ICMP) echo packets with varying IP Time-To-Live (TTL) values to the destination. Trace Route is used to determine where the packet is stopped on the network.

16.2 Diagnostic Logs


If you select **Diagnostic Log**, from the **System Self Test** menu, the following screen will be displayed.



To see a list of the log options, click on the arrow at the **LOGS** drop-down menu. Select an option from the list provided at the **Diagnostics Logs** screen.




If you clicked on **All**, the following screen will be displayed. This screen provides a detailed list of the Router's connection status and system information. Click on **clear diagnostic log** to clear the diagnostic log information.




16.2.1 Saving the Diagnostic Log File

If you want to save the diagnostic log file, go to your Browser's menu bar, and then select **File > Save As** from the drop-down menu.



At the **Save Web Page** dialog box, select a destination for your log file from the **Save in** drop-down arrow. Next, enter a name for your log file in the field labeled **File name** and click on **Save**.




Out Errors	The number of outbound packets that could not be transmitted due to errors.
Out Discard Packets	The number of outbound packets discarded.
Out Non Unicast Packets	The number of non-Unicast packets transmitted on the Ethernet interface.
Out Unicast Packets	The number of Unicast packets transmitted on the Ethernet interface.
Out Octets	The number of bytes transmitted on the Ethernet interface.
Interface Description	A description field that refers to the interface type.

16.3.2 DSL Transceiver Statistics

The following settings will be displayed if you select **Statistics > DSL Transceiver** from the **Troubleshooting** menu.

NOTE: If the Router is configured using **ETHERNET PORT 1**, the following screen will not be available.




Transceiver Revision	The transceiver software version number.
Vendor ID Code	The CPE Vendor's ID code for their chipset.
Line Mode	The operational mode. Modes supported are No Mode, Multi Mode, T.1413 Mode, G.DMT Mode, and G.LITE Mode.
Data Path	The data path used (either Fast or Interleaved).
Transceiver Information-Down Stream/Up Stream Path	
DSL Speed (Kbits/Sec)	The transmission rate that is provided by your Internet Service Provider (ISP).
SNR Margin (db)	The Signal-to-Noise Ratio (S/N) where 0 db = 1×10^{-7} , which inhibits your DSL speed.
Line Attenuation (dB)	The DSL line loss.
Transmit Power (db/Hz)	The transmitted signal strength.

16.3.3 WAN VC Statistics

The following settings will be displayed if you select **Statistics > WAN VC** from the **Troubleshooting** menu.

NOTE: If the Router is configured using **ETHERNET PORT 1**, the following screen will not be available.




VPI/VCI	Displays the VPI/VCI values obtained from your Internet Service Provider.
In Errors	The number of error packets received on the ATM port.
In Discard Packets	The number of discarded packets received.
In Non Unicast Packets	The number of non-Unicast packets received on the ATM port.
In Unicast Packets	The number of Unicast packets received on the ATM port.
In Octets	The number of bytes received on the ATM port.
Out Errors	The number of outbound packets that could not be transmitted due to errors.
Out Discard Packets	The number of outbound packets discarded.
Out Non Unicast Packets	The number of non-Unicast packets transmitted on the ATM port.
Out Unicast Packets	The number of Unicast packets transmitted on the ATM port.
Out Octets	The number of bytes transmitted on the ATM port.
MTU	Maximum Transmission Unit -The number of data bytes contained in the ATM frame.
Interface Type	A unique identifier that represents the interface type.
Interface Description	A description field that refers to the interface type.

16.3.4 USB Statistics (Models 7400, 328W10 only)

The following settings will be displayed if you select **Statistics > USB** from the **Troubleshooting** menu.


NOTE: If you are using Model 328W10 and the Router is configured using **ETHERNET PORT 1**, the following screen will not be available.



USB Port Statistics	
Number of Resets	The number of times the Host PC reset the USB Interface.
Number of Isrs	The number of times the Host PC requested communication with the modem.
NOTE: Data preceded by OUT pertain to transmissions from the Router to a station; the Router is the source. Data preceded by IN pertain to data received by the Router; the Router is the destination.	
IN-Unicast Packets	The number of packets received that did not have a Multicast or Broadcast class destination IP address.
IN-Non Unicast Packets	The number of packets received that had a Multicast or Broadcast class destination IP address.
IN Multicast Frames	The number of frames received that had a Multicast class destination IP address.
IN Broadcast Frames	The number of frames received that had a Broadcast class destination IP address.
IN Errors	The number of packets received with an invalid format.
Out-Good Frames	The number of frames sent to the Host PC.
Out-Unicast Packets	The number of packets sent that did not have a Multicast or Broadcast class destination IP address.
Out-Non Unicast Packets	The number of packets sent that had a Multicast or Broadcast class destination IP address.
Out-Multicast Frames	The number of frames sent that had a Multicast class destination IP address.
Out-Broadcast Frames	The number of frames sent that had a Broadcast class destination IP address.
Out Errors	The number of packets received by the modem but not sent to PC due to an Error condition.

16.3.5 Wireless Statistics (Models 328W10, 328W11 only)


The following settings will be displayed if you select **Statistics > Wireless Statistics** from the **Troubleshooting** menu.



Wireless Card Information	
Network Name (SSID)	This string, (32 characters or less) is the name associated with the Access Point (AP). To connect to the AP, the Service Set ID (SSID) on a Station card must match the SSID on the AP.
802.11 MAC Address (BSSID)	This is the Media Access Controller address of the AP. It is used as the Basic Service Set Identifier (BSSID).
FW Version	This is the Network Interface Card Identifier. It uniquely identifies the hardware platform of the AP. This is used with other information to determine if the inserted card can be used as an AP, and if so, the version of AP firmware to be used. Not all makes of wireless station cards can be used as an AP.
Communication Statistics	
NOTE: Data listed in the OUT column pertains to transmissions from the AP to a station; the AP is the source. Data listed in the IN column pertains to data received by the AP; the AP is the destination.	
Out-Bytes	The number of successfully transmitted bytes.
Out-Packets	The number of successfully transmitted packets.
Out-Errors	The number of packets that did not transmit due to an error.
In-Bytes	The number of successfully received bytes.
In-Packets	The number of successfully received packets.
In-Errors	The number of received packets with an error.


16.4 Status

NOTE: If you are using Router Model 328W10 or 328W11 and the Router is configured for **ETHERNET PORT 1**, the **QOS** option will not be displayed in the drop-down menu. You must configure the Router for **DSL ATM PORT** to access **QOS** in the **Advanced WAN** drop-down menu. Refer to section 13.6.3.1 for details on enabling and disabling DSL ATM PORT and ETHERNET PORT 1.



16.4.1 LAN Devices

The following settings will be displayed if you select **Status > LAN Devices** from the **Troubleshooting** menu.




Devices on LAN	
IP Address	Displays the IP network address that the Router is on.
MAC Address	Media Access Controller (MAC) address of this device.
Name	Displays the ASCII (text) name of the devices connected to the LAN.
Status	Displays the status of the devices connected to the LAN.

16.4.2 Wireless Stations (Models 328W10, 328W11)

The following settings will be displayed if you select **Status > Wireless Stations** from the **Troubleshooting** menu.

NOTE: A Wireless device must be connected to the Router for the fields in this screen to be populated.




Wireless Stations List	
Station	This number indicates the order in which the stations are first accessed by the Router.
MAC Address	The Media Access Controller Address assigned to the station.

16.4.3 RIP Table

The following settings will be displayed if you select **Status > RIP Table** from the **Troubleshooting** menu.

NOTE: RIP must be enabled for this table to be populated.



RIP Network Routing Table	Indicates Network routes received via RIP.
RIP Host Routing Table	The Host routes received via RIP.
Destination	The destination IP address of the route
Netmask	The IP mask of the route
Gateway	The gateway of the route
Metric	The RIP metric (0-15). A lower value is better.




16.4.4 QOS Status

The following settings will be displayed if you select **Status > QOS** from the **Troubleshooting** menu. Click on the **clear** button to clear all counts and statistics (not just latency counts). This does not affect the configuration values.

IMPORTANT: If you are using Model 328W10 or 328W11 and the Router is configured for **ETHERNET PORT 1**, the following screen will not be available.

NOTE: QOS must be enabled on the Router for this table to be populated.




Queue Number	Indicates the DiffServ Queue. Possible responses are: 0 = Best Effort (BE) 1 = Assured Forwarding 1 (AF1) 2 = Assured Forwarding 2 (AF2) 3 = Assured Forwarding 2 (AF3) 4 = Assured Forwarding 2 (AF4) 5 = Expedited Forwarding (EF)
--------------	---

	6 = Routing Protocols (DiffServ priorities 6 and 7)
Max Queue Size	The maximum number of packets that can be queued for this priority.
Total Dropped Packets	Indicates how many packets of this priority have been dropped by QOS due to lack of buffer space or filtering rules.
Total Enqueued Packets	Displays the number of packets, destined for the WAN, that have been received.
Current Depth	Displays the current number of packets of this priority that are queued.
Deepest Depth	Displays the most number of packets that have been queued at once for this priority.
QOS Filter Statistics	
Queue Number	The DiffServ Queue. (See Queue Number description above.)
Peak Info. Rate (%)	The maximum allowed rate for this priority, expressed as a percentage of the DSL rate.
Committed Info Rate (%)	The committed rate for this priority, expressed as a percentage of the DSL rate
Peak Burst (ms)	Displays the interval in milliseconds for averaging the peak offered rate.
Committed Burst (ms)	Displays the interval in milliseconds for averaging the committed offered rate.
Total Packets Received	Displays the total number of packets of this priority that are destined for the LAN.
Total Marked Packets	Displays the number of packets of this priority that exceeded the committed rate, but not the peak rate, and were marked with a higher drop priority
Total Filter Packet Drops	Displays the number of packets of this priority that exceeded the peak rate and that were, therefore, dropped.
Avg. DSL Bytes Per Packet	Displays the average size of packets for this priority, including all overhead.
Avg. Packet Rate Per second	Displays the average rate (in packets per seconds) for this priority.
QOS Latency Counts	
Queue Number	The DiffServ Queue. (See Queue Number description above.)
Not Time Stamped	The packets with no incoming time stamp. (Often these are generated internal to the modem.)
A ms to B ms	The number of packets of this priority whose time in the modem fell between A and B milliseconds. (Time is measured from the point the packet arrives at the modem's processor until is passed to the ATM hardware for transmission.) Possible ranges are (A ms to B ms): 0 ms to 10 ms 10 ms to 20 ms 20 ms to 40 ms 40 ms to 100 ms 100 ms to 1000 ms 1000 ms to 3000 ms - Larger than 3000 ms

16.4.5 VOIP Status

The following settings will be displayed if you select **Status > VOIP** from the **Troubleshooting** menu.

NOTE: A VOIP device must be connected to the Router for this table to be populated.



SIP Registry Information	
URI	The SIP URI that is trying to register. (This field only indicates that a SIP device tried to register, not that it succeeded.)
Local IP Address	The local, LAN IP address of the SIP device.
Expiration	Indicates the expiration (in seconds) of the registered SIP URI.

17. NAT SERVICES

For your convenience, the Router supports protocols for Applications, Games, and VPN-specific programs. The following chart provides protocol information for the services supported by the Router.

NOTE: To configure the Router for a service or application, follow the steps in section 14 (Setting Up Advanced Service Configuration) of this User Guide.

Applications/Games/VPN Support

Application/Game	Port/Protocol
Aliens vs. Predator	80 UDP, 2300 UDP, 8000-8999 UDP
America Online	5190 TCP/UDP
AoE II: Conquors	47624 TCP/UDP, 6073 TCP/UDP, 2300-2400 TCP/UDP
AOL Instant Messenger	4099 TCP, 5190 TCP
Asheron's Call	9000-9013 UDP, 28800-29000 TCP
Battlecom	2300-2400 TCP/UDP, 47624 TCP/UDP
Black and White	2611-2612 TCP, 6667 TCP, 6500 UDP, 27900 UDP
Blizzard Battle.net (Diablo II)	4000 TCP, 6112 TCP/UDP
Buddy Phone	700, 701 UDP
Bungie.net, Myth, Myth II Server	3453 TCP
Calista IP Phone	3000 UDP, 5190 TCP
Citrix Metaframe	1494 TCP
Client POP/IMAP	110 TCP
Client SMTP	25 TCP
Counter Strike	27015 TCP/UDP, 27016 TCP/UDP
Dark Reign 2	26214 TCP/UDP
Delta Force (Client and Server)	3568 UDP, 3100-3999 TCP/UDP
Delta Force 2	3568-3569 UDP
DeltaForce: Land Warrior	UDP 53 TCP 21 TCP 7430 TCP 80 UDP 1029 UDP 1144 UDP 65436 UDP 17478
DNS	53 UDP
Elite Force	2600 UDP, 27500 UDP, 27910 UDP, 27960 UDP
Everquest	1024-7000 TCP/UDP
F-16, Mig 29	3863 UDP
F-22 Lightning 3	4660-4670 TCP/UDP, 3875 UDP, 4533-4534 UDP, 4660-4670 UDP
F-22 Raptor	3874-3875 UDP
Fighter Ace II	50000-50100 TCP/UDP
Fighter Ace II for DX play	50000-50100 TCP/UDP, 47624 TCP, 2300-2400 TCP/UDP

Application/Game	Port/Protocol
FTP	20 TCP, 21 TCP
GameSpy Online	UDP 3783 UDP 6515 TCP 6667 UDP 12203 TCP/UDP 13139 UDP 27900 UDP 28900 UDP 29900 UDP 29901
Ghost Recon	TCP 80 UDP 1038 UDP 1032 UDP 53 UDP 2347 UDP 2346
GNUTella	6346 TCP/UDP, 1214 TCP
Half Life Server	27005 UDP(client only) 27015 UDP
Heretic II Server	28910 TCP
Hexen II	26900 (+1) each player needs their own port. Increment by one for each person
Hotline Server	5500, 5503 TCP 5499 UDP
HTTPS	443 TCP/UDP
ICMP Echo	4 ICMP
ICQ OLD	4000 UDP, 20000-20019 TCP
ICQ 2001b	4099 TCP, 5190 TCP
ICUII Client	2000-2038 TCP, 2050-2051 TCP, 2069 TCP, 2085 TCP, 3010-3030 TCP
ICUII Client Version 4.xx	1024-5000 TCP, 2050-2051 TCP, 2069 TCP, 2085 TCP, 3010-3030 TCP, 2000-2038 TCP 6700-6702 TCP, 6880 TCP, 1200-16090 TCP
IMAP	119 TCP/UDP
IMAP v.3	220 TCP/UDP
Internet Phone	22555 UDP
IPSEC ESP	PROTOCOL 50
IPSEC IKE	500 UDP
Ivisit	9943 UDP, 56768 UDP
KALI, Doom & Doom II	2213 UDP, 6666 UDP (EACH PC USING KALI MUST USE A DIFFERENT PORT NUMBER STARTING WITH 2213 + 1
KaZaA	1214 TCP/UDP
Limewire	6346 TCP/UDP, 1214 TCP
Medal Of Honor: Allied Assault	TCP 80 UDP 53 UDP 2093 UDP 12201 TCP 12300 UDP 2135 UDP 2139 TCP/UDP 28900
mIRC Chat	6660-6669 TCP

Application/Game	Port/Protocol
Motorhead Server	16000 TCP/UDP, 16010-16030 TCP/UDP
MSN Game Zone	6667 TCP, 28800-29000 TCP
MSN Game Zone (DX 7 & 8 play)	6667 TCP, 6073 TCP, 28800-29000 TCP, 47624 TCP, 2300-2400 TCP/UDP
MSN Messenger	6891-6900 TCP, 1863 TCP/UDP, 5190 UDP, 6901 TCP/UDP
Napster	6699 TCP
Need for Speed 3, Hot Pursuit	1030 TCP
Need for Speed, Porsche	9442 UDP
Net2Phone	6801 UDP
NNTP	119 TCP/UDP
Operation FlashPoint	47624 UDP, 6073 UDP, 2300-2400 TCP/UDP, 2234 TCP
Outlaws	5310 TCP/UDP
Pal Talk	2090-2091 TCP/UDP, 2095 TCP, 5001 TCP, 8200-8700 TCP/UDP, 1025-2500 UDP
pcAnywhere host	5631 TCP, 5632 UDP, 22 UDP
Phone Free	1034-1035 TCP/UDP, 9900-9901 UDP, 2644 TCP, 8000 TCP
Quake 2	27910 UDP
Quake 3	27660 UDP Each computer playing QuakeIII must use a different port number, starting at 27660 and incrementing by 1. You'll also need to do the following: 1. Right click on the QIII icon 2. Choose "Properties" 3. In the Target field you'll see a line like "C:\Program Files\Quake III Arena\quake3.exe" 4. Add the Quake III net_port command to specify a unique communication port for each system. The complete field should look like this: "C:\Program Files\Quake III Arena\quake3.exe" +set net_port 27660 5. Click OK. 6. Repeat for each system behind the NAT, adding one to the net_port selected (27660,27661,27662)
Quicktime 4/Real Audio	6970-32000 UDP, 554 TCP/UDP
Rainbow Six & Rogue Spear	2346 TCP
RealOne Player	TCP - 554, 7070 to 7071 UDP - 6970 to 7170
Real Audio	6970-7170 UDP
Roger Wilco	TCP/UDP 3782 UDP 3783 (BaseStation)
ShoutCast Server	8000-8005 TCP
SSH Secure Shell	22 TCP/UDP
Starcraft	2346 TCP
Starfleet Command	2300-2400 TCP/UDP, 47624 TCP/UDP
Telnet	23 TCP
Tiberian Sun & Dune 2000	1140-1234, 4000 TCP/UDP
Ultima Online	5001-5010 TCP, 7775-7777 TCP, 8800-8900 TCP, 9999 UDP, 7875 UDP
Unreal Tournament server	7777 (default gameplay port) 7778 (server query port) 7779,7779+ are allocated dynamically for each helper UdpLink objects,

Application/Game	Port/Protocol
	including UdpServerUplink objects. Try starting with 7779-7781 and add ports if needed 27900 server query, if master server uplink is enabled. Home master servers use other ports like 27500 Port 8080 is for UT Server Admin. In the [UWeb.WebServer] section of the server.ini file, set the ListenPort to 8080 and ServerName to the IP assigned to the Router from your ISP.
USENET News Service	143 TCP
VNC, Virtual Network Computing	5500 TCP, 5800 TCP, 5900 TCP
Westwood Online, C&C	4000 TCP/UDP, 1140-1234 TCP/UDP
World Wide Web (HTTP)	80 TCP 443 TCP (SSL) 8008 OR 8080 TCP (PROXY)
XBOX Live	TCP/UDP 88 and 3074
Yahoo Messenger Chat	5000-5001 TCP
Yahoo Messenger Phone	5055 UDP
VPN Protocol	Comments
IPSec Encryption	IPSec using AH can not be supported through NAT. IPSec using ESP and L2TP can be supported via an ALG
L2TP	IPSec using ESP and L2TP can be supported via an ALG.
PPTP	Works through NAT.



18. TECHNICAL SUPPORT INFORMATION

Westell Technical Support

If technical assistance is required, contact your Internet service provider for support. By using one of the following options:

North America

Phone: 1-630-375-4900

U.K./Europe

Phone: (44) 01256 843311

Visit Westell at www.Westell.com to view frequently asked questions and enter on-line service requests, or send email to global_support@westell.com to obtain additional information.

19. WARRANTY AND REPAIRS

Warranty

Westell warrants this product free from defects at the time of shipment. Westell also warrants this product fully functional for the period specified by the terms of the warranty. Any attempt to repair or modify the equipment by anyone other than an authorized representative will void the warranty.

Repairs

Westell will repair any defective Westell equipment without cost during the warranty period if the unit is defective for any reason other than abuse, improper use, or improper installation, or acts of nature. Before returning the defective equipment, request a **Return Material Authorization (RMA)** number from Westell. An RMA number must be quoted on all returns. When requesting an RMA, please provide the following information:

- Product model number (on product base)
- Product serial number (on product base)
- Customer ship-to address
- Contact name
- Problem description
- Purchase date

After an RMA number is obtained, return the defective unit, freight prepaid, along with a brief description of the problem to one of the following options:

North America

Westell, Inc.
ATTN: R.G.M Department
750 N. Commons Drive
Aurora, IL 60504-7940 USA

U.K./Europe

Westell, Ltd.
Ringway House
Bell Road
Daneshill
Basingstoke
RG24 8FB
United Kingdom

Westell will continue to repair faulty equipment beyond the warranty period for a nominal charge. Contact a Westell Technical Support Representative for details.

20. SOFTWARE LICENSE AGREEMENT

READ THE TERMS AND CONDITIONS OF THIS LICENSE AGREEMENT CAREFULLY. THIS SOFTWARE IS COPYRIGHTED AND LICENSED (NOT SOLD). BY INSTALLING AND OPERATING THIS PRODUCT, YOU ARE ACCEPTING AND AGREEING TO THE TERMS OF THIS LICENSE AGREEMENT. IF YOU ARE NOT WILLING TO BE BOUND BY THE TERMS OF THIS LICENSE AGREEMENT, YOU SHOULD PROMPTLY RETURN THE SOFTWARE AND HARDWARE TO WESTELL TECHNOLOGIES, INC. THIS LICENSE AGREEMENT REPRESENTS THE ENTIRE AGREEMENT CONCERNING THE SOFTWARE BETWEEN YOU AND WESTELL TECHNOLOGIES, INC. (REFERRED TO AS "LICENSOR"), AND IT SUPERSEDES ANY PRIOR PROPOSAL, REPRESENTATION, OR UNDERSTANDING BETWEEN THE PARTIES.

1. License Grant. Licensor hereby grants to you, and you accept, a nonexclusive license to use the Compact Disk (CD) and the computer programs contained therein in machine-readable, object code form only (collectively referred to as the "SOFTWARE"), and the accompanying User Documentation, only as authorized in this License Agreement. The SOFTWARE may be used only in connection with the number of systems for which you have paid license fees as dictated in your support agreement. You agree that you will not assign, sublicense, transfer, pledge, lease, rent, or share your rights under this License Agreement. You agree that you may not nor allow others to reverse assemble, reverse compile, or otherwise translate the SOFTWARE.

You may retain the SOFTWARE CD for backup purposes only. In addition, you may make one copy of the SOFTWARE in any storage medium for backup purposes only. You may make one copy of the User's Manual for backup purposes only. Any such copies of the SOFTWARE or the User's Manual shall include Licensor's copyright and other proprietary notices. Except as authorized under this paragraph, no copies of the SOFTWARE or any portions thereof may be made by you or any person under your authority or control.

2. Licensor's Rights. You acknowledge and agree that the SOFTWARE and the User's Manual are proprietary products of Licensor protected under U.S. copyright law. You further acknowledge and agree that all right, title, and interest in and to the SOFTWARE, including associated intellectual property rights, are and shall remain with Licensor. This License Agreement does not convey to you an interest in or to the SOFTWARE, but only a limited right of use revocable in accordance with the terms of this License Agreement.

3. License Fees. The fees paid by you under the support agreement are paid in consideration of the licenses granted under this License Agreement.

4. Term. This License Agreement is effective upon your opening of this package and shall continue until terminated. You may terminate this License Agreement at any time by returning the SOFTWARE and all copies thereof and extracts therefrom to Licensor. Licensor may terminate this License Agreement upon the breach by you of any term hereof. Upon such termination by Licensor, you agree to return to Licensor the SOFTWARE and all copies and portions thereof.

5. Limited Warranty. Licensor warrants, for your benefit alone, for a period of 90 days from the date of commencement of this License Agreement (referred to as the "Warranty Period") that the SOFTWARE CD in which the SOFTWARE is contained are free from defects in material and workmanship. Licensor further warrants, for your benefit alone, that during the Warranty Period the SOFTWARE shall operate substantially in accordance with the functional specifications in the User's Manual. If during the Warranty Period, a defect in the SOFTWARE appears, you may return the SOFTWARE to Licensor for replacement. You agree that the foregoing constitutes your sole and exclusive remedy for breach by Licensor of any warranties made under this Agreement.



User Guide

EXCEPT FOR THE WARRANTIES SET FORTH ABOVE, THE SOFTWARE CD, AND THE SOFTWARE CONTAINED THEREIN, ARE LICENSED "AS IS," AND LICENSOR DISCLAIMS ANY AND ALL OTHER WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, WITHOUT LIMITATION, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

6. Limitation of Liability. Licensor's cumulative liability to you or any other party for any loss or damages resulting from any claims, demands, or actions arising out of or relating to this Agreement shall not exceed the license fee paid to Licensor for the use of the SOFTWARE. In no event shall Licensor be liable for any indirect, incidental, consequential, special, or exemplary damages or lost profits, even if Licensor has been advised of the possibility of such damages. **SOME STATES DO NOT ALLOW THE LIMITATION OR EXCLUSION OF LIABILITY FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU.**

7. Governing Law. This License Agreement shall be construed and governed in accordance with the laws of the State of Illinois. You submit to the jurisdiction of the state and federal courts of the state of Illinois and agree that venue is proper in those courts with regard to any litigation arising under this Agreement.

8. Costs of Litigation. If any action is brought by either party to this License Agreement against the other party regarding the subject matter hereof, the prevailing party shall be entitled to recover, in addition to any other relief granted, reasonable attorney fees and expenses of litigation.

9. Severability. Should any term of this License Agreement be declared void or unenforceable by any court of competent jurisdiction, such declaration shall have no effect on the remaining terms hereof.

10. No Waiver. The failure of either party to enforce any rights granted hereunder or to take action against the other party in the event of any breach hereunder shall not be deemed a waiver by that party as to subsequent enforcement of rights or subsequent actions in the event of future breaches.



User Guide

21. PUBLICATION INFORMATION

Westell® Router (Models 7400, 7401, 328W10, 328W11)
User Guide Part Number 030-300432 Rev. A

Copyright © 2004 Westell, Inc.
All rights reserved.

Westell, Inc.
750 North Commons Drive
Aurora, Illinois 60504 USA
www.westell.com

All trademarks and registered trademarks are the property of their respective owners.

