


AFFINITY CONTROL

USER'S GUIDE



SOFTWARE V2.50

Document Number: 47267151-108

Revision: 0.1

Date: June 14, 2004

Copyright © 2004 by Thales Broadcast & Multimedia, Inc., All rights reserved.

Affinity® is a Registered Trademark of Thales Broadcast & Multimedia, Inc.

Win 95, Win 98, Win NT 4.0, Win 2000 and Win XP are registered trademarks of Microsoft Corporation.
All rights reserved

Pentium is a registered trademark of Intel Corporation. All rights reserved

No part of this manual may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, except as may be expressly permitted in writing by Thales Broadcast and Multimedia, Inc.

Information provided by Thales Broadcast and Multimedia, Inc. is intended and believed to be accurate; however, no liability can be assumed for its use. Materials, designs, and specifications are subject to change without notice.

For technical support call 1-800-345-9295 or log on to our web site at www.thales-bm.com.

Manufactured in the United States of America

Affinity Control User's Guide

Software v2.50

Table of Contents

1	Introduction and Installation.....	1
1.1	Program Description	1
1.2	System Requirements.....	1
1.3	Installation	1
1.4	Initial Setup.....	2
2	Program Operation	3
2.1	Main Control Screen Operation.....	3
2.1.1	Upconverter LCD Metering and Status Box	4
2.1.2	Controls	4
2.1.3	Fault Log Screen Operation	5
2.1.4	Maintenance Options Screen Operation	6
2.1.5	Setup/Configuration Screen Operation.....	7
2.2	Amplifier Gain Check Procedure.....	11
2.3	Full Upconverter Calibration Procedure	15
3	Affinity System Reference & Theory of Operation.....	29
3.1	ADAPT Reference	29
3.2	Affinity/Upconverter Theory of Operation	29
3.3	Affinity Power Amplifier(s) Reference.....	30
3.4	Affinity Control Software to EMSET Variable Cross Reference	31
	Figure 1 Upconverter RJ11 Serial Port Connector	2
	Figure 2 First Time Startup Dialog.....	2
	Figure 3 Old Upconverter Parameters Warning.....	2
	Figure 4 Main Control Screen – NOT CONNECTED.....	3
	Figure 5 Main Control Screen–After Connection	3
	Figure 6 Sample Fault History Log File	5
	Figure 7 Maintenance Screen	6
	Figure 8 Setup/Configuration Screen	7
	Figure 9 Meter/Display Calibration Screen	9
	Figure 10 Saved Upconverter Settings File Example	10
	Figure 11 Amplifier Gain Check for 500W System (Screen 1)	11
	Figure 12 Amplifier Gain Check for 500W System (Screen 2)	12

Affinity Control User's Guide

Software v2.50

Table of Contents

Figure 13 Amplifier Gain Check for 500W System (Screen 3)	12
Figure 14 Amplifier Gain Check for 500W System (Screen 4)	13
Figure 15 Amplifier Gain Check for 500W System (Screen 5)	13
Figure 16 Amplifier Gain Check for 500W System (Screen 6)	14
Figure 17 Amplifier Gain Check for 500W System (Screen 7)	14
Figure 18 Full Calibration-Initial Display Screen	16
Figure 19 Full Calibration-"Last Chance" Warning	17
Figure 20 Full Calibration-Upconverter Initialization	17
Figure 21 Full Calibration-ADAPT Output Level	18
Figure 22 Full Calibration-Power Meter Setup	18
Figure 23 Full Calibration-ALC Manual Ref Calibration	19
Figure 24 Full Calibration-System Fwd Pwr Sample Setup	19
Figure 25 Full Calibration-System Fwd Pwr Ref Calibration	20
Figure 26 Full Calibration-Upconv Fwd Pwr Ref Info	20
Figure 27 Full Calibration-Upconv Fwd Pwr Ref Calibration	21
Figure 28 Full Calibration-System Refl Power Ref Info	21
Figure 29 Full Calibration-System Refl Power Ref Calibration	22
Figure 30 Full Calibration-System Refl Power Ref Calibration	22
Figure 31 Full Calibration-ALC Auto Ref Info	23
Figure 32 Full Calibration-ALC Auto Mode Switch	23
Figure 33 Full Calibration-ALC Auto Ref Calibration	24
Figure 34 Full Calibration-Power Limiter Info	24
Figure 35 Full Calibration-Power Limiter Setup	25
Figure 36 Full Calibration-Power Limiter Calibration	25
Figure 37 Full Calibration-ALC Auto Full Power Restore	26
Figure 38 Full Calibration-Fast Reflected Shutdown Setup	26
Figure 39 Full Calibration-Fast Reflected Shutdown Calibration	27
Figure 40 Full Calibration-Reflected Power Limit Setup	27
Figure 41 Full Calibration-Fast Refl Power Percent Limit Calibration	28
Figure 42 Full Calibration-Reflected Power Sample Setup	28
Figure 43 Affinity System Simplified Block Diagram	29
Table 1 Amplifier Fault Power Reduction Levels (in ALC Auto mode)	30
Table 2 EMSET Variables to Affinity Control Software Cross Reference	32
Table 3 EMSET Variables Description	33

1 Introduction and Installation

1.1 Program Description

The Affinity Control software is designed to allow for minor adjustments to the Affinity system Upconverter/Amplifier plug-in module (hereafter referred to as "upconverter"). Control and monitoring for normal day-to-day operation is provided on a main control screen. Calibration, adjustment, and setup functions are provided through additional maintenance screens.

The program provides the capability of saving upconverter settings to a file. There is also a fault history log file, created during operation, which provides reporting capabilities on faults and operational activities. The fault history log file, along with the saved settings file, provides useful information to aid in troubleshooting problems that may arise.

Refer to the Affinity and Upconverter/Amplifier reference section of this document for more detailed information regarding the operation of the Affinity system, including details on the upconverter plug-in.

1.2 System Requirements

- Windows 95, 98, NT 4.0, 2000, or XP (Windows 2000 or XP recommended).
- 64MB Memory
- Pentium 3 – 350MHz or better.
- 800x600 or better display resolution – 256 colors minimum.
- One RS232 communication port.
- DB9 (PC) to RJ11 serial interface cable PN: 47267081

1.3 Installation

The Affinity Control software application is supplied in two possible forms: As a CD-ROM (Part # 47267204.01) or as a zip file delivered via e-mail (*AffinityControlGUIv250.zip*). Locate and run the supplied *setup.exe* file to install the Affinity Control software on your computer. The setup utility will install an executable file "*AffinityControlv250.exe*" in the directory "C:\Program Files\Thales B&M\Affinity Control". A shortcut to this executable is automatically added to the START > PROGRAMS menu and to the PC desktop.

1.4 Initial Setup

Connect the DB9 connector of the serial interface cable to an unused PC serial port connector. Connect the other end of the cable to the upconverter RJ11 serial port connector (see Figure 1).



Figure 1 Upconverter RJ11 Serial Port Connector

To start the program, click on the program icon. The first time that the program is started a popup window will appear (see Figure 2) requesting that the setup be run. Click on the **OK** button to run the program's Setup/Configuration dialog. If the **Cancel** button is pressed, the program will exit. The setup must be performed before the program can be run. When the Setup/Configuration window appears, select the desired COM Port, set the *Rated System Pwr*, then click on the **Save** button to save the configuration.

NOTE: The rated system power (*Rated System Pwr*) is the maximum system output power rating, NOT the power at which the system will be operated.

Click on the **Apply** button to activate the settings. The Setup/Configuration dialog can be accessed later from the Maintenance screen. Refer to the Setup/Configuration section of this manual for details on the remaining setup and configuration parameters.

A warning dialog message (Figure 3) will be displayed noting that the program could not load previous upconverter settings. This warning message will be displayed on every startup until the upconverter settings are saved. Refer to the Maintenance section of this manual for a description on how to save the current upconverter settings.




Figure 2 First Time Startup Dialog



Figure 3 Old Upconverter Parameters Warning

2 Program Operation

2.1 Main Control Screen Operation

The Main Control screen is the primary interface to the upconverter module. It displays the current operating power levels and status. It also includes controls for adjusting system output power, upconverter ON or OFF (Transmit or Standby), upconverter reset, and access to the fault history log file.

Each time the program is run, the Status window must be clicked to connect to the upconverter. It may take a couple of minutes for the connection to be made after the Status window is clicked. Figure 5 shows the Main Control screen after the program has successfully connected to the upconverter. During the connection process, the program extracts most of the important current upconverter parameter data. This is some of the data that is saved by clicking on the **Save Upconverter Settings** button in the Maintenance Options screen.




Figure 4 Main Control Screen – NOT CONNECTED




Figure 5 Main Control Screen—After Connection

2.1.1 Upconverter LCD Metering and Status Box

The power readings shown are basically a duplicate of the LCD display readings on the upconverter itself. However, the values displayed by the program are averaged for increased stability.

- **Forward Pwr** – Displays the current system output forward power (averaged 3 samples).
- **Reflected Pwr** – Displays the current system reflected power (averaged 3 samples).
- **Upconverter Pwr** – Displays the current upconverter internal forward power.
- **Status** – Displays the current status of the program or Affinity operation. Typical status conditions are: RF Transmit, RF Standby, RF OFF and Not Connected.

2.1.2 Controls

- **Transmit** – Clicking this button will place the upconverter in the Transmit mode. It may take thirty seconds or more for the upconverter to transition to the transmit state (RF ON).
- **Standby** – Clicking this button will place the upconverter in the Standby mode (RF OFF).
- **Reset** – Clicking this button will send a reset command to the Upconverter. It will briefly turn the output off, then return to the Transmit mode after approximately ten seconds

NOTE: Anytime the upconverter is reset it will revert back to ALC Auto mode, which is the normal operating state.

- **Raise Power** – Clicking this button will increase the Affinity system output power. The increase is typically between five and ten Watts.
- **Lower Power** – Clicking this button will decrease the Affinity system output power. The decrease is typically between five and ten Watts.
- **Maintenance** – Clicking this button will open the Maintenance Dialog window. Refer to the Maintenance Screen Operation section of this document for details.
- **Fault Log** – Clicking this button will open a window to display the current contents of the fault history file. The file can be scrolled page by page. As the fault history file grows in size, it will become more cumbersome to view. The fault history file should be purged occasionally or archived by copying to other storage.

NOTE: The Fault History file is a normal text file and can be opened and view with a standard text editor such as Notepad. DO NOT EDIT the file that is currently in use!

- **Quit** – This will exit the Affinity Control program.

2.1.3 Fault Log Screen Operation

Clicking on the **Fault Log** button in the Main Control Screen will open the Fault History Logfile display (Figure 6). Clicking the **Next Page** button will display the next page of the file. Clicking the **Prev Page** button will display the previous page of the file. The contents being displayed can be copied and pasted into another program if desired, but the information cannot be edited. It is strongly recommended that the fault log file be purged or archived frequently.




Figure 6 Sample Fault History Log File

2.1.4 Maintenance Options Screen Operation

Most of the buttons in the Maintenance Options Screen (Figure 7) will open additional windows. The following buttons are described below:

- **Setup/Config** – Clicking this button will open the Setup/Configuration dialog window. Refer to the Setup/Configuration Screen Operation section of this document for details.
- **Meter/Display Cal** – Clicking this button will open the Meter/Display Calibration dialog window. Refer to the Meter/Display Calibration Screen Operation section of this document for details.
- **Save Upconverter Settings** – Clicking on this button will save the current upconverter settings to a date and time stamped file. Refer to the Save Upconverter Settings section of this document for details.
- **Purge Fault Log** – Clicking this button will allow the fault history file to be emptied. This file can grow quite large. Refer to the Fault History section of this document for details.
- **Amplifier Gain Check** – Clicking this button will open the Amplifier Gain Check dialog window. Refer to the Amplifier Gain Check Procedure section of this document for details.
- **Full Upconverter Cal** – Clicking this button will open the Full Upconverter Calibration dialog window. Refer to the Full Upconverter Calibration Procedure section of this document for details.
- **Back to Main Window** – Clicking this button will close the Maintenance Options dialog window and return to the Main Control Screen.




Figure 7 Maintenance Screen

2.1.5 Setup/Configuration Screen Operation

The Setup/Configuration Screen (Figure 8) allows various program parameters to be adjusted, saved, and applied. A Setup Help screen located on the right side of the dialog describes most of the controls and their functions. More detail on each control is provided here:

2.1.5.1 Configuration & COM Setup

- **COM Port** – This control allows selection of the desired COM port (ports 1 - 4 are currently supported).
- **Rated System Power** – Use this control to select the rated system output power (not the operating power). This setting is required by the Amplifier Gain Check procedure in order to know how many amps are available.
- **COM Timeout** – SHOULD NOT NEED TO BE ADJUSTED. If COM lockouts occur, suspect a cable/COM connection problem. Timeouts will occasionally occur, but if they do not cause a COM lockout, they should be ignored. The program has built-in handling for these timeout errors and will automatically recover.




Figure 8 Setup/Configuration Screen

2.1.5.2 Power Alarm Trip Settings

These controls are used to set upper and lower alarm points for the forward and upconverter power meter readings. These limits do NOT cause the program to take any action other than to log the fault and display it on the Main Screen. If either the forward or upconverter power levels are outside the limits, the corresponding Power display box on the Main Screen will be highlighted red. Also, the fault will be recorded in the fault history file, with a date/time stamp, and the alarm limit vs. the actual level. Again, violating these limits does NOT cause the program to take any action to reduce or increase power.

- **Forward Pwr Low %** - Use this control to set the Forward Power LOWER alarm threshold.
- **Forward Pwr High %** - Use this control to set the Forward Power UPPER alarm threshold.
- **Upconverter Pwr Low %** - Use this control to set the Upconverter Internal Fwd Power LOWER alarm threshold.
- **Upconverter Pwr High %** - Use this control to set the Upconverter Internal Fwd Power UPPER alarm threshold.
- **Un-Check to Disable Alarms** – Check this box to enable Low/High Power alarm(s) monitoring and reporting. Uncheck the box to disable Low/High power monitoring and reporting.

2.1.5.3 Metering/Display Calibration Operation

The Meter/Display Calibration Screen (Figure 9 on the following page) allows the upconverter LCD "System Forward Power", "System Reflected Power" and "Upconverter Internal Fwd Pwr" readings to be calibrated/adjusted. There is also an adjustment on this screen for the Fast Reflected Shutdown Trip threshold. This is to eliminate nuisance reflected power trips caused when the ADAPT output is turned on. There is a Meter/Cal Help screen displayed to the right side of the dialog, which describes most of the controls and their function. More detail on each control is provided here:

NOTE: that the readings displayed for power are NOT AVERAGED. That is, they are "real-time."

- **System Fwd Pwr** – Use the Up/Down control to adjust the displayed value for the upconverter LCD "System Forward Pwr" reading. The reading displayed on-screen should match the upconverter LCD reading. The displayed value is NOT averaged.
- **System Reflected Pwr** – Use the Up/Down control to adjust the displayed value for the upconverter LCD "System Refl Pwr" reading. The reading displayed on-screen should match the upconverter LCD reading. The displayed value is NOT averaged.
- **Upconverter Pwr** – Use the Up/Down control to adjust the displayed value for the upconverter LCD "Upconv Fwd Pwr" reading. The reading displayed on-screen should match the upconverter LCD reading. The displayed value is NOT averaged.

- **Fast Reflected Shutdown Trip** – Use the Up/Down control to adjust the trip point for the Fast Reflected Shutdown. The only possible reason that this may require adjustment is to eliminate nuisance trips occurring when the ADAPT output is turned on. Adjust the level up by one click, reset the upconverter, and turn the ADAPT drive output control OFF and ON. If trip reoccurs, repeat this process until the upconverter no longer trips.

CAUTION: It should not be necessary to raise the level by more than 100 units (from the initial displayed value). Be aware that if the threshold level is adjusted too high, reflected power protection may be diminished.

- **Done** – Clicking on this button closes the Meter/Display Calibration window. Note that changes take effect immediately, so any changes are permanent (unless changed back).




Figure 9 Meter/Display Calibration Screen

2.1.5.4 Save Upconverter Settings

This function is accessible from the Maintenance Options screen. Clicking on the button will write the current program configuration and upconverter parameters to a file. Each time the button is pressed, a new file is created. The unique filename is created using the current date and time. An example file name would be: *Settings-2004-05-17-17-42-15.txt* where *2004-05-17* is the date in YYYY-MM-DD format and *17-42-15* is the time in HH-MM-SS format. A sample of the contents from a saved file is shown in Figure 10. Note that the parameters for each upconverter vary depending on the system. Your results probably will not match the values in this example.

Upconverter Parameter Settings
Saved: May 19, 2004 at 11:03:31

SETUP/CONFIGURATION INFORMATION

Date of last Setup/Config Change: 2004-05-19, 08:43:26
Affinity Control SW v2.18
Configured COM Port: 2, COM Timeout: 5000ms
System Pwr Level: 500W, Amp Count: 8
Power Alarms Enabled
Fwd Pwr Alarm Low: 95, Fwd Pwr Alarm High: 105
Upconverter Pwr Alarm Low: 90, Upconverter Pwr Alarm High: 110

UPCONVERTER PARAMETERS INFORMATION

Upconverter Firmware Version: 1.10
System Fwd Pwr: 102
Sys Rev Pwr: 0
Upconverter Fwd Pwr: 105
Temperature: 197
Health Mask: 0xFF7B
Health Reading: 0xFFFF
Health Snapshot: 0xFFBF
Personality: 0xFFFF
FW State: 4
FW Mode: 1
In Signal: 0
Current Channel: 21
Stored Channel: 21

CALIBRATION VARIABLES

ALC_AUTO_REF_MIN: 0
ALC_AUTO_REF: 669
ALC_MANUAL_REF: 1325
SYS_FWD_PWR_REF: 567
SYS_REFLECTED_PWR_REF: 565
UPCONVERTER_INT_FWD_PWR_REF: 577
FAST_REFLECTED_SHUTDOWN_THRESHOLD: 920
FAST_REFLECTED_PWR_PERCENT_LIMIT: 20
POWER_LIMITER: 430
FILTER_COEFF_1: 7
FILTER_COEFF_2: 7
AGC_AUTO_REF_MIN: 4095
AGC_AUTO_REF: 4095
AGC_MANUAL_REF: 4095
IF_THRESHOLD: 4095
FREQ_RESP_1: 4095
FREQ_RESP_2: 4095

Miscellaneous Readings

SYS_FWD_PWR_ADC: 568
SYS_REFLECTED_PWR_ADC: 264
UPCONVERTER_PWR_ADC: 579
OUTPUT_AMP_CURRENT: 48
FINAL_AMP_CURRENT: 71

END OF DATA

Figure 10 Saved Upconverter Settings File Example

2.1.5.5 Purge Fault Log Operation

Clicking on this button will bring up a dialog window asking for fault log purge confirmation. If "Yes" is clicked, the entire contents of the existing fault history file will be deleted. Fault history data is written to a file named *FaultHistory.txt*. The fault history file is a standard text file, which can be read/opened with a text editor program such as Notepad. It is recommended that the fault history file be archived and purged as a regular part of the normal system maintenance. The file can either be copied or moved to some external storage medium.

2.2 Amplifier Gain Check Procedure

The Amplifier Gain Check procedure (refer to Figures 11, 12, 13, 14, 15, 16 and 17) allows the RF output power contribution of each individual amplifier to be checked. The procedure walks the user through a step-by-step process with on-screen instructions for each step. The procedure can be canceled and restarted at any time. Currently, it is not possible to go backwards (backup one or two steps). The basic procedure is as follows:

- Set upconverter to ALC Manual mode
- Raise *ALC Manual* value to adjust power between 50 and 100% output power.
- Turn each amp off, record power drop.
- Turn each amp back on.
- Repeat previous two steps for each of the remaining amps.




Figure 11 Amplifier Gain Check for 500W System (Screen 1)




Figure 12 Amplifier Gain Check for 500W System (Screen 2)




Figure 13 Amplifier Gain Check for 500W System (Screen 3)




Figure 14 Amplifier Gain Check for 500W System (Screen 4)




Figure 15 Amplifier Gain Check for 500W System (Screen 5)




Figure 16 Amplifier Gain Check for 500W System (Screen 6)




Figure 17 Amplifier Gain Check for 500W System (Screen 7)

The block representing the amplifier being tested is highlighted yellow when it should be turned OFF, highlighted white when it is to be turned ON, and highlighted blue when the test is completed. As the test on each amplifier is completed, the power level recorded with the

amplifier OFF is displayed below the amp. Note that the program does NOT actually know which amplifier is being turned OFF and assumes that the operator is following the sequence as highlighted. If the sequence is not followed correctly, the values under each amplifier block will not be correct for the specific location shown.

After all of the amplifiers have been tested, the program will calculate an average power drop and highlight the amplifiers that have a gain contribution below a calculated limit.

NOTE: An amplifier making little or no contribution to the final output power (i.e. power drops little when amp in question is deactivated) is most likely defective and may require replacement.

It is important to understand that the program only offers "advice." The operator should make the final decision regarding which amplifier(s) is/are defective. It is strongly recommended that the power levels shown for each amplifier be reviewed closely, that suspect amps be swapped to a new location, and that the test be re-run before deciding that an amplifier has failed.

2.3 Full Upconverter Calibration Procedure

The Full Upconverter Calibration Procedure allows a new upconverter to be calibrated to the system in which it operates. An average power meter and a selection of SMA or N attenuator values are REQUIRED (a 0-10dB variable attenuator is recommended) in order to perform this procedure. The program provides a step-by-step procedure with instructions for the entire calibration. Each step is documented in this manual. This program performs some of the steps listed below automatically. The steps that are performed are as follows:

- Initialize the upconverter with default parameters.
- Put upconverter into ALC Manual mode.
- Check/adjust the ADAPT output level and connect to the RF input port of the upconverter.
- Adjust the *ALC Manual Ref* value to bring the system to full power.
- Check/adjust and connect a forward power sample to the forward power sample input of the upconverter.
- Adjust the *System Fwd Pwr Ref* value to calibrate the "System Fwd Pwr" metering value displayed on the upconverter LCD.
- Adjust the *Upconv Fwd Power Ref* value to calibrate the "Upconv Fwd Pwr" metering value displayed on the upconverter LCD.
- Check/adjust and connect a reflected power sample to the reflected power sample input of the upconverter.
- Adjust the *System Refl Power Ref* value to calibrate the "System Refl Pwr" metering value displayed on the upconverter LCD.
- Place upconverter into ALC Auto mode.
- Adjust the *ALC Auto Ref* value to bring the system to full power in ALC Auto mode.
- Calibrate the *Power Limiter* threshold to limit maximum system output power.

Affinity Control User's Guide

Software v2.50

- Adjust the *Fast Refl Shutdown Threshold* value to set the reflected power –6dB trip level to 15% system reflected power.
- Adjust the *Fast Refl Power Percent Limit* to set the reflected power shutdown trip level.

Every calibration screen contains a help window on the right side. The instructions for each step are shown in this window. The left side of the screen shows each of the variables to be set during the calibration. The variables are highlighted during any adjustment. As needed, controls will be displayed below the calibration variables. There is a **Cancel** button in the lower right corner of the screen. The calibration procedure can be terminated at any time by clicking on the **Cancel** button.

The screen shown in Figure 18 is strictly informational. No adjustments or changes are performed at this time. The instructions note the requirement for an average power meter and various attenuator sizes.




Figure 18 Full Calibration-Initial Display Screen

The screen shown in Figure 19 displays a "last chance" warning message. Clicking on the **Next** button in this screen will erase any previous parameters stored in the upconverter and initialize it using default values. Clicking on the **Cancel** button will terminate the procedure without any changes being made to the upconverter settings.




Figure 19 Full Calibration-"Last Chance" Warning

The screen in Figure 20 displays a wait message while the upconverter is initialized with the pre-calibration default values. Note that the initialization can take a few minutes – Be patient.




Figure 20 Full Calibration-Upconverter Initialization

Affinity Control User's Guide Software v2.50

The screen in Figure 21 instructs the operator to adjust the output level of the ADAPT for +6dBm to +7dBm. This is the OPTIMAL input level for the upconverter. Although it will operate at lower (and higher) input levels, the best performance can be achieved with this level.

THALES Broadcast & Multimedia	
ALC Manual Ref	
System Fwd Pwr Ref	
Upconv Fwd Power Ref	
System Refl Power Ref	
ALC Auto Ref	
Power Limiter	
Fast Refl Shutdown Threshold	
Fast Refl Power Percent Limit	

Adjust the Adapt output for a level between +6 to +7dBm. When set, turn off RF and connect the Adapt output to the input of the Upconverter chassis and then, turn RF back ON.

Press the Next button to continue

Next Cancel

Figure 21 Full Calibration-ADAPT Output Level

The screen in Figure 22 is informational only. It instructs the operator to connect a power meter to a calibrated coupler on the output RF system.

THALES Broadcast & Multimedia	
ALC Manual Ref	
System Fwd Pwr Ref	
Upconv Fwd Power Ref	
System Refl Power Ref	
ALC Auto Ref	
Power Limiter	
Fast Refl Shutdown Threshold	
Fast Refl Power Percent Limit	

Connect a Power Meter to one of the calibrated couplers, after the Bandpass filter. The following steps require a Power Meter to monitor system output power while adjusting the Upconverter level. After the Power Meter is connected and setup,

Press the Next button to continue

Next Cancel

Figure 22 Full Calibration-Power Meter Setup

The screen in Figure 23 performs the calibration of the *ALC Manual Ref* parameter. This parameter controls the output level of the system when in ALC Manual mode.

Affinity Control - Full Upconverter Calibration

THALES Broadcast & Multimedia

ALC Manual Ref	1530
System Fwd Pwr Ref	
Upconv Fwd Power Ref	
System Refl Power Ref	
ALC Auto Ref	
Power Limiter	
Fast Refl Shutdown Threshold	
Fast Refl Power Percent Limit	

UP/DOWN Step Size: 10

UP DOWN

Next Cancel

Raise the "ALC Manual Ref" value until the system reaches full output power. Wait 10 seconds after every change to allow the system to respond. Let the system run at full power for 15 minutes or until the amplifiers have stabilized. Typically, the output power will not begin to increase until the "ALC Manual Ref" value is between 1000 and 1500. Adjust the UP/DOWN Step Size to use smaller steps as the system output power rises. NOTE: It should NOT be necessary to exceed an "ALC Manual Ref" level greater than 2000 to achieve full power! Press the Next button after the system has stabilized at full power.

Figure 23 Full Calibration-ALC Manual Ref Calibration

The screen in Figure 24 instructs the operator to connect a forward power sample to the upconverter forward power sample input. This will become the reference level for the ALC Auto mode (Automatic Level Control) as well as the reference for the "Fwd Pwr" display reading.

Affinity Control - Full Upconverter Calibration

THALES Broadcast & Multimedia

ALC Manual Ref	1530
System Fwd Pwr Ref	
Upconv Fwd Power Ref	
System Refl Power Ref	
ALC Auto Ref	
Power Limiter	
Fast Refl Shutdown Threshold	
Fast Refl Power Percent Limit	

UP/DOWN Step Size: 10

UP DOWN

Next Cancel

Adjust the level of the Fwd Pwr sample to the Upconverter for -5dBm (+/- 1dBm) at full system output power. Typically, one of the -50dB couplers is used to supply this sample. Press the Next button after the level is set and connected to the Upconverter Fwd Pwr reference input. Press the Next button to continue.

Figure 24 Full Calibration-System Fwd Pwr Sample Setup

In Figure 25, adjustment of the *System Fwd Pwr Ref* is performed. This calibrates the upconverter LCD display reading for "System Forward Pwr."

The screenshot shows the 'Affinity Control - Full Upconverter Calibration' window. The title bar includes a close button (X). Below the title bar is the text 'THALES Broadcast & Multimedia'. The main area contains a list of calibration parameters on the left and a large text box on the right. The parameters are: ALC Manual Ref (1530), System Fwd Pwr Ref (576), Upconv Fwd Power Ref (black), System Refl Power Ref (black), ALC Auto Ref (black), Power Limiter (black), Fast Refl Shutdown Threshold (black), Fast Refl Power Percent Limit (black), System Fwd Power (100), UP/DOWN Step Size (1), UP button, DOWN button, Next button, and Cancel button. The right text box contains instructions: 'Press the UP/DOWN buttons to adjust the Upconverter's LCD "System Fwd Power" reading until it displays 100. The System Fwd Power level is also displayed below. The "System Fwd Pwr Ref" value will also change, but in the opposite direction. Press the Next button when the Upconverter's "System Fwd Power" LCD reading is 100.'

Figure 25 Full Calibration-System Fwd Pwr Ref Calibration

The screen in Figure 26 is informational only.

The screenshot shows the 'Affinity Control - Full Upconverter Calibration' window. The title bar includes a close button (X). Below the title bar is the text 'THALES Broadcast & Multimedia'. The main area contains a list of calibration parameters on the left and a large text box on the right. The parameters are: ALC Manual Ref (1530), System Fwd Pwr Ref (576), Upconv Fwd Power Ref (black), System Refl Power Ref (black), ALC Auto Ref (black), Power Limiter (black), Fast Refl Shutdown Threshold (black), Fast Refl Power Percent Limit (black), System Fwd Power (100), UP/DOWN Step Size (1), UP button, DOWN button, Next button, and Cancel button. The right text box contains instructions: 'In this step, the Upconverter's LCD "Upconv Fwd Power" display value will be adjusted to display 100 at full system output power. Press the Next button to perform the adjustment.'

Figure 26 Full Calibration-Upconv Fwd Pwr Ref Info

In Figure 27, the *Upconv Fwd Power Ref* parameter is calibrated. This calibrates the Upconverter LCD "Upconv Forward Pwr" reading.

THALES Broadcast & Multimedia	
ALC Manual Ref	1530
System Fwd Pwr Ref	576
Upconv Fwd Power Ref	597
System Refl Power Ref	
ALC Auto Ref	
Power Limiter	
Fast Refl Shutdown Threshold	
Fast Refl Power Percent Limit	
Upconv Fwd Power	100
UP/DOWN Step Size	1

Press the UP/DOWN buttons to adjust the Upconverter's LCD "Upconv Fwd Power" reading until it displays 100. The Upconv Fwd Power level is also displayed below. The "Upconv Fwd Pwr Ref" value above will also change, but in the opposite direction.

Press the Next button when the Upconverter's "Upconv Fwd Power" LCD reading is 100.

UP: DOWN

Next Cancel

Figure 27 Full Calibration-Upconv Fwd Pwr Ref Calibration

The screen in Figure 28 instructs the operator to connect the samples used for the *Fwd Pwr Ref* calibration, to the upconverter Reflected Pwr sample input.

THALES Broadcast & Multimedia	
ALC Manual Ref	1530
System Fwd Pwr Ref	576
Upconv Fwd Power Ref	597
System Refl Power Ref	
ALC Auto Ref	
Power Limiter	
Fast Refl Shutdown Threshold	
Fast Refl Power Percent Limit	
Upconv Fwd Power	96
UP/DOWN Step Size	1

Remove the Fwd Pwr sample input and connect it to the Reflected Pwr input. The Reflected Pwr LCD level will be calibrated using the same -5dBm level previously setup for the Fwd Pwr Cal.

Press the Next button after the sample is connected to the Reflected Pwr input.

UP: DOWN

Next Cancel

Figure 28 Full Calibration-System Refl Power Ref Info

In Figure 29, the *System Refl Power Ref* is calibrated. This calibrates the Upconverter LCD "System Refl Pwr" reading.

THALES Broadcast & Multimedia	
ALC Manual Ref	1530
System Fwd Pwr Ref	576
Upconv Fwd Power Ref	597
System Refl Power Ref	617
ALC Auto Ref	
Power Limiter	
Fast Refl Shutdown Threshold	
Fast Refl Power Percent Limit	
System Ref Power	100
UP/DOWN Step Size	1
UP DOWN Next Cancel	

Press the UP/DOWN buttons to adjust the Upconverter's LCD "System Ref Power" reading until it displays 100. The System Ref Pwr level is also displayed below. The "System Refl Pwr Ref" value will also change, but in the opposite direction.

Press the Next button when the Upconverter's "System Ref Power" LCD reading is 100.

Figure 29 Full Calibration-System Refl Power Ref Calibration

This screen is informational only.

THALES Broadcast & Multimedia	
ALC Manual Ref	1530
System Fwd Pwr Ref	576
Upconv Fwd Power Ref	597
System Refl Power Ref	617
ALC Auto Ref	
Power Limiter	
Fast Refl Shutdown Threshold	
Fast Refl Power Percent Limit	
System Fwd Power	96
UP/DOWN Step Size	1
UP DOWN Next Cancel	

Remove the Fwd Pwr sample from the Reflected sample input and reconnect it to the Fwd Sample input of the Upconverter. Verify that the Upconverter LCD System Fwd Pwr display still reads approximately 100 (96-105) and

Press the Next button to continue

Figure 30 Full Calibration-System Refl Power Ref Calibration

The screen in Figure 31 is also informational only and simply describes what will be done in the next step of the procedure.

The screenshot shows the 'Affinity Control - Full Upconverter Calibration' window. The title bar includes a close button (X). The window header displays 'THALES Broadcast & Multimedia'. On the left, a list of parameters is shown with their current values in green boxes: ALC Manual Ref (1530), System Fwd Pwr Ref (576), Upconv Fwd Power Ref (597), System Refl Power Ref (617), ALC Auto Ref (black), Power Limiter (black), Fast Refl Shutdown Threshold (black), and Fast Refl Power Percent Limit (black). Below this list, 'System Fwd Power' is set to 96. At the bottom left, 'UP/DOWN Step Size' is set to 1, with 'UP' and 'DOWN' buttons. At the bottom right are 'Next' and 'Cancel' buttons. The main text area on the right contains the following instructions: 'The next step will be to calibrate the "ALC Auto Ref" value. This value is the control point for the automatic level control that will maintain a stable output power. The Fwd Pwr sample MUST be connected to the Upconverter input and the LCD System Fwd Pwr display MUST be approximately 100. Press the Next button to continue.'

Figure 31 Full Calibration-ALC Auto Ref Info

In this step, the upconverter is placed into ALC Auto mode prior to adjustment of the *ALC Auto Ref* parameter.

The screenshot shows the 'Affinity Control - Full Upconverter Calibration' window at the next step. The layout is identical to Figure 31, but the 'System Fwd Power' is now set to 100. The main text area on the right contains the following instructions: 'The system is now being placed in ALC AUTO mode. When the system enters ALC AUTO mode, the system output level will probably drop to zero - THIS IS NORMAL. Please wait...'. The 'Next' and 'Cancel' buttons are still present at the bottom right.

Figure 32 Full Calibration-ALC Auto Mode Switch

Affinity Control User's Guide Software v2.50

The adjustment and calibration of the *ALC Auto Ref* parameter is performed in this step. This calibration parameter controls the system output power during normal operation.

Affinity Control - Full Upconverter Calibration

THALES Broadcast & Multimedia

ALC Manual Ref	1510
System Fwd Pwr Ref	575
Upconv Fwd Power Ref	596
System Refl Power Ref	578
ALC Auto Ref	0
Power Limiter	
Fast Refl Shutdown Threshold	
Fast Refl Power Percent Limit	

System Fwd Power: 0

UP/DOWN Step Size: 50

UP DOWN

Next Cancel

Raise the "ALC Auto Ref" value until the system reaches full output power. Wait 10 seconds after every change to allow the system to respond. Let the system run at full power for 10 minutes or until the amplifiers have stabilized. Typically, the output power will not begin to rise until the "ALC Auto Ref" value is greater than 400. Adjust the UP/DOWN Step Size to use smaller steps as the system output power begins to rise. NOTE: The step size should be reduced when power begins to rise, since large step sizes can cause overpower conditions. Also, it should NOT be necessary to go above 800 to achieve full power!

Press the Next button after the system has stabilized at full power.

Figure 33 Full Calibration-ALC Auto Ref Calibration

Figure 34 is an informational only screen describing the next step to be performed.

Affinity Control - Full Upconverter Calibration

THALES Broadcast & Multimedia

ALC Manual Ref	1530
System Fwd Pwr Ref	576
Upconv Fwd Power Ref	597
System Refl Power Ref	617
ALC Auto Ref	676
Power Limiter	
Fast Refl Shutdown Threshold	
Fast Refl Power Percent Limit	

System Fwd Power: 100

UP/DOWN Step Size: 1

UP DOWN

Next Cancel

The next step will be to calibrate the "Power Limiter" value. This value is used to Limit the maximum system output power and is typically set to 1 dB above the normal full power level. The calibration is done by raising the system output power to approximately +1 dB using the "ALC Auto Ref" setting. The "Power Limiter" value is then lowered until the output power begins to drop.

Press the Next button to continue

Figure 34 Full Calibration-Power Limiter Info

Affinity Control User's Guide Software v2.50

In this step, the *ALC Auto Ref* value is increased to approximately 130% to set the *Power Limiter* threshold value. The maximum power limit can be set as desired; a threshold of 130% is provided as an example.

The screenshot shows the 'Affinity Control - Full Upconverter Calibration' window. The title bar includes a close button (X). Below the title bar is the text 'THALES Broadcast & Multimedia'. The window contains a table of parameters with their current values, a text box with instructions, and control buttons at the bottom.

ALC Manual Ref	1510
System Fwd Pwr Ref	575
Upconv Fwd Power Ref	596
System Refl Power Ref	578
ALC Auto Ref	676
Power Limiter	
Fast Refl Shutdown Threshold	
Fast Refl Power Percent Limit	
System Fwd Power	100

UP/DOWN Step Size: 10

Buttons: UP, DOWN, Next, Cancel

Instructions: Use the UP/DOWN buttons to increase the "ALC Auto Ref" value and to raise the System Output Pwr to approximately 130% (+/- 10%). This is approximately the +1dB level for the system. Press the Next button when the output power level has been set.

Figure 35 Full Calibration-Power Limiter Setup

This step performs the actual adjustment of the *Power Limiter* parameter. The power limiter is set to limit the maximum system output to the level desired.

The screenshot shows the 'Affinity Control - Full Upconverter Calibration' window. The title bar includes a close button (X). Below the title bar is the text 'THALES Broadcast & Multimedia'. The window contains a table of parameters with their current values, a text box with instructions, and control buttons at the bottom.

ALC Manual Ref	1510
System Fwd Pwr Ref	575
Upconv Fwd Power Ref	596
System Refl Power Ref	578
ALC Auto Ref	686
Power Limiter	3500
Fast Refl Shutdown Threshold	
Fast Refl Power Percent Limit	
System Fwd Power	142

UP/DOWN Step Size: 500

Buttons: UP, DOWN, Next, Cancel

Instructions: Use the UP/DOWN buttons to lower the "Power Limiter" value until power just begins to drop. Adjust it in smaller step sizes so that it is only reducing power by a 5 to 10%. Press the Next Button when done.

Figure 36 Full Calibration-Power Limiter Calibration

Affinity Control User's Guide Software v2.50

In this step, the program restores the previously calibrated *ALC Auto Ref* value to return the system to its normal full power level.

The screenshot shows the 'Affinity Control - Full Upconverter Calibration' window. The title bar includes a close button (X). The window header displays 'THALES Broadcast & Multimedia'. On the left, a table lists calibration parameters with their current values in green boxes:

ALC Manual Ref	1530
System Fwd Pwr Ref	576
Upconv Fwd Power Ref	597
System Refl Power Ref	617
ALC Auto Ref	676
Power Limiter	610
Fast Refl Shutdown Threshold	
Fast Refl Power Percent Limit	

Below the table, 'System Ref Power' is set to 126. At the bottom left, 'UP/DOWN Step Size' is set to 10, with 'UP' and 'DOWN' buttons. At the bottom right are 'Next' and 'Cancel' buttons.

The right-hand text area contains the following instructions:

The "ALC Auto Ref" value will now be reset to the 100% power output level

Please wait ...

Figure 37 Full Calibration-ALC Auto Full Power Restore

This is an informational only screen that instructs the operator in the setup required to calibrate the *Fast Reflected Shutdown Threshold* value. Setting the required reflected power sample levels is best accomplished with a variable attenuator.

The screenshot shows the 'Affinity Control - Full Upconverter Calibration' window. The title bar includes a close button (X). The window header displays 'THALES Broadcast & Multimedia'. On the left, a table lists calibration parameters with their current values in green boxes:

ALC Manual Ref	1530
System Fwd Pwr Ref	576
Upconv Fwd Power Ref	597
System Refl Power Ref	617
ALC Auto Ref	676
Power Limiter	610
Fast Refl Shutdown Threshold	
Fast Refl Power Percent Limit	

Below the table, 'System Ref Power' is set to 15. At the bottom left, 'UP/DOWN Step Size' is set to 10, with 'UP' and 'DOWN' buttons. At the bottom right are 'Next' and 'Cancel' buttons.

The right-hand text area contains the following instructions:

The next step will be to calibrate the "Fast Refl Shutdown Threshold". A fixed level will be connected to the Reflected sample input of the Upconverter and the trip point adjusted until the system enters -6dB power reduction mode. Using one of the forwards couplers on the RF System, feed a sample to the Upconverter Reflected Input and adjust the level until 15% is shown on the Upconverter LCD System Reflected Power display. The reading is also shown below.

Press the Next button after the display is reading 15

Figure 38 Full Calibration-Fast Reflected Shutdown Setup

Affinity Control User's Guide
Software v2.50

In this step, the *Fast Reflected Shutdown Threshold* parameter is adjusted until the system detects the 15% reverse power threshold. This will cause the system to reduce power by approximately 6dB. It may require several tries to get the threshold set accurately (within 20 units of true threshold). As described in the instructions, increase the *Fast Reflected Shutdown Threshold* slightly and use the **Reset** button to clear the trip fault. Repeat as necessary to get the trip set within 20 units.

The screenshot shows the 'Affinity Control - Full Upconverter Calibration' window. The title bar includes a close button (X). Below the title bar is the text 'THALES Broadcast & Multimedia'. The window contains a table of parameters with their current values and a text box on the right with instructions. At the bottom, there are controls for 'UP/DOWN Step Size' (set to 10), 'UP' and 'DOWN' buttons, and 'Reset', 'Next', and 'Cancel' buttons.

ALC Manual Ref	1530
System Fwd Pwr Ref	576
Upconv Fwd Power Ref	597
System Refl Power Ref	617
ALC Auto Ref	676
Power Limiter	610
Fast Refl Shutdown Threshold	1020
Fast Refl Power Percent Limit	
System Fwd Power	21

UP/DOWN Step Size: 10

Buttons: UP, DOWN, Reset, Next, Cancel

Instructions: Use the UP/DOWN buttons to lower the "Fast Refl Shutdown Threshold" value until power drops to -6dB (25%). Typically, this trip point is below 1000. Use large steps to reduce the value until 1000 is reached, then decrease the step size to 20 and continue lowering the value. If the trip occurs before 1000 is reached, raise the value by 50, press the Reset button and wait for power to return to full. Decrease the step size and try again. Repeat this process until the trip occurs with a step size of 20. Leave the system in the tripped state to continue. Press the Next button when the trip value has been found.

Figure 39 Full Calibration-Fast Reflected Shutdown Calibration

This step instructs the operator to adjust the reflected power sample level, while still in the -6dB power reduction mode, to 25% reverse power. This will be used to calibrate the *Fast Reflected Power Percent Limit* threshold for full system power shutdown.

The screenshot shows the 'Affinity Control - Full Upconverter Calibration' window. The title bar includes a close button (X). Below the title bar is the text 'THALES Broadcast & Multimedia'. The window contains a table of parameters with their current values and a text box on the right with instructions. At the bottom, there are controls for 'UP/DOWN Step Size' (set to 10), 'UP' and 'DOWN' buttons, and 'Reset', 'Next', and 'Cancel' buttons.

ALC Manual Ref	1530
System Fwd Pwr Ref	576
Upconv Fwd Power Ref	597
System Refl Power Ref	617
ALC Auto Ref	676
Power Limiter	610
Fast Refl Shutdown Threshold	1020
Fast Refl Power Percent Limit	
System Ref Power	25

UP/DOWN Step Size: 10

Buttons: UP, DOWN, Reset, Next, Cancel

Instructions: The next step will be to calibrate the "System Refl Power Percent Limit". This is the trip level that will cause the system to turn off the RF output completely. Increase the level of the Reflected sample connected to the Upconverter Reflected input until the Upconverter LCD Reflected Power display reads 25. Press the Next button when the level has been adjusted.

Figure 40 Full Calibration-Reflected Power Limit Setup

Affinity Control User's Guide

Software v2.50

This step will perform the adjustment on the *Fast Reflected Power Percent Limit* value in order to set the trip point for full system power shutdown. Normally, this is accomplished automatically. However, in some cases the value may need to be decreased by one or two percent.

Parameter	Value
ALC Manual Ref	1530
System Fwd Pwr Ref	576
Upconv Fwd Power Ref	597
System Refl Power Ref	617
ALC Auto Ref	676
Power Limiter	610
Fast Refl Shutdown Threshold	1020
Fast Refl Power Percent Limit	20
System Fwd Power	0

UP/DOWN Step Size: 1

Buttons: UP, DOWN, Reset, Next, Cancel

Text: Calculating and adjusting the "System Refl Power Percent Limit". The level will be set to 1 less than the current LCD System Forward Pwr reading. This should cause the system to trip and turn RF OFF completely. Wait 30 seconds and if power is not OFF, reduce the value by one and wait another 30 seconds. If this does not cause the trip, suspect a setup problem, or a fault in the Upconverter.

Press the Next button to continue

Figure 41 Full Calibration-Fast Refl Power Percent Limit Calibration

This is an informational only step instructing the operator on configuring the reflected power sample to the input of the upconverter. Normally, a reflected coupler with the same attenuation factor as the forward power sample is used. If one is not available, the attenuation of the chosen reflected sample coupler can be adjusted with fixed attenuators. This step is also the final step of the calibration procedure, and clicking on the **Next** button will exit the procedure.

Parameter	Value
ALC Manual Ref	1530
System Fwd Pwr Ref	576
Upconv Fwd Power Ref	597
System Refl Power Ref	617
ALC Auto Ref	676
Power Limiter	610
Fast Refl Shutdown Threshold	1020
Fast Refl Power Percent Limit	20
System Fwd Power	100

UP/DOWN Step Size: 1

Buttons: UP, DOWN, Reset, Next, Cancel

Text: Calculating and adjusting the "System Refl Power Percent Limit". The level will be set to 1 less than the current LCD System Forward Pwr reading. This should cause the system to trip and turn RF OFF completely. Wait 30 seconds and if power is not OFF, reduce the value by one and wait another 30 seconds. If this does not cause the trip, suspect a setup problem, or a fault in the Upconverter.

Press the Next button to continue

Figure 42 Full Calibration-Reflected Power Sample Setup

3 Affinity System Reference & Theory of Operation

Refer to the Affinity Simplified Block Diagram in Figure 43

3.1 ADAPT Reference

The ADAPT performs the on-channel generation of the 8VSB RF signal. It also performs all linear and nonlinear precorrection of the RF signal. The remote interface to the Affinity system for RF output ON/OFF, Raise/Lower, and Correction, is provided through the user interface module in the ADAPT chassis. The recommended RF output level of the ADAPT is between +6 and +7dBm. The RF output of the ADAPT chassis is fed to the RF input of the upconverter module.

3.2 Affinity/Upconverter Theory of Operation

The upconverter (amplifier) module provides sufficient amplification of the on-channel signal from the ADAPT to drive the high power amplifier(s). When used in ATSC service, the term "upconverter" is actually a misnomer since the unit does not perform any frequency upconversion, the output of the ADAPT exciter already being on the desired UHF channel. That is, the upconverter function is disabled, and the module functions as a simple preamplifier and transmitter controller.

The upconverter module provides RF output level control of the Affinity system. A sample of the forward power taken from the RF system is fed back to the upconverter and calibrated at the full power level of the system. This ALC control is capable of overcoming small variations in the output of the ADAPT, such as occurs when non-linear correction is performed. This parameter is calibrated using the Affinity Control software. The output level can be adjusted from the Main Control screen of the Affinity Control software by means of the *ALC Auto Ref* value.




Figure 43 Affinity System Simplified Block Diagram

The upconverter also receives a reflected power sample from the RF system. The upconverter is calibrated to reduce output power by 6dB when a 15% reflected power level is detected at the transmitter output. If a 25% or greater reverse power level is detected at this reduced power level, the upconverter will turn off the RF output completely. These trip levels can be calibrated

using the Affinity Control software. The 15% trip level can also be adjusted within the Metering/Display Calibration screen accessible from the Maintenance window.

The LCD display on the upconverter module provides rudimentary displays of forward power (percent), reflected power (percent), and upconverter internal forward power (percent). The forward and reflected power displays are calibrated to the forward and reflected power samples obtained from the RF system. The upconverter internal forward power reading is obtained from a measurement circuit inside the upconverter module. This reading may vary substantially, even after calibration, as the upconverter adjusts its output power to maintain a constant system output power in ALC Auto mode. All three display readings can be calibrated using the Affinity Control software. In addition, minor adjustments can be performed in the Metering/Display Calibration screen.

Finally, the upconverter module provides an overpower limit control. This power limiter can be set as desired to limit the maximum system output power via the *Power Limiter* value with the Affinity Control software.

NOTE: For 250W or lower power, the forward and reflected power samples are obtained internally to the transmitter chassis. In order to adjust those levels (...which should NOT be necessary), the rear panel of the transmitter chassis must be opened. This will be necessary when calibrating the reflected power sample, since the forward power sample is fed to it for 100% calibration.

3.3 Affinity Power Amplifier(s) Reference

The power amplifiers in the Affinity system provide the high power output. The number of amplifiers in the system is dependent on the system's rated output power. The amplifiers have an internal microcontroller to monitor their operation. Should a fault condition be detected, the amplifier output will be shut down and the status LED on the amplifier module will turn RED. In addition, a logic board monitors amplifier status and reduces system power (in ALC Auto mode) when an amplifier fault is detected. The power reduction level is dependent on the number of amplifiers in the system and the number amplifiers currently faulted. Table 1 lists the various system power levels, faulted amplifiers, and associated power reduction.

	Faulted Amplifier Count							
Power	1	2	3	4	5	6	7	8
50W	Off							
100W	-6dB	Off						
200W	-3dB	-6dB	Off					
250W	-3dB	-6dB	Off					
500W	-1.5dB	-3dB	-6dB	-6dB	Off			
1kW	-1.5dB	-1.5dB	-3dB	-3dB	-6dB	-6dB	-6dB	-6dB

Table 1 Amplifier Fault Power Reduction Levels (in ALC Auto mode)

3.4 Affinity Control Software to EMSET Variable Cross Reference

Table 2 lists the EMSET v5.0 variables that are normally adjusted during either, the initial setup and calibration of an Upconverter, or during typical operation. Some of the variables are automatically set and/or controlled by the Affinity Control software and are not directly accessible by the user. Table 3 lists the same EMSET variables and includes a brief description of their effect. This table is provided for those users familiar with the original EMSET software.


EMSET Variable	Affinity Control Equivalent & Access
ALC_MODE_SELECT	Not directly accessible. Automatically set as appropriate for software operation.
ALC_AUTO_REF_MIN	Not directly accessible. Automatically set during the Full Upconverter Calibration procedure as part of the upconverter initialization.
ALC_AUTO_REF	Accessed during the Full Upconverter Calibration procedure. Also, the Main Control screen Raise & Lower buttons adjust this value up or down in steps of 1.
ALC_MANUAL_REF	Not directly accessible. Adjusted during the Full Upconverter Calibration procedure.
FAST REFLECTED SHUTDOWN THRESHOLD	Accessible in the Metering/LCD Display Calibration screen. Also adjusted during the Full Upconverter Calibration procedure.
POWER LIMITER	Not directly accessible. Adjusted during the Full Upconverter Calibration procedure.
FILTER_COEFF_1	Not directly accessible. Automatically set during the Full Upconverter Calibration procedure as part of the upconverter initialization.
FILTER_COEFF_2	Not directly accessible. Automatically set during the Full Upconverter Calibration procedure as part of the upconverter initialization.
SYSTEM FWD PWR REFERENCE	Accessible in the Metering/LCD Display Calibration screen. Also adjusted during the Full Upconverter Calibration procedure.
SYSTEM REFLECTED PWR REF	Accessible in the Metering/LCD Display Calibration screen. Also adjusted during the Full Upconverter Calibration procedure.
UPCONVERTER INTERNAL FRD PWR REF	Accessible in the Metering/LCD Display Calibration screen. Also adjusted during the Full Upconverter Calibration procedure.
SYSTEM REFLECTED POWER PERCENT LIMIT	Not directly accessible. Adjusted during the Full Upconverter Calibration procedure.
UPCONV HEALTH PLAN MASK	Not directly accessible. Automatically set during the Full Upconverter Calibration procedure as part of the upconverter initialization.
UNUSED WORD 1	Not directly accessible. Automatically set during the Full Upconverter Calibration procedure as part of the upconverter initialization.

Table 2 EMSET Variables to Affinity Control Software Cross Reference

EMSET Variable	Affinity Control Equivalent & Access
ALC_MODE_SELECT	This parameter places the upconverter either in ALC Auto or ALC Manual mode. The output power level is only controlled automatically in ALC Auto mode, which is the normal operating mode.
ALC_AUTO_REF_MIN	This parameter sets the minimum ALC level and is normally set to zero.
ALC_AUTO_REF	This parameter sets the ALC Auto full power level.
ALC_MANUAL_REF	This parameter sets the ALC Manual power output level.
FAST REFLECTED SHUTDOWN THRESHOLD	This parameter sets the trip point for the -6dB power reduction at 15% reflected power.
POWER LIMITER	This parameter sets the maximum overpower output limit.
FILTER_COEFF_1	This parameter sets the number of averages used for the "Fwd" and "Ref" power readings in the upconverter LCD display and is normally set to 7.
FILTER_COEFF_2	This parameter sets the number of averages used for the "Upconverter Internal Fwd" power reading in the upconverter LCD display and is normally set to 7.
SYSTEM FWD PWR REFERENCE	This parameter is the calibration value for the upconverter LCD "System Forward Pwr" reading.
SYSTEM REFLECTED PWR REF	This parameter is the calibration value for the upconverter LCD "System Reflected Pwr" reading.
UPCONVERTER INTERNAL FRD PWR REF	This parameter is the calibration value for the upconverter LCD "Upconv Forward Pwr" reading.
SYSTEM REFLECTED POWER PERCENT LIMIT	This parameter sets the trip point for 25% reflected power at the (already) -6dB reduced output level.
UPCONV HEALTH PLAN MASK	This parameter selects the features and capabilities of the upconverter. It is typically set to 65403 or 65407 (Rev B Upconverter).
UNUSED WORD 1	This parameter is normally set to 21. It is normally used only in multi-channel frequency-agile Affinity systems.

Table 3 EMSET Variables Description

QTY/VERSION			PARTS LIST		
		-	ITEM	PART NO.	DESCRIPTION
		-	1	47267081-040	DWG, HARNESS ASSY SW CTRL
		1	2	607159-01	CONN, SOCKET SUB-MINI DE-9S
		1	3	605624-01	CONN, 9POS D-SUB HOOD
		A/R	4	751106-01	WIRE, PHONE 6C 26GA 966B628
		1	5	751105-01	CONN, PHONE 6P 24-26GA 966B366
		1	6	605858-01	LABEL, PIN FEED 1" X 1.4"



NOTES:

- 1 LABEL TO CONTAIN PART NUMBER, REVISION LEVEL, VENDOR I.D. PER THALES-BM SPEC #452788, USING BLACK HELVETICA CHARACTERS ON WHITE BACKGROUND.

2 UNUSED YELLOW AND BLUE CONDUCTORS SHALL BE CUT FLUSH WITH JACKET.

A	~	JANUARY	3/31/04	DATE	ENGINEERING RELEASE	DESCRIPTION
REV	CHANGE ORDER	ISSUED	DATE	AUTHORIZED		
UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES. DIMENSIONS IN BRACKETS, DIMS. IN MILLIMETERS. TOLERANCES: ±.03, ±.001 FOR ±.XXX, ±.010, ±.005 FOR ±.XXX, ±.1, ±.1/2" FOR ANGLES						
ISSUED	JANUARY	3/31/04	MATERIAL	SEE PARTS LIST		
CHECKED	G DelCAMPE	4/2/04	TREATMENT	~		
ENG	DONALD WIKI	4/10/04	FINISH	~		
PROJECT	~		PROJECT NO.	CAD FILE	472667081040A1	PROJECTION  SCALE: 1:1
MFG	T JERARD	4/5/04	HARNES ASSY, DE9S-RJ11			
EDC	D M TOUGAS	4/16/04				
THALES BROADCAST & MULTIMEDIA, INC.			DOCUMENT NUMBER		PAGE	
			47267081		040 B 1 / 1	
OFFICE RESP. SOUTHWICK, MA					REV A	

Thales Broadcast & Multimedia, Inc.
104 Feeding Hills Road
Southwick, MA 01077 U.S.A.
(800) 345-9295
www.thales-bm.com
Made and printed in the U.S.A.