

INSTRUCTIONS FOR OPERATION

SETTING THE OPERATING CONTROLS

1. This unit operates on a 1.5 volts battery *2 (not included).
To prevent possible damage if the battery should leak , be sure to remove the battery when the unit is not use .
2. Store the controller away from excess heat or humidity .
3. This remote control unit is required with 26bit code combinations. To prevent possible interference from or to other remote units such as garage door openers, car alarm or security system .
4. Operation buttons on the panel of transmitter .



button - FAN ON/OFF



button – increases the fan speed



button – decreases fan speed



button – Start up/shut down natural wind mode



button – Start up/shut timer



button – Fan reverse Warm weather



button – Fan reverse Cool weather



button - Light ON/OFF



button - Decrease the desired light level



button - Increase desired light level

CONTROL SWITCH – For light brightness and ON/OFF control .

5. Start the fan or Turn off the fan

Press the FAN ON/OFF button .

6. Fan speed control :

Press the + , – button to run the fan at the desired.

7. Light control :

Turn the light on or off : Press the LIGHT ON/OFF button .

**Dimmer : press the Decrease the desired light level button , or
press the Increase desired light level button.**

GENERAL INFORMATION :

This REMOTE controller is designed to separately control your ceiling fan speed and light brightness . The Light

ON/OFF button will control the light brightness ON/OFF .

The LED indicator on the transmitter will light when the Function button is pressed .

INSTRUCTIONS FOR INSTALLATION AND OPERATION OF FAN SPEED CONTROLLER

1. Setting the code on your new transmitter .

Within 60 seconds of turning the AC power on, press and hold the FAN ON/OFF button for 5 seconds. The receiver will then lock in the chosen frequency.

If your fan has a light it will blink twice, for fans without lights check operation using the transmitter

NOTICE :

The changes or modifications not expressly approved by the party responsible for compliance could void user's authority to operate the equipment .

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause