


#### (4) DISTRESS RELAY CALL

Normally, a distress call is acknowledged by a coastal station, but if there is not acknowledgement by any station (e.g., due to propagation, etc.) relay it after editing the message for a relay call by selecting this menu. Normally, a distress relay is made by selecting this menu.



## Procedure

### Example: Procedure of a distress relay call to all ships

1. From the "MENU#1-EDIT&CALL" screen, press **[4]** , and then press **[ENT]** .  
The "DISTRESS RELAY CALL" screen is displayed.

```

DISTRESS RELAY CALL      Select no. __
▶1.ALL SHIP'S DIST rly EDIT
2.INDIVIDUAL DIST rly EDIT
  
```

### Note

1. Select 1 to relay the call to all ships and coastal stations.
2. Select 2 to relay the call to an individual ship or coastal station.

2. Press **[1]** . and then press **[ENT]** .

The "ALL SHIPS DIST-RELAY" screen is displayed.

```

ALL SHIP'S DIST-RELAY
▶Dist-address   : XXXXXXXXXX
Nature         : UNDESIGNATED DIST
Dist-position  : 12° 34' N123° 45' E
Dist-UTC       : 01:20
Dist-telecomm  : J3E TEL
Call TX/RX freq: 2,187.5 / 2,187.5 kHz
  
```

Use **[▲]** and **[▼]** to scroll the screen.

The following items have been set in this example.

```

「Dist-address」 : XXXXXXXXXX
「Nature」       : UNDESIGNATED DIST
「Dist-position」: 12° 34' N123° 45' E
「Dist-UTC」     : 01:20
「Dist-telecomm」: J3E TEL
「Call TX/RX freq」: 2,187.5/2,187.5 kHz
  
```


### ●Entering the respective items:

After selecting each item, press **[ENT]** to confirm the selection.

- (1) Dist-address: Use the numerical keys (**[0]** to **[9]**) to enter the address of the receiving station (ship or coastal station).
- (2) Nature  
Dist-telecomm: Use the **[◀]** and **[▶]** keys to select the items.
- (3) Dist-position: Use the **[◀]** and **[▶]** keys to determine the direction, and then input the ship's position using the numerical keys (**[0]** to **[9]**).
- (4) Dist-UTC: Use the numerical keys (**[0]** to **[9]**) to enter the time.
- (4) Call TX/RX freq: Use the **[◀]** and **[▶]** keys to select one of the preset frequencies, or use the numerical keys (**[0]** to **[9]** ,and **[.]**) to specify a frequency directly.

3. Press **CALL** , and then open the cover on the left and press **DISTRESS** for at least 3 seconds (until the intermittent alarm tone changes to a continuous tone).

The following screen is displayed and the message is transmitted.




ALL SHIP'S DIST-RELAY      Transmitting  
TX frequency : 2,187.5 kHz  
TX date&time : 06.Sep.2001(Thu) 01:30

**Note**

- Press **STOP** to cancel the DISTRESS transmission.
- To discard the message and quit without sending it, press **FUNC** **4** (QUIT).
- Unable to save the message.

## (5) AUTO/SEMI-AUTO CALL

This mode is available only to coastal stations where the telephone on board can be connected on-line to a public line on the land after DSC communication on the MF/HF band.



## Procedure

### 1. From the "MENU#1-EDIT&CALL" screen, press **[5]**, and then press **[ENT]**.

The "AUTO/SEMI-AUTO CALL" screen is displayed.

|                     |                  |               |
|---------------------|------------------|---------------|
| AUTO/SEMI-AUTO CALL |                  | Transmissible |
| ▶ Address           | : XXXXXXXXXX     |               |
| Telecommand-1       | : J3E TEL        |               |
| Telecommand-2       | : NO INFORMATION |               |

Ship's position: 12° 34' N 123° 45' E  
 Telephone no. : 04224507XX  
 Call TX/RX freq: 4,208.0/4,219.5kHz

Use **[▲]** and **[▼]** to scroll the screen.

The following items have been set in this example.

「Address」 : XXXXXXXXXX  
 「Telecommand-1」 : J3E TEL  
 「Telecommand-2」 : NO INFORMATION  
 「Ship's position」 : 12° 34' N 123° 45' E  
 「Telephone no.」 : 04224507XX  
 「Call TX/RX freq」 : 4,208.0/4,219.5 kHz

#### ● Entering the respective items:

After selecting each item, press **[ENT]** to confirm the selection.

- (1) Address: Use the numerical keys (**[0]** to **[9]**) to enter the address of the receiving station (ship or coastal station).
- (2) Telecommand-1: Use the **[◀]** and **[▶]** keys to select the items.  
Telecommand-2
- (3) Ship's-position: Use the **[◀]** and **[▶]** keys to determine the direction, and then input the ship's position using the numerical keys (**[0]** to **[9]**).
- (4) Telephone no. Use the numerical keys (**[0]** to **[9]**) to enter the telephone number.
- (5) Call TX/RX freq: Use the **[◀]** and **[▶]** keys to select one of the preset frequencies, or use the numerical keys (**[0]** to **[9]**, and **[.]**) to specify a frequency directly.
- (6) Other settings: **[◀]** **[▶]**
  - "Work TX/RX freq": Use the numerical keys (**[0]** to **[9]**, and **[.]**) to directly specify a frequency.
  - Switching from "Ship's position" to "Work TX/RX freq": Press **[FUNC]** **[6]** (FREQ).
  - Switching from "Work TX/RX freq" to "Ship's position": Press **[FUNC]** **[5]** (POS).

## ATTENTION

This call requires the auto/semi-auto call service of a coastal station.  
 Please ask the coastal station you use for details.

**2. Press** **CALL**

The following screen is displayed and the message is transmitted.

```
AUTO/SEMI-AUTO CALL Transmitting
TX frequency   : 4,208.0 kHz
TX date&time   : 06.Sep.2001(Thu) 01:30
```

**Note**

If the tuner is not tuned to the transmission frequency, the "tuner mismatch!!" warning message is displayed. Press **ENT** to tune the tuner, then transmit the message.

When the transmission is completed, the following screen is displayed. After a brief interval, operation returns to the "MENU#1-EDIT&CALL" screen.


```
AUTO/SEMI-AUTO CALL Send Completed
TX frequency   : 4,208.0 kHz
TX date&time   : 06.Sep.2001(Thu) 01:30
```

**Note**

To discard the message and quit without sending it, press **FUNC** **4** (QUIT).  
To store a message without sending it, press **FUNC** **9** (SAVE).

## (6) ALL SHIPS CALL

An all ships call is transmitted to all ships. Normally, this feature is used to acknowledge when a distress call is received and a distress acknowledgement from a coastal station has not been received in response.



## Procedure

**Example: Procedure for a distress relay call to all ships**

**1. From the "MENU#1-EDIT&CALL" screen, press **[6]**, and then press **[ENT]**.**

The "ALL SHIPS CALL" screen is displayed.

|                 |                         |
|-----------------|-------------------------|
| ALL SHIPS CALL  |                         |
| ▶ Category      | : DISTRESS              |
| Telecommand-1   | : DISTRESS RELAY        |
| Dist-address    | : XXXXXXXXX             |
| Nature          | : UNDESIGNATED DIST     |
| Dist-position   | : 12 ° 34'N123 ° 45'E   |
| Dist-UTC        | : 01:20                 |
| Dist-telecomm   | : J3E TEL               |
| Call TX/RX freq | : 4,208.0 / 4,208.0 kHz |

Use **[▲]** and **[▼]** to scroll the screen.

The following items have been set in this example.

|                   |                         |
|-------------------|-------------------------|
| 「Category」        | : DISTRESS              |
| 「Telecommand-1」   | : DISTRESS RELAY        |
| 「Dist-address」    | : XXXXXXXXX             |
| 「Nature」          | : UNDESIGNATED DIST     |
| 「Dist-position」   | : 12 ° 34'N123 ° 45'E   |
| 「Dist-UTC」        | : 01:20                 |
| 「Dist-telecomm」   | : J3E TEL               |
| 「Call TX/RX freq」 | : 4,208.0 / 4,208.0 kHz |

### ● Entering the respective items:

After selecting each item, press **[ENT]** to confirm the selection.


- (1) Dist-address: Use the numerical keys (**[0]** to **[9]**) to enter the address of the receiving station (ship or coastal station).
- (2) Category  
Telecommand-1: Use the **[◀]** and **[▶]** keys to select the items.  
Nature  
Dist-telecomm
- (3) Dist-position: Use the **[◀]** and **[▶]** keys to select the bearing, and then input the value using the numerical keys (**[0]** to **[9]**).
- (4) Dist-UTC: Use the numerical keys (**[0]** to **[9]**) to enter the time.
- (5) Call TX/RX freq: Use the **[◀]** and **[▶]** keys to select one of the preset frequencies.  
Alternatively, use the numerical keys (**[0]** to **[9]**, and **[.]**) to directly specify a frequency.

### Note

Set the "Work TX/RX freq" to a frequency in the same band as the "Call TX/RX freq".


2. Press **CALL** , then open the cover on the left and press **DISTRESS** for at least 3 seconds (until the intermittent alarm tone changes to a continuous tone).

The following screen is displayed and the set distress message is transmitted.



ALL SHIPS CALL                      Transmitting  
TX frequency :    4,208.0 kHz  
TX date&time : 06.Sep.2001 (Thu) 01:26

When the transmission is completed, the following screen is displayed and the message is automatically saved. After a brief interval, operation returns to the "MENU#1-EDIT&CALL" screen.



ALL SHIPS CALL                      Send Completed  
TX frequency :    4,208.0 kHz  
TX date&time : 06.Sep.2001 (Thu) 01:26

**Note**


See (1), "Individual Call" for how to send a general message.

To store a message without sending it, press **FUNC** **9** (SAVE).

To discard the message and quit without sending it, press **FUNC** **4** (QUIT).

## (7) GROUP CALL

This process is used to edit and transmit a message to a specific group.



## Procedure

1. From the "MENU#1-EDIT&CALL" screen, press **[7]**, and then press **[ENT]**.

The "GROUP CALL" screen is displayed.

|                 |                         |
|-----------------|-------------------------|
| GROUP CALL      |                         |
| Group address   | : XXXXXXXXXX            |
| Category        | : ROUTINE               |
| Telecommand-1   | : J3E TEL               |
| Telecommand-2   | : NO INFORMATION        |
| Work TX/RX freq | : 4,444.1 / 4,455.5 kHz |
| Call TX/RX freq | : 4,208.0 / 4,219.5 kHz |

Use **[▲]** and **[▼]** to scroll the screen.

The following items have been set in this example.

「Group address」 : XXXXXXXXXX  
 「Category」 : ROUTINE  
 「Telecommand-1」 : J3E TEL  
 「Telecommand-2」 : NO INFORMATION  
 「Work TX/RX freq」 : 4,444.1 / 4,455.5 kHz  
 「Call TX/RX freq」 : 4,208.0 / 4,219.5 kHz

### ● Entering the respective items:

After selecting each item, press **[ENT]** to confirm the selection.

- (1) Group address: Use the numerical keys (**[0]** to **[9]**) to enter the address of the receiving station (ship or coastal station).
- (2) Category  
Telecommand-1: Use the **[◀]** and **[▶]** keys to select the items.  
Telecommand-2
- (3) Work TX/RX freq Use the numerical keys (**[0]** to **[9]**, and **[.]**) to directly specify a frequency.
- (4) Call TX/RX freq: Use the **[◀]** and **[▶]** keys to select one of the preset frequencies. Alternatively, use the numerical keys (**[0]** to **[9]**, and **[.]**) to directly specify a frequency.
- (5) Other settings:
  - "Ship's position": Use the **[◀]** and **[▶]** keys to select the bearing, and then input the value using the numerical keys (**[0]** to **[9]**).
  - Switching from "Ship's position" to "Work TX/RX freq": Press **[FUNC]** **[6]** (FREQ).
  - Switching from "Work TX/RX freq" to "Ship's position": Press **[FUNC]** **[5]** (POS).

### Note

Set the "Work TX/RX freq" to a frequency in the same band as "Call TX/RX freq".

**2. Press CALL.**

The following screen is displayed and the message is transmitted.

```
GROUP CALL           Transmitting
TX frequency  : 4,208.0 kHz
TX date&time  : 06.Sep.2001(Thu) 01:30
```

**Note**

If the tuner is not tuned to the transmission frequency, the "tuner mismatch!!" warning message is displayed. Press ENT to tune the tuner, then transmit the message.

When the transmission is completed, the following screen is displayed. After a brief interval, operation returns to the "MENU#1-EDIT&CALL" screen.


```
GROUP CALL           Send Completed
TX frequency  : 4,208.0 kHz
TX date&time  : 06.Sep.2001(Thu) 01:30
```

**Note**

To discard the message and quit without sending it, press FUNC 4 (QUIT).  
To store a message without sending it, press FUNC 9 (SAVE).


## (8) AREA CALL

This procedure is used to edit and transmit a call message to ships in the specified area.



## ● Area call setting

An area call is received by all ships navigating in a designated geographical area. For the area of called stations (PARTY AD), latitude, longitude, deviation latitude (from North to South), and deviation longitude (from West to East) are necessary. The area of the shaded part is designated in the figure below.



First, select the direction from N.E. (North-East), N.W. (North-West), S.E. (South-East), and S.W. (South-West). In this example, the direction is N.E.

PARTY AD : N E DLAT LONG /

Next, enter 20°, 120°, making this latitude 20° and longitude 120°.

PARTY AD : N20E120 DLAT LONG /

In addition, as the deviation latitude (DLAT) and deviation longitude (LONG) are, respectively, 10° and 50°, input 1050..

PARTY AD : N20E120DLAT10LONG50

Finally, press **ENT** to confirm the area.

## Note

Up to 99° can be input for deviation latitude and deviation longitude.  
Ranges that include the Arctic Pole or Antarctic Pole cannot be specified.

## Procedure

1. From the "MENU#1-EDIT&CALL" screen, press **8**, and then press **ENT**.  
The "AREA CALL" screen is displayed.

|                 |                         |               |
|-----------------|-------------------------|---------------|
| AREA CALL       |                         | Transmissible |
| Area            | : N20E120DLAT10LONG50   |               |
| Category        | : ROUTINE               |               |
| Telecommand-1   | : J3E TEL               |               |
| Telecommand-2   | : NO INFORMATION        |               |
| Work TX/RX freq | : 4,444.1 / 4,455.5 kHz |               |
| Call TX/RX freq | : 4,208.0 / 4,219.5 kHz |               |

Use **▲** and **▼** to scroll the screen.

The following items have been set in this example.

「Area」 : N20E120DLAT10LONG50  
「Category」 : ROUTINE  
「Telecommand-1」 : J3E TEL  
「Telecommand-2」 : NO INFORMATION  
「Work TX/RX freq」 : 4,444.1/4,455.5 kHz  
「Call TX/RX freq」 : 4,208.0/4,219.5 kHz

● Entering the respective items:

After selecting each item, press **ENT** to confirm the selection.

(1) Category

Telecommand-1: Use the **◀** and **▶** keys to select the items.  
Telecommand-2

(2) Area

Ship's position: Use the **◀** and **▶** keys to select the bearing, and then input the value using the numerical keys (**0** to **9**).

(3) Call TX/RX freq: Use the **◀** and **▶** keys to select one of the preset frequencies. Alternatively, use the numerical keys (**0** to **9** , and **.** ) to directly specify a frequency.

(4) Other settings:

• "Work TX/RX freq": Use the numerical keys (**0** to **9** , and **.** ) to directly specify a frequency.

• Switching from "Ship's position" to "Work TX/RX freq": Press **FUNC** **6** (FREQ).


• Switching from "Work TX/RX freq" to "Ship's position": Press **FUNC** **5** (POS).

**Note**

Set the "Work TX/RX freq" to a frequency in the same band as "Call TX/RX freq".

**2. Press **CALL**.**

The following screen is displayed and the message is transmitted.




```
AREA CALL           Transmitting
TX frequency : 4,208.0 kHz
TX date&time : 06.Sep.2001(Thu) 01:30
```

**Note**

If the tuner is not tuned to the transmission frequency, the "tuner mismatch!!" warning message is displayed. Press **ENT** to tune the tuner, then transmit the message.

When the transmission is completed, the following screen is displayed. After a brief interval, operation returns to the "MENU#1-EDIT&CALL" screen.




```
AREA CALL           Send Completed
TX frequency : 4,208.0 kHz
TX date&time : 06.Sep.2001(Thu) 01:30
```

**Note**

To discard the message and quit without sending it, press **FUNC** **4** (QUIT).  
To store a message without sending it, press **FUNC** **9** (SAVE).

## (9) POSITION REQUEST CALL

This feature is used when a coastal station wants to know a ship's position, or two ships want to know each other's position.



## Procedure

### 1. From the "MENU#1-EDIT&CALL" screen, press **[9]**, and then press **[ENT]**.

The "POSITION REQUEST" screen is displayed.

```
POSITION REQUEST
▶ Address          : XXXXXXXXXX
Call TX/RX freq   : 4,208.0/4,219.5 kHz
```

The following items have been set in this example.

```
「Address」        : XXXXXXXXXX
「Call TX/RX freq」 : 4,208.0/4,219.5 kHz
```

#### ● Entering the respective items:

After selecting each item, press **[ENT]** to confirm the selection.

(1) Address: Use the numerical keys (**[0]** to **[9]**) to enter the address of the receiving station (ship or coastal station).

(2) Call TX/RX freq: Use the **[◀]** and **[▶]** keys to select one of the preset frequencies. Alternatively, use the numerical keys (**[0]** to **[9]**), and **[.]** to directly specify a frequency.

### 2. Press **[CALL]**.

The following screen is displayed and the message is transmitted.

```
POSITION REQUEST      Transmitting
TX frequency          : 4,208.0 kHz
TX date&time          : 06.Sep.2001(Thu) 01:30
```

#### Note

If the tuner is not tuned to the transmission frequency, the "tuner mismatch!!" warning message is displayed. Press **[ENT]** to tune the tuner, then transmit the message.

When the transmission is completed, the following screen is displayed. After a brief interval, operation returns to the "MENU#1-EDIT&CALL" screen.


```
POSITION REQUEST      Send Completed
TX frequency          : 4,208.0 kHz
TX date&time          : 06.Sep.2001(Thu) 01:30
```

#### Note

To discard the message and quit without sending it, press **[FUNC]** **[4]** (QUIT).  
To store a message without sending it, press **[FUNC]** **[9]** (SAVE).

## (10) POLLING CALL

This feature is used to confirm that the destination station exists within a communication area.



## Procedure

### 1. From the "MENU#1-EDIT&CALL" screen, press **[1]** **[0]** , and then press **[ENT]** .

The "POLLING CALL" screen is displayed.

```
POLLING CALL
▶Address      : XXXXXXXXX
Call TX/RX freq : 4,208.0 / 4,219.5 kHz
```

The following items have been set in this example.

```
「Address」      : XXXXXXXXX
「Call TX/RX freq」 : 4,208.0 / 4,219.5 kHz
```

#### ● Entering the respective items:

After selecting each item, press **[ENT]** to confirm the selection.

- (1) Address: Use the numerical keys (**[0]** to **[9]**) to enter the address of the receiving station (ship or coastal station).
- (2) Call TX/RX freq: Use the **[◀]** and **[▶]** keys to select one of the present frequencies.  
Alternatively, use the numerical keys (**[0]** to **[9]** ,and **[.]**) to directly Specify a frequency.

### 2. Press **[CALL]** .

The following screen is displayed and the message is transmitted.

```
POLLING CALL          Transmitting
TX frequency   : 4,208.0 kHz
TX date&time   : 06.Sep.2001 (Thu) 01:30
```

#### Note

If the tuner is not tuned to the transmission frequency, the "tuner mismatch!!" warning message is displayed. Press **[ENT]** to tune the tuner, then transmit the message.

When the transmission is completed, the following screen is displayed. After a brief interval, operation returns to the "MENU#1-EDIT&CALL" screen.


```
POLLING CALL          Send Completed
TX frequency   : 4,208.0 kHz
TX date&time   : 06.Sep.2001 (Thu) 01:30
```

#### Note

To discard the message and quit without sending it, press **[FUNC]** **[4]** (QUIT).  
To store a message without sending it, press **[FUNC]** **[9]** (SAVE).

#### (11) TEST CALL

If possible, refrain from making tests using any of the frequencies listed in Section 8.2.1. However, should such a test become unavoidable, first obtain permission from the targeted coastal station.



## Procedure

1. From the "MENU#1-EDIT&CALL" screen, press **[1]** **[1]**, and then press **[ENT]**.  
The "TEST CALL" screen is displayed.

```
TEST CALL                      Transmissible
▶ Address                      : XXXXXXXXXX
Call TX/RX freq: 4,208.0/4,219.5 kHz
```

The following items have been set in this example.

```
「Address」          : XXXXXXXXXX
「Call TX/RX freq」 : 4,208.0/4,219.5 kHz
```

2. Press **[CALL]**.

The following screen is displayed and the message is transmitted.

```
TEST CALL                      Transmitting
TX frequency   : 4,208.0 kHz
TX date&time   : 06.Sep.2001(Thu) 01:30
```

### Note

If the tuner is not tuned to the transmission frequency, the "tuner mismatch!!" warning message is displayed. Press **[ENT]** to tune the tuner, then transmit the message.

When the transmission is completed, the following screen is displayed. After a brief interval, operation returns to the "MENU#1-EDIT&CALL" screen.

```
TEST CALL                      Send Completed
TX frequency   : 4,208.0 kHz
TX date&time   : 06.Sep.2001(Thu) 01:30
```

### Note

To discard the message and quit without sending it, press **[FUNC]** **[4]** (QUIT).

To store a message without sending it, press **[FUNC]** **[9]** (SAVE).

Normally, the message content is predetermined so that the message is sent to a coastal station.

### 3.5.4 Other Functions

#### (1) Frequency scanning

When the JSB-196/196GM Radiotelephone is connected, scanning<sup>\*1</sup> reception among the six specified frequencies is available. When the NCT-196N automatic acknowledgement setting<sup>\*2</sup> is ON and a message requiring acknowledgment is received<sup>\*3</sup>, the acknowledgement message is transmitted on a transmit frequency that is paired with the reception frequency.

This section describes how to set up the scanning function.

\*1 : The selected reception frequency (scanning frequency) is switched at intervals of about 0.3 sec.

\*2 : See "● AUTO ACKNOWLEDGEMENT SETUP" in Section 3.5.4 (4), "Other Settings."

\*3 : Indicates that the "EOS" of the message compiled in steps (1) to (11) of Section 3.5.3, "Transmitting Messages" is set to ACK RQ (acknowledgement required).

#### ● Starting and stopping scanning

The scanning frequency must be specified before starting or stopping scanning. Refer to "Specifying the scanning frequency" below.

#### Procedure

**1. Press **FUNC** , and then **1** (SCAN).**

Scanning starts for the specified frequencies.

**2. Press **FUNC** , and then **1** (SCAN).**

Scanning stops.

#### ● Specifying the scanning frequency

#### Procedure

**1. Check that the "DSC watching" screen is displayed.**

```
DSC watching 06.Sep.2001(Thu) 01:26
99°99'N99°99'E SPEED:__.KT at 88:88
```

```
Self-ID = XXXXXXXXX [UTC]
```


#### Note

If the "DSC watching" screen is not displayed, press **STOP** 3 times in succession to switch to the "DSC watching" screen.

When the **P** mark is displayed on the screen, no printer is connected to the NCT-196.


## 2. Press **MENU**.

The "MENU#1-EDIT&CALL" screen is displayed.




## 3. Press **MENU** again.

The "MENU#2-READOUT&SETUP" screen is displayed.



## 4. Press **3**, and then press **ENT**.

The "SETUP" screen is displayed.



5. Press **8**, and then press **ENT** .  
The "SCANNING SETUP " screen is displayed.

SCANNING SETUP

|     |         |   |         |     |
|-----|---------|---|---------|-----|
| [1] | 1,610.0 | / | 1,615.0 | kHz |
| [2] | 2,000.0 | / | 2,000.0 | kHz |
| [3] | 3,000.0 | / | 3,000.0 | kHz |
| [4] | 4,208.0 | / | 4,219.0 | kHz |
| [5] | 5,000.0 | / | 5,000.0 | kHz |
| [6] | 6,000.0 | / | 6,000.0 | kHz |

TX                      RX

Use **▲** and **▼** to scroll the screen.

6. Enter the "Transmit frequency/Receive frequency" pair for each channel.

**Note** Press **CLR** and then **ENT** to cancel a setting and leave it blank.

7. On completion of entering the data, press **FUNC** , and then press **9** (SAVE).

Tune regist frequency?

[ENT] key : TUNE

[STOP] key : NO TUNE

Press **ENT** to tune the tuner and then return to the "SETUP" screen.


Press **STOP** to abort tuning and return to the "SETUP" screen.

**Note** Press **FUNC** , and then press **4** (QUIT) to cancel this menu.

## (2) Useful Functions

The NCT-196N register up to six party addresses with a shorthand name, and up to six calling frequencies. The registered contents are retrieved by using ◀ and ▶ when compiling a call message, obviating the need to enter numbers.

The addresses and calling frequencies are stored from the "SETUP" screen. See steps 1 to 3 of (1) Specifying the scanning frequency" for how to display the "SETUP" screen.




### ● Registering a calling frequency

#### Procedure

**1. From the "SETUP" screen, press [3], and then press [ENT].**

The "CALLING FREQUENCY REGISTRATION (TX/RX)" screen is displayed.




**2. Enter the "Transmit frequency/Receive frequency (name)" for each channel.**

- Enter the transmit frequency/receive frequency pair using [0] to [9] and [.] .
- Enter (name) as follows:
  1. Selecting characters: Use ◀ and ▶ to select characters inside the parentheses ( ).
  2. Confirming characters: After selecting each character, press [ENT] .

To go to the next channel or skip to the next channel without specifying a name, press [ENT] two times.

**3. On completion of entering the data, press [FUNC], and then press [9] (SAVE).**



Press [ENT] to tune the tuner and then return to the "SETUP" screen.

Press [STOP] to abort tuning and return to the "SETUP" screen.

**Note** Press [CLR] to delete registered calling frequency.

**Note** Press [FUNC], and then press [4] (QUIT) to cancel this menu.

## Procedure

### 1. From the "SETUP" screen, press **[4]**, and then press **[ENT]**.

The "ADDRESS REGISTRATION" screen is displayed.

ADDRESS REGISTRATION

|     |   |   |   |
|-----|---|---|---|
| [1] | — | ( | ) |
| [2] |   | ( | ) |
| [3] |   | ( | ) |
| [4] |   | ( | ) |
| [5] |   | ( | ) |
| [6] |   | ( | ) |

Use **[▲]** and **[▼]** to scroll the screen.

### 2. Enter the address (name) for each channel.

- Enter the address using **[0]** to **[9]** and **[.]**.
- Enter (name) as follows:
  1. Selecting characters: Use **[◀]** and **[▶]** to select characters inside the parentheses ( ).
  2. Confirming characters: After selecting each character, press **[ENT]**.

To go to the next channel or skip to the next channel without specifying a name, press **[ENT]** two times.

### 3. On completion of entering the data, press **[FUNC]**, and then press **[9]** (SAVE).

#### Note

Press **[CLR]** to delete registered address.

#### Note

Press **[FUNC]**, and then press **[4]** (QUIT) to cancel this menu.

### (3) Printing function

When a printer is connected, all received messages are printed out upon reception. In addition, it is also possible to print out other stored information.

The printing function enables the followings and the procedures are described in this section.

- The printing of all of the files, which classification is selected from the print menu.
- The printing of a selected file, which contents is displayed on screen.

#### ● Printing from the print menu (batch printing of multiple files)

##### Procedure

#### 1. Check that the "DSC watching" screen is displayed.

```
DSC watching 06.Sep.2001(Thu) 01:26
12°34'N123°45'E SPEED:12.4KT at 01:26

Self-ID = XXXXXXXXX [UTC]
```

#### Note

If the "DSC watching" screen is not displayed, press **STOP** 3 times in succession to switch to the "DSC watching" screen.

When the **P** mark is displayed on the screen, no printer is connected to the NCT-196.

#### 2. Press **FUNC**, and then **3** (PRINT).

The "PRINT MENU" screen is displayed.

```
PRINT MENU
▶ 1. ALL RECEIVED DISTRESS MESSAGES
  2. ALL RECEIVED OTHERS MESSAGES
  3. ALL EDIT/CALL MESSAGES
  4. ALL SETUP INFORMATION
```

Use **▲** and **▼** to scroll the screen.

#### 3. Select the item to be printed, and then press **ENT**.

Printing starts.

#### 4. When printing is finished, press **FUNC**, and then press **4** (QUIT).

Operation returns to the "DSC watching" screen.

#### ● Printing a specified file

##### Procedure

#### 1. Press **MENU** once or twice.

The "MENU#1-EDIT&CALL" screen or "MENU#2-READOUT&SETUP" screen is displayed.

#### 2. Enter the number of the file to be printed, and then press **ENT**.

The file content is displayed.

#### 3. Press **FUNC**, and then press **3** (PRINT).

The displayed file is printed.

#### 4. When printing is finished, press **FUNC**, and then press **4** (QUIT).

Operation returns to the "MENU#1-EDIT&CALL" screen or "MENU#2-READOUT&SETUP" screen.

#### (4) Other settings


The following procedures are explained in this section:

- How to compile the message transmitted when pressing **DISTRESS**.
- How to set the auto acknowledgement to ON/OFF for an acknowledgment required call
- Other settings.

### ATTENTION

Pay close attention when inputting and/or modifying the information described in this section as the contents are critical for operating the DSC. If these operations are unclear, contact JRC or our agents.

The data is input using the "SETUP" screen. See the above-mentioned "Specifying the scanning frequency" 1-3 steps of "(1) Frequency scanning" for how to display the "SETUP" screen. However regarding the "DATE&TIME EDIT" and "POSITION EDIT" settings in this setup menu, see Section 4.2 "Setting Position and Time Data".



Use  and  to scroll the screen.

## ● DISTRESS SETUP

This function is used to compile a distress call message to be transmitted by pressing **DISTRESS**.

|              |                       |   |                  |                                                         |
|--------------|-----------------------|---|------------------|---------------------------------------------------------|
| Nature       | : UNDESIGNATED DIS    | ← | 【FIXED】          | Nature of the distress (undesignated distress)          |
| Position     | : 12 ° 34'N123 ° 45'E | ← | 【AUTO or MANUAL】 | The navigation equipment data or manually entered data. |
| Time         | : 19:00               | ← | 【AUTO or MANUAL】 | The navigation equipment data or manually entered data. |
| Telecommand  | : J3E TEL             | ← | 【VARIABLE】       | The data set using this menu.                           |
| Tx frequency | : 2187.5kHz           | ← | 【VARIABLE】       | The data set using this menu.                           |


"Telecommand" shows the follow-on communication mode with the RCC that received the distress message. Normally, select either radiotelephone mode or MF/HF ARQ communication (F1B/J2B ARQ).

"Tx frequency" shows a transmission frequency for DSC distress message calls. When the radio equipment is set to 2187.5 or 8414.5kHz, those frequencies take priority.

### Procedure

#### 1. From the "SETUP" screen, press **5** and then press **ENT**.

The "DISTRESS SETUP" screen is displayed.



#### 2. Enter each item.

- Use **◀** and **▶** to change a setting and **▲** and **▼** to move the cursor and select the item.
- Press **ENT** to confirm a setting.
- See Section 4.3.3 (3), "Distress Call" for items for which "Telecommand" can be selected.

#### 3. On completion of entering the data, press **FUNC**, and then press **9** (SAVE).

Operation returns to the "SETUP" screen.

### Note

Press **FUNC**, and then press **4** (QUIT) to cancel this menu.

## ● OTHERS ALARM SETTING


---

This alarm can be set ON/OFF when receiving non-distress/non-urgency calls. Distress calls can be distinguished from other calls by the difference in the beeping sounds. When receiving distress calls, the alarm always sounds; the alarm for distress calls cannot be turned OFF.

### Procedure

**1. From the "SETUP" screen, press [6] and then press [ENT].**

The "OTHERS ALARM SETTING" screen is displayed.



**2. Select "ON" or "OFF".**

- The default setting is "ON". Use [◀] and [▶] to change the setting.
- Press [ENT] to confirm the setting.

**3. On completion of entering the data, press [FUNC] , and then press [9] (SAVE).**

Operation returns to the "SETUP" screen.

### Note

Press [FUNC] , and then press [4] (QUIT) to cancel this menu.

## ● AUTOMATIC ACKNOWLEDGEMENT SETUP


---

The DSC terminal can be set to automatically send back an acknowledgement call (with ACK BQ for EOS) when receiving a DSC call with ACK RQ for EOS. However, when the CATEGORY is DISTRESS, URGENCY, or SAFETY, no acknowledgement is made automatically, even though ACK RQ is specified for EOS. Acknowledgement is made manually for all distress calls.

### Procedure

1. From the "SETUP" screen, press **[7]** and then press **[ENT]**.

The "AUTOMATIC ACKNOWLEDGEMENT SETUP" screen is displayed.



2. Select "ON" or "OFF".

- The default setting is "ON". Use **[◀]** and **[▶]** to change the setting.
- Press **[ENT]** to confirm the setting.

3. On completion of entering the data, press **[FUNC]**, and then press **[9]** (SAVE).

Operation returns to the "SETUP" screen.

### Note

Press **[FUNC]**, and then press **[4]** (QUIT) to cancel this menu.


## ● WATCHKEEPING RECEIVER SETUP

This procedure sets the Watch-keeping receiver's scanning frequency. The 2187.5kHz and 8414.5kHz frequencies are preselected; here, frequencies are selected for the other four channels. The "DISTRESS FREQUENCY" lamps (on the front panel) are turned ON/OFF for each set channel. The lamps for 2187.5kHz and 8414.5kHz are always ON.

### Procedure

**1. From the "SETUP" screen, press **[9]** and then press **[ENT]**.**

The "WATCHKEEPING RECEIVER SETUP" screen is displayed.



**2. Select "ON" or "OFF".**

- The default setting is "ON". Use **[◀]** and **[▶]** to change the setting.
- Press **[ENT]** to confirm the setting.

The corresponding lamp for that frequency is turned ON or OFF according to the setting.

**3. On completion of entering the data, press **[FUNC]**, and then press **[9]** (SAVE).**

Operation returns to the "SETUP" screen.

### Note

Press **[FUNC]**, and then press **[4]** (QUIT) to cancel this menu.

## ● CLICK SOUND SETTING

The click sound set to ON/OFF during turning on the NCT-196N.

### Procedure

1. Press **FUNC** and **0** .

### Note

When turning OFF the power switch, click sound is reset to ON.

## ● MODEM RESET

This operation is the same as the Power ON reset.

### Procedure

1. Press **FUNC** and **STOP** .  
The following display appears.

```
JRC NCT-196N DSC/NBDP MODEM
Software Version  MAIN:X.XX  SUB:X.XX
Navigation :NMEA0183
Transceiver:JSB-196/196GM
```

2. The initialization is completed in several seconds.

The following initial display appears.

```
DSC watching  06.Sep.2001(Thu) 01:26
12°34'N123°45'E SPEED:12.4KT at 01:26

Self-ID =  XXXXXXXXXX                [UTC]
```

## 3.6 NBDP operations

The NCT-196N DSC/NBDP MODEM has several communication methods in telex (TLX) mode as NBDP function. Previously created message files or keyboard-typed messages can be sent during the communication. All of operations are performed using NDZ-127J DTE, and the communication methods and other settings for TLX mode are described in this chapter. (Regarding the MODE selection for TLX, see “4.3.2 MODE change to TLX”.)

### 3.6.1 NBDP Settings

Before operations in TLX mode, setup the NBDP functions using **SYSTEM** → **NBDP setup** menu of the NDZ-127J DTE. The following screen appeared by selecting the menu item.

| NBDP setup                    |                 |
|-------------------------------|-----------------|
| ARQ/FEC 4- or 5-digit Self-ID | : 54321         |
| GFEC 4- or 5-digit Self-ID    | : 11111         |
| ARQ/FEC 9-digit Self-ID       | : 987654321     |
| GFEC 9-digit Self-ID          | : 22222222      |
| Answerback                    | : 54321 FFFFF X |
| <b>Max. FEC error rate.</b>   | <b>: 30%</b>    |
| Max. automatic call series    | : 1             |
| Collective FEC receiving      | : ON            |
| Internal alarm                | : ON            |
| Time duration for AUTO/MRTX   | : 10 min.       |
| Restart                       | : ON            |
| Finite start/restart          | : ON            |
| ↓                             |                 |
| [ Save ] [ Cancel ]           |                 |

Each parameter is set as follows:

|                               |                                                                 |
|-------------------------------|-----------------------------------------------------------------|
| ARQ/FEC 4- or 5-digit Self-ID | : Fixed                                                         |
| GFEC 4- or 5-digit Self-ID    | : Fixed                                                         |
| ARQ/FEC 9-digit Self-ID       | : Fixed                                                         |
| GFEC 9-digit Self-ID          | : Fixed                                                         |
| Answerback                    | : Fixed                                                         |
| Max. FEC error rate           | : Press Enter key and setup in the input window.                |
| Max. automatic call series    | : Press Enter key and set a value of 1-99 in the input display. |
| Collective FEC receiving      | : Press Enter key to change ON/OFF.                             |
| Internal alarm                | : Press Enter key to change ON/OFF.                             |
| Time duration for AUTO        | : Press Enter key and setup the time in the input window.       |
| Restart                       | : Press Enter key to change ON/OFF.                             |
| Finite start/restart          | : Press Enter key to change ON/OFF.                             |
| Transmitter pre-key time      | : Press Enter key and setup the time in the input window.       |

After these settings, select the [Save] button or [Cancel] button to finish this setup.

#### Note

The above parameters showed “Fixed” have already been set and are impossible to be changed.

The meanings of the above items are as follows;

- Max. FEC error rate :The limit value of error rate to continue to receive CFEC/SFEC. When the error rate is beyond the value due to the noisy radio circuit condition or any other signals, the MODEM stops the receiving and return to stand-by.
- Max. automatic call series : The limit value of retrying the CALL mode sequence. The interval to retry is 15 minutes respectively.

- Collective FEC receiving :      ON -      CFEC receiving is permitted.  
                                                  OFF -      CFEC receiving is prohibited.
  
- Internal alarm :                      ON -      Internal alarm works.  
                                                  OFF -      Internal alarm does not work.
  
- Time duration for AUTO :          Time duration setting for AUTO mode
  
- Restart :                              ON -      The MODEM tries to reconnect when the circuit  
                                                                                                  established once is lost for 32 times of  
                                                                                                  successive REPEAT condition  
                                                  OFF -      The MODEM returns to stand-by when the  
                                                                                                  circuit established once is lost for 32 times of  
                                                                                                  successive REPEAT condition
  
- Finite start/restart :              ON -      The MODEM returns to stand-by when the  
                                                                                                  times of calling a partner station are reached to  
                                                                                                  128 in ARQ mode.  
                                                  OFF -      The MODEM continues to call a partner station  
                                                                                                  even if the times of calling are reached to 128  
                                                                                                  in ARQ mode.
  
- Transmitter pre-key time :          Adjustment of timing from KEY ON to signal output for the  
                                                                                                  transmitter electrical specification. It is also available to  
                                                                                                  arrange the Send/Receive timing between long-ranged  
                                                                                                  partner station.

### 3.6.2 ARQ Communication

ARQ mode is two way telex communication with a partner as a destination station. When beginning to call a partner using ARQ mode, it is necessary to select a partner (ID) and a communication channel. The operation from the beginning until the end of the communication with a partner are described in this section.

## ATTENTION

- Before transmitting, confirm that the selected channel / frequency is not occupied by other station(s).
- Do not operate JSB-196 during ARQ communication.

## Procedure

1. Select **Connect** → **ARQ** and press Enter key.

[TLX] Tx=12345.6 kHz / Rx=12345.6 kHz (ITU CH= 0) 17-JUL-1997 12:00(LT)  
Loc:N21.00 W156.30 at 19:20(UTC)  
File Tune **Connect** Service System Help

[ STATUS INFO ]

Scanning CALL Tuner/Tx.POWER  
[No scanning] AUTO TELEX TUNER : [READY]  
Last station FEC Tx.POWER: [FULL]

Move the cursor to the item you want with ↑,↓,←,→ then press Enter  
Connect by ARQ...

2. Select a partner station from the following window and press Enter key.

[TLX] Tx=12345.6 kHz / Rx=12345.6 kHz (ITU CH= 0) 17-JUL-1997 12:00(LT)  
Loc:N21.00 W156.30 at 19:20(UTC)  
File Tune **Connect** Service System Help

[ STATUS INFO ]

ST-BY Tuner/Tx.POWER

Scanning info [ARQ]→ Station selection...

| No. | Station Name | Stat.ID   | Location      | F.Sign |            |
|-----|--------------|-----------|---------------|--------|------------|
| 1   | JRCMI TAKA   | 123456789 | N12.34E123.46 | DOTDOT | [ Select ] |
| 2   | JRCSA I TAMA | 223456789 | N44.00E134.00 | K/00V/ | [ Manual ] |
| 3   |              |           |               |        | [ Cancel ] |
| 4   |              |           |               |        |            |
| 5   |              |           |               |        |            |
| 6   |              |           |               |        |            |
| 7   |              |           |               |        |            |
| 8   |              |           |               |        |            |
| 9   |              |           |               |        |            |
| 10  |              |           |               |        |            |

Tab Next field | Shift Tab Previous field | Esc Cancel  
List Box | Move cursor to the preferred item and press Enter

## Note

If [ Manual ] button is selected using Tab and Enter keys, the partner ID and Frequency/Channel can be set manually.

### 3. Select Tx/Rx frequency from the following window and press Enter key.

[TLX] Tx=12345.6 kHz / Rx=12345.6 kHz (ITU CH= 0) 17-JUL-1997 12:00 (LT)  
 Loc:N21.00 W156.30 at 19:20 (UTC)  
 File Mode Tune **Connect** Service System Help

[ STATUS INFO ]

ST-BY

Frequencies list for Group No.1

St.: [JRCMITAKA] ID: [123456789] Loc: [N12.34E123.46]

| Tx.F.   | Rx.F.   | CH. | Tx.F. | Rx.F. | CH.            |
|---------|---------|-----|-------|-------|----------------|
| 22112.2 | 22112.2 | 001 | -     | -     | 011            |
| -       | -       | 002 | -     | -     | 012            |
| -       | -       | 003 | -     | -     | 013 [ Set ]    |
| -       | -       | 004 | -     | -     | 014            |
| -       | -       | 005 | -     | -     | 015 [ Print ]  |
| -       | -       | 006 | -     | -     | 016            |
| -       | -       | 007 | -     | -     | 017 [ Cancel ] |
| -       | -       | 008 | -     | -     | 018            |
| -       | -       | 009 | -     | -     | 019            |
| -       | -       | 010 | -     | -     | 020            |

MUF: 24MHz, Range: 5291 Miles, Bearing: 279 deg, Sunspot: 100

Tab Next field | Shift Tab Previous field | Esc Cancel  
 List Box | Move cursor to the preferred item and press Enter

### 4. After the following window opened, check the channel condition and if not occupied, press Enter key.

[TLX] Tx=22112.2 kHz / Rx=22112.2 kHz (ITU CH= 0) 17-JUL-1997 12:00 (LT)  
 Loc:N21.00 W156.30 at 19:20 (UTC)  
 File Tune **Connect** Service System Help

[ STATUS INFO ]

ST-BY

Frequencies list for Group No.1

Station: [JRCMITAKA] ID: [123456789] Loc: [N12.34E123.46]

| Tx.F.   | Rx      | Confirmation                 |
|---------|---------|------------------------------|
| 22112.2 | 22112.2 | 1 Is the frequency free now? |
| -       | -       | 2                            |
| -       | -       | 3 [ Set ]                    |
| -       | -       | 4                            |
| -       | -       | 5 [ Print ]                  |
| -       | -       | 6 [ Cancel ]                 |
| -       | -       | 7                            |
| -       | -       | 008                          |
| -       | -       | 009                          |
| -       | -       | 010                          |

MUF: 24MHz, Range: 5291 Miles, Bearing: 279 deg, Sunspot: 100

Tab Next field | Shift Tab Previous field | Esc Cancel  
 Command Button | Press Space to carry out the related action

#### Note

If the channel is occupied by the other stations, select [ NO ] and return to step 3 to select another channel.

### 5. The channel is tuned automatically and the NCT-196N begins to call a partner station.

The following screen is displayed while calling.

[TLX] Tx=22112.2 kHz / Rx=22112.2 kHz (ITU CH= 0) 17-JUL-1997 12:00 (LT)  
 Loc:N21.00 W156.30 at 19:20 (UTC)  
 ARO mode...

[ STATUS INFO ]

ARO Calling Phasing Repeat

Scanning info: [No scanning] Tuner/Tx. POWER: TUNER : [READY] Tx. POWER: [FULL]

Last status messages

ARO: 17/07/1997, 12:00.  
 Station: [JRCMITAKA] ID: [123456789] Loc: [N12.34W123.46]

\*Waiting for transmitter ready

\*Received TX-READY signal

F10 Stop

- 6. When the connection is established, the following screen appears and the DTE is ready to communicate with a partner station.**  
Send message to the partner station using the keyboard.

```

[TLX] Tx=22112.2 kHz / Rx=22112.2 kHz (ITU CH= 0) 17-JUL-1997 12:00(LT)
Loc:N21.00 W156.30 at 19:20(UTC)
ARQ mode...
[TELEX Terminal Window]
[ARQ] [Calling] [Send]
ARQ connected...
F2 WRU|F3 Hereis|F4 TMS|F5 Over|F6 POLL|F8 F.Send|F10 Stop

```

In case of sending the previously created message file, press **F8** (F.Send) and select the file to be sent on the following window.

```

[TLX] Tx=22112.2 kHz / Rx=22112.2 kHz (ITU CH= 0) 17-JUL-1997 12:00(LT)
Loc:N21.00 W156.30 at 19:20(UTC)
[TELEX Terminal Window]
<File selection>
File name : [C: TEXT]
ARQ connected.
File name      *.TLX
File name      Date      Time      Size
..             01-01-97    00:01    <<DIR>>
JRC1.tlx       16-01-97    11:35      5
Sort by:
( ) Name
( ) Time
( ) Size
( ) Ext
[ F3:View ]
[ F8:Re-read ]
[ OK ]
[ Cancel ]
Drive: [C:] ↓ Total:1014KB, free:1004KB
Tab Next field | Shift Tab Previous field | Esc Cancel
Text Box | Type information. Keys BackSpace and Delete can be used

```

- 7. To terminate communication, press **F10** .**  
The following display appears and the DTE returns to the stand-by.

```

[TLX] Tx=22112.2 kHz / Rx=22112.2 kHz (ITU CH= 0) 17-JUL-1997 12:00(LT)
Loc:N21.00 W156.30 at 19:20(UTC)
File Tune Connect TLX [STATUS INFO] Service System Help
[ST-BY]
Scanning info Tuner/Tx.POWER
[No scanning] TUNER :[READY]
Tx.POWER:[FULL]
Last status messages
ARQ: 17/07/1997, 12:00.
Station:[JRCMITAKA] ID:[123456789] Loc:[N12.34W123.46]
*Waiting for transmitter ready
*Received TX-READY signal
Saved communication logfile: '125_2001.TLX'
Move the cursor to the item you want with ↑,↓,←,→ then press Enter
Message editor |File manager

```

**Note**

- The meanings of cells showed in [ STATUS INFO ] are as follows;

(no use) (\*1) (\*2) (\*3) (\*4) (\*5) (\*6)

- \*1 : Communication mode (**stand-by**, **ARQ**, **CFEC**, **SFEC**)
- \*2 : The position related with a partner station (**Calling** - master, **Called** - slave)
- \*3 : The right to send message (**Send** - enable to send message, **Receive** - wait)
- \*4 : MODEM condition on connecting with a partner station (**Phasing**, **Rephasing**)
- \*5 : Communication data error condition (**Repeat** - resending data)
- \*6 : Communication condition (**TRAF** - sending data completed, **RQ** - repeating)

- The function key **F 2** ~ **F10** assignments are as follows;

- |     |   |           |                                                                                                                     |
|-----|---|-----------|---------------------------------------------------------------------------------------------------------------------|
| F 2 | : | WRU -     | Request to send Answerback code of a partner station                                                                |
| F 3 | : | Here is - | Sending Answerback code of own station                                                                              |
| F 4 | : | TMS -     | Sending the time of own position                                                                                    |
| F 5 | : | Over -    | Exchanging the right to send message                                                                                |
| F 6 | : | POLL -    | Getting the right to send messages without terminating the communication even if a partner station try to terminate |
| F 8 | : | F.Send -  | Sending the previously created file                                                                                 |
| F10 | : | Stop -    | Terminating communication                                                                                           |

### 3.6.3 FEC Communication

There are two types of FEC modes such as SFEC (Selective FEC) in which a destination is specified and CFEC (Collective FEC) in which the destination is not specified. The ways to communicate using FEC modes are described below. Note that the FEC receiving is automatic so the operation method is left out in this section, and furthermore CFEC receiving can be disabled using NBDP setup. (See “6.1 NBDP settings.”)

#### 3.6.3.1 SFEC Communication

## ATTENTION

- Before transmitting, confirm that the selected channel / frequency is not occupied by other station(s).

### Procedure

1. Select **Connect** → **FEC** → **SFEC** and press Enter key.

[TLX] Tx=12345.6 kHz / Rx=12345.6 kHz (ITU CH= 0) 17-JUL-1997 12:00(LT)  
Loc:N21.00 W156.30 at 19:20(UTC)  
File Tune **Connect** Service System Help

[ STATUS INFO ]

Scanning [No scanning] ARQ  
CALL  
AUTO TELEX  
Last sta: FEC

Tuner/Tx.POWER  
TUNER : [READY]  
Tx.POWER: [FULL]

Move the cursor to the item you want with ↑,↓,←,→ then press Enter  
Connect by ARQ...

2. Select a partner station from the following window and press Enter key.

[TLX] Tx=12345.6 kHz / Rx=12345.6 kHz (ITU CH= 0) 17-JUL-1997 12:00(LT)  
Loc:N21.00 W156.30 at 19:20(UTC)  
File Tune **Connect** Service System Help

[ STATUS INFO ]

ST-BY

Scanning info [SFEC]→ Station selection...

| No. | Station Name | Stat.ID   | Location      | F.Sign |            |
|-----|--------------|-----------|---------------|--------|------------|
| 1   | JRCM ITAKA   | 123456789 | N12.34E123.46 | DOTDOT | [ Select ] |
| 2   | JRCSA ITAMA  | 223456789 | N44.00E134.00 | K/OOV/ | [ Manual ] |
| 3   |              |           |               |        | [ Cancel ] |
| 4   |              |           |               |        |            |
| 5   |              |           |               |        |            |
| 6   |              |           |               |        |            |
| 7   |              |           |               |        |            |
| 8   |              |           |               |        |            |
| 9   |              |           |               |        |            |
| 10  |              |           |               |        |            |

Tab Next field | Shift Tab Previous field | Esc Cancel  
List Box | Move cursor to the preferred item and press Enter

### Note

If [ Manual ] button is selected using Tab and Enter keys, the partner ID and Frequency/Channel can be set manually.

### 3. Select Tx/Rx frequency from the following window and press Enter key.

[TLX] Tx=12345.6 kHz / Rx=12345.6 kHz (ITU CH= 0) 17-JUL-1997 12:00 (LT)  
 Loc:N21.00 W156.30 at 19:20 (UTC)  
 File Mode Tune **Connect** Service System Help

[ STATUS INFO ]

ST-BY

Frequencies list for Group No.1

St.: [JRCMITAKA] ID: [123456789] Loc: [N12.34E123.46]

| Tx.F.   | Rx.F.   | CH. | Tx.F. | Rx.F. | CH.            |
|---------|---------|-----|-------|-------|----------------|
| 22112.2 | 22112.2 | 001 | -     | -     | 011            |
| -       | -       | 002 | -     | -     | 012            |
| -       | -       | 003 | -     | -     | 013 [ Set ]    |
| -       | -       | 004 | -     | -     | 014            |
| -       | -       | 005 | -     | -     | 015 [ Print ]  |
| -       | -       | 006 | -     | -     | 016            |
| -       | -       | 007 | -     | -     | 017 [ Cancel ] |
| -       | -       | 008 | -     | -     | 018            |
| -       | -       | 009 | -     | -     | 019            |
| -       | -       | 010 | -     | -     | 020            |

MUF: 24MHz, Range: 5291 Miles, Bearing: 279 deg, Sunspot: 100

Tab Next field | Shift Tab Previous field | Esc Cancel  
 List Box | Move cursor to the preferred item and press Enter

### 4. After the following window opened, check the channel condition and if not occupied, press Enter key.

[TLX] Tx=22112.2 kHz / Rx=22112.2 kHz (ITU CH= 0) 17-JUL-1997 12:00 (LT)  
 Loc:N21.00 W156.30 at 19:20 (UTC)  
 File Tune **Connect** Service System Help

[ STATUS INFO ]

ST-BY

Frequencies list for Group No.1

Station: [JRCMITAKA] ID: [123456789] Loc: [N12.34E123.46]

| Tx.F.   | Rx    | CH. | Tx.F. | Rx | CH.            |
|---------|-------|-----|-------|----|----------------|
| 22112.2 | 22112 | 001 | -     | -  | 011            |
| -       | -     | 002 | -     | -  | 012            |
| -       | -     | 003 | -     | -  | 013 [ Set ]    |
| -       | -     | 004 | -     | -  | 014            |
| -       | -     | 005 | -     | -  | 015 [ Print ]  |
| -       | -     | 006 | -     | -  | 016            |
| -       | -     | 007 | -     | -  | 017 [ Cancel ] |
| -       | -     | 008 | -     | -  | 018            |
| -       | -     | 009 | -     | -  | 019            |
| -       | -     | 010 | -     | -  | 020            |

MUF: 24MHz, Range: 5291 Miles, Bearing: 279 deg, Sunspot: 100

Tab Next field | Shift Tab Previous field | Esc Cancel  
 Command Button | Press Space to carry out the related action

#### Note

If the channel is occupied by the other stations, select [ NO ] and return to step 3 to select another channel.

### 5. The channel is tuned automatically and the NCT-196N begins to call a partner station.

- The communication is started after displayed "Message start..." on screen.
- To terminate communication, press **F10** .

## ATTENTION

- Before transmitting, confirm that the selected channel / frequency is not occupied by other station(s).

### Procedure

1. Select **Connect** → **FEC** → **CFEC** and press Enter key.

[TLX] Tx=12345.6 kHz / Rx=12345.6 kHz (ITU CH= 0) 17-JUL-1997 12:00(LT)  
 Loc:N21.00 W156.30 at 19:20(UTC)  
 File Tune **Connect** [ STATUS INFO ] Service System Help

|                           |                           |                                     |
|---------------------------|---------------------------|-------------------------------------|
| Scanning<br>[No scanning] | ARO<br>CALL<br>AUTO TELEX | Tuner/Tx.POWER                      |
| Last sta                  | FEC                       | TUNER : [READY]<br>Tx.POWER: [FULL] |

Move the cursor to the item you want with ↑,↓,→,← then press Enter  
 Connect by ARO...

2. Input Tx/Rx frequency on the following window. Then select [ Set ] using Tab key and press Enter key.

[TLX] Tx=12345.6 kHz / Rx=12345.6 kHz (ITU CH= 0) 17-JUL-1997 12:00(LT)  
 Loc:N21.00 W156.30 at 19:20(UTC)  
 File Tune **Connect** [ STATUS INFO ] Service System Help

|                                |                        |                         |
|--------------------------------|------------------------|-------------------------|
| Scanning info<br>[No scanning] | ST ARO<br>CALL<br>AUTO | Tuner/Tx.POWER          |
| Last status m                  | TX/RX frequency        | TUNER : [READY]<br>FULL |

Tx frequency. kHz: [ 0.0 ]

Rx frequency. kHz: [ 0.0 ]

[ ITU CHANNEL ] [ Set ] [ Cancel ]

Tab Next field | Shift Tab Previous field | Esc Cancel  
 Text Box | Type information. Keys BackSpace and Delete can be used

### Note

If input using ITU channel, select [ ITU CHANNEL ] button using Tab and Enter keys.

3. After the following window opened, check the channel condition and if not occupied, press Enter key.

|                                                                                                                                                                                                  |      |                                                                                                                                                                                                                                        |                     |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------|
| [TLX] Tx= 4100.0 kHz / Rx= 4105.0 kHz (ITU CH= 0)                                                                                                                                                |      | 17-JUL-1997 12:00 (LT)                                                                                                                                                                                                                 |                     |
|                                                                                                                                                                                                  |      | Loc:N21.00 W156.30 at 19:20 (UTC)                                                                                                                                                                                                      |                     |
| File                                                                                                                                                                                             | Tune | Connect                                                                                                                                                                                                                                | Service System Help |
| <div> <div>ST</div> <div>Scanning info</div> <div>[No scanning]</div> </div> <div> <div>ARO</div> <div>CALL</div> <div>AUTO</div> </div> <div> <div>FEC</div> <div>Last status m</div> </div>    |      | <div> <div>[ STATUS INFO ]</div> <div>Tuner/Tx.POWER</div> <div>TUNER : [READY]</div> <div>Tx.POWER: [FULL]</div> </div> <div>Confirmation</div> <div>Is the frequency free now?</div> <div> <div>►YES◄</div> <div>[ NO ]</div> </div> |                     |
| <div> <div>Tab Next field</div> <div>Shift Tab Previous field</div> <div>  Esc Cancel</div> </div> <div> <div>Command Button</div> <div>Press Space to carry out the related action</div> </div> |      |                                                                                                                                                                                                                                        |                     |

### Note

If the frequency is occupied by the other stations, select [ NO ] and return to step 2 to select another frequency.

4. The frequency is tuned automatically and the NCT-196N begins to call all ships.

- The communication is started after displayed "Message start..." on screen.
- To terminate communication, press **F10** .

### 3.6.4 Scanning for TLX mode

The NBDP function of the NCT-196N can be set to scan a specified group channels so that the NCT-196N respond to the station automatically if there is a station calling own station by ARQ or transmitting by FEC. The way to start/stop the scanning is described in this section.

#### 3.6.4.1 Scanning start

##### Procedure

1. Select **Tune** → **Scanning start** and press Enter key.

[TLX] Tx=12345.6kHz / Rx=12345.6kHz (ITU CH= 0) 10-APR-2002 12:00(LT)  
Loc: N19.00 E115.30 at 11:00(UTC)  
File **Tune** Connect Service System Help

Frequency List  
ITU Channel set  
Tx/Rx frequency set  
Tx. Tune  
**Scanning start**

TUNER : [READY]  
Tx. POWER: [FULL]

Move the cursor to the item you want with ↑, ↓, →, ← then press Enter

2. Select the desired station on the following window and press Enter key.

Scanning is started in order by the channel number.

[TLX] Tx=12345.6kHz / Rx=12345.6kHz (ITU CH= 0) 10-APR-2002 12:00(LT)  
Loc: N19.00 E115.30 at 11:00(UTC)  
File **Tune** Connect [ STATUS INFO ] Service System Help

ST-BY

Scanning info

Station List for [TLX] mode

| No. | Station Name | Stat.ID   | Location      | F.Sign |            |
|-----|--------------|-----------|---------------|--------|------------|
| 1   | JRCMITAKA    | 123456789 | N12.34E123.46 | DOTDOT | [ Scan ]   |
| 2   | JRCSAITAMA   | 223456789 | N44.00E134.00 | K/QQV/ | [ Cancel ] |
| 3   |              |           |               |        |            |
| 4   |              |           |               |        |            |
| 5   |              |           |               |        |            |
| 6   |              |           |               |        |            |
| 7   |              |           |               |        |            |
| 8   |              |           |               |        |            |
| 9   |              |           |               |        |            |
| 10  |              |           |               |        |            |

Move the cursor to the item you want with ↑, ↓, →, ← then press Enter

##### Note

To adjust the intervals for scanning, Select **System** → **Scan speed** and set scan speed.

### 3.6.4.2 Scanning stop

#### Procedure

1. Select **Tune** → **Scanning stop** and press Enter key.

|                                                 |                     |                       |  |
|-------------------------------------------------|---------------------|-----------------------|--|
| [TLX] Tx=12345.6kHz / Rx=12345.6kHz (ITU CH= 0) |                     | 10-APR-2002 12:00(LT) |  |
| Loc: N19.00 E115.30 at 11:00(UTC)               |                     | Service System Help   |  |
| File                                            | <b>Tune</b>         | Connect               |  |
| Frequency List                                  |                     | TUNER INFO ]          |  |
| Scanning                                        | ITU Channel set     | Tuner/Tx.POWER        |  |
| [No scan                                        | Tx/Rx frequency set | TUNER :[READY]        |  |
| Last sta                                        | Tx. Tune            | Tx.POWER:[FULL]       |  |
| <b>Scanning stop</b>                            |                     |                       |  |

Move the cursor to the item you want with ↑,↓,→,← then press Enter

2. Scanning is stopped and the NCT-196N returns to stand-by condition.  
The Tx/Rx frequency is set to the frequency scanned last.

## 3.7 PA operations

The NAH-692 Power Amplifier connected to JSB-196GM can be used basically without any settings after installation. However for checking such as output power, voltages or currents or for setting such as alarm or charge mode, the NAH-692 Power Amplifier has functions as described below.

### 3.7.1 AC/DC power source voltage checking

#### Procedure

1. Press **Menu** button and turn the dial to “AC/DC VOLTAGE” menu on the LCD.

|               |
|---------------|
| AC,DC VOLTAGE |
|---------------|

2. Press **ENT** button.

The menu is selected and LCD shows the AC/DC voltages.

|         |       |
|---------|-------|
| AC Volt | 221V  |
| DC Volt | 24.2V |

3. After completed, press **Menu** button again to return to menu selection.

### 3.7.2 DC (Battery) charge/discharge current checking

#### Procedure

1. Press **Menu** button and turn the dial to “DC CURRENT” menu on the LCD.

|            |
|------------|
| DC CURRENT |
|------------|

2. Press **ENT** button.

The menu is selected and LCD shows the value of DC (Battery) charge/ discharge current.

|                      |       |
|----------------------|-------|
| DC CURR              | +2.5A |
| (- : DISCHG,+ : CHG) |       |

3. After completed, press **Menu** button again to return to menu selection.

### 3.7.3 RF current of Antenna and PA checking


#### Procedure

1. Press **Menu** button and turn the dial to “ANT, PA CURR” menu on the LCD.



2. Press **ENT** button.

The menu is selected and LCD shows the value of Antenna and PA current.



3. After completed, press **Menu** button again to return to menu selection.

### 3.7.4 PA voltage (Vc) and current (Ic) checking


#### Procedure

1. Press **Menu** button and turn the dial to “ PA(A) Vc, Ic ” menu on the LCD.



2. Press **ENT** button.

The menu is selected and LCD shows the Vc and Ic values of PA(A) .



3. After completed, press **Menu** button again to return to menu selection.

Note) When checking the Vc and Ic for PA(B) or PA(C), substitute the above “PA(A)” for “PA(B)” or “PA(C)”. Furthermore, the components of PA(A/B/C) differs by the type of NAH-692/ 695/ 698 respectively such as the following table.

|                | PA (A) | PA (B) | PA (C) |
|----------------|--------|--------|--------|
| NAH-692 (250W) | ✓      |        |        |
| NAH-695 (500W) | ✓      | ✓      |        |
| NAH-698 (800W) | ✓      | ✓      | ✓      |

### 3.7.5 SWR of PA output checking


#### Procedure

1. Press **Menu** button and turn the dial to “PA SWR” menu on the LCD.



2. Press **ENT** button.

The menu is selected and LCD shows the SWR value of PA output.



3. After completed, press **Menu** button again to return to menu selection.


Note) When checking the SWR for PA(B) or PA(C), substitute the above “PA(A)” for “PA(B)” or “PA(C)”. Furthermore, the components of PA(A/B/C) differs by the type of NAH-692/ 695/ 698 respectively such as the following table.

|                | PA (A) | PA (B) | PA (C) |
|----------------|--------|--------|--------|
| NAH-692 (250W) | ✓      |        |        |
| NAH-695 (500W) | ✓      | ✓      |        |
| NAH-698 (800W) | ✓      | ✓      | ✓      |

### 3.7.6 Beeping sound ON/OFF setting

#### Procedure

1. Press **Menu** button and turn the dial to “TOUCH TONE” menu on the LCD.



2. Press **ENT** button.

The menu is selected and LCD shows setting of TOUCH TONE.



3. Turn the dial to select ON or OFF.



4. Press **ENT** button to set it and return to menu selection.

### 3.7.7 Alarm sound ON/OFF setting

#### Procedure

1. Press **Menu** button and turn the dial to “ALARM TONE” menu on the LCD.



2. Press **ENT** button.

The menu is selected and LCD shows setting of ALARM TONE.



3. Turn the dial to select ON or OFF.



4. Press **ENT** button to set it and return to menu selection.

### 3.7.8 Battery charge mode (Ordinary/Equal) setting

#### Procedure

1. Press **Menu** button and turn the dial to “CHARGE METHOD” menu on the LCD.



2. Press **ENT** button.

The menu is selected and LCD shows setting of CHARGE METHOD.



3. Turn the dial to select **ORDINARY** or **EQUAL**.



**ORDINARY:** Automatic charge mode where the battery is kept fully-charged. This mode is normally used.

**EQUAL:** Equaizing charge mode.  
After setting it as EQUAL mode, when charge current decreased, or when charge time has passed for 2 hours, it changes to ORDINARY mode automatically.

4. Press **ENT** button to set it and return to menu selection.

#### Note

When charge mode changes the EQUAL to the ORDINARY, JSB-196GM may turn off. In this case turn on the JSB-196GM.

### 3.7.9 DC operation

Attention for DC operation

#### 1. Single Setting

Either JSB or SES is usable in this setting.

- Turn on JSB-196GM : SES is turned off automatically.  
(JSB-196GM shows “SES OFF” on LCD.)
- Turn off JSB-196GM : SES is turned on automatically after 30-60sec.

#### 2. Dual Setting

Both JSB and SES are simultaneously usable in the setting.

#### Note

Refer to “Installation manual” about Single/Dual setting.

## 3.8 Printer operations

The contents of the communication files and messages can be printed out if connected the NKG-800 Printer to the NCT-196N DSC/NBDP MODEM and the NDZ-127J DTE via NCF-1960 PRN SELECTOR. This chapter describes the printer operation, paper roll loading, ribbon cassette cartridge replacement and how to set the DIP switch.



### CAUTION

#### Notes on using the printer



Be sure to turn OFF the printer's power when opening and closing the printer cover. Failure to comply could result in electrical shock, failure, or injury.



Do not drop or strike the printer.  
Doing so may cause failure or malfunction.



Just after printing, the temperature of the printing head is high.  
Do not touch the printing head until the temperature goes down.  
Doing so may cause a burn or an injury.



Never try to disassemble or repair the printer yourself.  
Doing so may cause failure or malfunction.



Do not touch any part of the cutter.  
Doing so is potentially dangerous.



When attaching the ribbon, be sure it does not get twisted.  
Doing so may cause failure or malfunction.



Wait at least two seconds to restart the system after turning the power switch OFF.  
Otherwise the initialization may not proceed correctly or a malfunction may occur.



Do not attempt to print without the ribbon cassette cartridge or paper.  
Doing so may cause failure or malfunction.



When the printer is working, be sure not to allow your hands, any articles of clothing or accessories (a necktie or jewelry for instance) too close to the unit.  
Doing so may cause injury.




Do not place anything such as liquids or metals on top of the printer.  
They may drop into the printer, causing fire or malfunction.



Do not install the printer in the following locations.  
Doing so may cause a fire, malfunction or degradation of printing quality.


- On a surface that is not horizontal, or where the vibration is severe.
- In a location subject to direct sunlight or excessive dust.
- In a location subject to extremely high or low temperatures.
- In a location subject to excessive humidity.

### 3.8.1 Names and Functions



### 3.8.2 Operating Panel

From the operating panel, switching on-line/off-line, selecting of high quality characters, forced line feed, and forced page feed can be controlled.



#### Paper park switch (Not operable in this system)

While the paper roll is set, this function allows single sheet paper use, such as size A4, by moving the paper roll back to the tractor position.



#### Page feed switch

Feeds paper one page at a time. The page length is set by DIP switch 6 (near end of paper sensor).



#### Line feed switch

Each time **[FF]** is pressed, the line feeds by 1/6 of an inch. Continuous line feed is executed by holding down the switch.



#### NLQ lamp

When selecting (NLQ) SERIF for high quality character: Lights

When selecting SANS SERIF for high quality character: Blinks

When selecting normal character (DRAFT): OFF

#### NLQ switch

Selects a character from among (NLQ) SERIF, Standard (DRAFT), and SANS SERIF. The relation of the printing mode, to the **[NLQ]** lamp, and number of beeps is as follows.

|               |             |   |         |   |            |   |           |
|---------------|-------------|---|---------|---|------------|---|-----------|
| Printing mode | : NLQ SERIF | → | DRAFT   | → | SANS SERIF | → | NLQ SERIF |
| NLQ lamp      | : Lights    |   | Off     |   | Blinks     |   | Lights    |
| Beep          | :           |   | 3 times |   | 1 time     |   | 2 times   |



#### ONLINE lamp

Lights when the printer is in an on-line state (data reception is set), and the light is off in the OFF line state. When the printing pitch and margin are set, the light blinks at 0.3 sec. intervals.

#### ONLINE switch

Switches the on-line/off-line state.



#### P.OUT lamp

Lights when there is no paper in the printer. When this happens, the printer is in an off-line state. The light goes off after loading the paper and pressing the **[ONLINE]** switch. When an error is detected, it blinks.



#### POWER lamp

Lights when the printer power is ON.

### 3.8.3 Opening / Closing the Printer Cover

When opening the printer cover, move the paper roll stand unit one step back. To open/close the printer cover, follow the procedures consecutively.

#### CAUTION



Be sure to turn OFF the printer's power when opening and closing the printer cover. Failure to comply could result in electrical shock, failure, or injury.



Just after printing, the temperature of the printing head is high. Do not touch the printing head until the temperature goes down. Failure to comply could result in a burn or injury.




Do not touch any part of the cutter. Doing so is potentially dangerous.


#### Procedure

**1. Loosen the two screws holding the paper roll stand unit fixed.**


When closing the printer cover, follow the steps in reverse order.



**2. Move the paper roll stand unit one step backwards.**



**3. Open the printer cover.**



### 3.8.4 Replacing the Roll Paper

When replacing the paper roll, proceed as follows.



## CAUTION



Be sure to turn OFF the printer power when opening and closing the printer cover. Failure to comply could result in electrical shock, failure, or injury.



Just after printing, the temperature of the printer head is high. Do not touch the printer head until the temperature goes down. Failure to comply could result in a burn or injury.




Do not touch any part of the cutter. Doing so may result in injury.

### Procedure


**1. Insert the roll bar through the center of the paper roll.**

If the leading edge of paper is torn or bent, cut it off in a straight line.



**2. Attach the roll bar with the paper roll onto the paper roll stand unit holder, taking care to notice the paper roll's direction.**


Set the sensor guide lever so that it touches the paper roll.




### Note

- Perform the consecutive procedures while the printer cover is open.
- To open the printer cover, refer to "9.3 Opening/Closing the Printer Cover".


- 3. Pull out the leading edge of the paper onto the paper guide bar.**




- 4. Insert the leading edge of the paper from behind the platen**




- 5. Turn the paper feed knob and pull out the leading edge of the paper.**




6. **Adjust the paper position for both sides of paper in and paper out, so that the left and right guide rings of the paper guide bar support the paper lightly.**




7. **Pull down the reflection lever.**  
The paper touches the platen securely.




8. **Pull down the reflection lever.**  
Lift the paper setting lever to harness the paper emerging from the platen.



9. **First, insert the axis of the left side of the paper roll cover into the left hole of the paper roll stand, then set the right side.**




10. **Lower the paper roll cover and then push down the paper support bar.**



11. **Close the printer cover.**  
For further details of steps 11 through 13, refer to "9.3 Opening/Closing the Printer Cover".

12. **Pull the paper roll stand unit one step forward.**

13. **Turn the screws tightly to stabilize the paper roll stand unit.**



### 3.8.5 Replacing the Ribbon Cassette Cartridge

When the printing quality becomes faint, replace the ribbon cassette cartridge with a new one. To replace, proceed as follows.

#### CAUTION



Be sure to turn OFF the printer power when opening and closing the printer cover. Failure to comply could result in electrical shock, failure, or injury.



Just after printing, the temperature of the printer head is high. Do not touch the printer head until the temperature goes down. Failure to comply could result in a burn or injury.




Do not touch any part of the cutter. Doing so may result in injury.

#### Procedure


1. Open the printer cover.

#### Note


- To open the printer cover, refer to "7.3 Opening/Closing the Printer Cover".



2. Lift up the tip of the ribbon cassette cartridge by grasping the projection on top, and remove it.




3. Turn the cassette knob of the new ribbon cassette cartridge counterclockwise to increase the tension of the ribbon.




4. Manually, move the printing head to the home position (left side) and place the ribbon cassette cartridge in the printer so that the ribbon is positioned between the ribbon mask and the printing head. In this case, make sure that the ribbon feed axis is inserted through the hole under the ribbon cassette knob.

**Note**

- Lightly press the ribbon cassette cartridge at both ends.
- Turn the cassette knob again to increase the tension of the ribbon.
- Confirm that the ribbon is positioned properly in front of the printing head.



5. Close the printer cover



### 3.8.6 Adjusting the Printing Pressure (to Printing Paper Thickness)

The printing pressure can be adjusted with the head adjust lever located on the right side of the inner part of the printer.



## CAUTION



Be sure to turn OFF the printer power when opening and closing the printer cover. Failure to comply could result in electrical shock, failure, or injury.



Just after printing, the temperature of the printer head is high. Do not touch the printer head until the temperature goes down. Failure to comply could result in a burn or injury.



Do not touch any part of the cutter. Doing so may result in injury.

## Procedure

### 1. Open the printer cover and set up the head adjusting lever.


Each type of paper should be set as follows:

Normal paper :

The optimal position among the numbers shown is ③.

Three layers of copying paper :

The optimum position is ⑤ or ⑥.



## Note

- The printing pressure increases in numerical order (①→⑥).
- To open/close the printer cover, refer to "7.3 Opening/Closing the Printer Cover".

### 3.8.7 Setting the DIP Switch

Set the DIP switch to select a language, character set, or particular function.

#### **ATTENTION**



Before beginning the procedure, be sure to turn the power OFF.  
Failure to do so may cause electrical shock, malfunction or injury.




Just after printing, the temperature of the printer head is high. Do not touch the printer head until the temperature goes down.  
Doing so may cause burns or injury.



Do not touch any part of the cutter.  
Doing so is potentially dangerous and may cause injury.

#### **Procedure**


1. **Open the printer cover, remove the ribbon cassette cartridge, and move the printing head manually to the right end.**



#### **Note**


- The printing pressure increases in numerical order (①→⑥).
- To open/close the printer cover, refer to "7.3 Opening/Closing the Printer Cover".
- To remove the ribbon cassette cartridge, refer to "7.5 Replacing the Ribbon Cassette Cartridge".

2. **Hold the tip of the partition cover and slide it to the left to remove it.**  
The DIP switch appears.



### 3. Set the DIP switch to desired mode

The following diagrams describe the relation between each DIP switch position and the content of each setting.



#### ① Selection of an international language

|                                                                     |                                                                     |                     |                                                                     |                                                                     |                     |                                                                     |                                                                     |                     |                                                                     |                                                                     |                    |
|---------------------------------------------------------------------|---------------------------------------------------------------------|---------------------|---------------------------------------------------------------------|---------------------------------------------------------------------|---------------------|---------------------------------------------------------------------|---------------------------------------------------------------------|---------------------|---------------------------------------------------------------------|---------------------------------------------------------------------|--------------------|
| ON <input type="checkbox"/> OFF <input checked="" type="checkbox"/> | ON <input type="checkbox"/> OFF <input checked="" type="checkbox"/> | U.S.A.<br>(English) | ON <input type="checkbox"/> OFF <input checked="" type="checkbox"/> | ON <input type="checkbox"/> OFF <input checked="" type="checkbox"/> | France<br>(French)  | ON <input type="checkbox"/> OFF <input checked="" type="checkbox"/> | ON <input type="checkbox"/> OFF <input checked="" type="checkbox"/> | Germany<br>(German) | ON <input type="checkbox"/> OFF <input checked="" type="checkbox"/> | ON <input type="checkbox"/> OFF <input checked="" type="checkbox"/> | U.K.<br>(English)  |
| ON <input type="checkbox"/> OFF <input checked="" type="checkbox"/> | ON <input type="checkbox"/> OFF <input checked="" type="checkbox"/> | Denmark<br>(Danish) | ON <input type="checkbox"/> OFF <input checked="" type="checkbox"/> | ON <input type="checkbox"/> OFF <input checked="" type="checkbox"/> | Sweden<br>(Swedish) | ON <input type="checkbox"/> OFF <input checked="" type="checkbox"/> | ON <input type="checkbox"/> OFF <input checked="" type="checkbox"/> | Italy<br>(Italian)  | ON <input type="checkbox"/> OFF <input checked="" type="checkbox"/> | ON <input type="checkbox"/> OFF <input checked="" type="checkbox"/> | Spain<br>(Spanish) |

#### ② Emulation

|                                                                     |     |
|---------------------------------------------------------------------|-----|
| ON <input type="checkbox"/> OFF <input checked="" type="checkbox"/> | IBM |
| ON <input type="checkbox"/> OFF <input checked="" type="checkbox"/> | FX  |

#### ③ Selection of character set (IBM mode)

|                                                                     |       |
|---------------------------------------------------------------------|-------|
| ON <input type="checkbox"/> OFF <input checked="" type="checkbox"/> | SET 2 |
| ON <input type="checkbox"/> OFF <input checked="" type="checkbox"/> | SET 1 |

#### ③ One inch skip perforation (FX mode)

|                                                                     |         |
|---------------------------------------------------------------------|---------|
| ON <input type="checkbox"/> OFF <input checked="" type="checkbox"/> | Valid   |
| ON <input type="checkbox"/> OFF <input checked="" type="checkbox"/> | Invalid |

#### ④ Paper near end sensor

|                                                                     |         |
|---------------------------------------------------------------------|---------|
| ON <input type="checkbox"/> OFF <input checked="" type="checkbox"/> | Valid   |
| ON <input type="checkbox"/> OFF <input checked="" type="checkbox"/> | Invalid |

#### ⑤ Selection of AUTO CR (IBM mode)

|                                                                     |         |
|---------------------------------------------------------------------|---------|
| ON <input type="checkbox"/> OFF <input checked="" type="checkbox"/> | Valid   |
| ON <input type="checkbox"/> OFF <input checked="" type="checkbox"/> | Invalid |

#### ⑤ Selection of valid/invalid for DC1/DC3 (FX mode)

|                                                                     |         |
|---------------------------------------------------------------------|---------|
| ON <input type="checkbox"/> OFF <input checked="" type="checkbox"/> | Invalid |
| ON <input type="checkbox"/> OFF <input checked="" type="checkbox"/> | Valid   |

DC3 code: Printer is set to ignore all data except DC1 code (By-pass state).

DC1 code: By-pass state in DC3 is canceled.

#### ⑥ Selection of LF code (IBM mode)

|                                                                     |         |
|---------------------------------------------------------------------|---------|
| ON <input type="checkbox"/> OFF <input checked="" type="checkbox"/> | LF+CR   |
| ON <input type="checkbox"/> OFF <input checked="" type="checkbox"/> | LF only |

#### ⑥ Selection of LF code (FX mode)

|                                                                     |         |
|---------------------------------------------------------------------|---------|
| ON <input type="checkbox"/> OFF <input checked="" type="checkbox"/> | Invalid |
| ON <input type="checkbox"/> OFF <input checked="" type="checkbox"/> | AUTO LF |

### 4. When settings are completed, put the partition cover back in its place, set up the ribbon cassette, and then close the printer cover.

### 5. While pressing **NLQ** turn the power ON.

After initialization is carried out, the selected function and current setting status of the DIP switch are printed.

#### Note

- When printing under the current setting status, the printer is set to an off-line state. When the test pattern is completely printed out, it is automatically set to an on-line state.

**Note**

Dip switch setting for each equipment.

|                                                                         | DIP switch setting                                            |
|-------------------------------------------------------------------------|---------------------------------------------------------------|
| JSS-296(NCT-196N/NDZ-127J)<br>JSS-825D(NCT-620D)<br>NCT-196<br>NCT-196N | <p>DIP switch</p> <p>ON</p> <p>OFF</p> <p>1 2 3 4 5 6 7 8</p> |
| JSS-850<br>JUE-75C(NDZ-127C)                                            | <p>DIP switch</p> <p>ON</p> <p>OFF</p> <p>1 2 3 4 5 6 7 8</p> |
| JSS-825NA/NC(NDZ-127N)                                                  | <p>DIP switch</p> <p>ON</p> <p>OFF</p> <p>1 2 3 4 5 6 7 8</p> |

### 3.8.8 How to Attend to Error Detection

There are two types of errors. When an error is detected, a beep sounds, and the **P.OUT** lamp blinks 5 times.

**(1) Paper discharge error**

When the "out of paper" state is not detected, even though an 18 inch line feed procedure is performed, a paper discharge error will result. The **P.OUT** lamp remains blinking until the error state is canceled.

When this happens, manually pull the paper out of the printer, or remove the paper automatically by using **LF** or **FF**, then press **ONLINE**.

**(2) Paper sending error**

If the paper is not properly set, even though a 10 inch line feed procedure is performed, a paper sending error results. In addition, if this error happens when the printing instruction is entered, the **P.OUT** lamp remains blinking until the error state is canceled.

When this happens, follow the procedure below.

#### Procedure

1. Press **ONLINE** switch.  
The printer is set to an off-line state.
2. Press **FF** switch, set the paper, then press **ONLINE**.  
The printer is set to an on-line state.



## 4. MAINTENANCE AND INSPECTION

### ATTENTION

This chapter describes about the JSS-296 Radio Equipment as a whole. So if further information is required, see the specialized instruction manuals such as the JSB-196GM Radiotelephone or NCT-196N DSC/NBDP MODEM.

The performance and longevity of this equipment depend on careful maintenance. To maintain the best performance, the following periodic inspections are highly recommended.

- (1) Keep the power supply voltage within the specified value.
- (2) Know the condition of normal status when the equipment is properly functioning. Keep comparing the current status to the normal status to immediately detect any malfunctions.

### WARNING



If you remove a unit, be sure to store it in a non-conductive bag. If you wrap it up with materials such as aluminum foil, the back-up power supply may short circuit and the ICs may be damaged.



There are no user-serviceable parts inside this equipment. Inspection or maintenance by unauthorized persons may result in fire or electric shock. For inspection and maintenance, contact JRC or its authorized agents.

### CAUTION



Do not turn the trimmer resistors or trimmer capacitors on the PCB unit (they are preset at the factory). Doing so may cause failure or malfunction.



Leave installation of this equipment to JRC or our agents. Installation by an unauthorized person may lead to malfunction.

## 4.1 General Maintenance and Inspection

General maintaining and inspecting items with usual tools and apparatus are listed below.

| No. | Item               | Maintenance and inspection                                                                                                                                                                                                                       |
|-----|--------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1   | Cleaning           | Gently clean the surface of the panel, knobs, switches, and upper/bottom cover with a soft cloth or silicon oil.<br>Remove dust in the unit using a brush or vacuum cleaner. No oil is needed because this unit has no moving mechanisms inside. |
| 2   | Looseness of parts | Inspect for looseness and correctly tighten the following:<br>screws, nuts, knobs, switches, volume pots, connectors and relays inserted into sockets.                                                                                           |
| 3   | Fuse               | If the power source fuse is blown, be sure to inspect the cause before replacing the blown fuse with a new one.                                                                                                                                  |
| 4   | PCB Unit           | Remove screws mounting the unit, demount the unit from the main chassis, and inspect the unit for discoloration and parching of components. To exchange parts, call our service center or agents.                                                |

**Note**

If you remove the PCB unit, be sure to store it in a non-conductive bag. If you wrap it up with materials such as aluminum, the buck-up power supply may short circuit and the IC may be damaged.

## 5. AFTER-SALES SERVICE

### 5.1 Before returning repair

If what appears to be a defect is detected, refer to Troubleshooting descriptions of the specialized instruction manual for every unit to check if the equipment is actually defective before requesting repair.

If the defect persists, immediately stop operation and call our service center or agents.

- During the warranty period, we or our agencies (\*1) will repair the malfunction without any fee, according to the specified procedure.
- After the warranty expires, we will repair the malfunction for a fee, if repair is possible.
- Items for notification
  - Product name, type, manufactured data, serial number,
  - information about the malfunction (the more detailed, the better),
  - your company or organization name, address and phone number.

(\*1) Refer to the inside of the back cover for contact numbers.

### 5.2 Periodical maintenance recommended

Performance of this equipment may degrade over time because parts wear out, although degradation depends on how this unit has been maintained, thus we recommend periodic professional maintenance checks in addition to daily maintenance. So please contact our service center or agents for periodic professional maintenance (This maintenance requires a service charge), or for further information about after-sales service.



## 6. SPECIFICATIONS

### 1. GENERAL

|                          |                                                                                                                          |
|--------------------------|--------------------------------------------------------------------------------------------------------------------------|
| Frequency range:         | Transmit: 1.6 to 27.5MHz (100Hz steps)<br>Receive: 0.1 to 29.9999MHz (100Hz steps)                                       |
| Frequency tolerance:     | ±10Hz or better                                                                                                          |
| Emission mode:           | J3E (TEL), F1B (DSC/TLX), A1A (CW), H2B,<br>H3E (AME: reception only)                                                    |
| User definable channels: | 200ch (20ch X 10 Groups)                                                                                                 |
| Preset ITU channels:     | 1722ch [ TEL:283, DSC:29, TLX:891, CW:519 ]                                                                              |
| Scanning channel         | 20 user defined channels                                                                                                 |
| Communication mode:      | Simplex and semi-duplex                                                                                                  |
| Antenna impedance:       | 50 ohms                                                                                                                  |
| Operating temperature:   | -15 to +55°C                                                                                                             |
| Power requirement:       | 90~132V/180~264V AC, Single-phase, 50/60Hz<br>Tx: 2.0kVA max, Rx: 0.5kVA max<br>21.6~31.2V DC<br>Tx: 30A max, Rx: 7A max |
| Compass safe distance:   | 1.5m                                                                                                                     |

### 2. TRANSMITTER

|                        |                                                                                                                                              |
|------------------------|----------------------------------------------------------------------------------------------------------------------------------------------|
| Output power:          | AC power source:<br>200Wpx ( 1.6 to 4MHz ) , 250Wpx ( 4 to 27.5MHz )<br>DC power source:<br>100Wpx ( 1.6 to 4MHz ) , 150Wpx ( 4 to 27.5MHz ) |
| Occupied bandwidth:    | J3E (TEL) 3kHz or better<br>F1B (DSC/TLX), A1A (CW) 0.5kHz or better                                                                         |
| Carrier suppression:   | 40dB or better                                                                                                                               |
| Spurious suppression:  | 43dB or better                                                                                                                               |
| AF frequency response: | 350 to 2700Hz (6dB bandwidth)                                                                                                                |
| Microphone input:      | 600 ohms (-40dBm standard)                                                                                                                   |
| Line input:            | 600 ohms, 0dBm (balanced)                                                                                                                    |

### **3. RECEIVER**

|                           |                                                                                                                                                                |
|---------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Receiving system:         | Triple superheterodyne                                                                                                                                         |
| Intermediate frequencies: | 70.455MHz, 455kHz, 20.217kHz                                                                                                                                   |
| Sensitivity (SINAD 20dB): | J3E (TEL) 6.3uV or better (1.6 to 4MHz)<br>3.5uV or better (4 to 27.5MHz)<br>F1B (DSC/TLX) 1.8uV or better (1.6 to 4MHz)<br>1.0uV or better (4 to 27.5MHz)     |
| Selectivity:              | J3E (TEL) 6dB bandwidth 2.4 to 3kHz,<br>66dB bandwidth Within $\pm 2.1$ kHz<br>F1B (DSC/TLX) 6dB bandwidth 270 to 300Hz,<br>60dB bandwidth Within $\pm 550$ Hz |
| Spurious response:        | 60dB or better                                                                                                                                                 |
| Clarifier range:          | $\pm 200$ Hz in 1Hz steps                                                                                                                                      |
| AF output:                | 5.0W max. 1W rated                                                                                                                                             |
| Line output:              | 600 ohms, 0dBm (balanced)                                                                                                                                      |

### **4. DSC/NBDP TERMINAL**

#### **DSC MODEM**

|                          |                                                                                          |
|--------------------------|------------------------------------------------------------------------------------------|
| Communications protocol: | In conformity with ITU-RM.493 and M.541                                                  |
| Emission:                | F1B/J2B 100 baud                                                                         |
| Code:                    | 10 units error detection specified by ITU-RM.493.                                        |
| Memory capacity:         | Received Distress messages: 20<br>Received Other messages: 20<br>Transmitted message: 11 |
| Clock:                   | Within $\pm 30$ ppm                                                                      |
| Data backup time:        | 24 hours (message content and time data)                                                 |
| Mark frequency:          | 1615 $\pm 0.5$ Hz                                                                        |
| Space frequency:         | 1785 $\pm 0.5$ Hz                                                                        |
| Output level:            | 0dBm (-20 to +10dBm variable/600 ohms balanced)                                          |
| Input frequency :        | 1700 $\pm 85$ Hz                                                                         |
| Input level :            | -25 to +10dBm (600-ohm balanced load)                                                    |

#### **NBDP MODEM**

|                          |                                                                               |
|--------------------------|-------------------------------------------------------------------------------|
| Communications protocol: | In conformity with ITU-RM.476, M.490, M.491, M.492, M.625 and ITU-T Rec. F130 |
| Emission:                | F1B/J2B 100 baud                                                              |
| Code:                    | 7-bit code 4B/3Y ratio constant mark signal                                   |
| Clock:                   | Within $\pm 30$ ppm                                                           |
| Mark frequency:          | 1615 $\pm 0.5$ Hz                                                             |
| Space frequency:         | 1785 $\pm 0.5$ Hz                                                             |
| Output level:            | 0dBm (-20 to +10dBm variable/600 ohms balanced)                               |
| Input frequency :        | 1700 $\pm 85$ Hz                                                              |
| Input level :            | -25 to +10dBm (600-ohm balanced load)                                         |

## **5. WATCHKEEPING RECEIVER**

|                           |                                                                |
|---------------------------|----------------------------------------------------------------|
| Receiving frequencies:    | 2187.5kHz, 4207.5kHz, 6312kHz, 8414.5kHz, 12577kHz, 16804.5kHz |
| Receiving system:         | Double superheterodyne                                         |
| Intermediate frequencies: | 40.455MHz, 455kHz                                              |
| Reception mode:           | F1B/J2B                                                        |
| Sensitivity:              | Symbol error rate of 1% or better at 1 micro-volt input        |
| Frequency stability:      | Within +/- 10Hz after 1-minute warm-up                         |
| Antenna impedance:        | 50 ohms unbalanced                                             |

## **6. ANTENNA TUNER**

|                        |                                                                 |
|------------------------|-----------------------------------------------------------------|
| Frequency range:       | 1.6 to 30MHz                                                    |
| Power capability:      | 300Wpx                                                          |
| SWR after tuning:      | 2:1                                                             |
| Tuning method:         | Automatic tuning and preset tuning                              |
| Tuning time:           | Automatic tuning: typical 3sec<br>Preset tuning: typical 0.5sec |
| Operating temperature: | -25 to +55 °C                                                   |

## **7. BATTERY CHARGER**

|                   |                                                  |
|-------------------|--------------------------------------------------|
| Charging current: | 20A (Ordinary charge)<br>10A (Equalizing charge) |
| Alarm function:   | Charge /Low voltage/ High voltage alarm          |

## **8. DATA TERMINAL**

|                  |                                               |
|------------------|-----------------------------------------------|
| Controlled item: | NBDP function (Control the DSC/NBDP Terminal) |
|------------------|-----------------------------------------------|

## **9. KEYBOARD**

|                 |                   |
|-----------------|-------------------|
| Interface:      | Matrix            |
| Contact method: | Membrane sheet    |
| Life:           | 5 million strokes |

## **10. PRINTER**

|                    |                          |
|--------------------|--------------------------|
| Print method:      | Serial impact dot matrix |
| Interface:         | Centronics               |
| Paper feed method: | Paper roll holder        |
| Paper type:        | 209 to 216mm Roll paper  |



## Main Office & Plants

### ● Main Office

Akasaka Twin Tower(Main)  
17-22,Akasaka 2-chome,  
Minato-ku,Tokyo 107-8432 JAPAN  
Maritime Sales Department I  
Phone : +81-3-3584-8786  
Fax : +81-3-3584-8795  
Maritime Sales Department II  
Phone : +81-3-3584-8790  
Fax : +81-3-3584-8797  
International Business Department  
Phone : +81-3-3584-8836  
Fax : +81-3-3584-8878 • 3584-8859  
International Marketing Department  
Phone : +81-3-3584-8845  
Fax : +81-3-3584-8879

### ● Mitaka Plant

1-1,Shimorenjaku 5-chome,Mitaka  
Tokyo 181-8510 JAPAN  
Phone : +81-422-45-9111  
Fax : +81-422-45-9110

## Overseas Branch Office

### ● U.S.A

Japan Radio Co.,Ltd./Seattle Branch  
1011 SW Klickitat Way  
Bldg.B,Suite 100  
Seattle,WA 98134 U.S.A  
Phone : +1-206-654-5644  
Fax : +1-206-654-7030

### ● JRC (UK) Limited

136,1st Floor,Friars House,  
157/168 Blackfriars Road,  
London SE18 EZ,U.K.  
Phone : +44-20-7261-1188  
Fax : +44-20-7803-0996

### ● U.S.A

Japan Radio Co.,Ltd./New York Branch  
Suite 209 2125 Center Avenue,  
Fort Lee, N.J. 07024, U.S.A.  
Phone : +1-201-242-1882  
Fax : +1-201-242-1885

## Overseas

## Liaison & Service Offices

### ● Indonesia

Japan Radio Co.,Ltd.  
J1.H.R.Rasuna Said Kav.  
X-0,Jakarta 12950,INDONESIA  
Phone : +62-21-520-4053  
Fax : +62-21-525-4264

### ● Taiwan

Japan Radio Co.,Ltd  
10F-4,No.110,Santou 4<sup>th</sup> Road,  
Kaohsiung Taiwan,R.O.C  
Phone : +886-7-3307151  
Fax : +886-7-3319400

### ● Philippines

Japan Radio Co.,Ltd.  
2320 Taft Avenue  
Malate,Manila PHILIPPINES  
Phone : +63-2-524-8565 • 525-3589  
Fax : +63-2-521-5049

### ● Spain

Japan Radio Co.,Ltd.  
Calle Luis Doreste Silva,50-1-B  
De Las Palmas De Gran Canaria, SPAIN  
Phone : +34-928-290076  
Fax : +34-928-293755

### ● Thailand

Japan Radio Co.,Ltd.  
Charturong Arphon Building,  
457 Phra Sumaru Street,  
Bangkok 10200,THAILAND  
Phone /Fax : +66-2-280-0401

### ● Singapore

Japan Radio Co.,Ltd  
c/o CODAR(PTE.)LTD  
315 Outram Road #11-06/07 Tan Boon Liat  
Building Singapore 169074,SINGAPORE  
Phone : +65-2229190  
Fax : +65-2229398

### ● India

Japan Radio Co.,Ltd.  
Best Western Surya Hotel,  
Business Center New Friends  
Colony,New Delhi 110065,  
INDIA  
Phone : +91-11-691-9294 • 691-9297  
Fax : +91-11-691-9305

### ● Greece

Japan Radio Co.,Ltd.  
Akti Miaoli 57,Piraeus,Greece  
Phone : +30-1-429-3304 • 429-3305  
Fax : +30-1-429-3306

## Overseas Service Center

### ● Netherlands

Japan Radio Co.,Ltd.  
Eekhoutstraat-7,  
3087AB Rotterdam, THE NETHERLANDS  
Phone : +31-10-429-4581 • 495-0020  
Fax : +31-10-428-2259

*For further information contact:*



*Since 1915*

*Japan Radio Co., Ltd.*

HEAD OFFICE &  
SALES DEPT.

Akasaka Twin Tower (Main),  
17-22, Akasaka 2-chome, Minato-ku,  
Tokyo 107-8432 JAPAN  
Phone : +81-3-3584-8711  
Fax : +81-3-3584-8715  
Telex : 0242-5420 JRCTOK J

MAIN PLANT

1-1, Shimorenjaku 5-chome, Mitaka-shi,  
Tokyo 181-8510 JAPAN  
Phone : +81-422-45-9111  
Fax : +81-422-45-9110  
Telex : 02822-351 JRCMTK J