

FC1080-B1G-US

User Manual





Table of Contents

1. INTRODUCTION.....	1
2. HARDWARE INSTALLATION.....	1
3. CONFIGURATION.....	1
3.1. BEFORE CONFIGURATION.....	1
3.2. ESTABLISH THE CONNECTION	1
3.3. DEVICE INFO.....	2
3.3.1. Summary.....	2
3.3.2. Statistics.....	2
3.3.3. Route.....	2
3.3.4. ARP.....	2
3.4. ADVANCED SETUP	3
3.4.1. LAN	3
3.4.2. DNS.....	3
3.4.3. IPSec.....	4
3.4.4. Certificate	6
3.5. MANAGEMENT.....	8
3.5.1. Backup Settings and Restore Default Settings	8
3.5.2. System Log	10
3.5.3. Alarm History.....	10
3.5.4. SNMP Agent.....	11
3.5.5. Internet Time	12
3.5.6. Access Control	13
3.5.7. Update Software.....	13
3.5.8. Reboot.....	13
4. APPENDIX - TECOM MIB FILE	15



Revision Information

Revision #	Description	Date	Author
V 0.01	First release.	April 08, 2014	Chris Han



1. Introduction

The FC1080-B1G-US , 3G Residential Femto Access Point (FAP) is a standalone WCDMA Femtocell with up to 8 CS/ PS simultaneous users. It's designed to allow users to receive better mobile service coverage and capacity in the home with IPsec as secured backhaul through any broadband internet connection to a mobile service provider.

Carrier board of FC1080-B1G-US is used to monitor and remote control the Femtocell. In this document, only carrier board related functions are included. For more details of FC1080-B1G-US , please refer the other related documents.

Features

- IP configuration and DNS
- SNMP v1, v2c, v3
- IPsec
- NTP for time sync
- SSH interface for management
- Web-based configuration
- Remotely intervene to reset, restore default or power cycle the product
- Power Supply/Temperature/Case Open monitoring and alarming
- Show and manage alarm history
- Configuration backup and restore
- Firmware upgrade thru web

System Requirements


Along with FC1080-B1G-US , you also need the following equipments or services before installation.

- Computers which equips at least an Ethernet 10Base-T/100Base-T network interface card (port)
- A web browser, such as Microsoft Internet Explorer (V5.0 or later version) or Firefox, Chrome, which is used to configure the FC1080-B1G-US.



2. Hardware Installation

Please refer system installation guide




3. Configuration

3.1. Before Configuration

Before configuration, you have to connect and power FC1080-B1G-US and PC. Then connect the Ethernet port of PC to LAN port of FC1080-B1G-US. The default IP address of FC1080-B1G-US is “192.168.1.1” and the default port number is 80.

3.2. Establish the Connection

Enter the IP address and Port (default is 192.168.1.1:80) on your web browser. A dialogue box is popped up and requests to enter the user name and password. (Figure 3-2-1)


A screenshot of a web browser's authentication dialog box. The title bar says "Authentication Required" with a close button (X). The main text reads: "The server http://192.168.1.1:80 requires a username and password. The server says: Broadband Router." Below this, there are two input fields. The first is labeled "User Name:" and contains the text "admin". The second is labeled "Password:" and contains six asterisks "*****". At the bottom right, there are two buttons: "Log In" and "Cancel".

Authentication Required	
The server http://192.168.1.1:80 requires a username and password. The server says: Broadband Router.	
User Name:	admin
Password:	*****
Log In Cancel	

Figure 3-2-1. Authentication

Please use the default user name and password, “admin” and “admin”, and click OK button to login into the system.

Once authentication process is verified, the home page “Device Info - Summary” is shown on your browser. (Figure 3-2-2)

A screenshot of the "Device Info - Summary" page in a web browser. On the left is a sidebar menu with links: "Device Info", "Summary", "Statistics", "Route", "ARP", "Advanced Setup", and "Management". The main content area is titled "Device Info" and contains two tables. The first table lists device specifications, and the second table lists LAN connection details. Below the second table is a note: "This information reflects the current status of your LAN connection."

Device Info	
Board ID:	96368VWW
Symmetric CPU Threads:	2
Build Timestamp:	130402_0931
Software Version:	v1.04.62
Bootloader (CFE) Version:	1.0.38-112.37
Uptime:	0D 1H 4M 26S

This information reflects the current status of your LAN connection.

LAN IPv4 Address:	192.168.1.1
Mac Address:	00:19:15:11:21:31
Default Gateway:	192.168.1.254
Primary DNS Server:	8.8.8.8
Secondary DNS Server:	4.4.4.4

Figure 3-2-2. Device Info Page



In “Device Info” page, it shows you the basic information about the equipment, such as software version, MAC address, LAN IP and DNS.

3.3. Device Info

3.3.1. Summary

This page is already introduced in section 3.2.

3.3.2. Statistics

In this page (Figure 3-3-1) you can get the network statistics of the LAN. Click “Reset Statistics” to clean up all network statistics.

Device Info	Statistics -- LAN							
Summary								
Statistics								
LAN								
Route								
ARP								
Advanced Setup								
Management								

Interface	Received				Transmitted			
	Bytes	Pkts	Errs	Drops	Bytes	Pkts	Errs	Drops
eth1	29271036	93934	3093	0	1038643	2145	0	0

Reset Statistics

Figure 3-3-1. Device Info - Statistics

3.3.3. Route

In this page you can get the IP route information of the device. (Figure 3-3-2)

Device Info	Device Info -- Route						
Summary							
Statistics							
Route							
ARP							
Advanced Setup							
Management							

Flags: U - up, ! - reject, G - gateway, H - host, R - reinstate
D - dynamic (redirect), M - modified (redirect).

Destination	Gateway	Subnet Mask	Flag	Metric	Service	Interface
192.168.1.0	0.0.0.0	255.255.255.0	U	0		br0
0.0.0.0	192.168.1.254	0.0.0.0	UG	0		br0

Figure 3-3-2. Device Info - Route

3.3.4. ARP

This page shows an ARP table which maps IP network addresses to hardware addresses used by data link level protocol. (Figure 3-3-3)



Device Info Summary Statistics Route ARP Advanced Setup Management	Device Info -- ARP			
	IP address	Flags	HW Address	Device
	192.168.1.164	Complete	00:14:78:39:0e:ef	br0
	192.168.1.254	Incomplete	00:00:00:00:00:00	br0

Figure 3-3-3. Device Info - ARP

3.4. Advanced Setup

3.4.1. LAN

Click the “Advanced Setup/LAN” button on the left hand side to enter into the configuration of LAN.(Figure 3-4-1)

Device Info Advanced Setup LAN DNS IPSec Certificate Management	Local Area Network (LAN) Setup	
	Configure the Broadband Router IP Address and Subnet Mask for LAN interface. GroupName br0 ▼	
	IP Address:	192.168.1.1
	Subnet Mask:	255.255.255.0
	Default Gateway:	192.168.1.254
Apply/Save		

Figure 3-4-1. Advanced Setup - LAN

In this page, you may program the IP address of LAN, its subnet mask and the default gateway.

Before you leave, please click “Apply/ Save” button to save the changes you made.

3.4.2. DNS

Click the “Advanced Setup/DNS” button on the left hand side of the web page to enter into the DNS server configuration. (Figure 3-4-2)



Figure 3-4-2. Advanced Setup – DNS

For the details of DNS servers, please contact your ISP.

3.4.3. IPSec

To use IPSec user interface, choose “IPSec” under “Advanced Setup” menu. The base screen will be shown: (Figure 3-4-3)

Connection Name	Local Addresses	Remote Addresses	Remove
connection1	192.168.1.1	192.168.1.100	☐

Figure 3-4-3. Advanced Setup – IPSec

The table shows current connections. User can control the following items in the base IPSec page:

- Click the “Remove” button to remove a connection
- Click the “Add New Connection” button to add a new connection

The following screen is used to edit configurations when adding an IPSec connection. (Figure 3-4-4)



Device Info Advanced Setup LAN DNS DNS Server IPSec Certificate Management	IPSec Settings	
	IPSec Connection Name	new connection
	Transport Mode	ESP ▼
	Remote IPSec Machine Address (IPv4 address in dotted decimal)	0.0.0.0
	Key Exchange Method	Auto(IKE) ▼
	Authentication Method	Pre-Shared Key ▼
	Pre-Shared Key	key
	Perfect Forward Secrecy	Disable ▼
	Advanced IKE Settings	Show Advanced Settings
	Apply/Save	

Figure 3-4-4. Advanced Setup – IPSec

This is a dynamic page. It will change itself by showing and hiding options when different types or connections are chosen. User can select automatic key exchange or manual key exchange, pre-shared key authentication or certificate authentication, etc.

When automatic key exchange method is used, click “Show Advanced Settings” will show more options: (Figure 3-4-5)

Device Info Advanced Setup LAN DNS IPSec Certificate Management	Perfect Forward Secrecy	Disable ▼
	Advanced IKE Settings	Hide Advanced Settings
	Phase 1	
	Mode	Main ▼
	Encryption Algorithm	3DES ▼
	Integrity Algorithm	MD5 ▼
	Select Diffie-Hellman Group for Key Exchange	1024bit ▼
	Key Life Time	3600 Seconds
	Phase 2	
	Encryption Algorithm	3DES ▼
	Integrity Algorithm	MD5 ▼
	Select Diffie-Hellman Group for Key Exchange	1024bit ▼
	Key Life Time	3600 Seconds
	Apply/Save	

Figure 3-4-5. Advanced Setup – IPSec



3.4.4. Certificate

To use Certificate user interface, choose “Certificate” under “Advanced Setup” menu. There are two menu items under “Certificate” menu: “Local” and “Trusted CA”. For either type of certificate, the base screen shows a list of certificates stored in FC1080-B1G-US. (Figure 3-4-6)

Name	In Use	Subject	Type	Action
Cert1	☐	CN=C1/O=TECOM/ST=TAIWAN/C=TW	request	<button>View</button> <button>Load Signed</button> <button>Remove</button>

Create Certificate Request Import Certificate

Figure 3-4-6. Advanced Setup – Certificate

In the menu, “Local” means local certificates. “Trusted CA” means trusted Certificate Authority certificates. Local certificates preserve the identity of the device. CA certificates are used by the device to verify certificates from other hosts.

Local certificates can be created by two ways:

- Create a new certificate request, have it signed by a certificate authority and load the signed certificate
- Import an existing signed certificate directly

Create New Local Certificate

Follow the following steps to create a new certificate:

Click “Create Certificate Request”, enter necessary information: (Figure 3-4-7)

Create new certificate request

To generate a certificate signing request you need to include Common Name, Organization Name, State/Province Name, and the 2-letter Country Code for the certificate.

Certificate Name:

Common Name:

Organization Name:

State/Province Name:

Country/Region Name:

Apply

Figure 3-4-7. Advanced Setup – Certificate



Wait several seconds, the generated certificate request will be shown: (Figure 3-4-8)

Device Info Advanced Setup LAN DNS IPSec Certificate Local Trusted CA Management	Certificate signing request Certificate signing request successfully created. Note a request is not yet functional - have it signed by a Certificate Authority and load the signed certificate to this device.	
	Name	Cert2
	Type	request
	Subject	CN=C2/O=TECOM/ST=TAIWAN/C=TW
	Signing Request	<pre> -----BEGIN CERTIFICATE REQUEST----- MIIBejCB5AIBADA7MQswCQYDVQQDEwJDMjEOMAwGA1UEChMFVEVDT0 BAgTB1RBSVdBtjELMAkGA1UEBhMCVFcwZ8wDQYJKoZIhvcNAQEBBQ AoGBALXOS3ExEELmhc0g6kyRx1Z6AmHxQfhsPSQnWaLKVvG0epzSiU 8mYqYOJFLHqOatTd1AwcAdv05mNi6jUwmBCJatTdWlKNmpGXB6a0ks fU5tQa6KLIhiCAiU8zwAz77Nq2dmXBJ879vxGDSRLJceawfNagMBAA hkiG9w0BAQQFAAOBQB1gwaJ/VvL9a1Jh2f8wC+4zXuFfrThTar8Q5 PDUndxchEH7FsuzZtLU+4w7/AmsBJZ6sVCp8mWmaeR4joRuKTeBnFp xr9Xynhn12Ur3Lgb7C3jddLkSS88tQSScm6HEq98AlKIYF98gfGjJI -----END CERTIFICATE REQUEST----- </pre>

Figure 3-4-8. Advanced Setup – Certificate

The certificate request needs to be submitted to a certificate authority, which would sign the request. Then the signed certificate needs to be loaded into device. Click “Load Certificate” button from the previous screen or from the base screen will bring up the load certificate page. Paste the signed certificate and click apply and a new certificate is created. (Figure 3-4-9)

Device Info Advanced Setup LAN DNS IPSec Certificate Local Trusted CA Management	Load certificate Paste signed certificate.	
	Certificate Name:	Cert1
	Certificate:	<pre> -----BEGIN CERTIFICATE----- <insert certificate here> -----END CERTIFICATE----- </pre>

Figure 3-4-9. Advanced Setup – Certificate

Import Existing Local Certificate

To import existing certificate, click “Import Certificate” button and paste both certificate and corresponding private key: (Figure 3-4-10)



Device Info Advanced Setup LAN DNS IPSec Certificate Local Trusted CA Management	Import certificate Enter certificate name, paste certificate content and private key. Certificate Name: -----BEGIN CERTIFICATE----- <insert certificate here> -----END CERTIFICATE----- Certificate:

Figure 3-4-10. Advanced Setup – Certificate

CA Certificates

CA certificate can only be imported. The screen for importing is shown below: (Figure 3-4-11)

Device Info Advanced Setup LAN DNS IPSec Certificate Local Trusted CA Management	Import CA certificate Enter certificate name and paste certificate content. Certificate Name: -----BEGIN CERTIFICATE----- <insert certificate here> -----END CERTIFICATE----- Certificate:

Figure 3-4-11. Advanced Setup – Certificate

3.5. Management

3.5.1. Backup Settings and Restore Default Settings

Click “Management/Setting/Backup” on the left side of main page, it enables users to save current configuration to a file, (Figure 3-5-1)






Figure 3-5-1 Management - Backup Settings

Click “Management/Setting/Update” on the left side of main page, it will allows users to upload a saved configuration file for FC1080-B1G-US, in Figure 3-5-2,




Figure 3-5-2 Management - Update Settings

Click “Management/Setting/Restore Default” on the left side of main page, it will allows users to reset all default settings for FC1080-B1G-US, in Figure 3-5-3,




Figure 3-5-3 Management - Restore default settings

Click the “Restore Default Settings” button, then system will reboot for a while.



3.5.2. System Log

This allows System Administrator to view the System Log and configure the System Log options. (Figure 3-5-4)




Figure 3-5-4 Management - System Log

Configure the System Log option.(Figure 3-5-5) There're 8 levels of Log Level and Display Level, Emergency, Alert, Critical, Error, Warning, Notice, Informational, Debugging. The Log Level implies that what log level is applied to FC1080-B1G-US to do the log. The Display Level would just show the users the log message that they want to know. As a result, Display Level was just a subset of the retrieved from the total log message which was logged according to the setting of the Log Level. If the "Mode" is set to "Remote" or "Both", the log messages would be sent to the specified UDP port of the specified log server.




Figure 3-5-5 Management - System Log

3.5.3. Alarm History

This allows System Administrator to view the Alarm History and reset it. (Figure 3-5-6) You can click "Reset" to clear and reset the Alarm History.






Figure 3-5-6 Management - Alarm History

Now there are four types of alarm: power, temperature, tamper, external PA. (Figure 3-5-7)

- Power Supply Monitoring alarms will be available for signalling over and under power conditions
- Temperature Monitoring alarms will be available for signalling over and under temperature
- Tamper alarms will be available to indicate that the Outdoor FAP has been opened or tampered with
- External PA health alarms will be provided if PA bias voltage is out of specification

Alarm History

Time Stamp	Alarm Type	Alarm Status
Tue Apr 9 09:54:23 2013	Tamper_Alarm	Raised
Tue Apr 9 09:54:23 2013	Power_Alarm	Raised
Tue Apr 9 09:54:23 2013	External_PA_Alarm	Raised

Refresh Close

Figure 3-5-7 Management - Alarm History

3.5.4. SNMP Agent

System Administrator could configure the embedded SNMP Agent here. SNMP Agent would allow a management application to retrieve statistics and remote control . (Figure 3-5-8)



Device Info
Advanced Setup
Management
Settings
System Log
Alarm History
SNMP Agent
Internet Time
Access Control
Update Software
Reboot

SNMP - Configuration

Simple Network Management Protocol (SNMP) allows a management application to retrieve statistics and status from the SNMP agent in this device.

Select the desired values and click "Apply" to configure the SNMP options.

Read Community: public
Set Community: private
System Name: Tecom
System Location:
System Contact:

SNMPv3 Security Parameters

Security User Name: femto
Authentication Protocol: HMAC-MD5
Authentication Password:
Privacy Protocol: CBC-DES
Privacy Password:
Trap Manager IP:

Save/Apply

Figure 3-5-8 Management - SNMP Agent

The detail function of Read Community, Set Community, System Name, System Location, System Contact, and SNMPv3 related parameters would not be described here. Please check with your system administrator.

You can also check appendix for the private MIBs supported by FC1080-B1G-US.

3.5.5. Internet Time

If you need FC1080-B1G-US to sync time from NTP server, you need to access this page to configure your local NTP information, see Figure 3-5-9, you need to choose corresponding NTP server or configure them manually.

Device Info
Advanced Setup
Management
Settings
System Log
Alarm History
SNMP Agent
Internet Time
Access Control
Update Software
Reboot

Time settings

This page allows you to the modem's time configuration.

☒ Automatically synchronize with Internet time servers

First NTP time server: time.nist.gov
Second NTP time server: ntp1.tummy.com
Third NTP time server: None
Fourth NTP time server: None
Fifth NTP time server: None

Time zone offset: (GMT+08:00) Beijing, Chongqing, Hong Kong, Urumqi

Apply/Save

Figure 3-5-9 Management - Internet Time



3.5.6. Access Control

Access control enables to change password of different accounts. (Figure 3-5-10)

Device Info
Advanced Setup
Management
Settings
System Log
Alarm History
SNMP Agent
Internet Time
Access Control
Passwords
Update Software
Reboot

Access Control -- Passwords

Access to your broadband router is controlled through two user accounts: admin and user.

The user name "admin" has unrestricted access to change and view configuration of your Broadband Router.

The user name "user" can access the Broadband Router, view configuration settings and statistics, as well as, update the router's software.

Use the fields below to enter up to 16 characters and click "Apply/Save" to change or create passwords.
Note: Password cannot contain a space.

User Name:

Old Password:

New Password:

Confirm Password:

Figure 3-5-10 Management - Access Control

3.5.7. Update Software

Figure 3-5-11 show the web page, which is used for updating software,

Device Info
Advanced Setup
Management
Settings
System Log
Alarm History
SNMP Agent
Internet Time
Access Control
Update Software
Reboot

Tools -- Update Software

Step 1: Obtain an updated software image file from your ISP.

Step 2: Enter the path to the image file location in the box below or click the "Browse" button to locate the image file.

Step 3: Click the "Update Software" button once to upload the new image file.

NOTE: The update process takes about 2 minutes to complete, and your Broadband Router will reboot.

Software File Name: No file chosen

Figure 3-5-11 Management - Update Software

The new released software could be updated from the PC. Click the "Choose File" to locate the new software image file in the PC. Then, press "Update Software" to proceed the software update.

It should be noticed that the update will take about more than 2 minutes; users should wait for a while, and the FC1080-B1G-US will reboot by itself.

3.5.8. Reboot

This allows system administrator to reboot the FC1080-B1G-US carrier board manually. (Figure 3-5-12)




Device Info
Advanced Setup
Management
Settings
System Log
Alarm History
SNMP Agent
Internet Time
Access Control
Update Software
Reboot

Click the button below to reboot the router.

Reboot

Figure 3-5-12 Management - Reboot



4. Appendix - MIB File


The following is part of TECOM Femto MIB file, it describes the node information of TECOM MIB tree

```
-- 1.3.6.1.4.1.28044.1.1.1
femtoReset OBJECT-TYPE
    SYNTAX Integer32
    MAX-ACCESS read-write
    STATUS current
    DESCRIPTION
        "femto module reset. set 1 to enable it."
    ::= { femtoObject 1 }

-- 1.3.6.1.4.1.28044.1.1.2
femtoFactoryReset OBJECT-TYPE
    SYNTAX Integer32
    MAX-ACCESS read-write
    STATUS current
    DESCRIPTION
        "femto module factory reset. set 1 to enable it."
    ::= { femtoObject 2 }

-- 1.3.6.1.4.1.28044.1.1.3
carrierReset OBJECT-TYPE
    SYNTAX Integer32
    MAX-ACCESS read-write
    STATUS current
    DESCRIPTION
        "carrier board reset. set 1 to enable it."
    ::= { femtoObject 3 }

-- 1.3.6.1.4.1.28044.1.1.4
carrierFactoryReset OBJECT-TYPE
    SYNTAX Integer32
    MAX-ACCESS read-write
    STATUS current
    DESCRIPTION
        "carrier board factory reset. set 1 to enable it."
    ::= { femtoObject 4 }
```



```

-- 1.3.6.1.4.1.28044.1.1.5
systemReset OBJECT-TYPE
    SYNTAX Integer32
    MAX-ACCESS read-write
    STATUS current
    DESCRIPTION
        "whole system reset. set 1 to enable it."
    ::= { femtoObject 5 }

-- 1.3.6.1.4.1.28044.1.1.6
systemFactoryReset OBJECT-TYPE
    SYNTAX Integer32
    MAX-ACCESS read-write
    STATUS current
    DESCRIPTION
        "whole system factory reset. set 1 to enable it."
    ::= { femtoObject 6 }

-- 1.3.6.1.4.1.28044.1.1.7
carrierTemperature OBJECT-TYPE
    SYNTAX OCTET STRING
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Get the temperature of carrier board."
    ::= { femtoObject 7 }

-- 1.3.6.1.4.1.28044.1.1.8
caseOpen OBJECT-TYPE
    SYNTAX Integer32
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "case open status. 1-opened, 0-closed"
    ::= { femtoObject 8 }

-- 1.3.6.1.4.1.28044.1.1.9
simCardOpen OBJECT-TYPE
    SYNTAX Integer32
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "sim card open alarm.1-opened, 0-closed"
    ::= { femtoObject 9 }

```



```
-- 1.3.6.1.4.1.28044.1.1.10
paTemperature OBJECT-TYPE
    SYNTAX OCTET STRING
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "Get the temperature of PA"
    ::= { femtoObject 10 }
```

```
-- 1.3.6.1.4.1.28044.1.1.11
currentOf28VDC OBJECT-TYPE
    SYNTAX OCTET STRING
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "current of front 28VDC."
    ::= { femtoObject 11 }
```

```
-- 1.3.6.1.4.1.28044.1.1.12
currentOf5VDC OBJECT-TYPE
    SYNTAX OCTET STRING
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "current of femto 5VDC."
    ::= { femtoObject 12 }
```

```
-- 1.3.6.1.4.1.28044.1.1.13
voltageOf28VDC OBJECT-TYPE
    SYNTAX OCTET STRING
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "voltage of front 28VDC."
    ::= { femtoObject 13 }
```

```
-- 1.3.6.1.4.1.28044.1.1.14
voltageOf5VDC OBJECT-TYPE
    SYNTAX OCTET STRING
    MAX-ACCESS read-only
    STATUS current
    DESCRIPTION
        "voltage of femto 5VDC."
    ::= { femtoObject 14 }
```



-- 1.3.6.1.4.1.28044.1.1.15
turnOnFemto5V OBJECT-TYPE
 SYNTAX Integer32
 MAX-ACCESS read-write
 STATUS current
 DESCRIPTION
 "turn on femto 5VDC. 1-turn on,0-turn off"
 ::= { femtoObject 15 }

-- 1.3.6.1.4.1.28044.1.1.16
enablePA OBJECT-TYPE
 SYNTAX Integer32
 MAX-ACCESS read-write
 STATUS current
 DESCRIPTION
 "enable PA. 1-enable, 0-disable"
 ::= { femtoObject 16 }

-- 1.3.6.1.4.1.28044.1.2
femtoTrap OBJECT IDENTIFIER ::= { femto 2 }

-- 1.3.6.1.4.1.28044.1.2.1
warmStartTrap NOTIFICATION-TYPE
 STATUS current
 DESCRIPTION
 "warm start trap."
 ::= { femtoTrap 1 }

-- 1.3.6.1.4.1.28044.1.2.2
caseOpenAlarmTrap NOTIFICATION-TYPE
 STATUS current
 DESCRIPTION
 "case open alarm trap."
 ::= { femtoTrap 2 }

-- 1.3.6.1.4.1.28044.1.2.3
simCardOpenAlarmTrap NOTIFICATION-TYPE
 STATUS current
 DESCRIPTION
 "sim card open alarm trap."
 ::= { femtoTrap 3 }

-- 1.3.6.1.4.1.28044.1.2.4
powerAlarmTrap NOTIFICATION-TYPE
 STATUS current
 DESCRIPTION
 "power alarm trap."
 ::= { femtoTrap 4 }



```
-- 1.3.6.1.4.1.28044.1.2.5
thermalAlarmTrap NOTIFICATION-TYPE
    STATUS current
    DESCRIPTION
        "PA thermal alarm trap."
    ::= { femtoTrap 5 }
```

```
-- 1.3.6.1.4.1.28044.1.2.6
externalPATrap NOTIFICATION-TYPE
    STATUS current
    DESCRIPTION
        "power alarm trap."
    ::= { femtoTrap 6 }
```



FCC Regulations:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RF Exposure Information

This equipment complies with radio frequency (RF) exposure limits adopted by the Federal Communications Commission for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20 cm between the radiator & your body.
