

Table of Contents

0. Notice	3
1. MagicWave Introduction	4
MagicWave Overview	4
Main Characteristics	5
Specifications	6
2. Network Installation	8
Peer-to-Peer Mode	8
StructureNet Mode	9
3. Hardware and Software Installation	10
Packing Contents	10
PC Configurations	11
Required Equipment for Network Connection	11
Hardware Installation	12
- Desktop PC adapter card	12
- Notebook PC adapter card	13
- Access Point	13
Software Installation	14
- Windows 95 / 98 Setup	14
- Network Environment Setup	18
- MagicWave Adapter Card Setup	23
- Windows NT Setup	25
4. Access Point Installation Guide and Manual	32
Access Point Setup	32
Modify CONFIG.TXT	35
Null Modem Cable Configuration	36
Parameter Descriptions	37
- Radio Related	37
- Access Point Features	37
- TCP/IP Parameters	37
- Management Functions	38
- Diagnostic Method	38

5. Management Utility	40
Management Utility	40
Statistics Screen	41
Configuration Screen	43
Wireless / LAN Screen	44
TELNET Command Management	46
- Help Command	47
- Bridge Commands	47
- System Commands	47
- Ping	48

Notice

The SWL-1000D and SWL-1000N complies with Part 15 of the FCC rules.

Operation is subject to the following two conditions;

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Note : The SWL-1000N and SWL-1000D have been tested and found to comply with the limits for a Class B digital device and a low power transmitter, according to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures;

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an output on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Service

MagicWave is the trademark of SAMSUNG in wireless LAN.

The most recent software and user documentation for all MagicWave products are available on our World Wide Web.

<http://www.sem.samsung.co.kr>

Service Dept. 82-331-210-6805

Sales Dept. 82-331-210-6386

1. MagicWave Introduction

MagicWave Overview

The MagicWave(SWL-1000X) is a wireless LAN adapter card that provides wireless connections between PC's.

The function of the MagicWave SWL-1000AP (Access Point) is to transfer information from a wired LAN to a wireless LAN and from the wireless LAN back to the wired LAN.

When operating, the MagicWave AP is invisible to most users (Normally, unless the user is an administrator, the MagicWave AP can not be seen or accessed by users on the network).

The MagicWave is similar to Ethernet, a most widely used network card, but it can be used on motion when applied to Notebook PC because of the wireless connection.

The MagicWave is designed to operate with IEEE802.11 compliant radio cards, wireless LAN International Standard, and uses a protocol (CSMA/CA) of collision avoidance method for protect a collision on the network, so a high speed communication is possible.

The MagicWave supports DSSS (Direct Sequence Spread Spectrum).

This is a radio technique which scrambles the data prior to transmission and uses a correlation technique on receive to improve the signal to noise ratio and makes a possibility to communicate in the office having a wall, a compartment.

The MagicWave provides network driver software to support most of the commonly used network softwares and diagnostic programs.

Main Characteristic

The MagicWave supports a peer-to-peer communication which makes point-to-point and point-to-multipoint communications possible, which makes the communications between wireless LAN users easy.

A wireless network can be connected to a wired Ethernet through a network interface called an Access Point. Since all the protocols for a wired network are supported through an Access Point, all the services for a wired network are available for a wireless network users.

The MagicWave supports various network softwares. The network driver is supplied to support most network softwares such as MS Windows for Workgroup3.11, Windows95, Windows NT 3.51 / 4.0, etc.

The SWL-1000N for Notebook PC is small and portable as a roaming function is provided for users who need network services while maintaining mobility.

SPECIFICATIONS

◆ System Interface

	SWL-1000N	SWL-1000D
Medium Access Controller	Am79c930	Am79c930
PC Interface	PCMCIA	ISA
Configuration	Plug and Play	Plug and Play
LAN Standard	IEEE802.11 (CSMA/CA)	IEEE802.11(CSMA/CA)
LAN Interface	Radio Frequency	Radio Frequency

◆ Radio Specifications

	SWL-1000N	SWL-1000D
Frequency	2412,2417,2422,2427 2432,2437,2442,2447 2452,2457,2462,2467 2472,2484Mhz	The same as SWL-1000N
Output Power	less than 10mW/MHz	less than 10mW/MHz
Transmission rate	2Mbps	2Mbps
Modulation Methods	DSSS-DQPSK	DSSS-DQPSK
Receive Signal Level	-90dBm	-90dBm
Main Lobe Bandwidth	22Mhz	22Mhz
FER	less than 8×10^{-2}	

◆ Transmission Range

	SWL-1000N	SWL-1000D
Outdoor	400m	420m
In the office having a compartment (About 1.5m height)	70m	70m
In the office having a wall (Not made of concrete or metal)	50m	50m
In the office having a wall made of concrete	30m	30m

◆ Physical Specifications

	SWL-1000N	SWL-1000D
Adapter card size	105*53*5mm	180*110*10mm
Antenna size	built-in	85*80*15mm
Weight (net)	38g	145g
Operating temperature	-10 ~ +50 °C	
Power Consumption	1.6W	1.75W

◆ Supplied Software (both SWL-1000N and SWL-1000D)

MS Windows for Workgroup 3.11(NDIS 2) / Windows 95 / Windows 98 /Windows NT3.51/
Windows NT4.0 driver

◆ Operating State Indication Lamp

- ① Power : SWL-1000D (turns on when the system is powered on)
SWL-1000N (turns on with beep sound when the PC
initializes the wireless LAN card in the PCMCIA slot on system booting).
- ② Tx : turns on when transmitting data.
- ③ Rx : turns on when receiving data.

A PCMCIA wireless LAN card automatically starts to operate when inserted into the slot while the system is on because most notebook PC's support hot plugging in the Windows 95 environment. To remove the card while the system is in operation follow the next steps:

- Click on the icon shaped a PCMCIA card on the right bottom menu bar.
- Click on the card removal message when it appears next to the icon.
- Remove the card when the permission appears in a small box.

2. Network Installation


The number of computers connected, Ethernet installation, and desired network applications determine the type of network, Ad-Hoc or Infrastructure.

The wireless LAN can easily be installed and used while one must connect cables to install a wired LAN.

Peer- to - Peer Mode


A peer-to-peer mode is suitable for the environment in which connections to wired network are not necessary and can be constructed by only wireless LAN adapter cards.

You can use the network immediately after setting up the operating mode using the supplied network driver.




StructureNet Mode

A wireless LAN can be used to access all the services that are available for a wired LAN through an access point which connects the wireless LAN to a wired network.



Roaming function is also supplied to users who need mobile capabilities in this mode.




Roaming is a service that disconnects the user from an access point allotted to the previous cell and connects to the one allotted to a new cell when the user moves into the cell.

3. Hardware and Software installation

After opening the box, verify that all parts are included and check your computer and network environment.

Packing Contents

- (1) SWL-1000N (PCMCIA Card) or SWL-1000D (ISA Card)
- (2) SWL-1000AP (Each Access Point requires a SWL-1000N adapter card for operation)
- (3) User's Manual
- (4) SWL-1000 Install Diskette (Driver Diskette)
- (5) Power Adapter (SWL-1000AP only)
- (6) SWL-1000AP Utilities Diskette (SWL-1000AP only)
- (7) External Antenna (SWL-1000D only)



PC Configurations

For the SWL-1000D, verify that your computer has an extra IRQ, I/O Address.

SWL-1000D is ISA Plug & Play card supporting IRQ 9, 10, 11, 12.

Some multimedia PC may not have an extra IRQ.

Required Equipment for Network Connection

- If you want to use Peer-to-Peer Network, you can install with only SWL-1000D, SWL-1000N adapter cards.
- If you want to use StructureNet Network, you must install Access Point (SWL-1000AP) first.

Equipment required to install Access Point is

- (1) Access Point (SWL-1000AP)
- (2) PCMCIA wireless LAN adapter card (SWL-1000N)
- (3) Power adapter.

Hardware Installation

Desktop PC Adapter Card (SWL-1000D)

- (1) Turn the PC off, uncover the case, and remove the Dummy Bracket of an empty ISA expansion slot.
- (2) Insert carefully a MagicWave wireless LAN card to the PC slot and insert the screw to mount it in place.
- (3) Then, insert the antenna to the antenna connected from the back of the PC card as shown in the following picture.
- (4) Turn the PC on and confirm that the adapter card is recognized by the PC by checking the LED before you put the cover over the PC.

► Verification procedure through LED


Red LED : power LED, lights when the computer turns on.

Orange LED : blinks when receiving data.

Green LED : blinks when transmitting data.

- A SWL-1000D supports ISA Plug and Play. The card is automatically recognized and installed in Windows 95 environment.

If your system does not support the Plug and Play, you can use the utility for ISA PnP (not included in the package)



Notebook PC Adapter Card (SWL-1000N)

You can insert the card into a Notebook PC while the power is on or off.

- When inserting the card while using your notebook PC

Insert the SWL-1000N adapter card into the PCMCIA slot. A pleasant “cheep” sound indicates the regular operation. A low monotonous tone indicates a failure of the recognition.

- When inserting the card before turning your notebook PC on.

The success or failure of the card recognition is also indicated by the sound as above.

If the card is successfully recognized, install the device driver following the instructions on page 14.




Access Point (SWL-1000AP)

A MagicWave Access Point connects a MagicWave wireless LAN to existing wired LAN.

An Access Point is equipped with an Ethernet adapter supporting 10base-T, 10base 2 and a MagicWave wireless LAN adapter card.

Installation can be done easily as follows;

1. Insert the MagicWave card (SWL-1000N) into the PCMCIA slot of the Access Point (SWL-1000AP)
2. Connect the network cable to Ethernet port (10base-T or 10base 2) on the back of the Access Point.
3. Connect the power adapter.



Software Installation

Windows 98/95 Setup

1. You can see the following message when you insert MagicWave adapter card on the PC slot. (As previous presentation, in case of SWL-1000N for Notebook PC, you can insert a SWL-1000N card while power is on or off. In case of SWL-1000D for desktop-PC, you turn on the desktop-PC after you insert a SWL-1000D card on the PC slot.) Click “Next” button




2. Select “Display a list of.....” radio button, Click “Next” button




3. Select “Network adapters”, Click “Next” button




4. Select “(detected net drivers)” in Manufacturers, and “Existing Ndis2 Driver” in Models
Click “Have Disk” button.



5. Insert the driver diskette offered with a card. Set "A:\", Click "OK" button




6. Following window appears, click "OK" button




7. Following window appears, click “Next” button.



8. Following window appears, type “A:\” in Copy files from: Box, then click “OK” button




9. Restart your computer to finish setting up.




Network Environment Setup

After hardware and driver installations are finished, network environment setting for Windows 98 is needed. The steps are following.


1. After restarting a computer, Click "Start", "Settings", and "Control Panel".




2. Double-click "Network" icon, then Network window appears, and click "Add" button.




3. When "Select Network Component Type" window appears, Click "Protocol", and click "Add" button.



4. When "Select Network Protocol" window appears, Click "Microsoft" and "TCP/IP", and then click "OK" button.




5. When you click the Configuration tab and select TCP/IP in the Network window, you might see the TCP/IP Properties window. From here, set up your IP Address and Subnet Mask (If you don't know this, you can find out from your network administrator).




Subnet Mask : Type the Subnet Mask number obtained from your network administrator.
This number combines with the IP address and identification, which your computer belongs to the networks.


6. Click the "Gateway" tab in the TCP/IP Properties window, and then type the IP address of gateway and click "Add" button.




7. Click the "DNS Configuration" tab, and then type IP Address of DNS server and click "Add" button. Set up 'Host', 'Domain' and 'Domain Server Search Order' one by one, and then click "OK" button.



8. Click the "Advanced" tab, and then check the "Set this protocol to be the default protocol" and click "OK" button.




9. Click the "Bindings" tab, and confirm that "Client for Microsoft Networks" and "File and printer sharing for Microsoft Networks" are checked. When you click "OK" button, TCP/IP setting is completed.




MagicWave Adapter Card Setup

As method of Network environment setting, you can see “SAMSUNG Wireless LAN Card” at the “Network” window in the “Control Panel”.

This component means that MagicWave adapter card (SWL-1000N or 1000D) is correctly working. As selecting this component, you can change into the desired value.




1. Click the “Properties” and then “SAMSUNG Wireless LAN Card Properties” window appear. Click “Operating Mode” tab and type desired ESS ID.



- **BSS (Extended Service Set)** : Minimum cell that composed wireless LAN.
- **ESS (Extended Service Set)** : Interconnection of BBSs to work as one BBS.
- **Instawave** : In this mode wireless stations communicate directly with each other and through compatible access point
- **StructureNet** : In this mode wireless stations communicate with wireless stations and LAN stations through a compatible Access Point
- **Peer-to-Peer** : In this mode wireless stations communicate directly with other wireless stations


3. Set up “DTIM period” and “Fragmentation Threshold”, “Listen Interval”, “RTS Threshold” in advanced tab if you need, and then click “OK” button. Then, you can see “Do you want to restart your computer now?” window. Click "Yes" button and then your computer will restart to set up your adapter card. (Recommend Cold booting. Some Desk top cannot load PNP Bios when warm booted.)



Windows NT Setup


The Network setting for Windows NT is as follows;

1. First, insert the MagicWave Adapter card in the empty slot, you should turn on PC.
After booting of the PC, click “Start”, ”Settings” and “Control Panel”.




2. When select the “Network” icon a network windows shown as below.


You can change the “Computer Name” and “Workgroup” after click the “Change” button.




3. Select “Adapter” tab, click the “Have Disk..” button as below picture.




4. Insert the provided disk “Install Diskette” and specify the path “A:\” in blank field as below picture and click “OK”.




5. If the location of the DRIVER is set normally, you can see the following picture.
Select the card type (ISA or PCMCIA) and click “OK” button.




6. Set each parameter (I/O Base, IRQ Level, ESS ID...) to proper value for your computer.
Click the “OK” button if the setting is complete.




7. Select the “Bindings” and set up the items that you want.




8. Select “TCP/IP protocol” in the “Protocols” tab, and click the “Properties...”.




9. In the “IP Address” tab, sets up each parameter (IP Address, Subnet Mask, Default Gateway) suitable for your environment of the network (Request from your network administrator).



10. In the “DNS” tab, set up each parameter.




11. Select the “WINS Address” and set up each parameter.




12. After select the “Routing” checking enable use IP Forwarding or not.

Click the “OK” button, and then the setting of the TCP/IP Protocol Properties are completed.



13. Click the “Close” button, appear message that “Do you want to restart your computer now?”. If you click the “OK” button the PC is going to restart.




4. Access Point installation Guide and Manual

Access Point Setup

In order to connect SWL-1000AP with the established ethernet to build an infrastructure network, you must modify the CONFIG in the Access Point using a PC and a Null Modem Cable.

Installation can be done easily as follows;


1. Link the PC serial port and the AP serial port with Null Modem Cable, and ethernet connection can be made either via the Coax (10Base 2) or RJ45 (10Base T) connector.
2. Insert the SWL-1000AP into the PCMCIA slot of the Access Point.
3. Plug the power cord into the socket on the back of the AP.
4. All the LEDs will on and off, if the “alert” LED remains on it indicates an error condition.
5. The sequence is as shown in the following picture, select “Start -> Programs -> Accessories -> Hyper Terminal “




6. If there is no “HYPER TERMINAL” in the “Accessories” you must reinstall “Windows Setup” as follows;
“ Control Panel -> Add/Remove Programs -> Windows Setup -> Communications -> Hyperterminal”.

After rebooting the PC, try it again #5 status.


7. Double click the “Hypertrm”




8. Fill the “Name” item with the wanted Name and click “OK” button



9. Select the “Direct to Com 1” at the “Connect using” item.




10. The “Port Settings” are same as the following picture Bits per second = 9600,
Data bits = 8, Parity = None, Stop bits = 1 and Flow control = None.




11. Click the “OK” button, you can see the next initial figure and if the connection is performed.

There is shown “9600-8-N-1” message on the status bar.



Modify CONFIG.TXT



1. Password is preset to “default”.
2. In order to identify the CONFIG, you write in “config” and press the ENTER key.
3. For getting help about commander just type “help”.
4. You can modify the environment using the SET command.

As follows;

CMD: set ESSID magicwave (Group Name)

CMD: set AP_name WLAN_AP (Access Point Name)

CMD: set channel 1 (RF channel)

CMD: set IP_address 123.45.67.8 (origin IP of the AP)

CMD: set gateway 123.45.67.1

CMD: set mode structurenet

CMD: set Telnet on / off (for telnet connection)

CMD: set Web on / off (for http connection)

CMD: set standard on (for interoperability)

5. After all the parameters are change as you want, executes “restart” command .

Null Modem Cable Configuration

9 pin female connector

pin 5	<=====>	pin 5	< Ground - Ground >
pin 3	<=====>	pin 2	< Transmit - Receive >
pin 7	<=====>	pin 8	< RTS - CTS >
pin 6	<=====>	pin 4	< DSR - DTR >
pin 2	<=====>	pin 3	< Receive - Transmit >
pin 8	<=====>	pin 7	< CTS - RTS >
pin 4	<=====>	pin 6	< DTR - DSR >

Parameter Descriptions

The available parameters are described below. Some parameters can be ignored but are assigned by default values.

◆ RADIO RELATED

channel : This field specifies the operating channel for the SWL-1000AP.(The SWL-1000AP allows from 1 to 13 but the channels used by adjacent AP should be apart by more than 5 channels)

RTS_threshold : This field determines the size of RTS(Request-To-Send)/CTS(Clear-To-Send) frames and the frames to be used.

Default : 2301

shot_retry : This field specifies the number of the transmission of RTS/CTS which will be attempted before aborting when the communication between clients is interfered. Note that RTS/CTS are delivered back and forth between the clients to monitor the channel for the possibility of communications.

Default : 15

long_retry : This field specifies the number of trials of the data transmission when the channel or a client causes the cease of data transmissions.

Default : 15

Standard : This field is used for interoperability between multiple IEEE802.11 venders.

Default : off

◆ ACCESS POINT FEATURES

ssid : This field is used to name that wireless LAN group when in StructureNet mode. Its value must be the same as that of clients. So if the roaming is to be supported, the value of ESS_ID of all the AP should be the same.

Default : wlan

ap_name : This field is a string up to 9 letters and is used to give the SWL-1000AP an identifier name. This is useful if you have multiple AP on a network for roaming. In this case the ssid for all the AP is the same but you can assign a different “ap_name” to each AP.

Default : LocalAP

mode : This field specifies the operating mode of the units. Insert the “Instawave” for <Ad-hoc> and the “StructureNet” for <Infrastructure>.

Default : Instawave

protocol : The normal mode of the AP is to pass all protocols. In this case the value of default of protocol should be “all”. If your wireless stations only use TCP/IP protocol you can set the value of protocols to “TCP/IP”. In this case non TCP/IP messages are not passed by the AP.

◆ TCP/IP PARAMETERS

IP_address : This field is used to assign a TCP/IP address to the AP and needed when a user manages the AP by TELNET or uses web manager utilities. A user can access a manage program for the AP by putting in the assigned IP address on TELNET or WEB BROWSER.

subnet_mask : This field is used to define the TCP/IP sub-net mask. This field should be set if you plan to use the built in management features of the AP.

Default : 255.255.255.0

gateway : This field is needed to connect to an external network by using the TCP/IP protocol. SWL-1000AP stores all the IP addresses received from TCP/IP ARP (Address Resolution Protocol) message. If the destination is an IP address instead of a local network, the packets are sent to a gateway.

Default : 0.0.0.0 (no gateway)

◆ MANAGEMENT FUNCTIONS

password : This field allows the manager to define the password used by the Command Line Manager before they can enter commands.

Default : “default”

telnet : This field enables or disables the built TELNET management capability. This field will not affect a terminal attached via the serial port, which is always enabled when a terminal is attached. Acceptable values for the field are “on” and “off”.

Default : on

web : This field enables or disables the built in web management utility. Acceptable values for the field are “on” and “off”.

Default : on

◆ DIAGNOSTIC METHOD

1. When the “power” LED of the Access Point is not illuminates.


- ☛ Make sure that the power cord is fully seated in the socket on the rear panel of the unit.

2. When the “alert” LED continuous illuminates or blinks.

- ☛ Check the states of the radio card (SWL-1000N) installed in the Access Point.
- ☛ Make sure the POWER reconnect (OFF/ON again). Operations are not incorrect continuously, please contact your local service center or the retailer where you purchased the units.

5. Management Utilities (Web, Telnet)

Management Utility (Main Screen = <http://166.79.60.26>)



In order to view the web management page, start your web browser and click on the “address” or “URL” field, simply enter the IP address of the Access Point.

On most browsers the screen will refresh with the latest information every 10 seconds. With IE4.0 you can stop the auto refresh by clicking on the “Stop” button of the browser.

- **Time** : The current time as set in the SWL-1000AP
- **Access Point Name** : The “AP_name” parameter of the SWL-1000AP.
- **Wireless Network Status** : If the radio is operating normally the field will show “Up”. If there is a problem with the radio, or no radio installed, the field will show “Down”.
- **Number Associated Wireless Stations** : This shows how many wireless stations are currently connected to the access point.
- **LAN Network status** : This field will show “TP” when the Twisted Pair (10baseT) connection is operation. Otherwise it will show “Coax”.


There are several Hyperlinks on the web page. Theses act just like conventional Hyperlinks and may take the browser to other web pages

1. **Wireless/LAN**: These sections provide access to the network status screens showing a

summary of the current active wireless and wired LAN devices.

2. **Configurations:** The configuration section displays the current configuration and allows access to a screen for updating the configuration.
3. **Statistics:** This section of the web manager provides information and operating statistics for access point and radio functions

Statistics Screen (Statistics Screen =<http://166.79.60.26/stats.htm>)




Statistics last cleared	Sun, 8 Jan 2000 02:52:53	
Seconds Accumulated	3442	
	Last 10 Sets	Accumulated
Air Transmit Statistics		
Frames Transmitted	71	50260
Bytes Transmitted	20301	10902609
Failed Transmits	0	3
Air Receive Statistics		
Frames Received	32	27725
Data Frames Recd	23	17710
Data Bytes Recd	2000	1600068
MAC Mgmt Frames Recd	3	248
Frames Discarded	0	5
LAN Transmit Statistics		
Frames Transmitted	5	11091
Bytes Transmitted	414	1415379
LAN Receive Statistics		
Total Frames Seen	130	172236
Frames Accepted	110	162634
Data Bytes Recd	13902	26841401

The statistics screen shows accumulated traffic information. Two columns are shown: “last 10 seconds” and, “accumulated”. Traffic statistics are collected and updated every 10 seconds. The “last 10 seconds” display shows the last 10 second collection period (the may not be precisely the 10 seconds before the screen is refreshed). The screen will automatically update every 10 seconds

The meaning of the fields is given in the following table:

<i>Field Name</i>	<i>Description</i>
Air Transmit Statistics	
Frames Transmitted	The count of frames transmitted on the wireless medium. This does not count retry frames - if a frame is sent twice.
Bytes Transmitted	The number of bytes contained in the frames that have been transmitted.
Failed Transmits	The number of frames which could not be transmitted.
Air Receive Statistics	
Frames Received	The number of frames of all types received by the Access Point from the radio.
Data Frames Received	The number of frames received from the radio which are data frames (as opposed to management frames etc).
Data Bytes Received	The number of bytes contained in the data frames received.
MAC Management Frames Received	The number of frames received such as IEEE802.11 beacons or association requests.
Frames Discarded	The count of frames which were discarded, because of duplicate rejection or because of buffer overflow.
LAN Transmit Statistics	
Frames Transmitted	The number of frames transmitted from the Access Point to the Ethernet LAN.
Bytes Transmitted	The number of bytes in the frames transmitted.
LAN Receive Statistics	
Total Frame Seen	The number of frames seen on the LAN
Frames Accepted	The number of frames accepted by the Access Point.
Data Bytes Received	The count of bytes contained in frames accepted by the AP.
Frames Discarded	Frames which were discarded because of a problem. This could be bad CRC, or buffer overflow.

Configuration Screen (Configuration Screen = <http://166.79.60.26/config.htm>)



The configuration screen gives a view of the currently loaded configuration.

Type correct password and click “Edit Configuration” button, You can edit configure with Web.

Wireless/LAN Screen (Station Screen = <http://166.79.60.20/tables0000.htm>)

Home

Access Point Bridge Table Report

SAMSUNG

MAC addresses known (total) : 80

Current Index: 00000

NEXT

ALL WIRELESS
LOCAL WIRELESS
ALL LAN

Station ID	IP Address	Status	Channel	AP Serving	Power Mode
0000F09403F0	166.79.60.179	Associated	4	This Unit	Active
0000F0940152	166.79.60.142	Disconnected	4	Not known	Active
0000F0950191	166.79.60.25	Associated	4	This Unit	Active
0000F09401D0	166.79.60.141	Associated	4	This Unit	Active
0000F0940195	166.79.60.101	Disconnected	4	Not known	Active
0000F0940594	166.79.60.245	Associated	4	This Unit	Active
0000F09403E6	166.79.60.239	Associated	4	This Unit	Save
0000F0940495	----	Disconnected	4	Not known	Save
----	----	-----	---	---	-----
----	----	-----	---	---	-----
----	----	-----	---	---	-----
----	----	-----	---	---	-----
----	----	-----	---	---	-----
----	----	-----	---	---	-----
----	----	-----	---	---	-----
----	----	-----	---	---	-----
----	----	-----	---	---	-----
----	----	-----	---	---	-----
----	----	-----	---	---	-----
----	----	-----	---	---	-----
----	----	-----	---	---	-----

Done

Internet 2000

This station screen allows the manager to see which wireless stations are currently active on the Access Point (Wireless) and Wired LAN (LAN). The screen shows up to 18 stations at a time. Therefore, The “NEXT” Hyperlink is causes the screen to be re-displayed showing the next 18 stations in the list and press the “PREV” Hyperlink will be shown allowing the option to go back to the previous 18 stations in the display.

The Hyperlinks labeled as following displayed in this screen :

1. “All wireless” stations known by the Access Point including those associated with other Access Points.
2. “Local wireless” stations which are associated with this access point.
3. “All LAN” stations which have been seen on the Ethernet LAN.

<i>Field Name</i>	<i>Description</i>
Station ID	This is the NID (Network ID) or the name of the station if set. The name is obtained from the NID name table.
IP Address	The IP address of the station (if known)
Status	“Associated” means that the station is associated with this Access Point.
	“Disconnected” means that the station is not associated with this AP could however, be associated with another AP.
	“Detected” means that frames from the station have been seen but, that it has not been associated.
	“Bridged” entries are wired stations that are reached through a different Access Point than the current displayed one.
	“Is Bridging” are Access Points detected over the air. These other Access Points provide for wireless bridging between two separate LAN segments.
	“Local AP” means that it is another AP on the same LAN. This entry will be seen where roaming is implemented.
Channel	The radio channel of the station.
AP Serving	If the station is associated the words “This Unit” will appear. Otherwise the NID or name of the Access Point to which the station is associated will be shown.
Power Mode	If the station supports “Power Save Poll” mode of IEEE802.11, this field will indicate that power saving is active with the word “On”.

As for the other screens it is necessary to click “refresh” or “reload” to get updated information.


TELNET Command Manager

The SWL-1000AP provides a “telnet” terminal session to the IP address of the Access Point.

Typing the command “telnet 166.79.60.26” in the DOS windows, and the TELNET utility is launched as below figure.

The IP address is the address of the destination Access Point.

The password is “default”.



```
Telnet - 166.79.60.26
Connect Edit Terminal Help
Password:*****
OK
CMD:config
=====Current Config =====
ESSID: test1
AP_name: WLAN_AP
channel: 4
Regulatory domain: USA
IP_address: 166.79.60.26
gateway: 166.79.60.1
subnet_mask: 255.255.255.0
RTS_threshold: 2301
short_retry: 15
long_retry: 15
SIFS_time: default
Protocols: all
mode: Structurenet
Telnet: On Web: On
Security lock: off
Standard: On
TFTP: On
Admission: All
Radio NID: 0000F0640376
Management NID: 00E003800265
CMD:
```

The user may enter commands in the general format:

Command parameter1 parameter2 ...

The available commands for the command line monitor are:

Help	Bridge	Traceon	Traceoff
Trace	Tracelp	Traceclr	Config
Ping	Stats	Time	Settime
Setdate	version	Set	nid
Logout	Restart		

--List of frequently used commands

◆ Help Command

A summary of commands can be obtained by typing the command “help”.

◆ Show Command

The “show” command allows inspection of the bridge table in the Access Point.

This displays information similar to the “stations” screen of the web interface.

1. “**Show G**” ; list of all known computers which are attached via the LAN port.
2. “**Bridge S**” ; list of all wireless stations.
3. “**Show A**” ; list of all devices via the radio link.

The result of the command is list providing the following information.

- **Net ID** : IEEE network address of the device.
- **State** : Current relationship of device with AP (Associated, Disconnected, Detected, is bridging, bridged, Local AP, Unknown).
- **Channel** : Radio channel.
- **Current AP** : The Access Point with which the unit is associated.
- **IP address** : IP address of the device.

◆ System Commands

- **Time** Print current data and time of last re-initialization.
- **Settime** Set the system time.
Format is “settime HH(hours):MM(minutes):SS(seconds)”.
- **Setdate** Set the system date.
Format is “setdate MM(month):DD(date):YY(year)”.
- **Config** Displays the current system settings for configuration. Note that if a configuration change has been made which requires a system restart to take effect, both the old and the new values will be shown.
- **Stats** The Stats command prints traffic statistics. Statistics are displayed for the last 10 second interval and cumulative since last cleared.
The cumulative total can be cleared by the command “stats c”.
- **Logout** After this command has been issued the user must re-enter the password

before any more commands can be issued.

- **Version** This command prints version information about the Access Point software.
- **Restart** This command causes the SWL-1000AP to perform a reinitialization.

◆ **Ping Command**

- **Ping** The ping command causes the Access Point to issue an ICMP Echo request

(PING) to the specified IP address.


The format of the command is : “ping 123.45.67.89”.

Where 123.45.67.89 is the destination IP address.


MagicWave Adapter Card Setup

As method of Network environment setting, you can see “SAMSUNG Wireless LAN Card” at the “Network” window in the “Control Panel”.

This component means that MagicWave adapter card (SWL-1000N or 1000D) is correctly working. As selecting this component, you can change into the desired value.




1. Click the “Properties” and then “SAMSUNG Wireless LAN Card Properties” window appear. Click “Operating Mode” tab and type desired ESS ID.



- **BSS (Extended Service Set)** : Minimum cell that composed wireless LAN.
- **ESS (Extended Service Set)** : Interconnection of BBSs to work as one BBS.
- **Instawave** : In this mode wireless stations communicate directly with each other and through compatible access point
- **StructureNet** : In this mode wireless stations communicate with wireless stations and LAN stations through a compatible Access Point
- **Peer-to-Peer** : In this mode wireless stations communicate directly with other wireless stations


3. Set up “DTIM period” and “Fragmentation Threshold”, “Listen Interval”, “RTS Threshold” in advanced tab if you need, and then click “OK” button. Then, you can see “Do you want to restart your computer now?” window. Click "Yes" button and then your computer will restart to set up your adapter card. (Recommend Cold booting. Some Desk top cannot load PNP Bios when warm booted.)



Windows NT Setup


The Network setting for Windows NT is as follows;

1. First, insert the MagicWave Adapter card in the empty slot, you should turn on PC.
After booting of the PC, click “Start”, ”Settings” and “Control Panel”.




2. When select the “Network” icon a network windows shown as below.


You can change the “Computer Name” and “Workgroup” after click the “Change” button.




3. Select “Adapter” tab, click the “Have Disk..” button as below picture.




4. Insert the provided disk “Install Diskette” and specify the path “A:\” in blank field as below picture and click “OK”.




5. If the location of the DRIVER is set normally, you can see the following picture.
Select the card type (ISA or PCMCIA) and click “OK” button.




6. Set each parameter (I/O Base, IRQ Level, ESS ID...) to proper value for your computer.
Click the “OK” button if the setting is complete.




7. Select the “Bindings” and set up the items that you want.




8. Select “TCP/IP protocol” in the “Protocols” tab, and click the “Properties...”.




9. In the “IP Address” tab, sets up each parameter (IP Address, Subnet Mask, Default Gateway) suitable for your environment of the network (Request from your network administrator).



10. In the “DNS” tab, set up each parameter.




11. Select the “WINS Address” and set up each parameter.




12. After select the “Routing” checking enable use IP Forwarding or not.

Click the “OK” button, and then the setting of the TCP/IP Protocol Properties are completed.



13. Click the “Close” button, appear message that “Do you want to restart your computer now?”. If you click the “OK” button the PC is going to restart.




4. Access Point installation Guide and Manual

Access Point Setup

In order to connect SWL-1000AP with the established ethernet to build an infrastructure network, you must modify the CONFIG in the Access Point using a PC and a Null Modem Cable.

Installation can be done easily as follows;


1. Link the PC serial port and the AP serial port with Null Modem Cable, and ethernet connection can be made either via the Coax (10Base 2) or RJ45 (10Base T) connector.
2. Insert the SWL-1000AP into the PCMCIA slot of the Access Point.
3. Plug the power cord into the socket on the back of the AP.
4. All the LEDs will on and off, if the “alert” LED remains on it indicates an error condition.
5. The sequence is as shown in the following picture, select “Start -> Programs -> Accessories -> Hyper Terminal “




6. If there is no “HYPER TERMINAL” in the “Accessories” you must reinstall “Windows Setup” as follows;
“ Control Panel -> Add/Remove Programs -> Windows Setup -> Communications -> Hyperterminal”.

After rebooting the PC, try it again #5 status.


7. Double click the “Hypertrm”




8. Fill the “Name” item with the wanted Name and click “OK” button



9. Select the “Direct to Com 1” at the “Connect using” item.




10. The “Port Settings” are same as the following picture Bits per second = 9600,
Data bits = 8, Parity = None, Stop bits = 1 and Flow control = None.




11. Click the “OK” button, you can see the next initial figure and if the connection is performed.

There is shown “9600-8-N-1” message on the status bar.



Modify CONFIG.TXT



1. Password is preset to “default”.
2. In order to identify the CONFIG, you write in “config” and press the ENTER key.
3. For getting help about commander just type “help”.
4. You can modify the environment using the SET command.

As follows;

CMD: set ESSID magicwave (Group Name)

CMD: set AP_name WLAN_AP (Access Point Name)

CMD: set channel 1 (RF channel)

CMD: set IP_address 123.45.67.8 (origin IP of the AP)

CMD: set gateway 123.45.67.1

CMD: set mode structurenet

CMD: set Telnet on / off (for telnet connection)

CMD: set Web on / off (for http connection)

CMD: set standard on (for interoperability)

5. After all the parameters are change as you want, executes “restart” command .

Null Modem Cable Configuration

9 pin female connector

pin 5	<=====>	pin 5	< Ground - Ground >
pin 3	<=====>	pin 2	< Transmit - Receive >
pin 7	<=====>	pin 8	< RTS - CTS >
pin 6	<=====>	pin 4	< DSR - DTR >
pin 2	<=====>	pin 3	< Receive - Transmit >
pin 8	<=====>	pin 7	< CTS - RTS >
pin 4	<=====>	pin 6	< DTR - DSR >

Parameter Descriptions

The available parameters are described below. Some parameters can be ignored but are assigned by default values.

◆ RADIO RELATED

channel : This field specifies the operating channel for the SWL-1000AP.(The SWL-1000AP allows from 1 to 13 but the channels used by adjacent AP should be apart by more than 5 channels)

RTS_threshold : This field determines the size of RTS(Request-To-Send)/CTS(Clear-To-Send) frames and the frames to be used.

Default : 2301

shot_retry : This field specifies the number of the transmission of RTS/CTS which will be attempted before aborting when the communication between clients is interfered. Note that RTS/CTS are delivered back and forth between the clients to monitor the channel for the possibility of communications.

Default : 15

long_retry : This field specifies the number of trials of the data transmission when the channel or a client causes the cease of data transmissions.

Default : 15

Standard : This field is used for interoperability between multiple IEEE802.11 venders.

Default : off

◆ ACCESS POINT FEATURES

essid : This field is used to name that wireless LAN group when in StructureNet mode. Its value must be the same as that of clients. So if the roaming is to be supported, the value of ESS_ID of all the AP should be the same.

Default : wlan

ap_name : This field is a string up to 9 letters and is used to give the SWL-1000AP an identifier name. This is useful if you have multiple AP on a network for roaming. In this case the essid for all the AP is the same but you can assign a different “ap_name” to each AP.

Default : LocalAP

mode : This field specifies the operating mode of the units. Insert the “Instawave” for <Ad-hoc> and the “StructureNet” for <Infrastructure>.

Default : Instawave

protocol : The normal mode of the AP is to pass all protocols. In this case the value of default of protocol should be “all”. If your wireless stations only use TCP/IP protocol you can set the value of protocols to “TCP/IP”. In this case non TCP/IP messages are not passed by the AP.

◆ TCP/IP PARAMETERS

IP_address : This field is used to assign a TCP/IP address to the AP and needed when a user manages the AP by TELNET or uses web manager utilities. A user can access a manage program for the AP by putting in the assigned IP address on TELNET or WEB BROWSER.

subnet_mask : This field is used to define the TCP/IP sub-net mask. This field should be set if you plan to use the built in management features of the AP.

Default : 255.255.255.0

gateway : This field is needed to connect to an external network by using the TCP/IP protocol. SWL-1000AP stores all the IP addresses received from TCP/IP ARP (Address Resolution Protocol) message. If the destination is an IP address instead of a local network, the packets are sent to a gateway.

Default : 0.0.0.0 (no gateway)

◆ MANAGEMENT FUNCTIONS

password : This field allows the manager to define the password used by the Command Line Manager before they can enter commands.

Default : “default”

telnet : This field enables or disables the built TELNET management capability. This field will not affect a terminal attached via the serial port, which is always enabled when a terminal is attached. Acceptable values for the field are “on” and “off”.

Default : on

web : This field enables or disables the built in web management utility. Acceptable values for the field are “on” and “off”.

Default : on

◆ DIAGNOSTIC METHOD

3. When the “power” LED of the Access Point is not illuminates.


- ☛ Make sure that the power cord is fully seated in the socket on the rear panel of the unit.

4. When the “alert” LED continuous illuminates or blinks.

- ☛ Check the states of the radio card (SWL-1000N) installed in the Access Point.
- ☛ Make sure the POWER reconnect (OFF/ON again). Operations are not incorrect continuously, please contact your local service center or the retailer where you purchased the units.

5. Management Utilities (Web, Telnet)

Management Utility (Main Screen = <http://166.79.60.26>)



In order to view the web management page, start your web browser and click on the “address” or “URL” field, simply enter the IP address of the Access Point.

On most browsers the screen will refresh with the latest information every 10 seconds. With IE4.0 you can stop the auto refresh by clicking on the “Stop” button of the browser.

- **Time** : The current time as set in the SWL-1000AP
- **Access Point Name** : The “AP_name” parameter of the SWL-1000AP.
- **Wireless Network Status** : If the radio is operating normally the field will show “Up”. If there is a problem with the radio, or no radio installed, the field will show “Down”.
- **Number Associated Wireless Stations** : This shows how many wireless stations are currently connected to the access point.
- **LAN Network status** : This field will show “TP” when the Twisted Pair (10baseT) connection is operation. Otherwise it will show “Coax”.


There are several Hyperlinks on the web page. Theses act just like conventional Hyperlinks and may take the browser to other web pages

4. **Wireless/LAN**: These sections provide access to the network status screens showing a

summary of the current active wireless and wired LAN devices.

5. **Configurations:** The configuration section displays the current configuration and allows access to a screen for updating the configuration.
6. **Statistics:** This section of the web manager provides information and operating statistics for access point and radio functions

Statistics Screen (Statistics Screen =[http: 166.79.60.26/stats.htm](http://166.79.60.26/stats.htm))




Access Point Statistics		
Statistics last cleared: Sun, 8 Jan 2000 02:52:53		
Seconds Accumulated: 3442		
	Last 10 Sets	Accumulated
Air Transmit Statistics		
Frames Transmitted	71	50260
Bytes Transmitted	23301	13992609
Failed Transmits	0	3
Air Receive Statistics		
Frames Received	32	27725
Data Frames Recd	23	17710
Data Bytes Recd	2800	168068
MAC Mgmt Frames Recd	3	248
Frames Discarded	0	5
LAN Transmit Statistics		
Frames Transmitted	5	11091
Bytes Transmitted	414	1415379
LAN Receive Statistics		
Total Frames Seen	130	172239
Frames Accepted	110	162634
Data Bytes Recd	13902	26841401

The statistics screen shows accumulated traffic information. Two columns are shown: “last 10 seconds” and, “accumulated”. Traffic statistics are collected and updated every 10 seconds. The “last 10 seconds” display shows the last 10 second collection period (the may not be precisely the 10 seconds before the screen is refreshed). The screen will automatically update every 10 seconds

The meaning of the fields is given in the following table:

<i>Field Name</i>	<i>Description</i>
Air Transmit Statistics	
Frames Transmitted	The count of frames transmitted on the wireless medium. This does not count retry frames - if a frame is sent twice.
Bytes Transmitted	The number of bytes contained in the frames that have been transmitted.
Failed Transmits	The number of frames which could not be transmitted.
Air Receive Statistics	
Frames Received	The number of frames of all types received by the Access Point from the radio.
Data Frames Received	The number of frames received from the radio which are data frames (as opposed to management frames etc).
Data Bytes Received	The number of bytes contained in the data frames received.
MAC Management Frames Received	The number of frames received such as IEEE802.11 beacons or association requests.
Frames Discarded	The count of frames which were discarded, because of duplicate rejection or because of buffer overflow.
LAN Transmit Statistics	
Frames Transmitted	The number of frames transmitted from the Access Point to the Ethernet LAN.
Bytes Transmitted	The number of bytes in the frames transmitted.
LAN Receive Statistics	
Total Frame Seen	The number of frames seen on the LAN
Frames Accepted	The number of frames accepted by the Access Point.
Data Bytes Received	The count of bytes contained in frames accepted by the AP.
Frames Discarded	Frames which were discarded because of a problem. This could be bad CRC, or buffer overflow.

Configuration Screen (Configuration Screen = <http://166.79.60.26/config.htm>)



The configuration screen gives a view of the currently loaded configuration.

Type correct password and click “Edit Configuration” button, You can edit configure with Web.

Wireless/LAN Screen (Station Screen = <http://166.79.60.20/tables0000.htm>)

Home

Access Point Bridge Table Report

SAMSUNG

MAC addresses known (total) : 80

Current Index
00000

NEXT

ALL WIRELESS
LOCAL WIRELESS
ALL LAN

Station ID	IP Address	Status	Channel	AP Serving	Power Mode
0000F09403F0	166.79.60.179	Associated	4	This Unit	Active
0000F0940152	166.79.60.142	Disconnected	4	Not known	Active
0000F0950191	166.79.60.25	Associated	4	This Unit	Active
0000F09401D0	166.79.60.141	Associated	4	This Unit	Active
0000F0940195	166.79.60.101	Disconnected	4	Not known	Active
0000F0940594	166.79.60.245	Associated	4	This Unit	Active
0000F09403E6	166.79.60.239	Associated	4	This Unit	Save
0000F0940495	----	Disconnected	4	Not known	Save
----	----	-----	----	----	-----
----	----	-----	----	----	-----
----	----	-----	----	----	-----
----	----	-----	----	----	-----
----	----	-----	----	----	-----
----	----	-----	----	----	-----
----	----	-----	----	----	-----
----	----	-----	----	----	-----
----	----	-----	----	----	-----
----	----	-----	----	----	-----
----	----	-----	----	----	-----
----	----	-----	----	----	-----
----	----	-----	----	----	-----
----	----	-----	----	----	-----

Done

Internet 2008

This station screen allows the manager to see which wireless stations are currently active on the Access Point (Wireless) and Wired LAN (LAN). The screen shows up to 18 stations at a time. Therefore, The “NEXT” Hyperlink is causes the screen to be re-displayed showing the next 18 stations in the list and press the “PREV” Hyperlink will be shown allowing the option to go back to the previous 18 stations in the display.

The Hyperlinks labeled as following displayed in this screen :

4. “All wireless” stations known by the Access Point including those associated with other Access Points.
5. “Local wireless” stations which are associated with this access point.
6. “All LAN” stations which have been seen on the Ethernet LAN.

<i>Field Name</i>	<i>Description</i>
Station ID	This is the NID (Network ID) or the name of the station if set. The name is obtained from the NID name table.
IP Address	The IP address of the station (if known)
Status	“Associated” means that the station is associated with this Access Point.
	“Disconnected” means that the station is not associated with this AP could however, be associated with another AP.
	“Detected” means that frames from the station have been seen but, that it has not been associated.
	“Bridged” entries are wired stations that are reached through a different Access Point than the current displayed one.
	“Is Bridging” are Access Points detected over the air. These other Access Points provide for wireless bridging between two separate LAN segments.
	“Local AP” means that it is another AP on the same LAN. This entry will be seen where roaming is implemented.
Channel	The radio channel of the station.
AP Serving	If the station is associated the words “This Unit” will appear. Otherwise the NID or name of the Access Point to which the station is associated will be shown.
Power Mode	If the station supports “Power Save Poll” mode of IEEE802.11, this field will indicate that power saving is active with the word “On”.

As for the other screens it is necessary to click “refresh” or “reload” to get updated information.


TELNET Command Manager

The SWL-1000AP provides a “telnet” terminal session to the IP address of the Access Point.

Typing the command “telnet 166.79.60.26” in the DOS windows, and the TELNET utility is launched as below figure.

The IP address is the address of the destination Access Point.

The password is “default”.



```
Telnet - 166.79.60.26
Connect Edit Terminal Help
Password:*****
OK
CMD:config
=====Current Config =====
ESSID: test1
AP_name: WLAN_AP
channel: 4
Regulatory domain: USA
IP_address: 166.79.60.26
gateway: 166.79.60.1
subnet_mask: 255.255.255.0
RTS_threshold: 2301
short_retry: 15
long_retry: 15
SIFS_time: default
Protocols: all
mode: Structurenet
Telnet: On Web: On
Security lock: off
Standard: On
TFTP: On
Admission: All
Radio NID: 0000F0640376
Management NID: 00E003800265
CMD:
```

The user may enter commands in the general format:

Command parameter1 parameter2 ...

The available commands for the command line monitor are:

Help	Bridge	Traceon	Traceoff
Trace	Tracelp	Traceclr	Config
Ping	Stats	Time	Settime
Setdate	version	Set	nid
Logout	Restart		

--List of frequently used commands

◆ Help Command

A summary of commands can be obtained by typing the command “help”.

◆ Show Command

The “show” command allows inspection of the bridge table in the Access Point.

This displays information similar to the “stations” screen of the web interface.

4. “**Show G**” ; list of all known computers which are attached via the LAN port.
5. “**Bridge S**” ; list of all wireless stations.
6. “**Show A**” ; list of all devices via the radio link.

The result of the command is list providing the following information.

- **Net ID** : IEEE network address of the device.
- **State** : Current relationship of device with AP (Associated, Disconnected, Detected, is bridging, bridged, Local AP, Unknown).
- **Channel** : Radio channel.
- **Current AP** : The Access Point with which the unit is associated.
- **IP address** : IP address of the device.

◆ System Commands

- **Time** Print current data and time of last re-initialization.
- **Settime** Set the system time.
Format is “settime HH(hours):MM(minutes):SS(seconds)”.
- **Setdate** Set the system date.
Format is “setdate MM(month):DD(date):YY(year)”.
- **Config** Displays the current system settings for configuration. Note that if a configuration change has been made which requires a system restart to take effect, both the old and the new values will be shown.
- **Stats** The Stats command prints traffic statistics. Statistics are displayed for the last 10 second interval and cumulative since last cleared.
The cumulative total can be cleared by the command “stats c”.
- **Logout** After this command has been issued the user must re-enter the password

before any more commands can be issued.

- **Version** This command prints version information about the Access Point software.
- **Restart** This command causes the SWL-1000AP to perform a reinitialization.

◆ **Ping Command**

- **Ping** The ping command causes the Access Point to issue an ICMP Echo request

(PING) to the specified IP address.

The format of the command is : “ping 123.45.67.89”.

Where 123.45.67.89 is the destination IP address.