

Installation and Operation Manual

Powerwave[®]
technologies
THE POWER IN WIRELESS[™]

*Power Amplifier Radio Module (PARM),
869-894 MHz, 40/30-Watt*



© 2005 Powerwave Technologies Incorporated. All rights reserved.

Powerwave Technologies, and the Powerwave logo are registered trademarks.

Powerwave Technologies, Inc. reserves the right to make changes to the documentation and equipment, including but not limited to component substitution and circuitry changes. Changes that impact this manual may subsequently be incorporated in a later revision of this manual.

This Powerwave product is designed to operate within the Normal Operating (typical operating) ranges or conditions specified in this document. Operation of this equipment beyond the specified ranges in this document may cause (1) spurious emissions that violate regulatory requirements; (2) the equipment to be automatically removed from service when maximum thresholds are exceeded; or (3) the equipment to not perform in accordance with its specifications. It is the Operator's responsibility to ensure this equipment is properly installed and operated within Powerwave operating specifications to obtain proper performance from the equipment and to comply with regulatory requirements.

January 2005

**Powerwave Technologies, Inc.
1801 E. St. Andrew Place
Santa Ana, CA 92705**

**Tel: (714) 466-1000
(888) 797-9283
Fax: (714) 466-5800
Web Site: www.powerwave.com**

Chapter 1 General Description

1-1 Introduction

This manual contains general information, installation procedures, and specifications for the operation and use of the Power Amplifier Radio Module (PARM). The manual is organized as follows:

- Chapter 1 General Description with Specifications
- Chapter 2 Installation and Operation

1-2 General Description

The PARM is designed as an integrated subassembly unit mounted in a Radio Module (RM) closed metal housing fitted with a heat sink and connected by RF coaxial and DC connectors. The PARM use a common DC/DC converter for operating power. Up to three PARM can be mounted in one RM.

The PARM's basic function is amplifying 25 MHz band modulated RF input signals (869-894 MHz) from the TX driver subassembly, up to the level of the whole transmitter, as defined in GSM 05.05, class 1 (20 watts minimum and 40 watts maximum). The main characteristics of the PARM are:

- GMSK compliant
- 8-PSK compliant

The PARM is rated for an average output power of 40/30 watts with an EDGE signal and 40/30 watts with a GMSK signal. The electrical specifications are also designed to be in compliance with the requirements of GSM 05.05.

1-3 Specifications

Specifications for the PARM are listed and described in table 1-1.

Table 1-1 PARM Operating Specifications

Frequency Range	869 - 894 MHz (25 MHz Bandwidth)
Total Typical / Maximum Input Power	-15.7 - +4.8 / +5.8 dBm
Average Output Power	40/30 Watts (46.02/44.8 dBm)
RF Gain	39 - 48 dB
Duty Cycle	Continuous
DC Operating Voltage	27 $\pm$ 2% VDC (26.46 to 27.54 VDC)
DC Operating Voltage Range	25 to 29.5 VDC
Operating Temperature	-5 °C to +60 °C
Storage Temperature	-40 °C to +85 °C
Operating Humidity	5 % to 95 % Relative Humidity (noncondensing)
Storage Humidity	0 % to 100 % Relative Humidity (noncondensing)
Alarms	See Chapter 2
RF Input Connector	MCX female, gold plated body and core
RF Output Connector	QN-type female (50 Ohm Nominal Impedence)
DC Input Connector	Samtec FHP-04-01-T-S, 8-pin (50 Ohm Nominal Impedence)
Power Consumption	94.5 Watts
Dimensions	3.75" High, .75" Wide, 6.75" Deep

Chapter 2 Installation and Operation

2-1 Introduction

This section contains operating instructions for the Power Amplifier Radio Module (PARM).

2-2 Installation

The PARM module is designed to be directly installed into the radio module.

2-2.1 Alarms Interface Connector

Pin Number	Signal	Comment
1	PA_VER_RADO	From PARM TO LRM
2	PA_VER_RAD1	From PARM TO LRM
3	PA_VER_RAD2	From PARM TO LRM
4	PA_VER_RAD3	From PARM TO LRM
5	PA_VER_RAD4	From PARM TO LRM
6	GND	
7	GND	
8	PA_ID_LDMOS0	From PARM TO LRM
9	PA_VG_LDMOS0	From LRM TO PARM
10	GND	
11	GND	
12	PA_ID_DRIVER	From PARM TO LRM
13	PA_ALA_TPTR_OUT	From PARM TO LRM
14	GND	
15	GND	
16	PA_OFF	From LRM TO PARM
17	PA_VG_LDMOS1	From LRM TO PARM
18	GND	
19	PA_ID_LDMOS1	From PARM TO LRM
20	PA_P_OUT	From PARM TO LRM

2-2.2 Alarm Descriptions

- **High Temperature** – A temperature monitor located inside the PARM indicates the alarm status if the temperature exceeds the defined threshold.
- **High Current** - This alarm indicates when a high current is pending that could damage the PARM if the system continues to operate.