

SECTION 5 ADJUSTMENT PROCEDURES

Note: [MPT] versions must use 'CS-F600' instead of 'CS-F500'.

5-1 PREPARATION

When you adjust the contents on pages 5-4 and 5-5, SOFTWARE ADJUSTMENT, the optional CS-F500 ADJ ADJUSTMENT SOFTWARE (Rev. 1.0 or later), *OPC-1122 JIG CABLE (modified OPC-1122 CLONING CABLE; see illustration below) are required.

■ SYSTEM REQUIREMENTS

- IBM PC compatible computer with an RS -232C serial port (38400 bps or faster)
- Microsoft Windows 95/98 or Windows ME
- Intel Pentium 100 MHz processor or faster
- At least 16 MB RAM and 10 MB of hard disk space
- 640x480 pixel display (800x600 pixel display recommended)

IBM is a registered trademark of International Business Machines Corporation in the U.S.A. and other countries. Microsoft and Windows are registered trademarks of Microsoft Corporation in the U.S.A. and other countries. Screen shots produced with permission from Microsoft Corporation. All other products or brands are registered trademarks or trademarks of their respective holders.


■ ADJUSTMENT SOFTWARE INSTALLATION

- ① Boot up Windows.
- Quit all applications when Windows is running.
- ② Insert the 'CS-F500' into the appropriate CD-ROM drive.
- ③ Select 'Run' from the [Start] menu.
- ④ Type the setup program name using the full path name, then push [Enter] key.
(ex. D:\CSF500ADJ\disk1\Setup.exe)
- ⑤ Follow the prompts.
- ⑥ Program group 'CS-F500 ADJ' appears in the 'Programs' folder of the [Start] menu.

■ STARTING SOFTWARE ADJUSTMENT

- ① Connect IC-F610, F620 or F621 and PC with *OPC-1122 JIG CABLE.
- ② Turn the transceiver power ON.
- ③ Boot up Windows, and click the program group 'CS-F500 ADJ' in the 'Programs' folder of the [Start] menu, then CS-F500 ADJ's window appears.
- ④ Click 'Connect' on the CS-F500's window, then appears IC-F610, F620 or F621's up-to-date condition.
- ⑤ Set or modify adjustment data as desired.


■ *OPC-1122 (JIG CABLE)



■ REQUIRED TEST EQUIPMENT

EQUIPMENT	GRADE AND RANGE	EQUIPMENT	GRADE AND RANGE
DC power supply	Output voltage : 13.2 (13.6) V DC Current capacity : 20 A or more	Audio generator	Frequency range : 300-3000 Hz Measuring range : 1-500 mV
RF power meter (terminated type)	Measuring range : 1-75 W Frequency range : 300-600 MHz Impedance : 50 Ω SWR : Less than 1.2 : 1	Standard signal generator (SSG)	Frequency range : 0.1-600 MHz Output level : 0.1 μV-32 mV (-127 to -17 dBm)
Frequency counter	Frequency range : 0.1-600 MHz Frequency accuracy : ±1 ppm or better Sensitivity : 100 mV or better	Oscilloscope	Frequency range : DC-20 MHz Measuring range : 0.01-20 V
FM deviation meter	Frequency range : DC-600 MHz Measuring range : 0 to ±10 kHz	AC millivoltmeter	Measuring range : 10 mV-10 V
DC voltmeter	Input impedance : 50 kΩ/V DC or better	External speaker	Input impedance : 4 Ω Capacity : 7 W or more
		Attenuator	Power attenuation : 50 or 60 dB Capacity : 100 W or more

- **Screen display example**




NOTE: The above values for settings are example only.

Each transceiver has its own specific values for each setting.


- | | | | |
|-------------------------------------|------------------------------|--|------------------------------------|
| ① : Transceiver's connection state | ⑤ : PLL lock voltage | ⑨ : FM deviation | ⑬ : Receive sensitivity (manually) |
| ② : Reload adjustment data | ⑥ : Operating channel select | ⑩ : CTCSS/DTCS deviation | ⑭ : Reference frequency |
| ③ : Receive sensitivity measurement | ⑦ : RF output power | ⑪ : Squelch level | ⑮ : S-meter |
| ④ : Connected DC voltage | ⑧ : Modulation balance | ⑫ : Receive sensitivity
(automatically) | ⑯ : Adjustment items |

- **Connections**




5-2 PLL ADJUSTMENT

ADJUSTMENT		ADJUSTMENT CONDITIONS	MEASUREMENT		VALUE	ADJUSTMENT	
			UNIT	LOCATION		UNIT	ADJUST
PLL LOCK VOLTAGE	1	• Operating freq. : 400.000 MHz [L] 440.000 MHz [M] 480.000 MHz [H] • Receiving	MAIN	Connect a digital multi-meter or an oscilloscope to the check point, "LV".	1.0 V	MAIN	C133
	2	• Output power : Low1 • Transmitting			1.1 V		C134
	3	• Operating freq. : 430.000 MHz [L] 490.000 MHz [M] 520.000 MHz [H] • Receiving			3.0-4.2 V [L] 3.3-4.5 V [M] 3.3-4.5 V [H]		Verify
	4	• Output power : Low1 • Transmitting					



5-3 SOFTWARE ADJUSTMENT

Select an operation using [↑] / [↓] keys, then set specified value using [←] / [→] keys on the connected computer keyboard.

ADJUSTMENT	ADJUSTMENT CONDITION	MEASUREMENT		VALUE
		UNIT	LOCATION	
REFERENCE FREQUENCY [TXF]	1 • Operating freq. : 430.000 MHz [L] 490.000 MHz [M] 520.000 MHz [H] • Output power : Low1 • Connect the RF power meter or 50 Ω dummy load to the antenna connector. • Transmitting	Rear panel	Loosely couple a frequency counter to the antenna connector.	430.0000 MHz [L] 490.0000 MHz [M] 520.0000 MHz [H]
OUTPUT POWER [Power (Hi)]	1 • Operating freq. : 400.000 MHz [L] 440.000 MHz [M] 480.000 MHz [H] • Output power : High • Transmitting	Rear panel	Connect an RF power meter to the antenna connector.	25.0 W [25W] 45.0 W [45W]
[Power (L2)]	2 • Output power : Low2 • Transmitting			10.0 W [25W] 25.0 W [45W]
[Power (L1)]	3 • Output power : Low1 • Transmitting			2.5 W [25W] 4.5 W [45W]
MODULATION BALANCE [Balance]	1 • Operating freq. : 415.000 MHz [L] 465.000 MHz [M] 500.000 MHz [H] • Output power : Low1 • Push [P0] key while transmitting	Rear panel	Connect an FM deviation meter with an oscilloscope to the antenna connector through an attenuator.	Set to square wave form 
FM DEVIATION [MOD W]	1 • Operating freq. : 415.000 MHz [L] 465.000 MHz [M] 500.000 MHz [H] • Output power : Low1 • IF bandwidth : Wide • Connect an audio generator to the [MIC] jack through the JIG cable and set as: 1.0 kHz/40 mVrms • Set an FM deviation meter as: HPF : OFF LPF : 20 kHz De-emphasis: OFF Detector : (P-P)/2 • Transmitting	Rear panel	Connect an FM deviation meter to the antenna connector through the attenuator.	±4.1 kHz [N/W] ±3.3 kHz [N/M]
[MOD N]	2 • IF bandwidth : Narrow • Transmitting			±2.1 kHz
CTCSS/DTCS DEVIATION [CTCS/DTCS]	• Operating freq. : 415.000 MHz [L] 465.000 MHz [M] 500.000 MHz [H] • Output power : Low1 • IF bandwidth : Wide • CTCSS : 88.5 Hz • DTCS code : 007 • Set the FM deviation meter as: HPF : OFF LPF : 20 kHz De-emphasis: OFF Detector : (P-P)/2 • No audio applied to the [MIC] connector. • Transmitting	Rear panel	Connect an FM deviation meter to the antenna connector through the attenuator.	±0.70 kHz [N/W] ±0.56 kHz [N/M]

SOFTWARE ADJUSTMENT – continued

Select an operation using [↑] / [↓] keys, then set specified value using [←] / [→] keys on the connected computer keyboard.

ADJUSTMENT	ADJUSTMENT CONDITION	MEASUREMENT		VALUE
		UNIT	LOCATION	
RX SENSITIVITY [BPF T1] – [BPF T4]	1 • Operating freq. : 400.000 MHz [L] 440.000 MHz [M] 480.000 MHz [H] • IF bandwidth : Wide • Connect a standard signal generator to the antenna connector and set as: Frequency : 400.000 MHz [L] 440.000 MHz [M] 480.000 MHz [H] Level : 10 μ V* (–87 dBm) Modulation : 1 kHz Deviation : $\pm$ 3.5 kHz [N/W] $\pm$ 2.8 kHz [N/M] • Receiving	MAIN	Connect a SINAD meter with a 4 Ω load to the external [SP] jack.	Minimum distortion level
	CONVENIENT: The BPF T1–BPF T4 can be adjusted automatically. ①-1: Set the cursor to "BPF ALL" on the adjustment program and then push [ENTER] key. ①-2: The connected PC tunes BPF T1–BPF T4 to peak levels. or ②-1: Set the cursor to one of BPF T1, T2, T3, or T4 as desired. ②-2: Push [ENTER] key to start tuning. ②-3: Repeat ②-1 and ②-2 to perform additional BPF tuning.			
S-METER [S-METER]	1 • Operating freq. : 400.000 MHz [L] 440.000 MHz [M] 480.000 MHz [H] • IF bandwidth : Wide • Connect an SSG to the antenna connector and set as: Frequency : 400.000 MHz [L] 440.000 MHz [M] 480.000 MHz [H] Level : 14 μ V* (–84 dBm) Modulation : 1 kHz Deviation : $\pm$ 3.5 kHz [N/W] $\pm$ 2.8 kHz [N/M] • Receiving			Push [ENTER] key on the connected computer keyboard to set "S3 level".
	2 • Set an SSG as: Level : 0.45 μ V* (–114 dBm) Modulation : 1 kHz Deviation : $\pm$ 3.5 kHz [N/W] $\pm$ 2.8 kHz [N/M] • Receiving			Push [ENTER] key on the connected computer keyboard to set "S1 level".
SQUELCH LEVEL [SQL]	1 • Operating freq. : 415.000 MHz [L] 465.000 MHz [M] 500.000 MHz [H] • IF bandwidth : Narrow • Connect an SSG to the antenna connector and set as: Frequency : 415.000 MHz [L] 465.000 MHz [M] 500.000 MHz [H] Level : 0.2 μ V* (–121 dBm) Modulation : 1 kHz Deviation : $\pm$ 1.75 kHz • Receiving	Rear panel	Connect a SINAD meter with a 4 Ω load to the external [SP] jack.	Set "SQL level" to close squelch. Then set "SQL level" at the point where the audio signals just appears.

*The output level of the standard signal generator (SSG) is indicated as the SSG's open circuit.