


snom



# M55

SIP DECT Handset

Quick Installation Guide

# Important Safety Information



This symbol is to alert you to important operating or servicing instructions that may appear on the product or in this user's manual. Always follow basic safety precautions when using this product to reduce the risk of injury, fire, or electric shock.

## Important Safety Instructions

---

When using your telephone equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury, including the following:

1. This product should be installed by a qualified technician.
2. This product should only be connected to the host equipment and never directly to the network such as Public Switch Telephone Network (PSTN) or Plain Old Telephone Services (POTS).
3. Read and understand all instructions.
4. Follow all warnings and instructions marked on the product.
5. Unplug this product from the wall outlet before cleaning. Do not use liquid or aerosol cleaners. Use a damp cloth for cleaning.
6. Do not use this product near water such as near a bath tub, wash bowl, kitchen sink, laundry tub or swimming pool, or in a wet basement or shower.
7. Do not place this product on an unstable table, shelf, stand or other unstable surfaces.
8. Slots and openings in the back or bottom of the handset are provided for ventilation. To protect them from overheating, these openings must not be blocked by placing the product on a soft surface such as a bed, sofa or rug. This product should never be placed near or over a radiator or heat register. This product should not be placed in any area where proper ventilation is not provided.
9. This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supplied at the premises, consult your dealer or local power company.
10. Do not allow anything to rest on the power cord. Do not install this product where the cord may be walked on.
11. Never push objects of any kind into this product through the slots in the handset because they may touch dangerous voltage points or create a short circuit. Never spill liquid of any kind on the product.

12. To reduce the risk of electric shock, do not disassemble this product, but take it to an authorized service facility. Opening or removing parts of the handset other than specified access doors may expose you to dangerous voltages or other risks. Incorrect reassembling can cause electric shock when the product is subsequently used.
13. Do not overload wall outlets and extension cords.
14. Unplug this product from the wall outlet and refer servicing to an authorized service facility under the following conditions:
  - A. When the power supply cord or plug is damaged or frayed.
  - B. If liquid has been spilled onto the product.
  - C. If the product has been exposed to rain or water.
  - D. If the product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operation instructions. Improper adjustment of other controls may result in damage and often requires extensive work by an authorized technician to restore the product to normal operation.
  - E. If the product has been dropped and the telephone base and/or handset has been damaged.
  - F. If the product exhibits a distinct change in performance.
15. Avoid using a telephone (other than cordless) during an electrical storm. There is a remote risk of electric shock from lightning.
16. Do not use the telephone to report a gas leak in the vicinity of the leak. Under certain circumstances, a spark may be created when the adapter is plugged into the power outlet, or when the handset is replaced in its cradle. This is a common event associated with the closing of any electrical circuit. The user should not plug the phone into a power outlet, and should not put a charged handset into the cradle, if the phone is located in an environment containing concentrations of flammable or flame-supporting gases, unless there is adequate ventilation. A spark in such an environment could create a fire or explosion. Such environments might include: medical use of oxygen without adequate ventilation; industrial gases (cleaning solvents; gasoline vapors; etc.); a leak of natural gas; etc.
17. Only put the handset of your telephone next to your ear when it is in normal talk mode.
18. The power adapters are intended to be correctly oriented in a vertical or floor mount position. The prongs are not designed to hold the plug in place if it is plugged into a ceiling, under-the-table or cabinet outlet.

19. Use only the power cord indicated in this manual.
20. For pluggable equipment, the socket-outlet shall be installed near the equipment and shall be easily accessible.
21. In wall mounting position, make sure to mount the telephone base on the wall by aligning the eyelets with the mounting studs of the wall plate. Then slide the telephone base down on both mounting studs until it locks into place. Mount the device only at heights not exceeding 2 meters. Refer to the full installation instructions in the User Manual.
22. CAUTION: Keep small metallic objects such as pins and staples away from the handset receiver.
23. WARNING: The product included (ITE) in this manual is to be connected only to PoE networks without routing to the outside plant.

## SAVE THESE INSTRUCTIONS

|                                                                                                                                                                                                 |                                                                                                                                                                                                                   |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Power requirements</b><br>  | Handset charger power adapter:<br>5.0Vdc 2A (Model number: NBS10B050200VUU)<br><br>Handset battery: 3.7V 1500mAh, Li-ion battery<br>(Model number: 503860AR1500, Manufacturer:<br>Yiyang Corun Battery Co., Ltd.) |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

### CAUTION

- The battery cannot be subjected to high or low extreme temperatures during use, storage or transportation.
- The battery cannot be subjected to low air pressure at high altitude during use, storage or transportation.
- The battery in the product is replaceable. There is a danger of explosion if the battery is incorrectly replaced.
- Replacement of a battery with an incorrect type can result in an explosion or the leakage of flammable liquid or gas.
- Avoid disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion.
- Avoid leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas.
- A battery subjected to extremely low air pressure may result in an explosion or the leakage of flammable liquid or gas.

For cUL compliance only

## Mesures de sécurité importantes



Ce symbole vous alertera d'informations importantes ou d'instructions d'entretien pouvant apparaître dans ce guide d'utilisation. Respectez toujours les mesures de sécurité et de sécurité de base lorsque vous utilisez ce produit, afin de réduire les risques de blessures, d'incendie, ou d'électrocution.

### Mesures de sécurité importantes

---

Afin de réduire les risques d'incendie, de blessures corporelles ou d'électrocution, suivez toujours ces mesures préventives de base lorsque vous utilisez votre téléphone

1. Cet appareil doit être installé par un technicien qualifié.
2. Cet appareil doit être branché à un équipement hôte et jamais branché à un réseau, tel qu'un réseau PSTN public ou un réseau téléphonique standard (POTS).
3. Lisez et comprenez bien toutes les instructions.
4. Observez toutes les instructions et mises en garde inscrites sur l'appareil.
5. Débranchez ce téléphone de la prise murale avant de le nettoyer. N'utilisez pas de nettoyeurs liquides ni en aérosol. N'utilisez qu'un chiffon doux et légèrement humecté.
6. N'utilisez pas ce produit près de l'eau, tel que près d'un bain, d'un lavabo, d'un évier de cuisine, d'un bac de lavage ou d'une piscine, ou dans un sous-sol humide ou sous la douche.
7. Ne déposez pas ce téléphone sur un chariot, support ou table chancelants. L'appareil pourrait tomber et être sérieusement endommagé.
8. Le boîtier de l'appareil est doté de fentes et d'ouvertures d'aération situées à l'arrière ou en dessous. Afin d'empêcher la surchauffe, ces ouvertures ne doivent pas être obstruées en plaçant l'appareil sur un lit, divan, tapis ou autre surface similaires. Ne placez pas cet appareil à proximité d'un élément de chauffage ni d'une plinthe électrique. De plus, ne l'installez pas dans une unité murale ou un cabinet fermé qui ne possède pas d'aération adéquate.
9. Ne faites fonctionner cet appareil qu'avec le type d'alimentation indiqué sur les étiquettes de l'appareil. Si vous ne connaissez pas le voltage de votre maison, consultez votre marchand ou votre fournisseur d'électricité.

10. Ne déposez rien sur le cordon d'alimentation. Installez cet appareil dans un endroit sécuritaire, là où personne ne pourra trébucher sur la ligne d'alimentation ni le cordon téléphonique modulaire.
11. N'insérez jamais d'objets à travers les fentes et ouvertures de cet appareil, car ils pourraient toucher à des points de tension dangereux ou court-circuiter des pièces, ce qui constituerait un risque d'incendie ou d'électrocution. N'échappez pas de liquides dans l'appareil.
12. Afin de réduire les risques d'électrocution, ne démontez pas l'appareil, mais apportez-le plutôt à un centre de service qualifié s'il doit être réparé. En enlevant le couvercle, vous vous exposez à des tensions dangereuses ou autres dangers similaires. Un remontage inadéquat peut être à l'origine d'une électrocution lors d'une utilisation ultérieure de l'appareil.
13. Ne surchargez pas les prises de courant ni les rallonges électriques, car ceci peut constituer un risque d'incendie ou d'électrocution.
14. Débranchez cet appareil de la prise de courant et communiquez avec le département de service à la clientèle de Snom dans les cas suivants:
  - A. Lorsque le cordon d'alimentation est endommagé ou écorché.
  - B. Si du liquide a été échappé dans l'appareil.
  - C. Si l'appareil a été exposé à une source d'humidité telle que la pluie ou l'eau.
  - D. Si l'appareil ne fonctionne pas normalement en suivant les directives du guide. N'ajustez que les commandes couvertes dans le guide d'utilisation, car un mauvais réglage de celles-ci peut être à l'origine de dommages, ce qui nécessiterait des réparations considérables pour remettre l'appareil à son état de fonctionnement normal.
  - E. Si l'appareil a été échappé ou son boîtier, endommagé.
  - F. Si le produit affiche une nette diminution de sa performance.
15. Évitez d'utiliser un téléphone (autre qu'un sans fil) pendant un orage. Les éclairs peuvent être à l'origine d'une électrocution.
16. N'utilisez pas le téléphone pour rapporter une fuite de gaz à proximité de celle-ci. Sous certaines circonstances, une intéincelle pourrait survenir lorsque l'adaptateur est branché à une prise de courant, ou lorsque le combiné est déposé sur le combiné. Ceci est un événement commun associé avec la fermeture d'un circuit électrique. L'utilisateur ne devrait pas brancher le téléphone dans une prise de courant, et ne devrait pas déposer le combiné chargé sur le socle, si le téléphone se trouve dans un environnement où la concentration de gaz inflammables, sans ventilation

adéquate. Une étincelle dans ces endroits pourrait provoquer un incendie ou une explosion. Ces environnements pourraient être l'utilisation médicale de l'oxygène sans ventilation adéquate; le gaz industriel (dissolvants, vapeurs d'essence, etc.); une fuite de gaz naturel, etc.

17. Placez uniquement le combiné de votre appareil près de votre oreille lorsqu'il est en mode de conversation normal.
18. Les adaptateurs sont conçus pour être orientés en position verticale ou en position horizontale sur le plancher.
19. N'utilisez que cordon d'alimentation et les piles indiquées dans ce guide d'utilisation.
20. Pour les PRODUITS À BRANCHER À UNE PRISE DE COURANT, la prise de courant doit être installée près du produit, afin d'assurer une accessibilité sécuritaire à la prise de courant.
21. En position de montage mural, assurez-vous de monter le socle du téléphone sur le mur en alignant les œillets avec les goujons de fixation de la plaque murale. Ensuite, faites glisser le socle vers le bas sur les deux goujons de fixation jusqu'à ce qu'il se verrouille en place. Ne fixez l'appareil qu'à des hauteurs ne dépassant pas 2 mètres. Reportez-vous aux instructions complètes dans la section Installation dans ce guide d'utilisation.
22. MISE EN GARDE : Éloignez les petits objets métalliques tels que les broches de l'écouteur du combiné.
23. AVERTISSEMENT : Le produit inclus (ITE) dans ce guide doit être connecté uniquement aux réseaux PoE sans être acheminé vers l'installation extérieure.

## CONSERVEZ CES INSTRUCTIONS

|                                                                                                                                                                                                   |                                                                                                                                                                                                                                                   |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Alimentation électrique<br>  | Adaptateur électrique du chargeur du combiné :<br>5,0 V CC, 2 A (Numéro de modèle : NBS10B050200VUU)<br>Pile du combiné : Pile au lithium-ion de 3,7 V 1 500 mAh<br>(Numéro de modèle : 503860AR1500, Fabricant : Yiyang Corun Battery Co., Ltd.) |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

### MISES EN GARDE

- La pile ne peut pas être soumise à des températures extrêmes hautes ou basses pendant l'utilisation, l'entreposage ou le transport.
- La pile ne peut pas être soumise à une faible pression atmosphérique à haute altitude pendant l'utilisation, l'entreposage ou le transport.
- La pile de ce produit est remplaçable. Il existe un risque d'explosion si la pile n'est pas remplacée correctement.

- Le remplacement d'une pile d'un type incorrect peut entraîner une explosion ou la fuite d'un liquide ou d'un gaz inflammable.
- Évitez de jeter une pile dans le feu ou dans un four chaud, ou d'écraser ou de couper mécaniquement une pile, car cela peut provoquer une explosion.
- Évitez de laisser une pile dans un environnement où la température est extrêmement élevée, ce qui pourrait provoquer une explosion ou une fuite de liquide ou de gaz inflammable.
- Une pile soumise à une pression d'air extrêmement basse peut entraîner une explosion ou une fuite de liquide ou de gaz inflammable.

## Compliance

### **FCC part 15**

---

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at the user's expense.

Privacy of communications may not be ensured when using this phone.

Warning: Changes or modifications to this equipment not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

To ensure safety of users, the FCC/ISED has established criteria for the amount of radio frequency energy that can be safely absorbed by a user or bystander according to the intended usage of the product. This product has been tested and found to comply with the FCC /ISED criteria. The handset may be safely held against the ear of the user.

# Compliance

## FCC Part 68

---

### Consumer Information:

- a. This equipment complies with Part 68 of the FCC rules and the requirements adopted by the ACTA. On the back or bottom of this equipment is a label that contains, among other information, a product identifier in the format **US:AAAEQ##TXXXX**. If requested, this number must be provided to the telephone company.
- b. An applicable certification jacks Universal Service Order Codes (USOC) for the equipment is provided (i.e., **RJ45C**) in the packaging with each piece of approved terminal equipment.
- c. A plug and jack used to connect this equipment to the premises wiring and telephone network must comply with the applicable FCC Part 68 rules and requirements adopted by the ACTA. A compliant LAN cable (RJ45) and modular plug is provided with this product. An RJ45 jack should normally be used for connecting to the SIP equipment through the LAN cable. See installation instructions for details.
- d. If this equipment causes harm to the telephone network, the telephone company will notify you in advance that temporary discontinuance of service may be required. But if advance notice isn't practical, the telephone company will notify the customer as soon as possible. Also, you will be advised of your right to file a complaint with the FCC if you believe it is necessary.
- e. The telephone company may make changes in its facilities, equipment, operations or procedures that could affect the operation of the equipment. If this happens the telephone company will provide advance notice in order for you to make necessary modifications to maintain uninterrupted service.
- f. Should you experience trouble with this equipment, please contact  
Snom Technology GmbH  
1 (339) 227-6160 (select option 2)  
for repair or warranty information. If the equipment is causing harm to the telephone network, the telephone company may request that you disconnect the equipment until the problem is resolved.
- g. Please follow instructions for repairing if any (e.g. battery replacement section); otherwise do not alternate or repair any parts of device except specified.

## Compliance

- h. Connection to party line service is subject to state tariffs. Contact the state public utility commission, public service commission or corporation commission for information.
- i. **NOTICE:** If you have specially wired alarm equipment connected to the telephone line, ensure the installation of this product does not disable your alarm equipment.  
If you have questions about what will disable alarm equipment, consult your telephone company or a qualified installer.
- j. This equipment is hearing aid compatible.

**NOTICE:** According to telephone company reports, AC electrical surges, typically resulting from lightning strikes, are very destructive to telephone equipment connected to AC power sources. To minimize damage from these types of surges, a surge arrestor is recommended.

### Industry Canada

---

This Class A digital apparatus complies with Canadian requirements: CAN ICES-3 (A)/NMB-3(A). Cet appareil numérique de la classe A est conforme à la norme CAN ICES-3 (A)/NMB-3(A) du Canada.

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s).

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Privacy of communications may not be ensured when using this telephone.

The term "IC:" before the certification/registration number only signifies that the Industry Canada technical specifications were met.

This product meets the applicable Innovation, Science and Economic Development Canada technical specifications.

## About this Guide


This quick installation guide provides a reference for the external features of the M55 SIP DECT Handset and installation instructions.

The M55 SIP DECT Handset is for use with the M500 Multi-cell SIP DECT Base Station. Please refer to the M55 SIP DECT Handset User Manual for complete operation instructions.


For customer service or product information, visit our website at **[www.snomamericas.com](http://www.snomamericas.com)**.

## Parts Checklist


Your telephone package contains the following items. Save your sales receipt and original packaging in the event warranty service is necessary.



Cordless handset



Power adapter




Handset charger



Battery



## Quick Reference Guide



|   |                                                          |
|---|----------------------------------------------------------|
| 1 | Earpiece                                                 |
| 2 | <b>MESSAGE</b> LED                                       |
| 3 | Color screen                                             |
| 4 | Soft keys                                                |
| 5 | Line <b>1-6</b> programmable feature keys                |
| 6 | ○ <b>MENU/Confirm</b> key and<br>^ v < > navigation keys |

|    |                       |
|----|-----------------------|
| 7  | <b>SPEAKER</b> key    |
| 8  | Alphanumeric keypad   |
| 9  | Microphone            |
| 10 | <b>- VOLUME +</b> key |
| 11 | Programmable key      |
| 12 | <b>OFF/Cancel</b> key |
| 13 | Belt clip             |
| 14 | Speaker               |

## Handset Installation

This section assumes that your network infrastructure is established and that your IP PBX phone service has been ordered and configured for your location.

Handset installation involves both the handset and the handset charger. The handset charger is powered using the supplied power adapter. The handset charger can be placed on a flat surface or mounted on a wall.

Avoid placing the handset too close to:


- Communication devices such as television sets, DVD players, or other cordless telephones
- Excessive heat sources
- Noise sources such as a window with traffic outside, motors, microwave ovens, refrigerators, or fluorescent lighting
- Excessive dust sources such as a workshop or garage
- Excessive moisture
- Extremely low temperature
- Mechanical vibration or shock such as on top of a washing machine or work bench

## Installing the charger

---

Install the charger as shown below.

Plug the power adapter into an electrical outlet not controlled by a wall switch.



## IMPORTANT INFORMATION

1. Use only the power adapter supplied with this product. To order a replacement power adapter, visit our website at **[www.snomamericas.com](http://www.snomamericas.com)**.
2. The power adapter is intended to be correctly oriented in a vertical or floor mount position. The prongs are not designed to hold the plug in place if it is plugged into a ceiling, under-the-table or cabinet outlet.

### Battery installation and charging

---

Install the battery as shown on the following page. Once you have installed the battery, the screen indicates the battery status (see the table below). If necessary, place the handset in the charger to charge the battery. For best performance, keep the handset in the charger when not in use. The battery is fully charged after 11 hours of continuous charging.

If the screen is blank, you need to charge the handset without interruption for at least 30 minutes to give the handset enough charge to use the telephone for a short time. When the battery is low, the handset shows a flashing Very low battery icon  or Low battery icon .

| Battery indicators                                                                                                                     | Battery Status                                                   | Action                                                                |
|----------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------|-----------------------------------------------------------------------|
| The screen is blank or Very low battery icon  flashes. | The battery has no or little charge. The handset cannot be used. | Charge without interruption (at least 30 minutes).                    |
| Low battery icon  flashes.                            | Battery has enough charge to be used for a short time.           | Charge without interruption (at least 30 minutes).                    |
| Full battery icon  appears.                           | Battery is charged.                                              | To keep the battery charged, place it in the charger when not in use. |



4. Charge the handset by placing it face forward in the charger.  
The battery icon indicates the charge status as the battery charges.

|                                                                                   |                                                        |
|-----------------------------------------------------------------------------------|--------------------------------------------------------|
|  | Very low battery. Charging less than 30 minutes.       |
|  | Charging less than 30 minutes.                         |
|  | Charging 30 to 80 minutes.                             |
|  | Charging 80 minutes to 7 hours.                        |
|  | Charging more than 7 hours. Fully charged at 11 hours. |

### IMPORTANT INFORMATION


- Use only the supplied rechargeable battery or replacement battery (model number 503860AR1500). To order a replacement battery, visit our website at **[www.snomamericas.com](http://www.snomamericas.com)**.
- If you do not use the handset for a long time, disconnect and remove the battery to prevent possible leakage.

## Wall mounting the charger

The charger is ready for tabletop use. If you want to mount the charger on a wall, use two 10 mm (3/8 inch) screws and wall anchors to hold the charger in place. Screws and wall anchors are not provided, but are available for purchase at hardware retailers. You might need a professional to install the charger.

### To mount the charger on the wall:

1. Use a pencil to mark the desired positions of the two holes on the wall. Make sure the space between the two holes is 30 mm (1 3/16 inches). Drill two holes in the wall according to the marks.



Mount the device only at heights not exceeding 2 meters.

2. If you drill the holes into a stud, go to step 3.

-OR-

If you drill the holes into an object other than a stud, insert the wall anchors into the holes and tap gently on the ends with a hammer until the wall anchors are flush with the wall.

3. Insert the screws into the holes and tighten them until only 6 mm (1/4 inch) of the screws are exposed.
4. Align the holes at the back of the charger with the screws on the wall and slide the charger down until it locks into place.



## Registering the handset to the base station

---

The handset must be registered to the base station in order to make and receive calls.

There are three methods of registration:

- Auto registration
- Manual registration (triggered via Web UI).
- Manual registration (triggered via LINK button on base).

### Registering the handset - Auto registration

---

1. Make sure the base station is connected to power and the network.
2. Press the **MENU/Confirm** key.  
The User Settings screen appears.
3. Press **^** or **v** to scroll down to **Registration** and press **OK**.  
The Registration screen appears.
4. With **This device** selected, press **OK**.  
The "This device" screen appears.
5. Press **^** or **v** to scroll down to **Auto Registration** and press **OK**.

The handset displays:

Trying to  
auto-register...

Keep the  
Handset within  
base's range.

If registration is successful:

The handset beeps and displays "Handset X Registered" .

If registration fails:

The handset displays "Registration failed". Press **OK**.

The handset displays "Consult the phone administrator to provision the device IPEI to the base." Press **IPEI** to display the phone's IPEI and serial number. Give these numbers to your phone administrator.

## Registering the handset - Manual registration (triggered via Web UI)

---

1. Make sure the base station is connected to power and the network.
2. Press the **MENU/Confirm** key.

The User Settings screen appears.

3. Press **^** or **v** to scroll down to **Registration** and press **OK**.

The Registration screen appears.

4. With **This device** selected, press **OK**.

The "This device" screen appears.

5. Press **^** or **v** to scroll down to **The base Web UI** and press **OK**.

The handset displays:

Login to the  
base's WebUI  
using a browser,  
Click Status,  
then Registration

Then, press  
the # key  
at the Handset.  
Keep the  
handset within  
base' range

6. Open the phone's Web UI in a web browser.
7. On the Web UI, click **Status** and then click **Registration**.
8. Press the **#** key on the handset to begin registration.  
The handset displays "Registering... Please Wait."
9. If you are prompted to enter a PIN, enter the PIN and then press **OK**.  
The default PIN is 0000.

If registration is successful:

The handset beeps and displays "Handset X Registered".

If registration fails:

The handset displays "Registration failed". Press **OK**.

- If the handset displays "Device not registered to base station.", press **Reg**. Place the handset in the charger again for a few seconds, remove it and try the registration steps again.
- If the handset displays "Out of range. Searching for base...", move the handset closer to the base, and try the registration steps again.
- If the handset displays the idle screen, it means the handset was already registered to another base. To register the handset to a different base, try the registration steps again.

## **Registering the handset - Manual registration (triggered via LINK button on base)**

1. Make sure the base station is connected to power and the network.
2. Press the **MENU/Confirm** key.

The User Settings screen appears.

3. Press **▲** or **▼** to scroll down to **Registration** and press **OK**.

The Registration screen appears.

4. With **This device** selected, press **OK**.

The "This device" screen appears.

5. With **The base LINK key** selected, press **OK**.

The handset displays:

Press and hold  
the LINK key  
at base for  
4 seconds

Then, press  
the # key  
at the Handset.

6. Press and hold the LINK button on the base station for four seconds.

The  (power) and  (SIP) LEDs flash green.

7. Press the **#** key on the handset to begin registration.

The handset briefly displays "Press the WPS button on your Hub .

The handset displays "Registering... Please Wait."

8. If you are prompted to enter a PIN, enter the PIN and then press **OK**.

The default PIN is 0000.

If registration is successful:

The handset beeps and displays "Handset X Registered" .

If registration fails:

The handset displays "Registration failed". Press **OK**.

- If the handset displays "Device not registered to base station.", press **Reg**. Place the handset in the charger again for a few seconds, remove it and try the registration steps again.
- If the handset displays "Out of range. Searching for base...", move the handset closer to the base, and try the registration steps again.
- If the handset displays the idle screen, it means the handset was already registered to another base. To register the handset to a different base, try the registration steps again.

## Deregistering the handset

---

Before using the handset with a different base station, you must deregister the handset from the base station to which it is currently registered.

### To deregister the handset:

1. Press the **MENU/Confirm** key.  
The User Settings screen appears.
2. Press **▲** or **▼** to scroll down to **Registration** and press **OK**.  
The Registration screen appears.
3. Press **▲** or **▼** to scroll down to **Deregistration** and press **OK**.  
The "Dereg. HS" screen appears, showing the list of registered handsets.  
Your handset is indicated by \* \*.
4. Press **▲** or **▼** to select the handset you want to deregister, and press **SELECT**.
5. Enter the PIN and press **OK** to begin deregistration. The default PIN is 0000.  
The handset beeps and displays "Handset is deregistered".

## Screen icons

The following screen icons indicate your phone's current status:

| Icon                                                                               | Status                                                                                           |
|------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------|
|    | Indicates signal strength, from one bar (weak) to four bars (strong). Flashes when out of range. |
|    | The ringer is off.                                                                               |
|   | Speakerphone—the speakerphone is active.                                                         |
|  | Microphone is muted.                                                                             |
|  | Call Forward is on.                                                                              |
|  | Do Not Disturb is on.                                                                            |
|  | Silent mode is on.                                                                               |

## Maintenance

### Taking care of your telephone

---

- Your base station and cordless handset contain sophisticated electronic parts, so you must treat them with care.
- Avoid rough treatment.
- Place the handset down gently.
- Save the original packing materials to protect your products if you ever need to ship them.

### Avoid water

---

- You can damage your cordless telephone if it gets wet. Do not use the handset in the rain, or handle it with wet hands. Do not install the base station and handset near a sink, bathtub or shower.

### Electrical storms

---

- Electrical storms can sometimes cause power surges harmful to electronic equipment. For your own safety, take caution when using electric appliances during storms.

### Cleaning your telephone

---

- Your products have a durable plastic casing that should retain its luster for many years. Clean it only with a soft cloth slightly dampened with water or a mild soap.
- Do not use excess water or cleaning solvents of any kind.

Remember that electrical appliances can cause serious injury if used when you are wet or standing in water. If the telephone base should fall into water, DO NOT RETRIEVE IT UNTIL YOU UNPLUG THE POWER CORD FROM THE WALL, then pull the unit out by the unplugged cord.

## Technical Specifications

|                                                                                                                                                                                              |                                                                                                                                                                                                                |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| RF frequency band                                                                                                                                                                            | 1921.536–1928.448 MHz                                                                                                                                                                                          |
| Channels                                                                                                                                                                                     | 5                                                                                                                                                                                                              |
| Operating temperature                                                                                                                                                                        | 32–104 °F (0–40 °C)                                                                                                                                                                                            |
| Power requirements<br>  | Handset charger power adapter:<br>5.0Vdc 2A (Model number: NBS10B050200VUU)<br><br>Handset battery: 3.7V 1500mAh, Li-ion battery<br>(Model number: 503860AR1500, Manufacturer: Yiyang Corun Battery Co., Ltd.) |
| Bluetooth range                                                                                                                                                                              | Up to 10m                                                                                                                                                                                                      |

VTECH COMMUNICATIONS, INC.

Tigard, Oregon 97223, USA.

Copyright © 2022 Snom Technology GmbH. All Rights Reserved.

v20220525 Version 2, 05/22