



XCESS-OS-DUAL

USER MANUAL

Version1.0

Last Modified Date: 06, March 2025



Preparedby:

Documentation& SupportTeam

Semnox Solutions, Punja Building Annexe, MG Rd, Lalbagh,
Mangalore, Karnataka- India



Legal Notice

The information presented is subject to change without notice. Semnox Solutions assumes no responsibility for inaccuracies contained herein.

Copyright © 2017 Semnox Solutions Pvt Ltd. All rights reserved.

Notice

No part of this document may be reproduced or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without prior written permission of Semnox Solutions. Every effort has been made to ensure that the information contained in this user manual was accurate at the time of printing. However, information is subject to change.

Contents

Introduction	5
Operational description	5
Product specs	6
Key Features.....	6
Materials	7
Operational Range.....	7
Physical Dimensions.....	7
Overview.....	8
Hardware Components.....	8
1. LAN Interface Board	8
2. Main Board + Phycore (AM335X)	8
3. Mifare board - RFID reader.....	9
4. Harnesses and accessories.....	9
Mounting.....	11
Mounting Requirement	11
Mounting Instructions.....	12
Compliance.....	13
FCC compliance and advisory statements.....	13
Radiation Exposure Statement	13

About this document

Purpose

This document explains the process for installation and configuration of Parafait XCESS-OS-DUAL

Revision History

2025 March. This is the first issue of the document.

Feedback

To send us your feedback on the document, email your comments to info@semnox.com

Introduction

Welcome to XCESS-OS-DUAL, a device designed to enhance the experience in amusement parks and entertainment centers. Its advanced technology allows users to access and enjoy activities quickly and easily.

This manual provides detailed information on the installation and configuration of the device to make the most of its features.

Operational description

The XCESS-OS-DUAL is a device that allows users to access and participate in amusement park activities and rides. It features a full-screen tap area and illuminating visuals that enhance both aesthetics and user feedback. Designed for hassle-free 'tap-to-play' convenience, it supports POE/Direct AC power and offers both wired and wireless network connectivity for greater flexibility.

The XCESS-OS-DUAL includes dual-band Wi-Fi, supporting both 2.4 GHz and 5 GHz, ensuring seamless connectivity. It provides over-the-air firmware updates and media transmission, a 4.5-inch touchscreen for intuitive interaction, and an advanced graphics engine for a rich multimedia experience. Additionally, it supports Multi-Gameplay and Repeat Play for enhanced user engagement. The device also features the ability to read QR codes and barcodes, expanding its functionality for various access and payment solutions.

Product specs

Key Features

- **Intuitive 4.5-inch TFT LCD Touchscreen** – Provides an interactive and engaging user experience.
- **LED Bezel with Software-Controlled Patterns** – Offers dynamic visual feedback.
- **Tap-Anywhere Functionality** – Eliminates the need for precise tag placement.
- **Seamless Connectivity** – Supports dual-band 2.4 GHz and 5 GHz Wi-Fi (select models) and Bluetooth Low Energy (BLE).
- **OTA Firmware Updates & Media Transmission** – Ensures easy software upgrades and content delivery.
- **Customizable Display** – Supports multilingual interfaces and dynamic content for user engagement.
- **Advanced Graphics Engine** – Enhances the multimedia experience with smooth animations.
- **Multi-Gameplay & Repeat Play Features** – Optimized for amusement park interactions.
- **Barcode Reader** - Capability to read barcodes and QR codes.



Materials


- Gorilla Glass.
- PC110.
- SECC0.4.
- SECC 2.0 or SS316 in some models.
- SILICONE RUBBER SHORE 60A.

Operational Range

- Operational Voltage: 11.4V to 12.6V
- Operating Temperature: -20~50 °C
- RF Communication Family: Wi-Fi – 2.4 GHz, 5GHz, BLE
- Antenna Type: FPC
- RFID Reading: Mifare
- Current: 2A

Physical Dimensions

- Dimensions(Inc. mounting): 106.84 x 271.71 x 131.07 mm.
- Connectors: Molex harness, LAN Cable.
- Connector Position: Bottom.
- Mounting Type: On the surface of the arcade machines, Wall mounting.




Overview

Hardware Components


1. LAN Interface Board

Allows the system to communicate with a LAN network for real-time data transmission. It converts and transmits the information processed by the Main Board to servers or management systems via Ethernet. It can also include security measures such as data encryption and authentication to ensure the integrity and privacy of the transmitted information.




2. Main Board + Phycore (AM335X)

It is the core of the system and manages the information received from the MIFARE Board. Its main function is to validate credentials, process data and manage additional functions. In addition, it acts as a bridge between the RFID Reader Board and the LAN Interface Board, ensuring that the information is processed and sent correctly within the system.



3. Mifare board - RFID reader

This board is responsible for detecting and reading RFID cards by means of radio frequency signals. It integrates an antenna and a specialized circuit that identifies the cards within its operating range, processes the information stored in them, and transmits it to the Main Board. Its function is fundamental in authentication and access control systems.



4. Harnesses and accessories

The device is equipped with the following accessories, which are essential to ensure correct operation.

Buzzer: The XCESS-OS-DUAL has an internal buzzer that emits an audible signal to indicate the reading of the device.

Ethernet Cable: The Ethernet cable allows direct connection between the XCESS-OS-DUAL and the central management system in amusement parks. Its function is to guarantee a fast and secure transmission of information, optimizing access control.

Molex Cable: It allows the XCESS-OS-DUAL to connect to multiple external peripherals, enabling seamless and efficient integration with its environment. Its design optimizes data transmission and power supply, ensuring stable communication and reliable performance.

Reset switch: If it is necessary to reset the XCESS-OS-DUAL, press the switch located on the back of the card reader for 5 seconds. The XCESS-OS-DUAL will restart automatically.




Mounting

The XCESS-OS-DUAL is designed to be easily integrated into turnstiles, allowing for a secure, practical and efficient installation that optimizes visitor flow. Below you will find detailed instructions for quick and secure setup, ensuring stable and reliable performance.


Mounting Requirement

This card reader requires four mounting holes on the installation surface, along with an additional hole for the cables. The vertical distance between the mounting holes is 37 mm, while the horizontal distance is 40 mm.



Mounting Instructions

Securely attach the Stand Plate with the Card Reader to the turnstile mounting surface using the M4x10 S3 mounting screws. Don't forget to use the M4x12 mounting washers.



Item	Description	QTY	Picture
1	M4X10 S3 Mounting Screws	4	
2	M4X12 Mounting Washers	4	
3	Turnstile Mounting Surface	1	
4	Stand Plate	1	
5	Card Reader	1	

Compliance

FCC compliance and advisory statements

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- *Reorient or relocate the receiving antenna.*
- *Increase the separation between the equipment and the receiver.*
- *Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.*
- *Consult the dealer or an experienced radio/TV technician for help.*

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

