

EXHIBIT A

[FCC Ref. 2.1033(b)(3)]

"Installation and Operating Instructions
Furnished to the User"

26990



**40-Channel 900 MHz
Cordless Telephone/Answerer
User's Guide**



We bring good things to life.

FCC REGISTRATION INFORMATION

Your telephone equipment is registered with the Federal Communications Commission and is in compliance with parts 15 and 68, FCC Rules and Regulations.

1 Notification to the Local Telephone Company

On the bottom of this equipment is a label indicating, among other information, the FCC Registration number and Ringer Equivalence Number (REN) for the equipment. You must, upon request, provide this information to your telephone company.

The REN is useful in determining the number of devices you may connect to your telephone line and still have all of these devices ring when your telephone number is called. In most (but not all) areas, the sum of the RENs of all devices connected to one line should not exceed 5. To be certain of the number of devices you may connect to your line as determined by the REN, you should contact your local telephone company.

Notes

- This equipment may not be used on coin service provided by the telephone company.
- Party lines are subject to state tariffs, and therefore, you may not be able to use your own telephone equipment if you are on a party line. Check with your local telephone company.
- Notice must be given to the telephone company upon permanent disconnection of your telephone from your line.

2 Rights of the Telephone Company

Should your equipment cause trouble on your line which may harm the telephone network, the telephone company shall, where practicable, notify you that temporary discontinuance of service may be required. Where prior notice is not practicable and the circumstances warrant such action, the telephone company may temporarily discontinue service immediately. In case of such temporary discontinuance, the telephone company must: (1) promptly notify you of such temporary discontinuance; (2) afford you the opportunity to correct the situation; and (3) inform you of your right to bring a complaint to the Commission pursuant to procedures set forth in Subpart E of Part 68, FCC Rules and Regulations.

The telephone company may make changes in its communications facilities, equipment, operations or procedures where such action is required in the operation of its business and not inconsistent with FCC Rules and Regulations. If these changes are expected to affect the use or performance of your telephone equipment, the telephone company must give you adequate notice, in writing, to allow you to maintain uninterrupted service.

INTERFERENCE INFORMATION

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference; and (2) This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna (that is, the antenna for radio or television that is "receiving" the interference).
- Reorient or relocate and increase the separation between the telecommunications equipment and receiving antenna.
- Connect the telecommunications equipment into an outlet on a circuit different from that to which the receiving antenna is connected.
- Consult the dealer or an experienced radio/TV technician for help.

If these measures do not eliminate the interference, please consult your dealer or an experienced radio/television technician for additional suggestions. Also, the Federal Communications Commission has prepared a helpful booklet, "How To Identify and Resolve Radio/TV Interference Problems." This booklet is available from the U.S. Government Printing Office, Washington, D.C. 20402. Please specify stock number 004-000-00345-4 when ordering copies.

HEARING AID COMPATIBILITY

This telephone system meets FCC standards for Hearing Aid Compatibility.

2

FCC NUMBER IS LOCATED ON THE CABINET BOTTOM
REN NUMBER IS LOCATED ON THE CABINET BOTTOM


INTRODUCTION

Your cordless telephone/answerer is designed to give you flexibility in use and high quality performance. To get the most from your new cordless telephone/answerer, we suggest that you take a few minutes right now to read through this instruction manual.

TABLE OF CONTENTS


FCC Registration Information	2	Inserting a Pause in the Dialing	14
Interference Information	2	Sequence	14
Hearing Aid Compatibility	2	Changing a Stored Number	14
Introduction	3	Dialing a Stored Number	14
Getting Started	4	Erasing a Stored Number	14
Before You Begin	4	Chain Dialing from Memory	15
Modular Jack Requirements	4	Temporary Tone	16
Digital Security System	4	Answering Machine Operation	17
Desktop Installation	5	Messages Indicator	17
Wall Mount Installation	6	Screening Calls from	
Answering Machine Setup	7	The Base	17
Setting the Voice Time/Day Stamp	7	Message Playback	17
Setting the Speaker Volume	8	Memory Full	18
Voice Instructions	8	Erasing Messages	18
Setting the Ring Select	8	Leaving a Memo	18
Using Toll Saver	8	Remote Access	19
Recording the Outgoing		Using the Handset	19
Announcement	9	Answerer-in-Use Indicator	20
Reviewing Announcement	9	Screening Calls	
Cordless Phone Basics	10	From the Handset	20
Making a Call	10	Accessing the Answerer from Another	
In-Use Indicator	10	Phone	21
Redial	10	Changing the Security Code	21
Receiving a Call	10	Changing the Battery	22
Flash Button	11	Battery Safety Precautions	22
Volume Button	11	General Product Care	23
Mute Button	11	Troubleshooting Guide	24
Ringer Switch	11	Handset Sound Signals	26
Paging the Handset	12	Causes of Poor Reception	26
Advanced Features	13	Accessory Order Form	27
Channel Button	13	Service	29
The Memory Feature	13	Index	30
Storing a Number in Memory	13	Limited Warranty	31

WARNING: TO PREVENT FIRE OR ELECTRICAL SHOCK HAZARD, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.




GETTING STARTED


Make sure your package includes the items shown here.



AC power supply




Telephone line cord



Base plate



Short telephone line cord



Base



Handset

BEFORE YOU BEGIN

MODULAR JACK REQUIREMENTS

You need an RJ11 type modular jack, which is the most common type of phone jack and might look like the one pictured here. If you don't have a modular jack, call your local phone company to find out how to get one installed.




DIGITAL SECURITY SYSTEM

Your cordless phone uses a digital security system to protect against false ringing, unauthorized access, and charges to your phone line.

When you place the handset in the base, the unit verifies its security code. After a power outage or battery replacement, you should place the handset in the base for about 20 seconds to reset the code.

IMPORTANT: Because cordless phones operate on electricity, you should have at least one phone in your home that isn't cordless, in case the power in your home goes out.

DESKTOP INSTALLATION




1. Plug the telephone line cord into the TEL LINE jack on the base and into a modular jack.
2. Connect the power supply adapter to the POWER 9V AC jack on the back of the unit, and plug it into an AC outlet.
3. Set the T/P switch to T for touch-tone service, or P for pulse/rotary service. If you don't know which type of service you have, check with the phone company.
4. Raise the base antenna.
5. Turn on the RINGER switch on the handset so the handset rings for incoming calls.
6. Place handset in the base to charge for 12 hours. The CHARGE light comes on indicating that the battery is charging.

CAUTION: Use only the Thomson 5-2402 power supply that came with this unit. Using other adapters may damage the unit.

INSTALLATION NOTE: Some cordless telephones operate at frequencies that may cause interference to nearby TVs and VCRs. To minimize or prevent such interference, the base of the cordless telephone should not be placed near or on top of a TV or VCR. If interference continues, moving the cordless telephone farther away from the TV or VCR will often reduce or eliminate the interference.

WALL MOUNT INSTALLATION

1. Remove the handset hook; turn it upside down, and put it back in the slot. You need to do this so the handset doesn't fall out of the base.
2. Plug one end of the short telephone line cord into the jack marked TEL LINE on the back of the unit and plug the other end into a modular wall jack.
3. Install the base plate by putting the tabs into the slots on the top of the unit first, and then snapping the bottom tabs into place.
4. Connect the power supply to the POWER 9V AC jack on the back of the unit, and plug it into an AC outlet.
5. Slip the mounting holes over the wall plate posts and slide the unit down firmly into place. (Wall plate not included.)
6. Set the T/P switch to T if you have touch-tone service or to P if you have pulse/rotary dial service.
7. Turn on the RINGER switch on the handset so the handset rings for incoming calls.
8. Place handset in the base to charge for 12 hours. The CHARGE light comes on indicating that the battery is charging.



CAUTION: Use only the Thomson 5-2402 power supply that came with this unit. Using other adapters may damage the unit.



ANSWERING MACHINE SETUP

This section shows you how to set up your answering machine to receive incoming calls. Before you begin the setup, you must turn on the answerer.

- Press the ANSWER ON/OFF button to turn the answering machine on and off. The MESSAGES indicator lights when the answering machine is on. The indicator blinks when you have messages.

SETTING THE VOICE TIME/DAY STAMP

1. Press and hold the DAY/CHECK button to set the day of the week.
2. Press the HOUR button to set the hour (a.m. or p.m.).
3. Press the MIN button to set the minute. When you press and hold the MIN button, the time advances in 5-minute intervals.
4. Press and release the DAY/CHECK button to review the day and time settings.




SETTING THE SPEAKER VOLUME

Use the VOL (volume) control to adjust speaker volume to a comfortable level.

VOICE INSTRUCTIONS


If you need additional assistance, press the REVIEW button when you plug in the answerer and follow the voice instructions.



Speaker volume control

SETTING THE RING SELECT

Set the RING SELECT switch on the back of the unit to choose the number of times you want the phone to ring before the machine answers the call. You can choose 2 rings, 5 rings, or TOLL SAVER.



RING SELECT switch

USING TOLL SAVER

Toll Saver can save you the cost of a call when you access your messages from another phone:

- If you have new messages, the unit answers after the 2nd ring.
- If you have no new messages, the unit answers after the 5th ring.

You can hang up after the 3rd or 4th ring and save the pay telephone or long distance charge.

RECORDING THE OUTGOING ANNOUNCEMENT

For best results when recording, you should be about 9 inches from the microphone, and eliminate as much background noise as possible.

1. Press and hold the GREETING button.
You need to hold the button until you finish the announcement.
2. Begin talking after you hear the beep.
3. Release the button when you finish your announcement.


If you choose not to record an outgoing announcement, a default announcement will play. To return to the default announcement after you have recorded your own outgoing announcement, press the GREETING button and release it when you hear the beep.

Sample Outgoing Announcement

Hi, this is (use your name here), I can't answer the phone right now, so please leave your name, number and a brief message after the tone, and I'll get back to you. Thanks.

REVIEWING ANNOUNCEMENT

- Press and release GREETING button to review your outgoing announcement.



CORDLESS PHONE BASICS

MAKING A CALL

The only two things you need to know to make a call are:

- Press the TALK button before you dial.
- Press TALK button or place the handset in the base to hang up.

Otherwise, it works just like any other phone.

CAUTION: Because cordless phones operate on electricity, you should have at least one phone in your home that isn't cordless, in case the power in your home goes out.

IN-USE INDICATOR

You know the phone is on when you see the IN-USE indicator on the handset come on.

REDIAL

Press the RE/PA (redial) button to redial the last number you called (up to 32 digits).

If you get a busy signal, and want to keep dialing the number, press TALK to turn off the phone. Press TALK again to turn it back on. Then press RE/PA to dial the number.


RECEIVING A CALL

To answer a call you must press the TALK button on the handset before you can talk.

TALK button

RE/PA
button

IN USE
indicator



FLASH BUTTON

Use the FLASH button to activate custom calling services such as call waiting or call transfer, which are available through your local phone company.

TIP: Don't use the TALK button to activate custom calling services such as call waiting, or you'll hang up the phone.

VOLUME BUTTON

Press the VOL button to adjust the volume of the handset's earpiece. There are four settings.


MUTE BUTTON

Use the MUTE button to interrupt a phone conversation to talk privately with someone else in the room.

1. Press MUTE to activate mute feature (the BAT LOW light blinks).
2. Press MUTE again to turn it off.


RINGER SWITCH

The RINGER switch must be ON for the handset to ring during incoming calls (or when paging the handset).



PAGING THE HANDSET

Press the PAGE button on the base to get the attention of the person near the handset, or to find a misplaced handset. Press and hold the PAGE button for several seconds (the handset rings). Press the PHONE button on the handset when you find it. Remember that the RINGER switch must be ON in order for the handset to ring.



ADVANCED FEATURES

CHANNEL BUTTON

While talking, you might need to manually change the channel in order get rid of static caused by baby monitors, garage door openers, or other cordless phones. Press and release the CHAN button to advance to the next clear channel.


THE MEMORY FEATURE

Store up to 10 numbers in memory for quick dialing.

STORING A NUMBER IN MEMORY

The phone must be OFF when you store numbers.

1. Press the MEM button.
2. Dial the number (up to 20 digits).
3. Press MEM and then press a number key (0-9) to store the dialed number in that memory location. (If you've made an error storing the number, the phone beeps twice.)
4. Record whose number is stored in the location on the memory directory card on the back of the handset.



CAUTION: If you make test calls to emergency numbers stored in memory, remain on the line and briefly explain the reason for the call to the dispatcher. Also, it's a good idea to make these calls in off-peak hours, such as early morning or late evening.

INSERTING A PAUSE IN THE DIALING SEQUENCE

Press the RE/PA button to insert a delay in the dialing sequence of a stored telephone number when a pause is needed to wait for a dial tone (for example, after you dial 9 for an outside line or when you need to wait for a computer access tone). Each pause counts as 1 digit.

CHANGING A STORED NUMBER

Use the same procedure to change a stored number as you do to store a number—in a sense, you're just replacing the phone number with a new one.

DIALING A STORED NUMBER

1. Make sure the phone is ON.
2. Press MEM.
3. Press the number for that memory location.

ERASING A STORED NUMBER

1. Make sure the phone is OFF.
2. Press and release MEM twice.
3. Press the memory location you want to erase.

CHAIN DIALING FROM MEMORY

Use this feature to make calls which require a sequence of numbers, for instance if you use a calling card for a frequently called long distance number. The following example shows how you can use chain dialing to make a call through a long distance service:

<i>The Number For</i>	<i>Memory Location</i>
Long distance access number	7
Authorization code	8
Frequently called long distance number	9


1. Make sure the phone is ON.
2. Press MEM and then press 7.
3. When you hear the access tone, press MEM and then press 8.
4. At the next access tone, press MEM and then 9.

TIP: Don't get in too big of a hurry. Wait for the access tones before pressing the next memory button, or your call might not go through.

TEMPORARY TONE

This feature enables pulse (rotary) service phone users to access touch-tone services offered by banks, credit card companies, etc. Press the TONE button to temporarily make the phone touch-tone compatible. To get information about your bank account, for example, you would:

1. Call the bank's information line.
2. Press the TONE key, denoted with (*) on the keypad, when your call is answered.
3. Follow the voice menu instructions to get the information. When you hang up, the phone goes back to pulse (rotary) service.



ANSWERING MACHINE OPERATION

This section discusses the buttons and features on the answering machine.

MESSAGES INDICATOR

The MESSAGES indicator blinks to show you how many new messages you have. The ANSWER ON/OFF button must be on in order for the MESSAGES indicator to work.

SCREENING CALLS FROM THE BASE

You can screen incoming calls by waiting for the caller to begin leaving a message (to hear who it is), then pick up the handset, and press TALK to talk to the caller. The answering machine automatically stops recording when you activate the handset or pick up an extension phone.


TIP: Make sure the volume on the base is set loud enough to hear your incoming calls.

MESSAGE PLAYBACK

The messages indicator lets you know when you have messages. To play messages, press PLAY/STOP.

While a message is playing, you can do the following:

- Press PLAY/ STOP to stop the message playback.
- Press and release REVIEW to restart the current message; continue to press and release REVIEW to go to previous messages.
- Press and release SKIP to go to the next message.
- Press PLAY/ STOP to stop message playback.



MEMORY FULL

When the memory is full, the system answers after 10 rings. You need to erase some messages so the answerer can record new messages.

ERASING MESSAGES

You can erase messages three ways: one message at a time using the ERASE button on the base; all messages using the ERASE button on the base; or one message at a time using the ERASE button (0) on the handset or a phone in another location.

- **To erase a message**, press PLAY/STOP on the base and press and release ERASE button on the base to erase the message that is playing.
- **To erase all messages**, press the ERASE button on the base when messages have stopped playing.
- **To erase a message from the handset:**
 1. Press ANSWER button on the handset.
 2. Press PLAY/STOP on the handset (the 2 button).
 3. Press ERASE on the handset (the 0 button) to erase the message that is playing.

NOTE: Erased messages cannot be restored. Also, be careful you don't press ERASE button as the next unheard message is playing because that message will also be erased.

LEAVING A MEMO

Use the Memo feature to leave a message.

1. Press and hold the MEMO button. You need to hold the button until you finish the message.
2. Begin talking after you hear the beep.
3. Release the MEMO button when you finish.

REMOTE ACCESS

This section explains two types of remote access: using the handset to access the answering machine and accessing the answering machine from another phone.

The handset contains integrated buttons that enable you access the answering machine with the handset.


You can also access your answering machine from any phone that is tone-dial compatible by entering a 3-digit security code after you hear the outgoing announcement. A voice menu system guides you through all of the procedures.

USING THE HANDSET

Press the ANSWER button to access the answering machine from the cordless handset.

After you access the answerer, use the marked handset keys just as if you were pressing the corresponding buttons on the base (see "Answering Machine Operation" for details on functions). To make it easy for you, the functions are listed on the handset above each number. For example, to play messages:

1. Press the ANSWER button.
2. Press 2 (PLAY/STOP).
3. When you are finished listening to your messages, press ANSWER again.



ANSWERER-IN-USE INDICATOR

You know the answerer is active when you see the Answerer-in-Use indicator on the handset come on.

**SCREENING CALLS
FROM THE HANDSET**

Use the handset to screen calls even when you can't hear the answering machine.


When the phone rings:

1. Press the ANSWER button to gain access to the answering machine.
2. Listen to the caller leaving a message.
3. Press the TALK button to talk to the person or press ANSWER to stop screening the call.

MEMORY FULL

When the memory is full, the system answers after 10 rings, beeps and waits for the caller to enter the 3-digit security code. If you don't enter the security code within 10 seconds after the unit beeps, the phone hangs up.

You need to erase some of the messages in order for the system to record new incoming messages.



NOTE: The unit also answers after the 10th ring if it is turned off. To access the answerer, enter your 3-digit security code after you hear the beep.

ACCESSING THE ANSWERER FROM ANOTHER PHONE

You can access your answering machine from a touch-tone phone by entering your 3-digit security code after you hear the outgoing announcement.

1. Dial the phone number for the answering machine.
2. Enter the security code after you hear the tone.
3. Follow the voice menu to use the answerer's remote functions.

The remote feature enables you to perform the following functions:

<i>To</i>	<i>Press this Button</i>
Review message	1
Play back messages	2
Stop message playback	2
Erase message	0 (during message playback)
Skip message	3
Turn off answerer	4
Review voice menu options	7

TIP: You can bypass the outgoing announcement by pressing any numbered key on the keypad while the announcement is playing. Then, you can enter your security code to access the answering machine.

CHANGING THE SECURITY CODE


The default security code for accessing the answerer from another location is 1 2 3. You must use the handset to change the security code. With the phone off, follow these steps:

1. Press ANSWER (the ANSWER IN-USE indicator comes on).
2. Press TONE (*).
3. Enter 3 numbers to be used as the new security code.
4. Press TONE (*) again.

CHANGING THE BATTERY

Make sure the telephone is **OFF** before you replace battery. Use battery 5-2450 only.

1. Remove the battery compartment door.
2. Disconnect the battery plug and remove the battery pack from the handset.
3. Insert the new battery pack and reconnect the battery plug.
4. Put the battery compartment door back on.
5. Place handset in the base to charge. If you don't charge the handset battery properly (for 12 hours) when you first set up the phone and/or when you install a new battery pack, the battery's long-term performance will be compromised.



BATTERY SAFETY PRECAUTIONS

- Do not burn, disassemble, mutilate, or puncture. Like other batteries of this type, toxic materials could be released which can cause injury.
- To reduce the risk of fire or personal injury, use only the battery listed in the User's Guide.
- Keep batteries out of the reach of children.



NOTE: The RBRC seal on the battery used in your Thomson Consumer Electronics product indicates that we are participating in a program to collect and recycle Nickel Cadmium batteries throughout the United States of America. Please call 1-800-8-BATTERY for information or contact your local recycling center.

GENERAL PRODUCT CARE

To keep your telephone working and looking good, follow these guidelines:

- Avoid putting the phone near heating appliances and devices that generate electrical noise (for example, motors or fluorescent lamps).
- DO NOT expose to direct sunlight or moisture.
- Avoid dropping the handset, as well as other rough treatment to the phone.
- Clean the phone with a soft cloth.
- Never use a strong cleaning agent or abrasive powder because this will damage the finish.
- Retain the original packaging in case you need to ship the phone at a later date.
- Periodically clean the charge contacts on the handset and base with a soft cloth.

TROUBLESHOOTING GUIDE

CORDLESS PHONE SOLUTIONS

<i>Problem</i>	<i>Solution</i>
No dial tone	• Check installation: – Is the base power cord connected to a working outlet? – Is the IN-USE indicator on? – Is the telephone line cord connected to the base unit and the wall jack? • Connect another phone to the same jack; the problem might be your wiring or local service. • Is the handset out of range of the base? • Make sure the battery is properly charged (12 hours). • Is the battery pack installed correctly? • Did the handset beep when you pressed the TALK button? Did the IN-USE indicator come on? The battery may need to be charged. • Place the handset in the base for at least 20 seconds.
Dial tone is OK, but can't dial out	• Make sure the T/P switch on the base is correctly set.
Handset does not ring	• Make sure the RINGER switch on the handset is turned to ON. • Move closer to the base. The handset may be out of range. • You may have too many extension phones on your line. Try unplugging some phones. • Check for dial tone.
You experience static, noise, or fading in and out	• Change channels. • Move closer to base (handset might be out of range). • Does the base need to be relocated? Make sure base is not plugged into an outlet with another household appliance. • Charge battery.

CORDLESS PHONE SOLUTIONS (CONTINUED)

<i>Problem</i>	<i>Solution</i>
Unit beeps	• Place handset in base for 20 seconds; if it still beeps, charge battery for 12 hours. • Clean charging contacts on handset and base with a soft cloth, or an eraser. • See solutions for "No dial tone." • Replace battery.
Memory Dialing doesn't work	• Did you program the memory location keys correctly? • Did you follow proper dialing sequence?

ANSWERING MACHINE SOLUTIONS

<i>Problem</i>	<i>Solution</i>
Can't hear messages, beep, etc.	• Adjust speaker volume.
Time/Day setting stuck at 12 a.m Mon.	• Set the time clock.
Answers on 10th ring	• Make sure answerer is turned on. • Memory may be full.
Incoming messages are incomplete	• Was an extension phone picked up? • Memory is full. • Accidentally pressed PLAY button during playback and stopped message.
Won't respond to remote commands	• Must use tone-dial phone. • Must enter correct security code. • Did unit hang up? If you take no action for a period of time, it automatically hangs up.

HANDSET SOUND SIGNALS

<i>Signal</i>	<i>Meaning</i>
Three long beeps or continuous beeps	Page signal
A long warbling tone (with ringer on)	Incoming call signal
One short beep every few seconds	Battery low

CAUSES OF POOR RECEPTION

- Aluminum siding
- Foil backing on insulation
- Heating ducts and other metal construction that can shield radio signals.
- You're too close to appliances such as microwaves, stoves, computers, etc.
- Atmospheric conditions, such as strong storms
- Base is installed in the basement or lower floor of the house.
- Base is plugged into AC outlet with other electronic devices.
- Baby monitor is using the same frequency.
- Handset battery is low.
- You're out of range of the base.

SERVICE

The FCC requires this product to be serviced only by the manufacturer or its authorized service agents. In accordance with FCC requirements, changes or modifications not expressly approved by Thomson Consumer Electronics could void the user's authority to operate this product. For instructions on how to obtain service, refer to the warranty included in this Guide or call Consumer Information, 1-800-448-0329.

Attach your sales receipt to the booklet for future reference or jot down the date this product was purchased or received as a gift. This information will be valuable if service should be required during the warranty period.

Purchase date _____ Name of store _____

INDEX

A

- Accessing the Answerer from another phone 21
- Accessory Order Form 27
- Advanced Features 13
- Answerer-in-Use Light 20
- Answering Machine Operation 17
- Answering Machine Setup 7
- Answering Machine Solutions 25

B

- Battery Safety Precautions 22
- Before You Begin 4

C

- Causes of Poor Reception 26
- Chain Dialing from Memory 15
- Changing a Stored Number 14
- Changing the Battery 22
- Changing the Security Code 21
- Channel Button 13
- Cordless Phone Basics 10

D

- Desktop Installation 5
- Dialing a Stored Number 14
- Digital Security System 4

E

- Erasing a Stored Number 14
- Erasing Messages 18

F

- FCC Registration Information 2
- Flash Button 11

G

- General Product Care 23
- Getting Started 4

H

- Handset Sound Signals 26
- Hearing Aid Compatibility 2

I

- In-Use Light 10
- Inserting a Pause in the Dialing Sequence 14
- Interference Information 2
- Introduction 3

L

- Leaving a Memo 18
- Limited Warranty 31

M

- Making a Call 10
- Memory Full 18, 20
- Message Playback 17
- Messages Indicator 17
- Modular Jack Requirements 4
- Mute Button 11

P

- Paging the Handset 12

R

- Receiving a Call 10
- Recording the Outgoing Announcement 9
- Redial 10
- Remote Access 19
- Reviewing Announcement 9
- Ringer Switch 11

S

- Screening Calls from the base 17
- Screening Calls from the Handset 20
- Service 29
- Setting the Ring Select 8
- Setting the Speaker Volume 8
- Setting the Voice Time/Day Stamp 7
- Storing a Number in Memory 13

T

- Temporary Tone 16
- The Memory Feature 13
- Troubleshooting Guide 24

U

- Using the Handset 19
- Using Toll Saver 8

V

- Voice Instructions 8
- Volume Button 11

W

- Wall Mount Installation 6

LIMITED WARRANTY

What your warranty covers:

- Any defect in materials or workmanship.

For how long after your purchase:

- One year.

(The warranty period for rental units begins with the first rental or 45 days from date of shipment to the rental firm, whichever comes first.)

What we will do:

- Provide you with a new or, at our option, a refurbished unit.
- The exchange unit is under warranty for the remainder of the original product's warranty period.

How to make a warranty claim:

- Properly pack your unit. Include any cables, etc., which were originally provided with the product. We recommend using the original carton and packing materials.
- Include in the package evidence of purchase date such as the bill of sale. Also print your name and address and a description of the defect. Send standard UPS or its equivalent to:

Thomson Consumer Electronics, Inc.
11721 B Alameda Ave.
Socorro, Texas 79927

- Pay any charges billed to you by the Exchange Center for service not covered by the warranty.
- Insure your shipment in case of loss or damage. Thomson accepts no liability in case of damage or loss.
- A new or refurbished unit will be shipped to you prepaid freight.

What your warranty *does not* cover:

- Customer instruction. (Your Owner's Manual provides information regarding operating instructions and user controls. For additional information, ask your dealer.)
- Installation and set-up service adjustments.
- Batteries.
- Damage from misuse or neglect.
- Products which have been modified or incorporated into other products.
- Products purchased or serviced outside the USA.
- Acts of God, such as but not limited to lightning damage.

Product Registration:

- Please complete and mail the Product Registration Card packed with your unit. It will make it easier to contact you should it ever be necessary. The return of the card is not required for warranty coverage.

How state law relates to this warranty:

- This warranty gives you specific legal rights, and you may have other rights which vary from state to state.

If you purchased your product outside the USA:

- This warranty does not apply. Contact your dealer for warranty information.

Model 26990A
15433010 (Rev. 0 E/S)
99-12
Printed in China

 **THOMSON CONSUMER ELECTRONICS**
© 1999 Thomson Consumer Electronics, Inc.
P.O. BOX 1976, Indianapolis, IN 46206
Trademark(s) ® Registered
Marca(s) Registrada(s)