
USER MANUAL VS-5L

Version 0.1

VACOM WIRELESS, INC.

CONTENTS

IMPORTANT SAFETY INFORMATION

GETTING TO KNOW YOUR PHONE

DISPLAY INDICATORS

BATTERY INFORMATION

BASIC FUNCTIONS

- 1. Making Calls**
- 2. Ending Calls**
- 3. Answering Calls**
- 4. Correcting Entry Errors**
- 5. Storing Phone Numbers**
- 6. Adjusting In-Call Mic Volume**
- 7. Volume**
- 8. Using Caller ID**
- 9. Redialing Last Dialed, Received, or Missed Number**
- 10. Speed Dial**
- 11. Keypad Lock**
- 12. Etiquette Mode**
- 13. Silence Mode**
- 14. Shortcut**

MENUS

I. PHONE BOOK

- 1. Phone Book Search**
- 2. Phone Number Addition**
- 3. Call List**
- 4. My Number**
- 5. Delete Phone Book**

II. PHONE SETTINGS MENU

- 1. Wallpaper**
- 2. Languages**
- 3. Selecting Font**
- 4. Backlight**
- 5. LCD Contrast**
- 6. Screen Saver**
- 7. Auto Keylock**

III. VOLUME & ALERT

- 1. Ring Type**
- 2. Selecting Bell**
- 3. Roam Ringer**
- 4. Volume**
- 5. Alert Setting**
- 6. Beep Length**

IV. PERSONAL INFORMATION MANAGEMENT

- 1. Alarm**
- 2. Schedule**
- 3. Calendar View**
- 4. Calculator**
- 5. Memo**
- 6. World Time View**

V. SECURITY FUNCTIONS

- 1. Phone Lock**
- 2. Changing Password**
- 3. Restricting**
- 4. Privacy Information**
- 5. Initialization**

VI. CALL INFORMATION

- 1. Auto Answer**
- 2. Call Answer**
- 3. Auto Redial**
- 4. Call Time**

VII. GAMES

- 1. Black Jack**
- 2. Othello**
- 3. Game Sound**

MESSAGE SERVICES

I. TEXT MESSAGE SERVICES (SMS)

- 1. Reading Text Messages**
- 2. Sending Text Messages**

II. VOICE MAIL SERVICE

III. SMS Settings

- 1. Alert**
- 2. Save Message**
- 3. Direct View**
- 4. Delivery ACK**
- 5. Priority**
- 6. Delete All**

USING MENU DURING CALLS

- 1. Phone Book Search**
- 2. Mute**
- 3. DTMF Mute**
- 4. Volume**
- 5. Mic Volume**
- 6. Voice Privacy**

IMPORTANT SAFETY INFORMATION

Some of the following information may not apply specifically to your phone. However, as with any electronic product, these safety precautions should be observed when using this product.

- ? Please keep this manual in a safe place, for it contains important safety information and operating instructions.
- ? Please follow and adhere to all warning, safety, and operating instructions indicated on both the phone and in this manual before use.
- ? **Do Not** expose the phone to water or moisture.
- ? **Do Not** expose the phone to extreme heat or cold.
- ? **Do Not** expose the phone to open flame.
- ? **Do Not** allow objects to fall or liquids to spill on the product.
- ? Use **Original Accessories** only. Any damage incurred from the use of non-approved accessories will void the warranty.
- ? Use approved chargers only and connect to a power source designated on the product.
- ? To reduce the risk of injury, remove the electrical cord from an outlet by pulling on the charger, rather than the cord.
- ? Ensure that the electrical cord is positioned accordingly so that it will not be vulnerable to damage.
- ? To reduce the risk of electrical shock, unplug the phone from the power source before cleaning. Once unplugged, use a soft cloth dampened with water to clean.
- ? **DANGER: Do Not** modify the cord or the plug. If the plug does not fit into an outlet, have a proper outlet installed by a qualified electrician. Improper connection can result in electrical shock.
- ? **Do Not** attempt to disassemble the product – doing so will void the warranty. This product does not contain consumer-serviceable components. Service should be performed only by authorized service centers.
- ? **Do Not** remove the antenna. A detached antenna can be a choking hazard for children.
- ? **Do Not** place the battery inside the mouth. The battery contains toxic electrolytes that are harmful for your health.

GETTING TO KNOW YOUR PHONE

LED Indicator

: Flashes to indicate an incoming call or message. It also lights up (flashes) when you turn on the phone.

Backlit LCD Screen

: The LCD screen contains three areas;

- The top line displays indication about your phone's operating mode.
- Two lines in the middle are the display areas for numbers and characters.
- The bottom line displays menus.

Menu Keys (/

: This key performs several useful functions.

- During incoming calls, press it to answer the incoming call.
- In Standby mode, press it briefly to access Main Menu and Select Menu.
- When navigating a menu, press it to select the highlighted selection.

SMS Key (

: When in Standby Mode, press this key to access Message Menu items.

Navigation Key (? ?)

: This key allows you to navigate the phone's variable functionality and useful shortcut.

Microphone

: Your typical voice microphone for conversation and you can also mute the microphone during conversation by pressing "MENU" "2".

DC Jack

: The location where you connect your charging device.

CLR Key

: This key is used to erase numbers or characters you may have entered incorrectly, or to return to a previous screen.

- To erase one character from the display screen, briefly press it once.
- To erase all of them, hold it for one second.
- To back up one menu level, press it once.
- To return to Standby Mode, hold it for one second.
- During a call, press it to control earpiece volume.

END() Key

: Press this key to disconnect a call or to return to Standby Mode from any menu. Press and hold this key to turn the phone On or Off.

SEND() Key

: This key performs several useful functions.

- Dial a number and press it to connect.
- Press it once to redial the last outgoing number.

Numeric Keys

: These keys are to dial and to input numbers and characters.

? *

: This key performs several useful functions.

- Change bells to vibration
- Use as navigation key.

?

: This key performs several useful functions.

- Use as instance phone lock.
- Use as navigation key.

Antenna

DISPLAY INDICATORS

Display indicators appear across the bottom of your phone's LCD screen. These display indicators (or icons) will vary based on your phone's operating modes.



Signal strength : This icon shows your current signal strength. More lines indicate more signal strength. Five lines indicate maximum strength, and one line indicates least strength.



No service indicator : This icon indicates your phone cannot find a signal because you're outside a service area. When this is displayed, you cannot make or receive calls. Wait a little while for a signal or move into an open area.



Roaming : This icon indicates you are "roaming" on to other carrier's service area. But you must register the roaming service.



Vibrator on : This icon means that an incoming call will vibrate the phone rather than ring it or before/after the phone ring.

It also means that your phone is on Etiquette mode. An incoming call will vibrate the phone rather than ring it. This feature is good for quiet situations where you don't want your ringer to disturb anyone.



Message indicator : This icon indicates you have message(s) waiting. Press SMS Menu button to see the message menu, or press and hold to be connected to voicemail.



Alarm on : This icon means that you set the alarm On.



Battery strength : This icon shows the level of your battery charge. The more black bars you see the greater the charge. When the battery becomes very low, an empty box appears and the phone flashes an alert.



This icon shows that you are in CDMA coverage area. (Cellular only)

BATTERY INFORMATION

The rechargeable Lithium-polymer battery included in your kit is partially charged so that you can use the phone immediately once it has been activated.

Attaching the Battery

To attach the battery to your phone:

1. Lineup the metallic contacts on the base of the battery to the base of the phone.
2. Place the battery on the back of the phone, with the top of the battery about a quarter of an inch from the latch.
3. Gently slide the battery towards the top of the phone until it snaps into place.

Charging the Battery

You can tell whether your battery needs to be recharged or not by checking the upper-right corner of your phone's display.

When the battery charge level becomes low, the battery sensor will alert you by blinking the battery icon and making an audible warning tone. The phone will automatically power itself off if the battery level becomes critically low, and any incoming or outgoing call will disconnect. To avoid such disconnection, be mindful of the battery strength indicator and make sure your battery is sufficiently charged.

Charging with a Travel Charger

Using an unauthorized accessory may be dangerous and will void the warranty if it causes damage to the phone.

To charge the Battery using a Travel Charger:

- Plug the power cord of the charger into a wall outlet.
- Insert the charger's connector to the DC jack of the phone.

Note) Ensure a proper connection of the charger and the phone. Incomplete connection may cause damage to the phone.

A completely discharged standard sized battery charges full in approximately tbd hours. Leaving your phone powered on during charging or charging two batteries simultaneously will increase charge times. Leaving the battery connected to the charger after it has been fully charged will not harm the battery.

? WARNING

After the battery is fully charged, the battery can be discharged. If the charger is connected to your phone for over 3hrs, please pull the plug from the phone and recharge the battery even if the battery is fully charged.

Turning your phone on and off.

When you're ready to turn on your phone, press and hold "END()" until the display is turned on and the phone makes the sound. When the phone has found a signal, the "" icon appears. Once the phone is turned on, it enters Standby mode and you are able to make and receive calls.

To turn your phone off, press and hold "END()" until the display is turned off and the phone makes the sounds. Then the display will go blank. When the phone is turned off, nothing is displayed on screen.

Note: If "END()" is pressed for less than one second, the phone will not be turned off. This function prevents your phone from being turned off accidentally.

Standby Mode.

Standby is the most basic state of your phone. The phone goes into standby mode soon after you turn it on, or whenever you briefly press "END()". When your phone is in Standby Mode, you will typically see the banner (that's the message displayed when you turn on your phone). If you enter a phone number, you press "SEND()" to complete the call, or press "STO ()" to save it in the internal phone book.

Power Save Mode

Your phone comes with a Power Save feature that will automatically be activated if your phone is unable to find a signal after 15 minutes of searching. While this feature is active, the phone's battery power is conserved.

The phone will automatically recheck for a signal periodically. To manually force the phone to recheck for a signal, press any key. A message on the display will let you know when the phone is operating in Power Save Mode.

Conversation Mode.

You can place and answer calls only when your phone is turned on. During a call, the phone is in Conversation Mode.

BASIC FUNCTIONS

1. Making Calls

In standby mode, enter the phone number (up to 32 digits) by pressing the digit keys. The phone number is displayed from left to right. Press “SEND(

2. Ending Calls

To end a call, press “END(

3. Answering Calls

To answer an incoming call, press any key if “Any Key Answer” is set. (Please refer to “2. Call Answer” in “VI. Call Information”). If your phone is registered in Caller ID, a caller’s phone number will be displayed on screen. If caller’s number is stored in Phone Book, the caller’s name will be displayed.

4. Correcting Entry Errors

To correct a misdialled digit, press “CLR” to erase one digit at a time. You can erase all the digits at once by pressing “CLR” and holding it down over one second.

5. Storing Phone Numbers

Phone numbers for frequently used services are pre-programmed into your phone. To store a number,

- Enter a phone number and press “STO (

6. Adjusting In-Call Mic Volume

To adjust the in-call mic volume:

- Press MENU (

-
- Press “? ” to increase and “? ” to decrease the mic volume.

Once a call has ended, the mic volume reverts back to factory set level.

7. Volume

You can adjust volume of the earpiece by using the volume keys on the side of the phone.

Briefly press the volume key once to display your current earpiece volume setting. Repeatedly press the volume key to adjust.

To adjust earpiece volume during a call, press “? ? ” to increase or decrease earpiece volume.

8. Using Caller ID

This feature informs you of the caller’s identification by displaying their number when the phone rings.

If the corresponding caller’s information is already available in your Phone Book, that caller’s name will appear on screen. Conversely, calling someone who has this feature will disclose your number on their phone. To access the call log, press “SEND(

9. Redialing Last Dialed, Received, or Missed Number

Up to 30 dialed, received, or missed can be redialed directly. Simply press “SEND(

- Access the call log of 30 call entries in chronological order.
- Then, press the “VIEW (

10. Speed Dialing

Once a phone number is stored in your Phone Book, you can access and dial that number using assigned speed dial keys. Press the location number of a stored number and hold the last digit.

The phone will then automatically connect to that number.

11. Keypad Lock

You can lock the keypad to prevent the keys being accidentally pressed, for example, when your phone is in your pocket. You can do it by pressing “(#)? ” for a second in standby mode.

12. Etiquette Mode

In social situations where audible rings, bells, or tones are inappropriate, such as in a movie theater, at a museum, play, etc, your phone can be set on Etiquette mode. All incoming calls under this mode will be notified by inaudible vibration. Press and hold “? *” to set the Etiquette mode and once more to cancel.

13. Silence Mode

If you want to silence an incoming ring, for example, when you are in a meeting, press “END(

Note 1) Although the incoming ring is silenced, the call is still coming. If you want to answer, press any keys.

Note 2) When you press “END(

14. Short Cut

- i. **Keypad Lock** : Press and hold “(#) ? ” for a second when it’s in Standby Mode, and the keypad will be locked. To unlock the keypad, press “

14

MENUS

I. PHONE BOOK

1. Phone Book Search

You can go to Phone Book list by pressing “?” to see all the phone number list you stored alphabetically. Also you can find a phone number according to Name, Location Number, Phone Number or Group.

a. Search by name

You can find a number you stored in Phone Book by entering a name.

- Press “Menu (📞)” , “1. Phone Book”, “1. Search” and select “1. Name”.
- Enter the name you want to call.
- If you don’t remember the full name, just enter the first letter of the name. Your phone will show you all similar names.
- Press “SEND(📞)” to dial.
- Or press “View (📞)” to edit or “Del (📞)” to delete.

b. Search by location

You can find a number you stored in Phone Book by locations.

- Press “Menu (📞)” , “1. Phone Book”, “1. Search” and select “2. Speed Key”.
- Enter the location number you want to find and press “Ok”.
- Press “SEND(📞)” to dial. Or press “View (📞)” to edit or “Del (📞)” to delete.
- If a number is not stored in the location, “Empty Location” is shown on the display.

c. Search by Number

You can find a number’s information you stored in Phone Book by entering a phone number.

- Press “Menu (📞)” , “1. Phone Book”, “1. Search” and select “3. Phone Number”.
- Enter the number you want to see and press “OK”. Then you will see the name and location.
- Press “SEND(📞)” to dial. Or press “View (📞)” to edit or “Del (📞)” to delete.
- If the number is not stored in the location, a warning tone is sounded and “No Number Matches” is shown on the display.

d. Search by group

You can find a number you stored in Phone Book.

- Press “Menu (📞)” , “1. Phone Book”, “1. Search” and select “4. Group”.
- Scroll “? (*)” or “(#)?” to select “No Group”, “Family”, “Friends”, “Business” or “Company”.
- Once you select “No Group”, “Family”, “Friends”, “Business” or “Company”, you can

see the numbers you stored and defined only as “No Group”, “Family”, “Friends”, “Business” or “Company”.

- Place the cursor on the number you want to dial by scrolling “? ” and “? ”.

Press “SEND(

2. Phone Number Addition

Phone numbers for frequently used services are pre-programmed into your phone. To store a number,

- Press “Menu (

3. Call List

Call history, including number, time, and duration, can be referenced by:

- Pressing “MENU (

A log of dialed, received, and missed calls will be displayed.

4. My Phone Number

To see your phone number, Press “Menu (

5. Delete Phone Book

If you want to clear call lists, which you missed, called, received and stored, or all in Phone Book.

- Press “Menu (

II. PHONE SETTING

1. Wallpaper

You can have the phone display various welcome greeting on stand-by mode. To edit the

greeting for the display on stand-by mode:

a. Set Wallpaper Type

- Press “Menu ()”, “2. Phone Setting”, “1. Wallpaper” and “1. Set Wallpaper”.
- Scroll “? ? ” to select a wallpaper and press “OK ()” to save.

b. Greeting Edit

- Press “Menu ()”, “2. Settings”, “1. Wallpaper”, “2. Greeting Edit”.
- Edit the banner and press “OK ()” to set.

2. Languages

You can set the phone to 2 different languages. (Spanish, Portuguese and English).

- Press “Menu ()”, “2. Phone Setting” and “2. Language”.
- Select “Spanish”, “Portuguese” or “English”, and press “OK ()” to save.

3. Selecting Font

You can select a font for the display among 4 fonts

- Press “Menu ()”, “2. Phone Setting” and “3. Font Select”.
- Scroll “? ? ” to select a font and press “OK ()” to save.

4. Backlight

You can set backlighting of LCD display and the keypad automatically turned off in 10, 20 and 30 seconds or set always off. To set back light;

- Press “Menu ()”, “2. Phone Setting” and “4. Backlight” and choose “1. LCD Light” or “2. Keypad Light”
- Select “10 seconds”, “20 seconds”, “30 seconds” or “Always Off” and press “OK ()” to save.

5. LCD Contrast

You can adjust LCD contrast.

- Press “Menu ()”, “2. Phone Setting” and “5. Contrast”.
- Scroll “? ” and “? ” to adjust LCD contrast and press “OK ()” to set.

6. Screen Saver

You can set Screen Saver of Standby mode.

- Press “Menu ()”, “2. Phone Setting” and “6. Screen Saver”
- Scroll “? ? ” to select a Screen Saver type.
- Press “? ” and Select “After 10 seconds”, “After 30 seconds” or “After 1 minute” and press “OK()” to store.

7. Auto Keypad Lock

If you set “Auto Keypad Lock” as “Auto”, the keypad will automatically locked after 30 seconds when you don’t use.

- Press “Menu (📞)”, “2. Phone Setting” and “7. Auto Keypad Lock”.
- Select “Auto” or “off” and press “OK (📞)” to set.
- If you want to release the keypad lock, press “MENU📞” and “(#) ? ” on a standby mode.

III. VOLUME / ALERT

1. Ring Type

You can set the alert for incoming calls in 5 different ways. (Bell, Vibration, Bell→Vibration, Vibration→Bell, Vibration+Bell).

- Press “Menu (📞)”, “3 Vol/Alert” and “1. Ring Type
- Select “Bell”, “Vibrator” “Bell→Vib”, “Vib→Bell” or “Vib+Bell” by scrolling “? ? ”
- Press “OK (📞)” to set.

2. Selecting Bell

This option enables you to set the sound of ringing among 10 bells,10 melodies and 32 midi sounds.

- Press “Menu (📞)”, “3. Vol/Alert” and “2. Bell Select” and choose “1. Bell”, “2. Melody” or “3. MIDI.
- Scroll “? ? ” or “? ? ” to select. While you scroll, you can hear bells and melodies.
- Press “OK (📞)” to set.

3. Roam Ringer

This option allows you to hear a distinctive ringing when you receive a call in other carriers’ service area, which you registered for a roaming service.

- Press “Menu (📞)”, “3. Vol/Alert” and “3. Roam Ringer”.
- Choose “on” or “off” and press “OK (📞)” to set.

4. Volume Control

a. Bell Volume

This option allows you to set the bell volume level.

- Press “MENU (📞)”, “3. Vol/Alert”, “4. Volume”, and “1. Bell Volume”.

-
- Scroll “? /? ” to increase or decrease the volume level.
 - Press “OK ()” to set.

b. Key Volume

This option allows you to set the key volume level.

- Press “MENU ()”, “3. Vol/Alert”, “4. Volume”, and “2. Key Volume”.
- Scroll “? /? ” to increase or decrease the volume level.
- Press “OK ()” to set.

c. Call Volume

This option allows you to set the earpiece volume level.

- Press “MENU ()”, “3. Vol/Alert”, “4. Volume”, and “3. Call Volume”.
- Scroll “? /? ” to increase or decrease the volume level.
- Press “OK ()” to set.

5. Alert Setting

a. Connection Beep

This option allows you to be audibly notified when a call is connected.

- Press “MENU ()”, “3. Vol/Alert”, “4. Alert Setting”, and “1. Connection”.
- Select between On and Off and press “OK ()” to set.

b. Call Drop

This option allows you to be audibly notified when a call is disconnected or the other party hangs up the phone.

- Press “MENU ()”, “3. Vol/Alert”, “4. Alert Setting”, and “2. Drop”.
- Select between On and Off and press “OK ()” to set.

c. 1 Minute Alert

This option allows you to be audibly warned when a call reaches the 1 minute mark.

- Press “MENU ()”, “3. Vol/Alert”, “4. Alert Setting”, and “3. Minute”.
- Select between On and Off and press “OK ()” to set.

d. Service

This option allows you to be audibly warned when you move into other base stations during a call.

- Press “MENU ()”, “3. Vol/Alert”, “4. Alert Setting”, and “4. Service”.
- Select between On or Off and press “OK ()” to set.

6. Beep Length

DTMF tone length can be set at normal or long.

- Press “MENU ()”, “3. Vol/Alert”, and “6. Beep Length”.

Set the beep length “Normal” or “Long” and press “OK ()” to set.

IV. PERSONAL INFORMATION MANAGEMENT

Your phone supports various additional functions, including Alarm, Schedule, Calendar, Calculator, Memo and World Time.

1. Alarm

The 24-hour alarm can be set to go off at a set time while your phone is on. If the phone is powered off at the set time, the alarm will not sound. To set the alarm, press “MENU ()”, “4. PIM”, and “1. Alarm”.

- Choose “Alarm 1” or “Alarm 2” and press “OK ()”.
- Choose from Off, Everyday, Mon~Sat, Mon~Fri, and Once Alarm by scrolling “? ? ”.
- Press “? ” and choose a Bell type by scrolling “? ? ”.
- Press “? ” and enter the time, and then select AM or PM by pressing “()”
- Press “STO ()” to set.

Note 1) You can set up to 2 different alarms.

Note 2)

- Disable: Once you’ve chosen Disable, the alarm will not sound even if you’ve set a time for it.
- Everyday: Once you’ve chosen Daily, the alarm will sound at the set time everyday.
- Mon~Sat: Once you’ve chosen Mon~Sat, the alarm will sound at the set time from Monday to Saturday.
- Mon~Fri: Once you’ve chosen Mon~Fri, the alarm will sound at the set time from Monday to Friday.
- Once Alarm: Once you’ve chosen Once, the alarm will only sound at the set time once.

2. Schedule

The Schedule Manager option helps to manage your schedule using the phone. To set or edit a schedule, press “MENU ()”, “4. PIM”, and “2. Schedule”.

a. Add Schedule :

- Select “1. Add”. Calendar of the current month will then appear on the display.
- Use “? ? ” and “? ? ” to scroll through the days and select the date by pressing “OK()”
- Enter the time (hour, minute and AM/PM) and press “OK()”
- Enter a memo under “Input Schedule”. Once you finish entering a memo, press “OK

().

- Scroll “? ? ” to choose the bell type.
 - Press “STO ()” to save.
- b. Schedule List : You can see the schedule list you stored.
- Select “2. List”. Then you can see the schedule list orderly.
 - To edit a schedule, choose a list by scrolling “? /? ” and pressing “OK ()”. You can then edit a schedule in the same manner as above.
 - Or delete a schedule by simply pressing “DEL ()”. Press “OK ()” to erase once the display prompts “Delete?”
- c. Schedule Delete : You can delete all schedules.
- Select “3. Delete”.
 - The phone will then prompt “Delete All?”
 - Press “OK ()” to erase.

3. Calendar View

Your phone can show you a calendar by pressing “MENU ()”, “4. PIM”, and “3. Calendar”.

4. Calculator

Your phone can double as a calculator. Press “MENU ()”, “4. PIM”, and “4. Calculator”.

5. Memo

The Memo option helps you to manage your daily tasks. To create or edit a Memo, press “MENU ()”, “4. PIM”, and “5. Memo”.

- a. Add Memo :
- Select “1. Add”.
 - Enter or edit your task and press “OK ()”.
- b. Memo List :
- Select “2. List”. The phone will then display a list of all stored memos.
 - Select by scrolling “? ” and “? ” and press “OK ()”.
 - The memo and stored time will then be displayed.
 - To edit, press “EDIT ()”.
- c. Delete :
- Select “3. Delete”. The phone will then prompt “Delete All?”.
 - Press “OK ()” to delete all memos.
 - Or if you would like to delete individual memos, choose a memo list and press

“DEL(

6. World Time View

Your phone is capable of displaying current times of the world. To access the world time view;

- Press “MENU (

V. SECURITY FUNCTION

Your phone provides many security options, including a user-programmable lock code and call restriction features. To access the Security Menu in Standby Mode, press “Menu (

Note: The password is “0000” if you don’t have your phone number yet or the last 4 digits of your number if you already have your phone number. If you want to change the password, see “Changing Password” on page --.

1. Phone Lock

Locked phone limits all outgoing calls except calls to the three hard-coded emergency numbers. You can lock the phone manually or set the phone to lock automatically when it is turned on. When the phone is in Lock Mode, you can answer incoming calls, but you must unlock the phone to place the outgoing calls (except designated emergency numbers).

- Press “Menu (

Notes 1) “Now” – The phone is locked from now.

“On Power Up” – The phone is locked automatically when it is turned on.

“Never” – The phone is unlocked.

Note 2) You can simply lock your keypad by pressing and holding “#” on Standby Mode.

2. Changing Password

If you want to change the password:

- Press “Menu (

22

-
- Enter the new password again and press “OK (📞)” to set.

3. Restricting

“Restricting” restricts outgoing calls, access to stored phone book and message service without entering correct password. To set restriction, press “MENU (📞)”, “5. Security”, and “3. Restrict”.

a. Call Restriction:

- Press “1. Call Restrict” and enter the password.
- Select “Yes” or “No” and press “OK (📞)” to set.

b. Phone Book :

- Press “2. Phone Book” and enter the password.
- Select “Yes” or “No” and press “OK (📞)” to set.

c. Message :

- Press “3. Message”, and enter the password.
- Select “Yes” or “No” and press “OK (📞)” to set.

4. Voice Privacy

You can set “Voice Privacy” on or off.

- Press “Menu (📞)”, “5. Security” and “4. Voice Privacy”, and enter the password.
- Choose “Standard” or “Enhanced” and press “OK (📞)” to set.

5. Initialization

“Initialization” lets you initialize your phone.

- Press “Menu (📞)”, “5. Security” and “5. Initialize”, and enter the password.
- Select “1. Part Initial” or “2. Full Initial”.
- Select “Yes” or “No” and press “OK (📞)” to set.
- Then your phone display “Initializing”.
- And your phone will be turned off and turned on automatically.

Note) Part Initial – The phone is initialized except PIM, Phone Book and Messages.

Full Initial – The Phone is initialized including PIM, Phone Book and Messages.

VI. Call Information

1. Auto Answer

With this option on, phone answers a call automatically.

-
- Press “MENU (📞)”, “6. Call Info” and “1. Auto Answer”.
 - Choose “Off”, “Always” or “Earphone” and press “OK (📞)” to save.

2. Call Answer

Calls can be answered either by pressing a SEND(📞)key or by pressing anykey.

- Press “MENU (📞)”, “6. Call Info” and “2. Call Answer”.
- Choose “Any Key” or “Send Key” and press “OK (📞)” to save.

3. Auto Redial

- Press “MENU (📞)”, “6. Call Info” and “2. Auto Answer”.
- Choose “On” or “Off” and press “OK (📞)” to save.

4. Call Time

The Call Time option shows approximate duration of the last call, the total call time in hours and minutes and the total number of calls made under the current phone number.

- a. Last Call : Press “MENU (📞)”, “6. Call Info”, “4. Call Time”, and “1. Last Call”. Your phone will then indicate an approximate duration of the last call made in minutes and seconds.
- b. Home Calls : Press “MENU (📞)”, “6. Call Info”, “4. Call Time”, and “2. Home Call”. Your phone will then indicate an approximate total time in hours and minutes that the phone has been used in your provider’s service area.
- c. Roam Calls : Press “MENU (📞)”, “6. Call Info”, “4. Call Time”, and “3. Roam Call”. Your phone will then indicate an approximate total time in hours and minutes that the phone has been used in roaming areas.
- d. All Calls : Press “MENU (📞)”, “6. Call Info”, “4. Call Time”, and “4. All”. Your phone will then indicate an approximate total time in hours and minutes that the phone has been used in home and roaming areas.

VII. GAMES

You can enjoy such entertaining games as Blackjack and Othello with your phone.

1. Black Jack

Press “MENU (📞)”, “7. Games” and “1. Black Jack”. To view game help message, press “HELP(📞)”.

2. Othello

Press “MENU (📞)”, “7. Games” and “2. Othello”. To view play keys of Othello, press

“MENU (

3.Game Sound

To set the phone in silent mode while playing games, press “MENU (

25

MESSAGE SERVICES

Your phone can send and receive two types of message services – text (SMS: Short Messaging Service) and voice - if the services are available from your carrier. If you subscribe to either or both services, callers can leave you text messages or voice mail. Your service provider then transmits the text messages and voice mail notifications to your phone

I. Text Message Services (SMS : Short Messaging Service)

The text message service is depended to the system used by your service provider.

Your service provider transmits the messages to your phone. If your phone is turned on, it can receive the messages as described below. If your phone is not turned on, your service provider retains the messages and transmits them again later.

When a new text message is received, your phone makes an alert tone or vibrates and  is displayed on screen. If you read the new message,  will disappear.

Note) Your phone can store up to TBD text messages or TBD KB.

1. Reading Text Messages

If your phone is turned on while the text message is coming through, it will notify you by either making the alert sound or by vibrating and  will be displayed on screen. You can select read the message immediately by pressing “SMS ” key.

To read a new message:

- Press “SMS ()”, “1. View” and “1. Inbox”.
- Select messages and press “OK ()” to see. Then the received time, the sender, the sender’s phone number, and the new text message will appear on screen.
- You can read the text message by scrolling “? ? ” keys.
- If you want to reread the message, Press “Menu ()”, “2. Message” and “1. Inbox”. Then you can see the message list on screen. Select the message you wish to read again and press “OK ()”. Or press “DEL ()” to delete.

While reading a message, press “OPT ()” to reply or forward this message or to store a phone number or message contents. Or press “DEL ()” to delete.

- a. Choose “1. Reply” to reply the message. Edit the message and press “YES ()”. Then you can send a message as the same manner as “2. Send Text Message” on page ____.
- b. Choose “2. Forward”. Edit the message and press “YES ()”. And enter the number you want to forward this message.
- c. Choose “3. Number Store”. Then you can store a phone number received with the message as the same manner as “3. Phone Number Addition” in “I. Phone Book” on page ____.

-
- d. If you wish to call the sender back, press “SEND ” while you are reading the message. Then “Call back #” appears on screen.

2. Sending Text Messages

You can send the text messages through your phone. To edit and send the text message, press “SMS (

- Choose “1. New MSG”, “2. Sent MSG” or “3. Message Box”. You can then write a new message, or edit sent messages or message in Message Box . Press “OK (?)” to complete.
- Enter a phone number you want to send to. Press “OK().
- Scroll “? /? ” and press “? ? ” to set message priority, message save, or delivery ACK.
- Press “OK (

3. Deleting Messages

You can delete a message one by one or delete all messages at once. To delete a message:

- Press “Del (

II. Voice Mail Service

Your phone can receive voice mail notification when it is turned on. If your service provider transmits the notification and your phone is turned off, you will receive the notification when you turn your phone on.

If your phone is turned on when it receives a voice mail notice, your phone makes an alert sound or vibrates and  is shown on screen. Once you listen to the new voice message,  will disappeared.

Note) Sometimes  wouldn't disappear even if you checked the message. It depends on the condition of the service providers' system.

If your phone is turned on when it receives a voice message, your phone will make the alert sound or vibrates and  will be displayed on screen. To listen to a voice message:

- Press “SMS (

27

-
- Choose “3. Number Store” to store a phone number received with a voice mail.
 - If you want to delete the message, press “DEL (📞)” while you are reading the voice mail list.
 - If you want to call the sender back, simply press “SEND(📞)” while you are listening to the voice mail.

Note) Voice mail feature may work differently depending on your service region. In certain regions, you can listen to the voice mail by pressing “Listen (📞)” while in the voice mail message view. In this case, you will not be able to use the Reply and Number Store options.

III. SMS Setting

1. Message Alert

You can select message alerts from 5 different settings (Lamp Only, Bells, and Vibrate).

- Press “SMS(📞)”, “3. SMS Setting”, “1. Message Alert” and “1. Alert type”
- Select from “Bell 1/2/3”, “Vibrator” and “None”
- Press “OK (📞)” to set.

You can also set the interval of alert.

- Press “SMS(📞)”, “3. SMS Setting”, and “1. Message Alert” and “2. Interval”
- Select “Once” or “2 min”
- Press “OK (📞)” to set

2. Save Message

To save the read message in the phone:

- Press “SMS(📞)”, “3. SMS Setting”, and “2. Save MSG”.
- Choose “Always” and press “OK (📞)” to save.

3. Direct View

To view received messages as soon as they are transmitted:

- Press “SMS(📞)”, “3. SMS Setting”, and “3. Direct View”.

Choose “On” and press “OK (📞)” to save.

4. Delivery ACK

To set Delivery ACK, press “SMS”, “3. SMS Setting”, and “4. Delivery ACK”. Then, choose between “On” and “Off” and press “OK(📞)” to set.

5. Priority

You can assign different priority levels for your messages. To do so:

-
- Press “SMS(

6. Delete All

You can delete all messages of Inbox or Outbox:

- Press “SMS”, “3. SMS Setting”, and “6. Delete All”.
- Choose “Inbox” or “Outbox” and “On” and press “OK (

29

Using Menu During a Call

1. Phone Book Search

During a call, press “Menu (

2. Mute

During a call, press “Menu (

3. DTMF Mute

During a call, press “Menu (

4. Volume

To adjust earpiece volume during a call, press “? ? ” to increase or decrease earpiece volume.

5. MIC Volume

- Press MENU (?) and “5. MIC Volume”.
- Press “? ” to increase and “? ” to decrease the mic volume.

Once a call has ended, the mic volume reverts back to factory set level.

6. Voice Privacy

Refer to “4. Voice Privacy” in “V. Security Setting” on Page__.

BATTERY LIFETIME

	Bateria	Tiempo de conversacion	Tiempo de reserva
Cellular digital	3.7V Li-ion 900mAh	Desde TBD min hasta TBD min	Hrs con min Hasta hrs con min
PCS	3.7V Li-ion 900mAh	Desde TBD min hasta TBD min	Hrs con min Hasta hrs con min
Analogo	3.7V Li-ion 900mAh	Desde TBD min hasta TBD min	Hrs con min Hasta hrs con min

FCC RF EXPOSURE INFORMATION

Read this information before using your handset

In August 1996 the Federal Communication Commission (FCC) of the United States with its action in Report and Order FCC 96-326 adopted an updated safety standard for human exposure to radio frequency (RF) electromagnetic energy emitted by FCC regulated transmitters. Those guidelines are consistent with the safety standard previously set by both U.S and international standards bodies. The design of this phone complies with the FCC guidelines and these international standards. Use only the supplied or an approved antenna. Unauthorized antennas, modifications, or attachment s could impair call quality, damage the phone, or result in violation of FCC regulations.

Do not use the phone with a damaged antenna. If a damaged antenna comes into contact with the skin, a minor burn may result. Please contact your local dealer for replacement antenna.

Body-worn Operation

This device was tested for typical body-worn operations. To comply with FCC RF exposure requirements, a minimum separation distance of 0.6 inches (1.5 cm) must be maintained between the user 's body and the handset, including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Bodyworn accessories that do not meet these requirements may not comply with FCC RF exposure requirements and should be avoided.

For more information about RF exposure, please visit the FCC website at www.fcc.gov