



NovoDisplay

VKA-K1 User Manual

(For DK430, DK550, DK650 and DK750 models)

Contents

Statements	1
SafetyInstructions	2
InstallationProcedure	3
ExternalInterface	4
ConnectionandSettings	5
DriverInstallation	7

Copyright Statements

Copyright

The user manual (including all pictures, illustrations and software) is protected by the international copyright right law. All rights are reserved. No duplication of the manual or any content included in the manual is allowed without the written consent of the manufacturer.

Vivitek is a trademark of Delta Electronics, Inc. ©All rights reserved. 2017

Disclaimer

The information in the manual is subject to change without notice. The manufacturer does not provide any statement or warranty of the contents in the manual and clearly give up the implied warranties of merchantability and of fitness for a particular purpose. The manufacturer reserves the rights to modify the publication and change the contents of the materials at any time without notice to any person.

About the Manual

The manual describes how to install and use the display and is applicable to the end-user. Relevant information (such as illustrations and descriptions) is put on the same page as possible as we can. The format, easy for printing, is convenient for reading and paper-saving which is beneficial to environmental protection. It is suggested printing the page you need.

.

Safety Instructions



1. Please carefully read the User Manual before using the product;
2. Before removing the product, please unplug the AC power cord from power socket;
3. Before connecting or disconnecting any signal cables, make sure that all the power cords are unplugged in advance;
4. To avoid damages caused by frequent startup and shutdown, wait for at least 30 seconds before restarting the product;
5. All the operations such as removal or installation shall be implemented on the electrostatic discharge (ESD) worktable, because some precision components are sensitive to electrostatic discharge;
6. If there is no ESD worktable, please take the following measures to minimize possible damages from electrostatic discharge;
Wear an antistatic wrist strap during operation;
Always touch the metal chassis or frame of the corresponding products before removal or installation of any components;
7. The normal working temperature for the product is 0°C~40°C, and the normal working humidity is 10%~90%;
8. Assure good cooling and ventilation;
9. Dispose or recycle the obsolete batteries properly. Keep children away from the batteries and do not throw the batteries into fire to avoid injuries;
10. There are heating holes on back cover, do not spray water to it or use damp cloth for cleaning;
11. Please call professional personnel for maintenance service.

Installation Procedure





Warning: Please make sure the power cord is disconnected before conducting the following operations.



1 > Screw off and take off the metal plate.




2 > Insert the PC module as shown on the left picture until the upper and lower shrapnel snap into place.



3 > Adjust the antenna to fold it upwards.




ExternalInterface



1		WiFi antenna interface
2		Anti-theft lock
3		Connected to device with DisplayPort input function
4		USB 3.0 interface to connect USB devices, such as mobile hard disk, U disk, USB keyboard and mouse, USB drives, etc
5		Connected to display device with VGA input function
6		Network interface, connecting RJ45 port to connect to the Internet (it can only work in computer system for Internet)
7		Working indicator light
8		Connected to device with headphone input function
9		Connect to device with microphone voice collection (used for recording function)
10		Connected to device with HDMI input function
11		Working indicator light


Connection and Settings

1. VGA Output Connection




- (1) Use VGA line to connect display devices with VGA input, and use headphone line to connect sound output;
- (2) Press INPUT key to switch to PC port;
- (3) Set internal computer as VGA output to multi-screen display.

2. HDMI Output Connection




- (1) Use HDMI line to connect display devices with HDMI input;
- (2) Press INPUT key to switch to PC port;
- (3) Set internal computer as HDMI output to multi-screen display.

3. DP Output Connection




- (1) Use DisplayPort line to connect display devices with DP input;
- (2) Press INPUT key to switch to PC port;
- (3) Set internal computer as DP output to multi-screen display.


4.USBEquipmentConnection



5.NetworkCableConnection



6.MicrophoneConnection




DriverInstallation

Put the driver disk of the main board in the CD-ROM, the disk operates automatically and the following screen is displayed:

If this screen does not appear, please double click X:\SETUP.EXE.

(Assume that the driver letter is "X:")



Please click the driver you want to install on the above screen, and perform installation following the instructions.

RF&Power

FrequencyRange	OutputPower(Max.)
2402to2480MHz(BT)	2.0dBm
2402to2480MHz(LE)	3.73dBm
2412to2472MHz	17.41dBm
5150to5250MHz	18.94dBm
5250to5350MHz	18.94dBm
5470to5725MHz	18.94dBm

Software:V19.20.3.4

AntennaType:Dipole

AntennaGain: 2400MHz-2500MHz: ANT A: 1.86 dBi ; ANT B: 1.86 dBi

5150MHz-5250MHz: ANT A: 0.40 dBi ; ANT B: 0.40 dBi

5725MHz-5850MHz: ANT A: 0.11 dBi ; ANT B: 0.11 dBi

Antenna Impedance:50Ω

In all EU member states, operation of 5150-5350MHz is restricted to indoor use only.

This device should be installed and operated with a minimum distance of 20cm between the radiator and your body.

**Vivitek Americas**

46101 Fremont Blvd, Fremont, CA 94538

U.S.A.

T: +1-510-668-5100

F: +1-510-668-0680

Vivitek Asia

7F, No. 186, RueyKuang Road, Neihu, Taipei 11491

Taiwan R.O.C.

T: +886-2-8797-2088

F: +886-2-6600-2358

Vivitek Europe

Zandsteen 15, 2132 MZ Hoofddorp

The Netherlands

T: +31-20-800-3960

F: +31-20-655-0999

www.vivitekcorp.com

FCC Statement

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Non-modification Statement:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.