

4/1/03 Accton Draft—CONFIDENTIAL

Aruba 50™

Wireless Access Point

Installation Guide

Model Name :
WAP-50/MP-50-B

ARUBA
WIRELESS NETWORKS

180 Great Oaks Blvd. Ste B
San Jose, California 95119

Net www.arubanetworks.com
Tel 408.227.4500
Fax 408.227.4550

Copyright

Copyright © 2003 Aruba Wireless Networks, Inc. All rights reserved.

Specifications in this manual are subject to change without notice.

Originated in the USA.

Trademarks

AirOS, Aruba 50, and Aruba 5000 are trademarks of Aruba Wireless Networks in the United States and certain other countries.

The K & Lock design is a registered trademark of the Kensington Technology Group in the United States and certain other countries.

Any other trademarks appearing in this manual are owned by their respective companies.

Compliance

FCC - Class B

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with instructions, may cause harmful interference to radio communications. However, there is no guarantee that the interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

FCC Caution: To assure continued compliance, use only shielded interface cables when connecting to computer or peripheral devices. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CAUTION STATEMENT: FCC RF Radiation Exposure Statement

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 centimeters (8 inches) between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

If this device is going to be operated in 5.15 ~5.25GHz frequency range, then it is restricted in indoor Industry Canada - Class B

This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus as set out in the interference-causing equipment standard entitled "Digital Apparatus," ICES-003 of the Department of Communications.

Cet appareil numérique respecte les limites de bruits radioélectriques applicables aux appareils numériques de Classe B prescrites dans la norme sur le matériel brouilleur: "Appareils Numériques," NMB-003 édictée par le ministère des Communications.

Contents

	Preface	vii
	Related Documents	vii
	Text Conventions	viii
	Contacting Aruba Wireless Networks	ix
<i>Chapter 1</i>	Introduction	1
	Product Features	1
	Ethernet Compatibility	2
	Radio Characteristics	2
	Power Over Ethernet	2
	Physical Description	3
	Package Checklist	3
	Top Panel	3
	Rear Panel	5
<i>Chapter 2</i>	Setup & Installation	7
	Requirements	7
	Select a Network Topology	8
	Perform Initial Setup	10
	Direct SPOE to the Aruba WLAN Switch	10
	Direct Terminal Connection	11
	Configure the Aruba 50	12
	Mount the Aruba 50	14
	Free-Standing Placement	15
	Using the Mounting Kit	15

	Connect Required Cables	18
	Direct SPOE to the Aruba WLAN Switch	18
	LAN or POE Connection	19
<i>Appendix A</i>	Troubleshooting	21
<i>Appendix B</i>	Port Specifications	23
	Console Port	23
	FE Port	24
	SPOE Adapter	25
<i>Appendix C</i>	Product Specifications	27

Preface

The preface includes the following information:

- A list of related documentation for further reading
- A key to the various text conventions used throughout this manual
- Aruba Wireless Networks support and service information

Related Documents

The following items are part of the complete documentation for the Aruba system:

- *Aruba 50 Installation Guide* (Part No. 050007A, May 2003)
- *Aruba 5000 Installation Guide* (Part No. 0500001A, May 2003)
- *Aruba AirOS v1.0 User's Guide* (Part No. 050002A, May 2003)

Text Conventions

The following conventions are used throughout this manual to emphasize important concepts:

TABLE 1 Text Conventions

Type Style	Description
<i>Italics</i>	This style is used to emphasize important terms and to mark the titles of books.
System items	This fixed-width font depicts the following: ● Sample screen output ● System prompts ● Filenames, software devices, and certain commands when mentioned in the text.
Commands	In the command examples, this bold font depicts text that the user must type exactly as shown.
<i><Arguments></i>	In the command examples, italicized text within angle brackets represents items that the user should replace with information appropriate to their specific situation. For example: # send <i><text message></i> In this example, the user would type “send” at the system prompt exactly as shown, followed by the text of the message they wish to send. Do not type the angle brackets.
[Optional]	In the command examples, items enclosed in brackets are optional. Do not type the brackets.
{ Item A Item B }	In the command examples, items within curled braces and separated by a vertical bar represent the available choices. Enter only one choice. Do not type the braces or bars.

Contacting Aruba Wireless Networks

**Information Pending

CHAPTER 1

Introduction

The Aruba 50 is part of a comprehensive wireless network solution. The device works in conjunction with the Aruba 5000 WLAN Switch and can act as a wireless access point or air monitor.

As a wireless access point, the Aruba 50 provides transparent, secure, high-speed data communications between wireless network devices (fixed, portable, or mobile computers with IEEE 802.11a or IEEE 802.11b wireless adapters) and the wired LAN.

As a wireless air monitor, a uniquely Aruba feature, the Aruba 50 enhances wireless networks by collecting statistics, monitoring traffic, detecting intrusions, enforcing security policies, balancing wireless traffic load, self-healing coverage gaps, and more.

Product Features

- Wireless dual-band transceiver
- Dual, omnidirectional antennas for reception diversity
- Protocol-independent networking functionality
- 802.11a – up to 54 Mbps data rate per channel: offers a high data rate and reliable wireless connectivity
- 802.11b – 11 Mbps data rate per channel: provides an alternative to wired LANs that can dramatically cut costs
- Compatible with IEEE 802.3af Power Over Ethernet (POE)
- Seamless connectivity to wired LANs augment existing networks quickly and easily
- Can be centrally managed, configured, and upgraded through the Aruba WLAN Switch to take advantage of network changes and security improvements

Ethernet Compatibility

The Aruba 50 attaches to 10/100 Mbps Ethernet (FE) LAN segments that utilize 10Base-T/100Base-TX (twisted-pair) wiring. The device appears as an Ethernet node and performs a routing function by moving packets between the wired LAN and remote workstations on the wireless infrastructure.

Radio Characteristics

For IEEE 802.11a operation, the Aruba 50 uses a radio modulation technique known as Orthogonal Frequency Division Multiplexing (OFDM), and a shared collision domain (CSMA/CA). It operates in the 5GHz Unlicensed National Information Infrastructure (UNII) band. Data is transmitted over a half-duplex radio channel operating at up to 54 Megabits per second (Mbps), and with a maximum operating range up to 503 m (1650 ft.).

Power Over Ethernet

The Aruba 50 supports the IEEE 802.3af standard for Power Over Ethernet (POE). With this feature, the Aruba 50 can accept electrical power from a compatible POE-capable device to which it is connected, directly over the FE cable. POE eliminates the need to provide separate power outlets in environments that are difficult or undesirable to wire for electricity.

The Aruba 50 supports POE only when the FE port is connected to an IEEE 802.3af compliant device (such as the Aruba 5000 WS-5032 Line Card).

Physical Description

Package Checklist

The Aruba 50 package includes:

- One Aruba 50 wireless access point
- One mounting kit
- One Serial & Power Over Ethernet (SPOE) adapter
- One AC power adapter (3.3 VDC, 4 A)
- Non-slip rubber foot-pads
- Assorted documentation

Inform your supplier if there are any incorrect, missing or damaged parts. If possible, retain the carton, including the original packing materials. Use them again to repack the product in case there is a need to return it.

Top Panel



FIGURE 1-1 Aruba 50 Top Panel

1 Dual, omnidirectional Antennas for Wireless Communications (on sides)

The antennas swivel and should be oriented vertically (straight up and down) away from the chassis for best performance.

2 Air Vents (on sides)

These vents promote proper air circulation for cooling the device. Do not allow these vents to be obstructed by mounting equipment, network cables, or any other material.

3 Indicator LEDs

During operation, the Aruba 50 LEDs provide the following information:

TABLE 1-1 Aruba 50 LEDs

LED	State	Description
Ready	Off	The device is off or initializing.
	Green	The device has passed self-test and is operating.
	Flashing	The device is running a self-test or loading new software. If the condition persists for more than one minute, refer to the troubleshooting information in Appendix A.
LAN	Off	No link on the FE port on back of the device.
	Green	Link detected on the FE port.
	Flashing	Transmitting or receiving data across the FE port. Flashing rate is proportional to your network activity.
.A	Off	The 802.11a wireless interface is disabled or down.
	Green	The device is operating as an 802.11a access point.
	Flashing	The device is operating as an 802.11a air monitor.
.B	Off	The 802.11b wireless interface is disabled or down.
	Green	The device is operating as an 802.11b access point.
	Flashing	The device is operating as an 802.11b air monitor.

Rear Panel



FIGURE 1-2 Aruba 50 Rear Panel

1 Kensington Security Slot

This slot is compatible with a Kensington MicroSaver Security Cable (not included) which can be used to prevent the unauthorized removal of the Aruba 50 from its installed location. To secure the Aruba 50, wrap a security cable around an immovable object, insert the cable's lock into the Kensington Security Slot, and turn the key.

2 Console Port

This port has a 9-pin, female serial connector. It is used primarily to connect a terminal during initial setup of the Aruba 50. See Appendix B for port details.

Using the included SPOE adapter, this port can also be connected directly to an FE port on an Aruba WLAN Switch that supports SPOE (see “Power Over Ethernet” on page 2). This direct connection provides extra maintenance options during normal operation.

3 FE Port

This port attaches the Aruba 50 to 10Base-T/100Base-TX (twisted-pair) Ethernet LAN segments. The port automatically adjusts MDI/MDX to accept either straight-through or cross-over cables. See Appendix B for port details.

This port also supports POE (see “Power Over Ethernet” on page 2). When POE is used, a straight-through cable is required.

4 DC Power Socket

This socket is used to connect the included AC power adapter. If POE is being used to supply power to the Aruba 50, the power adapter is not necessary.

5 Mounting Slots (on bottom)

The keyhole-shaped slots on the bottom of the chassis are used to mount the Aruba 50.

CHAPTER 2

Setup & Installation

This chapter covers the following topics:

- Requirements for installing the Aruba 50
- Supported network topology options
- Initial setup of the Aruba 50
- Physical mounting of the device
- Connecting the required cables
- Testing the installation

Requirements

Before you install the Aruba 50, you must have the following:

- An operational Aruba WLAN Switch with a valid IP route to the LAN segment to which the access point or air monitor will be connected.
- An appropriate physical location for the new access point or air monitor.

We recommend an up-to-date site survey to help determine the optimal location for your Aruba 50. See your *Aruba AirOS Software Guide* for instructions on using the Aruba WLAN Switch's built-in planning tools.

- Client devices with 802.11a or 802.11b compliant wireless Ethernet adapters with TCP/IP compatible protocol installed.

- One of the following power sources for the access point or air monitor:
 - An AC power outlet rated at 100~240 V, 50~60 Hz.
 - Power Over Ethernet (POE) capability on the device to which the Aruba 50 is connected (see “Power Over Ethernet” on page 2).

NOTE—When installing the Aruba 50 in plenums or air-handling spaces, as described in NEC (2002) Article 300.22(C), the device must be powered using POE, and not the included AC power adapter.

Select a Network Topology

The Aruba 50 can be installed in your network using the following topologies:




FIGURE 2-1 Aruba 50 Topology Options

1 Direct Serial & Power Over Ethernet (SPOE) to the Aruba WLAN Switch (recommended)

In this topology, both the console and 10/100 Mbps Ethernet (FE) ports on the Aruba 50 are connected to the included SPOE adapter. An 8-conductor, Category 5 UTP, straight-through FE cable connects the adapter directly to the Aruba WLAN Switch with no intervening hubs, routers, or other network equipment. The network port on the Aruba WLAN Switch must include optional SPOE capability (see “Power Over Ethernet” on page 2).

This topology provides the following features:

- 10/100 Mbps Ethernet connectivity
- Electrical power through the FE cable
- Serial console connectivity through the FE cable
- Convenient initial setup through the Aruba WLAN Switch management interface either before or after physical installation of the Aruba 50
- Extra console maintenance options during normal operation

2 POE connection through the LAN

In this topology, the Aruba 50 is connected to the LAN through a hub or switch that is POE compatible (see “Power Over Ethernet” on page 2). An 8- or 4-conductor, Category 5 UTP, straight-through FE cable is required. Initial setup requires a local serial console.

This topology provides the following features:

- 10/100 Mbps Ethernet connectivity (depending on the connecting port)
- Electrical power through the FE cable
- Versatile placement of the Aruba WLAN Switch and Aruba 50s within the network

3 Connection to a non-POE network port on the Aruba WLAN Switch or other network device

In this topology, the Aruba 50 is connected to the Aruba WLAN Switch either directly or through the LAN. An 8- or 4-conductor, Category 5 UTP, straight-through or crossover FE cable may be used. Initial setup requires a local serial console. Electrical power is supplied using the included AC power adapter.

This topology provides the following features:

- 10/100 Mbps Ethernet connectivity (depending on the connecting port)
- Versatile placement of the Aruba WLAN Switch and Aruba 50s within the network

Perform Initial Setup

The Aruba 50 requires some initial configuration before it will operate. The method used for connecting to the Aruba 50 for initial setup depends on your intended network topology (see Figure 2-1 on page 8).

Direct SPOE to the Aruba WLAN Switch

Use this procedure when connecting the Aruba 50 directly to an SPOE-compatible network port on the Aruba WLAN Switch (see “Power Over Ethernet” on page 2). SPOE provides 10/100 Mbps Ethernet, serial connection, and power over one cable.

NOTE—If connecting the Aruba 50 through the LAN or to a non-SPOE network port on the Aruba WLAN Switch, see the instructions on page 11.

1 Connect the included SPOE adapter to the Aruba 50.

- Ⓐ Connect the adapter’s 9-pin serial connector to the Console port on the back of the Aruba 50.
- Ⓑ Connect the adapter’s male RJ-45 plug to the FE port on the back of the Aruba 50.

2 Connect the Aruba 50 to the Aruba WLAN Switch.

The connection between the Aruba 50 and the Aruba WLAN Switch requires an 8-conductor, Category 5 UTP, straight-through FE cable with RJ-45 connectors (see Appendix B for port specifications).

- Ⓐ Connect one end of the FE cable directly to the RJ-45 socket on the SPOE adapter that was attached to the Aruba 50 in the previous step.
- Ⓑ Connect the other end of the FE cable directly to an available SPOE network port on the Aruba WLAN Switch.

NOTE—The Aruba 50 must be connected to the Aruba WLAN Switch without any intervening hubs, routers, or other networking equipment.

3 Telnet to the Aruba WLAN Switch Serial-Over-Ethernet (SOE) interface.

Run the Telnet client on your management workstation and connect to the Aruba WLAN Switch management IP address using logical port 2300. The connection command may vary depending on the specific software used, but commonly appears as follows:

```
telnet <switch management IP address> 2300
```

- 4 When prompted, log in to the Aruba WLAN Switch as the administrator:

user: **admin**

password: *<administrator password (not displayed)>*

This will present you with the Aruba WLAN Switch SOE console prompt (SOE>).

- 5 Specify the physical Aruba WLAN Switch port to which the new Aruba 50 is connected:

soe> **connect** *<slot number>/<port number>*

This will present you with the Aruba 50 console prompt (#). Once connected to the console, follow the instruction on page 12 to configure Aruba 50.

Direct Terminal Connection

Use this procedure when connecting the Aruba 50 through the LAN or to a non-SPOE network port on the Aruba WLAN Switch. Under these topologies, a direct terminal connection is required for initial setup.

NOTE—If connecting the Aruba 50 directly to a SPOE network port on the Aruba WLAN Switch, see the instructions on page 10.

- 1 Set up your local terminal.

This procedure requires a terminal or computer running terminal emulation software with the following settings:

TABLE 2-1 Console Terminal Settings

Baud Rate	Data Bits	Parity	Stop Bits	Flow Control
9600	8	None	1	None

- 2 Connect the terminal directly to the Aruba 50.

Use a standard serial cable to connect the Aruba 50 console port to a serial port on your terminal (see Appendix B for port specification).

- 3 Establish console communication.

Press <Enter> a few times to establish communication between the terminal and the Aruba 50. You will be presented the Aruba 50 console prompt (#).

Once connected to the Aruba 50 console, follow the instruction on page 12 to configure the device.

Configure the Aruba 50

- 1 From the Aruba 50 console, access the boot prompt.

Reboot the Aruba 50 and then immediately (within three seconds as the device is booting) press any key to interrupt the process:

```
# boot
<Any key (while booting)>
```

This will present you with the Aruba 50 boot prompt (apboot>).

- 2 Set the intended location for the Aruba 50:

```
apboot> setenv location <building number>.<floor number>.<device number>
```

If you performed the recommended site survey using the Aruba WLAN Switch's built-in planning tools, the location data for all access points and air monitors can be found on the tool's deployment screen (see the *Aruba AirOS Software Guide*).

If you plan to manually generate the location data, record the following information for each access point and air monitor. It will be required when configuring the Aruba WLAN Switch.


Building Number A unique number (1-255) is required for each building in your campus.

Floor Number Within any building, a unique number (1-255) is required for each floor.

Device Number Within any floor, a unique number (1-65536) is required for each access point or air monitor.

Device Description Note the intended function of the device (access point or dedicated air monitor) and a brief description of its service location.

X, Y Coordinates For each access point and air monitor, measure its X and Y position (in feet) relative to the bottom-left corner of the building plan as seen from overhead. For example:



Use the same fixed point and orientation for all floors in a building.

3 Specify host information, if necessary.

The Aruba 50 uses the default host name `aruba-master` to find the host Aruba WLAN Switch. This assumes that your DNS has been configured to resolve `aruba-master` to the master Aruba WLAN Switch IP address.

- If you are not using DNS, you must manually configure the Aruba 50 with the IP address of the master Aruba WLAN Switch:

```
apboot> setenv serverip <switch IP address>
```

- If you are using DNS but wish to specify a different host name, use the following commands:

```
apboot> setenv master <switch host name>  
apboot> setenv serverip <switch host name>
```

4 Save the configuration and reboot the Aruba 50.

```
apboot> save  
apboot> boot
```

Once the Aruba 50 boots, disconnect it and mount it in its intended service location (see instructions on page 14).

Mount the Aruba 50

When initial setup is complete, mount the Aruba 50 in its intended service location.

Select a location as close as possible to the center of the intended coverage area. If necessary, use the Aruba WLAN Switch's built-in site survey software to determine the optimum locations for your access points and air monitors (see your *Aruba AirOS Software Guide*).

The service location should be free from obstructions or obvious sources of interference. Normally, the higher you place an access point or air monitor, the better its performance.

The Aruba 50 can be mounted in the following ways:



FIGURE 2-2 Aruba 50 Mounting Options

- 1 Flat on a table or shelf (with the LEDs on top) either free-standing or using the included mounting kit
- 2 Upright on a wall (with the port connectors on top) using the included mounting kit
- 3 Suspended from above (with the LEDs on bottom) using the included mounting kit



CAUTION—For safety purposes, do not mount the Aruba 50 sideways (with the air vents on top and bottom).

Free-Standing Placement



CAUTION—Do not place the Aruba 50 in any place where it could fall on people or equipment. For more secure installation, use the included mounting kit.

To place the Aruba 50 on a flat table or shelf, first attach the included non-skid foot-pads to the bottom of the chassis.

Using the Mounting Kit

Use the included mounting kit to attach the Aruba 50 to a wall, shelf, or ceiling.

NOTE—Do not attach the rubber foot-pads to the Aruba 50 when using the mounting kit.

1 Attach the mounting cradle to a solid mounting surface.

Place the flat side of the cradle against the mounting surface. If attaching the cradle to a wall, orient it so that the cable tie anchors are positioned at the top. If attaching the cradle to a table, shelf, or ceiling, orient the cable tie anchors toward the cable route.

Use the four included #6 screws (or equivalent) to secure the mounting cradle. If attaching the cradle to drywall, we recommend using appropriate wall anchors (not included) as show in Figure 2-3:




FIGURE 2-3 Attaching the Mounting Cradle

- 2 Place the Aruba 50 into the mounting cradle as shown in Figure 2-4.




FIGURE 2-4 Placing the Aruba 50 into the Cradle

- Ⓐ Align the front edge of the chassis with the etched line on the mounting cradle. This will fit the Aruba 50 mounting slots over the matching cradle posts.
- Ⓑ Press and hold the Aruba 50 chassis against the retaining clips on the cradle.
- Ⓒ Slide the Aruba 50 into place. When properly positioned, the retaining clips will spring up to hold the chassis firmly in place.

NOTE—To remove the Aruba 50 from the cradle, press down on both retaining clips and slide the chassis free of the mounting posts.

- 3 Secure the Aruba 50, if desired.

To prevent the unauthorized removal of the Aruba 50 from its installed location, use a Kensington MicroSaver Security Cable (not included). Wrap the security cable around an immovable object, insert the cable's lock into the Kensington Security Slot on the back of the Aruba 50, and turn the key.

- 4 Orient the antennas.

For best performance, swivel the antennas so that they are oriented vertically (see Figure 2-2 on page 14).

Once mounting is complete, connect the required cables (see instructions on page 18).

Connect Required Cables

The cables required for operating the Aruba 50 depend on your intended network topology (see Figure 2-1 on page 8) and on the physical location.

Direct SPOE to the Aruba WLAN Switch

Use this procedure when connecting the Aruba 50 directly to an SPOE-compatible network port on the Aruba WLAN Switch (see “Power Over Ethernet” on page 2). SPOE provides 10/100 Mbps Ethernet, serial connection, and power over one cable.

NOTE—If connecting the Aruba 50 through the LAN or to a non-SPOE network port on the Aruba WLAN Switch, see the instructions on page 19.

1 Connect the included SPOE adapter to the Aruba 50.

- Ⓐ Connect the adapter's 9-pin serial connector to the Console port on the back of the Aruba 50.
- Ⓑ Connect the adapter's male RJ-45 plug to the FE port on the back of the Aruba 50.

2 Connect the Aruba 50 to the Aruba WLAN Switch.

The connection between the Aruba 50 and the Aruba WLAN Switch requires an 8-conductor, Category 5 UTP, straight-through FE cable with RJ-45 connectors (see Appendix B for port specifications).

Any FE cable installed in an air-handling space, as described in NEC (2002) Article 300.22(C), should be suitable under NEC Article 800.50 and marked accordingly for use in plenums and air-handling spaces with regard to smoke propagation, such as CL2-P, CL3-P, MPP or CMP. Install cables in accordance with all applicable local regulations and practices.

- Ⓐ Connect one end of the FE cable directly to the RJ-45 socket on the SPOE adapter that was attached to the Aruba 50 in the previous step.
- Ⓑ Connect the other end of the FE cable directly to an available SPOE network port on the Aruba WLAN Switch.

NOTE—The Aruba 50 must be connected to the Aruba WLAN Switch without any intervening hubs, routers, or other networking equipment.

LAN or POE Connection

Use this procedure when connecting the Aruba 50 through the LAN or to a non-SPOE network port on the Aruba WLAN Switch.

NOTE—If connecting the Aruba 50 directly to a SPOE network port on the Aruba WLAN Switch, see the instructions on page 18.

1 Connect the Aruba 50 to the network.

- Ⓐ Connect one end of an FE cable to a network hub, router, or switch that has a routable path to the Aruba WLAN Switch.
 - If the connecting device supports POE (see “Power Over Ethernet” on page 2), use an 8- or 4-conductor, Category 5 UTP, straight-through FE cable.
 - If the connecting device does not support POE, use a 4- or 8-conductor, Category 5 UTP, straight-through or crossover FE cable.

Any FE cable installed in an air-handling space, as described in NEC (2002) Article 300.22(C), should be suitable under NEC Article 800.50 and marked for use in plenums and air-handling spaces with regard to smoke propagation, such as CL2-P, CL3-P, MPP or CMP. Install cables in accordance with all applicable local regulations and practices.

For port and cable details, see Appendix B.

- Ⓑ Connect the other end of the FE cable to the FE port on the back of the Aruba 50.

2 Connect power.

The Aruba 50 can receive electrical power using the following options:

- POE—If connecting the Aruba 50 to a device that supplies IEEE 802.3af compliant POE (see “Power Over Ethernet” on page 2), no additional power connection is necessary.
- Power Outlet

NOTE—When the Aruba 50 is installed in an air-handling space, as described in NEC (2002) Article 300.22(C), POE must be used instead of a power outlet.

If local regulations and practices permit, connect the included AC power adapter cable to the DC power socket on the rear panel of the Aruba 50 and plug it into an appropriate power outlet.



CAUTION—Use only the AC power adapter supplied with this device. Otherwise, the product may be damaged.

4/1/03 Accton Draft—CONFIDENTIAL

APPENDIX A

Troubleshooting

*Information Pending

APPENDIX B

Port Specifications

Console Port

The console port is located on the back of the Aruba 50 and has a DB-9 female connector. Port pin-outs are shown in Figure B-1:




Figure B-1 Aruba 50 Console Port

Communication settings for the console port are specified in Table B-1:

Table B-1 Console Terminal Settings

Baud Rate	Data Bits	Parity	Stop Bits	Flow Control
9600	8	None	1	None

FE Port

The 10/100 Mbps Ethernet (FE) port is located on the back of the Aruba 50 and has an RJ-45 female connector. Port pin-outs are shown in Figure B-2:




Figure B-2 Aruba 50 FE Port

The port accepts a 4- or 8-conductor Category 5 UTP FE cable with an RJ-45 male connector.

The FE port detects MDI/MDX and automatically adjusts for straight-through or crossover cables. However, if Power Over Ethernet (POE) is used, a straight-through cable is required.

The maximum length for FE cables is 100 meters (325 feet).

When the Aruba 50 is installed in an air-handling space, as described in NEC (2002) Article 300.22(C), POE is required. Also, any FE cable installed in such spaces should be suitable under NEC Article 800.50 and marked accordingly for use in plenums and air-handling spaces with regard to smoke propagation, such as CL2-P, CL3-P, MPP or CMP.

Install cables in accordance with all applicable local regulations and practices.

SPOE Adapter

The Serial & Power Over Ethernet (SPOE) adapter pin-outs are shown in Figure B-3:




Figure B-3 Aruba SPOE Adapter

The adapter requires an 8-conductor Category 5 UTP, straight-through FE cable with RJ-45 male connectors. The cable must connect the SPOE adapter to an FE+SPOE port on the Aruba WLAN Switch, with no intervening hubs, routers, or other network equipment.

The maximum length for FE cables is 100 meters (325 feet).

The Aruba 50 and SPOE adapter are plenum rated. When is installed in an air-handling space, as described in NEC (2002) Article 300.22(C), the connecting FE cable should be suitable under NEC Article 800.50 and marked accordingly for use in plenums and air-handling spaces with regard to smoke propagation, such as CL2-P, CL3-P, MPP or CMP.

Install cables in accordance with all applicable local regulations and practices.

APPENDIX C

Product Specifications

The following specifications apply to the Aruba 50 Wireless Access Point (model WAP-50).

Physical

TABLE C-1 Physical Specifications

Item	Measurement
Size	20.5 x 13.6 x 4 cm (8.07 x 5.35 x 1.58 in)
Weight	280 gram (9.9 oz.)

Environment

TABLE C-2 Environmental Specifications

Item	Measurement
Temperature	Operating: 0 to 50 °C (32 to 122 °F) Storage: 0 to 70 °C (32 to 158 °F)
Humidity	5% to 95% (non-condensing)

Operation

General

TABLE C-3 Operational Specifications

Item	Measurement
Maximum Channels	802.11a—US & Canada: 13, Japan: 5 802.11b—US & Canada: 1-11, Europe: 1-13, France: 10-13, Japan: 1-14, Spain: 10-11
Maximum Clients	64
Operating Range	802.11a—Up to 503 m (1650 ft.) 802.11b—Up to 396 m (1300 ft.)
Data Rate	802.11a—6, 9, 12, 18, 24, 36, 48, 54 Mbps per channel 802.11b—1, 2, 5.5, 11 Mbps per channel
Operating Frequency	802.11a— 5.15 ~ 5.25 GHz (lower band) US/Canada, Japan 5.25 ~ 5.35 GHz (middle band) US/Canada 5.725 ~ 5.825 GHz (upper band) US/Canada 802.11b— 2.412 ~ 2.452 GHz US/Canada, Japan 2.457 ~ 2.462 GHz US/Canada, Europe, France, Japan, Spain 2.467 ~ 2.472 GHz Europe, France, Japan 2.484 GHz Japan
Output Power	802. 11a 20dBm minimum / 802. 11a 15dBm minimum
Power	Adapter Input— 100-240 AC, 50-60 Hz Access Point Input— 3.3 VDC, 3 A (AC adapter), or 48 VDC, 150 mA (POE)
LED Indicators	Ready (Power), LAN (Ethernet Link/Activity), .A and .B (Access Point/Air Monitor Mode)
Standards	IEEE 802.3 10Base-T, IEEE 802.3u 100Base-TX, IEEE 802.11a/b, IEEE 802.3af

Maximum Distance

Maximum distances posted below are the actual tested distance thresholds. However, there are many variables such as barrier composition and construction and local environmental interference that may impact your actual distances and cause you to experience distance thresholds far lower than those we post below:

TABLE C-4 IEEE 802.11a Maximum Distances

Condition	Speed (Mbps)							
	54	48	36	24	18	12	9	6
Outdoor Environment	40 m (132 ft.)	221 m (726 ft.)	251 m (825 ft.)	322 m (1056 ft.)	350 m (1155 ft.)	382 m (1254 ft.)	453 m (1485 ft.)	503 m (1650 ft.)
Indoor Environment	18 m (60 ft.)	25 m (82 ft.)	30 m (99 ft.)	35 m (115 ft.)	40 m (132 ft.)	45 m (149 ft.)	48 m (157 ft.)	50 m (165 ft.)

TABLE C-5 IEEE 802.11b Maximum Distances

Condition	Speed (Mbps)			
	11	5.5	2	1
Outdoor Environment	152 m (500 ft.)	233 m (766 ft.)	315 m (1033 ft.)	396 m (1300 ft.)
Indoor Environment	23 m (75 ft.)	30 m (100 ft.)	61 m (200 ft.)	61 m (200 ft.)

An Outdoor Environment is a line-of-sight environment with no interference or obstruction between the access point and clients.

An Indoor Environment is a typical office or home environment with floor to ceiling obstructions between the access point and clients.

*Sensitivity and Modulation***TABLE C-6** IEEE 802.11a Sensitivity and Modulation

Modulation/Rates	Sensitivity (dBm)	5.15-5.25GHZ (dBm)	5.25-5.35GHZ (dBm)
BPSK (6 Mbps)	-85	16	20
BPSK (9 Mbps)	-84	16	20
QPSK (12 Mbps)	-83	16	19
QPSK (18 Mbps)	-81	16	19
16 QAM (24 Mbps)	-78	16	18
16 QAM (36 Mbps)	-74	16	18
64 QAM (48 Mbps)	-69	16	16
64 QAM(54 Mbps)	-65	14	14

TABLE C-7 IEEE 802.11b Sensitivity and Modulation

Modulation/Rates	Sensitivity (dBm)	2.412-2.484GHZ (dBm)
DBPSK (1 Mbps)	-86	20
DQPSK (2 Mbps)	-85	17
PBCC (5.5 Mbps)	-85	15
CCK (5.5 Mbps)	-81	13
PBCC (11 Mbps)	-83	7
CCK (11 Mbps)	-81	0

Certifications

TABLE C-8 Certifications

Item	Measurement
Electromagnetic Compatibility	FCC Part 15 Class B, FCC Part 15 Class C 15.207/15.247, FCC Part 15 Class E 15.407 ICES-003, RSS 210 (CAN) IEC 61000-4-2/3/4/6/11 EN 55022, EN55024 (89/336/EEC), ETS 300 328 (89/336/EEC), ETS 301 489 (89/336/EEC), ETS 301 893 AS/NZS 3548, RFS 29 (NZ)
Safety	CSA/NTRL (CSA 22.2 No. 950 & UL 1950) EN60950 (TÜV/GS), IEC60950 (CB), UL 2043

