

Troubleshooting

If one or both of the "Chat with Me" Walkie Talkies do not work, this may indicate that the batteries are weak. Insert a new "9-Volt" battery into each unit.

If the signal range of the "Chat with Me" Walkie Talkies decreases notably, this may again be an indication that the batteries are weak. Insert a new "9-Volt" battery into each unit.

Please keep in mind that this product does not transmit well through obstacles such as trees, buildings, and metal structures.

If there is a sizable increase in static, it may be due to the proximity of electric motors, fluorescent lights, power lines, or other signal-disrupting objects. You may have to change your location.

If problems persist, DO NOT ATTEMPT TO REPAIR THE UNIT. See the Warranty for factory services.

FCC Warning

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communication. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does not cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARNING: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Questions or Comments

- If you have questions or comments regarding this or other products, please call our toll-free number: **1-888-TOP-TOYS**

Please also visit our website at www.toptoysonline.com

Limited One-Year Warranty

KIDesigns warrants this product to be free from defects in workmanship and materials, under normal use and conditions, for a period of one year from the date of original purchase.

Should service be required by reason of any defect or malfunction, it is best to first return this product and all parts thereof to the store where it was originally purchased. If you need to send the product for service during the warranty period, KIDesigns will repair or, at its discretion, replace this product without charge (except for a \$6.00 charge for handling, packing, return UPS/postage and insurance). This decision is subject to verification of the defect or malfunction upon delivery of this product to the Factory Service Center listed below. The product must include proof of purchase, including date of purchase.

Before returning this product for service, please first replace the batteries (if applicable) with fresh ones, as exhausted or defective batteries are the most common cause of problems encountered.

If service is still required:

1. Remove batteries (if applicable) and pack unit in a well-padded, heavy corrugated box.
2. Enclose a photocopy of your sales receipt, credit card statement, or other proof of the date of purchase.
3. Enclose a check or money order payable to the order of KIDesigns, for the sum of \$6.00.
4. Send the unit prepaid to the Factory Service Center listed below.

NOTE: This warranty is valid only if the product is used for the purpose for which it was designed. It does not cover (i) products which have been damaged by negligence, misuse or accident, or which have been modified or repaired by unauthorized persons; (ii) cracked or broken cabinets, or units damaged by excessive heat; (iii) damage to tape cassettes (if applicable); (iv) the cost of shipping this product to the Factory Service Center and its return to the owner.

This warranty is valid only in the United States of America and does not extend to owners of the product subsequent to the original purchaser. Any applicable implied warranties are also limited to one year, and KIDesigns will not be liable for consequential damages. (Some states do not allow limitations on implied warranties or exclusion of consequential damages, so these restrictions may not apply to you.) This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Send unit to:
Consumer Repair Department
KIDesigns Inc.
1401 Pullman Drive, Suite A
El Paso, Texas 79936-7726

BARBIE is a trademark owned by and used under license from Mattel, Inc. © 2003 Mattel, Inc. All Rights Reserved.

Manufactured and Distributed by KIDesigns, Inc.
Rahway, NJ 07065.

Printed in China

NJCS102801 V1

Barbie™

Model BE-225

"Chat with Me" Walkie Talkies

Important Message to Customers

Thank you for purchasing one of Barbie's many top-quality electronic products. We would appreciate it if you take a few moments to read through these instructions. This will help you explain to the child the safe and proper way to use this toy, and to help give it the long-lasting life that Barbie products are designed for.

Getting Started

Installing the Batteries

Note: Batteries should always be installed by an adult.

- 1 Use a Phillips screwdriver to loosen the screw on the battery compartment door, then open the door, as shown in the insert at right.
- 2 We recommend the use of alkaline batteries for longer battery life. Insert one new "9-Volt" battery into each Walkie Talkie, with + and - terminals as indicated in the compartment.
- 3 Replace the compartment door and tighten the screw with a Phillips screwdriver. Do not over-tighten the screw.

For the Best Possible Performance

- We recommend using alkaline batteries.
- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the toy before being charged (if removable).
- Rechargeable batteries are only to be recharged under adult supervision (if removable).
- Different types of batteries or new and used batteries are not to be mixed.
- Only batteries of the same or equivalent type as recommended are to be used.
- Batteries are to be inserted with correct polarity.
- Exhausted batteries are to be removed from the toy.
- The supply terminals are not to be short circuited.
- Batteries should always be removed if the toy is not going to be used for an extended period of time (approximately 30 days or more) to prevent leakage or damage to the toy.

Turning Power On/Off


- To activate the Walkie Talkies, turn each ④ On/Off/Volume Control thumbwheel counterclockwise until a "click" can be heard and the ⑤ Red Power On LED lights up.
- **Both** Walkie Talkies must be turned on in order to send and receive messages.
- To shut down the Walkie Talkies, turn each ④ On/Off/Volume Control thumbwheel clockwise until a "click" can be heard and the ⑤ Red Power On LED goes out.

Sending Voice Messages

Press and hold the ⑥ Transmit Key while speaking into the ⑩ Microphone.

You Should Know

For clear transmission, keep the ⑩ Microphone approximately two inches from your mouth.



Sending Morse Code Messages

- To send a Morse code message, press and hold the ⑥ Transmit Key while pressing the ⑧ Morse Code Button.
- When you send Morse code, the ④ Green Send LED will blink while the Morse code is being sent.

International Morse Code

A ·-·	H ····	O ---	V ···-	1 ····	8 ···-
B -···	I ···	P -···	W -··-	2 ····	9 ···-
C -·-·	J -··-	Q -··-	X -··-	3 ····	0 ----
D -··-	K -··-	R -··	Y -··-	4 ····	
E ·-·	L -··-	S -··	Z -··-	5 ····	End ·-·-
F -··-	M -··	T -··		6 ····	7 ····
G -··-	N -··	U -··			

In Morse code, a dot is sent by signalling a short beep, and a dash is signalled by a longer beep.

Receiving Messages

- Both Walkie Talkies must be turned on in order to send and receive messages.
- Messages cannot be received while either the ⑥ Transmit Key or ⑧ Morse Code Button is being pressed.
- Messages can be heard through the ⑦ Speaker.
- Volume can be adjusted to a comfortable level by turning the ④ On/Off/Volume Control thumbwheel.

Playing Walkie Talkie Games

Walkie Talkies can be used for all kinds of fun games and activities. Here are two suggestions:

Hide and Seek

Just like regular Hide and Seek, but with a twist: the "Hider" can send clues to the "Seeker" using the Walkie Talkies.

Mystery Sounds

Can you recognize the mystery sound? One kid sends a sound over the Walkie Talkies, while another tries to guess what the sound is. Examples can include an animal, song, TV show, or anything else!

Maintenance

It is important to keep the "Chat with Me" Walkie Talkies as dry and clean as possible. You may clean the cabinet with a cloth or sponge moistened with mild soap and water. Do not attempt to use strong cleansers or solvents, as they may cause damage.