

APPLICANT: MOTOROLA, INC.


FCC ID: IHDT56CF1

INSTRUCTION MANUAL

A preliminary draft copy of the Users Manual follows:

Welcome

Welcome to the world of Motorola digital wireless communications! We are pleased that you have chosen the Motorola C331 wireless phone.



Personal Communications Sector
600 North U.S. Highway 45
Libertyville, Illinois 60048

1-800-331-6456 (United States)
1-888-390-6456 (TTY/TDD United States)
1-800-461-4575 (Canada)

www.motorola.com (United States)
www.motorola.ca (Canada)

MOTOROLA, the Stylized M Logo and all other trademarks indicated as such herein are trademarks of Motorola, Inc. ® Reg. U.S. Pat. & Tm. Off. TrueSync, Sidekick, Starfish, and the Stylized Starfish Logo are registered trademarks of Starfish Software, Inc., a wholly owned independent subsidiary of Motorola, Inc. All other product or service names are the property of their respective owners.

© 2002 Motorola, Inc. All rights reserved.

Software Copyright Notice

The Motorola products described in this manual may include copyrighted Motorola and third party software stored in semiconductor memories or other media. Laws in the United States and other countries preserve for Motorola and third party software providers certain exclusive rights for copyrighted software, such as the exclusive rights to distribute or reproduce the copyrighted software. Accordingly, any copyrighted software contained in the Motorola products may not be modified, reverse-engineered, distributed, or reproduced in any manner to the extent allowed by law. Furthermore, the purchase of the Motorola products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any license under the copyrights, patents, or patent applications of Motorola or any third party software provider, except for the normal, non-exclusive, royalty-free license to use that arises by operation of law in the sale of a product.

Manual number:

Cover number: 8988485L49-O



Menu Map

Main Menu

- **Recent Calls**
 - Received Calls
 - Dialed Calls
 - Notepad
 - Call Times
- **Phonebook**
- **Voice Dial**
- **Datebook**
- **Radio**
- **Messages**
 - Create Msg
 - Voicemail
 - Text Msgs
 - Quick Notes
 - Outbox
 - Drafts
- **Ring Styles**
 - Style
 - Style Detail
 - My Tones
- **Shortcuts**
- **Web Sessions**
- **Calculator**
- **Games**
- **Settings**
(see next page)

Note: This is the standard phone menu layout. You or your service provider may have changed the menu layout or changed some feature names. Not all features may be available for all users.

For example, the **Radio** feature on the main menu (left) is displayed only when the optional FM Stereo Radio Headset accessory is plugged into the accessory connector port on your phone (see phone illustration, page 1).

Shortcuts
Change display zoom: Press  , then press and hold 
Lock/unlock keypad: Press  
Display my phone number: Press  
Go to dialed calls list: Press 
Exit menu system: Press 

Settings Menu



Phone Status

- My Tel. Number
- Active Line
- Battery Meter
- Other Information

Connection

- Incoming Call

In-Call Setup

- In-Call Timer
- Answer Options

Security

- Phone Lock
- Lock Keypad
- Lock Application
- Talk Secure
- Restrict Calls
- New Passwords

• Other Settings

Personalize

- Main Menu
- Keys
- Greeting
- Quick Dial

Initial Setup

- Time and Date
- Backlight
- Zoom
- TTY Setup
- Scroll
- Animation
- Language
- Battery Save
- Contrast
- DTMF
- Master Reset
- Master Clear

Network

- Car Settings
- Headset

Contents

Menu Map	3
About This Guide	10
Safety and General Information	11
Getting Started	18
What's in the Box?	18
Installing the Battery	18
Charging the Battery	19
Turning Your Phone On	20
Making a Call	20
Ending a Call	21
Answering a Call	21
Seeing Your Phone Number	21
About Your Phone	22
Using the Display	22
Zooming In and Out	24
Adjusting Volume	24
Battery Use	25
Making and Answering Calls	27
Redialing a Number	27
Using Caller ID	27
Using Talk Secure	27
Returning Unanswered Calls	28
Calling an Emergency Number	28
Turning Off a Call Alert	29
Canceling an Incoming Call	29
Calling With Speed Dial	30
Calling With One-Touch Dial	30

Calling a Number In a Text Message	30
Additional Calling Features	31
Using Features While On a Call	32
Using Call Waiting	32
Making a Three-Way Call	32
Additional On-Call Features	33
Using the Menu	34
Navigating to a Feature	34
Selecting a Feature Option	35
Entering Feature Information	36
Entering Text	38
Choosing a Text Mode	38
Using Tap Method	39
Using Symbol Mode	42
Using iTAP™ Software Predictive Text Entry Method	43
Menu Feature Descriptions	47
Recent Calls	58
Viewing Received Calls or Dialed Calls	58
Using the Notepad	60
Viewing and Resetting Call Timers	60
Phonebook	63
Viewing Entry Details	63
Storing a Phonebook Entry	64
Storing a PIN Code With the Phone Number	66
Recording a Voice Name For a Phonebook Entry ...	68
Dialing a Phonebook Entry	69
Editing a Phonebook Entry	70
Deleting a Phonebook Entry	70
Setting the Primary Number for a Phonebook Entry .	71
Checking Phonebook Capacity	71
Sorting the Phonebook List	72

Datebook	74
Week View	74
Day View	75
Event View	75
Adding a Datebook Event	76
Changing Event Information	76
Copying an Event	77
Deleting an Event	78
Radio	79
Turning the Radio On and Off	79
Tuning a Station	80
Storing a Preset	80
Selecting a Preset	80
Sending and Receiving Calls with the Radio On	80
Messages—Voicemail	82
Storing Your Voicemail Number	82
Receiving a Voicemail Message	83
Listening to a Voicemail Message	83
Messages—Text	84
Setting Up the Text Message Inbox	84
Receiving a Text Message	85
Reading, Locking, or Deleting a Text Message	86
Storing Sounds	89
Sending a Text Message	89
Sending a Quick Note Text Message	91
Viewing the Status of Sent Text Messages	92
Ring Styles	93
Selecting a Ring Style	93
Customizing a Ring Style	94
Creating Alert Tones	95
Setting Reminders	102

Shortcuts	104
Standard Shortcuts	104
Creating a Shortcut	104
Using Shortcuts	106
Micro-Browser	107
Starting a Micro-Browser Session	107
Interacting With Web Pages	108
Calculator	109
Calculating Numbers	109
Converting Currency	111
Games	112
Playing a Game	112
Game Options	112
Blackjack	113
Falling Numbers	114
Video Poker	115
Adjusting Your Settings	117
Reordering Menu Items	117
Customizing a Soft Key Function	117
TTY Operation	118
Hands-Free Use	120
Data Calls	123
Connecting Your Phone to an External Device	123
Sending a Data Call	125
Receiving a Data Call	126
Security	129
Assigning a New Code or Password	129
If You Forget a Code or Password	130
Locking and Unlocking Your Phone	131
Locking and Unlocking Your Keypad	132

Restricting Calls	132
Activating Talk Secure	133
Troubleshooting	134
Programming Instructions	143
Specific Absorption Rate Data	145
Additional Health and Safety Information	148
Warranty	157
Product Registration	165
Export Law Assurances	165
Index	166
Wireless Phone Safety Tips	177

About This Guide

This user guide introduces you to the many features in your Motorola wireless phone.

Navigating to a Menu Feature

Use the menu system to access your phone's features. This guide shows you how to select a menu feature as follows:

Find the Feature

☰ > **Messages**
> **Text Msgs**

This example shows that you must press ☰, scroll to and select **Messages**, then scroll to and select **Text Msgs**.

Optional Features



This label identifies an optional network or subscription-dependent feature that may not be offered by all service providers in all geographical areas. Contact your service provider for more information.

Optional Accessories



This label identifies a feature that requires an optional Motorola Original™ accessory.

Safety and General Information

IMPORTANT INFORMATION ON SAFE AND EFFICIENT OPERATION. READ THIS INFORMATION BEFORE USING YOUR PHONE.

The information provided in this document supersedes the general safety information contained in user guides published prior to July 2000. For information regarding radio use in a hazardous atmosphere please refer to the Factory Mutual (FM) Approval Manual Supplement or Instruction Card, which is included with radio models that offer this capability.

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Operational Characteristics

Your phone contains a transmitter and a receiver. When it is ON, it receives and transmits radio frequency (RF) energy. The phone operates in the frequency range of 824 MHz to 849 MHz in analog and digital mode and 1850 MHz to 1910 MHz in digital mode.

When you communicate with your phone, the system handling your call controls the power levels at which your phone transmits. The output power level typically may vary over a



range from ____ watts to ____ watts in analog mode and ____ watts to ____ watts in digital mode.

Exposure To Radio Frequency Energy

Your Motorola phone is designed to comply with the following national and international standards and guidelines regarding exposure of human beings to radio frequency electromagnetic energy:

- United States Federal Communications Commission, Code of Regulations; 47 CFR part 2 sub-part J
- American National Standards Institute (ANSI) / Institute of Electrical and Electronic Engineers (IEEE) C95.1-1992
 - Institute of Electrical and Electronic Engineers (IEEE) C95.1-1999 Edition
 - National Council on Radiation Protection and Measurements (NCRP) of the United States, Report 86, 1986
- International Commission on Non-Ionizing Radiation Protection (ICNIRP) 1998
- Ministry of Health (Canada) Safety Code 6. Limits of Human Exposure to Radiofrequency Electromagnetic Fields in the Frequency Range from 3 kHz to 300 GHz, 1999
- Australian Communications Authority Radiocommunications (Electromagnetic Radiation-Human Exposure) Standard 1999

To assure optimal phone performance and make sure human exposure to radio frequency electromagnetic energy is within

the guidelines set forth in the above standards, always adhere to the following procedures:

Portable Phone Operation and EME Exposure

Antenna Care

Use only the supplied or an approved replacement antenna. Unauthorized antennas, modifications, or attachments could damage the phone and may violate FCC regulations.

Do NOT hold the antenna when the phone is in use.

Holding the antenna affects call quality and may cause the phone to operate at a higher power level than needed.

Phone Operation

When placing or receiving a phone call, hold your phone as you would a wireline telephone. **Speak directly into the microphone.**

Body-Worn Operation

To maintain compliance with FCC/Health Canada RF exposure guidelines, if you wear a phone on your body when transmitting, always place the phone in a Motorola-supplied or approved clip, holder, holster, case, or body harness for this product. Use of non-Motorola-approved accessories may exceed FCC/Health Canada RF exposure guidelines. If you do not use one of the Motorola-supplied or approved body-worn accessories, and are not using the phone held in the normal use position, **ensure the phone and its antenna are at least one inch (2.5 centimeters) from your body when transmitting.**



Data Operation

When using any data feature of the phone, with or without an accessory cable, **position the phone and its antenna at least one inch (2.5 centimeters) from your body.**

Approved Accessories

For a list of approved Motorola accessories, visit our website at www.mot.com.

Electromagnetic Interference/Compatibility

Note: Nearly every electronic device is susceptible to electromagnetic interference (EMI) if inadequately shielded, designed, or otherwise configured for electromagnetic compatibility.

Facilities



To avoid electromagnetic interference and/or compatibility conflicts, turn off your phone in any facility where posted notices instruct you to do so. Hospitals or health care facilities may be using equipment that is sensitive to external RF energy.

Aircraft

When instructed to do so, turn off your phone when on board an aircraft. Any use of a phone must be in accordance with applicable regulations per airline crew instructions.

Medical Devices

Pacemakers

The Advanced Medical Technology Association recommends that a minimum separation of 6 inches (15 centimeters) be

maintained between a handheld wireless phone and a pacemaker. These recommendations are consistent with the independent research by, and recommendations of, the United States Food and Drug Administration.

Persons with pacemakers should:

- ALWAYS keep the phone more than six inches (15 centimeters) from your pacemaker when the phone is turned ON.
- NOT carry the phone in the breast pocket.
- use the ear opposite the pacemaker to minimize the potential for interference.
- turn OFF the phone immediately if you have any reason to suspect that interference is taking place.

Hearing Aids

Some digital wireless phones may interfere with some hearing aids. In the event of such interference, you may want to consult your hearing aid manufacturer to discuss alternatives.

Other Medical Devices

If you use any other personal medical device, consult the manufacturer of your device to determine if it is adequately shielded from RF energy. Your physician may be able to assist you in obtaining this information.

Safety and General Use While Driving

Check the laws and regulations on the use of phones in the area where you drive. Always obey them.



When using your phone while driving, please:

- give full attention to driving and to the road.
- use hands-free operation, if available.
- pull off the road and park before making or answering a call if driving conditions so require.

Operational Warnings

For Vehicles With an Air Bag

Do not place a portable phone in the area over an air bag or in the air bag deployment area. Air bags inflate with great force. If a portable phone is placed in the air bag deployment area and the air bag inflates, the phone may be propelled with great force and cause serious injury to occupants of the vehicle.

Potentially Explosive Atmospheres

Turn off your phone prior to entering any area with a potentially explosive atmosphere, unless the phone is a model specifically identified as being “Intrinsically Safe.” Do not remove, install, or charge batteries in such areas. Sparks in a potentially explosive atmosphere can cause an explosion or fire resulting in bodily injury or even death.

Note: The areas with potentially explosive atmospheres referred to above include fueling areas such as below decks on boats, fuel or chemical transfer or storage facilities, areas where the air contains chemicals or particles, such as grain, dust, or metal powders, and any other area where you would normally be advised to turn off your vehicle engine. Areas with potentially explosive atmospheres are often but not always posted.

Blasting Caps and Areas

To avoid possible interference with blasting operations, turn OFF your phone when you are near electrical blasting caps, in a blasting area, or in areas posted: "Turn off two-way radio." Obey all signs and instructions.

Operational Cautions

Antennas

Do not use any portable phone that has a damaged antenna. If a damaged antenna comes into contact with your skin, a minor burn can result.

Batteries

All batteries can cause property damage and/or bodily injury such as burns if a conductive material such as jewelry, keys, or beaded chains touches exposed terminals. The conductive material may complete an electrical circuit (short circuit) and become quite hot. Exercise care in handling any charged battery, particularly when placing it inside a pocket, purse, or other container with metal objects.

ITC01-101



Getting Started

What's in the Box?

Your wireless phone typically comes equipped with a battery and a charger. Other accessory options can customize your phone for maximum performance and portability.

To purchase Motorola Original™ accessories, contact the Motorola Customer Call Center at 1-800-331-6456 in the United States or 1-800-461-4575 in Canada.

Installing the Battery

You must install and charge the battery to use your phone.



Your phone is designed to be used only with Motorola Original batteries and accessories. We recommend that you store batteries in their protective cases when not in use.



Do This

- 1 Remove the battery from its protective clear plastic case.
- 2 If necessary, slide down the battery door release latch and lift the door off of the phone.
- 3 Insert the battery, printed arrows first, into the top of the battery compartment and push down.
- 4 Replace the battery door.

Charging the Battery

New batteries are shipped partially charged. Before you can use your phone, you need to install and charge the battery, as indicated by the following instructions. Some batteries perform best after several full charge/discharge cycles.

Do This

- 1 Plug the travel charger into your phone with the release tab facing up.
- 2 Plug the other end of the travel charger into the appropriate electrical outlet.
- 3 When your phone indicates that the battery is fully charged (**Charge Complete**), press the release tab and remove the travel charger.



Notes:


- When you charge the battery, the battery level indicator in the upper right corner of the display shows how much of the charging process is complete.
- If the battery charge drops too low, your phone may power off during a call, even when the charger is connected. To avoid this possibility, do not make calls while charging the battery.



Turning Your Phone On

Do This

- 1 Press and hold 



- 2 If necessary, enter your four-digit unlock code and press **OK** ()

To

turn on your phone

unlock your phone

The unlock code is originally set to 1234. Your service provider may change this number before you receive your phone.

Making a Call

Press

- 1 keypad keys

To

dial the phone number

Tip: If you make a mistake, press **DELETE** () to delete the last digit, or press and hold **DELETE** () to clear all digits.

- 2 

make the call



Ending a Call

Press	To
	end the call

Answering a Call

When you receive a call, your phone rings and/or vibrates and displays an incoming call message.

Press	To
 or ANSWER ()	answer the call

Tip: If your phone is locked, you must unlock it to answer the call.

Seeing Your Phone Number


Press	To
 	see your phone number



About Your Phone

See page 1 for a basic phone diagram.

Using the Display



The *idle display* is the standard display that you see when you are *not* on a call or using the menu.

Labels at the bottom corners of the display show the current soft key functions. A  (menu) indicator at the bottom center of the display indicates that you can press  to enter the main menu.



❶ Signal Strength Indicator Vertical bars show the strength of the network connection. You cannot make or receive calls when the  (no signal) indicator is displayed.



❷ Digital () or Analog () Signal Indicator Shows whether you are receiving a digital or analog signal.

❸ In Use Indicator Shows that a call is in progress.



❹ Roam Indicator Shows that your phone is seeking or using another network system outside your home network.



❺ Message Waiting Indicator Appears when you receive a text message.



❻ Voice Message Waiting Indicator Appears when you receive a voicemail message.

❼ Battery Level Indicator Vertical bars show the battery charge level. Recharge the battery when you see **Low Battery** and hear the low battery alert.



❽ Active Line Indicator Shows the current active phone line.

❾ Menu Indicator Indicates that you can press  to enter the main menu or open a feature sub-menu.



⑩ Ring Style Indicator Shows the ring style setting.

 = loud ring

 = soft ring

 = vibrate

 = ring and vibrate

 = silent

Zooming In and Out

Press and release , then press and hold  to zoom in and out on the display. Zoom in to increase text size, zoom out to display more information.

You can also zoom in and out from the menu. See page 54.

Adjusting Volume

You can adjust your phone's earpiece and ringer volume by using the  key:

When	Adjust
during a call	earpiece speaker volume
phone is idle	ringer volume

Press  (up-arrow) to increase volume

Press  (down-arrow) to decrease volume.



Battery Use

Battery performance depends on many factors, including your wireless carrier's network configuration; signal strength; the temperature at which you operate your phone; the features and/or settings you select and use; and your voice, data, and other application usage patterns.

Battery Care

Caution: To prevent injuries or burns, do not allow metal objects to contact or short-circuit the battery terminals.

To maximize your battery's performance:

- Always use Motorola Original™ batteries and battery chargers. The phone warranty does not cover damage caused from using non-Motorola batteries and/or battery chargers.
- New batteries or batteries that have been stored for long periods of time may require a longer charge time.
- Maintain the battery at or near room temperature when charging.
- Do not expose batteries to temperatures below -10°C (14°F) or above 45°C (113°F). Always take your phone with you when you leave your vehicle.
- When you do not intend to use a battery for a while, store it uncharged in a cool, dark, dry place, such as a refrigerator.



- Over extended periods of time, batteries gradually wear down and require longer charging times. This is normal. If you charge your battery regularly and notice a decrease in talk time or an increase in charging time, then it is probably time to purchase a new battery.



The rechargeable batteries that power this product must be disposed of properly and may need to be recycled. Refer to your battery's label for battery type. Contact your local recycling center for proper disposal methods. Never dispose of batteries in a fire because they may explode.

Extending Battery Life

- **Turn off your display backlight**

The backlight uses power. To turn it off, see page 54.

- **Avoid keypad-intense functions**

Activities that require intensive keystroke use (such as playing a game or using messaging) reduce your phone's talk and standby time. Lock the keypad when storing the phone in your purse or pocket to avoid unnecessary keypad and backlight activations. See page 132.



Making and Answering Calls



For basic instructions on how to make a call, end a call, and answer a call, see pages 20–21.

Redialing a Number

If you hear an ordinary busy signal:

Press	To
1	hang up
2	redial the busy number

Using Caller ID



Calling line identification (caller ID) displays the phone number for incoming calls.

The phone displays the caller's name when the name is stored in your phonebook, or

Incoming Call when caller ID information is not available.

Using Talk Secure

When *talk secure* is activated, your phone always tries to use a high-security connection to prevent others from intercepting your calls. To activate talk secure, see page 133.

If a high-security connection is not available, your phone uses a standard connection and displays **Line Not Secure**.

This message does not appear when caller ID or other information is displayed.

Returning Unanswered Calls

Your phone keeps a record of your unanswered calls, and displays:

- the  (missed call) indicator
- X Missed Calls Y Unknown**, where **X** is the total number of missed calls and **Y** is the number of missed calls with no caller ID information

Press	To
1 VIEW (⊙)	see the received calls list
2 	select a call to return
3 	make the call

Calling an Emergency Number

Your service provider programs one or more emergency phone numbers, such as 911, that you can call under any circumstances, even when your phone is locked.

Note: Emergency numbers vary by country. Your phone's preprogrammed emergency number(s) may not work in all locations, and sometimes an emergency call cannot be placed due to network, environmental, or interference issues.

**Press****To****1** keypad keys

dial the emergency number

2

call the emergency number

Turning Off a Call Alert

You can turn off your phone's incoming call alert before answering the call.

Press**To**

either volume key

turn off the alert

Canceling an Incoming Call

While the phone is ringing or vibrating:

Press**To** or **IGNORE**

cancel the incoming call



Depending on your phone settings and/or service subscription, the call may be forwarded to another number, or the caller may hear a busy signal.

Calling With Speed Dial

Each entry you store in your phonebook is assigned a unique *speed dial* number. To speed dial a phonebook entry:

Press	To
1 keypad keys	enter the speed dial number for the entry you want to call
2 	submit the number
3 	call the entry

Calling With One-Touch Dial

To call phonebook entries 1 through 9, just press and hold the one-digit speed dial number for one second.

We recommend that you reserve phonebook entry 1 (speed dial number 1) for storing and dialing your voicemail number. In many cases, your service provider has already done this for you. If necessary, see page 64 to store your voicemail number for one-touch dial access.

Calling a Number In a Text Message



To call a phone number embedded in a text message that you receive:

Press	To
1 	open the Text Msg Menu

Press	To
2 	scroll to Call Back
3 SELECT 	call the number

Additional Calling Features

While dialing (with digits visible in the display), open the **Dialing Menu** to perform the following tasks:

Press	To
 > Attach Number	attach a number from the phonebook or recent call lists
 > Send Message	open a new text message with the number in the To field

You can also call a number using these features:

Do This	To Call
Press  , scroll to and select Voice Dial , and say the entry's name within two seconds	a phonebook entry using voice dial To record a voice name, see page 68.
Press  > Recent Calls > Received Calls or Dialed Calls > <i>entry to call</i>	a missed call, or a recent received or dialed call



Using Features While On a Call

Using Call Waiting

When you are on a call, an alert tone sounds to indicate that you have received a second call.



Press	To
1 	answer the new call
2 	switch back to the first call

Making a Three-Way Call

During a call, you can call and connect a third party for a three-way call. You cannot do this if you already have a call on hold.



Press	To
1 keypad keys	dial the third party's number
2 	call the number
3 	connect the two calls
4 	end the entire call

Additional On-Call Features

Press	To
MUTE (⊙) (if available) or ☰ > Mute	mute the call
SPEAKER (⊙) (if available) or ☰ > Spkrphone On	activate an attached speakerphone
☰ > My Tel. Number	see your phone number
☰ > Send Tones	send a number to the network as DTMF tones, for credit card or password calls To activate DTMF tones, see the “DTMF” option on page 55.
☰ > Received Calls or Dialed Calls	view recent received or dialed call numbers
☰ > Messages	view or send messages
☰ > Datebook	view datebook entries
☰ > Other Information	view phone specifications
☰ > TTY Setup	switch to TTY mode For more information, see “Switch to TTY Mode During a Voice Call” on page 119.



Using the Menu

Navigating to a Feature

Use these keys to move through the menu system:

Left Soft Key

Perform the function shown in the lower left corner of the display (usually **EXIT** or **BACK**).

Right Soft Key

Perform the function shown in the lower right corner of the display (usually **SELECT** the highlighted menu item).

Menu Key

Enter the menu system, or open a sub-menu, when  appears in the bottom center of the display.

Navigation Key


Scroll through lists, adjust volume.

Power/End Key

Exit the menu system without making changes, return to the idle display.

 and 


Cycle through and set the value of the highlighted menu item.



Selecting a Feature Option

Some features require you to select an item from a list:

Press **BACK** (⊙) to go back to the previous screen.



Press (≡) to open the sub-menu.

Press **VIEW** (⊙) to view details of the highlighted item.

- Press (⬆/⬇) to scroll up or down to highlight the item you want.
- In a numbered list, press a number key to highlight the item.
- In an alphabetized list, press a key multiple times to cycle through the letters on the key and highlight the closest matching list item.



Entering Feature Information

Some features require you to enter information:

Press  to scroll down to additional items.



The dialog box is titled "Entry Details" and contains two input fields. The first field is labeled "Name:" and contains the text "John Smith". The second field is labeled "No.:" and contains the text "2125551212". Below the input fields are two buttons: "CANCEL" on the left and "CHANGE" on the right. A line points from the "Highlighted item" text to the "Name:" field.

Highlighted item

Press **CANCEL** () to exit without making changes. **DONE** () appears when you enter or edit information.

Press **CHANGE** () to edit the information.

- 
- Enter numbers or text with the keypad.
 - When an item has a list of possible values, press  or  to scroll through and select a value.
 - When an item has a list of possible numeric values, press a number key to set the value.
 - If you enter or edit information and do not want to save your changes, press  to exit without saving.

The message center lets you compose and send text messages. A *flashing cursor* shows where text will appear:

Flashing cursor indicates insertion point.



Press **BROWSE** (⊙) to view and insert a name, number, or message from previously stored information.

Press **CANCEL** (⊙) to exit without making changes.

Press (≡) to open the sub-menu.

When you enter text, the flashing cursor changes to a *block cursor*, and the soft key functions change:

Block cursor indicates current highlighted character.



Press **OK** (⊙) to accept and store the text.

After two seconds, the block cursor reverts to a flashing cursor and moves to the next position.

Press **DELETE** (⊙) to delete the character to the left of the insertion point.



Entering Text

Multiple text entry methods make it easy for you to enter names, numbers, and messages on your phone.

Choosing a Text Mode

Press  from any text entry screen to select a text mode:

- | | |
|-------------------|---|
| iTAP | Let the phone predict each word as you enter it. See page 43. |
| Tap Method | Enter letters, numbers, and symbols by pressing a key one or more times. See page 39. |
| Numeric | Enter numbers only. |
| Symbol | Enter symbols only. See page 42. |
| Browse | Browse your phonebook or recent call lists to select a name or number. |

Note: The text mode you select remains active until you change it by selecting another mode.



Using Tap Method

This is the standard mode for entering text on your phone.

Press  from any text entry screen and select the **Tap Method** menu option.


Do This	To
1 Press a number key one or more times	select a letter, number, or symbol shown in the "Character Chart" on page 41
2 Continue pressing number keys	enter the remaining characters
3 Press OK ()	store the text when you are finished

General Text Entry Rules

Press a number key repeatedly to cycle through its characters. See “Character Chart” on page 41.

Press a number key as many times as necessary to enter the desired character at flashing cursor location.

Move flashing cursor to the left or right in text message.



Change letter in block cursor to uppercase or lowercase.

Press and hold a number key to cycle between **tap method** and numeric mode.

- If you do not press a key for two seconds, the character in the block cursor is accepted, and the cursor moves to the next position.
- The first character of every sentence is capitalized. (Press  down to force the character to lowercase while it is highlighted by the block cursor).

- Your phone may support multiple languages. The current language setting determines whether a new message begins on the left or right side of the display.

You can switch languages within a message. Press  to select the text mode and language you want to use.

Character Chart

Use this chart as a guide for entering spaces, letters, numbers, and symbols with the tap method.

1 	space . 1 ? ! , @ _ & ~ : ; " - () ' ¿ ¡ % £ \$ ¥ ¤ €
2 ABC	a b c 2 á à â ã ç
3 DEF	d e f 3 é è ê ë
4 GHI	g h i 4 í î ï
5 JKL	j k l 5
6 MNO	m n o 6 ñ ó ô õ
7 PQRS	p q r s 7
8 TUV	t u v 8 ð ü ú û û
9 WXYZ	w x y z 9
0+ 	+ - 0 x * / \ [] = > < # §

Note: This chart may not reflect the exact character set available on your phone.

Using Symbol Mode

Your phone provides an alternate way to enter symbol characters in a message. Press  from any text entry screen and select the **Symbol** menu option.

Do This	To
1 Press a number key one time	display its symbol options at the bottom of the display See "Symbol Chart" on page 42.
2 Press  or  or Press the number key multiple times	highlight the symbol you want
3 Press SELECT ()	enter the symbol at the flashing cursor location

Symbol Chart

Use this chart as a guide for entering characters in symbol mode.

	space . ? ! , @ _ & ~ : ; " - () ' ` ¡ ¢ % £ \$ ¥ ¤ €
	@ _ \ α β
	/ : ; δ φ

4 CHI	" & ' γ
5 OJL	() [] { } λ
6 NNO	ı i ~ ω
7 PQRS	< > = π β σ
8 TUV	\$ £ ¥ ¤ € θ
9 WXYZ	# % * ξ ψ
0 +	+ - x * / = > < # §

Using iTAP™ Software Predictive Text Entry Method

iTAP™ software provides a predictive text entry method that lets you enter a word using one keypress per letter.

Press  from any text entry screen and select the iTAP menu option.

Enter Words

Do This

- 1 Press a number key one time

To


enter the first letter of the word

The letters associated with the key are shown at the bottom of the display.

Do This	To
2 Press number keys (one per letter)	enter the rest of the word Alternative words and letter combinations are shown at the bottom of the display. The word choices are updated with each keypress.
3 Press or	highlight the word you want
4 Press SELECT	enter the word at the flashing cursor location A space is automatically inserted after the word.

For example, to spell the word “act,” press .
The display shows:

Flashing cursor indicates insertion point.



Press to scroll and see additional word choices.

Press **DELETE** to clear the last letter.

Press **SELECT** to insert the highlighted word.

Enter Novel Words

You may enter a word that is not in the iTAP software dictionary. If the word you want is not displayed:

Do This	To
1 Press DELETE (⊙) one or more times	delete letters until you see a letter combination that matches the start of the word
2 Press (✱) or (#)	highlight the letter or letter combination
3 Press SELECT (⊙), then press (✱)	shift the text entry cursor to the left and “lock” the selected word portion
4 Continue to enter letters and highlight letter combinations	spell the word

Punctuation

Press	To
(0+) or (1.0)	enter punctuation or other characters as shown in the “Character Chart” on page 41

Capitalization

The first word of a sentence is automatically capitalized, with following words in lowercase.

Press	To
	change the words to initial character capitalized, all uppercase characters, or all lowercase characters

Enter Numbers

Do This	To
1 Enter the first digit and then highlight it	put the iTAP software in number entry mode
2 Press number keys	add digits to the number
3 Press SELECT ()	enter the number at the flashing cursor location

Delete Letters and Words

Place the cursor to the right of the text you want to delete, and then do the following:

Do This	To
Press DELETE ()	delete one letter at a time
Hold DELETE ()	delete the entire message

Menu Feature Descriptions

This chapter describes all of your phone's features in order of the menu map shown on pages 3–4.

Main Menu

RECENT CALLS

Received Calls

☰ > Recent Calls
> Received Calls

View a list of recently received calls. See page 58.

Dialed Calls

☰ > Recent Calls
> Dialed Calls

View a list of recently dialed calls. See page 58.

Notepad

☰ > Recent Calls
> Notepad

Call or store the last number entered on the keypad.
See page 60.

Call Times

☰ > Recent Calls
> Call Times

View call timers that track time spent on your last call, dialed calls, received calls, all calls since reset, and all calls total. See page 60.



PHONEBOOK☰ > **Phonebook**

Store names and numbers as entries in your phonebook, then call numbers by selecting them from the phonebook list. See page 63.

VOICE DIAL☰ > **Voice Dial**

You can record a voice name for a new or existing phonebook entry. A voice name lets you call the phonebook entry using voice dial

DATEBOOK☰ > **Datebook**

Use the datebook calendar to schedule and review your appointments. See page 74.

RADIO☰ > **Radio**

Listen to FM radio stations with the optional Motorola Original™ FM Stereo Radio Headset accessory. This menu feature is displayed only when the FM Stereo Radio Headset is plugged into the accessory connector port on your phone. See page 79.

**MESSAGES**☰ > **Messages**

Adjust message settings, view and manage the various types of messages your phone can receive and/or send:

**Create Msg**

Create new text messages.
See page 89.

VoiceMail

Listen to your recorded voice messages. See page 82.



Text Msgs	Read and manage text messages. See page 84.
Quick Notes	Select and send pre-written messages from the quick notes list. See page 91.
Outbox	View all outgoing text messages, delivered and undelivered.
Drafts	Store and edit text messages that you have written but not sent.

RING STYLES

Style

☰ > Ring Styles
> Style

Select the ring style your phone uses to notify you of incoming calls, messages, or other events. See page 93.

Style Detail

☰ > Ring Styles
> Style Detail

Change details about the current ring style. *Style* represents the name of the ring style. See page 93.

My Tones

☰ > Ring Styles
> My Tones

Create custom alert tones for your phone. See page 95.

SHORTCUTS

☰ > Shortcuts

Create keypad shortcuts to menu features. See page 104.



WEB SESSIONS > **Web Sessions**

Access Web pages and run Web-based applications. The micro-browser delivers WAP (Wireless Application Protocol) pages from your service provider directly to your phone. See page 107.

**CALCULATOR** > **Calculator**

Use your phone as a calculator or currency converter. See page 109.

GAMES > **Games**

Play games on your phone. See page 112.

Settings Menu

PHONE STATUS***My Tel. Number*** > **Settings**
> **Phone Status**
> **My Tel. Number**

View, enter, and edit information about your name and phone number.

Active Line > **Settings**
> **Phone Status**
> **Active Line**

Change the active phone line to send and receive calls from either of the available numbers.

Battery Meter > **Settings**
> **Phone Status**
> **Battery Meter**

View a detailed battery charge meter.



Other Information

- > Settings
- > Phone Status
- > Other Information



View your phone's feature specifications (if available from the service provider).

CONNECTION

Connect your phone to a computer or hand-held device to send and receive data calls on the connected device. See page 123.



Incoming Call

- > Settings
- > Connection
- > Incoming Call

Specify the format for the next incoming call. You can select **Data In Only** or **Normal**. See page 126.

IN-CALL SETUP

Set the features that are active during a call, such as the in-call timer and call answering options.

In-Call Timer

- > Settings
- > In-Call Setup
- > In-Call Timer

Adjust call timer **Display** and **Beep** settings. You can set your timer to beep at a selected interval during your calls. (60 seconds is the default.) You can also turn on or off a display timer during calls as follows:

Time

Display the elapsed time for the current call.

Off

No in-call timer display.



Answer Options

- ⓘ > Settings
- > In-Call Setup
- > Answer Options

Turn call answering options on or off:

Multi-Key

Answer by pressing any key.

SECURITY**Phone Lock**

- ⓘ > Settings > Security
- > Phone Lock

Lock and unlock your phone. See page 131.

Lock Keypad

- ⓘ > Settings > Security
- > Lock Keypad

View instructions on how to lock and unlock your keypad. See page 132.

Lock Application

- ⓘ > Settings > Security
- > Lock Application

Lock and unlock specific phone applications (such as phonebook or datebook). When an application is locked, users must enter the unlock code to use the application.

Talk Secure

- ⓘ > Settings > Security
- > Talk Secure

Activate a secure connection to prevent others from intercepting your calls. See pages 27 and 133.

Restrict Calls

- ⓘ > Settings > Security
- > Restrict Calls

Restrict incoming and outgoing calls. See page 132.



New Passwords

- ☰ > Settings > Security
> New Passwords

Change your unlock code (originally set to 1234) or your security code (originally set to 000000). See page 129.

OTHER SETTINGS

Personalize

- ☰ > Settings
> Other Settings
> Personalize

Set several personal phone options:

Main Menu

Change the order of the main menu. See page 117.

Keys

Change the functions of the soft keys in the idle display. See page 117.

Greeting

Change the text displayed when you turn on your phone.



Initial Setup

- ☰ > Settings
> Other Settings
> Initial Setup

Set many basic phone options:

Time and Date

Set the phone's time and date.



**Backlight**

Set the amount of time that the display backlight remains on, or turn off the backlight to conserve battery power.

Zoom

Switch between three lines (**Zoom Out**) and two lines (**Zoom In**) of display text.

TTY Setup

Set your phone to operate in one of three TTY modes, or return to normal **Voice** mode. See page 118.

**Scroll**

Force the cursor to stop or wrap around when it reaches the top or bottom of a list in the display.

Animation

Turn animation off (to conserve battery power) or on. Animation makes your phone's menus move smoothly as you scroll up and down.

Language

Set the language for phone menus.

Battery Save

Adjust the phone's power usage characteristics to conserve power.



Contrast

Adjust the contrast setting for your display.

DTMF

Your phone can send a number to the network as dual tone multi-frequency (DTMF) tones. DTMF tones are used to communicate with automated systems that require you to enter a number such as a code, password, or credit card number. Use this option to set DTMF tones on or off.

Master Reset

Reset all options back to their original factory settings *except* for the unlock code, security code, and lifetime timer.

Master Clear

Reset all options back to their original factory settings *except* for the unlock code, security code, and lifetime timer, *and* clear all user settings and entries.

Note: This option *erases all user-entered information* stored in your phone's memory, including phonebook and datebook entries. Once you erase the information, it cannot be recovered.

Network

- ⌘ > Settings
- > Other Settings
- > Network



View and adjust your phone's network settings.

Your service provider registers your phone to a network. You can view information about the current network, change how your phone searches for a network, and activate alerts that indicate when a call is dropped or network registration changes.



Car Settings

- ⌵ > Settings
- > Other Settings
- > Car Settings



Adjust hands-free car kit settings.

You can set your phone to route calls directly to the car kit when it detects a connection, and automatically answer calls after two rings. See page 120.

Note: The use of wireless devices and their accessories may be prohibited or restricted in certain areas. Always obey the laws and regulations on the use of these products.

Headset

- ⌵ > Settings
- > Other Settings
- > Headset



Set your phone to automatically answer calls after two rings when connected to a headset. See page 120.



Recent Calls



Viewing Received Calls or Dialed Calls

Your phone keeps a list of the calls you recently received and dialed, even if the calls did not connect. The lists are sorted from newest to oldest entries. The oldest entries are deleted as new ones are added.

Shortcut: Press to go directly to the dialed calls list from the idle display.

Find the Feature

> Recent Calls

Press	To
1	scroll to Received Calls or Dialed Calls
2 SELECT ()	select the list
3	scroll to an entry
Note: ✓ means the call connected.	



Press	To
4	call the entry's number
or	
VIEW	view entry details
or	
	open the Last Calls Menu to perform other procedures as described in the following list

The **Last Calls Menu** includes the following options:

Option	Description
Store	Create a phonebook entry with the number in the No. field.
Delete	Delete the entry.
Delete All	Delete all entries in the list.
Send Message	Open a new text message with the number in the To field.
Add Digits	Add digits after the number.
Attach Number	Attach a number from the phonebook or recent call lists, after the highlighted number.
Send Tones	Send the number to the network as DTMF tones, for credit card or password calls.

Using the Notepad

Your phone stores the most recent string of digits entered on the keypad in a temporary memory location called the *notepad*. This can be a phone number that you called, or a number that you entered but did not call. To retrieve the number stored in the notepad:

Find the Feature

☰ > Recent Calls
> Notepad

Press

To

⓪

call the number

or

☰

open the **Dialing Menu** to
attach a number or insert a
special character

or

STORE (Ⓢ)

create a phonebook entry
with the number in the **No.**
field

Viewing and Resetting Call Timers

Network connection time is the elapsed time from the moment you connect to your service provider's network to the moment you end the call by pressing Ⓢ. This time includes busy signals and ringing.

The amount of network connection time you track on your resettable timer may not equal the amount of time for which you are billed by your service provider. For billing information, please contact your service provider directly.



You can view the following network connection times:

Timer	Description
Last Call	Time spent on last dialed or received call. You cannot reset this timer.
Dialed Calls	Time spent on dialed calls since the last time you reset this timer.
Received Calls	Time spent on received calls since the last time you reset this timer.
All Calls	Time spent on dialed and received calls since the last time you reset this timer.
Lifetime	Time spent on all calls on this phone. You cannot reset this timer.



Recent Calls



To view a call timer:

Find the Feature

☰ > Recent Calls
> Call Times

Press	To
1 ☰	scroll to the timer you want\
2 SELECT (☉)	view the recorded time

To reset the call timer:

Press	To
1 RESET (☉)	reset the time (if available)
2 YES (☉)	confirm the reset

Phonebook

You can store names and phone numbers or email addresses in your phone's electronic phonebook.

To see the names in your phonebook, press **☰** > **Phonebook** from the idle display. Scroll to a name and press **VIEW** (**⊙**) to view details of the phonebook entry as shown below.

Viewing Entry Details

Type indicator identifies number type:

-  Work
-  Home
-  Main
-  Mobile
-  Fax
-  Pager
-  Email

Voice Name indicator indicates a recorded voice name

Entry's Name


Entry's phone number or email address

Entry's speed dial number

Return to list

Press **☰** to open the Phonebook Menu

Edit entry



Note: When you set a distinctive ringer alert for an entry, the **Ringer ID** setting appears below the speed dial number.

Storing a Phonebook Entry

A phone number or email address is required for a phonebook entry. All other information is optional.

Shortcut: Enter a phone number in the idle display, then press **STORE** (⊙) to create a phonebook entry with the number in the **No.** field. Go directly to step 3 to continue.

Enter Information

Find the Feature

☰ > **Phonebook**

☰ > **New**

Press	To
1 ⊙	scroll to Phone Number or Email Address
2 SELECT (⊙)	select the entry type
3 CHANGE (⊙)	select Name
4 keypad keys	enter a name for the entry
5 OK (⊙)	store the name
6 CHANGE (⊙)	select No. or Email
7 keypad keys	enter the phone number or email address
Tip: You can store a PIN code with the phone number. See page 66.	
8 OK (⊙)	store the phone number or email address



Press	To
9 CHANGE (⊙)	select Type Note: This option is not available for email entries.
10 (⊙)	scroll to the number type
11 SELECT (⊙)	select the number type
12 RECORD (⊙) or Go to step 13 if you do not want a voice name	record a voice name for the entry, if desired (see page 68)
13 (⊙)	scroll to Speed No. The next available speed dial number is assigned to a new phonebook entry.
14 CHANGE (⊙)	select Speed No. if you want to change it
15 keypad keys	enter a different speed dial number, if desired
16 OK (⊙)	store the speed dial number
17 CHANGE (⊙)	select Ringer ID if you want to assign a distinctive ringer alert for the phone number Your phone uses the alert to notify you when you receive a call from this phone number. See page 94.





Press	To
18	scroll to the alert you want
19 SELECT	store the ringer ID alert
20 SELECT	select MORE if you want to create another entry under the same Name
You must use a different Type identifier for each number.	

Complete Phonebook Entry

When you finish entering information for a phonebook entry:

Press	To
DONE	store the entry

Storing a PIN Code With the Phone Number

You can store a PIN code with the phone number for calls that require additional digits (for example, to make a calling card call, or to retrieve voicemail or answering machine messages). Insert one or more of the following characters in the dialing sequence to ensure that the number dials and connects properly:



Press	To
 > Insert Pause	insert a p (pause) character Your phone dials the preceding digits, waits for the call to connect, then sends the remaining digit(s).
 > Insert Wait	insert a w (wait) character Your phone dials the preceding digits, waits for the call to connect, then prompts you for confirmation before it sends the remaining digit(s).
 > Insert 'n'	insert an n (number) character Your phone prompts you for a number before dialing the call. The number you enter is inserted into the dialing sequence in place of the n character

Note: You can store a maximum of 32 digits per number. Each character counts as one digit.

Recording a Voice Name For a Phonebook Entry

You can record a voice name for a new or existing phonebook entry. A voice name lets you call the phonebook entry using voice dial (see page 69).

Tip: Make your recording in a quiet location. Hold the phone about four inches (10 centimeters) from your mouth, and speak directly into the phone in a normal tone of voice.

Find the Feature

 > **Phonebook**

Do This	To
1 Press 	scroll to the entry
2 Press VIEW ()	view entry details
3 Press EDIT ()	edit the entry
4 Press 	scroll to Voice Name
5 Press RECORD ()	begin recording
6 Press and release RECORD () and say the entry's name (in two seconds)	record the voice name
7 Press and release RECORD () and say the name	confirm the voice name
8 Press DONE ()	store the voice name

Dialing a Phonebook Entry

Use one of the following procedures to call a number (or send a text message to an email address) stored in your phonebook.

Phonebook List

Find the Feature

 > Phonebook

Press	To
1 keypad key letter	jump to entries that begin with that letter (optional)
2 	scroll to the entry
3 	make the call

Voice Dial

Do This	To
Press V. Dial () and say the entry's name within two seconds)	make the call

To speed dial a phonebook entry, see page 30. To call an entry with one-touch dial, see page 30.



Editing a Phonebook Entry

Find the Feature

 > **Phonebook**

Press	To
1 	scroll to the entry
2 VIEW ()	view entry details
3 EDIT ()	edit the entry

Edit the entry as described on pages 64-66.

Deleting a Phonebook Entry

Find the Feature

 > **Phonebook**

Press	To
1 	scroll to the entry
2 	open the Phonebook Menu
3 	scroll to Delete
4 SELECT ()	select Delete
5 YES ()	confirm the deletion



Setting the Primary Number for a Phonebook Entry

When you enter multiple phone numbers for the same name, you can set one as the primary number.

Find the Feature

 > Phonebook

Press	To
1 	scroll to the entry
2 	open the Phonebook Menu
3 	scroll to Set Primary
4 SELECT ()	select Set Primary
5 	scroll to the number you want to set as the primary number
6 SELECT ()	set the primary number

Depending on how the phonebook list is sorted, the primary number is listed first, or is the only number that appears for a phonebook entry. See page 72.

Checking Phonebook Capacity

You can see how much memory space remains for storing phonebook and datebook entries on your phone.

Find the Feature

 > Phonebook

Press	To
1 	open the Phonebook Menu
2 	scroll to Ph Book Capacity



Press	To
3 SELECT (⊙)	select Ph Book Capacity
	Your phone displays the phone memory meter.

Sorting the Phonebook List

You can sort your phonebook list by speed dial number (the standard), name, email address, or voice name.

Tip: The voice name sort is identical to the name sort, except that entries with voice name tags appear first.

Find the Feature ☰ > **Phonebook**

Press	To
1 ☰	open the Phonebook Menu
2 ⬅➡	scroll to Setup
3 SELECT (⊙)	select Setup
4 ⬅➡	scroll to Sort by
5 CHANGE (⊙)	select Sort by
6 ⬅➡	scroll to Name, Speed No., Voice Name, or Email
7 SELECT (⊙)	select the sort order

If you select **Speed No.**, **Voice Name**, or **Email**, the procedure is complete.



If you select **Name**, you must specify whether you want to view all numbers or just the primary number for each name:

Press	To
8 CHANGE (⊙)	change view preference
9 ⊕	scroll to Primary Contacts or All Contacts
10 SELECT (⊙)	select the view preference
11 DONE (⊙)	set the view preference

To set an entry's primary phone number, see page 71.



Datebook

The datebook is a calendar that lets you schedule and organize events such as appointments and meetings. You can set the datebook to send a reminder alarm for specific events.

Note: You must set the correct time and date on your phone to use the datebook.


To schedule or review datebook events:

Find the Feature

 > Datebook


Week View

The datebook initially displays a calendar for the week. Lines or filled boxes indicate scheduled events.




Day View

Select a day and press **VIEW** (⊙) to see the day's events.



Event View

Select an event and press **VIEW** (⊙) to see event details.



Adding a Datebook Event

A title is required for a datebook event. All other information is optional.

Note: You must create an event to use the reminder alarm.

Find the Feature

 > **Datebook** > *day*
 > **New**

Press	To
1 CHANGE ()	select Title
2 keypad keys	enter a title for the event
3 OK ()	store the event title
4 	scroll to other fields and enter information as necessary You can set start time, duration, date, repeat interval, and reminder alarm.
5 DONE ()	store the event

Changing Event Information

Find the Feature

 > **Datebook**

Press	To
1 	scroll to the day
2 VIEW ()	display the day view
3 	scroll to the event
4 VIEW ()	display the event view
5 EDIT ()	edit the event



Press	To
6	scroll to the information you want to change
7 CHANGE ()	edit the information
8 keypad keys	enter new information
9 DONE ()	store the information

Copying an Event

Find the Feature > **Datebook**

Press	To
1	scroll to the day
2 VIEW ()	display the day view
3	scroll to the event
4	open the Datebook Menu
5	scroll to Copy
6 SELECT ()	copy the event
7 YES ()	confirm the copy
Your phone assumes you want to change the date, and displays the Date field.	
8 keypad keys	enter date information
9 ()	move to month, day, and year
10 DONE ()	save the copy of the event
11	scroll to and edit event information, if necessary
12 DONE ()	store the information



Deleting an Event

Find the Feature

 > **Datebook**

Press	To
1 	scroll to the day
2 VIEW ()	display the day view
3 	scroll to the event
4 	open the Datebook Menu
5 	scroll to Delete
6 SELECT ()	select Delete
7 YES ()	confirm the deletion



Radio



You can use your phone to listen to FM radio stations when the optional Motorola Original™ FM Stereo Radio Headset accessory is plugged into the phone's accessory connector port.

Turning the Radio On and Off

Press	To
Radio (⊙)	turn the radio on and off

Alternatively, you can use the following procedure:

Press	To
1 (≡)	open the menu
2 (⊙)	scroll to Radio
3 On (⊙) or Off (⊙)	turn the radio on or off

Note: The **Radio** menu feature and soft key options appear only when the FM Stereo Radio Headset is plugged into the accessory connector port.



Tuning a Station

Do This	To
Press 	scroll to the next frequency
or	
Press and hold 	scroll to the next available stereo station

Storing a Preset

Do This	To
Press and hold a number key ( to )	assign its preset number to the tuned station

Selecting a Preset

Press	To
a number key ( to )	tune the station stored at the preset location

Sending and Receiving Calls with the Radio On

Your phone rings or vibrates as usual to notify you of an incoming call, message, or other event.



Do This	To
Press IGNORE (⊙)	ignore the call
Press ANSWER (⊙) or Press the button on the FM Stereo Radio Headset microphone	answer the call Note: You can use the FM Stereo Radio Headset microphone to converse with the other party during a call

To end the call and resume the FM broadcast:

Do This	To
Press ⊕ or Press and hold the button on the FM Stereo Radio Headset microphone	end the call

Turn the radio off before dialing outgoing calls from the phone keypad. You do not have to turn off the radio to dial emergency numbers, or numbers selected from your phonebook or recent call lists.

Tip: To dial a recently called number, press ⊕ or the button on the FM Stereo Radio Headset microphone to go to the dialed calls list. For more information, see page 58.



Messages—Voicemail



You can listen to your voicemail messages by calling your network voicemail phone number. Voicemail messages are stored on the network—not on your phone.

Storing Your Voicemail Number

Storing your voicemail number on your phone makes it easy for you to listen to new voicemail messages. In many cases, your service provider has already done this for you.

Find the Feature



> Messages



> VoiceMail Setup

Press	To
1 keypad keys	enter your voicemail number
Tip: You can store your PIN code with the voicemail number. See page 66.	
2 OK (⊙)	store the number

Your service provider additionally may store your voicemail number as phonebook entry number 1, so you can use one-touch dial to listen to your voicemail messages. If necessary, see page 64 to store your voicemail number for one-touch dial access.



Receiving a Voicemail Message

When you receive a voicemail message, your phone displays the  (voice message waiting) indicator and a **New VoiceMail** notification.

Press	To
CALL (☎)	listen to the message

If reminders are turned on, your phone sends a reminder at regular intervals until you close the new message notification, listen to the message, or turn off your phone.

Listening to a Voicemail Message

Find the Feature  > **Messages** > **VoiceMail**

The phone calls your voicemail number. If no voicemail number is stored, your phone prompts you to store one.

Shortcut: If your voicemail number is also stored as phonebook entry number 1, you can press and hold  to listen to your voicemail message(s).



Messages—Text



Text messages are brief messages that you can send and receive.

Quick notes are pre-written text messages that you can customize and send quickly.

Your text message inbox must be set up *before* you can send and receive messages. The number of messages the inbox can hold depends on the length of the messages, and the number of other messages and drafts stored on your phone.

Setting Up the Text Message Inbox

Note: In many cases, your service provider has already set up the text message inbox for you.

Find the Feature

☰ > Messages

☰ > Text Msg Setup

Press	To
1 CHANGE (⊙)	change the Srvce Center No.
2 keypad keys	enter the phone number for the service that handles your outgoing messages
3 OK (⊙)	store the number
4 CHANGE (⊙)	change the Expire After period



Press	To
5 keypad keys	enter the expiration period—the number of days your network tries to send unreceived messages
6 OK (⊙)	store the expiration period
7 CHANGE (⊙)	change the Cleanup setting
8 ⬇️	scroll to the number of days you want to keep messages in the inbox, or the number of messages you want to keep
9 SELECT (⊙)	select the cleanup setting
10 CHANGE (⊙)	change the SMS Alert setting
11 ⬇️	select whether you want incoming message alerts turned On or Off while you are on a voice call
12 SELECT (⊙)	select the SMS Alert setting
13 DONE (⊙)	save the inbox settings

Receiving a Text Message

Note: Your text message inbox must be set up before you can receive text messages. See page 84.

When you receive a text message, your phone displays the  (message waiting) indicator and a **New Message** notification, and gives an alert.

Press	To
READ (⊙)	open the message



If reminders are turned on, your phone sends a reminder at regular intervals until you close the new message notification, read the message, or turn off your phone.

When your phone displays **Memory is Full!**, you must delete some existing messages to receive new messages.

Reading, Locking, or Deleting a Text Message

Messages in the text message inbox are sorted from newest to oldest. The oldest messages are deleted automatically as specified by the inbox cleanup setting (see page 84). If you want to save a message, you should lock it to prevent it from being deleted during cleanup.

Find the Feature

ⓘ > Messages
> Text Msgs



Press	To
1 	scroll to the message
	The following indicators show message status:
	 = unread
	 = unread (with attachment)
	 = unread and urgent
	 = unread and urgent (with attachment)
	 = read
	 = read (with attachment)
	 = read and urgent
	 = read and locked
	 = read and locked (with attachment)
2 READ ()	open the message
3 SAVE ()	close the message
or	
REPLY ()	compose and send a reply
or	
	open the Text Msg Menu to perform other procedures as described in the following list

The **Text Msg Menu** includes the following options:

Option	Description
Delete	Delete the message.



Option	Description
Call Back	Call the number in the message header or embedded in the message.
Go To	Launch the micro-browser and go to a Web address (URL) embedded in the message.
Forward	Open a copy of the text message, with an empty To field. Note: You cannot forward sound files embedded in a text message. Only the text is forwarded.
Store Tone	Store the selected sound file.
Play	Play a sound file in the message.
Lock/Unlock	Lock or unlock the message.
Store Number	Create a phonebook entry, with the embedded number in the No. field.
Delete All	Delete all inbox messages.
Create Message	Open a new text message.
Store Address	Create a phonebook entry, with the embedded email address in the Email field.
Setup	Open the text message inbox setup menu.

Storing Sounds

Text messages that you receive can contain sounds. A sound begins playing when you scroll to or select the  (sound file) indicator in the message.

You can store these embedded sound files on your phone, and use them as alert tones.

Press	To
1 	open the Text Msg Menu
2 	scroll to Store Tone
3 SELECT ()	select the option
	Your phone adds the sound to the My Tones list.

For more information about using sound files, see pages 94 and 95.

Sending a Text Message

You can send a text message to one or more recipients. You can manually enter each recipient's phone number or email address, or select numbers/addresses from the phonebook or recent call lists.

Note: When you manually enter numbers and/or email addresses, you must insert a space between each entry. Press and hold  until the space appears, then enter the next number or email address.

Find the Feature

 > **Messages**
> **Create Message**





Press	To
1 CHANGE (⊙)	select To
2 keypad keys	enter one or more phone numbers and/or email addresses
Tip: Press and hold 1.e to insert a space between each number/address that you enter manually.	
or	
BROWSE (⊙)	select numbers/addresses from the phonebook or recent call lists
3 OK (⊙)	store the numbers/addresses
4 CHANGE (⊙)	select Msg
5 keypad keys	enter the message
Note: Message length is limited. As you near the limit, a display counter shows how many characters are left.	
6 OK (⊙)	store the message
7 CHANGE (⊙)	select Priority
8 	scroll to the priority you want
9 SELECT (⊙)	set the priority
10 CHANGE (⊙)	select Call
11 keypad keys	enter a number for the recipient to call back



Press	To
12 OK (⊙)	store the number
13 CHANGE (⊙)	select Receipt
14 (⊙)	select whether you want the message status to be updated when the recipient opens the message
Note: Sent messages are stored in your outbox. See page 92.	
15 OK (⊙)	store your receipt preference
16 DONE (⊙)	finish the message
17 YES (⊙)	send the message
or	
NO (⊙)	cancel the message or save it in the drafts folder

Sending a Quick Note Text Message

Quick notes are pre-written messages that you can edit and send quickly (for example, **Meet me at ...**). You can also create and store new quick notes.

Find the Feature

(⊙) > **Messages**
> **Quick Notes**

Press	To
1 (⊙)	scroll to the quick note

**Press****2 READ** (⊙)**or****To**

read the quick note

open the **Quick Note Menu** to perform other procedures as described in the following list

The **Quick Note Menu** includes the following options:

Option	Description
New	Create a new quick note.
Edit	Edit the quick note.
Delete	Delete the quick note.
Send	Open a new message with the quick note in the Msg field.

Viewing the Status of Sent Text Messages

Messages that you send are stored in the outbox.

Find the Feature

⊙ > **Messages** > **Outbox**

Messages in the outbox are sorted from newest to oldest. The following indicators show message status:

» = sending in progress

✉ = delivered

✕ = sending failed

📖 = read by recipient

Ring Styles

Your phone rings or vibrates to notify you of an incoming call or other event. This ring or vibration is called an *alert*. You can select one of five different ring styles:

 = loud ring

 = soft ring

 = vibrate

 = ring and vibrate

 = silent

The ring style indicator in the display shows the current ring style (see page 22).

Each ring style contains settings for specific event alerts, ringer ID, and ringer and keypad volume.

Selecting a Ring Style

Find the Feature

 > Ring Styles > Style

Press	To
1 	scroll to the ring style
2 SELECT ()	select the ring style



Customizing a Ring Style

Change Style Settings

You can change the alerts that notify you of the following events: incoming calls, text messages, voicemail messages, data calls, fax calls, alarms, and reminders. Any changes you make are saved to the current ring style.

Find the Feature

 > Ring Styles
> Style Detail

Note: *Style* represents the current ring style.

Press	To
1 	scroll to the event
2 CHANGE ()	select the event
3 	scroll to the alert you want
4 SELECT ()	select the alert

Activate and Deactivate Ringer IDs

When ringer IDs are turned on, your phone uses distinctive ringer alerts to notify you of incoming calls or messages from specific entries stored in your phonebook. To assign a ringer ID to a phonebook entry, see page 64.

Find the Feature

 > Ring Styles
> Style Detail

Note: *Style* represents the current ring style.

Press	To
1 	scroll to Ringer IDs

Press	To
2 CHANGE (⊙)	change the ringer IDs setting
3 (⊙)	scroll to On or Off
4 SELECT (⊙)	select the option

Set Ringer or Keypad Volume

Find the Feature

(≡) > **Ring Styles**
> **Style Detail**

Note: *Style* represents the current ring style.

Press	To
1 (⊙)	scroll to Ring Volume or Key Volume
2 (* or #)	scroll to the desired volume
3 OK (⊙)	confirm the new volume

Creating Alert Tones

You can create and store up to 32 custom alert tones on your phone. The tones appear in the list of available alerts.

Create a Tone

Find the Feature

(≡) > **Ring Styles**
> **My Tones**

Press	To
1 (⊙)	scroll to [New Tone]
2 SELECT (⊙)	select [New Tone]
3 CHANGE (⊙)	select Notes





Press	To
4 keypad keys	enter notes (see page 96)
5 OK (⊙)	store the notes
6 CHANGE (⊙)	select Name
7 keypad keys	enter a name for the tone
8 OK (⊙)	store the name
9 DONE (⊙)	store the tone

Enter Notes

To create a new tone, use the keypad keys to enter notes. For each note, you must specify the octave (optional), pitch, length, and a length modifier (optional). Press a key multiple times to cycle through its available options and enter the necessary character as described in the following lists.

Octave

The default setting for a new tone is octave four.

Key	Display	Description
0 (○)	*	enter * followed by a number (0 to 8) to set the octave

Notes and Rests

Key	Display	Description
0 (○)	#	sharp
	&	flat

Key	Display	Description
2 ABC	a	note A
	b	note B
	c	note C
3 DEF	d	note D
	e	note E
	f	note F
4 GHI	g	note G
7 PQRS	r	rest

Lengths and Modifiers

Key	Display	Description
0 +	0	whole note
1 _@	1	half note
2 ABC	2	quarter note
3 DEF	3	eighth note
4 GHI	4	sixteenth note
5 @JLK	5	1/32 note
1 _@	.	dotted note
	:	double dotted note
	;	2/3 length note



Volume Control Characters

Key	Display	Description
	V, +, and -	Set volume level from V1 to V15. Enter V+ or V- to increase or decrease volume one level from current setting.

Repeat Characters

Key	Display	Description
	(,), and @	Use parentheses to enclose sequence of notes to be repeated. After the sequence, enter @ followed by digit(s) to set number of repetitions.

Note Entry Sequence

Do This	Action
1 Set the octave (optional)	Set the octave (*0 to *8) <i>before</i> selecting the note. The octave applies to the note and all following notes until you change it again.
2 Set the note to a sharp or flat, if necessary	Enter a sharp or flat (# or &) <i>before</i> selecting the note.



Do This	Action
3 Select the note (required)	Press a keypad key.
4 Set length (required)	Set the length (0 to 5) <i>after</i> selecting the note. If you do not specify a length, a 2 (quarter note) length is appended to the note.
5 Modify length (optional)	Enter a length modifier (. , : , or ;) <i>after</i> you set the length.



You can perform the following tasks when creating a tone:

Task	Action
Insert a rest	Enter one or more rests (r characters) as needed in the tone sequence. Set the length of the rest (0 to 5) <i>after</i> the rest, just as you would for a note.
Repeat a note sequence	Use (and) to group a sequence of notes. After the sequence, enter @ followed by a number to set the number of repetitions.
Adjust volume	Enter V+ or V- to increase or decrease volume one level at the current location in the note sequence.
Listen to a new tone as you compose it	Press  to enter the Compose Menu , and select Play All to play the notes you have entered.

Example

Press the following keys to create this sequence of notes and rests in octave three: **C** (quarter note), **E flat** (quarter note), **half rest**, and **G** (whole note):

Press	To	Display
1 	set octave three	*3
2	enter note C	c
3	set length to quarter note	2
4	enter flat symbol	&
5	enter note E flat	e
6	set length to quarter note	2
7	enter rest	r
8	set length to half rest	1
9	enter note G	g
10	set length to whole note	0

Play a Tone

Find the Feature

> Ring Styles
> My Tones

Press	To
1 	scroll to the tone
2 	open the My Tones Menu
3 	scroll to Play
4 SELECT ()	select Play
5 PLAY ()	play the tone again
or	
CANCEL ()	return to my tones list

Edit a Tone

You cannot edit the predefined alert tones included with your phone. To edit a custom alert tone:

Find the Feature  > **Ring Styles**
> **My Tones**

Press	To
1 	scroll to the tone
2 EDIT ()	open the tone details
3 	scroll to the item you want to edit (Name or Notes)
4 CHANGE ()	select the item
5 keypad keys	enter new text or notes
6 OK ()	store the tone



Delete a Tone

You cannot delete the predefined alert tones included with your phone. To delete a custom alert tone:

Find the Feature

☰ > Ring Styles
> My Tones

Press	To
1 	scroll to the tone
2 	open the My Tones Menu
3 	scroll to Delete
4 SELECT ()	select Delete
5 YES ()	confirm the deletion

Download a Tone

You can download custom alert tones from a text message. See page 89.

Setting Reminders

A reminder is an alert that rings or vibrates at regular intervals to notify you about a voicemail or text message that you have received.

Find the Feature

☰ > Ring Styles
> Style Detail
> Reminders

Note: *Style* represents the current ring style.

Press	To
1 	scroll to Beep or Vibrate to set the reminder alert type, or Off to turn off all reminders
2 SELECT ()	select the reminder alert



Ring Styles

Shortcuts

Your phone includes several standard shortcuts. You can create additional shortcuts to frequently used menu items.

Standard Shortcuts

The following shortcuts are pre-programmed in your phone. You cannot edit or delete these shortcuts.

Do This	To
Press  , then press and hold  (within two seconds)	zoom in/out on your phone display
Press  	lock/unlock your keypad
Press  	see your phone number
Press 	go to the dialed calls list
Press 	exit the menu system

Creating a Shortcut

You can create a keypad shortcut *plus* an optional voice shortcut to a menu item. A voice shortcut takes you directly to the menu item when you say the shortcut name.

Tip: Make your recording in a quiet location. Hold the phone about four inches (10 centimeters) from your mouth, and speak directly into the phone in a normal tone of voice.

Do This	To
1 Press 	enter the menu system

Do This	To
2 Press 	scroll to the menu item
3 Press and hold 	open the shortcut editor
4 Press YES ()	view shortcut options
5 Press CHANGE ()	change the keypad shortcut number
or	
Press DONE ()	select the default keypad shortcut number
or	
Press 	scroll to Voice to assign a voice shortcut
6 Press RECORD ()	begin recording The phone displays Press Voice Key then say voice shortcut.
7 Press and release RECORD () and say the shortcut's name (in two seconds)	record the shortcut name
8 Press and release RECORD () and repeat the name	confirm the shortcut name
9 Press DONE ()	store the shortcut name



Using Shortcuts

Use a Keypad Shortcut

Press	To
1 	open the menu
2 <i>the keypad shortcut number</i>	go to the menu item or perform the menu action

Select a Shortcut From the List

Find the Feature  > **Shortcuts**
> *the shortcut you want*

Use a Voice Shortcut

Do This	To
1 Press 	open the menu
2 Press and release the voice key and say the shortcut's name (in two seconds)	go to the menu item or perform the menu action



Micro-Browser



The micro-browser lets you access Web pages and Web-based applications on your phone. Contact your service provider to set up access, if necessary.



Starting a Micro-Browser Session

Find the Feature

☰ > Web Sessions

Press	To
1 	scroll to a bookmark, service, or application
2 SELECT (⊙)	select the item

If you are unable to establish a network connection with the micro-browser, contact your service provider.



Interacting With Web Pages

Press	To
	scroll through text, or highlight a selectable item
SELECT ()	select the highlighted item
	call the highlighted phone number from the micro-browser
keypad keys, followed by OK ()	enter information Press  to delete one letter at a time if you make a mistake.
	go back to the previous page
	open the Browser Menu



Calculator

You can use your phone as a calculator and currency converter.


Calculating Numbers

Press	To
1 number keys	enter a number
2 	highlight a calculator function
3 SELECT ()	perform the function

Selected function appears here

Press  to highlight a function

Exit the calculator



Press  to open the Calculator Menu

Entered number

Press  to select other functions

Perform the highlighted function



The calculator can perform the following functions:



Function	Description
.	Insert a decimal point
C	Clear the calculation
CE	Clear entry (replaces C when you enter subsequent values in a calculation)
=	Calculate the result
+	Add
-	Subtract
x	Multiply
÷	Divide
%	Divide the displayed value by 100
±	Change the entry's sign (positive/negative)
\$	Calculate the exchange rate
MS	Store the value in memory (overwrites current stored value)
MC	Clear the value stored in memory
MR	Replace the displayed value with the value stored in memory

Converting Currency

The currency converter works just like the calculator, but uses the \$ (currency) function:

Find the Feature

 > **Calculator**

 > **Exchange Rate**

Press	To
1 number keys	enter the exchange rate
2 OK ()	store the exchange rate
3 number keys	enter the amount to convert (amount to multiply by the exchange rate)
4 	highlight the \$ function
5 SELECT ()	perform the conversion



Games

You can play games on your phone between phone calls. An incoming call, message, alarm, or alert automatically ends the game.

Playing a Game

Find the Feature

 > Games

Press	To
1 	scroll to a game
2 SELECT ()	start the game

When the game is over:

Press	To
NEW () or YES ()	start another session of the same game
BACK () or NO ()	end the game session

Game Options

Press  to select the following options during a game:

Option	Description
Game Sounds	Switch game sounds on/off.
New Game	Start a new game session.



Option	Description
Key Configuration	Assign game functions to different keypad keys.
Help	Review the goal of the game. Note: This option is not available for Blackjack.

Blackjack

In this classic card game, you play against the dealer to see who can get closer to 21 points without going over.

Rules of the Game

- The first card is dealt to the dealer. The dealer's cards are shown at the top of the display, and your cards are shown at the bottom.
- Face cards count as 10 points. Number cards count as the points shown on their face.
- An ace counts as 11 points, unless that would put you over 21 points. Otherwise, an ace is counted as 1 point. An ace that is originally counted as 11 may later be counted as 1 if it will bring your total under or equal to 21 points.
- An initial deal of an ace and a card with a face value of 10 points counts as exactly 21 points or Blackjack.
- Blackjack automatically wins against any other hand that totals 21 points.
- If you score more than 21 points, you go "bust" or lose.





- If you get five cards without going bust, you win.
- If you and the dealer have the same score, the dealer wins.
- You can ask for a “hit” or another card as long as you do not go bust.
- As long as the dealer’s total is less than 17 points, the dealer must continue to take a hit.

How to Play

When the game begins, you are dealt two cards.

Press	To
STAY (⊙)	see the results of the hand
HIT ME (⊙)	request another card

Falling Numbers

Score points by pressing the corresponding number key for numbers as they “fall” down the display.

Rules of the Game

- If a number reaches the bottom of the display or if you press an incorrect number key, you score one miss.
- The game is over when you score three misses.
- The game has five levels. When you complete a level, play continues automatically at the next level.
- You earn a bonus if you finish a level without a miss.

How to Play

When the game begins, numbers start falling from the upper portion of the display. Press the corresponding number key to eliminate a falling number before it reaches the bottom of the display.

Press  to select the following options:

Option	Description
Level	Choose the starting level of play.
Top Scores	View the top five scores.



Video Poker

Turn 100 credits into 9,999-plus credits by making the best possible poker hands.

Rules of the Game

- You start a new game with 100 credits. You must bet from 1-10 credits for each hand you play.
- You are dealt five cards face up, and have one opportunity to trade in cards (zero to five) for new ones.
- A winning hand earns credits as listed in the **Awards Table**.
- Your credit total is saved when you exit the game. The next time you play, you start with the number of credits that remain from the previous session.
- The game is over when you lose all of your credits.

How to Play

Place your initial bet or change your bet (from 1-10 credits) and then:

Press	To
DEAL (●)	start a new hand
4 CH	select the card to the left
6 MR	select the card to the right
5 DRL or DISCARD (●)	discard selected card
5 DRL or UNDO (●)	undo discard (replaces previous option after discard)
DONE (●)	remove discarded cards and deal replacements

Press (≡) to select the following options:

Option	Description
Change Bet	Change bet amount (not available while hand is in play).
Choose Deck	Choose the deck image.
Awards Table	View the list of odds/payouts for each winning hand.

Adjusting Your Settings

Reordering Menu Items

You can reorder the items in your phone's main menu.

Find the Feature

- ☰ > Settings
- > Other Settings
- > Personalize
- > Main Menu

Press	To
1 	scroll to a menu item
2 GRAB ()	grab the menu item
3 	move the item to a new location in the menu
4 INSERT ()	insert the menu item

Customizing a Soft Key Function

You can relabel the soft keys ( and ) to access different menu items from the idle display.

Find the Feature

- ☰ > Settings
- > Other Settings
- > Personalize > Keys



Press	To
1 	scroll to Left or Right
2 CHANGE ()	select the key
3 	scroll to the new key function
4 CHANGE ()	confirm the new function

TTY Operation



You can use an optional TTY device with your phone to send and receive calls. You must plug the TTY device into the phone's headset jack and set the phone to operate in one of three TTY modes.

Notes:

- Use a TSB-121 compliant cable (provided by the TTY manufacturer) to connect the TTY device to your phone.
- For optimal performance, your phone should be at least 12 inches (30 centimeters) away from the TTY device. Placing the phone too close to the TTY device may cause high error rates.

Set TTY Mode

When you set your phone to a TTY mode, it operates in that mode whenever the TTY device is connected.

Find the Feature

-  > **Settings**
- > **Other Settings**
- > **Initial Setup**
- > **TTY Setup**

Press	To
1 	scroll to TTY Setup
2 CHANGE ()	change the TTY mode
3 	scroll to the TTY mode
4 SELECT ()	select the TTY mode

The **TTY Setup** menu includes the following options:

Option	Description
TTY	Transmit and receive TTY characters
VCO	Receive TTY characters but transmit by speaking into the microphone
HCO	Transmit TTY characters but receive by listening to the earpiece
Voice	Return to normal voice mode



When your phone is in a TTY mode, the international TTY symbol and the mode setting are shown in the display. You can press **TTYMODE** () to change the mode setting.

Switch to TTY Mode During a Voice Call

Press	To
1 	open the Call menu
2 	scroll to TTY Setup
3 SELECT ()	display the TTY Setup menu
4 	scroll to the TTY mode
5 SELECT ()	select the TTY mode



Press	To
1 	open the Call menu
2 	scroll to TTY Setup
3 SELECT 	display the TTY Setup menu
4 	scroll to the TTY mode
5 SELECT 	select the TTY mode

Return to Voice Mode

To return to normal voice mode, select **Voice** from the **TTY Setup** menu as described on page 118.

Hands-Free Use



You can purchase an optional Motorola Original™ hands-free car kit or headset for your phone. These accessories provide alternative ways for you to use your phone

without using your hands.

Note: The use of wireless devices and their accessories may be prohibited or restricted in certain areas. Always obey the laws and regulations on the use of these products.

Automatic Answer

You can set your phone to automatically answer calls after two rings (four seconds) when connected to a car kit or headset.

Find the Feature

 > **Settings**
> **Other Settings**

Press	To
1 	scroll to Car Settings or Headset
2 SELECT ()	select the feature
3 	scroll to Auto Answer
4 CHANGE ()	select Auto Answer
5 	scroll to On or Off
6 SELECT ()	confirm the setting

Automatic Hands-Free

You can set your phone to automatically route calls to a car kit when it detects a connection.

Find the Feature

-  > **Settings**
- > **Other Settings**
- > **Car Settings**
- > **Auto Handsfree**

Press	To
1 	scroll to On or Off
2 SELECT ()	confirm the setting

Power-Off Delay

When your phone is connected to a car kit, you can set it to stay on for a period of time after you switch off the ignition. This prevents the phone from draining your vehicle battery, but leaves the phone on long enough that you do not have to re-enter your unlock code when making short stops.



Note: This feature may not work with all car ignition switches.

Caution: If you select **Continuous**, the phone does not power off when you turn off the ignition. Be careful not to drain your vehicle battery if you select this option.

Find the Feature

- ☰ > Settings
- > Other Settings
- > Car Settings
- > Power-Off Delay

Press	To
1 	scroll to the time delay
2 SELECT ()	confirm your selection

Charger Time

When your phone is connected to a car kit, you can set it to charge itself for a specified time period after you switch off the ignition. This helps ensure that the phone battery gets fully charged while the vehicle is parked.

Note: This feature may not work with all car ignition switches.

Find the Feature

- ☰ > Settings
- > Other Settings
- > Car Settings
- > Charger Time

Press	To
1 	scroll to the charge time
2 SELECT ()	confirm your selection

Data Calls



A Motorola Original™ data kit lets you transfer data between your phone and a computer or other external device. You can:

- use your phone as a modem to connect to the Internet.
- use your phone to send and receive data calls on your computer or hand-held device.

Connecting Your Phone to an External Device

Connect your phone to a computer or hand-held device using a serial cable or a USB cable.

Note: Not all devices are compatible with serial cable or USB cable connections. Check your external device for specifications.

Set Up a Cable Connection

Attach a serial cable or Motorola Original USB cable to the phone and external device as follows.

Note: Check your computer or hand-held device to determine the type of cable you need.





Attaching a Serial Cable

Use the interchangeable head on the Motorola Multi-Connect Serial Cable to connect a computer, Palm III device, or Palm V device to your phone.

Do This

- 1 Plug the serial cable into the detachable head. Make sure that the Motorola logo on the detachable head and the metal shielding on the serial cable plug are both facing you.
- 2 With the Motorola logo and the phone both facing you, plug the detachable head into the phone's accessory connector port.
- 3 Plug the other end of the cable into the serial interface connection on the external device and tighten the screws.

Attaching a USB Cable

Do This

- 4 Plug the end of the cable with the Motorola logo into the phone's accessory connector port. Make sure that the logo and the phone are both facing you.
- 5 Plug the other end—the USB connection—into the USB port on the external device.

Install the Software

Install the software from the CD-ROM that comes with your Motorola Original data kit. See the data kit's user guide for more information.

Sending a Data Call

Use this procedure to send data from a connected device, and to synchronize phonebook and datebook information between your phone, computer, and/or hand-held device.

Connect your phone to the device as described on page 123 and do the following:

Do This

To

- 1 Check the phone make sure that the phone is connected and powered on





Do This	To
2 Open the application on your computer	place the call through the application (such as dial-up-networking) Note: You cannot dial data numbers through your phone's keypad. You must dial them through your computer.
3 End the call from the connected device	close the call and connection when the transfer is complete

Receiving a Data Call

Use this procedure to transfer data to your computer or hand-held device.

Set Up Your Phone

Find the Feature

☰ > **Settings**
> **Connection**
> **Incoming Call**

Do This	To
1 Press CHANGE (⊙)	select Next Call
2 Press ⊕	scroll to Data In Only
3 Press SELECT (⊙)	set the call format
4 Connect your phone to the device	enable the data transfer

Note: You cannot answer incoming voice calls when your phone is in data mode. Any voice calls you receive are treated as unanswered calls. To return a voice call, reset your phone to voice mode as described on page 127.

Transfer the Data

Your phone notifies you when the data call arrives, and transfers the call to the connected device. Use the application running on the device to answer the call.

End the Data Connection

When the data transfer is complete:

Do This	To
End the call from the connected device	close the connection

Reset Normal Voice Operation

After making a data call, you must reset your phone to resume normal voice operations. You cannot receive voice calls when your phone is in data mode.

Find the Feature

☰ > **Settings**
> **Connection**
> **Incoming Call**

Do This	To
1 Press CHANGE (⊙)	select Next Call
2 Press ⊕	scroll to Normal
3 Press SELECT (⊙)	reset your phone



Your phone also reverts to normal voice operations when you turn it off and then turn it back on.



PRELIMINARY

Security

Assigning a New Code or Password

Your phone's unlock code is originally set to 1234, and the security code is originally set to 000000. Your service provider may reset these numbers before you receive your phone.

If your service provider has *not* reset these numbers, we recommend that you change them to prevent other users from accessing your personal information. The unlock code must contain four digits, and the security code must contain six digits.

Notes:

- Your service provider may retain your phone's security code for customer service purposes. In this case, you will not be able to use phone features that require you to enter the security code.
- If the unlock code is the only code you can change, the **New Passwords** menu is not available. In this case, change the unlock code by selecting:  > **Settings** > **Security** > **Phone Lock** > **Unlock Code**.

To change a code or password:

Find the Feature

 > **Settings** > **Security**
> **New Passwords**



Press	To
1 	scroll to the code or password
2 CHANGE ()	select the code or password
3 keypad keys	enter your old code
4 OK ()	submit your old code
5 keypad keys	enter the new code
6 OK ()	assign the new code
7 keypad keys	re-enter the new code
8 OK ()	confirm the new code

If You Forget a Code or Password

If you forget your security code, contact your service provider.

If you forget your unlock code, try entering 1234 or the last four digits of your phone number. If that does not work, do the following at the **Enter Unlock Code** prompt:

Press	To
1 	go to the unlock code bypass screen
2 keypad keys	enter your security code
3 OK ()	submit your security code



Locking and Unlocking Your Phone

You can lock your phone manually or set the phone to lock automatically whenever you turn it off.

To use a locked phone, you must enter the unlock code. A locked phone still rings or vibrates for incoming calls or messages, *but you must unlock it to answer.*

You can make emergency calls on your phone even when it is locked. For more information, see page 28.

Lock Your Phone Manually

Find the Feature

☰ > Settings > Security
> Phone Lock
> Lock Now

Press	To
1 keypad keys	enter your unlock code
2 OK (⊙)	lock the phone

Set Your Phone to Lock Automatically

You can set your phone to lock every time you turn it off.

Find the Feature

☰ > Settings > Security
> Phone Lock
> Automatic Lock > On

Press	To
1 keypad keys	enter your unlock code
2 OK (⊙)	activate automatic lock



Unlock Your Phone

At the **Enter Unlock Code** prompt:

Press	To
1 keypad keys	enter your unlock code
2 OK (⊙)	unlock your phone

Locking and Unlocking Your Keypad

You can lock your phone keypad to prevent accidental keypresses (for example, when carrying your phone in a purse or pocket).

Press	To
 	lock or unlock your keypad

Note: Incoming calls and messages unlock the keypad.

Restricting Calls

You can stop all incoming and/or outgoing calls, or you can restrict them to the numbers stored in your phonebook.

Notes:

- You can make emergency calls when outgoing calls are restricted.
- Your phone still receives incoming text messages when incoming calls are restricted.



When you restrict incoming calls to numbers stored in the phonebook, a valid incoming call may be restricted if caller ID information for the call is not available from the network.

Find the Feature

 > **Settings** > **Security**
> **Restrict Calls**

Press	To
1 keypad keys	enter your unlock code
2 OK (⊙)	open the restrict calls menu
3 	scroll to Outgoing Calls or Incoming Calls
4 CHANGE (⊙)	select the option
5 CHANGE (⊙)	change the Allow setting
6 	scroll to All , None , or Phonebook
7 SELECT (⊙)	select the allowed calls

Activating Talk Secure

Find the Feature

 > **Settings** > **Security**
> **Talk Secure**

Press	To
1 	scroll to Preferred or Off
2 SELECT (⊙)	switch talk secure on or off

Your phone can attempt to send your calls using a high-security connection, to prevent others from intercepting them. For more information, see page 27



Troubleshooting



Check these questions first if you have problems with your phone. If you need additional help, contact the Motorola Customer Call Center at 1-800-331-6456 (United States) or 1-800-461-4575 (Canada).

Question	Answer
Is your phone set up correctly?	Press . If you do not see your phone number, contact your service provider.
Is your battery charged? Do you see in the display?	The battery level indicator should have at least one segment showing (). If it does not, recharge your battery. See page 19.
Does the handset have a signal? Do you see in the display?	The signal strength indicator should have at least one segment showing (). If it does not, move to an area with a stronger signal to use your phone.
Is the earpiece volume too low?	While on a call, press the upper volume key on the side of your phone.



Question	Answer
Is the other party unable to hear you?	Your phone may be muted. Press UNMUTE (⊙) if necessary to unmute the phone. Also, make sure that your phone's microphone is not blocked by its carrying case or a sticker.
Has the phone been damaged, dropped, or gotten wet?	Dropping your phone, getting it wet, or using a non-Motorola battery or battery charger can damage the phone. The phone's limited warranty does not cover liquid damage or damage caused from using non-Motorola accessories.
Was a non-Motorola battery or battery charger used?	

The following refer to specific problems:

Problem	Solution
My phone was stolen. To whom should I report this?	Report a stolen phone to the police and to your service provider (the company that sends you your monthly wireless service bill).
I forgot my password.	See page 130.



Problem	Solution
I pressed the power key, but nothing happened.	Be sure to press and hold  (the power key) until the display appears and you hear an alert. This could take several seconds. If nothing happens, check that a charged battery is installed. See page 18.
The display says: Enter Unlock Code. How do I unlock my phone?	Enter the factory-preset unlock code (1234), or the last four digits of your phone number. If this fails, call your service provider (the company that sends you your monthly wireless service bill).
My phone asks for an unlock code when I try to open a feature.	The application you want is locked. If you do not know the unlock code, see page 130.
My phone does not ring.	If you see  or  in the display, then the ringer is turned off. See page 93. Also, the ringer may be set to Silent even though your phone is set to an audible ring style. See page 94.



Problem	Solution
My phone rings even though I selected the Silent (or Vibrate) ring style.	The ringer may be set to play a tone even though your phone is set to a silent ring style. See page 94.
I tried to place a call and heard an alternating high/low tone.	Your call did not reach the wireless system. You may have dialed the number too soon after turning the phone on. Wait until you see the idle display before making a call.
I cannot send/receive calls.	Make sure that you have a phone signal (see the “Signal Strength Indicator” item on page 23). Avoid electrical or radio interference, and obstructions such as bridges, parking garages, or tall buildings. Your phone also may have the Restrict Calls feature turned on. If you know the unlock code, you can change this setting in the security menu (☰ > Settings > Security).



Problem	Solution
My phone has poor reception and drops calls.	Make sure that your antenna is not bent or damaged. Also, make sure you have a phone signal (see the “Signal Strength Indicator” item on page 23). Stay clear of any obstructions such as bridges, parking garages, or tall buildings.
I cannot hear others on my phone.	While on a call, press the upper volume key. The display should show the volume increasing. Also, make sure that your phone’s earpiece is not blocked by its carrying case.
I cannot open my message inbox.	Before you can use text messages, you must set up the message inbox. See page 84.
How do I see the calls I sent or received?	To see the most recent calls you dialed or received: ⊞ > Recent Calls > Received Calls - or - Dialed Calls



Problem	Solution
My phone will not send voicemail commands, passwords, or other codes.	Your phone sends commands and passwords as DTMF tones. You can set your phone's DTMF tones to be On or Off. If you have trouble sending numbers, check your DTMF setting. - From the idle display, press: ⓘ > Settings > Other Settings > Initial Setup > DTMF - Press ⬅ to scroll to On. - Press SELECT (⊙) to select it.
My phone's display is too dark.	Use the Contrast feature to change the level of contrast in your display. See page 55. You can also use the Backlight feature to change the length of time that the display backlight stays on. See page 54.
My battery didn't last as long as I expected. What can I do to extend battery life	Your battery's performance is affected by charge time, feature use, temperature changes, backlight use, and other factors. For tips on extending your battery life, see page 25.



Problem	Solution
I am unable to record a voice note, voice name, or voice shortcut.	Try moving to a quieter location to make your voice recording. Hold the phone about four inches (10 centimeters) from your mouth, and speak directly into the phone in a normal tone of voice.
My TTY device doesn't work with my phone.	Your phone must be set to a TTY mode for the phone to detect your TTY device. See page 118.
I plugged the data cable into my phone but my phone did not beep. How do I know if the data cable is ready to go?	The beep indicates that you are set up correctly. If you did not hear a beep, make sure that both ends of the data cable are connected—the smaller end to your phone and the larger end to your computer. Also, your computer may have deactivated the port to save power. Try opening an application that uses the port, like a fax or dial-up application, to automatically activate the port.



Problem	Solution
My phone beeped when I attached the data cable, but my data applications don't work.	You must be in an area with digital coverage. Check your phone's display for the digital signal indicator (D). Some wireless networks may not support data transmission. If you see the digital indicator, but you are roaming on an unfamiliar network, this may be the case. Also, remember that data transmission usually requires a subscription. Call your service provider for more information.
When sending data with the data cable, why does the computer show a connection rate of 19200 Kbps?	19200 Kbps is the data transfer rate of the connection between your computer and the phone. The rate of the connection between your phone and the network is displayed on your phone, and will be either 14400 or 9600 Kbps.
I can't end my data call by closing the application on my computer. What can I do?	Try pressing Ⓢ on your phone. Or try disconnecting the cable or turning off the phone. If possible, always close the connection through your computer, as these alternative methods may disrupt the application on your computer.



Problem	Solution
I launched the micro-browser but the display says: Service Not Available.	You may be in an area without service. If you have wireless service, look in the display for the digital signal indicator (D). If you do not see the indicator, you may be in an area that has only analog service or no service at all. If you see the digital signal indicator, you may be connected to a digital network that does not support Internet access.
I launched the micro-browser but the display says: Data Server Unavailable.	Try again in a few minutes. The servers may be temporarily busy.

Programming Instructions

Follow this procedure if you need to program your phone's phone number(s).

Note: Programming is normally done by a trained technician at the site of purchase. Users should not make changes other than ones in the following procedure.

Before programming, ask your service provider for your:

- Carrier System ID (a one- to five-digit number)
- 10-digit MIN (Mobile Identification Number)

Press	To
1 # , the Carrier System ID number, # , x , 0	enter programming mode
2 0+ , 0+ , 0+ , 0+ , 0+ , 0+	enter the security code
(This is the security code that is in the phone when it is shipped from the factory.)	
3 OK (0)	submit the security code
4 left arrow	scroll to MIN
5 CHANGE (0)	open the MIN display
6 keypad keys for the 10-digit MIN	enter the new MIN

Press	To
7 OK (⊙)	store the new MIN
8 DONE (⊙)	exit programming mode

PRELIMINARY

Specific Absorption Rate Data

This model phone meets the government's requirements for exposure to radio waves.

Your wireless phone is a radio transmitter and receiver. It is designed and manufactured not to exceed limits for exposure to radio frequency (RF) energy set by the U.S. Federal Communications Commission for the United States and by Health Canada for Canada. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons, regardless of age or health.

The exposure standard for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC and by Health Canada is 1.6 W/kg.¹ Tests for SAR are conducted using standard operating positions accepted by the FCC and by Industry Canada with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are

to a wireless base station antenna, the lower the power output.

Before a phone model is available for sale to the public in the U.S. and Canada, it must be tested and certified to the FCC and Industry Canada that it does not exceed the limit established by each government for safe exposure. The tests are performed in positions and locations (e.g., at the ear and worn on the body) reported to the FCC and available for review by Industry Canada. The highest SAR value for this model phone when tested for use at the ear is 1.51 W/kg^2 , and when worn on the body, as described in this user guide, is 0.69 W/kg^2 (Body-worn measurements differ among phone models, depending upon available accessories and regulatory requirements). While there may be differences between the SAR levels of various phones and at various positions, they all meet the governmental requirements for safe exposure.

The FCC and Industry Canada have granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as being in compliance with the FCC and Health Canada RF exposure guidelines. SAR information on this model phone is on file with the FCC and can be found under the Display Grant section of:

<http://www.fcc.gov/oet/fccid>

after searching on FCC ID: IHDT56CF1. You may also refer to Motorola's Web site:

<http://www.motorola.com/rfhealth>

Additional information on Specific Absorption Rates (SAR) can be found on the Cellular Telecommunications & Internet Association (CTIA) Web site:

<http://phonefacts.net>

or the Canadian Wireless Telecommunications Association (CWTA) Web site:

<http://www.cwta.ca>

1. In the United States and Canada, the SAR limit for mobile phones used by the public is 1.6 watts/kg (W/kg) averaged over one gram of tissue. The standard incorporates a substantial margin of safety to give additional protection for the public and to account for any variations in measurements.
2. Additional related information includes the Motorola testing protocol, assessment procedure, and measurement uncertainty range for this product.

ITC01-064

***The U.S. Food and Drug
Administration's Center for
Devices and Radiological Health
Consumer Update on Mobile Phones***



FDA has been receiving inquiries about the safety of mobile phones, including cellular phones and PCS phones. The following summarizes what is known—and what remains unknown—about whether these products can pose a hazard to health, and what can be done to minimize any potential risk. This information may be used to respond to questions.

Why the concern?

Mobile phones emit low levels of radio frequency energy (i.e., radio frequency radiation) in the microwave range while being used. They also emit very low levels of radio frequency energy (RF), considered non-significant, when in the stand-by mode. It is well known that high levels of RF can produce biological damage through heating effects (this is how your microwave oven is able to cook food). However, it is not known whether, to what extent, or through what mechanism, lower levels of RF might cause adverse health effects as well. Although some research has been done to address these questions, no clear picture of the biological effects of this type of radiation has emerged to date. Thus, the available science does not allow us to conclude that mobile phones are absolutely safe, or that they are unsafe. However, the available scientific evidence does not demonstrate any adverse health effects associated with the use of mobile phones.

What kinds of phones are in question?

Questions have been raised about hand-held mobile phones, the kind that have a built-in antenna that is positioned close to the user's head during normal telephone conversation. These types of mobile phones are of concern because of the short distance between the phone's antenna—the primary source of the RF—and the person's head. The exposure to RF from mobile phones in which the antenna is located at greater distances from the user (on the outside of a car, for example) is drastically lower than that from hand-held phones, because a person's RF exposure decreases rapidly with distance from the source. The safety of so-called “cordless phones,” which have a base unit connected to the telephone wiring in a house and which operate at far lower power levels and frequencies, has not been questioned.

How much evidence is there that hand-held mobile phones might be harmful?

Briefly, there is not enough evidence to know for sure, either way; however, research efforts are on-going. The existing scientific evidence is conflicting and many of the studies that have been done to date have suffered from flaws in their research methods. Animal experiments investigating the effects of RF exposures characteristic of mobile phones have yielded conflicting results. A few animal studies, however, have suggested that low levels of RF could accelerate the development of cancer in laboratory animals. In one study, mice genetically altered to be predisposed to developing one type of cancer developed more than twice as many such cancers when they were exposed to RF energy compared to controls. There is much uncertainty among scientists about whether results obtained from animal studies apply to the use

of mobile phones. First, it is uncertain how to apply the results obtained in rats and mice to humans. Second, many of the studies that showed increased tumor development used animals that had already been treated with cancer-causing chemicals, and other studies exposed the animals to the RF virtually continuously—up to 22 hours per day.

For the past five years in the United States, the mobile phone industry has supported research into the safety of mobile phones. This research has resulted in two findings in particular that merit additional study:

- 1 In a hospital-based, case-control study, researchers looked for an association between mobile phone use and either glioma (a type of brain cancer) or acoustic neuroma (a benign tumor of the nerve sheath). No statistically significant association was found between mobile phone use and acoustic neuroma. There was also no association between mobile phone use and gliomas when all types of types of gliomas were considered together. It should be noted that the average length of mobile phone exposure in this study was less than three years.

When 20 types of glioma were considered separately, however, an association was found between mobile phone use and one rare type of glioma, neuroepitheliomatous tumors. It is possible with multiple comparisons of the same sample that this association occurred by chance. Moreover, the risk did not increase with how often the mobile phone was used, or the length of the calls. In fact, the risk actually decreased with cumulative hours of mobile phone use. Most cancer causing agents increase risk with increased exposure. An ongoing study of brain

cancers by the National Cancer Institute is expected to bear on the accuracy and repeatability of these results.¹

- 2 Researchers conducted a large battery of laboratory tests to assess the effects of exposure to mobile phone RF on genetic material. These included tests for several kinds of abnormalities, including mutations, chromosomal aberrations, DNA strand breaks, and structural changes in the genetic material of blood cells called lymphocytes. None of the tests showed any effect of the RF except for the micronucleus assay, which detects structural effects on the genetic material. The cells in this assay showed changes after exposure to simulated cell phone radiation, but only after 24 hours of exposure. It is possible that exposing the test cells to radiation for this long resulted in heating. Since this assay is known to be sensitive to heating, heat alone could have caused the abnormalities to occur. The data already in the literature on the response of the micronucleus assay to RF are conflicting. Thus, follow-up research is necessary.²

FDA is currently working with government, industry, and academic groups to ensure the proper follow-up to these industry-funded research findings. Collaboration with the Cellular Telecommunications Industry Association (CTIA) in particular is expected to lead to FDA providing research recommendations and scientific oversight of new CTIA-funded research based on such recommendations.

Two other studies of interest have been reported recently in the literature:

- 1 Two groups of 18 people were exposed to simulated mobile phone signals under laboratory conditions while

they performed cognitive function tests. There were no changes in the subjects' ability to recall words, numbers, or pictures, or in their spatial memory, but they were able to make choices more quickly in one visual test when they were exposed to simulated mobile phone signals. This was the only change noted among more than 20 variables compared.³

- 2 In a study of 209 brain tumor cases and 425 matched controls, there was no increased risk of brain tumors associated with mobile phone use. When tumors did exist in certain locations, however, they were more likely to be on the side of the head where the mobile phone was used.

Because this occurred in only a small number of cases, the increased likelihood was too small to be statistically significant.⁴

In summary, we do not have enough information at this point to assure the public that there are, or are not, any low incident health problems associated with use of mobile phones. FDA continues to work with all parties, including other federal agencies and industry, to assure that research is undertaken to provide the necessary answers to the outstanding questions about the safety of mobile phones.

What is known about cases of human cancer that have been reported in users of hand-held mobile phones?

Some people who have used mobile phones have been diagnosed with brain cancer. But it is important to understand that this type of cancer also occurs among people who have not used mobile phones. In fact, brain cancer occurs in the

U.S. population at a rate of about 6 new cases per 100,000 people each year. At that rate, assuming 80 million users of mobile phones (a number increasing at a rate of about 1 million per month), about 4800 cases of brain cancer would be expected each year among those 80 million people, whether or not they used their phones. Thus it is not possible to tell whether any individual's cancer arose because of the phone, or whether it would have happened anyway. A key question is whether the risk of getting a particular form of cancer is greater among people who use mobile phones than among the rest of the population. One way to answer that question is to compare the usage of mobile phones among people with brain cancer with the use of mobile phones among appropriately matched people without brain cancer. This is called a case-control study. The current case-control study of brain cancers by the National Cancer Institute, as well as the follow-up research to be sponsored by industry, will begin to generate this type of information.

What is FDA's role concerning the safety of mobile phones?

Under the law, FDA does not review the safety of radiation-emitting consumer products such as mobile phones before marketing, as it does with new drugs or medical devices. However, the agency has authority to take action if mobile phones are shown to emit radiation at a level that is hazardous to the user. In such a case, FDA could require the manufacturers of mobile phones to notify users of the health hazard and to repair, replace or recall the phones so that the hazard no longer exists.

Although the existing scientific data do not justify FDA regulatory actions at this time, FDA has urged the mobile

phone industry to take a number of steps to assure public safety. The agency has recommended that the industry:

- support needed research into possible biological effects of RF of the type emitted by mobile phones
- design mobile phones in a way that minimizes any RF exposure to the user that is not necessary for device function
- cooperate in providing mobile phone users with the best possible information on what is known about possible effects of mobile phone use on human health

At the same time, FDA belongs to an interagency working group of the federal agencies that have responsibility for different aspects of mobile phone safety to ensure a coordinated effort at the federal level. These agencies are:

- National Institute for Occupational Safety and Health
- Environmental Protection Agency
- Federal Communications Commission
- Occupational Health and Safety Administration
- National Telecommunications and Information Administration

The National Institutes of Health also participates in this group.

In the absence of conclusive information about any possible risk, what can concerned individuals do?

If there is a risk from these products—and at this point we do not know that there is—it is probably very small. But if people

are concerned about avoiding even potential risks, there are simple steps they can take to do so. For example, time is a key factor in how much exposure a person receives. Those persons who spend long periods of time on their hand-held mobile phones could consider holding lengthy conversations on conventional phones and reserving the hand-held models for shorter conversations or for situations when other types of phones are not available.

People who must conduct extended conversations in their cars every day could switch to a type of mobile phone that places more distance between their bodies and the source of the RF, since the exposure level drops off dramatically with distance. For example, they could switch to:

- a mobile phone in which the antenna is located outside the vehicle
- a hand-held phone with a built-in antenna connected to a different antenna mounted on the outside of the car or built into a separate package
- a headset with a remote antenna to a mobile phone carried at the waist

Again, the scientific data do not demonstrate that mobile phones are harmful. But if people are concerned about the radio frequency energy from these products, taking the simple precautions outlined above can reduce any possible risk.

Where can I find additional information?

For additional information, see the following Web sites:

Federal Communications Commission (FCC) RF Safety Program (select "Information on Human Exposure to RF

Fields from Cellular and PCS Radio Transmitters”):

<http://www.fcc.gov/oet/rfsafety>

World Health Organization (WHO) International Commission on Non-Ionizing Radiation Protection (select Qs & As): <http://www.who.int/emf>

United Kingdom, National Radiological Protection Board: <http://www.nrpb.org.uk>

Cellular Telecommunications Industry Association (CTIA): <http://www.wow-com.com>

U.S. Food and Drug Administration (FDA) Center for Devices and Radiological Health: <http://www.fda.gov/cdrh/consumer/>

1. Muscat et al. Epidemiological Study of Cellular Telephone Use and Malignant Brain Tumors. In: State of the Science Symposium; 1999 June 20; Long Beach, California.
2. Tice et al. Tests of mobile phone signals for activity in genotoxicity and other laboratory assays. In: Annual Meeting of the Environmental Mutagen Society; March 29, 1999, Washington, D.C.; and personal communication, unpublished results.
3. Preece, AW, Iwi, G, Davies-Smith, A, Wesnes, K, Butler, S, Lim, E, and Varey, A. Effect of a 915-MHz simulated mobile phone signal on cognitive function in man. *Int. J. Radiat. Biol.*, April 8, 1999.
4. Hardell, L, Nasman, A, Pahlson, A, Hallquist, A and Mild, KH. Use of cellular telephones and the risk for brain tumors: a case-control study. *Int. J. Oncol.*, 15: 113-116, 1999.

ITC00-010

Warranty

Limited Warranty for Motorola Personal Communications Products and Accessories Purchased in the United States and Canada

I. What This Warranty Covers

Defects in materials and workmanship in the following new **“Products”** manufactured, sold or certified by Motorola, with which this limited warranty is included in/on the package:

(a) wireless cellular telephones, pagers and two-way radios that operate via “Personal Radio Service” (such as Family Radio Service and General Mobile Radio Service), together with software imbedded in any of these products, and
(b) subject to the following exceptions, accessories or software sold for use with these products.

- Battery Exception. This limited warranty extends only to batteries in which the fully-charged capacity falls below 80% of rated capacity and batteries that leak;
- Software Exceptions. This limited warranty extends only to physical defects in the media (such as CD-ROM) that tangibly embodies each copy of any software sold and/or certified by Motorola for use with Products. Software that is not tangibly embodied in media and that is purchased separately from Products (such as software that is downloaded from the internet) comes **“as is” and without warranty**.

II. What the Period of Coverage Is

Subject to the following exceptions, one year from the date the Products are purchased by the first end-user:

- 90-Day Warranty Exception. The warranty is for 90 days for: (a) any software tangibly embodied in media or (b) any accessories for two-way radios that are covered by this warranty, as described in Section I, above.
- Limited Lifetime Warranty Exception. The warranty is a limited lifetime warranty for the lifetime of ownership by the first end-user of the following products, **only**: (a) decorative covers, including bezel, PhoneWrap™ or case (any model); and (b) ear buds and boom headsets that transmit mono sound through a wire connection (this does **not** include ear buds or boom headsets that either transmit stereo sound or that are wireless, or both).
- Repair/Replacement Exception. The warranty is for the balance of the original warranty or for 90 days from the date returned and delivered to the first end-user, whichever is longer.

III. Who is Covered

This warranty extends to you only if you are the first end-user purchaser.

IV. What We Will Do to Correct Warranty Problems

At no charge to you, we have the option to repair or replace the Products that do not conform to the warranty, or to refund the Products' purchase price. We may use functionally equivalent reconditioned/refurbished/pre-owned or new Products or parts. No software updates are provided.

V. How to Get Warranty Service

PLEASE CALL US — DO NOT SHIP:

USA

Cellular 1-800-331-6456

Paging 1-800-548-9954

FRS Radios 1-800-353-2729

TTY (Text Telephone)

1-888-390-6456

Canada

All Products

1-800-461-4575

TTY (Text Telephone)

1-888-390-6456

Accessories and software—call the number designated for the product with which they are used.

You will receive instructions on how to ship the Products to Motorola or our designated resource. If instructed to ship the Products, you must ship them with freight, duties and insurance prepaid. Regardless of where you are instructed to return the Products, you must include: (a) a copy of your receipt, bill of sale or other comparable proof of purchase; (b) a written description of the problem; (c) the name of your service provider (if this Product requires subscription service); (d) the name and location of the installation facility (if applicable) and, most importantly; (e) your address and telephone number. If requested, you must also return all detachable parts such as antennas, batteries and chargers. **RETAIN YOUR ORIGINAL PROOF OF PURCHASE.**

For Products we ask you ship to us, we will ship repaired or replacement Products at our expense for the freight and insurance, but at your expense for any duties. If additional information is needed, please contact us at the telephone number listed above.

VI. What This Warranty Does Not Cover

- **Products that are operated in combination with ancillary or peripheral equipment or software not furnished or otherwise certified by Motorola for use with the Products (“ancillary equipment”), or any damage to the Products or ancillary equipment as a result of such use. Among other things, “ancillary equipment” includes batteries, chargers, adaptors, and power supplies not manufactured or supplied by Motorola. Any of these voids the warranty.**
- Someone other than Motorola (or its authorized service centers) tests, adjusts, installs, maintains, alters, modifies or services the Products in any way. Any of these voids the warranty.
- Rechargeable batteries that: (a) are charged by other than the Motorola-approved battery charger specified for charging such batteries; (b) have any broken seals or show evidence of tampering; (c) are used in equipment other than the Product for which they are specified; or (d) are charged and stored at temperatures greater than 60 degrees centigrade. Any of these voids the warranty.
- Products that have: (a) serial numbers or date tags that have been removed, altered or obliterated; (b) board serial numbers that do not match each other, or board serial numbers that do not match the housing; or (c) nonconforming or non-Motorola housings or parts. Any of these voids the warranty.

- Defects or damage that result from: (a) use of the Products in a manner that is not normal or customary; (b) improper operation or misuse; (c) accident or neglect such as dropping the Products onto hard surfaces; (d) contact with water, rain, extreme humidity or heavy perspiration; (e) contact with sand, dirt or the like; or (f) contact with extreme heat, or spills of food or liquid.
- Physical damage to the surface of the Products, including scratches, cracks or other damage to a display screen, lens or other externally exposed parts.
- Failure of Products that is due primarily to any communication service or signal you may subscribe to or use with the Products.
- Coil cords that are stretched or that have any broken modular tabs.
- Leased Products.

Flat-rate repair rates may apply to Products not covered by this warranty. To obtain information about Products needing repairs that are not covered by this warranty, please call the telephone number previously listed. We will provide information on repair availability, rates, methods of payment, where to send the Products, etc.

VII. Some Other Limitations

This is Motorola's complete warranty for the Products, and states your exclusive remedies. This warranty is given in lieu of all other express warranties. Implied warranties, including without limitation, the implied warranties of merchantability and fitness for a particular purpose, are given only if specifically required by applicable law. Otherwise, they are specifically excluded.

No warranty is made as to coverage, availability, or grade of service provided by the Products, whether through a service provider or otherwise.

No warranty is made that the software will meet your requirements or will work in combination with any hardware or applications software products provided by third parties, that the operation of the software products will be uninterrupted or error free, or that all defects in the software products will be corrected.

In no event shall Motorola be liable, whether in contract or tort (including negligence) for damages in excess of the purchase price of the Product, or for any indirect, incidental, special or consequential damages of any kind, or loss of revenue or profits, loss of business, loss of information or data, or other financial loss arising out of or in connection with the ability or inability to use the Products, to the full extent these damages may be disclaimed by law.

VIII. Patent and Software Provisions

At Motorola's expense, we will defend you, and pay costs and damages that may be finally awarded against you, to the extent that a lawsuit is based on a claim that the Products directly infringe a United States patent. Our obligation is conditioned on: (a) you notifying us promptly in writing when you receive notice of the claim; (b) you giving us sole control of the defense of the suit and all negotiations for its settlement or compromise; and (c) should the Products become, or in Motorola's opinion be likely to become, the subject of a claim of infringement of a United States patent, you permit us, at our option and expense, either to: procure for you the right to continue using the Products; replace or modify them so that they become non-infringing; or grant you a credit for such Products, as depreciated, and accept their return. The depreciation will be an equal amount per year over the lifetime of the Products, as established by Motorola.

Motorola will have no liability to you with respect to any claim of patent infringement that is based upon the combination of the Products or parts furnished under this limited warranty with ancillary equipment, as defined in VI., above.

This is Motorola's entire liability with respect to infringement of patents by the Products.

IX. State Law and Other Jurisdiction Rights

Some states and other jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, or limitation on the length of an implied warranty, so the above limitations or exclusions may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights, which vary from jurisdiction to jurisdiction.

To obtain information on Motorola Personal Communications Products, including warranty service, accessories and optional Extended Warranties on selected Products, please call:

USA

Cellular 1-800-331-6456

Paging 1-800-548-9954

FRS Radios 1-800-353-2729

TTY (Text Telephone)

1-888-390-6456

Canada

All Products

1-800-461-4575

TTY (Text Telephone)

1-888-390-6456

Accessories and software—call the telephone number designated above for the product with which they are used.

**DO NOT SHIP PRODUCTS TO THESE ADDRESSES —
INSTEAD PLEASE CALL.**

To correspond with Motorola about Products, please write us at: <http://www.motorola.com> or at:

In the USA:

Motorola, Inc.

600 North U.S. Highway 45

Libertyville, IL 60048

In Canada:

Motorola Canada Limited

5875 Whittle Road

Mississauga, ON L4Z 2H4

ITC01-078

Product Registration

Online Product Registration:

<http://www.motorola.com/warranty>

Product registration is an important step toward enjoying your new Motorola product. Registering helps us facilitate warranty service, and permits us to contact you should your product require an update or other service. Registration is for U.S. residents only and is not required for warranty coverage.

Please retain your original dated sales receipt for your records. For warranty service of your Motorola Personal Communications Product you will need to provide a copy of your dated sales receipt to confirm warranty status.

Thank you for choosing a Motorola product.

Export Law Assurances

This product is controlled under the export regulations of the United States of America and Canada. The Governments of the United States of America and Canada may restrict the exportation or re-exportation of this product to certain destinations. For further information contact the U.S. Department of Commerce or the Canadian Department of Foreign Affairs and International Trade.

Index

A

accessories

optional 10, 79, 118,
120, 123

standard 18

accessory connector port
1

active line indicator

defined 23

illustration 22

Add Digits feature 59

alarm 74, 76

alert

creating 95–102

defined 93

reminders, turning on/off
102

selecting 94

turning off 29

analog signal indicator

defined 23

illustration 22

animation 54

answering a call 21

antenna 1

application, locking 52

appointments. *See*
datebook

Attach Number feature 31,
59

B

backlight 54

battery

car kit charger time 122

charging 19

extending battery life
25–26, 54

installing 18

level indicator 19, 22,
23

meter 50

battery save 54

blackjack 113–114

block cursor, defined 37

browse text mode 38

browser. *See*

micro-browser

C

calculator 109–111

calendar. *See* datebook
call

adding digits after phone
number 59

alert, creating 95–102

- alert, selecting 94
- alert, turning off 29
- answer options 52
- answering 21
- call waiting 32
- calling card 66
- canceling 29
- data call 125–128
- datebook, opening 33
- deleting 58–59
- dialed calls list 31, 33, 58–59
- dialing 20
- dialing a recent call 58–59
- emergency number 28
- ending 21
- in-call timer 51
- incoming call type, setting 126–128
- making 20
- message center, accessing 33
- muting 33
- prefix digits, inserting 31
- privacy 27, 133
- received calls list 31, 33, 58–59
- receiving 21
- recent calls 58–59
- restricting 132–??
- ring style, setting 93
- secure connection 27, 133
- speakerphone, activating 33
- storing 58–59
- three-way call 32
- timing 60–62
- unanswered call 28
- voice dial 31
- call timers 60–62
 - resetting 62
 - viewing 62
- call waiting 32
- caller ID 27, 28
- calling card call 66
- calling line identification. See caller ID
- car kit
 - automatic answer 120
 - automatic hands-free 121
 - charger time 122
 - power-off delay 121
- clock 22
- codes
 - changing 129–130
 - default 20
 - if you forget a code/password 130
 - original 129

- computer
 - connecting to phone 123–125
- contrast, display 55
- currency converter 111
- cursor 37
- customizing the menu 117

D

- data call
 - connecting to external device 123–125
 - incoming call format, setting 126–128
 - receiving 126–127
 - sending 125–126
- date, setting 53
- datebook
 - adding an event 76
 - alarm 76
 - calendar 74
 - changing event information 76
 - copying an event 77
 - day view 75
 - deleting an event 78
 - event reminders, turning on/off 102
 - event view 75
 - reminders 76
 - week view 74
- deleting a call 58–59

- dialed calls list 31, 33, 58–59

- dialing a number 20

- Dialing Menu** 60

- digital signal indicator
 - defined 23
 - illustration 22

- display
 - animation 54
 - backlight 54
 - contrast 55
 - described 22–24
 - greeting 53
 - idle display 22
 - illustration 22
 - language 54
 - zoom setting 54
 - zooming in/out 24

- drafts folder 49

- DTMF tones 33, 55, 59, 139

E

- earpiece
 - illustration 1
 - volume, adjusting 24

- email
 - address, storing in phonebook 64–66

- email, sending 69, 89–91

- emergency number 28

end key
 functions 21
 menu functions 34
 ending a call 21
Enter Unlock Code
 message 130, 132
 event alert 94
 exchange rate, calculating
 111
 external device
 connecting to phone
 123–125

F

factory settings, resetting
 55–56
 falling numbers 114–115
 flashing cursor, defined 37
 FM Stereo Radio Headset
 48, 79–81

G

games 112–116
 greeting, display 53

H

hands-free mode
 automatic answer 120
 automatic call routing
 121
 charger time 122

defined 120
 power-off delay 121
 speakerphone,
 activating 33
 headset
 automatic answer 120
 FM Stereo Radio
 Headset 48,
 79–81
 high-security connection
 27, 133

I

idle display, defined 22
 in use indicator
 defined 23
 illustration 22
 inbox, text message
 84–85
 in-call timer 51
 incoming call
 canceling 29
 type, setting 126–128

Incoming Call message
 27

indicators

active line 22, 23
 battery level 19, 22, 23
 digital/analog signal 22,
 23
 in use 22, 23
 loud ring style 24, 93

- menu 22, 23
 - message waiting 22, 23, 85
 - missed call 28
 - ring and vibrate ring style 24, 93
 - ring style 22, 24, 93
 - roam 22, 23
 - signal strength 22, 23
 - silent alert 24
 - silent ring style 24, 93
 - soft ring style 24, 93
 - vibrate ring style 24, 93
 - voice message waiting 22, 23, 83
 - voice name 63
 - iTAP software 43–46
- K**
- key
 - end 21, 34
 - left soft key 1, 22, 34, 117
 - lock 52, 132
 - menu 1, 10, 23, 34
 - navigation 34
 - power 20
 - power/end 1
 - right soft key 1, 22, 34, 117
 - scroll 1
 - send 1, 20, 21, 58
 - voice 68
 - keypad
 - answering calls 52
 - locking and unlocking 52, 132
 - volume, setting 95
- L**
- language, setting 54
 - left soft key
 - customizing 117
 - functions 1, 22, 34
 - Line Not Secure** message 28
 - lock
 - applications 52
 - keypad 52, 132
 - phone 131–132
 - lock application feature 52
 - loud ring style indicator 24, 93
 - Low Battery** message 23
- M**
- making a call 20
 - master clear 56
 - master reset 55
 - Memory is Full!** message 86
 - menu
 - Browser Menu** 108
 - Calculator Menu** 109

- customizing 117
 - Datebook Menu** 74, 75
 - Dialing Menu** 31, 60
 - entering text 36–37, 38–46
 - features 47–57
 - language, setting 54
 - Last Calls Menu** 59
 - lists 35
 - locking applications 52
 - My Tones Menu** 101, 102
 - navigating 10, 34
 - Phonebook Menu** 63
 - Quick Note Menu** 92
 - rearranging features 117
 - scroll feature 54
 - Text Msg Menu** 87–88
 - using features 10, 35–37
 - menu indicator
 - defined 23
 - illustration 22
 - menu key 1, 10, 23, 34
 - message
 - deleting, text 86–88
 - dialing number from 30
 - drafts folder 49
 - inbox setup, text message 84–85
 - locking, text 86–88
 - outbox 49, 92
 - quick note 91–92
 - reading, text 86–88
 - receiving, text 85–86
 - reminders, receiving 83, 86
 - reminders, turning on/off 102
 - sending 31, 89–91
 - sound 89
 - status 92
 - text 84–92
 - voicemail 82–83
 - message waiting indicator
 - defined 23
 - displayed 85
 - illustration 22
 - micro-browser
 - using 107–108
 - microphone 1
 - missed call indicator 28
 - Missed Call** message 28
 - missed call, dialing 31
 - muting a call 33
 - my telephone number 21, 33, 50
 - my tones 95–102
 - My Tones Menu** 101, 102
- ## N
- navigation key 34
 - network settings 56

notepad
 defined 60
 entering digits 60
 retrieving digits 60
number, viewing your own
 50
numeric text mode 38

O

one-touch dial
 defined 30
 using 30
 voicemail number 30
optional accessory,
 defined 10
optional feature, defined
 10
outbox 49, 92

P

passwords. *See* codes
pause character 67
phone
 active line indicator 23
 alert, turning off 29
 answer options 52
 codes 129–130
 connecting to external
 device 123–125
 erase user-entered
 information 56

feature specifications
 33, 51
information 33
keypad, locking and
 unlocking 52,
 132
locking 131–132
muting a call 33
reset all options 55
secure connection 27,
 133
security code 129
specifications 33, 51
turning on/off 20
unlock code 20, 129,
 130
unlocking 20, 131–132
voice dial 31
phone number
 active line indicator 23
 active phone line,
 changing 50
 adding digits after 59
 attaching to prefix digits
 31
 attaching two numbers
 59
 redialing 27
 seeing your own 21, 33
 sending text message to
 31

- storing in phonebook 64–66
 - viewing your own 50
 - voice dial 31
 - phonebook
 - attaching two numbers 59
 - capacity, checking 71
 - deleting an entry 70
 - dialing a number 69
 - editing an entry 70
 - email address 63
 - entry details 63
 - entry name 63
 - number type indicator 63
 - one-touch dial 30
 - phone number 63
 - prefix digits, inserting 31
 - primary number, setting 71
 - ringer ID,
 - activating/deactivating 94–95
 - ringer ID, defined 65, 94
 - ringer ID, setting 65
 - sending an email 69
 - sorting entries 72
 - speed dial number 63, 65
 - speed dial number,
 - defined 30
 - speed dial, using 30
 - storing an entry 64–66
 - voice name entry 68
 - voice name indicator 63
 - PIN code 66
 - power key 20
 - power/end key
 - functions 1
 - predictive text entry 43–46
 - privacy, call 27, 133
- Q**
- quick note 91–92
 - defined 84
- R**
- radio 79–81
 - received calls list 31, 33, 58–59
 - recent calls 58–59
 - redial
 - busy number 27
 - reminders
 - datebook 76
 - defined 102
 - text message 86
 - turning on/off 102
 - voicemail message 83
 - restricting calls 132–??

- right soft key
 - customizing 117
 - functions 1, 22, 34
- ring alert
 - selecting 94
 - turning off 29
- ring and vibrate alert
 - turning off 29
- ring and vibrate ring style indicator 24, 93
- ring style
 - customizing 94–95
 - defined 93
 - indicators 24, 93
 - setting 93
- ring style indicator
 - defined 24, 93
 - illustration 22
- ringer
 - volume, adjusting 24
 - volume, setting 95
- ringer ID
 - activating/deactivating 94–95
 - defined 65, 94
 - listed in phonebook entry 63
 - setting for phonebook entry 65
- roam indicator
 - defined 23
 - illustration 22

S

- scroll feature 54
- scroll keys 1
- secure connection 27, 133
- security code
 - changing 129–130
- send key 1, 20, 21, 58
- short message service.
 - See text message
- shortcuts
 - creating 104–105
 - standard 104
 - using 106
- signal strength indicator
 - defined 23
 - illustration 22
- silent alert indicator 24
- silent ring style indicator 24, 93
- SMS. See text message
- soft keys
 - customizing 117
 - functions 22, 34
 - illustration 1
 - labels 22
- soft ring style indicator 24, 93
- sound
 - storing 89
- speakerphone, activating 33
- speed dial

- changing number 65
- number, defined 30
- sorting phonebook
 - entries by 72
- using 30
- standby time, increasing 26
- storing a call 58–59
- symbol text mode 42–43
- symbols, entering 42–43

T

- Talk Secure** feature 27, 133
- tap method text entry 39–41
- telephone number, viewing your own 50
- text
 - block cursor 37
 - browse mode 38
 - character chart 41
 - entering from keypad 38–46
 - entry mode, changing 38
 - flashing cursor 37
 - iTAP software predictive text entry 43–46
 - numeric mode 38
 - symbol chart 42
 - symbol mode 42–43

- tap method 39–41
- text message
 - defined 84
 - deleting 86–88
 - dialing number from 30
 - drafts folder 49
 - inbox setup 84–85
 - locking 86–88
 - outbox 49
 - quick note 91–92
 - reading 86–88
 - receiving 85–86
 - reminders 86
 - sending 31, 89–91
 - sound 89
 - status 92
- text mode, changing 38
- three-way call 32
- time, setting 53
- timers 60–62
 - resetting 62
 - viewing 62
- travel charger, using 19
- TTY device 118–120

U

- unlock
 - keypad 52, 132
 - phone 131–132
- unlock code 130
 - bypassing 130
 - changing 129–130

entering 20, 131, 132

V

vibrate alert

selecting 94

turning off 29

vibrate ring style

indicator 24, 93

setting 93

video poker 115–116

voice dial

dialing a number 31, 69

recording voice name

68

voice key

recording a voice name

68

voice message waiting

indicator 22, 23, 83

voice name

defined 68

phonebook indicator 63

recording 68

voice shortcut

creating 104–105

defined 104

using 106

voicemail

dialing with one-touch

dial 30

reminders, turning on/off

102

using 82–83

volume

earpiece 24

keypad 95

ringer 24, 95

volume control 24

W

wait character 67

warranty 157–164

Web pages 107–108

Z

zoom setting 54

zooming in/out 24



MOTOROLA

Wireless Phone Safety Tips

"Safety is your most important call!"

Your Motorola wireless telephone gives you the powerful ability to communicate by voice—almost anywhere, anytime, wherever wireless phone service is available and safe conditions allow. But an important responsibility accompanies the benefits of wireless phones, one that every user must uphold.

When driving a car, driving is your first responsibility. If you find it necessary to use your wireless phone while behind the wheel of a car, practice good common sense and remember the following tips:

- 1 Get to know your Motorola wireless phone and its features such as speed dial and redial.** If available, these features help you to place your call without taking your attention off the road.



- 2 **When available, use a hands-free device.** If possible, add an additional layer of convenience to your wireless phone with one of the many Motorola Original™ hands-free accessories available today.
- 3 **Position your wireless phone within easy reach.** Be able to access your wireless phone without removing your eyes from the road. If you receive an incoming call at an inconvenient time, if possible, let your voice mail answer it for you.
- 4 **Let the person you are speaking with know you are driving; if necessary, suspend the call in heavy traffic or hazardous weather conditions.** Rain, sleet, snow, ice, and even heavy traffic can be hazardous.
- 5 **If you receive an incoming call at an inconvenient time do not take notes or look up phone numbers while driving.** Jotting down a “to do” list or going through your address book takes attention away from your primary responsibility—driving safely.
- 6 **Dial sensibly and assess the traffic; if possible, place calls when you are not moving or before pulling into traffic.** Try to plan calls when your car will be stationary. If you need to make a call while moving, dial only a few numbers, check the road and your mirrors, then continue.
- 7 **Do not engage in stressful or emotional conversations that may be distracting.** Make people you are talking with aware you are driving and suspend conversations which have the potential to divert your attention away from the road.

- 
- 8 **Use your wireless phone to call for help.** Dial 9-1-1 or other local emergency number in the case of fire, traffic accident or medical emergencies.*
- 9 **Use your wireless phone to help others in emergencies.** If you see an auto accident, crime in progress or other serious emergency where lives are in danger, call 9-1-1 or other local emergency number, as you would want others to do for you.*
- 10 **Call roadside assistance or a special non-emergency wireless assistance number when necessary.** If you see a broken-down vehicle posing no serious hazard, a broken traffic signal, a minor traffic accident where no one appears injured, or a vehicle you know to be stolen, call roadside assistance or other special non-emergency wireless number.*
- PRELIMINARY

* Wherever wireless phone service is available.

Check the laws and regulations on the use of wireless telephones and their accessories in the areas where you drive. Always obey them. The use of these devices may be prohibited or restricted in certain areas.



For more information,
please call
1-888-901-SAFE
or visit the
CTIA Web site at
www.wow-com.comTM

ITC00-011

