

INSTRUCTION MANUAL

A preliminary draft copy of the Users Manual follows:

Note:

Upon FCC approval, the users manual will include the following SAR information for FCC ID: IHDT6BC1.

0.77mW/g (head)

0.56mW/g (body worn)

Motorola Timeport 280 Tri-Band Mobile Phone User's Guide

Interim Draft

March 9, 2001

This is a preliminary version of the Panther 2 GSM user guide. In particular, color-coded text describes new R1.1 features for which the software is not yet fully developed. Please use this draft as reference only. It is not yet ready for review. If you want to provide feedback, contact John Arminio or Bill Bernie.

PRELIMINARY

Welcome

Welcome to the world of Motorola digital wireless communications! We are pleased that you have chosen the Motorola **TIMEPORT** 280 wireless phone.



Personal Communications Sector
600 North U.S. Highway 45
Libertyville, Illinois 60048

1-800-331-6456 (United States)
1-888-390-6456 (TTY/TDD United States)
1-800-461-4575 (Canada)

www.motorola.com

MOTOROLA, the Stylized M Logo and all other trademarks indicated as such herein are trademarks of Motorola, Inc. ® Reg. U.S. Pat. & Tm. Off. TrueSync is a trademark of Starfish, Inc., a wholly owned independent subsidiary of Motorola, Inc. The Bluetooth trademarks are owned by their proprietor and used by Motorola, Inc. under license. All other product or service names are the property of their respective owners.

© 2001 Motorola, Inc. All rights reserved. Printed in the U.S.A.

Computer Program Copyrights

The Motorola products described in this manual may include Motorola computer programs stored in semiconductor memories or other media that are copyrighted with all rights reserved worldwide to Motorola. Laws in the United States and other countries preserve for Motorola, Inc. certain exclusive rights to the copyrighted computer programs, including the exclusive right to copy, reproduce, modify, decompile, disassemble, and reverse-engineer the Motorola computer programs in any manner or form without Motorola's prior written consent. Furthermore, the purchase of Motorola products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any license or rights under the copyrights, patents, or patent applications of Motorola, except for a nonexclusive license to use the Motorola product and the Motorola computer programs with the Motorola product.

Manual number: 9888873L01-O
Cover number: 8988485L01-O



Menu Map

Main Menu

- **Recent Calls**
 - Received Calls
 - Dialed Calls
 - Notepad
 - Call Times
 - Call Cost
- **Service Dial**
- **Fixed Dial**
- **Phonebook**
- **Datebook**
- **Quick Dial**
- **Radio**
- **Messages**
 - Voicemail
 - Text Msgs
 - Browser Alerts
 - Quick Notes
 - Outbox
 - Drafts
- **Shortcuts**
- **Voice Notes**
- **SIM Applications**
- **Browser**
- **Calculator**
- **Games**
- **Settings**
(see next page)

Note: This is the standard menu layout. You or your service provider may have modified the menu structure or changed some feature names. Not all features may be available for all users. For example, the **Radio** feature is displayed only when the FM Stereo Radio Headset accessory is plugged into the accessory connector port on your phone.

Shortcuts
Change display zoom: Press  , then press and hold 
Lock/unlock keypad: Press  
Display my phone number: Press  
Go to dialed calls list: Press 



Settings Menu

• Ring/Vibrate

- Alert
- *Alert* Detail

• Call Forward

- Voice Calls
- Fax Calls
- Data Calls
- Cancel All
- Forward Status

• Phone Status

- My Tel. Number
- Credit Available
- Credit Info
- Battery Meter
- Phone: Line 1/2
- Other Information

• Connection

- IrDA Link
- Incoming Call

• In-Call Setup

- In-Call Timer
- Call Cost Setup
- My Caller ID
- Talk and Fax
- Answer Options
- Call Waiting

• Security

- Phone Lock
- Lock Keypad
- Lock Application
- Fixed Dial
- Call Barring
- SIM Pin
- New Passwords

• Other Settings

• Personalize

- Main Menu
- Keys
- Greeting
- Banner
- Quick Dial

• Initial Setup

- Time and Date
- One-Touch Dial
- Auto Redial
- Backlight
- Zoom
- Scroll
- Language
- Preferred Card
- Battery Save
- Contrast Setting
- Master Reset
- Master Clear

• Network

- Car Settings
- Headset

Contents

Menu Map	3
About This Guide	10
Safety and General Information	12
Getting Started	20
What's in the Box?	20
Installing the SIM Card	20
Installing the Battery	21
Removing the Battery	23
Charging the Battery	24
Turning Your Phone On	24
Sending a Call	25
Ending a Call	26
Receiving a Call	26
Displaying Your Phone Number	26
About Your Phone	27
Display	27
Changing the Zoom Setting	30
Volume Keys	30
4-Way Navigation Key	31
Battery Use	31
Sending and Receiving Calls	33
Redialing a Number	33
Using Automatic Redial	33
Caller ID	34
Line Security	34
Returning an Unanswered Call	34
Dialing an Emergency Number When the Phone is Locked	35

Contents

Entering Numbers in the Notepad	36
Muting the Ring or Vibrate Alert	36
Terminating an Incoming Call	37
Dialing With Speed Dial	37
Dialing With One-Touch Dial	38
Dialing a Number In a Text Message	39
Additional Dialing Features	40
Using Features While On a Call	42
Using Call Waiting	42
Making a Conference Call	43
Transferring a Call	43
Additional On-Call Features	45
Using the Menu	46
Navigating to a Feature	46
Selecting a Feature Option	47
Entering Feature Information	48
Entering Text	51
Menu Feature Descriptions	58
Recent Calls	73
Viewing the Received Calls or Dialed Calls List	73
Using the Notepad	76
Call Times and Costs	77
Viewing and Resetting Call Times and Costs	79
Phonebook	81
Fields in a Phonebook Entry Form	81
Storing a Phonebook Entry	82
Recording a Voice Name For a Phonebook Entry	84
Dialing a Phonebook Entry	86
Editing a Phonebook Entry	87

Contents

Deleting a Phonebook Entry	87
Copying Phonebook Entries to a SIM Card	88
Checking Phonebook Capacity	91
Synchronizing with TrueSync Software	91
Setting Up the Phonebook	92
Datebook	94
Week View	94
Day View	95
Event View	96
Storing a New Event	97
Changing Event Information	98
Copying an Event	99
Deleting an Event	100
Radio	101
Turning the Radio On and Off	101
Tuning a Station	102
Storing a Preset	102
Selecting a Preset	102
Sending and Receiving Calls With the Radio On	103
Messages—Voicemail	105
Storing Your Voicemail Number	105
Receiving a New Voicemail Message	105
Listening to a Voicemail Message	106
Messages—Text	107
Setting Up the Text Message Inbox	107
Receiving a New Text Message	109
Reading, Locking, or Deleting a Text Message	109
Sending a New Text Message	111
Viewing the Status of Sent Text Messages	114

Shortcuts	115
Standard Shortcuts	115
User-Settable Shortcuts	115
Creating a Shortcut	116
Using Shortcuts	118
Voice Notes	119
Recording a Voice Note	119
Viewing the Voice Notes List	120
Playing a Voice Note	121
Locking and Unlocking a Voice Note	124
Deleting a Voice Note	125
Micro-Browser	126
Starting a Micro-Browser Session	126
Interacting With Web Pages	127
Calculator	128
Calculating Numbers	128
Converting Currency	130
Games	131
Selecting and Starting a New Game	131
Ending a Game	132
Playing the Games	132
Adjusting Your Settings	136
Ring/Vibrate	136
Reminders	143
Call Forwarding	143
Reordering Menu Items	146
Customizing a Soft Key Function	146
Hands-Free Use	147

Contents

Data and Fax Calls	151
Connecting Your Phone to an External Device	151
Sending a Data or Fax Call	155
Receiving a Data or Fax Call	156
Sending a Talk then Data or Talk then Fax Call	159
Security	160
Assigning a New Code or Password	160
If You Forget a Code or Password	161
Locking and Unlocking Your Phone	162
Locking and Unlocking Your Keypad	164
Barring Calls	164
Protecting the SIM Card	165
Troubleshooting	166
Specific Absorption Rate Data	173
FDA Update	175
Warranty	184
Export Law Assurances	192
Index	193
Wireless Phone Safety Tips	205

About This Guide

Using Your Phone's Features

This user guide introduces you to the many features in your Motorola **TIMEPORT** phone. A reference guide for your phone is also available that explains the phone's features in more detail. To obtain a copy of the reference guide or another copy of this user guide, see the Motorola Web site at:

<http://motorola.com/consumer/manuals>

or contact the Motorola Customer Call Center at 1-800-331-6456.

Navigating To a Menu Feature

You can access many of your phone's features through the menu system. This guide shows you how to navigate to a specific menu feature as follows:

Find the Feature



> Recent Calls
> Dialed Calls

The > symbol means that you should scroll to and select the feature. This example shows that you must press , scroll to and select **Recent Calls**, then scroll to and select **Dialed Calls** to view the dialed calls list.

Optional Features



Features marked with this label are optional network and/or subscription-dependent features. These features may not be offered by all service providers in all geographical areas. Contact your service provider for information about availability.

Optional Accessories



Features marked with this label require the use of an optional Motorola Original™ accessory.

Safety and General Information

IMPORTANT INFORMATION ON SAFE AND EFFICIENT OPERATION. READ THIS INFORMATION BEFORE USING YOUR PHONE.

RF Operational Characteristics

Your phone contains a transmitter and a receiver. When it is ON, it receives and transmits radio frequency (RF) energy. The phone operates in the frequency range of ____ MHz to ____ MHz in digital mode.

When you communicate with your phone, the system handling your call controls the power levels at which your phone transmits. The output power level typically may vary over a range from ____ watts to ____ watts in digital mode.

Exposure To Radio Frequency Energy

Your Motorola phone is designed to comply with the following national and international standards and guidelines regarding exposure of human beings to radio frequency electromagnetic energy (EME):

- United States Federal Communications Commission, Code of Regulations; 47 CFR part 2 sub-part J
- American National Standards Institute (ANSI) / Institute of Electrical and Electronic Engineers (IEEE) C95. 1-1992



- Institute of Electrical and Electronic Engineers (IEEE) C95.1-1999 Edition
- National Council on Radiation Protection and Measurements (NCRP) of the United States, Report 86, 1986
- International Commission on Non-Ionizing Radiation Protection (ICNIRP) 1998
- National Radiological Protection Board of the United Kingdom 1995
- Ministry of Health (Canada) Safety Code 6. Limits of Human Exposure to Radiofrequency Electromagnetic Fields in the Frequency Range from 3 kHz to 300 GHz, 1999
- Australian Communications Authority Radiocommunications (Electromagnetic Radiation-Human Exposure) Standard 1999

To assure optimal phone performance and make sure human exposure to radio frequency electromagnetic energy is within the guidelines set forth in the above standards, always adhere to the following procedures:

Portable Phone Operation and EME Exposure

Antenna Care

Use only the supplied or an approved replacement antenna. Unauthorized antennas, modifications, or

Safety and General Information

attachments could damage the phone and may violate FCC regulations.

Do NOT hold the antenna when the phone is in use.

Holding the antenna affects call quality and may cause the phone to operate at a higher power level than needed.

Phone Operation

When placing or receiving a phone call, hold your phone as you would a wireline telephone. **Speak directly into the microphone.**

Body-Worn Operation

To maintain compliance with FCC RF exposure guidelines, if you wear a phone on your body when transmitting, always place the phone in a **Motorola-supplied or approved clip, holder, holster, case, or body harness.** Use of non-Motorola-approved accessories may exceed FCC RF exposure guidelines. **If you do not use a body-worn accessory, and are not holding the phone in the normal use position at the ear, ensure the phone and its antenna are at least one inch (2.5 centimeters) from your body when transmitting.**

Data Operation

When using any data feature of the phone, with or without an accessory cable, **position the phone and its antenna at least one inch (2.5 centimeters) from your body.**



Approved Accessories

For a list of approved Motorola accessories, visit our website at www.motorola.com.

Electromagnetic Interference/ Compatibility

Note: Nearly every electronic device is susceptible to electromagnetic interference (EMI) if inadequately shielded, designed, or otherwise configured for electromagnetic compatibility.

Facilities

To avoid electromagnetic interference and/or compatibility conflicts, turn off your phone in any facility where posted notices instruct you to do so. Hospitals or health care facilities may be using equipment that is sensitive to external RF energy.

Aircraft

When instructed to do so, turn off your phone when on board an aircraft. Any use of a phone must be in accordance with applicable regulations per airline crew instructions.

Medical Devices

Pacemakers

The Health Industry Manufacturers Association recommends that a minimum separation of 6 inches (15 centimeters) be

maintained between a handheld wireless phone and a pacemaker. These recommendations are consistent with the independent research by, and recommendations of, Wireless Technology Research.

Persons with pacemakers should:

- ALWAYS keep the phone more than six inches (15 centimeters) from your pacemaker when the phone is turned ON.
- NOT carry the phone in the breast pocket.
- use the ear opposite the pacemaker to minimize the potential for interference.
- turn OFF the phone immediately if you have any reason to suspect that interference is taking place.

Hearing Aids

Some digital wireless phones may interfere with some hearing aids. In the event of such interference, you may want to consult your hearing aid manufacturer to discuss alternatives.



Other Medical Devices

If you use any other personal medical device, consult the manufacturer of your device to determine if it is adequately shielded from RF energy. Your physician may be able to assist you in obtaining this information.

Safety and General

Use While Driving

Check the laws and regulations on the use of phones in the area where you drive. Always obey them.

When using your phone while driving, please:

- give full attention to driving and to the road.
- use hands-free operation, if available.
- pull off the road and park before making or answering a call if driving conditions so require.

Operational Warnings

For Vehicles With an Air Bag

Do not place a portable phone in the area over an air bag or in the air bag deployment area. Air bags inflate with great force. If a portable phone is placed in the air bag deployment area and the air bag inflates, the phone may be propelled with great force and cause serious injury to occupants of the vehicle.

Potentially Explosive Atmospheres

Turn off your phone prior to entering any area with a potentially explosive atmosphere, unless the phone is a model specifically identified as being "Intrinsically Safe" for use in such areas (for example, Factory Mutual, CSA, or UL Approved). Do not remove, install, or charge batteries in such areas. Sparks in a potentially explosive atmosphere can cause an explosion or fire resulting in bodily injury or even death.

Note: The areas with potentially explosive atmospheres referred to above include fueling areas such as below decks on boats, fuel or chemical transfer or storage facilities, areas where the air contains chemicals or particles such as grain, dust, or metal powders, and any other area where you would normally be advised to turn off your vehicle engine. Areas with potentially explosive atmospheres are often but not always posted.

Blasting Caps and Areas

To avoid possible interference with blasting operations, turn OFF your phone when you are near electrical blasting caps, in a blasting area, or in areas posted: "Turn off two-way radio." Obey all signs and instructions.



Operational Cautions

Antennas

Do not use any portable phone that has a damaged antenna. If a damaged antenna comes into contact with your skin, a minor burn can result.

Batteries

All batteries can cause property damage and/or bodily injury such as burns if a conductive material such as jewelry, keys, or beaded chains touches exposed terminals. The conductive material may complete an electrical circuit (short circuit) and become quite hot. Exercise care in handling any charged battery, particularly when placing it inside a pocket, purse, or other container with metal objects.

ITC01-027

Getting Started

What's in the Box?

Your digital wireless phone typically comes equipped with a battery and a charger. Other accessory options can customize your phone for maximum performance and portability.

To purchase Motorola Original™ accessories, please phone 1-800-331-6456 in the United States or 1-800-461-4575 in Canada.


Installing the SIM Card

Your SIM (Subscriber Identity Module) card contains your phone number, service details, and phonebook/message memory. It is stored in a recess in the battery compartment.

Caution: Do not bend or scratch your SIM card. Avoid exposing your SIM card to static electricity, water, or dirt.

Do This


- 1 If the phone's battery door is already in place, push down the battery door release latch, then slide the door down and lift off.






Do This


- 2 Slide the SIM card door to the left and lift open.



- 3 Insert the SIM card into the SIM card door with the notch in the upper right corner and the gold plate facing down.



- 4 Close the SIM card door and slide it to the right to lock the SIM card in place.



- 5 Install the battery as described in the following section.

Installing the Battery

Before you can use your phone, you need to install and charge the battery.

Getting Started




Your phone is designed to be used only with Motorola Original batteries and accessories. We recommend that you store batteries in their protective cases when not in use.


Do This

- 1 Remove the battery from its protective clear plastic case.


- 2 If the phone's battery door is already in place, push down the battery door release latch, then slide the door down and lift off.



- 3 Insert the battery, printed arrow first, into the battery compartment and push down.



- 4 Replace the battery door, then slide the door up until it clicks into place.







Removing the Battery

Do This


- 1 Push down the battery door release latch, then slide the door down and lift off.



- 2 Pull down the battery release latch.



- 3 Pull up on the battery and remove it from the phone.



Charging the Battery

Before you can use your phone, you need to install and charge the battery.

Do This

- 1 Plug the travel charger into your phone with the release tab facing up.



- 2 Plug the other end of the travel charger into the appropriate electrical outlet.
- 3 When your phone indicates that the battery is fully charged (**Charge Complete**), press the release tab and remove the travel charger.

Turning Your Phone On

Do This

To

- 1 Press and hold  turn on your phone
(the power key)

Power
key





Do This	To
2 If necessary, enter your SIM card PIN code and press OK (↵)	unlock your SIM card See "Protecting the SIM Card" on page 165. Caution: If you enter an incorrect PIN code three times in a row, your SIM card is disabled.
3 If necessary, enter your four-digit unlock code and press OK (↵)	unlock your phone The unlock code is originally set to 1234. (For more information, see "Locking and Unlocking Your Phone" on page 162.)

Sending a Call

To call a number, your phone must be turned on, **have a SIM card inserted**, be unlocked, and have a network connection with adequate signal strength.

Press	To
1 keypad keys	dial the phone number (up to 32 digits) Tip: If you make a mistake, press DELETE (⌫) to delete the last digit, or press and hold DELETE (⌫) to clear all digits.
2 (⏻) (send key)	send the call

Ending a Call

Press	To
 (end key)	end the call

Receiving a Call

To receive a call, your phone must be turned on, [have a SIM card inserted](#), and have a network connection with adequate signal strength. If your phone is locked, you must unlock the phone to answer the call.

Note: Your phone cannot receive calls when your SIM card is locked.

When you receive a call, your phone rings and/or vibrates and displays an incoming call message.

Press	To
 or ANSWER ()	answer the call

Displaying Your Phone Number

From the idle display:

Press	To
 	see your phone number

About Your Phone



See page 1 for a diagram of your phone that describes basic phone components.


Display

The top section of the display shows phone status indicators. The following illustration shows some of the common indicators that you may see at the top of the display when using your phone.

Messages, phone numbers, and menu options appear in the middle of the display. Text labels at the bottom corners of the display show the current soft key functions. A  (menu) indicator in the bottom center of the display indicates that you can open the main menu or a feature sub-menu to see more options. For more information about the soft key and menu key labels, see “Using the Menu” on page 46.

Some of the phone functions described in this guide must be performed from the idle display. The term *idle display* refers to the standard display that you see when your phone is on and ready to use, when you are *not* on a call or using the menu system.

About Your Phone



1 Signal Strength Indicator Shows the strength of your phone's connection with the network.

Strong      No signal

You cannot send or receive calls when the "no signal" indicator is displayed.

2 In Use Indicator Appears when a call is in progress.

3 Roam Indicator Appears when your phone uses another network system outside your home network. When you leave your home network area, your phone *roams* or seeks another network.



4 Message Waiting Indicator Appears when your phone receives a text message.



5 Voice Message Waiting Indicator Appears when you receive a voicemail message.

6 Battery Level Indicator Shows the amount of charge left in your battery. The more segments visible, the greater the charge.



Recharge your battery as soon as possible when you see the **Low Battery** warning message.



7 Clock Shows the current time.

8 Menu Indicator Indicates that you can press  to open a menu. See "Using the Menu" on page 46.

9 Alert Setting Indicator Shows the current selected alert. The default alert setting is a ringer.



Loud ring



Soft ring



Vibrate



Ring and vibrate



Silent

Changing the Zoom Setting

You can set your phone's display to show either six lines or four lines of text plus soft key labels. Six lines of text display more information, while four lines increase text size.

To change the display view, press **MENU** once, then press and hold **MENU** again within two seconds of the first press.

You can also adjust the zoom setting from the menu. See the "Zoom" item on page 70.

Volume Keys

Use the upper and lower volume keys to adjust your phone's earpiece and ringer volume.



When	Press	To
During a call	volume keys	increase or decrease earpiece speaker volume
From the idle display	volume keys	increase or decrease ringer volume

You can also use the volume keys to scroll up or down through menus and lists.

To change keypad volume, see "Select a Ring/Vibration for a Specific Event" on page 137.



4-Way Navigation Key

4-way navigation key



The 4-way navigation key is a joystick that you use to move through the menu. It lets you adjust feature settings by pressing the key in the desired direction.

Tip: Down and up are your primary movements within menus. Right and left are available for shortcuts (advancing through choices), datebook, adjusting settings (such as contrast or key volume), and when entering or editing text.

Battery Use

Caution: To prevent injuries or burns, do not allow metal objects to contact or short-circuit the battery terminals.

To maximize your battery's performance:

- Always use Motorola approved batteries and battery chargers. The phone warranty does not cover damage caused from using non-Motorola batteries and/or battery chargers.
- New batteries or batteries that have been stored for long periods of time may require a longer charge time.
- Maintain the battery at or near room temperature when charging.

About Your Phone

- Do not expose batteries to temperatures below -10°C (14°F) or above 45°C (113°F). Always take your phone with you when you leave your vehicle.
- When you do not intend to use a battery for a while, store it uncharged in a cool, dark, dry place, such as a refrigerator.
- Over extended periods of time, batteries gradually wear down and require longer charging times. This is normal. If you charge your battery regularly and notice a decrease in talk time or an increase in charging time, then it is probably time to purchase a new battery.
- The more you talk on the phone or use phone features (like sending text messages), the less standby time your battery has.



The rechargeable batteries that power this product must be disposed of properly and may need to be recycled. Refer to your battery's label for battery type.

Contact your local recycling center for proper disposal methods. Never dispose of batteries in a fire because they may explode.



Sending and Receiving Calls

For basic instructions on how to send a call, end a call, and receive a call, see page 25 of the “Getting Started” section.

Redialing a Number

If you hear an ordinary busy signal, the phone number you dialed is busy.

Press	To
1 	hang up
2 	redial the busy number

Using Automatic Redial

If the network is busy, you hear a fast busy signal, and your phone displays the message **Call Failed**.

With automatic redial, your phone makes a number of redial attempts until the call goes through.

Press	To
1  or RETRY ()	activate automatic redial When the call goes through, your phone rings or vibrates one time and displays Redial Successful .

Sending and Receiving Calls

Press	To
2  or OK 	connect the call

You must activate automatic redial in order to use the feature. See the “Auto Redial” item on page 70.

Caller ID



The *calling line identification* (caller ID) feature lets you see who is calling before you answer.

- If the caller's name is stored in your phonebook, the phone automatically displays the name. Otherwise, the phone displays the caller's phone number.
- If caller ID information is not available, your phone displays the message **Incoming Call**.

Line Security

If your phone displays **Line Not Secure** while you are on a call, it means that the phone has detected another device monitoring the call.

Returning an Unanswered Call

Your phone keeps a record of your unanswered calls. When you cannot answer a call, your phone displays:

- the  (missed call) indicator



- the message **X Missed Calls Y Unknown**, where **X** is the total number of missed calls and **Y** is the number of missed calls for which caller ID information is not available.

Press	To
1 VIEW (👁)	see the received calls list, with the most recent call at the top
2 ⏮	scroll through the list and select a call that you want to return
3 (📞)	send the call

Dialing an Emergency Number When the Phone is Locked

Your service provider may program one or more emergency phone numbers that you can call even if your phone is locked or restricted.

When you see **Enter Unlock Code** in the display:

Press	To
1 keypad keys	dial the emergency number (such as 911)
2 (📞)	call the emergency number

Entering Numbers in the Notepad

Your phone stores the most recent string of digits entered on the keypad in a temporary memory location called the *notepad*.

These digits can be the last phone number that you called, or a phone number that you simply entered but did not call. These digits remain in the notepad even when you turn off the phone.

You can use the notepad to store a phone number that you intend to call later (such as a phone number told to you by the other party during a call). To retrieve these digits, see “Using the Notepad” on page 76.

Muting the Ring or Vibrate Alert

You can mute your phone’s incoming call alert before answering the call.

While the phone is ringing or vibrating:

Press	To
either volume key	turn off the ring or vibration alert

To specify a ring or vibration type, see “Ring/Vibrate” on page 136.



Terminating an Incoming Call

While the phone is ringing or vibrating:

Press	To
 or IGNORE ()	cancel the incoming call

Depending on your phone settings and the type of subscription you have with your service provider, the call may be forwarded to another number, or the calling party may hear a busy signal.

Dialing With Speed Dial

The *speed dial* feature lets you dial any phonebook entry with a minimal number of keypresses.

Whenever you store an entry in your phonebook, the entry is assigned a unique speed dial number. If you know the speed dial number for the phonebook entry you want to call, you can use the speed dial feature.

Press	To
1 keypad keys	enter the one-, two-, or three-digit speed dial number for the entry you want to dial
2 	submit the number
3 	call the entry

Sending and Receiving Calls

To make an entry in the phonebook or view an existing entry's speed dial number, see "Storing a Phonebook Entry" on page 82.

Dialing With One-Touch Dial

You can call phonebook entries 2 through 9 with the push of a single key. Just press and hold the one-digit speed dial number for one second.

It is recommended that you reserve location 1 in the phonebook for storing your voicemail number. In many cases, your service provider has already stored your voicemail number in location 1. If your voicemail number is not accessible by pressing and holding the **1** key, complete the following steps:

Do This	To
1 Store your voicemail number in phonebook location number 1 (see "Storing a Phonebook Entry" on page 82)	enable the 1 key voicemail shortcut
2 Complete the instructions for "Storing Your Voicemail Number" on page 105	enable voicemail soft key and menu shortcuts

To store entries in locations 2 through 9 in the phonebook, see "Storing a Phonebook Entry" on page 82.



Note: You must specify which phone number list you want to use with this feature: phone memory phonebook, fixed dial list, or SIM card phonebook. See “One-Touch Dial Preference” on page 93.

Dialing a Number In a Text Message



If you receive a text message with an embedded phone number, you can dial the number directly.

Note: You must set up your inbox before opening text messages. See “Setting Up the Text Message Inbox” on page 107.

Find the Feature



> Messages

> Text Msgs

Press	To
1	scroll to the message with the number
2	open the Text Msg Menu
3	scroll to Call Back
4 SELECT (	dial the number in the message

If the message contains more than one phone number, press to scroll to a number and then press **SELECT** () to dial.

Sending and Receiving Calls

Additional Dialing Features

In addition to pressing numbers on your keypad, you can insert numbers or characters and send calls in a variety of ways.

While dialing (with digits visible in the display):

Do This	To
Press 0+ for two seconds	insert the international access code for the country from which you are calling
Press MENU and then scroll to and select one of the following: • Insert Pause (to insert a p) • Insert Wait (to insert a w) • Insert 'n' (to insert an n)	insert a special character when making a call that requires you to dial and send additional digits (for example, to make a calling card call, or to retrieve messages from an answering machine): • Pause tells your phone to wait until the call connects before it sends the next digit(s) in a series. • Wait tells your phone to wait until the call connects, and then to prompt you before it sends the next digit(s). • 'n' tells your phone to stop and to prompt you for a number before it sends the next digit(s).



Do This	To
Press  > Attach Number	attach a number from the phonebook or recent calls list to the end of the digits you entered
Press  > Send Message	create a text message addressed to the number entered

You can also call numbers using these features:

Do This	To Call
Press and release the voice key on the right side of your phone and say the entry's name (in two seconds).  Voice key	a phone number using the voice dial feature See "Recording a Voice Name For a Phonebook Entry" on page 84.
Press  > Service Dial <i>> entry to call</i>	a service dial number programmed on the SIM card
Press  > Fixed Dial <i>> entry to call</i>	a fixed dial number
Press  > Recent Calls > Received Calls or Dialed Calls <i>> entry to call</i>	a missed call or a number from a call you recently dialed or received

Using Features While On a Call

Using Call Waiting



If you subscribe to call waiting, an alert tone sounds while you are on a call to indicate that you have received a second call.

To put the first call on hold and answer the second call:

Press	To
1 	answer the new call
2 SWITCH 	switch back to the first call

To end the first call and answer the second call:

Press	To
1 	end the current call Your phone rings to signal the new call.
2 	answer the new call

You must activate call waiting in order to use the feature. See the "Call Waiting" item on page 67.



Making a Conference Call



To talk to more than one person on a call, you can make a conference call. Call the first person, call the second person, then link the two calls.

Press	To
1 keypad keys	dial the first person's number
2 	call the number
3 HOLD () (if available) or  > Hold	put the first call on hold Your phone displays a  (flashing phone) indicator next to the call on hold.
4 keypad keys	dial the next person's number
5 	call the number Your phone displays a  (active call) indicator next to the new active call.
6 LINK ()	connect the two calls
7 	end the entire call

Transferring a Call

While you are on a call, you can transfer the call to another phone by first talking to the person who answers the other phone, or by directly transferring the call.

Announce the Call Transfer

You can talk to the person who answers the other phone before you transfer the call, to tell them whom you are transferring.

Find the Feature

 > Hold

Press	To
1 keypad keys	enter the phone number where you are transferring the call
2 	dial the phone number Speak to the person who answers the target phone.
3 	open the menu
4 	scroll to Transfer
5 SELECT ()	select Transfer
6 OK ()	confirm the transfer Your phone displays the message Transfer: Complete when the call is transferred.

Do Not Announce the Call Transfer

You can directly transfer a call without talking to the person who answers.

Find the Feature

 > Transfer



Press	To
1 keypad keys	enter the phone number where you are transferring the call
2 	dial the phone number Your phone displays the message Transfer: Complete when the call is transferred.

Additional On-Call Features

While you are on a call, you can perform the following tasks:

Do This	To
Press HOLD () (if available) or Press  > Hold	put a call on hold Your phone displays a  (flashing phone) indicator to indicate that the call is on hold.
Press SPEAKER () (if available) or Press  > Spkrphone On	activate an attached speakerphone (hands-free mode)
Press  > My Tel. Number	see your phone number

Using the Menu

Navigating to a Feature

You can access many of your phone's features by using these keys to move through the menu system:

Left Soft Key

Perform the function shown in the lower left corner of the display (usually **EXIT** or **BACK**).

Right Soft Key


Perform the function shown in the lower right corner of the display (usually **SELECT** the highlighted menu item).

Menu Key

Enter the menu system, or open a sub-menu, when  appears in the bottom center of the display.

End Key

Exit the menu system without making changes, return to the idle display.



4-Way

Navigation Key

Scroll up or down through menus and lists. Scroll **left** and **right** to cycle through and set the value of the highlighted menu item.



This guide shows you how to navigate to a specific menu feature as follows:


Find the Feature

 > Recent Calls
> Dialed Calls

The > symbol means that you should scroll to and select the feature. This example shows that you must press , scroll to and select **Recent Calls**, then scroll to and select **Dialed Calls** to see the dialed calls list.

Selecting a Feature Option

Some features require you to select an item from a list:



Using the Menu

Select an item by highlighting it. Use one of the following approaches:

- Press  to scroll up or down to the item you want.
- In a numbered list, press a number key to highlight the item.
- In an alphabetized list, press a key multiple times to cycle through the letters on the key and highlight the closest matching list item.

Entering Feature Information

Features such as the phonebook and datebook require you to enter information to fill in an entry's details:

Press  to scroll down to additional items.



Highlighted item

Press **CANCEL** () to exit without making changes. **DONE** () appears when you enter or edit information. Press **DONE** () to save your changes.

Press **CHANGE** () to edit the selected information.



- Enter numbers or text with the keypad. (See “Entering Text” on page 51.)
- When an item has a list of possible values, press  to the left or right to scroll through and select a value.
- When an item has a list of possible numeric values, press a number key to set the value.
- If you enter or edit information and then decide that you do not want to save your changes, press  to exit without saving.

The message center lets you compose and send text messages. (See “Entering Text” on page 51.) A *flashing cursor* shows you where the text will appear:

Flashing cursor indicates insertion point.



Press **BROWSE**  to view and insert a name, number, or message from previously stored information.

Press **CANCEL**  to exit without making changes.

Press  to open the sub-menu.

Using the Menu

When you enter text, the flashing cursor changes to a *block cursor*, and the soft key functions change:

Block cursor indicates current highlighted character.



Press **OK** (👁) to accept and store the text.

After two seconds, the block cursor reverts to a flashing cursor and moves to the next position.

Press **DELETE** (👁) to delete the character to the left of the insertion point.



Entering Text

General Text Entry Rules

Use the keypad to enter letters, numbers, and other characters. Press the same key repeatedly to cycle through available characters (see "Character Chart" on page 52):

Press a number key to enter text at flashing cursor location.

Press a number key as many times as necessary to enter the desired character.

Press and hold a number key to cycle between uppercase and lowercase characters.



Press joystick **up** or **down** to move flashing cursor up or down one line in text message, or change character in block cursor to uppercase or lowercase.

Press joystick **left** or **right** to move flashing cursor to the left or right in text message.

Using the Menu

- If you do not press a key for two seconds, the character in the block cursor is accepted, and the cursor moves to the next position.
- The first character of every sentence is capitalized unless you manually override it. (Hold the number key or press  down to force the character to lowercase while it is highlighted by the block cursor.)

Character Chart

Use this chart as a guide for entering spaces, numbers, letters, and other characters. Press and hold a key to cycle between uppercase and lowercase characters.

①	space . 1 ? ! , @ & : ; " - () ' ÿ i % £ \$ ¥ ¤
② ABC	a b c 2 ä å à α β ç
③ DEF	d e f 3 Δ é è Φ
④ GHI	g h i 4 Γ
⑤ JKL	j k l 5 Λ
⑥ MNO	m n o 6 ñ ö ø ò Ω
⑦ PQRS	p q r s 7 Π β Σ
⑧ TUV	t u v 8 Θ ü ù
⑨ WXYZ	w x y z 9 Ξ Ψ
⑩ +	+ - 0 x * / = > < # §



Predictive Text Entry with iTAP Software

iTAP™ software provides a predictive text entry method that lets you enter the letters of a word using only one keypress per letter.

Activating and Deactivating iTAP Software

You must activate iTAP software prior to entering letters. You can do this from any text entry screen by pressing  and selecting the **iTAP** menu option.

When you are finished using iTAP software, press  again from any text entry screen and select **TAP Method** to reset your phone to use the standard text entry method described on pages 51 and 52.

Entering Words

To enter a word:

Do This	To
1 Press a keypad key once	enter the first letter of the word The letters associated with the key you pressed are shown at the bottom of the display.
2 Press keypad keys (one per letter)	enter the rest of the word Alternative words and letter combinations are shown at the bottom of the display based on the keys you press. These word choices are updated with each keypress.

Using the Menu

Do This	To
3 When you have entered all the letters of the word, press 	locate and highlight the word you want
4 Press SELECT 	add the highlighted word to the text area at the top of the display A space is automatically inserted after the word.

For example, to spell the word "act," press   . The display shows:

Flashing cursor indicates insertion point.



Press  to scroll and see additional word choices.

Press **DELETE**  to clear the last letter entered.

Press **SELECT**  to insert the highlighted word at the insertion point.



Entering Novel Words

You may enter a word that is not in the iTAP software dictionary. If you enter all the letters of a word but the word is not displayed:

Do This	To
1 Press DELETE (🗑️) one or more times	delete one or more letters until you see a letter combination that matches the start of the word
2 Press ⬅️	highlight the letter or letter combination
3 Press SELECT (👁️), then press ⬅️ to the left	shift the text entry cursor to the left and “lock” the selected portion of the word
4 Continue entering letters and highlighting letter combinations	spell the word

Punctuation

The iTAP software automatically adds a space after each word. When you enter punctuation, this space is removed. To use punctuation:

Press	To
1 or 0+	enter punctuation or other characters as shown in the “Character Chart” on page 52

Capitalization

The first word of a sentence is automatically capitalized, with following words in lowercase. To set or adjust character capitalization:

Press	To
5  up or down	change the words to initial character capitalized, all uppercase characters, or all lowercase characters

Entering Numbers

To enter a number:

Do This	To
1 Enter the first digit and then highlight it	put the iTAP software in number entry mode
2 Press keypad keys	add digits to the number
3 Press SELECT ()	enter the number at the insertion point



Deleting Letters and Words

Place the cursor to the right of the text that you want to delete, and then do the following:

Do This	To
Press DELETE ()	delete one letter at a time
Continue to hold DELETE ()	delete the entire message

Menu Feature Descriptions

This chapter describes all of your phone's features in order of the menu map shown on pages 3–4. Some descriptions also include page numbers where you can find more detailed information.

If you would like to learn more about a specific feature, a reference guide for your phone is also available. To obtain a copy of the reference guide or another copy of this user guide, see the Motorola Web site at:

<http://motorola.com/consumer/manuals>

or contact the Motorola Customer Call Center at 1-800-331-6456.

Main Menu

RECENT CALLS

Received Calls



> Recent Calls
> Received Calls

View a list of recently received calls. See "Viewing the Received Calls or Dialed Calls List" on page 73.

Dialed Calls



> Recent Calls
> Dialed Calls

View a list of recently dialed calls. See "Viewing the Received Calls or Dialed Calls List" on page 73.



Notepad

 > Recent Calls
> Notepad

Call or store the last number entered on the keypad. See "Entering Numbers in the Notepad" on page 36, and "Using the Notepad" on page 76.

Call Times

 > Recent Calls
> Call Times

View call timers that track time spent on your last call, dialed calls, received calls, all calls since reset, and all calls total. See "Call Times and Costs" on page 77.

Call Cost

 > Recent Calls
> Call Cost

View call cost information. Your network may provide current credit information, and can provide cost information about the amount spent on your last call, dialed calls, received calls, and all calls total. See "Call Times and Costs" on page 77.

SERVICE DIAL

 > Service Dial

Dial pre-programmed numbers stored on your SIM card. Your service provider can program your SIM card with phone numbers for services such as taxi companies, restaurants, and hospitals.



FIXED DIAL

 > Fixed Dial

Dial or edit numbers in the fixed dial list.

When you activate the fixed dial feature, users can only call the numbers in the fixed dial list. To activate fixed dial, see the "Fixed Dial" item on page 68.

Menu Feature Descriptions

Fixed dial list entries can be any length. If there is a fixed dial entry for the digits 555, users can call any number that starts with 555.

You must enter your SIM PIN2 code to edit fixed dial entries. In the fixed dial list, you can create, edit, delete, and sort entries just like with the phonebook list. Fixed dial list entries are stored on your SIM card and do not have **Type** or **Voice Name** fields.

Note: Employers can use fixed dial to limit employees' phones to a predefined list of numbers, country codes, or other prefixes.

PHONEBOOK

 > Phonebook

Store names and numbers as entries in your phonebook, then call numbers by selecting them from the phonebook list. See "Phonebook" on page 81.

DATEBOOK

 > Datebook

Use the datebook calendar to schedule and review your appointments. See "Datebook" on page 94.

QUICK DIAL

 > Quick Dial

Dial pre-programmed numbers stored on your phone. Your service provider may program your phone with one or more quick dial numbers, such as the customer service number. You can call them by selecting them from the quick dial list.

Note: Your service provider may use a different name for this feature.





RADIO

 > **Radio**

Listen to FM radio stations with the optional Motorola Original™ FM Stereo Radio Headset accessory. This menu feature is displayed only when the FM Stereo Radio Headset is plugged into the accessory connector port on your phone. See "Radio" on page 101.



MESSAGES

 > **Messages**

Adjust message settings, view and manage the various types of messages your phone can receive and/or send:



Vicemail

Listen to your recorded voice messages. See "Messages—Vicemail" on page 105

Text Msgs

Send and receive text messages. See "Messages—Text" on page 107

Browser Alerts

Read alert messages received by your micro-browser

Quick Notes

Select and send pre-written messages from the quick notes list

Outbox

View all outgoing text messages, delivered and undelivered

Drafts

Store and edit text messages that you have written but not sent

SHORTCUTS

 > **Shortcuts**

Create keypad or voice shortcuts to menu features. See "Shortcuts" on page 115.

Menu Feature Descriptions

VOICE NOTES



> Voice Notes

Use the voice key to record messages and phone calls. See "Voice Notes" on page 119.

SIM APPLICATIONS



> SIM Applications

Access information and applications stored on your SIM card.

Your SIM card may contain applications that process your outgoing calls, text messages, and other events. Contact your service provider for details.



BROWSER



> Browser

Access Web pages and run Web-based applications. The micro-browser delivers WAP (Wireless Application Protocol) pages from your service provider directly to your phone. See "Micro-Browser" on page 126.



CALCULATOR



> Calculator

Use your phone as a calculator or currency converter. See "Calculator" on page 128.

GAMES



> Games

Play games on your phone. See "Games" on page 131.



Settings Menu

RING/VIBRATE

Alert

-  > Settings
- > Ring/Vibrate
- > Alert

Select a type of ring or vibration alert for incoming calls and messages. See “Ring/Vibrate” on page 136.

Alert Detail

-  > Settings
- > Ring/Vibrate
- > Alert Detail

Change details about the ring or vibration alert. *Alert* represents the name of the current alert setting. See “Ring/Vibrate” on page 136.

CALL FORWARD

-  > Settings
- > Call Forward

Set options for forwarding incoming voice, data, and/or fax calls to another phone number. See “Call Forwarding” on page 143.

PHONE STATUS

My Tel. Number

-  > Settings
- > Phone Status
- > My Tel. Number

View, enter, and edit your name and phone number.

Credit Available

-  > Settings
- > Phone Status
- > Credit Available

Advice-of-charge users can view the credit available.

Menu Feature Descriptions

Credit Info

-  > Settings
- > Phone Status
- > Credit Info



Prepay users can view current credit information.

If you use a prepay option, you can view the credit available, its expiration date, and the date of the last deposit.

Battery Meter

-  > Settings
- > Phone Status
- > Battery Meter

View a detailed battery charge meter.

Phone: Line 1/2

-  > Settings
- > Phone Status
- > Phone: Line 1/2



Change the active phone line (on dual-line phones) to send or receive calls from either of the available numbers.

Other Information

-  > Settings
- > Phone Status
- > Other Information

View your phone's feature specifications (if available from the service provider).

CONNECTION

Connect your phone to a computer or hand-held device to send and receive data and fax calls on the connected device. See "Data and Fax Calls" on page 151.





IrDA Link

 > Settings > Connection
> IrDA Link

Set up a wireless infrared connection. See “Establish an Infrared Connection” on page 153.

Incoming Call

 > Settings
> Connection
> Incoming Call

Specify the format for the next incoming call. You can select **Fax In Only**, **Data In Only**, or **Normal**. See “Receiving a Data or Fax Call” on page 156.

IN-CALL SETUP

Set the features that are active during a call, such as the in-call timer, **cost trackers**, **call waiting**, and call answering options.

In-Call Timer

 > Settings
> In-Call Setup
> In-Call Timer

Adjust call timer display and beep settings. You can set your timer to beep at a selected interval during your calls. (60 seconds is the default.) You can also turn on or off a display timer during calls as follows:

Time

Display the elapsed time for the current call

Cost

Display the cost of the current call (if you subscribe to call cost features or advice-of-charge)

Menu Feature Descriptions

Total Cost Display the cost of all calls since the last time you reset the timer (if you subscribe to call cost features or advice-of-charge)

Credit Available Display how much credit you have left (if you subscribe to call cost features or advice-of-charge)

Off No in-call timer display

Call Cost Setup

 > **Settings**
> **In-Call Setup**
> **Call Cost Setup**

Adjust call cost settings.

You can assign a credit limit so that your phone displays your remaining credit during calls. Your phone notifies you when you approach your limit, and ends the call when you reach it.

Your phone network expresses cost in the amount of units used, but this feature lets you tell your phone how to translate the units to a currency.

My Caller ID

 > **Settings**
> **In-Call Setup**
> **My Caller ID**

Activate and deactivate the display of your phone number as an ID when you call someone.

Talk and Fax

 > **Settings**
> **In-Call Setup**
> **Talk and Fax**

Activate and deactivate the talk/fax service.



Use this feature prior to making a call when you want to talk and then send or receive a fax—all to the same phone number and within the same call.

You can also use the talk then fax feature to send a fax during a call. See “Sending a Talk then Data or Talk then Fax Call” on page 159.

Answer Options



> Settings
> In-Call Setup
> Answer Options

Turn call answering options on or off:

Multi-Key

Answer by pressing any key

Call Waiting



> Settings
> In-Call Setup
> Call Waiting



Activate and deactivate call waiting.

When call waiting is activated and another call arrives while you are on a call, call waiting can play a tone to notify you of the new call. See “Using Call Waiting” on page 42.

SECURITY

Phone Lock



> Settings > Security
> Phone Lock

Lock and unlock your phone. See “Locking and Unlocking Your Phone” on page 162.

Lock Keypad



> Settings > Security
> Lock Keypad

Lock and unlock your keypad. See “Locking and Unlocking Your Keypad” on page 164.

Menu Feature Descriptions

Lock Application



> Settings > Security
> Lock Application

Lock and unlock specific phone applications (such as phonebook or datebook). When an application is locked, users must enter the unlock code to use the application.

Fixed Dial



> Settings > Security
> Fixed Dial

Restrict outgoing calls to numbers on the fixed dial list. See "Fixed Dial" on page 59.

Call Barring



> Settings > Security
> Call Barring

Restrict incoming and outgoing calls. See "Barring Calls" on page 164.

SIM PIN



> Settings > Security
> SIM PIN

Switch protection on and off, so users must enter the SIM PIN code when they turn on the phone or insert a SIM card. See "Protecting the SIM Card" on page 165.

New Passwords



> Settings > Security
> New Passwords

Change your unlock code (originally set to 1234) or your security code (originally set to 000000). See "Assigning a New Code or Password" on page 160.



OTHER SETTINGS

Personalize

 > Settings
> Other Settings
> Personalize

Set several personal phone options:

Main Menu Change the order of the main menu.
(See "Reordering Menu Items" on page 146.)

Keys Change the functions of the soft keys in the idle display. (See "Customizing a Soft Key Function" on page 146.)

Greeting Change the text displayed when you turn on your phone

Banner Change the text that appears in the idle display

Quick Dial Change quick dial number(s)

Initial Setup

 > Settings
> Other Settings
> Initial Setup

Set many basic phone options:

Time and Date Set the phone's time and date

One-Touch Dial Assign the one-touch dial feature to numbers 2 through 9 in your phone memory phonebook, fixed dial list, or SIM card phonebook. (See "One-Touch Dial Preference" on page 93.)

Menu Feature Descriptions

Auto Redial	Automatically redial calls that fail due to busy network conditions. (See "Using Automatic Redial" on page 33.)
Backlight	Set the amount of time that the display backlight remains on, or turn off the backlight to conserve battery power
Zoom	Switch between six lines (Zoom Out) and four lines (Zoom In) of display text
Scroll	Force the cursor to stop or wrap around when it reaches the top or bottom of a list in the display
Language	Set the language for phone menus
Preferred Card	Set the preferred SIM card
Battery Save	Adjust the phone's power usage characteristics to conserve power
Contrast Setting	Adjust the contrast setting for your display
Master Reset	Reset all options back to their original factory settings <i>except</i> for the unlock code, security code, and lifetime timer



Master Clear

Reset all options back to their original factory settings *except* for the unlock code, security code, and lifetime timer, *and* clear all user settings and entries *except for information on the SIM card*

This option *erases all user-entered information* stored in your phone's memory, including phonebook and datebook entries. Once you erase the information, it cannot be recovered.

Network

-  > Settings
- > Other Settings
- > Network

View and adjust your phone's network settings.

Your service provider registers your phone to a network. You can view information about the current network, change how your phone searches for a network, and turn on/off alerts that indicate when a call is dropped or network registration changes.

Car Settings

-  > Settings
- > Other Settings
- > Car Settings



Adjust hands-free car kit settings.

You can set your phone to route calls directly to the car kit when it detects a connection, and automatically answer calls after two rings. See "Hands-Free Use" on page 147.

Headset



- > Settings
- > Other Settings
- > Headset



Set your phone to automatically answer calls after two rings when connected to a headset. See "Hands-Free Use" on page 147.

PRELIMINARY

Recent Calls



You can use the recent calls menu to view received calls or dialed calls, retrieve the last number stored in the notepad, and view or reset call times [and costs](#).

Viewing the Received Calls or Dialed Calls List

Your phone keeps lists of the numbers from calls you recently received and dialed, even if the calls did not connect. The lists are sorted from newest to oldest entries. The oldest entries are deleted as new ones are added. Each entry tells you the person's number (or name, if available) and whether the call connected or not. You can call, store, or delete the numbers on these lists.

Shortcut: Press to go directly to the dialed calls list from the idle display.

To open the recent calls menu:

Find the Feature



> Recent Calls

Press	To
1	scroll to Received Calls or Dialed Calls
2 SELECT (	select Received Calls or Dialed Calls

Recent Calls

Press	To
3 	scroll to an entry you want to call, store, or delete Note:  means the call connected.
4  or  or 	call the entry's number view the entry's details if View appears above the  key, or store the entry's details in the phonebook if Store appears above the  key open the Last Calls Menu to perform other procedures as described in the following list



The **Last Calls Menu** includes the following options:

Option	Description
Store	Create a phonebook entry with the selected number in the No. field. (This option is not available if STORE appears above the  key, or if the number is already stored as a phonebook entry.)
Delete	Delete the entry. (This option is not available if DELETE appears above the  key.)
Delete All	Delete all entries in the current list.
Hide ID/Show ID	Hide (or show) your caller ID for the next call.
Send Message	Create a new text message, with the selected number in the Tel No. field. See “Sending a New Text Message” on page 111.
Add Digits	Add digits to the end of the selected number.
Attach Number	Attach another number from the phonebook or recent calls list to the end of the selected number.
Talk then Fax or Talk then Data	Tell the network you want to call and talk to someone, and then send data or a fax—all to the same number in the same call. See “Sending a Talk then Data or Talk then Fax Call” on page 159.

Using the Notepad

Your phone uses a notepad to store the most recent string of digits entered—either for a phone number that you called or for a number that you entered but did not call.

To call the number stored in the notepad, press  from the idle display.

To create a phonebook entry or perform other operations with the number:

Find the Feature



> Recent Calls
> Notepad

Press



To

open the **Dialing Menu** (to attach a number or insert a special character). See “Additional Dialing Features” on page 40.

or

STORE 

create a new phonebook entry, with the notepad number copied into the **No.** field. See “Storing a Phonebook Entry” on page 82.



Call Times and Costs

Your phone tracks and records call times and costs. Use the recent calls menu to view and reset a call timer or cost tracker.

Network connection time is the elapsed time from the moment you connect to your service provider's network to the moment you end the call by pressing . This time includes busy signals and ringing.

The amount of network connection time you track on your resettable timer may not equal the amount of time for which you are billed by your service provider. For billing information, please contact your service provider directly.

You can view the approximate network connection time elapsed and cost incurred during the following calls:

Timer	Description
Last Call	Time spent on the last call dialed or received. You cannot reset this timer.
Dialed Calls	Total time spent on dialed calls since the last time you reset this timer.
Received Calls	Total time spent on calls received since the last time you reset this timer.
All Calls	Total time spent on dialed and received calls since the last time you reset this timer.
Lifetime	Total time spent on all calls on this phone. You cannot reset this timer.

Recent Calls

Your phone network can provide the following cost information:

Cost Tracker	Description
Credit Available	Amount of your credit remaining.  For GSM advice of charge, this is only available if you set a credit limit. Note: Your phone receives cost information from the GSM advice of charge feature or third-party prepay software.
Expiration Date	Date that the available credit expires (only available with third-party software).
Last Deposit	Amount of the last deposit (only available with third-party software).
Last Call	Amount spent on the last call you dialed or received. You cannot reset this cost tracker.
Dialed Calls	Amount spent on calls you dialed since the last time you reset this cost tracker.
Received Calls	Amount spent on calls you received since the last time you reset this cost tracker.



Cost Tracker	Description
All Calls	Amount spent on all dialed and received calls since the last time you reset this cost tracker. You can reset this value separate from Dialed Calls and Received Calls, so Dialed Calls plus Received Calls may not equal All Calls.

Viewing and Resetting Call Times **and** Costs

To view a call timer **or** cost tracker:

Find the Feature



> Recent Calls

Press	To
1	scroll to Call Times or Call Cost
2 SELECT (	open the list of timers or cost trackers
3	scroll to the timer or cost tracker you want
4 SELECT (	view the recorded time or cost

Recent Calls

To reset the call timer [or cost tracker](#):

Press	To
1 RESET (👁)	reset the time or cost (if available)
2 <i>for a timer:</i> YES (👁)	confirm the reset
<i>for a cost tracker:</i> keypad keys and OK (👁)	enter your PIN2 code to confirm the reset


Phonebook



You can store a list of names and phone numbers in your phone's electronic phonebook. You can view these entries and call them directly from your phone.

To see the list of names stored in your phonebook, press **MENU** > **Phonebook** from the idle display. Scroll to a name and press **VIEW** (👁️) to view details of the phonebook entry as shown in the following display.

Fields in a Phonebook Entry Form



Note: Numbers stored on the SIM card do not have **Type** or **Voice Name** information.

Storing a Phonebook Entry

A phone number is required for a phonebook entry. All other information is optional.

Shortcut: Enter a phone number in the idle display, then press **STORE** (Ⓢ) to create a phonebook entry with the number in the **No.** field. Go directly to step 1 in the following procedure to enter additional information and store the entry.

Note: You can also use the following procedure to store a fixed dial entry by scrolling to and selecting **Fixed Dial**.

Enter Information

Find the Feature



> Phonebook



> New

Press	To
1 CHANGE (Ⓢ)	select Name
2 keypad keys	enter a name for the phonebook entry (See "Entering Text" on page 51.)
3 OK (Ⓢ)	store the name
4 CHANGE (Ⓢ)	select No.
5 keypad keys	enter the phone number



Press	To
6 OK (⏎)	store the phone number
7 CHANGE (⏎)	select Type <i>(not available for entries stored on a SIM card)</i>
8 ⬅➡	scroll to the type of phone number
9 SELECT (⏎)	select the number type
10 RECORD (⏎) or Go to step 11 if you do not want to record a voice name for the entry	record a voice name for the entry, if desired <i>(not available for entries stored on a SIM card)</i> See "Recording a Voice Name For a Phonebook Entry" on page 84.
11 ⬅➡	scroll to Speed No. , the number to "speed dial" the entry The next available speed dial number is assigned to a new phonebook number by default.
12 CHANGE (⏎)	select Speed No. if you want to change it
13 keypad keys	enter a different speed number, if desired
14 OK (⏎)	save the modified speed number If your chosen speed number is already assigned to another entry, you are asked if you want to replace that entry.

Press	To
15 SELECT (👁)	select MORE if you want to create another entry with the same Name Note: You must enter a name and number to use this option.

Complete Phonebook Entry

When you are finished entering information for a phonebook entry:

Press	To
DONE (👁)	store the entry and return to the phonebook list

Recording a Voice Name For a Phonebook Entry

You can record a voice name when you create a new phonebook entry, or when you edit a previously stored phonebook entry. This lets you use voice dial to call the number without dialing (see “Voice Dial” on page 86).

Note: You cannot record a voice name for an entry stored on a SIM card.



Tip: Make your voice recording in a quiet location. Hold the phone about four inches (10 centimeters) from your mouth, and speak directly into the phone's microphone in a normal tone of voice.

Find the Feature



> Phonebook

Do This	To
1 Press	scroll to the entry that needs a voice name
2 Press VIEW ()	display the entry's detailed view
3 Press EDIT ()	edit the phonebook entry
4 Press	scroll to Voice Name
5 Press RECORD ()	begin the recording process The phone displays Press Voice key then say name.
6 Press and release the voice key on the right side of your phone and say the entry's name (in two seconds)	record the voice name The phone displays Press Voice Key then REPEAT name.
7 Press the voice key and repeat the name	confirm the voice name The phone displays Trained: Voice Name.

Dialing a Phonebook Entry

You can use the phonebook list, voice dial, speed dial, or one-touch dial to call the numbers stored in your phonebook. To use speed dial, see “Dialing With Speed Dial” on page 37. To use one-touch dial, see “Dialing With One-Touch Dial” on page 38.

Phonebook List

To call a number from the phonebook list:

Find the Feature



> Phonebook

Press	To
1 	scroll to the entry you want to call
2 	send the call

Voice Dial

To call a number using voice dial:

Do This	Result
Press and release the voice key on the right side of your phone and say the entry's name (in two seconds).	Your phone goes to the entry in the phonebook list, plays back the voice name stored with the phonebook entry, waits two seconds, then automatically dials the call.



Editing a Phonebook Entry

Find the Feature



> Phonebook

Press	To
1	scroll to the entry you want to edit
2 VIEW (	display the entry's detailed view
3 EDIT (	edit the phonebook entry

Edit a phonebook entry by following the procedures described in "Storing a Phonebook Entry" on page 82.

Deleting a Phonebook Entry

To delete a phonebook entry:

Find the Feature



> Phonebook

Press	To
1	scroll to the entry you want to delete
2	open the Phonebook Menu
3	scroll to Delete
4 SELECT (	select Delete
5 YES (	confirm the deletion

Copying Phonebook Entries to a SIM Card

You can copy one or more entries from your phonebook list to a SIM card. This lets you free up infrequently used speed dial numbers.

Note: The SIM card cannot store **Type** and **Voice Name** data for entries. If you try to copy an entry with a type or voice name to the SIM card, the phone asks you for confirmation before dropping this information and copying the entry.

Copy a Single Entry

To copy a single phonebook entry from your phone to your SIM card:

Find the Feature



> Phonebook

Press	To
1	scroll to the entry you want to copy
2	open the Phonebook Menu
3	scroll to Copy Entry
4 SELECT	select Copy Entry The phone displays the Copy To dialog, with the next available speed dial number.



Press	To
5 keypad keys	edit the speed dial number, if necessary Change the speed dial number in the Copy To dialog by entering a new number on the keypad.
6 OK (↵)	approve the copy to the speed dial number The phone displays the Stored notification. You can now delete the old phonebook entry.

Copy Multiple Entries

To copy multiple phonebook entries from your phone to your SIM card:

Find the Feature



> Phonebook

Press	To
1	open the Phonebook Menu
2	scroll to Copy Entries
3 SELECT (↵)	select Copy Entries The phone displays the Copy Entries dialog.
4	scroll to From (start)
5 CHANGE (↵)	select From (start)

Press	To
6 keypad keys	enter the first (lowest) speed dial number in the range of entries that you want to copy
7 OK (⏎)	store the number and return to the Copy Entries dialog
8 ⬅➡	scroll to From (end)
9 CHANGE (⏎)	select From (end)
10 keypad keys	enter the last (highest) speed dial number in the range of entries that you want to copy
11 OK (⏎)	store the number and return to the Copy Entries dialog
12 ⬅➡	scroll to To
13 CHANGE (⏎)	select To
14 keypad keys	enter the first (lowest) new speed dial number for the entries' new location
15 OK (⏎)	store the number and return to the Copy Entries dialog
16 DONE (⏎)	copy the entries The phone displays the Copied Entries message. You can now delete the old entries.



Checking Phonebook Capacity

You can check your phonebook's capacity to see how many entries you have used and how many more are available. Since you can store phonebook entries on both your phone and your SIM card, you can check either your phone's capacity or your SIM card's capacity.

To check the phonebook capacity for your phone or SIM card:

Find the Feature



> Phonebook

Press	To
1	open the Phonebook Menu
2	scroll to Ph Book Capacity or SIM Capacity
3 SELECT	select Ph Book Capacity or SIM Capacity The phone displays the number of entries that are in use and the number that are empty.

Synchronizing with TrueSync Software



You can synchronize phonebook entries between your phone and computer or hand-held device with TrueSync[®] software, a Motorola accessory product. See the TrueSync user guide for more information.

Setting Up the Phonebook

You can specify the sort order for your phonebook entries and the location of your one-touch dial entries.

Phonebook List Sort Preference

You can set up your phone to sort your phonebook list by speed dial number (the standard), name, or voice dial.

Tip: The voice dial sort is identical to the name sort, except that the entries with voice name tags appear first.

Find the Feature



> Phonebook

Press	To
1 	open the Phonebook Menu
2 	scroll to Setup
3 SELECT ()	select Setup
4 	scroll to Sort by
5 CHANGE ()	select Sort by
6 	scroll to the entry you want
7 SELECT ()	select the entry you want



One-Touch Dial Preference

Your phone lets you specify whether your one-touch dial entries are located in the phone memory, the fixed dial list, or your SIM card:

Find the Feature



> Phonebook

Press	To
1	open the Phonebook Menu
2	scroll to Setup
3 SELECT ()	select Setup The phone displays the Phonebook Setup form.
4	scroll to One-Touch Dial
5 CHANGE ()	select One-Touch Dial
6	scroll to the list you want
7 SELECT ()	select the list you want

Datebook

The datebook is a calendar that lets you schedule and organize events such as appointments and meetings. You can review your schedule of events for the week or by the day, and have the datebook play a reminder alarm for specific events. To schedule or see events:


Find the Feature

 > **Datebook**

The datebook is organized by *views*—from the week view, to the day view, to a view of a specific event.

Week View

When you open the datebook, your phone displays a calendar for the week. Lines or filled boxes under each day indicate that events have been scheduled.






Day View

Select a day in the week view and press **VIEW** (👁) to see the day's events. You can store, edit, view, copy, and delete any event from the day view.



Event View

Select an event in the day view and press **VIEW** (👁) to open the detailed event view. You can edit, copy, and delete events from the event view.





Storing a New Event

A title is required for a datebook event. All other information is optional.

Find the Feature

 > **Datebook** > *day*
 > **New**

See "Selecting a Feature Option" on page 47 for instructions on scrolling to and selecting options.

Press	To
1 CHANGE ()	select Title
2 keypad keys	enter a title for the event (see "Entering Text" on page 51.)
3 OK ()	store the event title
4 	scroll to other fields and enter information as necessary Other fields let you enter start time, duration, date, repeating events, and reminder alarm.
5 DONE ()	store the new event and return to the day view

Changing Event Information

To change information about an existing event:

Find the Feature



> Datebook

Press	To
1  left or right	scroll to the scheduled event day
2 VIEW ()	display the day view
3 	scroll to the event you want to change
4 VIEW ()	display the event view
5 EDIT ()	edit the event
6 	scroll to the detail you want to change
7 CHANGE ()	edit the information
8 keypad keys	enter the new information
9 DONE ()	store the information and return to the day view



Copying an Event

To copy information from a current event to a new event:

Find the Feature



> **Datebook**

Press	To
1 ◀▶ left or right	scroll to the scheduled event day
2 VIEW (👁)	display the day view
3 ◀▶	scroll to the event to copy
4 	open the Datebook Menu
5 ◀▶	scroll to Copy
6 SELECT (👁)	copy the event
7 YES (👁)	confirm the copy
	Your phone assumes that you want to change the date, and displays the Date field.
8 keypad keys	enter the date information
9 ▶ (👁)	move to the month, day, and year
or ◀▶ to the right	
10 DONE (👁)	save the copy of the event
11 DONE (👁)	return to the day view

Deleting an Event

Find the Feature

 > Datebook

Press	To
1  left or right	scroll to the scheduled event day
2 VIEW ()	display the day view
3 	scroll to the event to delete
4 	open the Datebook Menu
5 	scroll to Delete
6 SELECT ()	select Delete For non-repeating events, go to step 7. For repeating events, the phone displays a delete event menu: a  scroll to This Event Only or Repeat Events b SELECT () select the event(s) to delete
7 YES ()	confirm the deletion The phone briefly displays a Deleted : message and returns you to the day view.



You can use your phone to tune, store presets, and listen to FM radio stations when the optional Motorola Original™ FM Stereo Radio Headset accessory is plugged into the phone's accessory connector port.

Turning the Radio On and Off

Press	To
Radio (👁)	turn the radio on and off

Alternatively, you can use the following procedure:

Press	To
1	open the menu
2	scroll to Radio
3 On (👁) or Off (👁)	turn the radio on or off

Note: The **Radio** (👁) soft key option and **Radio** menu feature are displayed only when the FM Stereo Radio Headset is plugged into the accessory connector port.

Tuning a Station

To tune a radio station with the radio on:

Do This	To
Press ◀◀▶▶	scroll up or down to the next frequency
or	
Press and hold ◀◀▶▶	scroll up or down to the next available stereo station

Storing a Preset

To store a station to a preset that you can recall later:

Do This	To
Press and hold a number key (1 to 9WXTZ)	assign its preset number to the tuned station

Selecting a Preset

To select a preset radio station:

Press	To
a number key (1 to 9WXTZ)	tune the station stored at that preset location



Sending and Receiving Calls With the Radio On

Your phone interrupts the radio signal and rings or vibrates as usual to notify you of an incoming call, message, or other event. When you receive a call:

Do This	To
Press IGNORE (👁)	ignore the call
Press ANSWER (👁) or Press the button on the FM Stereo Radio Headset microphone	answer the call Note: You can use the FM Stereo Radio Headset microphone to converse with the other party during a call

To end the call and resume the FM broadcast:

Do This	To
Press (⌂) or Press and hold the button on the FM Stereo Radio Headset microphone	end the call

Turn the radio off before dialing outgoing calls from the phone keypad. You do not have to turn off the FM radio feature to dial emergency numbers, or numbers selected from your phonebook or other lists.

Tip: To dial a recently called number, press  or the button on the FM Stereo Radio Headset microphone to go to the dialed calls list. For more information, see “Recent Calls” on page 73.



Messages—Voicemail



You can listen to your voicemail messages by calling your network voicemail phone number. Voicemail messages are stored on the network—not on your phone. Contact your service provider for more details.

Storing Your Voicemail Number

Store your voicemail number in your phone to make it faster and easier to use voicemail. Your voicemail number is provided by your service provider.

Find the Feature



> Messages



> VoiceMail Setup

Press	To
1 keypad keys	enter the phone number for your voicemail
2 OK (⏏)	store the number

Receiving a New Voicemail Message

When you receive a voicemail message, your phone displays **New VoiceMail** . (Some networks only indicate when you have messages, whether they are new or not.) If reminders are turned on, your phone sends a reminder every five minutes until you close the new message notification, listen to the message, or turn off your phone. (See “Reminders” on page 143.)

Messages—Voicemail

From the new message notification:

Do This	To
Press CALL (📞)	call your voicemail phone number and listen to the message

Listening to a Voicemail Message

To listen to your voicemail messages at any time:

Find the Feature



> **Messages** > **VoiceMail**

Your phone calls the voicemail phone number you stored. If you do not have a voicemail number stored, the phone guides you through storing a number.



Messages—Text



Text messages are brief messages that you can send and receive (such as **Where are we meeting?**). Received messages appear on your phone display or in your text message inbox.

You must set up the text message inbox *before* you can send and receive these messages. The total number of messages the inbox can hold depends on the length of the messages, and the number of other messages and drafts stored in your phone.

Setting Up the Text Message Inbox

Find the Feature



> Messages



> Text Msg Setup

Press	To
1	scroll to Srvce Center No.
2 CHANGE (	change the Srvce Center No. which is provided by your service provider
3 keypad keys	enter the phone number for the service center that handles your outgoing messages
4 OK (	store your service center number
5 CHANGE (	change the Expire After period

Messages—Text

Press	To
6 keypad keys	enter the expiration period—the number of days your network tries to send unreceived messages
7 OK (↵)	store the expiration period
8 CHANGE (↵)	change the Reply Type
9 ↻	scroll to the default type of replies you want to send— text messages, faxes, or other formats
10 SELECT (↵)	store the reply type
11 CHANGE (↵)	change the Cleanup setting
12 ↻	scroll to the period of time that messages stay in your inbox
13 SELECT (↵)	select the cleanup period If you select Custom , continue. Otherwise, the procedure is complete.
14 ↻	change the entry for the number or label
15 ↻ left or right	switch between the number and the label
16 DONE (↵)	store the custom cleanup period after you finish entering all information



Receiving a New Text Message

Note: You must set up the text message inbox before you can receive text messages.

When you receive a new message, your phone displays **New Message**  and gives an alert. If reminders are turned on, your phone sends a reminder every five minutes until you close the new message notification, read the message, or turn off your phone. (See “Reminders” on page 143.)

When your inbox is full, any new message replaces the oldest unlocked message.

From the new message notification:

Press	To
READ ()	open the message (or your text message inbox if there are multiple messages)

Reading, Locking, or Deleting a Text Message

You can open your text message inbox to read, lock, or delete messages at any time.

Messages in the text message inbox are sorted from newest to oldest. The oldest messages are deleted as new ones are added.

Messages—Text

If you want to save a message, you should lock it to prevent it from being overwritten as new messages are received.

Find the Feature



> Messages > Text Msgs

Press	To
1	scroll to the message you want (= unread and urgent, = read, = read and locked)
2 READ ()	open the message
3 SAVE ()	close the message without changes
or DELETE ()	delete the message
or 	open the Text Msg Menu to perform other procedures as described in the following list

The **Text Msg Menu** includes the following options:

Option	Description
Call Back	Call the number in the message header or the message text.
Go To	Go to a Web address (URL) in the message.



Option	Description
Reply	Open a new text message, with the message's Reply To number in the To field.
Forward	Open a copy of the text message, with an empty To field
Lock/Unlock	Lock or unlock the message.
Delete or Delete All	Delete the message or all inbox messages. Press Yes (✓) to confirm the deletion.
Store Number	Open a new phonebook entry with the message's embedded number in the No. field.
Create Message	Open a new text message form.
Setup	Open the inbox setup menu.

Sending a New Text Message

To create and send a new text message:

Find the Feature



> **Messages** > **Text Msgs**

> **Create Message**

Press

To

1 CHANGE (✓)

select **To**

Messages—Text

Press	To
2 keypad keys	enter the phone number where you want to send the message
3 OK (⏎)	store the number
4 CHANGE (⏎)	select Msg
5 keypad keys	enter the text message (see “Entering Text” on page 51.)
6 OK (⏎)	store the text message
Note: Message length is limited. When 40 or fewer characters remain, a two-digit counter at the top of the display shows how many are left.	
7 CHANGE (⏎)	select Priority
8 ⏮⏭	scroll to the priority you want
9 SELECT (⏎)	set the priority
10 CHANGE (⏎)	select Call
11 keypad keys	enter the number you want your recipient to call back (the message’s From field)
12 OK (⏎)	store the number
13 CHANGE (➡)	select Receipt



Press	To
14 	select whether you want the message status to be updated when the recipient opens the message Note: Sent messages are stored in your phone's outbox. See "Viewing the Status of Sent Text Messages" on page 114.
15 OK ()	store your receipt preference
16 DONE ()	finish the message Your phone displays Send Message Now?
17 YES () or NO ()	send the message cancel the message or save it as a draft

Viewing the Status of Sent Text Messages

Text messages that you send are stored in the outbox. To view the contents of your outbox:

Find the Feature



> Messages > Outbox

Messages are sorted from newest to oldest.

The following icons indicate message status:

» = Sending in progress

✕ = Sending failed

Shortcuts



Your phone includes several pre-programmed shortcuts. You can create additional shortcuts, if you like, to mark frequently used menu items.

Standard Shortcuts

The following shortcuts are pre-programmed in your phone. You cannot edit or delete these shortcuts.

Do This	To
Press  , then press and hold  (within two seconds)	zoom in/out your phone's display view (See "Changing the Zoom Setting" on page 30.)
Press  	lock/unlock your keypad
Press  	display your phone number
Press 	go to the dialed calls list (See "Recent Calls" on page 73.)

User-Settable Shortcuts

You can create shortcuts to many menu features and applications. A shortcut takes you directly to the menu item, or performs the menu action (if applicable).

Creating a Shortcut

You can assign a keypad shortcut, or both a keypad shortcut *and* a voice shortcut to a menu item.

A voice shortcut lets you go directly to a menu item by saying its shortcut name.

Tip: Make your voice recording in a quiet location. Hold the phone about four inches (10 centimeters) from your mouth, and speak directly into the phone's microphone in a normal tone of voice.

Do This	To
1 Press 	enter the menu system
2 Scroll to the item to which you want to assign a shortcut	highlight the menu item
3 Press and hold 	open the shortcut editor The phone displays: Assign Shortcut for: <i>"Item"?</i> where <i>Item</i> is the name of the item you selected.
4 Press YES ()	view shortcut options



Do This	To
5 Press CHANGE (👁️) or Press DONE (👁️) or Press ⏮️	change the keypad shortcut number, if necessary select the default keypad shortcut number and close the shortcut editor if you do not want to assign a voice shortcut scroll to Voice if you want to assign a voice shortcut
6 Press RECORD (👁️)	begin the recording process The phone displays Press Voice key then say voice shortcut.
7 Press and release the voice key on the right side of your phone and say the shortcut's name (in two seconds)	record the shortcut name The phone displays Press Voice key then REPEAT voice shortcut.
8 Press and release the voice key and repeat the name	confirm the shortcut name The phone displays Trained: Voice Shortcut
9 Press DONE (👁️)	close the shortcut editor

Using Shortcuts

You can use a shortcut from the idle display, while on a call, or while scrolling through a menu.

Use a Keypad Shortcut

If you know the shortcut number:

Press	To
1 	open the menu
2 the shortcut's number	go to the menu item, or perform the menu action

Select a Shortcut From the List

To select a shortcut from the shortcut list:

Find the Feature



> **Shortcuts**

> *the shortcut you want*

Use a Voice Shortcut

To use a voice shortcut:

Do This	To
1 Press 	open the menu
2 Press and release the voice key on the right side of your phone and say the shortcut's name (in two seconds)	go to the menu item, or perform the menu action



Voice Notes

The voice note feature lets you record personal messages or phone calls. You can play back a voice note at any time. There are no pre-recorded voice notes on your phone.

Recording a Voice Note

Use this procedure to record a voice note when the idle display is visible, or use it during a phone call to record the call. Your phone plays an alert tone to notify the other party that the call is being recorded.

Note: Recording phone calls is subject to varying state and federal laws regarding privacy and recording of conversations.

Tip: Make your voice recording in a quiet location. Hold the phone about four inches (10 centimeters) from your mouth, and speak directly into the phone's microphone in a normal tone of voice.

Do This	Result
1 Press and hold the voice key on the right side of your phone for the duration of the recording.	A tone sounds in the earpiece and the phone displays the Recording Voice Note message.
2 Speak your voice message into the phone.	The phone records the message and displays a recording timer.

Do This	Result
3 Release the voice key to stop recording.	The phone displays the voice notes list number and the total recording time.


Viewing the Voice Notes List

The voice notes list shows all your voice notes along with other important information and features.

Find the Feature



> Voice Notes



New Voice Note appears at the end of the list or by itself if no voice notes are stored. Select **New Voice Note** to view instructions on how to record a new voice note.



Playing a Voice Note

To play a recorded voice note:

Find the Feature



> Voice Notes


Press	To
1	scroll to the voice note
2 PLAY	play the voice note

When an optional Motorola Original™ headset accessory or FM Stereo Radio Headset accessory is connected to your phone, voice note playback is automatically routed to the headset.

Tip: You can play a voice note while taking a call. It won't be transmitted to the other party.

Playback Screen

While the voice note is playing, the playback screen is displayed.





Voice Note Controls

While playing back a voice note, press these keys to do the following:

Stop playback and go to **Voice Notes Menu**.

Stop playback and return to voice notes list.

Press **up/down** to stop playback and scroll to next voice note.

Press **left** to rewind three seconds, resume playing. Press **left and hold** to rewind to the beginning


Press any number key to alternately stop and start playback.

If the voice note is unlocked, stop playback and display **Delete Voice Note?**

If the voice note is locked, stop playback and unlock voice note.

Press **right** to fast forward three seconds, resume playing. Press **right and hold** to fast forward to end.

When playback is complete, press **right** to restart.



Locking and Unlocking a Voice Note

You can prevent a voice note from being accidentally deleted by locking it. To delete a locked voice note, you must first unlock it.

Find the Feature

 > Voice Notes

Press	To
1 	scroll to the voice note you want to lock or unlock
2 	open the Voice Notes Menu
3 	scroll to Lock or Unlock
4 SELECT ()	lock or unlock the voice note

You can also lock or unlock a voice note while playing it back. When the playback screen is displayed:

Press	To
1 	open the Voice Notes Menu
2 	scroll to Lock or Unlock
3 SELECT ()	lock or unlock the voice note

Playback stops when you lock or unlock a voice note. Press any number key to resume playback.



Deleting a Voice Note

You can delete a single unlocked voice note or all unlocked voice notes. To delete a locked voice note, you must first unlock it. See “Locking and Unlocking a Voice Note” on page 124.

Find the Feature



> Voice Notes

Press	To
1	scroll to the voice note you want to delete
2	open the Voice Notes Menu
3	scroll to Delete or Delete All
4 SELECT ()	select the highlighted option The phone displays Delete Voice Note X? , or Delete All Voice Notes?
5 YES ()	delete the selected voice note, or delete all voice notes

Notes:

- You can always press **NO** () to cancel deletion.
- A deleted voice note cannot be recovered.

Micro-Browser



The micro-browser lets you access Web pages on your phone. Contact your service provider to set up access, if necessary.

Starting a Micro-Browser Session

To open the micro-browser:

Find the Feature



> **Browser**

The micro-browser displays the home page set up by your service provider.

Press	To
1 	scroll to a bookmark or service
2 SELECT ()	select the service

Shortcut: If you open a text message with a Web address (URL) in it, you can go directly to the URL by selecting  > **Go To**.

If you are unable to establish a network connection with the micro-browser, contact your service provider.



Interacting With Web Pages

You can perform the following operations on a Web page:

Do This	To
Press 	scroll through a text message
Press  and then SELECT ()	scroll through and select items in a list
Press keypad keys and then OK ()	enter requested information
Press  to scroll to a phone number on a Web page, then press 	call the number from the micro-browser
Press 	go back to the previous Web page

Calculator

You can use your phone as a convenient calculator and currency converter.

Calculating Numbers

Find the Feature




> **Calculator**

Press	To
1 number keys	enter a number in the calculator
2 ◀▶ left or right	select a calculator function
3 SELECT (👁)	perform the selected function

Selected function appears here

Press ◀▶ to highlight a function

Exit the calculator



Entered number

Perform the highlighted function

Press to open the **Calculator Menu**



The calculator can perform the following functions:

Function	Description
.	Insert a decimal point
C	Clear the calculation
CE	Clear entry
=	Calculate the result
+	Add
-	Subtract
*	Multiply
÷	Divide
%	Divide the displayed value by 100
±	Change the entry's sign (positive/negative)
M ^R	Replace the displayed value with the value stored in memory
M ^S	Store the current value in memory (overwrites values already stored)
M ^C	Store 0 in memory

Converting Currency

The currency converter works just like the calculator, but uses the \$ (currency) function:

Find the Feature



> Calculator



> Exchange Rate

Press	To
1 number keys	enter the exchange rate
2 OK (↵)	store the exchange rate
3 number keys	enter the amount to convert (amount to multiply by the exchange rate)
4 ⬅➡ left or right	select the \$ function
5 SELECT (⏎)	perform the conversion



Your phone contains three games that you can play between phone calls. If you get an incoming call, message, alarm, or alert, the game ends automatically.

Selecting and Starting a New Game

Find the Feature



> Games

Press	To
1	scroll to the game of your choice
2 SELECT (	start the game

When the game is over, you can play another session of the same game or return to the games menu.

Press	To
BACK (or NO (	return to the games menu
NEW (or YES (	start another session of the game you just played

Ending a Game

You can end the game at any time.

Press	To
BACK ()	end the game session and return to the games menu
or	



Playing the Games

Blackjack

In this classic Las Vegas card game, you play against the dealer to see who can get closer to 21 points without going over.

Rules of the game

- All face cards count as 10 points.
- All number cards count as the points shown on their face.
- An Ace counts as 11 points, unless that would put you over 21 points. Otherwise, an Ace is counted as 1 point. An Ace that was originally counted as 11 may later be counted as 1 point if it will bring your points under or equal to 21 points.
- An initial deal of an Ace and a card with a face value of 10 points counts as exactly 21 points or Blackjack.
- Blackjack automatically wins against any other hand that totals 21 points.



- If you score more than 21 points, you go “bust” or lose.
- If you get five cards without going bust, you win.
- If you and the dealer have the same score, the dealer wins.
- You can ask for a “hit” or another card as long as you do not go bust.
- As long as the dealer’s total is less than 17 points, the dealer must continue to take a hit.

How to Play

When the game begins, you are dealt two cards. Based on their total face value, you can:

Press	To
STAY (🀄)	see the results of the hand
HIT ME (🀄)	request another card

Mindblaster

Your goal is to guess a secret four-symbol code. You play by entering symbols into four spaces and then submitting a guess.

Rules of the Game

- Your score is the number of guesses it takes to reveal the secret code.
- When you submit a guess, you get a clue that shows how many symbols have been identified correctly or are in the correct position.

- You can see a history of your last 10 guesses.
- Once you enter a symbol into a blank space, you can change the symbol but you cannot make the space blank again.
- When you correctly guess the four-symbol code, the display shows your score and the level of your next game.
- After you win one game, you progress from level 1 to level 2.
- After you win two more games, you progress from level 2 to level 3.
- When you exit the game or turn off the phone, you begin again at level 1.
- If you quit the game before you discover the secret code, you can see the number of guesses you attempted and view the correct answer.

How to Play

When the game begins, you see four blank spaces. To play the game:

Press	To
 left or right	move from space to space
 up or down	place a symbol in a space
	submit a guess (when all four spaces contain symbols)
	view a history of your last 10 guesses



Press	To
◀▶ up or down	move through the history

Paddleball

In this test of endurance, your mission is move your paddle to strike a bouncing ball. The more you succeed, the smaller your paddle gets.

Rules of the game

- Your score is the number of times your paddle hits the ball.
- You lose when the paddle misses the ball and the ball hits the wall.

How to play

Press	To
◀▶ up or down	move your paddle so that it hits the bouncing ball

Adjusting Your Settings

You can adjust a wide variety of phone settings to suit your needs.

Ring/Vibrate

Your phone rings or vibrates to notify you of an incoming call, message, or other event. This ring or vibration is called an *alert*. You can use a standard alert for all events, or set different alert types for different events. The alert setting indicator in your display shows the current standard alert setting:

 Loud ring

 Soft ring

 Vibrate

 Ring and vibrate

 Silent

Select a Ring/Vibration for All Events

Find the Feature



> Settings > Ring/Vibrate
> Alert

Press	To
1 	scroll to the alert you want to use
2 SELECT 	select the alert
	The phone displays the Changed: Alert message.



Select a Ring/Vibration for a Specific Event

You can select the alert that your phone uses for a specific event (such as an incoming call) from 32 different preset tones and vibrations. When you select a ring or vibration alert for a *specific* event, it overrides the default alert set for *all* events.

Tip: This feature also lets you set the ringer volume and keypad volume.

Find the Feature



> Settings > Ring/Vibrate
> Alert Detail

Press	To
1	scroll to the event for which you want to set a new alert
2 CHANGE (	select the event The phone displays the list of available alerts.
3	scroll to the alert you want for the event
4 SELECT (	select the alert The phone displays the Changed : Event Alert message.

Use the My Tones Feature

The my tones feature lets you create up to 32 custom alert tones for your phone. The tones you create appear in the list of available alerts (see “Select a Ring/Vibration for a Specific Event” on page 137).

Creating a Tone

Find the Feature



> **Settings** > **Ring/Vibrate**
> **My Tones**
> **New Tone**



Press	To
1 CHANGE (⏏)	select Notes
2 keypad keys	enter notes for the tone (see “Entering Notes” on page 139)
3 OK (⏏)	store the notes
4 CHANGE (⏏)	select Name
5 keypad keys	enter the name for the tone
6 OK (⏏)	store the name
7 DONE (⏏)	store the tone



Entering Notes

To create a new tone, use the keypad keys to enter each note in turn. You can modify a note's pitch, octave, or length by entering an octave/note/length combination as described below:

Key	Note or Option	Description
1 oct	1	set octave one
	2	set octave two
	3	set octave three
2 acc	A	note A
	B	note B
	C	note C
3 dec	D	note D
	E	note E
	F	note F
4 cm	G	note G
	R	rest
7 mod	#	sharp
	b	flat
8 trn	V	vibrate (one second)
0 len	h	half note
	w	whole note
	q	quarter note

Adjusting Your Settings

Notes:

- Press a key multiple times to cycle through its available notes or options.
- To change a note to a sharp or flat, enter the appropriate character (**#** or **b**) *after* the note (for example: **A#** for an A sharp).
- The default setting for a new tone is a quarter note in octave two. To change a note's octave, set the new octave (**1**, **2**, or **3**) *before* the note (for example: **3C#** for a C sharp in octave three). The new octave applies to the note and all following notes until you change it.
- To change a note's length, set the new length (**h**, **w**, or **q**) *after* the note (for example: **Dh** for a D half note). The new length applies to the note and all following notes until you change it.
- To add a rest, enter one or more **R** characters in the tone sequence. You can set a length (**h**, **w**, or **q**) *after* the rest just as you can for a note.
- Some sharps and flats are played as standard notes (for example: **B# = C**). Press  to scroll to valid notes when entering a new note.
- To listen to a new tone as you compose it, press  to enter the **Compose Menu**, and select **Play All** to play the notes you have entered.
- For help, press  to enter the **Compose Menu**, and select **Help** to view instructions on how to enter notes.



Playing a Tone

Find the Feature



> Settings > Ring/Vibrate
> My Tones

Press	To
1	scroll to the tone you want
2	open the My Tones Menu
3	scroll to Play
4 SELECT (	select Play The phone displays the playback meter and plays the tone.
5 PLAY (	play the tone again
or CANCEL (	return to the my tones list

Editing a Tone

You cannot edit the standard tones included with your phone. To edit a custom tone that you created:

Find the Feature



> Settings > Ring/Vibrate
> My Tones

Press	To
1	scroll to the tone you want to edit
2 EDIT (	open the tone details

Adjusting Your Settings

Press	To
3 	scroll to the details you want to edit (Name or Notes)
4 CHANGE ()	select the details you want to edit
5 keypad keys	enter new text or notes (see "Entering Notes" on page 139)
6 OK ()	store the details

Deleting a Tone

You cannot delete the standard tones included with your phone. To delete a custom tone that you created:

Find the Feature

 > **Settings** > **Ring/Vibrate**
> **My Tones**

Press	To
1 	scroll to the tone you want
2 	open the My Tones Menu
3 	scroll to Delete
4 SELECT ()	select Delete
5 YES ()	confirm the deletion



Reminders

Reminders are alerts that ring or vibrate to notify you about a voicemail or text message that you have received, or a datebook event that you have scheduled.

To set or turn off reminders:

Find the Feature



> **Settings** > **Ring/Vibrate**
> **Alert Detail** > **Reminders**

Press	To
1	scroll to the reminder alert you want: Beep , Vibrate , or Off Beep or Vibrate sets the corresponding reminder alert type. Off turns off all reminders.
2 SELECT (	select the reminder alert

Call Forwarding



Call forwarding sends your phone's incoming voice, fax, and/or data calls directly to another phone number. Use call forwarding options to specify which calls your phone should forward. When you are ready to accept calls on your phone again, you can turn off call forwarding.

Adjusting Your Settings

Set Up or Cancel Call Forwarding

The call forwarding options for voice, fax, or data calls are:

All Calls	forwards all calls
If Unavailable	forwards calls if your phone is unavailable
Detailed	uses different forwarding numbers if you are out of range, unable to answer, or busy (<i>voice calls only</i>)
Off	does not forward calls

Find the Feature



> **Settings** > **Call Forward**

Press	To
1	scroll to the type of calls you want to forward (Cancel All cancels all call forwarding and ends the procedure.)
2 SELECT (	open the call forward details for that call type
3	scroll to Forward
4 CHANGE (	change the Forward option
5	scroll to the call forward option you want
6 SELECT (	store the option



Press	To
7	scroll to To (same for If Busy , If No Answer , or If Unreachable)
8 CHANGE ()	change the phone number
9 keypad keys or BROWSE ()	enter the forwarding phone number browse through your phonebook or other lists for the forwarding phone number
10 OK ()	store the forwarding phone number

Note: You can repeat this procedure to enter forwarding information for other call types.

Check Call Forwarding Status

Your network may store call forwarding status for you. If you change your phone's call forward settings (see "Set Up or Cancel Call Forwarding" on page 144), then you should confirm that the network call forward status matches your preferences.

Find the Feature



> **Settings** > **Call Forward**
> **Forward Status**

Press	To
1	scroll to Voice , Fax , or Data calls
2 View ()	confirm that the network settings are correct

Reordering Menu Items

You can customize the order of the items in your phone's main menu, depending upon your usage.

Find the Feature

 > Settings
> Other Settings
> Personalize > Main Menu

Press	To
1 	scroll to the menu item you want to move
2 GRAB ()	grab the menu item you want to move
3 	move the item up or down the menu
4 INSERT ()	insert the item in the new location

Customizing a Soft Key Function

You can relabel the soft keys ( and ) to access different main menu items from the idle display.

Find the Feature

 > Settings
> Other Settings
> Personalize > Keys

Press	To
1 	scroll to Left or Right
2 CHANGE ()	open the key editor



Press	To
3 	scroll to the new key function
4 CHANGE ()	confirm the new function
	The key will have the new function whenever the phone is idle.

Hands-Free Use



You can purchase an optional Motorola Original™ hands-free car kit or headset for your phone. These accessories provide alternative ways for you to use your phone without using your hands.

Note: The use of wireless devices and their accessories may be prohibited or restricted in certain areas. Always obey the laws and regulations on the use of these products.

Automatic Answer

When you activate automatic answer and connect your phone to a car kit or headset, your phone automatically answers calls after two rings.

Find the Feature



> **Settings**
> **Other Settings**

Press	To
1 	scroll to Car Settings or Headset
2 SELECT ()	select the feature

Adjusting Your Settings

Press	To
3 	scroll to Auto Answer
4 CHANGE ()	select Auto Answer
5 	scroll to On or Off
6 SELECT ()	confirm the setting

Automatic Hands-Free

You can set up your phone to automatically route calls to a car kit when it detects a connection.

Find the Feature



- > **Settings**
- > **Other Settings**
- > **Car Settings**
- > **Auto Handsfree**

Press	To
1 	scroll to On or Off
2 SELECT ()	confirm the setting



Power-Off Delay

When your phone is connected to a car kit, you can set it to stay on for a specified time period after you switch off the ignition. This keeps your phone from draining your vehicle battery by staying on indefinitely, but leaves your phone on long enough that you do not have to re-enter your unlock code when you make short stops.

Find the Feature

-  > Settings
- > Other Settings
- > Car Settings
- > Power-Off Delay

Press	To
1 	scroll to the time delay option you want
2 SELECT ()	confirm your selection

Caution: If you select **Continuous**, the phone does not power off when you turn off the ignition. Be careful not to accidentally drain your vehicle battery if you select this option.

Charger Time

When your phone is connected to a car kit, you can set it to charge itself for a specified time period after you switch off the ignition. This helps ensure that the phone battery gets fully charged while the vehicle is parked.

Find the Feature



- > Settings
- > Other Settings
- > Car Settings
- > Charger Time

Press	To
1	scroll to the charge time option you want
2 SELECT	confirm your selection



Data and Fax Calls



A Motorola Original™ data kit lets you transfer data between your phone and a computer or other external device. You can:

- synchronize data between your phone and an external device with TrueSync® software, a Motorola accessory product. See the TrueSync user guide for more information.
- use your phone as a wireless modem to connect to the Internet
- use your phone to send and receive data and fax calls on your computer or hand-held device.

More information about Motorola Original data kits is available at:

<http://www.motorola.com/dataaccessories>.

Connecting Your Phone to an External Device

Connect your phone to an external device (such as a computer or hand-held device) using [an Infrared Data Association \(IrDA\) wireless link](#), a serial cable, or a USB cable.

Set Up a Cable Connection

Attach a serial cable or Motorola Original USB cable to the phone and external device as follows.


Note: Check your computer or hand-held device to determine the type of cable you need.

Attaching a Serial Cable


Use the interchangeable head on the Motorola Multi-Connect Serial Cable to connect a computer, Palm III device, or Palm V device to your phone.

Do This

- 1 Plug the serial cable into the detachable head. Make sure that the Motorola logo on the detachable head and the metal shielding on the serial cable plug are both facing you.



- 2 With the Motorola logo and the phone both facing you, plug the detachable head into the phone's accessory connector port.



- 3 Plug the other end of the cable into the serial interface connection on the external device and tighten the screws.



Attaching a USB Cable

Do This

- 1 Plug the end of the cable with the Motorola logo into the phone's accessory connector port. Make sure that the logo and the phone are both facing you.



- 2 Plug the other end—the USB connection—into the USB port on the external device.

Establish an Infrared Connection

Use the following procedure to connect your phone to an external device using an infrared data link.

Important: In order to create and maintain an infrared connection, your phone must be within one meter (about three feet) of the other device. Nothing can block the line of sight between the two devices.

Find the Feature



> Settings > Connection
> IrDA Link

Press

To

1



access the infrared link feature

Press	To
2 START (👁)	activate the infrared link The phone displays the Infrared Link connecting message for 60 seconds or until the link is established. When the link has been established, the phone displays the IRDA link is active message.

If the phone does not find an infrared-capable device, it displays the **Infrared link failed. Retry Now?** message.

Press	To
YES (👁)	try another connection

Break an Infrared Connection

You can break the infrared data connection by moving the device away from the phone, turning off the device, or turning off the phone.

Install the Software

Install the software from the CD-ROM that comes with your Motorola Original data kit. See the data kit's user guide for more information.



Sending a Data or Fax Call

You can connect your phone to a computer or hand-held device to send data or a fax from the connected device.

Use this feature to transfer data from your computer onto another device, and to synchronize phonebook and datebook information between your phone, computer, and/or hand-held device.

Connect your phone (see “Connecting Your Phone to an External Device” on page 151) and do the following:

Do This	To
1 Check the phone	make sure that the phone is connected and powered on
2 Open the application on your computer	place the call through the application (such as dial-up-networking or fax) Note: You cannot dial data or fax numbers through your phone's keypad. You must dial them through your computer.
3 End the transfer on your computer	close the call and connection when the transfer is complete

Receiving a Data or Fax Call

You can connect your phone to a computer or hand-held device to receive data or a fax.

Use this feature to transfer data to your computer from another device.

Set Up Your Phone

Before you receive a data or fax call, you must configure your phone for the incoming call type and connect the phone to the device that will receive the call.

Find the Feature



> Settings > Connection
> Incoming Call

Do This	To
1 Press CHANGE (👁)	select the Next Call menu option
2 Press ⬅➡	scroll to Data In Only or Fax In Only Selecting either of these options mutes the earpiece and routes the next incoming call to the connected device.
3 Press SELECT (👁)	set the format for the next incoming call



Do This	To
4 Connect your phone to the device	enable the data or fax transfer (See "Connecting Your Phone to an External Device" on page 151.)

Note: You cannot answer incoming voice calls when your phone is in data or fax mode. Any voice calls you receive are treated as unanswered calls. You must reset your phone to voice mode to return these calls. See "Reset Normal Voice Operation" on page 158 and "Returning an Unanswered Call" on page 34.

Transfer the Data or Fax

Your phone notifies you when the data or fax call arrives, and transfers the call to the connected device. You must use the application running on the connected device to answer the call.

End the Data/Fax Connection

When the data or fax transfer is complete:

Do This	To
End the call from the connected device	close the connection

Reset Normal Voice Operation

After you receive a data or fax call, you *must* reset your phone to resume normal voice operations. You cannot receive voice calls when your phone is in data or fax mode.

Find the Feature



> **Settings** > **Connection**
> **Incoming Call**

Do This	To
1 Press CHANGE (⏏)	select the Next Call menu option
2 Press ⏏	scroll to Normal
3 Press SELECT (⏏)	reset your phone to make and receive regular voice calls

Your phone also reverts to normal voice operations when you turn it off and then turn it back on.



Sending a Talk then Data or Talk then Fax Call

You can place a call where you talk and then send data or a fax to the same phone number within the same call.

Connect to the device that will send the data or fax (see "Connecting Your Phone to an External Device" on page 151) and do the following:

Press	To
1 keypad keys	enter the phone number for the call
2 	open the Dialing Menu
3 	scroll to Talk Then Data or Talk Then Fax
4 SELECT ()	select Talk Then Data or Talk Then Fax (for the next call only)
5 	dial the call Speak and, when ready, initiate the data or fax transfer on the connected device. When transfer is complete, end the call from the connected machine.

Security

Assigning a New Code or Password

Your phone's four-digit unlock code is originally set to 1234, and the six-digit security code is originally set to 000000 at the factory. Your service provider may reset these numbers before you receive your phone.

If your service provider has *not* reset these numbers, we recommend that you change them to prevent other users from accessing your personal information or modifying your phone settings. The unlock code must contain four digits, and the security code must contain six digits. Be sure to make a note of the new numbers.

Notes:

- Your service provider may retain your phone's security code for customer service purposes. In this case, you will not be able to use phone features that require you to enter the security code (such as master clear, master reset, and the unlock code bypass feature).
- If the only password you can change is the unlock code, the **New Passwords** menu is unavailable and the **Unlock Code** option appears on the **Phone Lock** menu. In this case, open the unlock code editor by selecting:  > **Settings** > **Security** > **Phone Lock** > **Unlock Code**.



To change a code or password:

Find the Feature



> Settings > Security
> New Passwords

Press	To
1	scroll to the code or password you want to change
2 CHANGE (	select the code or password
3 keypad keys	enter your old code If you do not know your code, see "If You Forget a Code or Password" on page 161.
4 OK (	submit your old code
5 keypad keys	enter the new code
6 OK (	assign the new code
7 keypad keys	re-enter the new code
8 OK (	confirm the new code

If You Forget a Code or Password

If you forget your security code (originally set to 000000), [SIM PIN](#), [SIM PIN2](#), or [call barring password](#), contact your service provider.

If you forget your unlock code, try entering 1234 or the last four digits of your phone number. If that does not work, do the following when you see the **Enter Unlock Code** message:

Press	To
1 	go to the unlock code bypass screen
2 keypad keys	enter your security code
3 OK ()	submit your security code

Locking and Unlocking Your Phone

You can lock your phone manually or set your phone to lock automatically whenever you turn it off.

When you try to use a locked phone, it asks you to enter the unlock code. A locked phone still rings or vibrates for incoming calls or messages, *but you must unlock it to answer.*

You can make emergency calls on your phone even when it is locked. See “Dialing an Emergency Number When the Phone is Locked” on page 35.

Lock Your Phone Manually

Find the Feature



> **Settings** > **Security**
> **Phone Lock** > **Lock Now**

Press	To
1 keypad keys	enter your four-digit unlock code
2 OK ()	lock the phone



Set Your Phone to Lock Automatically

You can set your phone to lock every time you turn it off:

Find the Feature



> Settings > Security
> Phone Lock
> Automatic Lock > On

Press	To
1 keypad keys	enter your four-digit unlock code
2 OK (⏎)	set the phone to lock automatically

Unlock Your Phone

At the **Enter Unlock Code** prompt:

Press	To
1 keypad keys	enter your four-digit unlock code The unlock code is originally set to 1234. If necessary, see "If You Forget a Code or Password" on page 161.
2 OK (⏎)	unlock your phone

Locking and Unlocking Your Keypad

You can lock your phone keypad to prevent accidental use. This feature is useful in situations where an accidental keypress might inadvertently dial an emergency number or one-touch dial number (for example, when carrying your phone in a purse or pocket).

Press	To
 	lock or unlock your keypad

Note: Incoming calls and messages unlock the keypad.

Barring Calls



Call barring lets you restrict outgoing or incoming calls. You can restrict all calls, calls to international numbers, or calls while roaming.

Find the Feature



> **Settings** > **Security**
> **Call Barring**

Press	To
1 keypad keys	enter your call barring password
2 OK ()	submit your password
3 	scroll to Outgoing or Incoming calls
4 CHANGE ()	select barring for Outgoing or Incoming calls



Press	To
5 	scroll to a restriction for the barred calls
6 SELECT ()	select the restriction for the barred calls

Protecting the SIM Card

When the SIM PIN feature is activated, you must enter your SIM card PIN code each time you turn on the phone or insert a SIM card.

Find the Feature



> **Settings** > **Security**
> **SIM PIN**

Press	To
1 	scroll to On or Off
2 SELECT ()	switch protection on or off
3 keypad keys	enter your SIM card PIN code
4 OK ()	submit your code

Troubleshooting

Check these questions first if you have problems with your phone:

Question	Answer
Is your phone set up correctly?	Press   . If you do not see your phone number, contact your service provider.
Is your battery charged? Do you see  in the display?	The battery level indicator should have at least one segment showing (). If it does not, recharge your battery. (See "Charging the Battery" on page 24 and "Battery Use" on page 31.)
Does the handset have a signal? Do you see  in the display?	The signal strength indicator should have at least one segment showing (). If it does not, move to an area with a stronger signal to use your phone.
Is the earpiece volume too low?	While on a call, press the upper volume key on the side of your phone.
Is the other party unable to hear you?	Press UNMUTE () if necessary to unmute the phone. Also, make sure that your phone's microphone is not blocked by its carrying case or a sticker.



Question	Answer
Has the phone been damaged, dropped, or gotten wet?	Dropping your phone, getting it wet, or using a non-Motorola battery or battery charger can damage the phone. The phone's limited warranty does not cover liquid damage or damage caused from using non-Motorola accessories.
Was a non-Motorola battery or battery charger used?	

The following refer to specific problems:

Problem	Solution
My phone was stolen. To whom should I report this?	Report a stolen phone to the police and to your service provider (the company that sends you your monthly wireless service bill).
I forgot my password.	See "If You Forget a Code or Password" on page 161.
I pressed the power key, but nothing happened.	Be sure to press and hold  (the power key) until the display appears and you hear an audible alert (this could take a couple of seconds). If nothing happens, check that a charged battery is installed. (See "Installing the Battery" on page 21.)


Troubleshooting

Problem	Solution
The display says: Enter Unlock Code. How do I unlock my phone?	Enter the factory-preset unlock code (1234), or the last four digits of your phone number. (See "Locking and Unlocking Your Phone" on page 162.) If this fails, call your service provider (the company that sends you your monthly wireless service bill).
My phone asks for an unlock code when I try to open a feature.	The application you want is locked. If you own the phone but do not know the unlock code, see "If You Forget a Code or Password" on page 161.
My phone does not ring.	If you see  or  in the display, then the ringer is turned off. See "Ring/Vibrate" on page 136.
I tried to place a call and heard an alternating high/low tone.	Your call did not reach the wireless system. You may have dialed the number too soon after turning the phone on. Wait until the display says Ready before making a call.



Problem	Solution
I cannot send/receive calls.	Make sure that you have a phone signal (see the “Signal Strength Indicator” item on page 28). Avoid electrical or radio interference, and obstructions such as bridges, parking garages, or tall buildings. Your phone also may have the Call Barring feature turned on. If you know the unlock code, you can change this setting in the security menu ( > Settings > Security). Also, check to be sure your SIM card is installed and working.
My phone has poor reception and drops calls.	Make sure that your antenna is not bent or damaged. Also, make sure you have a phone signal (see the “Signal Strength Indicator” item on page 28). Stay clear of any obstructions such as bridges, parking garages, or tall buildings.
I cannot hear others on my phone.	While on a call, press the upper volume key on the left side of your phone. Your phone display should show the volume increasing. Also, make sure that your phone’s earpiece is not blocked by its carrying case.

Troubleshooting

Problem	Solution
I cannot open my inbox.	Before you can use text or information services messages, you must set up the appropriate inbox. See "Setting Up the Text Message Inbox" on page 107.
How do I see the calls I sent or received?	To see the most recent calls you dialed or received, open the "Recent Calls" lists:  MENU > Recent Calls > Received Calls or Dialed Calls
My phone's display is too dark.	You can use the Contrast Setting feature (see page 70) to change the level of contrast in your phone display. You can also use the Backlight feature (see page 70) to change the length of time that your phone's backlight display stays on.
My battery didn't last as long as I expected. What can I do to extend battery life?	Your battery's performance is affected by charge time, feature use, temperature changes, and other factors. For tips on extending your battery life, see "Battery Use" on page 31.



Problem	Solution
I am unable to record a voice note, voice name, or voice shortcut	Try moving to a quieter location to make your voice recording. Hold the phone about four inches (10 centimeters) away from your mouth, and speak directly into your phone's microphone in a normal tone of voice.
I plugged the data cable into my phone but my phone did not beep. How do I know if the data cable is ready to go?	The beep indicates that you are set up correctly. If you did not hear a beep, make sure that both ends of the data cable are connected—the smaller end to your phone and the larger end to your computer. Finally, your computer may have deactivated the port to save power. Try opening an application that uses the port, like a fax or dial-up application, and your computer will automatically activate the port.
My phone beeped when I attached the data cable, but my fax and data applications don't work.	Some wireless networks may not support data or fax transmission. If you are roaming on an unfamiliar network, this may be the case. Also, remember that data and fax transmission usually requires a subscription. Call your service provider for more information.

Troubleshooting

Problem	Solution
When sending data with the data cable, why does the computer show a connection rate of 19200 Kbps?	19200 Kbps is the data transfer rate of the connection between your computer and the phone. The rate of the connection between your phone and the network is displayed on your phone, and will be either 14400 or 9600 Kbps.
I can't end my data call by closing the application on my computer. What can I do?	Try pressing  on your phone. Also try disconnecting the cable or turning off the phone. If possible, always close the connection through your computer. These alternative methods may disrupt the application on your computer.
I launched the micro-browser but the display says: Service Not Available.	You may be in an area without service, or you may be connected to a network that does not support Internet access.
I launched the micro-browser but the display says: Data Server Unavailable.	Try again in a few minutes. The servers may be temporarily busy.

Specific Absorption Rate Data

This model phone meets the government's requirements for exposure to radio waves.

Your wireless phone is a radio transmitter and receiver. It is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons, regardless of age and health.

The exposure standard for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6 W/kg.¹ Tests for SAR are conducted using standard operating positions reviewed by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output.

Before a phone model is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the limit established by the government-adopted requirement for safe exposure. The tests are performed in positions and locations (e.g., at the ear and worn on the body) as required by the FCC for each model. The highest SAR value for this model phone when tested for use at the ear is _____², and when worn on the body, as described in this user guide, is _____². (Body-worn measurements differ among phone models, depending upon available accessories and FCC requirements). While there may be differences between the SAR levels of various phones and at various positions, they all meet the government requirement.

The FCC has granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model phone is on file with the FCC and can be found under the Display Grant section of:

<http://www.fcc.gov/oet/fccid>

after searching on FCC ID _____.

1. In the United States and Canada, the SAR limit for mobile phones used by the public is 1.6 watts/kg (W/kg) averaged over one gram of tissue. The standard incorporates a substantial margin of safety to give additional protection for the public and to account for any variations in measurements.
2. The SAR information provided to the FCC includes the FCC-accepted Motorola testing protocol, assessment procedure, and measurement uncertainty range for this product.

***The U.S. Food and Drug
Administration's Center for Devices
and Radiological Health Consumer
Update on Mobile Phones***



FDA has been receiving inquiries about the safety of mobile phones, including cellular phones and PCS phones. The following summarizes what is known—and what remains unknown—about whether these products can pose a hazard to health, and what can be done to minimize any potential risk. This information may be used to respond to questions.

Why the concern?

Mobile phones emit low levels of radio frequency energy (i.e., radio frequency radiation) in the microwave range while being used. They also emit very low levels of radio frequency energy (RF), considered non-significant, when in the stand-by mode. It is well known that high levels of RF can produce biological damage through heating effects (this is how your microwave oven is able to cook food). However, it is not known whether, to what extent, or through what mechanism, lower levels of RF might cause adverse health effects as well. Although some research has been done to address these questions, no clear picture of the biological effects of this type of radiation has emerged to date. Thus, the available science does not allow us to conclude that mobile phones are absolutely safe, or that they are unsafe. However, the available scientific evidence does not demonstrate any adverse health effects associated with the use of mobile phones.

What kinds of phones are in question?

Questions have been raised about hand-held mobile phones, the kind that have a built-in antenna that is positioned close to the user's head during normal telephone conversation. These types of mobile phones are of concern because of the short distance between the phone's antenna—the primary source of the RF—and the person's head. The exposure to RF from mobile phones in which the antenna is located at greater distances from the user (on the outside of a car, for example) is drastically lower than that from hand-held phones, because a person's RF exposure decreases rapidly with distance from the source. The safety of so-called “cordless phones,” which have a base unit connected to the telephone wiring in a house and which operate at far lower power levels and frequencies, has not been questioned.

How much evidence is there that hand-held mobile phones might be harmful?

Briefly, there is not enough evidence to know for sure, either way; however, research efforts are on-going. The existing scientific evidence is conflicting and many of the studies that have been done to date have suffered from flaws in their research methods. Animal experiments investigating the effects of RF exposures characteristic of mobile phones have yielded conflicting results. A few animal studies, however, have suggested that low levels of RF could accelerate the development of cancer in laboratory animals. In one study, mice genetically altered to be predisposed to developing one type of cancer developed more than twice as many such cancers when they were exposed to RF energy compared to controls. There is much uncertainty among scientists about whether results

obtained from animal studies apply to the use of mobile phones. First, it is uncertain how to apply the results obtained in rats and mice to humans. Second, many of the studies that showed increased tumor development used animals that had already been treated with cancer-causing chemicals, and other studies exposed the animals to the RF virtually continuously—up to 22 hours per day.

For the past five years in the United States, the mobile phone industry has supported research into the safety of mobile phones. This research has resulted in two findings in particular that merit additional study:

- 1 In a hospital-based, case-control study, researchers looked for an association between mobile phone use and either glioma (a type of brain cancer) or acoustic neuroma (a benign tumor of the nerve sheath). No statistically significant association was found between mobile phone use and acoustic neuroma. There was also no association between mobile phone use and gliomas when all types of types of gliomas were considered together. It should be noted that the average length of mobile phone exposure in this study was less than three years.

When 20 types of glioma were considered separately, however, an association was found between mobile phone use and one rare type of glioma, neuroepitheliomatous tumors. It is possible with multiple comparisons of the same sample that this association occurred by chance. Moreover, the risk did not increase with how often the mobile phone was used, or the length of the calls. In fact, the risk actually decreased with cumulative hours of mobile phone use. Most cancer causing agents increase risk with increased exposure. An ongoing study of brain cancers by the

National Cancer Institute is expected to bear on the accuracy and repeatability of these results.¹

- 2 Researchers conducted a large battery of laboratory tests to assess the effects of exposure to mobile phone RF on genetic material. These included tests for several kinds of abnormalities, including mutations, chromosomal aberrations, DNA strand breaks, and structural changes in the genetic material of blood cells called lymphocytes. None of the tests showed any effect of the RF except for the micronucleus assay, which detects structural effects on the genetic material. The cells in this assay showed changes after exposure to simulated cell phone radiation, but only after 24 hours of exposure. It is possible that exposing the test cells to radiation for this long resulted in heating. Since this assay is known to be sensitive to heating, heat alone could have caused the abnormalities to occur. The data already in the literature on the response of the micronucleus assay to RF are conflicting. Thus, follow-up research is necessary.²

FDA is currently working with government, industry, and academic groups to ensure the proper follow-up to these industry-funded research findings. Collaboration with the Cellular Telecommunications Industry Association (CTIA) in particular is expected to lead to FDA providing research recommendations and scientific oversight of new CTIA-funded research based on such recommendations.

Two other studies of interest have been reported recently in the literature:

- 1 Two groups of 18 people were exposed to simulated mobile phone signals under laboratory conditions while they

performed cognitive function tests. There were no changes in the subjects' ability to recall words, numbers, or pictures, or in their spatial memory, but they were able to make choices more quickly in one visual test when they were exposed to simulated mobile phone signals. This was the only change noted among more than 20 variables compared.³

- 2 In a study of 209 brain tumor cases and 425 matched controls, there was no increased risk of brain tumors associated with mobile phone use. When tumors did exist in certain locations, however, they were more likely to be on the side of the head where the mobile phone was used.

Because this occurred in only a small number of cases, the increased likelihood was too small to be statistically significant.⁴

In summary, we do not have enough information at this point to assure the public that there are, or are not, any low incident health problems associated with use of mobile phones. FDA continues to work with all parties, including other federal agencies and industry, to assure that research is undertaken to provide the necessary answers to the outstanding questions about the safety of mobile phones.

What is known about cases of human cancer that have been reported in users of hand-held mobile phones?

Some people who have used mobile phones have been diagnosed with brain cancer. But it is important to understand that this type of cancer also occurs among people who have not used mobile phones. In fact, brain cancer occurs in the U.S.

population at a rate of about 6 new cases per 100,000 people each year. At that rate, assuming 80 million users of mobile phones (a number increasing at a rate of about 1 million per month), about 4800 cases of brain cancer would be expected each year among those 80 million people, whether or not they used their phones. Thus it is not possible to tell whether any individual's cancer arose because of the phone, or whether it would have happened anyway. A key question is whether the risk of getting a particular form of cancer is greater among people who use mobile phones than among the rest of the population. One way to answer that question is to compare the usage of mobile phones among people with brain cancer with the use of mobile phones among appropriately matched people without brain cancer. This is called a case-control study. The current case-control study of brain cancers by the National Cancer Institute, as well as the follow-up research to be sponsored by industry, will begin to generate this type of information.

What is FDA's role concerning the safety of mobile phones?

Under the law, FDA does not review the safety of radiation-emitting consumer products such as mobile phones before marketing, as it does with new drugs or medical devices. However, the agency has authority to take action if mobile phones are shown to emit radiation at a level that is hazardous to the user. In such a case, FDA could require the manufacturers of mobile phones to notify users of the health hazard and to repair, replace or recall the phones so that the hazard no longer exists.

Although the existing scientific data do not justify FDA regulatory actions at this time, FDA has urged the mobile phone industry to take a number of steps to assure public safety. The agency has recommended that the industry:

- support needed research into possible biological effects of RF of the type emitted by mobile phones
- design mobile phones in a way that minimizes any RF exposure to the user that is not necessary for device function
- cooperate in providing mobile phone users with the best possible information on what is known about possible effects of mobile phone use on human health

At the same time, FDA belongs to an interagency working group of the federal agencies that have responsibility for different aspects of mobile phone safety to ensure a coordinated effort at the federal level. These agencies are:

- National Institute for Occupational Safety and Health
- Environmental Protection Agency
- Federal Communications Commission
- Occupational Health and Safety Administration
- National Telecommunications and Information Administration

The National Institutes of Health also participates in this group.

In the absence of conclusive information about any possible risk, what can concerned individuals do?

If there is a risk from these products—and at this point we do not know that there is—it is probably very small. But if people

are concerned about avoiding even potential risks, there are simple steps they can take to do so. For example, time is a key factor in how much exposure a person receives. Those persons who spend long periods of time on their hand-held mobile phones could consider holding lengthy conversations on conventional phones and reserving the hand-held models for shorter conversations or for situations when other types of phones are not available.

People who must conduct extended conversations in their cars every day could switch to a type of mobile phone that places more distance between their bodies and the source of the RF, since the exposure level drops off dramatically with distance. For example, they could switch to:

- a mobile phone in which the antenna is located outside the vehicle
- a hand-held phone with a built-in antenna connected to a different antenna mounted on the outside of the car or built into a separate package
- a headset with a remote antenna to a mobile phone carried at the waist

Again, the scientific data do not demonstrate that mobile phones are harmful. But if people are concerned about the radio frequency energy from these products, taking the simple precautions outlined above can reduce any possible risk.

Where can I find additional information?

For additional information, see the following Web sites:

Federal Communications Commission (FCC) RF Safety Program (select "Information on Human Exposure to RF Fields from Cellular and PCS Radio Transmitters"):
<http://www.fcc.gov/oet/rfsafety>

World Health Organization (WHO) International Commission on Non-Ionizing Radiation Protection (select Qs & As):
<http://www.who.int/emf>

United Kingdom, National Radiological Protection Board: <http://www.nrpb.org.uk>

Cellular Telecommunications Industry Association (CTIA):
<http://www.wow-com.com>

U.S. Food and Drug Administration (FDA) Center for Devices and Radiological Health: <http://www.fda.gov/cdrh/consumer/>

1. Muscat et al. Epidemiological Study of Cellular Telephone Use and Malignant Brain Tumors. In: State of the Science Symposium; 1999 June 20; Long Beach, California.
2. Tice et al. Tests of mobile phone signals for activity in genotoxicity and other laboratory assays. In: Annual Meeting of the Environmental Mutagen Society; March 29, 1999, Washington, D.C.; and personal communication, unpublished results.
3. Preece, AW, Iwi, G, Davies-Smith, A, Wesnes, K, Butler, S, Lim, E, and Varey, A. Effect of a 915-MHz simulated mobile phone signal on cognitive function in man. *Int. J. Radiat. Biol.*, April 8, 1999.
4. Hardell, L, Nasman, A, Pahlson, A, Hallquist, A and Mild, KH. Use of cellular telephones and the risk for brain tumors: a case-control study. *Int. J. Oncol.*, 15: 113-116, 1999.

Warranty

Limited Warranty for Motorola Personal Communications Products Purchased in the United States and Canada

I. What This Warranty Covers

- Products. Defects in materials and workmanship in wireless cellular telephones, pagers, and/or two-way radios, and certain accessories that are sold with them, such as the battery, battery charger and holster manufactured and/or sold by Motorola (Products).
- Batteries. Defects in materials and workmanship in batteries that are manufactured by Motorola and/or sold with Products are covered by this warranty only if the fully-charged capacity falls below 80% of rated capacity or they leak.
- Software. Physical defects in the media that tangibly embodies each copy of any software supplied with the Products.

II. What the Period of Coverage Is

From the date the Products are purchased by the first end-user:

- Products. The warranty is for one year. Exception: The warranty for Spirit GT series and Talkabout series two-way radio accessories is for 90 days.
- Software. The warranty is for 90 days.
- Repairs/Replacements. The warranty is for the balance of the original warranty or for 90 days from the date you receive it, whichever is longer.

III. Who is Covered

This warranty extends to the first end-user purchaser, only.

IV. What We Will Do to Correct Warranty Problems

At no charge to you, we have the option to repair or replace the Products or software that do not conform to the warranty, or to refund the Products' purchase price. We may use functionally equivalent reconditioned/refurbished/pre-owned or new Products or parts. No software updates are provided.

V. How to Get Warranty Service

Please call:

USA

Cellular

1-800-331-6456

Paging

1-800-548-9954

Two-Way

1-800-353-2729

TTY (Text Telephone)

1-888-390-6456

Canada

All Products 1-800-461-4575

TTY (Text Telephone) 1-888-390-6456

You will receive instructions on how to ship the Products to Motorola. You must ship the Products to us with freight, duties and insurance prepaid. Along with the Products you must include: (a) a copy of your receipt, bill of sale or other comparable proof of purchase; (b) a written description of the problem; (c) the name of your service provider (if this Product requires subscription service); (d) the name and location of the installation facility (if applicable) and, most importantly; (e) your address and telephone number. If requested, you must also return all detachable parts such as antennas, batteries and chargers. **RETAIN YOUR ORIGINAL PROOF OF PURCHASE.**

We will ship repaired or replacement Products at our expense for the freight and insurance, but at your expense for any duties. If additional information is needed, please contact us at the telephone number listed above.

VI. What This Warranty Does Not Cover

- Products that are operated in combination with ancillary or peripheral equipment or software not furnished by Motorola for use with the Products ("ancillary equipment"), or any damage to the Products or ancillary equipment as a result of such use. Among other things, "ancillary equipment" includes batteries, chargers, adaptors, and power supplies not manufactured or supplied by Motorola. Any of these voids the warranty.

Warranty

- Someone other than Motorola (or its authorized service centers) tests, adjusts, installs, maintains, alters, modifies or services the Products in any way. Any of these voids the warranty.
- Rechargeable batteries that: (a) are charged by other than the Motorola-approved battery charger specified for charging such batteries; (b) have any broken seals or show evidence of tampering; (c) are used in equipment other than the Product for which they are specified; or (d) are charged and stored at temperatures greater than 60 degrees centigrade. Any of these voids the warranty.
- Products that have: (a) serial numbers or date tags that have been removed, altered or obliterated; (b) board serial numbers that do not match each other, or board serial numbers that do not match the housing; or (c) nonconforming or non-Motorola housings or parts. Any of these voids the warranty.
- Defects or damage that result from: (a) use of the Products in a manner that is not normal or customary; (b) improper operation or misuse; (c) accident or neglect such as dropping the Products onto hard surfaces; (d) contact with water, rain, extreme humidity or heavy perspiration; (e) contact with sand, dirt or the like; or (f) contact with extreme heat, or spills of food or liquid.
- Physical damage to the surface of the Products, including scratches, cracks or other damage to a display screen, lens or other externally exposed parts.

- Failure of Products that is due primarily to any communication service or signal you may subscribe to or use with the Products.
- Coil cords that are stretched or that have any broken modular tabs.
- Products that are leased.

Flat-rate repair rates may apply to Products not covered by this warranty. To obtain information about Products needing repairs that are not covered by this warranty, please call the telephone number previously listed. We will provide information on repair availability, rates, methods of payment, where to send the Products, etc.

VII. Some Other Limitations

This is Motorola's complete warranty for the Products, and states your exclusive remedies. This warranty is given in lieu of all other express warranties. Implied warranties, including without limitation, the implied warranties of merchantability and fitness for a particular purpose, are given only if specifically required by applicable law. Otherwise, they are specifically excluded.

No warranty is made as to coverage, availability, or grade of service provided by the Products, whether through a service provider or otherwise.

No warranty is made that the software will meet your requirements or will work in combination with any hardware or applications software products provided

by third parties, that the operation of the software products will be uninterrupted or error free, or that all defects in the software products will be corrected.

In no event shall Motorola be liable, whether in contract or tort (including negligence) for damages in excess of the purchase price of the Product, or for any indirect, incidental, special or consequential damages of any kind, or loss of revenue or profits, loss of business, loss of information or data, or other financial loss arising out of or in connection with the ability or inability to use the Products, to the full extent these damages may be disclaimed by law.

VIII. Patent and Software Provisions

At Motorola's expense, we will defend you, and pay costs and damages that may be finally awarded against you, to the extent that a lawsuit is based on a claim that the Products directly infringe a United States patent. Our obligation is conditioned on: (a) you notifying us promptly in writing when you receive notice of the claim; (b) you giving us sole control of the defense of the suit and all negotiations for its settlement or compromise; and (c) should the Products become, or in Motorola's opinion be likely to become, the subject of a claim of infringement of a United States patent, you permit us, at our option and expense, either to: procure for you the right to continue using the Products; replace or modify them so that they become non-infringing; or grant you a credit for such Products, as depreciated, and accept their return. The depreciation will be an equal amount per year over the lifetime of the Products, as established by Motorola.

Motorola will have no liability to you with respect to any claim of patent infringement that is based upon the combination of the Products or parts furnished under this limited warranty with ancillary equipment, as defined in VI., above.

This is Motorola's entire liability with respect to infringement of patents by the Products.

Laws in the United States and other countries preserve for Motorola and other third party software providers certain exclusive rights for copyrighted software, such as the exclusive rights to reproduce in copies and distribute copies of such software. The software may be copied into, used in and redistributed with only those Products that are associated with such software. No other use, including without limitation, disassembly or reverse engineering of such software or exercise of exclusive rights in such software is permitted.

IX. State Law and Other Jurisdiction Rights

Some states and other jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, or limitation on the length of an implied warranty, so the above limitations or exclusions may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights, which vary from jurisdiction to jurisdiction.

To obtain information on Motorola Personal Communications Products, including warranty service, accessories and optional Extended Warranties on selected Products, please call:

USA

Cellular	1-800-331-6456
Paging	1-800-548-9954
Two-Way	1-800-353-2729
TTY (Text Telephone)	1-888-390-6456

Canada

All Products	1-800-461-4575
TTY (Text Telephone)	1-888-390-6456

To correspond with Motorola about the Products, please write us at <http://www.motorola.com> or at:

In the USA:

Motorola, Inc.

600 North U.S. Highway 45

Libertyville, IL 60048

In Canada:

Motorola Canada Limited

5875 Whittle Road

Mississauga, ON L4Z 2H4

Export Law Assurances

This product is controlled under the export regulations of the United States of America and Canada. The Governments of the United States of America and Canada may restrict the exportation or re-exportation of this product to certain destinations. For further information contact the U.S. Department of Commerce or the Canadian Department of Foreign Affairs and International Trade.

Index

A

- accessories
 - optional 11, 101, 121, 147, 151
 - standard 20
- accessory connector port 1
- Add Digits** feature 75
- alert
 - creating 138–142
 - defined 136
 - indicators 29, 136
 - muting 36
 - reminders 143
 - setting 136
 - type, selecting 137
- alert setting indicator
 - defined 29, 136
 - illustration 28
- antenna 1
- application, locking 68
- appointments. *See* datebook
- Attach Number** feature 41, 75
- automatic redial
 - activating 70
 - using 33–34

B

- backlight 70
- banner text 69
- barring calls 164–165
- battery
 - car kit charger time 150
 - charging 24
 - extending battery life 31–32, 170
 - installing 21–22
 - level indicator 28, 29
 - meter 64
 - removing 23
- blackjack 132–133
- block cursor, defined 50
- browser alerts 61
- browser. *See* micro-browser

C

- calculator 128–130
- calendar. *See* datebook
- call
 - adding digits after phone number 75
 - alert type, selecting 137
 - alert, creating 138–142
 - alert, muting 36
 - alert, setting 136

- call (continued)
 - answer options 67
 - answering 26
 - attaching phone number to
 - prefix digits 41
 - barring 164–165
 - call waiting 42
 - calling card 40
 - cost setup 66
 - credit limit 66
 - data call, setting 65
 - dialed calls list 41, 58
 - emergency number 35
 - ending 26
 - fax call, setting 65
 - hold 45
 - in-call timer 65–66
 - incoming call type, setting 65
 - international access code,
 - dialing 40
 - placing 25
 - privacy 34
 - received calls list 41, 58
 - receiving 26
 - secure connection 34
 - sending 25
 - speakerphone, activating 45
 - talk then data 159
- call (continued)
 - talk then fax 159
 - terminating 37
 - timing 77
 - transferring 43–45
 - unanswered call 34–35
 - voice dial 41
- call barring 164–165
- call cost information 78–79
- call forwarding
 - defined 143
 - status, checking 145
 - using 144–145
- call timers
 - described 77
 - resetting 80
 - viewing 79
- call waiting 42
 - activating/deactivating 67
- caller ID
 - incoming calls 34, 35
 - outgoing calls 66
- calling card call 40
- calling line identification. *See* caller ID
- car kit
 - automatic answer 147–148
 - automatic hands-free 148
 - charger time 150
 - power-off delay 149

- clock
 - defined 29
 - illustration 28
- codes. *See* passwords
- computer
 - connecting to phone 151–154
 - synchronizing data 91, 151
- conference call 43
- connecting external device 65
- contrast 70
- cost trackers
 - described 78–79
 - resetting 80
 - viewing 79
- credit available 63, 78
- credit information 64, 78
- currency converter 130
- cursor 49–50
- customer service, calling 60
- customizing the menu 146
- D**
- data call
 - connecting to external device 64, 151–154
 - incoming call format, setting 65
 - receiving 156–158
 - sending 155
- data call (continued)
 - talk then data call 159
 - wireless connection 153–154
- date, setting 69
- datebook
 - adding an event 97
 - alarm 97
 - calendar 94
 - changing event information 98
 - copying an event 99
 - day view 95
 - deleting an event 100
 - event view 96
 - reminders 97, 143
 - week view 94
- Datebook Menu** 94, 95, 96
- default passwords 160
- dialed calls list 41, 58, 73–75
- Dialing Menu** 159
- display
 - backlight 70
 - banner text 69
 - contrast 70
 - described 27–29
 - greeting 69
 - idle display 27
 - illustration 28

display (continued)

language 70

zoom 30, 70

drafts folder 61

E

earpiece

illustration 1

volume, adjusting 30

emergency number 35

end key

functions 1, 26

menu functions 46

ending a call 26

Enter Unlock Code message

162, 163

event alert 137

exchange rate, calculating

130

external device

connecting to phone

151–154

synchronizing data 91, 151

F

factory settings, resetting 70,

71

fax call

connecting to external

device 64, 151–154

fax call (continued)

incoming call format, setting

65

receiving 66, 156–158

sending 66, 155

talk then fax call 159

wireless connection

153–154

fixed dial

activating/deactivating 68

defined 59–60

dialing numbers 41, 59–60

editing numbers 59–60

storing an entry 82

flashing cursor, defined 49

FM Stereo Radio Headset 61,

101–104, 121

forwarding calls 143

4-way navigation key 1, 46

G

games 131–135

greeting, display 69

H

hands-free mode

automatic answer 147–148

automatic call routing 148

charger time 150

defined 147

hands-free mode (continued)
 power-off delay 149
 speakerphone, activating 45
headset
 automatic answer 147–148
 FM Stereo Radio Headset 61, 101–104, 121
headset jack 1
hold a call 45

I

idle display, defined 27
in use indicator
 defined 28
 illustration 28
inbox, text message 107
in-call timer 65–66
incoming call
 terminating 37
 type, setting 65
Incoming Call message 34
indicators
 alert setting 28, 29, 136
 battery level 28, 29
 in use 28
 menu 27, 28
 message waiting 28, 29
 missed call 34
 ring alert 29, 136

indicators (continued)
 roam 28
 signal strength 28
 silent alert 29, 136
 vibrate alert 29, 136
 voice message waiting 28, 29
 voice name 81
infrared connection
 setting 153–154
international access code 40
IrDA Link 65
IrDA link 151
iTAP software
 activating and deactivating 53
 capitalization 56
 deleting text 57
 entering numbers 56
 entering words 53–55
 punctuation 55

J

joystick 1, 46

K

key
 end 1, 26, 46
 4-way navigation 1, 46
 left soft key 1, 46, 146–147

- key (continued)
 - lock 164
 - menu 1, 26, 46
 - power 1, 24
 - right soft key 1, 46, 146–147
 - send 1, 25, 26, 73
 - voice 1, 85, 119–120
 - volume control 1
- keypad volume 137
- keypad, answering calls with 67

L

- language 70
- Last Calls Menu**
 - opening 74
 - options 75
- left soft key
 - customizing 146–147
 - functions 1, 46
- Line Not Secure** message 34
- link, IrDA 151
- lock
 - applications 68
 - keypad 164
 - phone 162–163
 - SIM card 165
 - voice notes 124

- lock application feature 68
- loud ring alert 29, 136

M

- making a call 25
- master clear 71
- master reset 70
- menu
 - customizing 146
 - Datebook Menu** 94, 95, 96
 - Dialing Menu** 159
 - entering text 51–57
 - features 58–72
 - language, setting 70
 - Last Calls Menu** 74–75
 - locking applications 68
 - My Tones Menu** 141, 142
 - navigating 10, 46–47
 - Phonebook Menu** 81
 - rearranging features 146
 - scroll feature 70
 - Text Msg Menu** 110–111
 - using features 10, 47–50
 - Voice Notes Menu** 120, 122, 123
- menu indicator
 - defined 27, 29
 - illustration 28
- menu key 1, 26, 46

message
 deleting 109–110
 dialing number from 39
 drafts folder 61
 inbox setup 107–108
 locking 109–111
 outbox 61, 114
 quick note 61
 reading 109–110
 reminders 105, 109, 143
 text 39, 61, 107–113
 voicemail 61, 105–106
message waiting indicator
 defined 29
 illustration 28
micro-browser
 browser alerts 61
 call a number from 127
 defined 126
 functions 127
 go back to previous page 127
 starting 126
microphone 1
mineblaster 133–135
missed call indicator 34
Missed Calls message 35
my telephone number 45, 63
my tones 138–142
My Tones Menu 141, 142

N

'n' character 40
network settings 71
notepad
 defined 36
 entering digits 36
 retrieving digits 76
number, viewing your own 26, 45, 63

O

one-touch dial
 setting preference 93
 using 38–39
optional accessory, defined 11
optional feature, defined 11
outbox 61, 114

P

paddleball 135
passwords
 changing 160
 default 160
 if you forget a password 161–162
pause character 40
phone
 accessories, optional 11
 accessories, standard 20

- phone (continued)
 - active phone line, changing 64
 - alert, muting 36
 - answer options 67
 - connecting an external device 65
 - connecting to external device 64, 151–154
 - credit available 63, 78
 - credit information 64
 - credit limit 66
 - date, setting 69
 - erase user-entered information 71
 - feature specifications 64
 - keypad, answering calls with 67
 - keypad, locking and unlocking 164
 - language, setting 70
 - locking 162–163
 - network settings 71
 - one-touch dial 38–39
 - passwords 160, 161–162
 - reset all options 70
 - secure connection 34
 - security code 161
 - specifications 64
 - speed dial, using 37–38
- phone (continued)
 - startup greeting 69
 - text in idle display 69
 - time, setting 69
 - turning on/off 24
 - unlock code 162
 - unlocking 25, 162–163
 - voice dial 41
 - wireless connection 153–154
- phone number
 - adding digits after 75
 - attaching to prefix digits 41
 - attaching two numbers 75
 - international access code, dialing 40
 - redialing 33
 - viewing your own 26, 45, 63
 - voice dial 41
- phonebook
 - attaching phone number to prefix digits 41
 - attaching two numbers 75
 - capacity, checking 91
 - copying entries 88–90
 - deleting an entry 87
 - dialing an entry number 86
 - editing an entry 87
 - entry name 81

phonebook (continued)
 fields 81
 number type indicator 81
 one-touch dial 38–39
 phone number 81
 sorting entries 92–93
 speed dial number 37, 81,
 83
 speed dial, using 37–38
 storing an entry 82–84
 synchronizing entries 91,
 151
 voice name entry 84–85
 voice name indicator 81

Phonebook Menu 81

PIN code
 activating/deactivating 165
 protecting SIM card 165

PIN2 code 60

power key 1, 24

predictive text entry
 activating and deactivating
 53

 capitalization 56

 deleting text 57

 entering numbers 56

 entering words 53–55

 punctuation 55

preferred SIM card 70

privacy, call 34

Q

quick dial
 setting number 69
 using 60
quick note 61

R

radio 101–104

received calls list 41, 58,
 73–75

receiving a call 26

recent calls 73–75

 adding digits after phone
 number 75

 attaching phone number to
 prefix digits 41

 attaching two numbers 75

redial

 automatic redial 33–34

 busy number 33

reminders

 datebook 97

 setting 143

 text message 109

 voicemail message 105

right soft key

 customizing 146–147

 functions 1, 46

- ring alert
 - creating 138–142
 - indicators 29, 136
 - muting 36
 - setting 136
 - type, selecting 137
- ring and vibrate alert
 - indicator 29, 136
 - muting 36
- ringer
 - volume, adjusting 30, 137
- roam indicator
 - defined 28
 - illustration 28
- S**
- scroll feature 70
- secure connection 34
- security code 161
- send key 1, 25, 26, 73
- sending a call 25
- service dial
 - defined 59
 - dialing numbers 41
- short message service. *See* text message
- shortcuts
 - creating 116–117
 - standard 115
 - using 118
- signal strength indicator
 - defined 28
 - illustration 28
- silent alert indicator 29, 136
- SIM applications 62
- SIM card
 - applications 62
 - defined 20
 - installing 20–21
 - PIN code entry 25
 - precautions 20
 - protecting 165
 - service phone numbers 59
 - setting preferred card 70
 - unlocking 25
- SIM PIN code
 - activating/deactivating 165
 - protecting SIM card 165
- SIM PIN2 code 60
- SMS. *See* text message
- soft keys
 - customizing 146–147
 - functions 46
 - illustration 1
- soft ring alert 29, 136
- speakerphone 45
- speed dial
 - changing number 83
 - number, defined 37

- speed dial (continued)
 - sorting phonebook entries
 - by 92
 - using 37–38
- standby time, increasing 32
- synchronizing data 91, 151

T

- talk and fax call 66
- talk then data call 159
- talk then fax call 159
- telephone number, viewing
 - your own 26, 45, 63
- text
 - activating/deactivating iTAP
 - software 53
 - block cursor 50
 - character chart 52
 - entering from keypad
 - 51–57
 - flashing cursor 49
 - iTAP software predictive text
 - entry 53–57
- text message 39, 61,
107–113
- Text Msg Menu**
 - opening 110
 - options 110–111
- time, setting 69

- timers
 - described 77
 - resetting 80
 - viewing 79
- transfer a call 43–45
- travel charger
 - charging phone battery 24
- TrueSync 91, 151

U

- unlock
 - keypad 164
 - phone 162–163
- unlock code 162

V

- vibrate alert
 - indicator 29, 136
 - muting 36
 - setting 136
 - type, selecting 137
- voice dial
 - dialing a number 41, 86
 - recording voice name
 - 84–85
- voice key
 - dialing a number 41
 - functions 1

voice key (continued)
 recording a voice name 85
 recording a voice note
 119–120
voice message waiting
 indicator 28, 29
voice name
 defined 84
 phonebook indicator 81
 recording 84–85
voice note
 defined 119
 deleting 125
 locking and unlocking 124
 playback controls 123
 playback screen 122
 playing 121–123
 recording 119–120
 viewing voice notes list 120
Voice Notes Menu 120, 122,
 123
voice shortcut
 creating 116–117
 defined 116
 using 118
voicemail 61, 105–106

volume
 earpiece 30
 keypad 137
 ringer 30, 137
volume keys 1, 30

W

wait character 40
warranty 184–191
Web pages
 functions 127
 viewing 126

Z

zoom setting 30, 70



MOTOROLA

Wireless Phone Safety Tips

"Safety is your most important call!"

Your Motorola wireless telephone gives you the powerful ability to communicate by voice—almost anywhere, anytime, wherever wireless phone service is available and safe conditions allow. But an important responsibility accompanies the benefits of wireless phones, one that every user must uphold.

When driving a car, driving is your first responsibility. If you find it necessary to use your wireless phone while behind the wheel of a car, practice good common sense and remember the following tips:

- 1 Get to know your Motorola wireless phone and its features such as speed dial and redial.** If available, these features help you to place your call without taking your attention off the road.
- 2 When available, use a hands-free device.** If possible, add an additional layer of convenience to your wireless phone with one of the many Motorola Original™ hands-free accessories available today.



- 3 **Position your wireless phone within easy reach.** Be able to access your wireless phone without removing your eyes from the road. If you receive an incoming call at an inconvenient time, if possible, let your voice mail answer it for you.
- 4 **Let the person you are speaking with know you are driving; if necessary, suspend the call in heavy traffic or hazardous weather conditions.** Rain, sleet, snow, ice, and even heavy traffic can be hazardous.
- 5 **If you receive an incoming call at an inconvenient time do not take notes or look up phone numbers while driving.** Jotting down a “to do” list or going through your address book takes attention away from your primary responsibility—driving safely.
- 6 **Dial sensibly and assess the traffic; if possible, place calls when you are not moving or before pulling into traffic.** Try to plan calls when your car will be stationary. If you need to make a call while moving, dial only a few numbers, check the road and your mirrors, then continue.
- 7 **Do not engage in stressful or emotional conversations that may be distracting.** Make people you are talking with aware you are driving and suspend conversations which have the potential to divert your attention away from the road.
- 8 **Use your wireless phone to call for help.** Dial 9-1-1 or other local emergency number in the case of fire, traffic accident or medical emergencies.*

- 
- 9 **Use your wireless phone to help others in emergencies.** If you see an auto accident, crime in progress or other serious emergency where lives are in danger, call 9-1-1 or other local emergency number, as you would want others to do for you.*
- 10 **Call roadside assistance or a special non-emergency wireless assistance number when necessary.** If you see a broken-down vehicle posing no serious hazard, a broken traffic signal, a minor traffic accident where no one appears injured, or a vehicle you know to be stolen, call roadside assistance or other special non-emergency wireless number.*
- PRELIMINARY

* Wherever wireless phone service is available.

Check the laws and regulations on the use of wireless telephones and their accessories in the areas where you drive. Always obey them. The use of these devices may be prohibited or restricted in certain areas.

For more information,
please call
1-888-901-SAFE
or visit the
CTIA Web site at
www.wow-com.comTM

