



POLAR M600



USER MANUAL

CONTENTS

- Contents 2
- Getting Started14
 - Introduction to the Polar M600 14
 - Button functions on the M600 15
 - Front button15
 - Side power button 15
 - Charging the M600 16
 - Battery Operating Time 17
 - Low Battery Notification 17
 - Turning the M600 on and off 17
 - To turn the M600 on 17
 - To turn the M600 off 17
 - Setting up your Polar M600 17
 - To get ready for setup 17
 - To pair your smartphone with Polar M600 18
 - To activate the Polar app on the M600 18
 - Connecting the M600 to Wi-Fi 19
 - To turn Android Wear cloud sync on 19
 - To turn Wi-Fi on and off 19
- Using the M600 20
 - M600 features available for Android and iOS 20
 - Navigating the M600 21
 - Using the touchscreen 21
 - Wrist gestures 21

To turn wrist gestures on	22
Voice actions	22
To use voice actions	22
What can you do with voice actions	22
Dimming and waking up the screen	22
To dim the screen	22
To wake up the screen	23
Menu structure	23
Home screen	25
To change the watch face	25
Cards	25
To view cards	25
To hide card preview	25
To take action on the cards	25
To dismiss a card	26
To bring back a dismissed card	26
Status icons	26
Apps menu	28
To open the apps menu	28
To open and use apps	28
To get more apps	29
Agenda	29
To see your schedule using your voice	29
To see your schedule using the touchscreen	29
Alarm	29

To set an alarm using your voice	29
To set an alarm using the app	29
To turn off an alarm when it goes off	29
To snooze an alarm	29
Find my phone	30
To make your phone ring	30
Fit	30
To see your step count using your voice	30
To see your step count using the app	30
To see your current heart rate using your voice	30
To see your current heart rate using the app	30
Polar app	30
Training with the Polar app on your M600	30
Sport profiles	31
Polar features	31
Reminders	31
Reminders on M600 paired with an Android phone	32
To set a reminder using your voice	32
To set a reminder using the app	32
To mark a reminder as done using the app	32
Reminders on M600 paired with an iPhone	32
To sign in to the Google app and turn on Google Now	32
To delete reminders from your iPhone	32
Stopwatch	32
To start the stopwatch using your voice	33

To start the stopwatch using the touchscreen	33
To pause the stopwatch	33
To restart the stopwatch	33
To reset the stopwatch	33
Timer	33
To set a timer using your voice	33
To set a timer using the app	33
To pause the timer	33
To restart the timer	33
To reset the timer	34
To dismiss the timer	34
Together watch face	34
What you can do with the Together watch face	34
Translate	34
Communication	35
Text messages on the M600	35
Reading text messages on your M600	35
To read a text message	35
Replying to text messages from the M600	35
To reply to a text message using your voice	35
Sending text messages from your M600	35
To send a text message using your voice	35
Phone calls	36
Handling incoming calls	36
To answer an incoming call	36

To reject an incoming call	36
To reject an incoming call with a predefined text	36
Making phone calls	36
To make a phone call using your voice	37
To make a phone call using the touchscreen	37
Emails	37
Reading emails	37
To read emails	37
Replying to emails	37
To reply to emails	37
Sending emails	37
To send an email using voice command	38
To send an email using the touchscreen	38
Emails on M600 paired with an iPhone	38
To turn on Rich Gmail cards	38
Music on the M600	38
To control the music from your smartwatch	38
Route directions	39
To get turn-by-turn directions	39
To start using other M600 features during the turn-by-turn navigation	39
To return to the navigation	39
To cancel the navigation	39
To find a place or a business	39
Quick answers	39
To get quick answers	39

Standalone usage of the M600	40
Training with Polar	41
Polar app and Polar Flow	41
Polar app	41
Getting the app	41
Polar Flow app	41
Training data	41
Activity data	41
Changing settings and planning your training	42
Polar Flow web service	42
Feed, Explore and Diary	42
Progress	42
Community	42
Programs	42
Polar app menu	43
Training	43
My day	43
Sync	43
Navigating the Polar app	44
To open the Polar app	44
Using the touchscreen and wrist gestures to navigate the Polar app	44
To browse menus, lists and summaries	44
To choose items	44
To go back one step	44
Using the front button to navigate the Polar app	44

Using your voice to navigate the Polar app	45
To start a training session	45
To pause a training session	45
Training with Polar app	45
Wearing your M600	45
Starting a training session	46
To start a training session	46
To enable/disable permissions	47
Starting a training session with a target	47
To start a training session with a target	47
During training	48
Training views	48
To browse through the training views	48
Automatic lap view	48
To see the Automatic lap view	48
To see the previous laps	48
To exit the Polar app without stopping your training session	49
To return to your training session	49
Training summary during training	49
To see the training Summary view	49
Pausing/Stopping a training session	50
To pause a training session	50
To continue a paused training session	50
To stop a training session	51
After training	51

Training summary on your M600	51
To view your training summary later	53
Training data in Polar Flow app	53
Training data in Polar Flow web service	53
GPS features	53
Syncing	54
Automatic syncing of training data	54
Syncing changed settings	54
To sync activity data and changed settings manually (iPhone users)	54
Planning your training	55
To create a Training Target in the Polar Flow web service	55
Quick Target	55
Phased target	55
Pairing the Polar app with a heart rate sensor	55
To pair a Polar Bluetooth® Smart heart rate sensor with the Polar app on your M600	56
To unpair a Polar Bluetooth® Smart heart rate sensor from the Polar app	56
Polar Features	57
24/7 Activity Tracking	57
Activity Goal	57
Activity data	57
Inactivity alert	58
Sleep information in the Polar Flow app and web service	58
Activity data in the Polar Flow app and web service	59
Heart rate zones	60
Sport profiles	61

Polar Sport profiles in Flow Web Service	62
To add a Sport profile	62
To edit a Sport Profile	62
Basics	62
Heart Rate	63
Speed/Pace settings	63
Training views	63
Gestures and Feedback	63
GPS and altitude	63
Polar Smart Coaching features	63
Activity Benefit	64
Smart Calories	64
Training Benefit	65
Running program	66
Settings	67
Accessing settings	67
To open the Settings menu using the side power button	67
To open the Settings menu using your voice	67
To open the Settings menu using the touchscreen	67
Screen settings	67
To adjust the brightness level of the screen	67
To boost brightness temporarily	67
Changing the watch face	67
To change the watch face from the M600	68
To change the watch face from your phone	68

Turning the Always-on screen on/off	68
To change the setting from the M600	68
To change the setting from your phone	68
Turning the automatic screen lock on/off	68
To turn the automatic screen lock on	68
To turn the automatic screen lock off	69
To adjust the font size	69
To zoom in and out on the screen of your M600	69
Notification settings on the M600	69
Muting the connected phone	69
To mute connected phone	69
Block specific apps from sending notifications	70
To block apps from your watch	70
To block apps from your phone	70
To unblock an app	70
Stop your watch from vibrating for notifications	70
Date and time settings	70
To set date and time	70
Airplane mode	71
To turn the airplane mode on/off	71
Theater mode	71
To turn the theater mode on	71
To turn the theater mode off	71
Permissions	71
To edit the permission settings	71

Language settings	72
Restarting and resetting	73
To restart the M600	73
To reset the M600 to factory settings	73
Updating software	73
To manually check for an update	73
To install the software update	73
Updating the Polar app	74
Important Info	75
Taking care of your M600	75
Storing	75
Service	75
Removing the wristband	76
To remove the wristband	76
To attach the wristband	76
Disposal information	76
Precautions	76
Interference	76
Minimizing Risks When Training	77
Distraction	78
Technical Specification	78
Polar M600	78
Water Resistance	79
Limited International Polar Guarantee	79
Compliance Statement	80

GETTING STARTED

INTRODUCTION TO THE POLAR M600

Congratulations on your new Polar M600!

Polar M600 combines the best of both worlds: leading heart rate technology and the power of Android Wear™. It's perfect for tracking your training and 24/7 activity with the Polar app.

The Polar M600 sports watch works with smartphones running Android™ 4.3+ or iOS® 8.2+. iPhone users need to have at least model 5 or later. You can visit g.co/WearCheck on your phone to see if it's compatible with Android Wear. Pair your new Polar M600 with your smartphone and enjoy the Android Wear smartwatch features. You can, for example:

- Get [notifications](#) from your phone to your watch
- Manage [phone calls](#)
- Read and reply to [text messages](#) and [emails](#)

The smartwatch also supports [wrist gesture](#) controls and [voice actions](#).

The M600 also has a wrist-based heart rate monitor and integrated [GPS](#). And when you train with the [Polar app](#), you'll get the unique Polar smart coaching features to your smartwatch. Let your new sport-optimized smartwatch encourage you towards a more active and healthier lifestyle.

[Polar Flow](#) is the online window to your training, activity and sleep. Together with the Polar Flow web service and the Polar Flow app on your smartphone, your M600 helps you train effectively and understand how your choices and habits affect your well-being.

This user manual helps you get started with your new Polar M600 sports watch. To see M600 video tutorials and FAQs, go to support.polar.com/en/M600. For more information on Android Wear, visit the [Android Wear Help Center](#).

BUTTON FUNCTIONS ON THE M600

The Polar M600 has two buttons: the front button and the side power button.



1. Front button
2. Side power button
3. Touchscreen

FRONT BUTTON

The front button is a handy way to use the [Polar app](#) throughout your training session. You can use the front button to:

- quickly open the Polar app from the home screen
- to open **Training** in the main menu
- to choose the sport you want to do and to start the training session
- to stop the training session

For more information, see [Navigating the Polar app](#).

SIDE POWER BUTTON

The side power button has several functionalities:

- press the button once to wake up the screen of your M600
- press the button once on the active home screen to dim the screen or to turn the screen off, depending on your [Always-on screen setting](#)
- press the button once to get to the home screen from anywhere in the watch
- press the button twice anywhere in the watch to turn theater mode on
- press the button once when the watch is in theater mode to turn the screen back on again
- press and hold the button until the watch vibrates to open the apps menu
- press and hold the button until the screen turns off to power down your smartwatch
- when the M600 is turned off, press and hold the button to turn the M600 on
- press and hold the button until you see the Polar logo to restart the watch
- press the button three times anywhere in the watch to temporarily boost the brightness of the screen

CHARGING THE M600

The M600 has an internal, rechargeable battery. Rechargeable batteries have a limited number of charge cycles. You can charge and discharge the battery over 300 times before a notable decrease in its capacity. The number of charge cycles also varies according to use and operating conditions.

You can charge your M600 via a computer's USB port with the charging cable provided to you in the sales package. You can also charge your M600's battery using a wall outlet (a USB power adapter is not included in the product set). If you use a USB power adapter, make sure that the adapter is marked with "output 5Vdc" and that it provides a minimum of 500mA. Only use an adequately safety approved USB power adapter (marked with "LPS", "Limited Power Supply" or "UL listed").

The magnetic end of the cable snaps into place to the M600's charging port when it's properly connected to your smart watch. The M600 also vibrates briefly when the charging begins. If the smartwatch is turned on when you plug it into charge, you'll see a small lightning bolt icon on the home screen of your M600. You can see the battery charging level of your watch by swiping down halfway from the top of the home screen. If the smartwatch is turned off when you plug it into charge, a battery icon animation begins to fill up on the display. When the battery icon is full, the M600 is fully charged. It may take up to two hours to fully charge an empty M600 battery.

1. Wrist-based heart rate monitor sensors
2. Charging port



⚠ When you've finished charging the battery of your M600, remove the charging cable from the USB port of your computer or from the wall adapter. If the charging cable is left connected to a power source, the magnetic end of the cable attracts iron-containing objects and can short-circuit, possibly causing circuit damage, overheating, fire or explosion.

i Don't leave the battery fully discharged for a long period of time or keep it fully charged all the time because it may affect the battery life time. Also, do not charge the battery in temperatures under 0°C or over +40°C or when the charging port is wet or sweaty. If the charging port of your M600 has gotten wet, let it dry before plugging in the charging cable.

BATTERY OPERATING TIME

The battery operating time is

- 2 days / 8 hours of training on M600 paired with an Android phone.
- 1 day / 8 hours of training on M600 paired with an iPhone.

The operating time depends on many factors, such as the temperature of the environment in which you use your M600, the features you use, if the screen is in the Always-on mode, and battery aging. The operating time is significantly reduced in temperatures well below freezing. Wearing the M600 under your overcoat helps to keep it warmer and to increase the operating time.

LOW BATTERY NOTIFICATION

When the charge in your M600's battery drops down to 15% or less, you'll see a card stating the charge level and the status of battery saver mode. You can swipe left on the card to see and tap **Turn on/off battery saver**. The battery saver mode will automatically turn on when the battery charge level hits 5%.

Since the GPS recording is NOT on in the battery saver mode, you'll get a notification card if the battery saver mode is on when you're about to start training with the Polar app or if the battery falls below 5% while you're training.

When the display doesn't wake up from a wrist gesture or a press of the side power button, the battery is empty and M600 has gone to sleep mode. In that case, you need to charge your M600. If the battery is totally drained, it may take a while for the charging animation to appear on the display.

 You can quickly see how much battery your M600 has left by swiping down from the top of the home screen.

TURNING THE M600 ON AND OFF

TO TURN THE M600 ON

- Press and hold the side power button until you see the Polar logo appear on the screen.

TO TURN THE M600 OFF

1. [Navigate to the Settings menu](#), and scroll the menu down to find and tap **Power off**.
2. Confirm turning the power off by tapping the check mark icon.

SETTING UP YOUR POLAR M600

The Polar M600 sports watch is compatible with smartphones running Android 4.3+ or iOS 8.2+. iPhone users need to have at least model 5 or later. You can visit g.co/WearCheck on your phone to see if it's compatible with Android Wear.

TO GET READY FOR SETUP

1. To make sure there's enough charge in your M600 during the setup, plug the charging cable into a powered USB port on your computer or to a USB power adapter and a wall outlet. Make sure that the adapter is marked with "output 5Vdc" and that it provides a minimum of 500mA.
2. Turn on your M600 by pressing and holding the side power button until you see the Polar logo. After that, the initial powering up of the operating system will take a few minutes.

3. Swipe left on the touchscreen of your M600 to begin the setup, then swipe up or down to find and tap the **language** of your choice. If you choose a language you can't use to finish the setup, press and hold the side power button until the M600 restarts the setup.
4. Make sure your phone is connected to the Internet and has Bluetooth turned on.
5. Make sure the Google™ Search and the Google Play™ services apps (on Android phones) or the App Store app (on iPhones) are up to date on your phone.
6. Keep your M600 and the phone close to each other during the setup.

TO PAIR YOUR SMARTPHONE WITH POLAR M600

You need to install the Android Wear app on your phone to connect your smartwatch and your phone.

1. Install the Android Wear app on your smartphone from Google Play or the App Store. Or, if you already have the Android Wear app on your phone, make sure it's the latest version.

 *If you already have the Android Wear app installed on your smartphone and another device connected to it, open the mobile app and (on an Android phone) choose **Pair with a new watch** from the drop-down menu next to your device name at the top of the screen, or (on an iPhone) tap the three dots at the top right corner of the screen, and choose **Pair with a new wearable**. Then continue to follow the instructions below from step number 3.*

2. When you open the Android Wear app on your phone, it automatically prompts you to start setting up your watch.
3. Swipe left on your M600 to see its watch code, and tap the same code on your phone.
4. Make sure the pairing code on your M600 matches with the pairing code on your phone, and tap **Pair** or **OK**.
5. You'll see a quick confirmation message on both the M600 and your phone when the pairing is completed. After that, it takes a while for the M600 to finish syncing with your phone. The smartwatch will open to the time view once the sync is done.
6. You need to turn on watch notifications so that your phone can send updates to your watch. Follow the onscreen instructions on your phone to do this. If you have used the Android Wear app earlier with another device, you should have already allowed notifications for the app. You can check this in your phone's settings.

After the initial sync, your new smartwatch launches a tutorial on how to get started with the watch. You can swipe through the tutorial and continue the setup after that. Or you can skip the tutorial for the time being by swiping the tutorial card down, and you can later get back to the tutorial by swiping the tutorial card up again from the bottom of the home screen.

TO ACTIVATE THE POLAR APP ON THE M600

To get the most out of your new Polar M600, and to be able to use Polar's activity tracking and training features, you need to activate the Polar app on the smartwatch. To do this, first you need to install the Polar Flow app on your smartphone. If you already have the Polar Flow mobile app installed on your smartphone, make sure it's the latest version, then continue the setup from step number 2 below.

1. Go to Google Play or the App Store on your phone, and search and download the Polar Flow app.
2. Open the Polar Flow app on your phone. iOS users: To proceed you need to open the Polar app on your M600 by pressing the front button. Then tap **Start** on your phone.
3. Choose whether you'll wear the M600 on your left or right wrist, then tap **Continue**. iOS users: tap **Save and sync**.
4. Sign in with your Polar account or create a new one.
5. You'll see "Setup completed" when you've successfully activated the Polar app on your M600.

You're ready to go, have fun!

You can start using the Polar app on the M600 by pressing the front button.

 Please note that you can pair your M600 with only one Android phone, iPhone or tablet at a time. You can pair your M600 with a new tablet or phone after you first reset your smartwatch to factory settings.

CONNECTING THE M600 TO WI-FI



Applicable only to Polar M600 paired with an Android phone

Your Polar M600 Android Wear supports Wi-Fi and can automatically connect to saved Wi-Fi networks if it loses the Bluetooth connection with your phone. When your Android phone is connected to either a Wi-Fi or mobile network and your M600 is connected to a Wi-Fi network, your smartwatch can stay synced with your phone, and you can get notifications and Quick answers even if you leave your phone to another room.

Your phone and M600 share data through the Android Wear cloud sync. So, you must turn cloud sync on in the Android Wear app on your phone.

TO TURN ANDROID WEAR CLOUD SYNC ON

1. In the Android Wear app on your phone, tap the Settings icon.
2. Tap **Privacy & personal data**.
3. Then tap **Cloud sync**.
4. Move the switch to **On** position.

TO TURN WI-FI ON AND OFF

1. [Navigate to the Settings menu](#) on your M600, and swipe down to find and tap the **Wi-Fi** settings.
2. Tap **Wi-Fi OFF** to turn Wi-Fi on. Or, if you want to turn Wi-Fi off, scroll down to find and tap **Wi-Fi Automatic**, and verify turning the Wi-Fi off by tapping the check mark icon.

See [Android Wear Help](#) for more information on Wi-Fi on your wearable.

USING THE M600

M600 FEATURES AVAILABLE FOR ANDROID AND IOS

The user experience of Polar M600 is a bit different depending on whether you've paired it with a smartphone running an Android operating system or iOS. Below, you can see examples of the available features for each operating system.

	M600 paired with an Android phone	M600 paired with an iOS phone
Operating system compatibility	Android 4.3 or later	iPhone model 5 or later, running iOS 8.2 or later
Operating time	Up to 48 hours usage time or 8,5 hours training time	
Wi-Fi support	●	
Default apps	●	●
Download more apps	●	
Use wrist gestures	●	●
Use voice actions	●	●
Train with Polar app	●	●
Automatic syncing of training data to Polar Flow app on paired phone	●	●
Read texts	●	●
Reply texts	●	
Send texts	●	
Answer incoming phone call	●	●
Reject incoming phone call	●	●
Reject incoming phone call with a pre-defined text	●	
Initiate phone calls	●	
Read emails	●	● (Gmail™)
Reply emails	●	● (Gmail™)

Send emails	●	
Control music playing on your phone	●	●
Listen to music from your M600	●	
Get turn-by-turn directions	●	
Find a place or a business	●	●
Get quick answers	●	●

NAVIGATING THE M600

You can navigate your smartwatch in many ways. Find out more detailed information on the different styles of getting around in the M600 from the links below:

- [Touchscreen](#)
- [Wrist gestures](#)
- [Voice actions](#)
- [Button functions](#)

See also how to [dim or wake up the screen](#) of your smartwatch.

USING THE TOUCHSCREEN

You can navigate the M600 using the touchscreen. You can use the touchscreen by swiping, tapping, tapping and holding, or drawing.

- You can swipe left, right, up and down to scroll menus and cards.
- You can tap the touchscreen to wake up the watch, to open apps and cards, and to select items.
- You can tap and hold the home screen to change the watch face. In the Polar app, you can stop recording a training session by tapping and holding the stop icon. For more information on using the Polar app, see [Polar app](#).
- You can also draw on the touchscreen with your finger. For example, you can draw emojis to emails, or you can set up a pattern to unlock the locked screen of your M600.

WRIST GESTURES

You can use wrist gestures to navigate your M600. You can flick your wrist in and out to scroll cards and menus up and down. You can push your arm down to select and open items. And you can also pivot your arm up to go back to the previous screen.

 See [Navigating the Polar app](#) for information on which wrist gestures work while training with the Polar app.

Before you can use the wrist gestures, you have to turn them on.

TO TURN WRIST GESTURES ON

1. [Navigate to the Settings menu](#), and find and tap **Gestures**.
2. Turn the wrist gestures on by tapping **Wrist gestures OFF**. (If **Wrist gestures ON** is displayed, the wrist gestures are already turned on.)

 You can watch a tutorial on how to use the wrist gestures, and at the same time practice using them. You can find the tutorial in the same Gestures menu where you turned on the wrist gestures. Scroll the Gestures menu to find and tap **Launch tutorial**. For more detailed info on what you can do with wrist gestures, see [Android Wear Help](#).

VOICE ACTIONS

You can use your voice to perform simple actions on your M600.

Please note that some voice actions may not be available in all languages. Visit [Android Wear Help](#) to see which languages are supported for voice actions.

 See [Operating the Polar app](#) for information on which voice actions work with the Polar app.

TO USE VOICE ACTIONS

1. Make sure the home screen of your M600 is active.
2. Say "Ok Google". If your voice is recognized, you'll see a picture of a microphone with the text **Speak now**.
3. Say the action you want to perform. For example, you can say "Start a run."

 To ensure the voice actions function properly, you should speak clearly, ideally in quiet places, and avoid speaking in dialectal accents.

WHAT CAN YOU DO WITH VOICE ACTIONS

After you've said "Ok Google" and your voice is recognized, you can swipe up to see a list of the voice actions you can perform on the M600. You can also get to the list by swiping left three times from the home screen. You can find more detailed instructions from the [Android Wear Help](#) site.

[From this page](#) you can find instructions on how to change the apps that you use for voice actions.

See also the instructions in this manual under [Using the M600](#) to find out what else you can do using your voice, for example, how to [send texts](#) or how to get [Quick answers](#).

DIMMING AND WAKING UP THE SCREEN

The screen of your M600 will automatically dim when the smartwatch is left unused for a short while. You can also dim the screen manually.

TO DIM THE SCREEN

- Place your palm onto the screen until the watch vibrates.

OR

- Briefly press the side power button.

TO WAKE UP THE SCREEN

- Tap the screen.

OR

- Quickly raise the M600 in front of you.

OR

- Briefly press the side power button.


i Note that dimming the screen is applicable when the Always-on screen is turned on. If the Always-on screen is off, the screen of your M600 will turn off when the smartwatch is left unused for a period of time. Also, placing your palm onto the screen or briefly pressing the side power button will then turn the screen off.

MENU STRUCTURE


The starting point to getting around your smartwatch is the [home screen](#).




From the top of the home screen, you can pull down the Quick Settings menu. Keep swiping left in the menu to find all the following settings:




[Do not disturb/Notifications/Mute](#): tap to silence notifications on your M600.



[Theater mode](#): tap to turn theater mode on.




Brightness boost: tap to boost screen brightness temporarily.




Settings: tap to open the Settings menu.


From the right hand side of the home screen, you can get to the apps menu. Here, you'll find the applications that you have on your M600 and you can access the Settings menu.



On M600 paired with an Android phone, in the next menu to the right, you can access your contacts. The M600 shows contacts saved on your phone's contact list that you have communicated with recently. You can tap a contact to send an email, a text or to initiate a call.



The last menu to the right shows a list of the possible voice actions you can perform on your M600.



See Touchscreen, Wrist gestures, Voice actions and Button functions to learn the different ways to navigate your M600.

HOME SCREEN

On the home screen, you can view the current time. Depending on the watch face, you can also see the date.

You can change the watch face to suit your style.

TO CHANGE THE WATCH FACE

1. Tap and hold the home screen to open the watch face selection menu.
2. Then swipe left or right to find your preferred watch face.
3. Tap to choose the one you want to use.

By choosing the “Polar Jumbo” (the default watch face) or the “Polar Activity” as your watch face, you’ll be able to see the progress of your [daily activity](#) on the home screen when the screen is awake.



On the home screen, you can view [cards](#) that tell you different kind of important information and also view the status of your M600. To find out more about the different statuses, see [Status icons](#).

You can quickly get to the home screen from anywhere in your M600 by pressing the side power button or by shaking your wrist. To learn more about how to get around in your smartwatch see [Navigating the M600](#).

CARDS

Useful bits of information, like the weather, traffic information, or notifications of received emails, appear as cards on the screen of your M600.

To view cards

1. Swipe up from the bottom of the screen or turn your wrist away from you.
2. To see all the information on the card, tap the card.
3. To see more cards (if available), keep swiping up from the bottom of the screen or keep turning your wrist away from you.

To hide card preview

If you don't want to see a card that's peeking from the bottom of the screen right now:

- Swipe down on the card.

Find out how to [Turn off card previews](#) if you'd rather not see cards peeking out from the bottom of your watch screen.

To take action on the cards

Some cards have more details or available actions related to the info on them.

1. Swipe from right to left on the card to see the available actions or more details on the card's info.
2. Tap on your chosen action (if applicable). For example, you can archive received emails from your M600.

To dismiss a card

Once you've got all the info you need from a card:

- Swipe it from left to right to dismiss it.

If you dismiss a card on your M600, the related notification will be dismissed on your phone as well.

To bring back a dismissed card

If you want to bring back a card you just dismissed, you have a few seconds.

- Swipe down from the top of the screen to restore the card.

Or, if the dismissed card was the last card available:

1. Swipe up from the bottom of the screen.
2. Then tap the undo icon of a left-pointing u-turn arrow.

See how you can change the settings for notification cards in [Notification settings](#).

STATUS ICONS

The M600 displays the current status of the smartwatch with small indicator icons.

The following status icons may appear on the home screen of your M600:



Your M600 is disconnected from your phone



The battery is charging



Airplane mode is on



GPS monitoring for your locations is on

If the smartphone paired with your M600 runs Android version 6.0, also the following status icon may appear on the home screen of your M600 to show you have the Alarms only notification setting turned on:



Do not disturb mode is on

Changing this setting on the M600 will also change the setting on the phone and vice versa.

If the smartphone paired with your M600 runs Android version 5.0, also the following status icons may appear on the home screen of your M600 to show the status of your interruption setting:



None of the notifications come through



Only allow priority interruptions mode is on



All notifications come through

Changing these settings on the M600 will also change the settings on the phone and vice versa.

See [Android Wear Help](#) for more information on the different options to silence the notifications on your smartwatch.

If the smartphone paired with your M600 runs Android version 4.3 or 4.4 or iOS, also the following status icon may appear on the home screen of your M600 to show the notifications are muted on your smartwatch:




Notifications are muted

 *iPhone users note that if your phone is set to Do Not Disturb mode, your watch will not vibrate for notifications.*

APPS MENU

The apps menu displays icons for all the apps in use on your M600.



TO OPEN THE APPS MENU

- Swipe from right to left from the home screen.

OR

- You can also get to the apps menu from anywhere in the watch by pressing and holding the side power button until the watch vibrates and the apps menu appears.

TO OPEN AND USE APPS

- You can start using an app by tapping its icon in the apps menu.

OR

- You can also open an app when the home screen is active by saying "Ok Google, open (the app's name)".

The M600 includes the following default apps:

- [Agenda](#)
- [Alarm](#)
- [Find my phone](#)*
- [Fit](#)
- Flashlight
- [Polar](#)
- [Reminders](#) *
- [Stopwatch](#)
- [Timer](#)
- [Together](#) *
- [Translate](#)
- Weather

**Only on Polar M600 paired with an Android phone*

Any other apps you might see on your M600 apps menu were installed from your phone during setup. For any questions concerning these apps, please turn to the app developer.

TO GET MORE APPS



Applicable only to Polar M600 paired with an Android phone

You can get more apps from the Google Play Store. To see a list of recommended watch apps, open the Android Wear app on your phone and scroll down to "**Essential watch apps**". You can tap **MORE** to go to Google Play Store and open a bigger selection of suggested apps that support Android Wear.

See the Android Wear Help page about [Google apps that work with Android Wear](#).

AGENDA

Events saved in the calendar application on your phone appear automatically as cards on your M600. You can also pull up your schedule.

To see your schedule using your voice

1. Make sure the home screen is active and say "Ok Google."
2. To view today's schedule, say "Agenda."

To see your schedule using the touchscreen

- [Navigate to the apps menu](#), and find and tap **Agenda**.

Your schedule for the day opens.

ALARM

You can set an alarm to go off on your M600. When the alarm goes off, your M600 vibrates and displays a card.



Note that when you set an alarm on your M600, it won't go off on your phone.

To set an alarm using your voice

1. Make sure the home screen is active and say "Ok Google."
2. Say "Set an alarm for [the time you want]."

To set an alarm using the app

1. [Navigate to the apps menu](#), and find and tap **Alarm**.
2. Scroll the hour menu up and down, and set the wanted hour.
3. Move to set the wanted minutes by tapping the screen or swiping left.
4. Set the wanted minutes.
5. Tap **Set alarm**.

To turn off an alarm when it goes off

- Drag the alarm clock icon to the right.

To snooze an alarm

If you want to snooze an alarm when it goes off:

- Drag the Zs to the left.

FIND MY PHONE



Applicable only to Polar M600 paired with an Android phone

If you can't find your phone, you can use your M600 to make the phone ring even if the phone is set to mute or vibrate only.

To make your phone ring

1. [Navigate to the apps menu](#), and find and tap **Find my phone**.
2. If your phone is within range for the Bluetooth connection to work, your phone will start to ring. If not, try to move to get within a range of 10 meters or 33 feet from your phone with no solid objects in between.
3. You can stop the phone from ringing by tapping the X on the M600's screen or by opening your phone.



Note that the M600 must be connected to your phone using Bluetooth in order for this function to work.

FIT

With the Google Fit™ app, you can see how close you are to achieving your daily step goal. You can see the estimated amount of steps you've taken during the days of the past week as well as your current heart rate.

To see your step count using your voice

1. Make sure the home screen is active and say "Ok Google."
2. Say "Show me my steps."
3. Swipe up to see more details of your steps during the last seven days.

To see your step count using the app

- [Navigate to the apps menu](#), and find and tap **Fit**.

You can change your daily step goal by swiping left twice from the step count view.

To see your current heart rate using your voice

1. Make sure the home screen is active and say "Ok Google."
2. Say "Show me my heart rate."

To see your current heart rate using the app

1. [Navigate to the apps menu](#), and find and tap **Fit**.
2. Swipe once from right to left, and tap the heart icon to get a reading of your heart rate.

For more info on Google Fit on Android Wear devices, see [Android Wear Help](#).

POLAR APP

Training with the Polar app on your M600

Use the Polar app on your M600 to take full advantage of your sport-optimized smartwatch.

Find out what's in the Polar app and how to get around in it:

- [Navigating the Polar app](#)
- [Polar app menu structure](#)

Track your training sessions, and see, for example, your heart rate, speed, and distance during training:

- [Start a training session](#)
- [During training](#)
- [Pause/stop a training session](#)
- [After training](#)

See also our instructions on how to wear your M600 in order to get accurate heart rate measurements, and find out in what kind of sports we recommend wearing a Polar heart rate sensor with a chest strap to ensure reliable heart rate measurement:

- [Wearing your M600](#)
- [Pairing the M600 with a heart rate sensor](#)

Sport profiles

Separate profiles for all the sports you want to do with specific settings for each one of them. Adjust the sport profile settings to best suit your training needs:

- [Sport profiles](#)

Polar features

Polar's unique Smart Coaching features offer the best possible guidance on how to develop your training as well as helpful feedback on your progress. The Polar app on your M600 includes the following Polar **Smart Coaching** features:

- [24/7 activity tracking](#)
- [Smart calories](#)
- [Heart rate zones](#)
- [Training Benefit](#)
- [Running program](#)

Together with the Polar Flow mobile app and the Polar Flow web service, you can plan your training and achieve your training targets, analyze and learn about your performance, follow your progress, and share your sessions with others. See [Polar app and Polar Flow](#) for more information.

REMINDERS

See below for reminders on "Reminders on M600 paired with an iPhone" on the next page.

Reminders are saved to Google Now™. For the Google Now feature to work, you need to have at least version 5.6 of the Google app on your phone. You can download the Google app from Google Play or the App Store. You can find more information on other Google Now features and how to customize the Google Now notification cards from [Android Wear Help](#).

Reminders on M600 paired with an Android phone

You can set your M600 to remind you to do something at a specific time or location. Reminders appear as cards on the M600.

To set a reminder using your voice

1. Make sure the home screen is active and say "Ok Google."
2. Say "Remind me to (your task with a time or location)." For example, you can say "Remind me to go for a run in 2 hours" or "Remind me to call Jane when I get home."

To set a reminder using the app

1. [Navigate to the apps menu](#), and find and tap **Reminders**.
2. Tap the plus icon.
3. Speak your task with a time or location. For example, you can say "Watch the new TV show at seven."

To mark a reminder as done using the app

1. [Navigate to the apps menu](#), and find and tap **Reminders**.
2. Swipe the reminder you want to archive to either side.

If you mark a reminder as done, it won't appear in the list of reminders on your M600 anymore. You will still be able to see it in the past reminders in the Google app on your phone.

Reminders on M600 paired with an iPhone

If your M600 is paired with an iPhone, you can also set your M600 to remind you to do something at a specific time or location. Reminders appear as cards on the M600.

You can "To set a reminder using your voice " above. But not through the Reminder app on the M600. You can check your reminders and delete them only from the Google app on your iPhone. For this to work, you need to sign in to the Google app with the same Google account you use in the Android Wear app, and you need to turn on Google Now.

To sign in to the Google app and turn on Google Now

1. In the Google app on your iPhone, tap the Settings icon to open the Settings menu.
2. Tap **Sign in**, and choose the same Google account you use in the Android Wear app.
3. In the Settings menu, tap **Google Now**, and then tap **CONTINUE**.
4. To be able to use the Google Now feature, you need to agree to turn on the suggested Google Account settings. Tap **YES I'M IN**.
5. Use the switches to turn on **Location** and **Notifications**, and then tap **FINISHED**.

To delete reminders from your iPhone

1. In the Google app on your iPhone, tap your name and profile picture to open the Settings menu.
2. In the Settings menu, find and tap **Reminders**.
3. Tap the reminder you want to delete.
4. Tap **DELETE REMINDER** to remove the reminder.

STOPWATCH

You can use your M600 as a stopwatch.

To start the stopwatch using your voice

1. Make sure the home screen is active and say "Ok Google."
2. Say "Start stopwatch."
3. Start the stopwatch by tapping the play icon.

The stopwatch opens on the screen.

To start the stopwatch using the touchscreen

1. [Navigate to the apps menu](#), and find and tap **Stopwatch**.
2. Start the stopwatch by tapping the play icon.

The stopwatch opens on the screen.

To pause the stopwatch

- Tap the pause icon.

To restart the stopwatch

- Tap the play icon.

To reset the stopwatch

If you want to zero the stopwatch:

- Tap the reset icon.

TIMER

You can use your M600 as a countdown timer.

To set a timer using your voice

1. Make sure the home screen is active and say "Ok Google."
2. Say "Set a timer for (the amount of seconds, minutes or hours you want)."

The timer opens on the screen.

To set a timer using the app

1. [Navigate to the apps menu](#), and find and tap **Timer**.
2. Move between the hours, minutes and seconds by swiping or tapping the screen.
3. Press play to start the timer.

The timer opens on the screen.

To pause the timer

- Tap the pause icon.

To restart the timer

- Tap the play icon.

To reset the timer

If you want to begin the timer again:

- Tap the restart icon.

To dismiss the timer

When the timer goes off, your M600 vibrates. To dismiss the timer when it vibrates:

- Swipe right on the screen.

TOGETHER WATCH FACE



Applicable only to Polar M600 paired with an Android phone

With the interactive Together watch face, you can pair your watch with your friend's to stay connected throughout the day.

What you can do with the Together watch face

With the Together watch face you can connect with your friend and share the following:

- Emojis: You can draw or pick emojis to express yourself to your friend.
- Doodle: You can choose a color and sketch a background picture for your friend's watch face.
- Photo: You can send one of your 10 most recent photos to appear as the background image of your friend's watch face.
- Sticker: You can choose to brighten up your friend's watch face with a cute sticker.
- Your activity: You can share your status updates with your friend.

See [Android Wear Help](#) for more information on how to invite a friend to connect with you, what to do to accept an invitation, and how to start sharing your day with your friend.

TRANSLATE

You can use the Google Translate™ app to translate phrases:

1. [Navigate to the apps menu](#), and find and tap **Translate**.
2. You'll see two languages you can translate between. You can tap a language's name to change it.
3. Tap the microphone icon and say the phrase you want to translate.

The translation appears on the screen.

COMMUNICATION

You can use your M600 to read, reply and send text messages and emails. With the M600, you can also handle phone calls from your wrist.

Find out more from the links below:

- [Text messages](#)
- [Phone calls](#)
- [Emails](#)

 Note that there are some restrictions on the availability of the communication features depending on the operating system on your phone.

TEXT MESSAGES ON THE M600

READING TEXT MESSAGES ON YOUR M600

If you use notifications for text messages on your phone, you will see a card on your M600 when you get a new text.

To read a text message

- Swipe up the card.

REPLYING TO TEXT MESSAGES FROM THE M600

 Applicable only to Polar M600 paired with an Android phone.

You can reply to and send text messages directly from your wrist.

To reply to a text message using your voice

1. On the message notification card, swipe from right to left to see the actions you can take.
2. Tap **Reply**, and say your message.

Your message gets sent automatically.

See [Android Wear Help](#) for instructions on how to reply a text with emoji.

SENDING TEXT MESSAGES FROM YOUR M600

 Applicable only to Polar M600 paired with an Android phone.

You can also send texts from the M600 to people on the contact list. The M600 shows contacts saved on your phone's contact list that you have communicated with recently.

To send a text message using your voice

1. Make sure the home screen is active and say "Ok Google."
2. Say "Send a text to [a name saved in your contacts]."
3. Then say the text you want to send.

Your message gets sent automatically.

See [Android Wear Help](#) for instructions on other ways to send texts and what other apps you can use to send messages.

PHONE CALLS


HANDLING INCOMING CALLS

When you get a call on your phone, you can see who's calling on the screen of your M600. You can answer or reject the call from your M600.




To answer an incoming call

1. To pick up an incoming call, swipe from left to right on the screen of your M600.
2. Use your phone to communicate with the caller.



To reject an incoming call

- Swipe from right to left on the screen of your M600.



To reject an incoming call with a predefined text



Applicable only to Polar M600 paired with an Android phone

1. Swipe up on the screen of your M600.
2. Find and tap your preferred message.

MAKING PHONE CALLS



Applicable only to Polar M600 paired with an Android phone

You can also initiate calls from the M600 to people on the contact list. The M600 shows contacts saved on your phone's contact list that you have communicated with recently.

To make a phone call using your voice

1. Make sure the home screen of your M600 is active and say "Ok Google."
2. Say "Call [a name saved in your contacts]."
3. The phone call will open on your phone. Use your phone to communicate with the person your are calling.

To make a phone call using the touchscreen

1. From the home screen, swipe twice from right to left to see your contact list.
2. Find and tap the name of your contact who you want to call.
3. Tap **Call**.
4. The phone call will open on your phone. Use your phone to communicate with the person your are calling.

 *Note that your phone must be connected to your M600 using Bluetooth for you to be able to see the incoming calls on your smartwatch and for you to be able to initiate calls using the M600.*

EMAILS

See below for more details on handling "Emails " above.

READING EMAILS

If you use email notifications on your phone, you will see a card on your M600 when you get new mail.

To read emails

- Swipe the card up.

You can tap the card to see more of the message. If you have several new emails, you'll see a bar at the bottom of the card showing how many new emails you've got. You can tap the bar to see the other messages.

REPLYING TO EMAILS

You can reply to emails from your wrist.

To reply to emails

1. On the email notification card, swipe from right to left to see the actions you can take.
2. Tap **Reply**, and choose whether you want to speak your message, draw an emoji, or use one of the predefined messages.

Your spoken message gets sent automatically when you're finished. If you use emojis or predefined messages, send your message by tapping the check mark icon.

SENDING EMAILS



Applicable only to Polar M600 paired with an Android phone

You can also send emails from the M600 to people on the contact list. The M600 shows contacts saved on your phone's contact list that you have communicated with recently.

To send an email using voice command

1. Make sure the home screen is active and say "Ok Google."
2. Say "Email {a name saved in your contacts})."
3. Speak the message you want to send.

Your message gets sent automatically.

To send an email using the touchscreen

1. From the home screen, swipe twice from right to left to see your contact list.
2. Find and tap the name of your contact who you want to email.
3. Tap **Email**, and choose whether you want to speak your message, draw an emoji, or use one of the predefined messages.
4. Follow the on-screen instructions to finish sending the email.

EMAILS ON M600 PAIRED WITH AN IPHONE

If you use email notifications on your phone, you will see a card on your M600 when you get new mail no matter what email app you use on your iPhone.

If you use Gmail, you can turn on Rich Gmail cards, and then you'll be able "To read emails" on the previous page, "To reply to emails" on the previous page, and to delete or archive emails from your M600.

To turn on Rich Gmail cards

1. In the Android Wear app on your iPhone, tap the **Settings** icon.
2. Tap **Email cards**.
3. Use the switch to enable **Rich Gmail cards**.
4. Return to the Settings menu and tap **DONE**.

Find out more about using Gmail with Android Wear [here](#).

MUSIC ON THE M600

When you're playing music on your phone, you'll see a song card on the M600.

TO CONTROL THE MUSIC FROM YOUR SMARTWATCH

- Tap the card to pause and restart the music.
- Swipe left once to control the volume and to skip songs.
- Depending on the music app you're using, you might be able to swipe left to get more options, like browse music and play your playlists.

See [Android Wear Help](#) for instructions on how to change the default app your watch uses for music.

If your M600 is paired with an Android phone and you have Bluetooth headphones, you can also download music to your M600 and listen to it even if the M600 is disconnected from your phone, for example when you go running or biking and would rather leave your phone home. For more instructions on how to listen to music without your phone, see [Android Wear Help's site](#).

ROUTE DIRECTIONS

You can use your voice to get turn-by-turn directions to your destination.

TO GET TURN-BY-TURN DIRECTIONS



Applicable only to Polar M600 paired with an Android phone

1. Make sure the home screen is active and say "Ok Google."
2. Say "Navigate to (your destination)."

A Google Maps™ card will appear on your M600 and the turn-by-turn navigation will start.



For the turn-by-turn directions feature to work, you must allow the Maps app to access your device's location.

See [Android Wear Help](#) for details on the languages and countries that are supported for the turn-by-turn directions and how to see more detailed information about the route.

TO START USING OTHER M600 FEATURES DURING THE TURN-BY-TURN NAVIGATION

- Swipe from left to right on the navigation card. This will mute the navigation.

TO RETURN TO THE NAVIGATION

- Touch the blue arrow on the directions notification.

TO CANCEL THE NAVIGATION

- Swipe left on the navigation card to find and tap **Exit navigation**.

You can also get instructions to a place or to a business, or find information about a business.

TO FIND A PLACE OR A BUSINESS

1. Make sure the home screen is active and say "Ok Google."
2. Say what you're looking for, like: "Where's the London Eye?" or "How far is the central train station?" or "Find the nearest supermarket."

QUICK ANSWERS

You can ask your M600 for answers to things you want to find out. For example, you can translate words, solve math problems, or look up random facts.

TO GET QUICK ANSWERS

1. Make sure the home screen is active and say "Ok Google."
2. Say your question, for example, "How do you say 'hello' in Spanish?"

The answer to your question appears on the screen of your M600. Depending on your question, your smartwatch may also suggest a link with relevant information that you can open on your phone.

See the [Android Wear Help site](#) for more information on what types of questions you can ask, how to formulate the questions and which languages you can use to get quick answers.

STANDALONE USAGE OF THE M600

Even if your M600 is disconnected from your phone, some of the M600's basic features will continue to work.


In the standalone mode, you can:

- Tell time and view the date.
- Train using the [Polar app](#).
- Listen to [music](#) saved on the M600.
- Use the [stopwatch](#).
- Use the [timer](#).
- View your [schedule](#) for the day.
- Set an [alarm](#).
- View your [step count](#).
- View your [heart rate](#).
- [Change the watch face](#).
- Use the [airplane mode](#).

 Note that voice actions won't work when your M600 is not connected to your phone. You'll have to use the touch-screen or wrist gestures to navigate your M600.

TRAINING WITH POLAR

POLAR APP AND POLAR FLOW



POLAR APP

The Polar app on your M600 turns your Android wear smartwatch into a Polar sport and activity tracker.

The app monitors your training data, such as heart rate, speed, distance and route. It also measures your activity around the clock: you can see how many steps you've taken, how much distance you've covered and how much calories you've burned. If you wear the M600 to bed, you'll also get an analysis of your sleep time and quality.

GETTING THE APP

In order to get Polar's activity tracking and training features to work on your M600, you need to install the Polar Flow app from Google Play or App Store on your phone and activate the Polar app on your smartwatch. See [here](#) for more information on how to activate the Polar app on your M600.

POLAR FLOW APP

In the Polar Flow mobile app, you can see an instant visual interpretation of your training and activity data. You can also change some settings and plan your training in the app.

TRAINING DATA

With the Polar Flow app, you can get an instant overview of your training straight after your session on your phone. You can see weekly summaries of your training in the training diary, and share your best achievements with your friends in the Flow Feed.

ACTIVITY DATA

In the mobile app, you can see your daily activity in detail. See how much time you've spent on each activity intensity level, and find out how much you're missing from your daily goal and how to reach it. You can also see detailed information on your sleeping data.

CHANGING SETTINGS AND PLANNING YOUR TRAINING

You can change your Polar account settings and some basic device settings in the Polar Flow app. In addition, you can add and remove [sport profiles](#), and you can plan your training by creating quick or phased training targets.

For support and more information about using Polar Flow app, go to support.polar.com/en/support/Flow_app.

For information on how to sync your training and activity data and the changed settings between the Polar app and the Polar Flow mobile app, see [Syncing](#).

POLAR FLOW WEB SERVICE

In the Polar Flow web service, you can plan and analyze your training in detail and learn more about your performance.

In the web service, you can also customize the Polar app on your M600 to perfectly fit your training needs by adding new sport profiles and [editing their settings](#). For example, you can define specific **training view settings** for each sport and choose what data you want to see while you're training.

You can also follow and visually analyze your progress, join a network of fellow exercisers, and you can get a personalized training program for a running event. To start using the Polar Flow web service, go to flow.polar.com, and sign in with the Polar account you created when you set up your M600.

FEED, EXPLORE AND DIARY

In **Feed** you can see what you and your friends have been up to lately. Check out the latest training sessions and activity summaries, share your best achievements, comment and like your friends' activities. In **Explore** you can browse the map and see other users' shared training sessions with route information. You can also relive other people's routes and see where the highlights happened. In **Diary** you can see your daily activity and planned training sessions (training targets), as well as review past training results.

PROGRESS

In **Progress** you can follow your development with reports. Reports are a handy way to follow your training progress over longer periods. In week, month and year reports you can choose the sport for the report. In custom period, you can choose both the period and the sport. Choose the time period and the sport for the report from the drop-down lists, and press the wheel icon to choose what data you want to view in the report graph.

COMMUNITY

In the **Flow Groups**, **Clubs** and **Events** you can find fellow exercisers who train for the same event or in the same health club as you do. Or you can create your own group for the people you want to train with. You can share your exercises and training tips, comment other members' training results and be part of the Polar Community.

PROGRAMS


In **Programs** you can create a Running Program that will help you train for a 5K, 10K, half marathon or marathon run. Polar Running Program is tailored for your event, taking your personal attributes, training background and preparation time into account.

For support and more information about using the Polar Flow web service, go to support.polar.com/en/support/flow.

For detailed information on how to edit the sport profiles

POLAR APP MENU

TRAINING




This is where you start your training sessions. Open **Training** to see a list of the [sport profiles](#) that you have in the Polar app. This is where you can choose the sport you want to do.

You can edit the selection of sport profiles you see in the Polar app on your M600 either in the Polar Flow app or in the Polar Flow web service. In the mobile app menu, tap **Sport profiles**. Or go to flow.polar.com, click your name in the upper right corner, and choose **Sport profiles**. In both the mobile app and the web service, you can add and remove sports and reorganize the list to keep your favorite sports easily accessible on your M600.

To start training, wait for your heart rate to appear next to the sport icon. If your chosen sport profile supports GPS-tracking, the GPS icon is also displayed. The green circle around the GPS will stop rotating when the GPS signal is found. Press the front button, tap the icon to choose the sport and the training session begins.

MY DAY



You can see the progress of your daily activity on the home screen of your M600 when you use Polar's own watch faces, like the "Polar Jumbo". In **My Day** you can see your daily activity in more detail and your training sessions for the day.

Open **My Day** to see your activity status **NOW**. Here you'll see the percentage of how much you've achieved of your daily activity goal so far. Your progress is also visualized in the gradually filling activity bar. You'll also see the amount of steps you've taken, the distance you've covered so far and the calories you've burned.

Scroll the My day menu to see the training sessions you've done during the day and any planned training sessions you've created for the day in the Polar Flow web service. You can open the past sessions to view them in more detail.

SYNC

Applicable only to Polar M600 paired with an iPhone

The Polar app in your M600 syncs your training and activity data with the Polar Flow app automatically after you've completed a training session. But if you don't train using the Polar app and want to see your activity data in the mobile

icon. Your M600 displays **Syncing** during and **Completed** after a successful sync.

When the Polar app on your M600 syncs with the mobile app, your activity and training data are also synced automatically via an internet connection to the web service.

NAVIGATING THE POLAR APP

TO OPEN THE POLAR APP

- Press the front button of your M600 (note that you must exit any other apps first).

OR

- [Navigate to the apps menu](#) and find and tap **Polar**.

OR

- Use your voice:
 1. • Make sure the home screen of your M600 is active.
 2. • Say "Ok Google". If your voice is recognized, you'll see a picture of a microphone with the text **Speak now**.
 3. • Say either "Open Polar" or "Start a workout."

USING THE TOUCHSCREEN AND WRIST GESTURES TO NAVIGATE THE POLAR APP TO BROWSE MENUS, LISTS AND SUMMARIES

- Swipe the touch screen up or down.

OR

- Flick your wrist in and out.

TO CHOOSE ITEMS

- Tap the icons.

TO GO BACK ONE STEP

- Swipe the screen from left to right.

USING THE FRONT BUTTON TO NAVIGATE THE POLAR APP

- In the Polar app menu, press the front button to open **Training**.
- In the list of sport profiles, press the front button to choose the sport profile icon shown on the screen.
- During training, press and hold the front button to pause the exercise.
- In pause mode, press and hold the front button to stop the training session.
- In summary view after training, press the front button to exit the Polar app.

USING YOUR VOICE TO NAVIGATE THE POLAR APP

TO START A TRAINING SESSION

1. Make sure the home screen of your M600 is active.
2. Say "Ok Google". If your voice is recognized, you'll see a picture of a microphone with the text **Speak now**.
3. Say either "Start a run" or "Start a bike ride" to start your training session,

OR

say "Start a workout" to open the list of sport profiles, and find and tap the sport you want to do to start the session.

TO PAUSE A TRAINING SESSION

1. Make sure the home screen of your M600 is active.
2. Say "Stop a run" or "Stop a bike ride."

TRAINING WITH POLAR APP

Use the Polar app on your M600 to take full advantage of your sport-optimized smartwatch.

See detailed information on how to train with the Polar app on your M600 from the links below:

- [Wearing your M600](#)
- [Starting a training session](#)
- [During training](#)
- [Pausing/Stopping a training session](#)
- [After training](#)

WEARING YOUR M600

Your sport-optimized smartwatch has a built-in heart rate sensor that measures your heart rate from the wrist. To measure wrist-based heart rate accurately, you need to secure the wristband firmly around your wrist, just behind the wrist bone, with the display facing up. The sensor must be touching your skin, but the wristband should not be too tight to prevent blood flow.



When you're not working out, you should wear the wristband a little looser, just as you would wear a normal watch. But you should tighten it up for your training sessions to make sure you get accurate heart rate readings from the wrist. If you have tattoos on the skin of your wrist, avoid placing the sensor right on it as it may prevent accurate readings.

It's a good idea to warm up the skin under the sensor if your hands and skin get cold easily. Get the blood going before starting your session!


In sports where it's more challenging to keep the sensor stationary on your wrist or where you have pressure or movement in muscles or tendons near the sensor, we recommend using a Polar heart rate sensor with a chest strap to get better measurement of your heart rate. See [Pairing the Polar app with a heart rate sensor](#) for more information.

Although there are many subjective clues as to how your body is doing during exercise (perceived exertion, breathing rate, physical sensations), none of them are as reliable as measuring heart rate. It is objective and affected by both internal and external factors—meaning you will have a dependable measure of your physical state.

STARTING A TRAINING SESSION

 See [Navigating the Polar app](#) to find out the alternative ways to get around in the app.

TO START A TRAINING SESSION



1. Open the Polar app by pressing the front button of your M600. Note that you must exit any other apps first.
2. Press the front button to open **Training** and to see your list of sport profiles.
3. Flick your wrist in or out to scroll the list of sport profiles and to find the one you want to use. Stay in this pre-training mode until the M600 has found your heart rate and the GPS satellite signals (if applicable to your sport) to make sure your training data is accurate.

The heart icon begins to display your heart rate when it's detected.

If a sport profile supports GPS-tracking, the GPS icon is displayed. To catch the GPS satellite signals, go outdoors and away from tall buildings and trees. For best GPS performance, wear the M600 on your wrist with the display facing up. Keep it in a horizontal position in front of you and away from your chest. Keep your arm stationary and raised above the level of your chest during the search. Stand still and hold the position until the M600 has found the satellite signals.

Due to the location of the GPS antenna on the M600, it is not recommended to wear it with the display on the underside of your wrist. If you wear it on the handlebars of a bike, make sure the display is facing up. For more information on the GPS, see [GPS](#).

The green circle around the GPS will stop rotating when the GPS signal is found.

4. To begin a training session, press the front button on your chosen sport profile.

 *Note that you need to give the Polar app on your M600 permission to track your location and to measure your heart rate if you want to view information based on these measurements in your training data.*

To enable/disable permissions

1. [Navigate to the Settings menu](#), and find and tap **Permissions**.
2. Find and tap **Polar**.
3. Tap **Location** or **Sensors** to switch between setting its status as **ENABLED** or **DISABLED**.

See [During Training](#) for more information on what kind of information the Polar app can show you while you're training.

STARTING A TRAINING SESSION WITH A TARGET

You can plan your training and [create personal training targets](#) for yourself in the Polar Flow app or web service. Note that you have to sync the training targets to the Polar app before you can use them. See [syncing](#) for more information. The Polar app will guide you towards completing your target during training.

To start a training session with a target

1. Press the front button of your M600 to open the Polar app.
2. Tap **Training**. You'll be prompted to start a training you've scheduled for the day.
3. Tap the checkmark icon.
4. Find and tap the sport profile you want to use for the training session.

OR

1. Press the front button of your M600 to open the Polar app.
2. Go to **My day**.
3. Find and tap your training target.
4. Find and tap your preferred sport for the training session.

DURING TRAINING

TRAINING VIEWS

To browse through the training views


- Swipe the display up or down.

OR


- Flick your wrist in and out.

The information you see on the training views depends on your edit of the chosen sport profile. You can define the settings for each [sport profile in the Polar Flow web service](#).

For example, your training views can have the following information:



Your current heart rate
The heart rate ZonePointer
Duration of training session



Distance covered during the session so far
Your current pace
Time of day
Calories burned so far during training

AUTOMATIC LAP VIEW

Applicable if you have the Automatic lap setting turned on in the chosen sport profile. For more information on how to change sport profile settings, see [Sport profiles in Polar Flow web service](#) or Sport profiles in Polar Flow app on the Polar support pages.


To see the Automatic lap view

- Swipe left on the training view.

To see the previous laps


- Swipe the lap view up.

Depending on your Automatic lap settings, your lap view will display:



Lap duration or lap distance
Average speed or pace
Average heart rate


TO EXIT THE POLAR APP WITHOUT STOPPING YOUR TRAINING SESSION



- tap and hold the display for 2 seconds, and then tap the red quit icon

OR

- press the side power button of your M600



When you've exited Polar app during training, a Recording on card will peek from the bottom of the home screen. You can navigate and use the M600 as usual.

To return to your training session

- tap the Recording on card

OR

- press the front button of your M600.

TRAINING SUMMARY DURING TRAINING

To see the training Summary view

- swipe left on the lap view.




Depending on the sport profile you're using, the Summary view will display some or all of the following information

- Time of day
- Duration of training session
- Distance covered (If applicable to your sport)
- Average heart rate
- Maximum heart rate
- Time spent in different heart rate zones
- Average speed or pace (If applicable to your sport)
- Maximum speed or pace (If applicable to your sport)
- Burned calories

PAUSING/STOPPING A TRAINING SESSION

TO PAUSE A TRAINING SESSION




- Press and hold the front button.

OR

- Swipe right on the training view to find and tap the pause icon.


 You can see the training summary in the pause mode by swiping left.

TO CONTINUE A PAUSED TRAINING SESSION



- Tap the green arrows icon.

TO STOP A TRAINING SESSION



- During training or in the pause mode, press and hold the front button until the green counter counts all the way down.

OR


- In the pause mode, tap and hold the red stop icon to end the recording.

AFTER TRAINING

Get instant analysis and in-depth insights into your training with the Polar app, the Polar Flow app and the Polar Flow web service.

TRAINING SUMMARY ON YOUR M600

After each training session, you'll get an instant training summary of your session on your wearable.



The information shown in your summary depends on the sport profile. The available details include:

Duration: The duration of the session.

Distance (If applicable to your sport): Distance covered in the session.

Average heart rate: Your average heart rate during the session.

Maximum heart rate: Your maximum heart rate during the session.

Average pace/speed (If applicable to your sport): Average pace/speed of the session.

Maximum pace/speed (If applicable to your sport): Maximum pace/speed of the session.

Calories: Calories burned during the session.


Heart rate zones: Training time spent in different heart rate zones.


Running index: Your running performance class and numerical value

Training load: The calculated exertion of your training session.

Training Benefit: Feedback on the effectiveness of your training session.

You can view your training summary later in My Day.





To view your training summary later

1. Press the front button to open Polar app.
2. Swipe up to find and tap **My day**.
3. Swipe down to view today's training sessions.
4. Tap the session you want to see in the summary view.

You can only view the training summaries of the current day in the Polar app. You can see your full training history with more detailed analysis in the Polar Flow app or the web service.

TRAINING DATA IN POLAR FLOW APP

Analyze your data at a glance after each session on your phone. The Polar app on your M600 syncs your training data with the Polar Flow app automatically after you've completed a training session.

For more information, see [Polar apps and services](#) and [Syncing](#).

TRAINING DATA IN POLAR FLOW WEB SERVICE

You can analyze every detail of your training and learn more about your performance in the Polar Flow web service. Follow your progress and also share your best sessions with others.

For more information, see [Polar apps and services](#) and [Syncing](#).

GPS FEATURES

The M600 has built-in GPS that provides accurate speed and distance measurement for a range of outdoor sports. When you train using the Polar app, you can see your route on a map in the Polar Flow app and web service after your session.

The M600 includes the following GPS features:

- Altitude: Real-time altitude measurement.
- Distance: Accurate distance during and after your session.
- Speed/Pace: Accurate speed/pace information during and after your session.

Note that the GPS stops recording when the battery saver mode is on in your M600. The battery saver mode turns on automatically when the battery's charge drops to 5%.

 *Even if you aren't measuring your heart rate from your wrist, for best GPS performance, wear the M600 on your wrist with the display facing up. Due to the location of the GPS antenna on the M600, it is not recommended to wear it with the display on the underside of your wrist. If you wear it on the handlebars of a bike, make sure the display is facing up.*

SYNCING

To be able to sync data between the Polar app on your M600, the Polar Flow mobile app and the Polar Flow web service, you need to have a Polar account. You already created an account if you finished [setting up your M600](#).

AUTOMATIC SYNCING OF TRAINING DATA

The Polar app on your M600 syncs your training and activity data with the Polar Flow app automatically after you've completed a training session. For the automatic sync to work, you need to be signed in to the mobile app with your Polar account, and your phone and M600 need to be connected via Bluetooth or Wi-Fi.

The Polar app also syncs your activity data with the mobile app if you get an inactivity alert or reach your daily activity goal.

When your activity and training data are updated to the mobile app, the data is automatically also synced with the Polar Flow web service via an internet connection.

 **iPhone users note!** *If you don't train using the Polar app and want to see your activity data in the mobile app, you need to use the manual sync.*

SYNCING CHANGED SETTINGS

You can change your Polar account settings, add or remove sport profiles and create training targets in both the Polar Flow web service and the Polar Flow mobile app. In the web service you can also edit the sport profile settings.

Any changes you make in the mobile app, with your phone connected to the Internet, will sync between the mobile app and the web service automatically. If you make the changes in the Polar Flow web service, they will be synced to your mobile app next time you open the app on your phone.

 *Applicable to Polar M600 paired with an Android phone*

If your M600 is paired with an Android phone, the changed settings will sync from the mobile app to the Polar app on your M600 automatically via Bluetooth or Wi-Fi connection.

Applicable to Polar M600 paired with an iPhone

If your M600 is paired with an iPhone, you need to manually sync the changed settings between the mobile app and the Polar app on your M600.

TO SYNC ACTIVITY DATA AND CHANGED SETTINGS MANUALLY (IPHONE USERS)

1. Press the front button of your M600 to open the **Polar** app.
2. Swipe down the menu to find and tap **Sync**.
3. The watch displays **Syncing** during and **Completed** after a successful sync.

For support and more information about using Polar Flow app, go to www.polar.com/en/support/Flow_app.

For support and more information about using the Polar Flow web service, go to www.polar.com/en/support/flow.

PLANNING YOUR TRAINING

You can plan your training and create personal training targets for yourself in the Polar Flow app or in the Polar Flow web service. Note that the training targets need to be synced to the Polar app before you can use them. See [syncing](#) for more information. The Polar app will guide you towards completing your target during training.

- **Quick Target:** Choose a duration, distance or calorie target for the training. You can, for example, choose to swim for 30 minutes, run 10 km or burn 500 kcal.
- **Phased Target:** You can split your training session into phases and set a different duration and intensity for each of them. This one is for e.g. creating an interval training session, and adding proper warm-up and cool-down phases to it.

TO CREATE A TRAINING TARGET IN THE POLAR FLOW WEB SERVICE

1. Go to **Diary**, and click **Add > Training target**.
2. In the **Add training target** view, choose **Quick** or **Phased**.

QUICK TARGET

1. Choose **Quick**
2. Choose **Sport**, enter **Target name** (maximum 45 digits), **Date** and **Time** and any **Notes** (optional) you want to add.
3. Fill in either **Duration** or **Calories**. You can only fill in one of the values.
4. Click **Save** to add the target to your **Diary**.

PHASED TARGET

1. Choose **Phased**
2. Choose **Sport**, enter **Target name** (maximum 45 digits), **Date** and **Time** and any **Notes** (optional) you want to add.
3. Choose whether you want to **Create new** or **Use template**.
4. Add phases to your target. Click **Duration** to add a phase based on duration. Choose **Name** and **Duration** for each phase, **Manual** or **Automatic** next phase start, and **Select intensity**.
5. Click **Save** to add the target to your **Diary**.

After your training targets have been synced to the Polar app on your M600, you can find the training targets for the current day listed under **My day**.

For instructions on starting a training session with a target, see [Starting a training session](#).

See more information on how to create training targets in the Polar Flow app from the [Polar support pages](#).

PAIRING THE POLAR APP WITH A HEART RATE SENSOR

In sports where it's more challenging to keep the sensor stationary on your wrist or where you have pressure or movement in muscles or tendons near the sensor, we recommend using a Polar heart rate sensor with a chest strap to get better measurements of your heart rate.


The Polar training app on your M600 is compatible with *Bluetooth®* Smart heart rate sensors, like Polar H6 and H7.

The *Bluetooth®* Smart heart rate sensor must be paired with the Polar app for them to function together. The pairing takes only a few seconds and ensures that the Polar app receives signals from only your sensors and devices and

allows disturbance-free training in a group. Before entering an event or race, make sure that you do the pairing at home to prevent interference from other devices.

TO PAIR A POLAR **BLUETOOTH®** SMART HEART RATE SENSOR WITH THE POLAR APP ON YOUR M600

1. Wear the heart rate sensor.



- Moisten the electrode areas of the strap.
 - Attach the connector to the strap.
 - Adjust the strap length to fit tightly but comfortably. Tie the strap around your chest, just below the chest muscles, and attach the hook to the other end of the strap.
 - Check that the moist electrode areas are firmly against your skin and that the Polar logo of the connector is in a central and upright position.
1. Open the Polar app on the M600 by pressing the front button. (You need to exit any other apps first.)
 2. Tap **Training** or press the front button to open the list of sport profiles on your M600.
 3. You'll be prompted to pair your M600 with your heart rate sensor. You'll see your heart rate sensor's device ID, for example, **Pair Polar H7 XXXXXXXX**.
 4. Accept the pairing request by tapping the checkmark icon.
 5. You'll see **H7 connected** when your heart rate sensor is paired with your smartwatch. Also the heart icon turns to display your heart rate and the circle around the heart rate turns from green to blue.

i When you use a Polar Bluetooth Smart® heart rate sensor, the Polar app does not measure heart rate from your wrist.

TO UNPAIR A POLAR **BLUETOOTH®** SMART HEART RATE SENSOR FROM THE POLAR APP

1. Go to flow.polar.com.
2. Click your name in the upper right corner, and choose **Products**.
3. You'll see a list of your **Registered products**. Click **Remove** next to your heart rate sensor to unpair it from any of the devices.

i Detach the connector from the chest strap, and rinse the strap under running water after every training session. Sweat and moisture may keep the heart rate sensor activated, so also remember to wipe it dry.

POLAR FEATURES

24/7 ACTIVITY TRACKING

The Polar app on your M600 tracks your activity with a 3D accelerometer that records your wrist movements. It analyzes the frequency, intensity and regularity of your movements together with your physical information, allowing you to see how active you really are in your everyday life, on top of your regular training. We recommend that you wear your M600 on your non-dominant hand for more accurate activity tracking.

The activity tracking feature is always on. If you use a Polar watch face on your M600, you'll see your activity progress on the home screen.

ACTIVITY GOAL

The Polar app guides you in reaching your personal activity goal each day. The activity goal is based on your personal data and activity level setting, which you can find in the Daily Activity Goal settings in the [Polar Flow web service](#). Sign in to the web service, click your name/profile photo in the upper right corner and go to the Daily Activity goal tab in Settings.


The Daily Activity goal setting lets you choose the one that best describes your typical day and activity from three activity levels. Below the selection area, you can see how active you need to be to reach your daily activity goal on the chosen level. For example, if you're an office worker and spend most of your day sitting, you would be expected to reach about four hours of low intensity activity during an ordinary day. For people who stand and walk a lot during their working hours, the expectations are higher.

ACTIVITY DATA

The Polar app records your progress towards your daily goal. You can check your activity progress from the activity bar in **My day** or from the Polar watch faces.



In **My day** you can see how active your day has been so far and any training sessions you've done or planned for the day.



- **Steps:** Steps you've taken so far. The amount and type of body movements are registered and turned into an estimation of steps.
- **Distance:** Distance you've covered so far. The distance calculation is based on your height and the steps you've taken.
- **Calories:** Shows how many calories you've burned through training, activity and BMR (Basal metabolic rate: the minimum metabolic activity required to maintain life).

 You can quickly open the activity display from the home screen if you have Polar Jumbo as your watch face. Just tap the light blue activity icon.

To see what you should still do to reach your activity goal for the day, tap the activity data view or push your arm down when the activity data view is open on the screen.

When you reach your daily activity goal, you'll get a notification card. If you use a Polar watch face on your M600, you'll get a vibrating animation.

INACTIVITY ALERT

It's widely known that physical activity is a major factor in maintaining health. In addition to being physically active, it's important to avoid prolonged sitting. Sitting for long periods of time is bad for your health even on those days when you train and gain enough daily activity. The Polar app spots if you're being inactive for too long during your day and helps you to break up your sitting to avoid the negative effects it has on your health.

Whichever activity level you've set for your daily activity goal, if you've been still for 55 minutes, you'll get an inactivity alert card: **It's time to move** is shown along with a small vibration. Stand up and find your own way to be active. Take a short walk, stretch, or do some other light activity. The message goes away when you start moving or press any button.

If you don't get active in five minutes, you'll get an inactivity stamp. You can see the inactivity stamp in **My Day** in the Polar app below your daily activity data. You can also see how many inactivity stamps you've received each day in the Polar Flow app and web service. This way you can check back on your daily routine and make changes towards a more active life.

The inactivity alerts or stamps won't affect your progress towards reaching your daily activity goal.

SLEEP INFORMATION IN THE POLAR FLOW APP AND WEB SERVICE

The Polar app tracks your sleep time and quality (restful / restless) if you wear the M600 at night. You don't have to turn the sleep mode on. The app automatically detects that you're sleeping from your wrist movements. Sleep time, and its quality (restful / restless) is shown in the Polar Flow app and web service .

Your sleep time is the longest continuous rest time that takes place within 24 hours starting from 18:00/6pm to next day's 18:00/6pm. Breaks shorter than one hour in your sleep don't stop sleep tracking, but they are not taken into account in the sleep time. Breaks longer than 1 hour stop sleep time tracking.

The periods when you sleep peacefully and don't move a lot are calculated as restful sleep. The periods when you move and change your position are calculated as restless sleep. Instead of simply summing up all the immobile periods, the calculation gives more weight to long than short immobile periods. The percentage of restful sleep compares the time you slept restfully with the total sleeping time. Restful sleep is highly individual and should be interpreted together with sleep time.

Knowing the amount of restful and restless sleep gives you insight into how you sleep at night and if it's affected by any changes in your daily life. This may help you in finding ways to improve your sleep and feel well rested during the day.

ACTIVITY DATA IN THE POLAR FLOW APP AND WEB SERVICE

With the Polar Flow mobile app, you can follow and analyze your activity data on the go and have your data synced from the Polar app to the Polar Flow web service. The web service gives you the most detailed insight into your activity information.

HEART RATE ZONES

Polar heart rate zones introduce a new level of effectiveness in heart rate-based training. Training is divided into five heart rate zones based on percentages of maximum heart rate. With heart rate zones, you can easily select and monitor training intensities.

Target zone	Intensity % of HR _{max} *	Example: Heart rate zones**	Example durations	Training effect
MAXIMUM 	90–100%	171–190 bpm	less than 5 minutes	Benefits: Maximal or near maximal effort for breathing and muscles. Feels like: Very exhausting for breathing and muscles. Recommended for: Very experienced and fit athletes. Short intervals only, usually in final preparation for short events.
HARD 	80–90%	152–172 bpm	2–10 minutes	Benefits: Increased ability to sustain high speed endurance. Feels like: Causes muscular fatigue and heavy breathing. Recommended for: Experienced athletes for year-round training, and for various durations. Becomes more important during pre competition season.
MODERATE 	70–80%	133–152 bpm	10–40 minutes	Benefits: Enhances general training pace, makes moderate intensity efforts easier and improves efficiency. Feels like: Steady, controlled, fast breathing. Recommended for: Athletes training for events, or looking for performance gains.
LIGHT 	60–70%	114–133 bpm	40–80 minutes	Benefits: Improves general base fitness, improves recovery and boosts metabolism. Feels like: Comfortable and easy, low muscle and cardiovascular load. Recommended for: Everybody for long training sessions during base training periods and for recovery exercises during competition season.
VERY LIGHT	50–60%	104–114 bpm	20–40	Benefits: Helps to warm up and cool down and

Target zone	Intensity % of HR _{max} *	Example: Heart rate zones**	Example durations	Training effect
			minutes	assists recovery. Feels like: Very easy, little strain. Recommended for: For recovery and cool-down, throughout training season.

* HR_{max} = Maximum heart rate (220-age).

** Heart rate zones (in beats per minute) for a 30-years-old person, whose maximum heart rate is 190 bpm (220-30).

Training in heart rate zone 1 is done at a very low intensity. The main training principle is that performance improves when recovering after, and not only during training. Accelerate the recovery process with very light intensity training.

Training in heart rate zone 2 is for endurance training, an essential part of any training program. Training sessions in this zone are easy and aerobic. Long-duration training in this light zone results in effective energy expenditure. Progress will require persistence.

Aerobic power is enhanced in heart rate zone 3. The training intensity is higher than in sport zones 1 and 2, but still mainly aerobic. Training in sport zone 3 may, for example, consist of intervals followed by recovery. Training in this zone is especially effective for improving the efficiency of blood circulation in the heart and skeletal muscles.

If your goal is to compete at top potential, you will have to train in heart rate zones 4 and 5. In these zones, you exercise anaerobically in intervals of up to 10 minutes. The shorter the interval, the higher the intensity. Sufficient recovery between intervals is very important. The training pattern in zones 4 and 5 is designed to produce peak performance.

The Polar target heart rate zones can be personalized by using a laboratory measured HR_{max} value, or by taking a field test to measure the value yourself. When training in a target heart rate zone, try to make use of the entire zone. The mid-zone is a good target, but keeping your heart rate at that exact level all the time is not necessary. Heart rate gradually adjusts to training intensity. For instance, when crossing from heart rate target zone 1 to 3, the circulatory system and heart rate will adjust in 3-5 minutes.

Heart rate responds to training intensity depending on factors such as fitness and recovery levels, as well as environmental factors. It is important to look out for subjective feelings of fatigue, and to adjust your training program accordingly.

SPORT PROFILES

Sport profiles are the sport choices you have in the Polar app on your M600.

There are six default sport profiles in the Polar app in your M600:

- Group exercise
- Running
- Strength training

- Cycling
- Other indoor
- Other outdoor

You can add and remove sport profiles in the Polar Flow mobile app or in the Polar Flow web service.

In the Polar Flow web service, you can define specific settings for each profile service. For example, you can create tailored **training views** for each sport you do and choose what data you want to see when you train: just your heart rate or just speed and distance—whatever suits you and your training needs and requirements best.

You can have a maximum of 20 sport profiles in the Polar app on your M600 at a time. The number of sport profiles in Polar Flow mobile app and Polar Flow web service is not limited.

For more information, see [Sport Profiles in Polar Flow Web Service](#) or Sport Profiles in Polar Flow app on the [Polar support pages](#).

POLAR SPORT PROFILES IN FLOW WEB SERVICE

There are six default sport profiles in the Polar app on your M600. You can add and remove sports from the list in the Polar Flow web service. You can also define specific settings for each sport profile.

The Polar app on your M600 can contain a maximum of 20 sport profiles. If you have over 20 sport profiles in the web service, the first 20 in the list will sync to the Polar app. You can change the order of the sport profiles by dragging and dropping them in the Polar Flow web service.

TO ADD A SPORT PROFILE

In the Polar Flow web service:

1. Click your name/profile photo in the upper right corner.
2. Choose **Sport Profiles**.
3. Click **Add sport profile**, and choose a sport from the list.

The sport is added to your sport list.

See more information on how to add and remove sport profiles in the Polar Flow app from [Polar support pages](#).

TO EDIT A SPORT PROFILE

In the Polar Flow web service:

1. Click your name/profile photo in the upper right corner.
2. Choose **Sport Profiles**.
3. Click **Edit** under the sport you want to edit.

In each sport profile, you can edit the following information:

Basics

- Automatic lap (Can be set to duration or distance-based or turned off)

Heart Rate

- Heart rate view (Beats per minute or % of maximum)
- Heart rate zone settings (With the heart rate zones you can easily select and monitor training intensities. If you choose Default, you cannot change heart rate limits. If you choose Free, all limits can be changed. Default heart rate zone limits are calculated from your maximum heart rate.)

Speed/Pace settings

- Speed/Pace view (km/h or min/km)

Training views

Choose what information you see on your training views during your sessions. You can have a total of eight different training views for each sport profile. Each training view can have a maximum of four different data fields.

Click the pencil icon on an existing view to edit it, or add a new view. You can select one to four items for your view from four categories:

Time	Body measurement	Distance	Speed
Time of day	Heart rate	Distance	Speed/pace
Duration	Average heart rate	Automatic lap distance	Average speed/pace
Automatic lap time	Maximum heart rate		Maximum speed/pace
	Calories		Automatic lap speed/pace avg
	HR ZonePointer		Automatic lap max speed/pace
	Time in HR zone		
	Automatic lap HR avg		
	Automatic lap HR max		

Gestures and Feedback

- Vibration feedback (on/off)

GPS and altitude

- GPS recording rate (high accuracy/off)

When you're done editing the sport profile settings, click **Save**. Note that the changed settings have to be synced to the Polar app before you can use them. For more information, see [Syncing](#).

POLAR SMART COACHING FEATURES

Whether it's assessing your day-to-day fitness levels, creating individual training plans, working out at the right intensity or receiving instant feedback, Smart Coaching offers a choice of unique, easy-to-use features, personalized to

your needs and designed for maximum enjoyment and motivation when training.


The Polar app on your M600 includes the following Polar Smart Coaching features:

- [24/7 Activity Tracking](#)
- [Smart Calories](#)
- [Training Benefit](#)
- [Running Program](#)

ACTIVITY BENEFIT

Activity benefit gives you feedback on the health benefits that being active has given you, and also on what kind of unwanted effects sitting for too long has caused for your health. The feedback is based on international guidelines and research on the health effects of physical activity and sitting behavior. The core idea is: the more active you are, the more benefits you get!

Both Flow app and Flow web service show the activity benefit of your daily activity. You can view the activity benefit on daily, weekly and monthly basis. In the Flow web service, you can also view the detailed information on health benefits.



For more information, see [24/7 Activity Tracking](#).

SMART CALORIES

The most accurate calorie counter on the market calculates the number of calories burned. The energy expenditure calculation is based on:

- Body weight, height, age, gender
- Individual maximum heart rate (HR_{max})
- Heart rate during training
- Activity measurement outside of training sessions and when you train without heart rate
- Individual maximal oxygen uptake ($VO2_{max}$)

$VO2_{max}$ can be measured or predicted by fitness tests.

TRAINING BENEFIT

The Training Benefit feature helps you better understand the effectiveness of your training. After each training session you get textual feedback on your performance providing that you have trained at least a total of 10 minutes in the sport zones. The feedback is based on training time distribution on the different sport zones, calorie expenditure and duration. You can see the Training Benefit in the summary of your training session in the Polar app, in the Polar Flow app and in the Polar Flow web service. The descriptions of different training benefit options are listed in the table below.

Feedback	Benefit
Maximum training+	What a session! You improved your sprint speed and the nervous system of your muscles, which make you more efficient. This session also increased your resistance to fatigue.
Maximum training	What a session! You improved your sprint speed and the nervous system of your muscles, which make you more efficient.
Maximum & Tempo training	What a session! You improved your speed and efficiency. This session also significantly developed your aerobic fitness and your ability to sustain high intensity effort for longer.
Tempo & Maximum training	What a session! You significantly improved your aerobic fitness and your ability to sustain high intensity effort for longer. This session also developed your speed and efficiency.
Tempo training+	Great pace in a long session! You improved your aerobic fitness, speed, and ability to sustain high intensity effort for longer. This session also increased your resistance to fatigue.
Tempo training	Great pace! You improved your aerobic fitness, speed, and ability to sustain high intensity effort for longer.
Tempo & Steady state training	Good pace! You improved your ability to sustain high intensity effort for longer. This session also developed your aerobic fitness and the endurance of your muscles.
Steady state & Tempo training	Good pace! You improved your aerobic fitness and the endurance of your muscles. This session also developed your ability to sustain high intensity effort for longer.
Steady state training +	Excellent! This long session improved the endurance of your muscles and your aerobic fitness. It also increased your resistance to fatigue.
Steady state training	Excellent! You improved the endurance of your muscles and your aerobic fitness.
Steady state & Basic training, long	Excellent! This long session improved the endurance of your muscles and your aerobic fitness. It also developed your basic endurance and your body's ability to burn fat during exercise.
Steady state & Basic training	Excellent! You improved the endurance of your muscles and your aerobic fitness. This session also developed your basic endurance and your body's ability to burn fat during exercise.
Basic & Steady state training, long	Great! This long session improved your basic endurance and your body's ability to burn fat during exercise. It also developed the endurance of your muscles and your aerobic fitness.
Basic & Steady state training	Great! You improved your basic endurance and your body's ability to burn fat during exercise. This session also developed the endurance of your muscles and your aerobic fitness.
Basic training, long	Great! This long, low intensity session improved your basic endurance and your body's ability to burn fat during exercise.
Basic training	Well done! This low intensity session improved your basic endurance and your body's ability to burn fat during exercise.
Recovery training	Very nice session for your recovery. Light exercise like this allows your body to adapt to your training.

RUNNING PROGRAM

The Polar Running program is a ready-made and personalized running plan to help you train for a running event. Whether you're training for a 5K or a marathon, the Running program tells you how, how much and how often use should be training.

The Polar Running program is based on your fitness level and designed to make sure that you train right and avoid overtraining. The program is tailored to your event, taking your personal attributes, training background and preparation time into account. Programs are available for 5K, 10K, half marathon and marathon events. You can read more about the Running program [here](#).

The Polar Running program is free. Just log in to the Polar Flow web service at flow.polar.com, tap PROGRAMS at the top of the page, and get a running start to your training.

SETTINGS

ACCESSING SETTINGS

You can view and edit the settings of your M600 on the smartwatch in the Settings menu. You can get to the Settings menu by using the side power button, voice command or the touchscreen.

TO OPEN THE SETTINGS MENU USING THE SIDE POWER BUTTON

1. Press and hold the side power button until the watch vibrates and the apps menu appears.
2. Find and tap **Settings**.

TO OPEN THE SETTINGS MENU USING YOUR VOICE

1. Make sure the display is active on your M600.
2. Say "Ok Google" and then say "settings".

TO OPEN THE SETTINGS MENU USING THE TOUCHSCREEN

1. Make sure the display of your M600 is active.
2. On the home screen, swipe once from right to left.
3. From the apps menu, find and tap **Settings**.

There's also another way to get to the Settings menu using the touchscreen

1. Make sure the display of your M600 is active.
2. On the home screen, swipe down from the top of the screen to access the Quick settings menu.
3. Swipe from right to left to find and tap **Settings**.

SCREEN SETTINGS

TO ADJUST THE BRIGHTNESS LEVEL OF THE SCREEN

1. [Navigate to the Settings menu](#), and find and tap **Adjust brightness**.
2. Choose and tap the brightness level of your choice.

 *You can save battery life by turning down the brightness of your watch screen.*

TO BOOST BRIGHTNESS TEMPORARILY

You can light up the screen for a few seconds with the brightness boost

1. Swipe down from the top of the home screen to access the Quick settings menu.
2. Swipe from right to left to find and tap the **Brightness boost** icon.

 *You can also boost the brightness of the screen from anywhere in the watch by pressing the side power button three times quickly.*

CHANGING THE WATCH FACE

You have many different watch faces to choose from. By choosing the "Polar Jumbo" or the "Polar Activity" as your watch face, you'll be able to see the progress of your daily activity on the home screen when the screen is awake.

TO CHANGE THE WATCH FACE FROM THE M600

1. Tap and hold the watch face on the home screen when the screen is awake.

OR, [Navigate to the Settings menu](#), and find and tap **Change watch face**.

2. Swipe left or right to find your preferred watch face.
3. Choose the one you like best by tapping it.

TO CHANGE THE WATCH FACE FROM YOUR PHONE

1. Open the Android Wear app.
2. Choose one from under **Watch faces** or tap **More** to see more options.
3. Tap the one you want to use.

 You can get more watch face options using third-party apps. In the Andoird Wear app on your phone, tap **MORE** next to the **Watch faces**, then tap **Get more watch faces** from the bottom of the menu.

TURNING THE ALWAYS-ON SCREEN ON/OFF

You can choose whether you want the screen to dimly show the time or to turn completely off when you're not using the watch.

TO CHANGE THE SETTING FROM THE M600

- [Navigate to the Settings menu](#), and find and tap **Always-on screen**.

TO CHANGE THE SETTING FROM YOUR PHONE

1. Open the Android Wear app.
2. Tap the Settings icon.
3. (on Android phones) Find and tap the **M600** under the **Device settings**
4. Use the switch to turn the Always-on screen on or off.

If the **Always-on screen** is turned off and the screen of your M600 is black, you can **turn the screen back on** by tapping the screen, quickly raising the smartwatch in front of you, or by pressing the side power button.

 If you let the screen of your M600 turn off when you're not using the watch, it will help improve battery life.

TURNING THE AUTOMATIC SCREEN LOCK ON/OFF

You can set the automatic screen lock to turn on when you're not wearing your M600 or when your watch loses the Bluetooth connection to your phone. You can open the locked screen by drawing your screen lock pattern.

TO TURN THE AUTOMATIC SCREEN LOCK ON

1. [Navigate to the Settings menu](#), and find and tap **Screen lock OFF**.
2. Tap the check mark icon to confirm turning the auto-lock on.
3. Create your screen lock pattern by connecting at least four dots.
4. Draw the pattern again to confirm it.

When the automatic screen lock is turned on, you can also **lock the screen manually**:

1. [Navigate to the Settings menu](#), and find and tap **Lock screen now**
2. Confirm by tapping the check mark icon.

TO TURN THE AUTOMATIC SCREEN LOCK OFF

1. [Navigate to the Settings menu](#), and find and tap **Screen lock Automatic**.
2. Tap the check mark icon to confirm turning the auto-lock off.
3. Draw your screen lock pattern.

TO ADJUST THE FONT SIZE

If you want, you can change the size of the text on the screen of your M600

1. [Navigate to the Settings menu](#), and find and tap **Font size**.
2. You can choose between **Small** and **Normal**. Tap your preferred font size to turn it on.

TO ZOOM IN AND OUT ON THE SCREEN OF YOUR M600

If you have trouble seeing what's on the screen of your M600, you can turn on the magnification feature

1. [Navigate to the Settings menu](#), and find and tap **Accessibility**.
2. Tap **Magnification gestures**.
3. Confirm by tapping the check mark icon.

When you've enabled magnification, you can **zoom** in and out on the screen of your M600 **by triple tapping the screen**.

NOTIFICATION SETTINGS ON THE M600

 *The following advice applies to Polar M600 paired with an Android phone*

Many of the notifications you see on your Android phone also appear on the M600. When you dismiss a notification on your watch, it's also dismissed on your phone, and the other way around. Your watch will only vibrate for notifications, it will not make a sound.

You can define the notification settings for each app on your phone. If you've set an app notification to either vibrate or make a sound on your phone, your watch will vibrate for the same notification. If an app won't vibrate or make a sound for a notification, you'll see the notification card on your watch, but your watch won't vibrate.

MUTING THE CONNECTED PHONE

When your phone is connected to your M600, you can silence your phone so the alerts and calls won't vibrate on both devices. You'll still see the notifications on your phone as well.

TO MUTE CONNECTED PHONE

1. Open the Android Wear app on your phone, and tap the Settings icon.
2. Under **General** settings, use the switch to turn on **Mute phone alerts & calls**.

The following advice applies to Polar M600 paired with an iPhone

Your M600 uses the notification settings you've set for each app on your iPhone. If you've set notifications to show on the lock screen on your phone, the notification will also appear and vibrate on your M600. If an app is set to not show notifications on the lock screen on your phone, you'll see a card on your M600 but your watch won't vibrate.

The following advice applies to Polar M600 paired with both Android phones and iPhones

BLOCK SPECIFIC APPS FROM SENDING NOTIFICATIONS

You can control which apps are allowed to send notifications to your M600.

TO BLOCK APPS FROM YOUR WATCH

1. On your M600, view a card.
2. Swipe the card from right to left until you see **Block app**.
3. Tap **Block app** and confirm by tapping the check mark icon.

TO BLOCK APPS FROM YOUR PHONE

1. Open the Android Wear app, and tap the Settings icon.
2. Tap **Block(ed) app notifications**
3. **On Android phones:** Tap the plus icon, and choose any app from the list to add it to the blocked list.
On iPhones: Tap **+ Add apps to block list**, and choose any app from the list to add it to the blocked list. And to save the changes, tap **DONE**.

TO UNBLOCK AN APP

You can unblock an app only from your phone.

1. Open the Android Wear app, and tap the Settings icon.
2. Tap **Block(ed) app notifications**.
3. **On Android phones:** Tap the X next to the app you want to unblock.
On iPhones: Tap **EDIT** and **UNBLOCK** next to the app you want to remove from the blocked apps list. Finally, tap **DONE**.

STOP YOUR WATCH FROM VIBRATING FOR NOTIFICATIONS

Depending on the operating system and its version your phone runs, you silence notifications on your M600 a little differently. See [Android Wear Help](#) for instructions on how to stop your watch from vibrating for notifications that apply to your version of the operating system.

 See how you can turn off all notifications and the display as well, for example for the night, by activating the [theater mode](#).

DATE AND TIME SETTINGS

 Applicable only to Polar M600 paired with an Android phone. On M600 paired with iPhones, the date and time settings sync automatically from your phone.

TO SET DATE AND TIME

You can set date and time manually on your M600, or you can sync them automatically from you phone.

1. [Navigate to the Settings menu](#), and find and tap **Date & time**.
2. Tap **Automatic date & time**.
3. Choose and tap either

- Sync from phone or
- **OFF.** If you choose this option, swipe once from left to right, and you'll be able to set the date and time manually. Here, you'll also be able to choose if you want to use the 24-hour or the 12-hour time view.

 *In the same date & time settings menu, you can also choose to sync the time zone from your phone or set it yourself.*

AIRPLANE MODE

In the airplane mode, the Bluetooth and Wi-Fi connections are turned off on your M600. You can still use some of the basic features of the smartwatch, for example, you can train with the Polar app using the wrist-based heart rate monitoring. But you can't sync your data with the Polar Flow mobile app or use the M600 with any wireless accessories.

TO TURN THE AIRPLANE MODE ON/OFF

- [Navigate to the Settings menu](#), and find and tap **Airplane mode**.

 *Voice commands are not available in airplane mode. You must use wrist gestures or the touchscreen to navigate the M600.*

THEATER MODE

In the theater mode, the M600's screen and all notification cards are temporarily turned off. Even if you turn your wrist or touch the screen, the screen won't light up.

TO TURN THE THEATER MODE ON

1. Swipe down from the top of the home screen to access the Quick settings menu, and swipe once from right to left.
2. Tap the **Theater mode** icon.

 *You can also turn the theater mode on by pressing the side power button twice quickly.*

TO TURN THE THEATER MODE OFF

- Press the side power button.

PERMISSIONS

In Permission settings you can define what kind of information you allow the different apps and features on your M600 to use.

TO EDIT THE PERMISSION SETTINGS

1. [Navigate to the Settings menu](#), and find and tap **Permissions**.
2. Find and tap the app or service whose permissions you want to edit. You can also choose to edit system level permissions.
3. Tap to switch a permission setting to either **ENABLED** or **DISABLED**.

LANGUAGE SETTINGS

You can choose the language you want to use on your M600 during the setup. You can choose one from the following languages:

- Cantonese (Hong Kong)
- Dutch
- English (US, UK)
- French (France, Canada)
- German
- Indonesian
- Italian
- Japanese
- Korean
- Mandarin (Taiwan)
- Polish
- Portuguese (Brazil)
- Russian
- Spanish (US, Spain, Latin America)
- Thai

Note that your smartwatch will eventually copy the language setting of your phone. In other words, if you choose a different language on your M600 from the one you have on your phone, your watch will switch to using your phone's language. Except, if your phone language is not supported on the M600. Then your watch will notify you that your language configuration is not supported. You'll still be able to use the different language on your smartwatch, you'll just get notifications about the mismatch of language choices on your M600.

The Polar app on your M600 does not support some of the languages available for the Android Wear operating system. As a result, if you choose to use your M600 in one of the unsupported languages, the language of the Polar app on your smartwatch will be English (US).

In addition to English (US), other supported languages in the Polar app are:

- Dutch
- French (France)
- German
- Indonesian
- Italian
- Japanese
- Korean
- Polish
- Portuguese (Portugal)
- Russian
- Spanish (Spain)

 For the voice actions to work on your M600, your phone and smartwatch must use the same language!

RESTARTING AND RESETTING

Like with any electronic device, we recommend that you switch off the M600 every now and then.

If you experience problems with your M600, you can try restarting it. Restarting your smartwatch will not delete any of the settings or your personal data from the M600.

TO RESTART THE M600

1. [Navigate to the Settings menu](#), and find and tap **Restart**.
2. Confirm restarting the watch by tapping the check mark icon.

OR

- Press and hold down the side power button until the Polar logo appears.

Sometimes restarting your electronic device doesn't do the trick. If you, for example, have trouble re-establishing a lost connection between your M600 and phone, and have first tried our other [troubleshooting tips], but still can't come to no success, you can reset the M600 to factory settings. Note, however, that resetting empties all personal data and settings from the M600, and you need to set it up again for your personal use.

TO RESET THE M600 TO FACTORY SETTINGS

1. [Navigate to the Settings menu](#), and find and tap **Unpair with phone**.
2. Confirm the resetting by tapping the check mark.

After resetting, you need to [Set up your M600](#) again.

UPDATING SOFTWARE

Your Polar M600 is powered by Android wear. You'll get an automatic notification to your M600 if there's a new Android Wear system update available. The update will download to your M600 when your smartwatch is plugged in to charge and connected to your phone and your phone has an Internet connection.

You can also check for an available Android Wear software update manually from you smartwatch.

TO MANUALLY CHECK FOR AN UPDATE

1. [Navigate to the Settings menu](#), and find and tap **About**.
2. Scroll the list down to find and tap **System updates**.

The M600 will either tell you that "System is up to date" or "System update available". If there's a new update available, the download will start when your smartwatch is plugged in to charge and connected to your phone and your phone has an Internet connection.

TO INSTALL THE SOFTWARE UPDATE

Once the system update has been downloaded to your M600, you'll receive a notification that the update is ready to be installed.

1. Swipe the notification card from right to left.
2. Tap **Open**.
3. Tap the checkmark to start the installation.



*You can check the version number of your Android Wear software from the Settings menu > **About** > **Versions**.*

UPDATING THE POLAR APP



Applicable to Polar M600 paired with an Android phone

The Polar app on your M600 updates through the Polar Flow mobile app. By keeping your Polar Flow mobile app up to date, you'll ensure that also the Polar app on your M600 has the latest improvements and fixes.

Applicable to Polar M600 paired with an iPhone

The Polar app on your M600 stays up to date through the operating system updates.

IMPORTANT INFO

TAKING CARE OF YOUR M600

Like any electronic device, the Polar M600 should be treated with care. The suggestions below will help you fulfill guarantee obligations and enjoy this product for many years to come.

Don't charge the device when the charging port is wet.

Keep your training device clean.

- We recommend that you wash the device and the silicone wristband after each training session under running water with a mild soap and water solution. Please remove the device from the wristband and wash them separately. Wipe them dry with a soft towel.

 *It is essential that you wash the device and the wristband if you wear them in a swimming pool where chlorine is used for keeping the pool clean.*

- If you don't wear the device 24/7, wipe off any moisture before storing it. Don't store in non-breathable material or in a damp environment, e.g. plastic bag or damp gym bag.
- Wipe it dry with a soft towel when needed. Use a damp paper towel to wipe dirt from the training device. To maintain the water resistance, do not wash the training device with a pressure washer. Never use alcohol or any abrasive material such as steel wool or cleaning chemicals.
- When you connect your M600 to a computer or a USB power adapter, check that there is no moisture, hair, dust or dirt on the M600's charger. Gently wipe off any dirt or moisture. Don't use any sharp tools for cleaning to avoid scratching.

Operating temperatures are -10 °C to +50 °C / +14 °F to +122 °F.

STORING

Keep your training device in a cool and dry place. Do not keep them in a damp environment, in non-breathable material (a plastic bag or a sports bag) nor with conductive material (a wet towel). Do not expose the training device to direct sunlight for extended periods, such as by leaving it in a car or mounted on the bike mount.

It is recommended to store the training device partially or fully charged. The battery slowly loses its charge when it is stored. If you are going to store the training device for several months, it is recommended to recharge it after a few months. This will prolong the battery lifetime.

Dry and store the strap and the connector separately to maximize the heart rate sensor battery lifetime. Keep the heart rate sensor in a cool and dry place. To prevent snap oxidation, do not store the heart rate sensor wet in non-breathing material, such as a sports bag. Do not expose the heart rate sensor to direct sunlight for extended periods.

SERVICE

During the two-year guarantee/warranty period, we recommend that you have service done by an authorized Polar Service Center only. The warranty does not cover damage or consequential damage caused by service not authorized by Polar Electro. For further information, see [Limited International Polar Guarantee](#).


For contact information and all Polar Service Center addresses, visit support.polar.com and country-specific websites.

REMOVING THE WRISTBAND

Removing and replacing the wristband of your M600 is very simple. We recommend that you separate the wristband from the device after each training session and rinse them under running water in order to keep the M600 clean.

TO REMOVE THE WRISTBAND

1. Bend the wristband from both sides, one side at a time, to detach it from the device. It's easiest to remove the side closest to the charging port first.



2. Pull the device from the wristband.

TO ATTACH THE WRISTBAND

1. Set one end of the device in its place.
2. Gently pull from the opposite side of the wristband to get it over the other end of the device.
3. Make sure the band fits flush with the device, both front and back.

DISPOSAL INFORMATION

At the end of the working life of the product, Polar encourages you to minimize possible effects of waste on the environment and human health by following local waste disposal regulations and, where possible, utilizing separate collection of electronic devices. Do not dispose of this product as unsorted municipal waste.

PRECAUTIONS

The Polar M600 is designed to measure heart rate and tell your activity. No other use is intended or implied.

The training device should not be used for obtaining environmental measurements that require professional or industrial precision.

We recommend that once in a while you wash the device and the wrist strap to avoid any skin problems from a dirty bracelet.

INTERFERENCE

Electromagnetic Interference and Training Equipment

Disturbance may occur near electrical devices. Also WLAN base stations may cause interference when training with the training device. To avoid erratic reading or misbehavior, move away from possible sources of disturbance.

Training equipment with electronic or electrical components such as LED displays, motors and electrical brakes may cause interfering stray signals.

If the training device still does not work with the training equipment, it may be electrically too noisy for wireless heart rate measurement. For further information, visit support.polar.com.

MINIMIZING RISKS WHEN TRAINING

Training may include some risk. Before beginning a regular training program, it is recommended that you answer the following questions concerning your health status. If you answer yes to any of these questions, we recommend that you consult a doctor before starting any training program.

- Have you been physically inactive for the past 5 years?
- Do you have high blood pressure or high blood cholesterol?
- Are you taking any blood pressure or heart medication?
- Do you have a history of breathing problems?
- Do you have symptoms of any disease?
- Are you recovering from a serious illness or medical treatment?
- Do you use a pacemaker or other implanted electronic device?
- Do you smoke?
- Are you pregnant?

Note that in addition to training intensity, medications for heart conditions, blood pressure, psychological conditions, asthma, breathing, etc., some energy drinks, alcohol, and nicotine may also affect heart rate.

It is important to be sensitive to your body's responses during training. **If you feel unexpected pain or excessive fatigue when training, it is recommended that you stop the training or continue at a lighter intensity.**

Note! If you are using a pacemaker, defibrillator or other implanted electronic device, you can use Polar products. In theory interference to pacemaker caused by Polar products should not be possible. In practice no reports exist to suggest anyone ever having experienced interference. However, we cannot issue an official guarantee on our products' suitability with all pacemakers or other implanted devices, such as defibrillators, due to the variety of devices available. If you have any doubts, or if you experience any unusual sensations while using Polar products, please consult your physician or contact the implanted electronic device manufacturer to determine safety in your case.

If you are allergic to any substance that comes into contact with your skin or if you suspect an allergic reaction due to using the product, check the listed materials in [Technical Specification](#). To avoid any skin reaction to the heart rate sensor, wear it over a shirt, but moisten the shirt well under the electrodes to ensure flawless operation.

 *The combined impact of moisture and intense abrasion may cause color to come off the heart rate sensor's surface, possibly staining clothes. If you use perfume, suntan/sunscreen lotion or insect repellent on your skin, you must ensure that it does not come into contact with the training device or the heart rate sensor. Please avoid clothing with colors that might transfer onto the training device (especially training devices with light/bright colors) when worn together.*

DISTRACTION

Operating a smartwatch while driving a car, riding a bike, or even running or walking may distract you from your surroundings and cause a dangerous situation. We recommend that you avoid operating the Polar M600 in circumstances where it may risk your safety. Observe also local laws and regulations prohibiting or restricting the use of electronic devices, for example, while driving.

TECHNICAL SPECIFICATION POLAR M600

Operating system	Android Wear
Processor	MediaTek MT2601, Dual-Core 1.2GHz processor based on ARM Cortex-A7
Battery type	500 mAh Li-pol rechargeable battery
Operating time (Android)	2 days / 8 hours of training
Operating time (iOS)	1 day / 8 hours of training
Operating temperature	-10 °C to +50 °C / 14 °F to 122 °F
Charging time	Up to two hours.
Charging temperature	0 °C to +40 °C / 32 °F to 104 °F
Materials	Device: Corning® Gorilla® 3 Glass Polycarbonate/acrylonitrile butadiene styrene/glass fiber Stainless steel Polymethyl methacrylate Polyamide Wristband: Silicone Polycarbonate Stainless steel
GPS accuracy	Distance ±2%, speed ±2 km/h
Sample rate	1 s
Heart rate sensor	Optical heart rate measurement with 6 LEDs
Sensors	Accelerometer, Ambient Light Sensor, Gyroscope, Vibration motor, Microphone
Water resistance	Suitable for swimming (IPX8 10m)
Memory capacity	4GB internal storage + 512MB RAM
Display	1,30", 240 x 240 pixels, 260ppi transmissive TFT display
Weight	63g
Dimensions	45x36x13mm

Polar M600 sports watch works with smartphones running Android 4.3+ or iOS 8.2+. Visit [g.co/WearCheck](https://polar.com/g.co/WearCheck) on your phone to see if it's compatible with Android Wear.

Uses Bluetooth® Smart wireless technology.

Your M600 is compatible with the following Polar heart rate sensors: Polar H6 and H7.

WATER RESISTANCE

Water resistance of Polar products is tested according to International IEC 60529 standard or ISO 22810 standard. Products are divided into different categories according to water resistance. Check the back of your Polar product for the water resistance category and compare it to the chart below. Please note that these definitions do not necessarily apply to products of other manufacturers.

Marking on case back	Water resistant characteristics
Water resistant IPX7	Not suitable for bathing or swimming. Protected against wash splashes and raindrops. Refers to IEC 60529 standard.
Water resistant IPX8 10m	Suitable for swimming and bathing. Protected against wash splashes and raindrops. Not suitable for snorkeling, diving or fast water sports. Refers to IEC 60529 standard.
Water resistant or Water resistant 20m	Suitable for swimming and bathing. Protected against wash splashes and raindrops. Not suitable for snorkeling, diving or fast water sports Refers to ISO 22810 standard.
Water resistant 30 m/50 m	Suitable for bathing and swimming. Refers to ISO 22810 standard .
Water resistant 100 m	Suitable for swimming and snorkeling (without air tanks). Refers to ISO 22810 standard .

LIMITED INTERNATIONAL POLAR GUARANTEE

- This guarantee does not affect the consumer's statutory rights under applicable national or state laws in force, or the consumer's rights against the dealer arising from their sales/purchase contract.
- This limited Polar international guarantee is issued by Polar Electro Inc. for consumers who have purchased this product in the USA or Canada. This limited Polar international guarantee is issued by Polar Electro Oy for consumers who have purchased this product in other countries.
- Polar Electro Oy/Polar Electro Inc. guarantees the original consumer/purchaser of this device that the product will be free from defects in material or workmanship for two (2) years from the date of purchase.
- The receipt of the original purchase is your proof of purchase!
- The guarantee does not cover the battery, normal wear and tear, damage due to misuse, abuse, accidents or non-compliance with the precautions; improper maintenance, commercial use, cracked, broken or scratched cases/displays, armband, elastic strap and Polar apparel.
- The guarantee does not cover any damage/s, losses, costs or expenses, direct, indirect or incidental, consequential or special, arising out of, or related to the product.
- Items purchased second hand are not covered by the two (2) year warranty, unless otherwise stipulated by local law.
- During the guarantee period, the product will be either repaired or replaced at any of the authorized Polar Service Centers regardless of the country of purchase.

Guarantee with respect to any product will be limited to countries where the product has been initially marketed.



This product is compliant with Directives 1999/5/EC and 2011/65/EU.

The relevant Declaration of Conformity is available at www.polar.com/en/regulatory_information.



This crossed out wheeled bin marking shows that Polar products are electronic devices and are in the scope of Directive 2012/19/EU of the European Parliament and of the Council on waste electrical and electronic equipment (WEEE) and batteries and accumulators used in products are in the scope of Directive 2006/66/EC of the European Parliament and of the Council of 6 September 2006 on batteries and accumulators and waste batteries and accumulators. These products and batteries/accumulators inside Polar products should thus be disposed of separately in EU countries. Polar encourages you to minimize possible effects of waste on the environment and human health also outside the European Union by following local waste disposal regulations and, where possible, utilize separate collection of electronic devices for products, and battery and accumulator collection for batteries and accumulators.

To see the M600-specific certification and compliance information, navigate to the Settings menu, swipe all the way up and tap **About** and then **Regulatory information**. Manufactured by Polar Electro Oy, Professorintie 5, FI-90440 KEMPELE, Tel +358 8 5202 100, Fax +358 8 5202 300, www.polar.com.

Polar Electro Oy is a ISO 9001:2008 certified company.

© 2016 Polar Electro Oy, FI-90440 KEMPELE, Finland. All rights reserved. No part of this manual may be used or reproduced in any form or by any means without prior written permission of Polar Electro Oy.

The names and logos in this user manual or in the package of this product are trademarks of Polar Electro Oy. The names and logos marked with a ® symbol in this user manual or in the package of this product are registered trademarks of Polar Electro Oy.

App Store is a service mark of Apple Inc.

iOS is a registered trademark of Cisco Systems, Inc. and/or its affiliates in the United States and certain other countries.

Google, Google Play, Android and other marks are trademarks of Google Inc.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Polar Electro Oy is under license.

COMPLIANCE STATEMENT

CANADA

Polar Electro Oy has not approved any changes or modifications to this device by the user. Any changes or modifications could void the user's authority to operate the equipment.

Polar Electro Oy n'a approuvé aucune modification apportée à l'appareil par l'utilisateur, quelle qu'en soit la nature. Tout changement ou toute modification peuvent annuler le droit d'utilisation de l'appareil par l'utilisateur.

Innovation, Science and Economic Development Canada (ISED) regulatory information

This device complies with Innovation, Science and Economic Development Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

This device complies with the safety requirements for RF exposure in accordance with RSS-102 Issue 5 for portable use conditions.

Avis de conformité à la réglementation d'Innovation, Sciences et Développement économique Canada (ISDE)

Le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Cet appareil est conforme aux exigences de sécurité concernant l'exposition aux RF selon la norme RSS-102, 5ème édition, pour des conditions d'utilisation portable.

Class B digital device notice

This Class B digital apparatus complies with Canadian RSS-Gen and RSS-247.

Cet appareil numérique de la classe B est conforme à la norme CNR-Gen et CNR-247 du Canada.

CAN ICES-3(B)/NMB-3(B)

USA

Polar Electro Oy has not approved any changes or modifications to this device by the user. Any changes or modifications could void the user's authority to operate the equipment.

FCC regulatory information

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experienced radio/ TV technician for help.

This product emits radio frequency energy, but the radiated output power of this device is far below the FCC radio frequency exposure limits.

This equipment complies with FCC RF radiation exposure limits for an uncontrolled environment. Nevertheless, the device should be used in such a manner that the potential for human contact with the antenna during normal operation is minimized.

DISCLAIMER

- The material in this manual is for informational purposes only. The products it describes are subject to change without prior notice, due to the manufacturer's continuous development program.
- Polar Electro Inc./Polar Electro Oy makes no representations or warranties with respect to this manual or with respect to the products described herein.
- Polar Electro Inc./Polar Electro Oy shall not be liable for any damages, losses, costs or expenses, direct, indirect or incidental, consequential or special, arising out of, or related to the use of this material or the products described herein.

1.0 EN 06/2016