

# TROUBLE SHOOTING

## General Problems

| SYMPTOM                                                                | HINT                                                                                                                                                                                                                                                                                                                                                                                                                                              |
|------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| The computer does not have an available USB port.                      | Check if there is an available USB port on a USB hub. If none are available you will need to add a USB hub.                                                                                                                                                                                                                                                                                                                                       |
| The Graphire 2 Pen selects everything, will not stop drawing.          | Open the Wacom control panel and go to the tool's TIP FEEL tab. Move the TIP PRESSURE FEEL slider toward Firm, or select the More Options button and increase the Click Force setting.                                                                                                                                                                                                                                                            |
| The side switch does not work.                                         | Be sure you press the side switch when the pen tip is in proximity--do this without pressing down on the pen tip. From the Wacom control panel, verify that the side switch is set to the proper function for the application and tool that you are using. Make sure the tablet status LED changes from orange to green when you press the side switch. If it does not, you may have defective hardware (See also the last part of this section). |
| Changing the function settings for the Graphire 2 tools has no effect. | Make sure that you change the settings for the tool and the application that you are using. See <i>Working with Graphier Tools</i> and <i>Working with Application-Specific Settings</i> in the online Help or Graphire 2 User's Manual.                                                                                                                                                                                                          |
| The screen cursor jumps back.                                          | Do not place the Graphire 2 Pen or Cordless Mouse on the tablet when using another pointing device.<br>Leaving your tool on the tablet may interfere with screen cursor positioning when using other input devices.                                                                                                                                                                                                                               |
| Double-clicking is difficult.                                          | Be sure you are quickly tapping the tablet twice in the same place on the tablet's active area. Wacom recommends using the side switch to double-click.<br>Try increasing the DOUBLE-CLICK DISTANCE or reducing the double-click speed (see ADJUSTING DOUBLE-CLICK in the ONLINE HELP).<br>Try using a lighter TIP PRESSURE FEEL (see ADJUSTING TIP FEEL in the ONLINE HELP).                                                                     |

| SYMPTOM                                                                                     | HINT                                                                                                                                                                                                                                                                                                                             |
|---------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| The Graphire 2 Pen tip does not function.                                                   | Make sure the status LED changes from orange to green when the tip is pressed. If it does not, you may have defective hardware (See also the last part of this section).<br>Check the control panel's <i>Tool Buttons</i> tab and verify that the tip is assigned to a <i>Left Click</i> ( <i>Click</i> for Macintosh) function. |
| Within a graphics application, you notice a screen delay while drawing lines on the tablet. | In the Wacom control panel, try decreasing the <i>DOUBLE-CLICK DISTANCE</i> or increasing the double-click speed (see <i>ADJUSTING DOUBLE-CLICK</i> in the <i>ONLINE HELP</i> ). If that does not work, try unchecking the <i>DOUBLE-CLICK ASSIST</i> checkbox.                                                                  |
| You have to press hard with the Graphire 2 Pen when clicking or drawing.                    | Open the Wacom control panel and go to the tool's <i>TIP FEEL</i> tab. Move the <i>TIP PRESSURE FEEL</i> slider toward <i>SOFT</i> , or select the <i>MORE OPTIONS</i> button and decrease the <i>CLICK FORCE</i> setting.                                                                                                       |
| The tablet hardware seems defective.                                                        | See <i>TROUBLE SHOOTING</i> in the English Graphire 2 user's manual to test your tablet. See <i>APPENDIX</i> in this manual for product support.                                                                                                                                                                                 |

### Windows or PC Specific Problems

| SYMPTOM                               | HINT                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|---------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| The USB tablet power light is not on. | Make sure all USB cables are securely connected to an active USB port. Try connecting to the USB port on another computer if available.<br>If the tablet's status LED does not illuminate after your computer is on and has finished booting up, your USB port may be inactive. Graphire 2 USB tablets require Windows 98. If you upgraded your computer to Windows 98, verify that the USB ports are enabled in the BIOS and that all necessary system software has been installed. Refer to your system documentation or contact your system manufacturer for information on enabling USB support for your computer.<br>Run the USB Ready utility located on the Graphire 2 CD to check if your system is USB ready. If your system is not USB ready, correctly configure your USB port and install the necessary USB system software, then restart your computer. The <i>NEW HARDWARE FOUND</i> dialog should appear and you can continue with the Graphire 2 installation. |

*Windows and PC Specific Problems -- continued*

| SYMPTOM                                                                                                                                                                                  | HINT                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| After switching to left-handed mouse in the Mouse control panel, the pen tip no longer works as a left click                                                                             | This will reverse the right and left button settings on your Wacom tools.<br>Restart Windows for your Wacom tool settings to be correctly recognized.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
| Cannot move the cursor where you want to on the screen, or the line you are drawing does not line up with the location of the pointer in paint applications.                             | Open the Wacom control panel and go to the MAPPING tab. Verify that PEN MODE is selected and that the DISPLAY AREA is set to ENTIRE DISPLAY for the selected tool and application. If this does not help, click on the RESET TAB TO DEFAULTS button to reestablish tablet to screen mapping. If this does not work, open the Windows folder and delete the WACOM.DAT file. Then restart your computer. When the tablet driver loads, it will create a new preferences file with the factory default settings.                                                                                                                              |
| When the pen tip contacts the tablet surface, the cursor jumps to the top left corner of the screen, or the message, "Unable to implement function", appears in the Wacom control panel. | If you have had another manufacturer's tablet, and the drivers are still loaded on your system, uninstall these drivers according to their manufacturer's instructions and reinstall the Graphire 2 driver.<br><b>ACECAT:</b> Edit your SYSTEM.INI. Go to the drivers= line in the [boot] section and remove awintab. Then go to the [drivers] section and remove the awintab=awintab.drv line. Look also for any reference to Virtual Tablet and remove it. Save the changes and restart Windows.<br><b>KURTA:</b> Edit your SYSTEM.INI by looking for any references to wtkurta and removing them. Save the changes and restart Windows. |
| After pressing CTRL+ALT+DEL, the screen cursor cannot be controlled with your Graphire 2 tool.                                                                                           | When the CLOSE PROGRAM dialog box (Windows 95, 98 or Me) or the TASK MANAGER (Windows NT) is active, the Wacom tablet will not work. Use your mouse or keyboard to continue. When this dialog box is closed, you can again use your Graphire 2 tool to control the screen cursor.                                                                                                                                                                                                                                                                                                                                                          |

| SYMPTOM                                                                                                                                                                                                        | HINT                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Windows 98 or Me. When working with multiple monitors, the screen cursor positioning is incorrect after moving into the unmapped area of the virtual desktop.                                                  | <p>On a multiple monitor system, the tablet is mapped to the virtual desktop (a rectangular area covering all monitors). In the Wacom control panel's PORTION OF DISPLAY dialog box, the screen rectangle represents the entire virtual desktop.</p> <p>If your video display areas do not form a rectangle because they are different sizes or they are not evenly aligned, the screen cursor positioning will be incorrect after moving into the unmapped area of the virtual desktop. To reestablish the correct screen cursor position, lift your Graphire 2 tool out of tablet proximity and bring it back into proximity over an area of the tablet that is mapped to a display area.</p> |
| After changing the resolution of a monitor or the alignment of the monitors on a multiple monitor system, a portion of the tablet or monitor is not accessible and the tablet to display mapping is incorrect. | <p>To reestablish the correct tablet to display mapping, open the Wacom control panel. Select the MAPPING tab, and choose ENTIRE DISPLAY.</p> <p>Click OK to close the control panel, then restart your computer.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| Windows NT. Application-specific settings do not work correctly or blue screen crash occurs.                                                                                                                   | <p>You must update the operating system with Service Pack 3 (SP3) or later in order for application-specific settings to work correctly.</p> <p>Running your Graphire 2 tablet software on a Windows NT 4.0 system that is not updated to SP3 may cause you to experience a blue screen crash.</p>                                                                                                                                                                                                                                                                                                                                                                                              |
| In Windows 95, 98 or Me, your Graphire 2 tool does not function inside a full screen DOS window.                                                                                                               | You must use a mouse when working in a full screen DOS window.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |

### Macintosh Specific Problems

| SYMPTOM                                                                                                                                                            | HINT                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| The USB tablet status LED is off.                                                                                                                                  | <p>Make sure all USB cables are securely connected to an active USB port.</p> <ul style="list-style-type: none"><li>■ If you have an iMac, you will need Macintosh OS 8.5 and Mac OS ROM 1.2.1. Refer to the iMac Update instructions for information on running the iMac Update software located on the Graphire 2 CD.</li><li>■ If you added a USB interface card you must also install system software to support the USB card. If your computer came from the factory with a USB port installed, it should be USB ready.</li><li>■ Plug in a different USB device to verify that the USB port is functional.</li></ul> |
| At startup, a dialog box appears telling you that either the driver failed to load or the tablet preferences have not yet been created.                            | <p>The tablet was not detected at startup. Make sure all cables are securely connected and that the status LED on the tablet is orange. If this does not correct the problem, see <i>Testing Your Graphire 2 Tablet</i> in the electronic Graphire 2 user's Manual.</p>                                                                                                                                                                                                                                                                                                                                                    |
| Graphire 2 works in mouse mode and pressure does not function.                                                                                                     | <p>If you are using an iMac, install the iMac Firmware Update and iMac Update 1.1 located in the Graphire 2 CD. Then install the Graphire 2 software.</p> <p>If the Graphire 2 software was not installed or did not load properly, the tablet will function in mouse emulation mode and pressure support will not be available. If the driver was not installed, complete the software installation. If the driver failed to load, see <i>Resolving Software Conflicts</i> in the electronic Graphire 2 User's Manual.</p>                                                                                                |
| Cannot move the screen cursor where you want to on the screen, or the line you are drawing does not line up with the location of the pointer in paint application. | <p>Open the Wacom control panel and go to the MAPPING tab. Verify that PenMode is selected. If this does not help, the Wacom preference file may be corrupted. Click on the RESET TAB TO DEFAULTS button to reestablish tablet to screen mapping.</p> <p>If this does not work, from the System Folder open the Preferences and Tablet folder. From the Tablet folder, drag the Tablet Preferences file into the trash. Then restart your computer. When the tablet driver loads, it will create a new preferences file with the factory default settings.</p>                                                             |

# PRODUCT SPECIFICATIONS

## GRAPHIRE 2 TABLET (ET-0405A-U)

|                                  |                                                |
|----------------------------------|------------------------------------------------|
| Active area (W x D)              | 127.6 x 92.8 mm (5.02 x 3.65 in)               |
| Physical size (W x D x H)        | 216.1 x 218.0 x 9.3 mm (8.51 x 8.58 x 0.37 in) |
| Weight                           | 426 g (0.94 lb)                                |
| Cable length                     | 1.5 m (4.9 ft)                                 |
| Coordinate resolution (relative) | 40 lpmm (1015 lpi)                             |
| Accuracy                         | +/- 0.5 mm (0.02 in)                           |
| Maximum reading height           | 3 mm (0.12 in) approximately                   |
| Maximum report rate              | 100 points per second                          |
| Communication interface          | USB (USB tablets)                              |
| Connector                        | USB A (USB tablets)                            |
| Power consumption                | 0.2 watts                                      |
| Power requirements               |                                                |
| USB tablets                      | DC 5V 40 mA, from USB port                     |
| Operating temperature            | 5 to 40 degrees C (41 to 104 degrees F)        |
| Storage temperature              | -10 to +60 degrees C (14 to 140 degrees F)     |
| Operating relative humidity      | 20% to 80% noncondensing                       |
| Storage relative humidity        | 20% to 90% noncondensing                       |
| Certification                    | FCC class B                                    |
| Compliance                       | VCCI class B, CE                               |

## GRAPHIRE 2 PEN (MODEL EP-120E)

|                       |                                |
|-----------------------|--------------------------------|
| Physical size (L x D) | 145 x 12.5 mm (5.71 x 0.49 in) |
| Pressure levels       | 512 levels                     |
| Pen tip travel        | 0.1 mm (0.004 in) or less      |
| Eraser tip travel     | 0.1 mm (0.004 in) or less      |
| Weight                | 11 g (0.02 lb), approximately  |
| Tip refill type       | Polyacetal (Part No. PSI-A007) |

## GRAPHIRE 2 CORDLESS MOUSE (MODEL EC-120)

|                           |                                          |
|---------------------------|------------------------------------------|
| Physical size (L x W x H) | 116 x 58 x 37 mm (4.57 x 2.28 x 1.47 in) |
| Weight                    | 84 g (0.19 lb), approximately            |
| Fingerwheel type          | Continuous rotation, 24 clicks per turn  |

# LICENSE AND WARRANTIES

(WORLDWIDE, EXCEPT FOR EUROPE, AFRICA AND MIDDLE EAST)

## **Software License**

This legal document is an agreement between you, the end-user, and Wacom Technology Corporation (Wacom).

1. **Grant of License.** The enclosed product includes computer programs embedded in firmware and accompanying diskette or CD-ROM (the "Software"). The Software is licensed, not sold, to you for use only with Wacom products upon the terms of this license, and Wacom reserves any rights not expressly granted to you. Wacom grants to you a non-exclusive right to use this copy of the Software in conjunction with a Wacom product at a single location.
2. **Ownership of Software.** Although you may own the product in which the Software is originally recorded, Wacom retains ownership of the Software itself. You acknowledge that the Software is Wacom's property, and contains valuable confidential, unpublished information developed or acquired by Wacom at great expense, including data processing algorithms, innovations and concepts. The Software is protected by copyright and other federal and state laws. You agree to use your reasonable best efforts to protect the Software from unauthorized reproduction, distribution, disclosure, use, or publication.
3. **Copy Restrictions.** Unauthorized copying of the Software is expressly forbidden.
4. **Use Restrictions.** You may not decompile, reverse assemble, disassemble or reverse engineer the Software.
5. **Termination.** This License is effective until terminated. This License will terminate automatically without notice from Wacom if you fail to comply with any provisions of the License.
6. **Miscellaneous.** This License is governed by the laws of the United States of America and the state of California except in Asia Pacific and by the laws of Japan for Asia Pacific.

## **LIMITED WARRANTY**

Wacom warrants the product, except for the Software, to be free from defects in materials and workmanship under normal use and service for a period of one (1) year from the date of original retail purchase, as evidenced by a copy of the receipt and a registration card that has been returned to Wacom within 30 days of purchase.

The Software is licensed "as is." Wacom makes no warranty with respect to its quality or performance. Wacom cannot guarantee you uninterrupted service or the correction of any errors.

Upon discovery of a defect in the product, except in the Software, within the Warranty Period, you should contact Wacom Technical Support via telephone to obtain an RMA (Return Merchandise Authorization) number and instructions for shipping the product to a service location designated by Wacom. You should send the product, shipping charges prepaid, to the designated service location, accompanied by the return authorization number, your name, address and telephone number, proof of purchase date, and a description of the defect. Wacom will pay for return shipping by United Parcel Service or by an equivalent service as chosen by Wacom. Wacom's sole obligation and entire liability under this warranty shall be, at Wacom's option, either the repair or replacement of the defective product or parts thereof of which Wacom is notified during the Warranty Period; provided, however, that you are responsible for (i) the cost of transportation of the product to the designated service location and (ii) any loss or damage to the product resulting from such transportation.

Wacom shall have no responsibility to repair or replace the product if the failure of the product has resulted from accident, abuse, misuse, negligence, or unauthorized modification or repair, or if it has been handled or stored other than in accordance with Wacom's storage instructions. Any descriptions, drawings, specifications, samples, models, bulletins, or similar material, used in connection with the sale of the product, shall not be construed as an express warranty that the product will conform or comply with your requirements.

EXCEPT FOR THE LIMITED WARRANTY DESCRIBED ABOVE, THERE ARE NO OTHER WARRANTIES MADE BY WACOM ON THIS PRODUCT. NO ORAL OR WRITTEN INFORMATION OR ADVICE GIVEN BY WACOM, ITS DEALERS, DISTRIBUTORS, AGENTS, OR EMPLOYEES SHALL CREATE A WARRANTY OR IN ANY WAY INCREASE THE SCOPE OF

THIS WARRANTY, AND YOU MAY NOT RELY ON ANY SUCH INFORMATION OR ADVICE. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, WHICH VARY FROM STATE TO STATE.

WACOM LIMITS THE DURATION OF ANY LEGALLY IMPLIED WARRANTIES INCLUDING IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, TO THE DURATION OF WACOM'S EXPRESS WARRANTY. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS. SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU. NEITHER WACOM NOR ANYONE ELSE WHO HAS BEEN INVOLVED IN THE CREATION, PRODUCTION, OR DELIVERY OF THIS PRODUCT SHALL BE LIABLE FOR ANY DIRECT, CONSEQUENTIAL, OR INCIDENTAL DAMAGES (INCLUDING DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, LOSS OF BUSINESS INFORMATION AND THE LIKE) ARISING OUT OF THE USE OF OR INABILITY TO USE SUCH PRODUCT, EVEN IF WACOM HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. BECAUSE SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF LIABILITY FOR CONSEQUENTIAL DAMAGES, THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

In the event that any of the above limitations are held unenforceable, Wacom's liability for any damages to you or any party shall not exceed the purchase price you paid, regardless of the form of any claim.

This Limited Warranty is governed by the laws of the United States of America and the state of California.

This Limited Warranty is valid for and only applies to products purchased and used inside the United States (and its territories or possessions) and Canada.

#### WARRANTY ON SALES OUTSIDE OF U.S. AND CANADA

For products purchased or used outside of the United States and Canada, upon discovery of a defect in the product, except in the Software, within the Warranty Period you should notify your local dealer or distributor. In all other respects the terms of the warranty as set forth above apply to such sales.

Should you have any questions about this Agreement, or if you desire to contact Wacom for any reason, please contact in writing:

In North and South America contact:  
Wacom Technology Corporation  
1311 S.E. Cardinal Court  
Vancouver, Washington 98683  
U.S.A.

In Asia and Asia Pacific contact:  
WACOM Co., Ltd.  
2-510-1 Toyonodai  
Otone-Machi, Kitasaitama-Gun  
Saitama, 349-1148  
Japan

#### **Copyright © WACOM Company, Limited, 2001**

All rights reserved. No part of this manual may be reproduced except for your express personal use. Wacom reserves the right to revise this publication without obligation to provide notification of such changes. Wacom does its best to provide current and accurate information in this manual. However, Wacom reserves the right to change any specifications and product configurations at its discretion, without prior notice and without obligation to include such changes in this manual.

#### **TRADEMARKS**

Wacom is a registered trademark and Graphire 2 is a trademark of Wacom Company, Limited. Apple, the Apple logo, and Macintosh are registered trademarks of Apple Computer, Inc., registered in the U.S. and other countries. Microsoft, Windows and Windows NT are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries. Any additional company and product names mentioned in this documentation may be trademarked and/or registered as trademarks. Mention of third-party products is for information purposes only and constitutes neither an endorsement nor a recommendation. Wacom assumes no responsibility with regard to the performance or use of these products.

# Lucy tablet ET-0405A-U Specifications

| Items                                     | Specifications                    |
|-------------------------------------------|-----------------------------------|
|                                           | USB                               |
| <b>General</b>                            |                                   |
| External dimension                        | 206x227x10mm                      |
| Weight                                    | 400g                              |
| Operating temperature                     | 5℃ to 40℃                         |
| Operating relative humidity               | 20% to 80% noncondensing          |
| Storage temperature                       | -10℃ to 60℃                       |
| Storage relative humidity                 | 20% to 90% noncondensing          |
| <b>Performance and interface</b>          |                                   |
| Operation method                          | Electro-magnetic give and receive |
| Active area                               | 127.6x92.8mm                      |
| Coordinate data resolution                | 40 lpm (1000 lpi)                 |
| Coordinate data accuracy                  | +/-0.5mm                          |
| Maximum reading height                    | 0.3mm or less                     |
| Title allowance for guranteed coord. data | 40 degress from vertical          |
| Data transfer rate                        | 100(default)/200(max) points/sec  |
| Command system                            | WACOM4                            |
| Output data format                        | WACOM4                            |
| Pressure levles                           | 512 levels                        |
| Eraser-pen support                        | Yes                               |
| Interface                                 | USB                               |
| Baud rate                                 | USB                               |
| Communication method                      | USB                               |
| Data lenth, parity, stop bit              | USB                               |
| Cable length                              | 2m                                |
| Connector type                            | USB type B                        |
| LED colors                                | Amber/Green                       |
| Pointing device                           | Lucy pen/Mouse                    |
| <b>Power Requirement</b>                  |                                   |
| Power intake method                       | USB                               |
| Input voltage                             | DC 5V +/-5%                       |
| Input current                             | 100mA or less                     |
| <b>Others</b>                             |                                   |
| International certificate compliance      | FCC class B, CE, VCCI class 2     |
| Standard accessories                      | Pen, Mouse, guide, CD-ROM         |