

Using the Configuration Menu (continued)

Tools> Admin

The screenshot shows the D-Link configuration interface for a DI-524 router. The top navigation bar includes 'Home', 'Advanced', 'Tools' (selected), 'Status', and 'Help'. The 'Tools' section is titled 'Administrator Settings' and contains two main sections: 'Administrator (The Login Name is "admin")' and 'User (The Login name is "user")'. Each section has fields for 'New Password' and 'Reconfirm Password'. Below these is the 'Remote Management' section, which includes a radio button to enable or disable remote access, and fields for 'IP Address' and 'Port'. At the bottom right are 'Apply', 'Cancel', and 'Help' buttons.

D-Link
Building Networks for People

AirPlus G

802.11g/2.4GHz Wireless Router

DI-524

Admin

Time

System

Firmware

Misc

Home Advanced Tools Status Help

Administrator Settings
Administrators can change their login password.

Administrator (The Login Name is "admin")

New Password: [password field]
Reconfirm Password: [password field]

User (The Login name is "user")

New Password: [password field]
Reconfirm Password: [password field]

Remote Management
Let administrator perform administration task from remote host.

☐ Enabled ☒ Disabled

IP Address: [0.0.0.0]
Port: [8080]

Apply Cancel Help

At this page, the DI-524 administrator can change the system password. There are two accounts that can access the Broadband Router's Web-Management interface. They are admin and user. Admin has read/write access while user has read-only access. User can only view the settings but cannot make any changes.

Administrator- admin is the **Administrator login name**

Password- Enter the password and enter again to confirm

User- user is the **User login name**

Password- Enter the password and enter again to confirm

Remote Management- Remote management allows the DI-524 to be configured from the Internet by a web browser. A username and password is still required to access the Web-Management interface. In general, only a member of your network can browse the built-in web pages to perform **Administrator** tasks. This feature enables you to perform Administrator tasks from the remote (Internet) host.


IP Address- The Internet IP address of the computer that has access to the Broadband Router. If you input an asterisk (*) into this field, then any computer will be able to access the Router. Putting an asterisk (*) into this field would present a security risk and is not recommended.

Port- The port number used to access the Broadband Router.

Example- http://x.x.x.x:8080 where x.x.x.x is the WAN IP address of the Broadband Router and 8080 is the port used for the Web-Mangement interface.

Using the Configuration Menu (continued)

Tools > Time



Default NTP Server-

NTP is short for *Network Time Protocol*. NTP synchronizes computer clock times in a network of computers. This field is optional.

Time Zone-

Set Device Date and Time: To manually input the time. Enter the values in these fields for the Year, Month, Day, Hour, Minute, and Second.

Set the Time-


To manually input the time, enter the values in these fields for the Year, Month, Day, Hour, Minute, and Second. Click **Set Time**.

Daylight Saving-

To select Daylight Saving time manually, select **enabled** or **disabled**, and enter a start date and an end date for daylight saving time.

Using the Configuration Menu (continued)

Tools > System



The current system settings can be saved as a file onto the local hard drive. The saved file or any other saved setting file can be loaded back on the Broadband Router. To reload a system settings file, click on **Browse** to browse the local hard drive and locate the system file to be used. You may also reset the Broadband Router back to factory settings by clicking on **Restore**.

Save Settings to Local Hard Drive-

Click **Save** to save the current settings to the local Hard Drive

Load Settings from Local Hard Drive-


Click **Browse** to find the settings, then click **Load**

Restore to Factory Default Settings-

Click **Restore** to restore the factory default settings

Using the Configuration Menu (continued)

Tools > Firmware




You can upgrade the firmware of the Router here. Make sure the firmware you want to use is on the local hard drive of the computer. Click on **Browse** to browse the local hard drive and locate the firmware to be used for the update. Please check the D-Link support site for firmware updates at <http://support.dlink.com>. You can download firmware upgrades to your hard drive from the D-Link support site.

Firmware Upgrade- Click on the link in this screen to find out if there is an updated firmware; if so, download the new firmware to your hard

Browse- After you have downloaded the new firmware, click **Browse** in this window to locate the firmware update on your hard drive. Click **Apply** to complete the firmware upgrade.

Using the Configuration Menu (continued)

Tools > Misc



Ping Test-

The Ping Test is used to send Ping packets to test if a computer is on the Internet. Enter the IP Address that you wish to Ping, and click **Ping**

Restart Device-

Click **Reboot** to restart the DI-524

Block WAN Ping-

If you choose to block WAN Ping, the WAN IP Address of the DI-524 will not respond to pings. Blocking the Ping may provide some extra security from hackers.

Discard Ping from WAN side-

Click **Enabled** to block the WAN ping

UPNP-

To use the *Universal Plug and Play* feature click on **Enabled**. UPNP provides compatibility with networking equipment, software and peripherals of the over 400 vendors that cooperate in the Plug and Play forum.

VPN Pass Through-


The DI-524 supports VPN (Virtual Private Network) pass-through for both PPTP (Point-to-Point Tunneling Protocol) and IPSec (IP Security). Once VPN pass-through is enabled, there is no need to open up virtual services. Multiple VPN connections can be made through the DI-524. This is useful when you have many VPN clients on the LAN network.

PPTP- select **Enabled** or **Disabled**

IPSec- select **Enabled** or **Disabled**

Using the Configuration Menu (continued)

Status > Device Info



This page displays the current information for the DI-524. It will display the LAN, WAN and MAC address information.

If your WAN connection is set up for a **Dynamic IP address** then a **Release** button and a **Renew** button will be displayed. Use *Release* to disconnect from your ISP and use *Renew* to connect to your ISP.

If your WAN connection is set up for **PPPoE**, a **Connect** button and a **Disconnect** button will be displayed. Use *Disconnect* to drop the PPPoE connection and use *Connect* to establish the PPPoE connection.

This window will show the DI-524's working status:

WAN

IP Address: WAN/Public IP Address
Subnet Mask: WAN/Public Subnet Mask
Gateway: WAN/Public Gateway IP Address
Domain Name Server: WAN/Public DNS IP Address
WAN Status: WAN Connection Status

LAN

IP Address: LAN/Private IP Address of the DI-524
Subnet Mask: LAN/Private Subnet Mask of the DI-524

Wireless

MAC Address: Displays the MAC address
SSID: Displays the current SSID
Channel: Displays the current channel
WEP: indicates whether WEP is enabled or disabled

Using the Configuration Menu (continued)

Status > Log

The screenshot shows the D-Link configuration interface for an AirPlus G 802.11g/2.4GHz Wireless Router. The top navigation bar includes links for Home, Advanced, Tools, Status (highlighted), and Help. On the left sidebar, there are buttons for Device Info, Log (highlighted), Stats, and Wireless. The main content area is titled 'View Log' and contains a description: 'View Log displays the activities occurring on the DI-524. Click on Log Settings for advance features.' Below this is a row of buttons: First Page, Last Page, Previous, Next, Clear, and Log Settings. A 'Help' icon with a red cross is also present. The log content shows the WAN Type as 'PPP over Ethernet (V1.00)' and the display time as 'Fri Aug 13 03:31:02 2004'. The log entries are in Chinese and show various PPPoE events from August 13, 2004, at 03:00:49 and 03:00:53.

D-Link
Building Networks for People

AirPlus™ G
802.11g/2.4GHz Wireless Router

DI-524

Device Info
Log
Stats
Wireless

Home Advanced Tools Status Help

View Log
View Log displays the activities occurring on the DI-524. Click on Log Settings for advance features.

First Page Last Page Previous Next Clear Log Settings

Help

Page 1/68

WAN Type: PPP over Ethernet (V1.00)
Display time: Fri Aug 13 03:31:02 2004

2004年8月13日 上午 03:00:49 DOD:triggered internally
2004年8月13日 上午 03:00:49 PPPoE start to dial-up
2004年8月13日 上午 03:00:49 PADI sent
2004年8月13日 上午 03:00:49 PADI sent
2004年8月13日 上午 03:00:50 PADI sent
2004年8月13日 上午 03:00:53 DOD:triggered internally
2004年8月13日 上午 03:00:53 PPPoE start to dial-up
2004年8月13日 上午 03:00:53 PADI:3com sent
2004年8月13日 上午 03:00:53 PADI:3com sent
2004年8月13日 上午 03:00:54 PADI:3com sent

The Broadband Router keeps a running log of events and activities occurring on the Router. If the device is rebooted, the logs are automatically cleared. You may save the log files under Log Settings.

View Log-

First Page - The first page of the log

Last Page - The last page of the log

Previous - Moves back one log page


Next - Moves forward one log page

Clear - Clears the logs completely

Log Settings - Brings up the page to configure the log

Using the Configuration Menu (continued)

Status > Log > Log Settings



The screenshot shows the D-Link configuration interface for an AirPlus G 802.11g/2.4GHz Wireless Router. The left sidebar contains a device image and buttons for 'Device Info', 'Log' (highlighted in yellow), 'Stats', and 'Wireless'. The main content area has tabs for 'Home', 'Advanced', 'Tools', 'Status' (highlighted in yellow), and 'Help'. Under the 'Status' tab, the 'Log Settings' section is active. It includes a sub-header 'Log Settings' and a note: 'Logs can be saved by sending it to an admin email address or to a syslog server.' The 'E-mail Alert' section contains fields for 'SMTP Server / IP Address', 'Email Address', and 'E-mail Subject', along with a 'Send Mail Now' button. The 'Syslog' section includes a 'Syslog Server IP Address' field (pre-filled with '192.168.0.') and radio buttons for 'Enabled' and 'Disabled' (with 'Disabled' selected). Below this, the 'Log Type' section has five checked checkboxes: 'System Activity', 'Debug Information', 'Attacks', 'Dropped Packets', and 'Notice'. At the bottom right, there are three icons: a green checkmark for 'Apply', an orange 'X' for 'Cancel', and a red plus sign for 'Help'.

Not only does the Broadband Router display the logs of activities and events, it can setup to send these logs to another location.

**SMTP Server/
IP Address -**

The address of the SMTP server that will be used to send the logs

Email Address -

The email address to which the logs will be sent.
Click on **Send Mail Now** to send the email.

Using the Configuration Menu (continued)

Status > Stats

The screenshot shows the D-Link configuration interface for an AirPlus G 802.11g/2.4GHz Wireless Router. The left sidebar contains a device image and navigation buttons: Device Info, Log, Stats (highlighted), and Wireless. The main content area has tabs for Home, Advanced, Tools, Status, and Help. Under the Status tab, the 'Traffic Statistics' section displays packet counts for WAN, LAN, and Wireless ports, categorized by Receive and Transmit. A 'Refresh' button and a 'Reset' button are present. A red plus icon with the word 'Help' is also visible.

	Receive	Transmit
WAN	0 Packets	2037 Packets
LAN	4091 Packets	3509 Packets
Wireless	0 Packets	2037 Packets

The screen above displays the Traffic Statistics. Here you can view the amount of packets that pass through the DI-524 on both the WAN and the LAN ports. The traffic counter will reset if the device is rebooted.

Status > Wireless

The screenshot shows the D-Link configuration interface for an AirPlus G 802.11g/2.4GHz Wireless Router. The left sidebar contains a device image and navigation buttons: Device Info, Log, Stats, and Wireless (highlighted). The main content area has tabs for Home, Advanced, Tools, Status, and Help. Under the Status tab, the 'Connected Wireless Client List' section displays a table of connected wireless clients. A 'Refresh' button and a red plus icon with the word 'Help' are present.

Connected Time	MAC Address
----------------	-------------

The wireless client table displays a list of current connected wireless clients. This table also displays the connection time and MAC address of the connected wireless client.

Click on **Help** at any time, for more information.

Networking Basics

Using the Network Setup Wizard in Windows XP

In this section you will learn how to establish a network at home or work, using **Microsoft Windows XP**.

Note: Please refer to websites such as <http://www.homenethelp.com> and <http://www.microsoft.com/windows2000> for information about networking computers using Windows 2000, ME or 98.

Go to **Start>Control Panel>Network Connections**

Select **Set up a home or small office network**



When this screen appears, **Click Next**.