



# User Manual

**AX3200 Wi-Fi 6 Gigabit Router**

**DIR-X3260**

---

# Preface

D-Link reserves the right to revise this publication and to make changes in the content hereof without obligation to notify any person or organization of such revisions or changes.

## Manual Revisions

| Hardware | Revision | Date       | Description     |
|----------|----------|------------|-----------------|
| A1       | v1.00    | 2021/05/19 | Initial release |

## Trademarks

D-Link and the D-Link logo are trademarks or registered trademarks of D-Link Corporation or its subsidiaries in the United States or other countries. All other company or product names mentioned herein are trademarks or registered trademarks of their respective companies.

Apple®, Apple logo®, Safari®, iPhone®, and Macintosh® are trademarks of Apple Inc., registered in the U.S. and other countries. App Store<sup>SM</sup> is a service mark of Apple Inc.

Chrome™ browser, Google Play™ and Android™ are trademarks of Google Inc.

Internet Explorer®, Windows® and the Windows logo are trademarks of the Microsoft group of companies.

Copyright © 2021 by D-Link Corporation, Inc.

All rights reserved. This publication may not be reproduced, in whole or in part, without prior expressed written permission from D-Link Corporation, Inc.

---

# ErP Power Usage

This device is an Energy Related Product (ErP) with High Network Availability (HiNA), and automatically switches to a power-saving Network Standby mode within 1 minute of no packets being transmitted. It can also be turned off through a power switch to save energy when it is not needed.

|                  |                                                         |
|------------------|---------------------------------------------------------|
| <b>DIR-X3260</b> | Network Standby: 5.31 watts<br>Switched Off: 0.69 watts |
|------------------|---------------------------------------------------------|

# Table of Contents

|                                           |           |                                                |           |
|-------------------------------------------|-----------|------------------------------------------------|-----------|
| <b>Product Overview.....</b>              | <b>1</b>  | IPv4 - DS-Lite .....                           | 36        |
| Package Contents.....                     | 1         | Internet - IPv6.....                           | 37        |
| System Requirements .....                 | 2         | IPv6 - Auto Detection .....                    | 38        |
| Features.....                             | 3         | IPv6 - Static IPv6 .....                       | 40        |
| Hardware Overview .....                   | 4         | IPv6 - Auto Configuration (SLAAC/DHCPv6) ..... | 42        |
| LED Indicators .....                      | 4         | IPv6 - PPPoE .....                             | 45        |
| <b>Installation .....</b>                 | <b>5</b>  | IPv6 - 6rd .....                               | 49        |
| Before you Begin.....                     | 5         | IPv6 - Local Connectivity Only .....           | 51        |
| Wireless Installation Considerations..... | 6         | Internet - VLAN .....                          | 52        |
| Setup.....                                | 7         | Wireless .....                                 | 54        |
| D-Link Wi-Fi App Setup.....               | 8         | Guest Zone.....                                | 60        |
| Hardware Setup .....                      | 10        | Network.....                                   | 61        |
| Setup Wizard .....                        | 13        | D-Link Cloud.....                              | 63        |
| <b>Configuration.....</b>                 | <b>20</b> | Features.....                                  | 64        |
| Home .....                                | 21        | QoS Engine.....                                | 64        |
| Internet.....                             | 22        | Firewall Settings - Advanced .....             | 66        |
| DIR-X3260.....                            | 23        | Firewall Settings - IPv4/IPv6 Rules.....       | 68        |
| Connected Clients .....                   | 24        | Port Forwarding .....                          | 70        |
| Settings .....                            | 26        | Port Forwarding - Virtual Server.....          | 72        |
| Wizard .....                              | 26        | Website Filter.....                            | 74        |
| Internet - IPv4.....                      | 27        | Static Route - IPv4.....                       | 75        |
| IPv4 - Dynamic IP (DHCP).....             | 28        | Static Route - IPv6.....                       | 76        |
| IPv4 - Static IP .....                    | 29        | Dynamic DNS .....                              | 77        |
| IPv4 - PPPoE .....                        | 30        | Quick VPN .....                                | 79        |
| IPv4 - PPTP.....                          | 32        | <b>Management.....</b>                         | <b>80</b> |
| IPv4 - L2TP .....                         | 34        | Time & Schedule - Time .....                   | 80        |
|                                           |           | Time & Schedule - Schedule .....               | 81        |

|                                                       |            |                                       |            |
|-------------------------------------------------------|------------|---------------------------------------|------------|
| System Log .....                                      | 82         | Windows® 10 .....                     | 118        |
| System Admin - Admin .....                            | 84         | <b>Troubleshooting .....</b>          | <b>119</b> |
| System Admin - System .....                           | 85         | <b>Wireless Basics .....</b>          | <b>121</b> |
| User .....                                            | 86         | <b>Wireless Modes .....</b>           | <b>125</b> |
| Upgrade .....                                         | 87         | <b>Networking Basics .....</b>        | <b>126</b> |
| Statistics .....                                      | 88         | <b>Wireless Security .....</b>        | <b>128</b> |
| <b>Third Party Services.....</b>                      | <b>89</b>  | <b>Technical Specifications .....</b> | <b>129</b> |
| Registering a D-Link Cloud Service Account .....      | 90         | <b>Regulatory Statements .....</b>    | <b>130</b> |
| Amazon Alexa Setup .....                              | 93         | <b>Wall Mounting .....</b>            | <b>150</b> |
| Amazon Alexa Voice Commands .....                     | 97         |                                       |            |
| The Google Assistant Setup .....                      | 98         |                                       |            |
| The Google Assistant Voice Commands .....             | 101        |                                       |            |
| <b>Quick VPN.....</b>                                 | <b>102</b> |                                       |            |
| Important Information .....                           | 103        |                                       |            |
| iOS Devices .....                                     | 104        |                                       |            |
| VPN Setup Instructions.....                           | 104        |                                       |            |
| Connect or Disconnect .....                           | 106        |                                       |            |
| Mac OS X.....                                         | 107        |                                       |            |
| VPN Setup Instructions.....                           | 107        |                                       |            |
| Connect or Disconnect .....                           | 109        |                                       |            |
| Windows 10 .....                                      | 110        |                                       |            |
| VPN Setup Instructions.....                           | 110        |                                       |            |
| Connect or Disconnect .....                           | 112        |                                       |            |
| Android .....                                         | 113        |                                       |            |
| VPN Setup Instructions.....                           | 113        |                                       |            |
| Connect or Disconnect .....                           | 115        |                                       |            |
| <b>Connect a Wireless Client to your Router .....</b> | <b>117</b> |                                       |            |
| WPS Button .....                                      | 117        |                                       |            |

# Product Overview

## Package Contents

|                          | DIR-X3260 |
|--------------------------|-----------|
| DIR-X3260                | V         |
| Quick Installation Guide | V         |
| Quick Installation Card  | V         |
| Ethernet Cable (RJ45)    | V         |
| Power Adapter            | V         |

*If any of the above items are missing or damaged, please contact your local reseller.*

**Note:** *Using a power supply with a different voltage rating than the one included with the router will cause damage and void the warranty for this product.*

# System Requirements

|                                                     |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|-----------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Network Requirements</b>                         | <ul style="list-style-type: none"><li>• An Ethernet-based cable, DSL or fiber modem</li><li>• IEEE 802.11ax/ac/n/g/b/a wireless clients</li><li>• 10/100/1000 Ethernet</li></ul>                                                                                                                                                                                                                                                                                                                                                                                                     |
| <b>Web-based Configuration Utility Requirements</b> | <p><b>Computer with the following:</b></p> <ul style="list-style-type: none"><li>• Windows®, Macintosh, or Linux-based operating system</li><li>• An installed Ethernet adapter</li></ul> <p><b>Browser Requirements:</b></p> <ul style="list-style-type: none"><li>• Internet Explorer 10 or higher</li><li>• Firefox 28 or higher</li><li>• Safari 6 or higher</li><li>• Chrome 28 or higher</li></ul> <p><b>Windows® Users:</b> Make sure you have the latest version of Java installed. Visit <a href="http://www.java.com">www.java.com</a> to download the latest version.</p> |
| <b>D-Link Wi-Fi App Requirements</b>                | <ul style="list-style-type: none"><li>• iOS® or Android™ device (Please refer to the app's store page to check whether your device is compatible.)</li></ul>                                                                                                                                                                                                                                                                                                                                                                                                                         |

# Features

Need super-fast Wi-Fi for your wire-free, all-streaming house? With a powerful dual-core processor, the AX3200 Wi-Fi 6 Gigabit Router packs in enough processing power to handle every networking task you throw at it. It's a powerful, intelligent home router with integrated voice assistant compatibility for Amazon Alexa and Google Assistant so you can control your network with voice commands.

## **Handle More with a High-Power Processor**

With the DIR-X3260, you're not only enjoying buffer-free gaming and lightning fast surfing, you're also enjoying features such as an optimizing QoS, an automatic firmware update system that ensures the best protection and the latest features, and compatibility with voice assistants. All this is possible with the router's 1.3 GHz dual-core high-power processor, 128 MB of flash memory and 512 MB of RAM.

## **Enhanced Quality of Service Features**

The built-in Quality of Service (QoS) engine allows you to prioritize important traffic to ensure that your favorite applications are receiving optimal bandwidth.

## **Always Up-to-Date with the Latest Features**


The DIR-X3260 will automatically check daily for updates to make sure that the device always has the latest features and the most secure firmware, and will install the update silently in the background. For an extra peace of mind, in the event of failure during the firmware update, the router will store a backup system image in the memory before proceeding with the update.

## **Easy to Set Up and Manage**

Sharing your Internet connection doesn't have to be a complicated process; just download the free D-Link Wi-Fi app for your mobile device and follow the on-screen step-by-step instructions to set up your DIR-X3260. You also have the option to use a web browser to access the setup wizard and to manage your router. Support for industry-standard Wi-Fi Protected Setup (WPS) lets you create encrypted connections to new devices by pressing a button.

# Hardware Overview

## LED Indicators



|   |                    |                 |                                                                   |
|---|--------------------|-----------------|-------------------------------------------------------------------|
| 1 | Power              | Solid White     | The device is on and the system is healthy.                       |
|   |                    | Solid Orange    | The device is booting up or performing the factory reset process. |
|   |                    | Blinking Orange | The device is under recovery mode.                                |
| 2 | Internet           | Solid White     | The Internet port connection is established.                      |
|   |                    | Solid Orange    | The device cannot connect to the Internet.                        |
|   |                    | Blinking Orange | The device is undergoing the firmware upgrade process.            |
| 3 | Wireless (2.4 GHz) | Solid White     | The 2.4 GHz wireless band is enabled.                             |
|   |                    | Blinking White  | The device is processing WPS.                                     |
| 4 | Wireless (5 GHz)   | Solid White     | The 5 GHz wireless band is enabled.                               |
|   |                    | Blinking White  | The device is processing WPS.                                     |

# Installation

This section will walk you through the installation of your DIR-X3260.

## Before you Begin

- Placement of the router is very important. Do not place the router in an enclosed area such as a closet, cabinet, attic, or garage.
- Configure the router with the computer that was last connected directly to your Internet connection. Verify that it is connected to the Internet before connecting additional devices.
- You can only use the Ethernet port on your modem. If you were using the USB connection before using the router, then you must turn off your modem, disconnect the USB cable and connect an Ethernet cable to the Internet port on the router, and then turn the modem back on. In some cases, you may need to call your Internet Service Provider (ISP) to change connection types (USB to Ethernet).
- If connecting to a DSL modem, make sure to have your DSL service information provided by your Internet Service Provider handy. This information is likely to include your DSL account's Username and Password. Your ISP may also supply you with additional WAN configuration settings which might be necessary to establish a connection.
- If you are connecting a considerable amount of networking equipment, it may be a good idea to take the time to label each cable or take a picture of your existing setup before making any changes.
- If you have DSL and are connecting via PPPoE, make sure you disable or uninstall any PPPoE software such as WinPoET, BroadJump, or EnterNet 300 from your computer or you will not be able to connect to the Internet.
- For wall mounting, please use screws to secure the device. We recommend using screws with the following dimensions: 6.5 mm head diameter / 3.5 mm screw diameter / 25 mm screw length (not including screw head).

# Wireless Installation Considerations

The D-Link wireless router lets you access your network using a wireless connection from virtually anywhere within the operating range of your wireless network. Keep in mind that the number, thickness and location of walls, ceilings, or other objects that the wireless signals must pass through may limit the range. Typical ranges vary depending on the types of materials and background RF (radio frequency) noise in your home or business. The key to maximizing wireless range is to follow these basic guidelines:

1. Keep the number of walls and ceilings between the D-Link router and other network devices to a minimum - each wall or ceiling can reduce your adapter's range from 3-90 feet (1-30 meters.) Position your devices so that the number of walls or ceilings is minimized.
2. Be aware of the direct line between network devices. A wall that is 1.5 feet thick (0.5 meters), at a 45-degree angle appears to be almost 3 feet (1 meter) thick. At a 2-degree angle it looks over 42 feet (14 meters) thick. Position devices so that the signal will travel straight through a wall or ceiling (instead of at an angle) for better reception.
3. Building materials make a difference. A solid metal door or aluminum studs may have a negative effect on range. Try to position access points, wireless routers, and computers so that the signal passes through drywall or open doorways. Materials and objects such as glass, steel, metal, walls with insulation, water (fish tanks), mirrors, file cabinets, brick, and concrete will degrade your wireless signal.
4. Keep your product away (at least 3-6 feet or 1-2 meters) from electrical devices or appliances that generate RF noise.
5. If you are using 2.4 GHz cordless phones or X-10 (wireless products such as ceiling fans, lights, and home security systems), your wireless connection may degrade dramatically or drop completely. Make sure your 2.4 GHz phone base is as far away from your wireless devices as possible. The base transmits a signal even if the phone is not in use.

# Setup

There are several different ways you can configure your router to connect to the Internet

- **D-Link Wi-Fi App** - Use your compatible iOS or Android device to install and configure your router. Refer to **D-Link Wi-Fi App Setup** on page **8**.
- **Hardware Setup** - This section explains how to setup your DIR-X3260. Refer to **Hardware Setup** on page **10**.
- **D-Link Setup Wizard** - This wizard will launch when you log into the router by using your PC for the first time. Refer to **Setup Wizard** on page **13**.
- **Manual Setup** - Log in to the router to manually configure your router. Refer to **Configuration** on page **20**

## D-Link Wi-Fi App Setup

The D-Link Wi-Fi app allows you to install and configure your DIR-X3260 from your compatible Android or iOS device.

**Note:** *The screenshots may be different depending on your mobile device's OS version. The following steps show the iOS interface of the D-Link Wi-Fi app. If you are using an Android device, the appearance may be different from that of the screenshots, but the process is the same.*

### Step 1

Search and install the free **D-Link Wi-Fi** app available on the App Store or on Google Play. You can also scan the QR code on the right, which will take you to the respective D-Link Wi-Fi app store page.



### Step 2


Launch the D-Link Wi-Fi app from the home screen of your device.



D-Link Wi-Fi


### Step 3

Tap on the **Install New Device** button at the middle of the screen.




## Step 4

Tap **Scan the QR code** to scan the setup QR code located on the Quick Installation Card and proceed to step 6. Alternatively, you can tap **Continue without scanning** to proceed to step 5.



## Step 5

Select **Router** and select **DIR-X3260** from the list of available devices. Tap **Next** to continue.




## Step 6

You will now be guided through a step-by-step process for setting up your router. Simply follow the on-screen instructions to continue the installation and the configuration process.

# Hardware Setup


## Step 1

Position your DIR-X3260 near your Internet-connected modem. Place it in an open area for better wireless coverage.




## Step 2

Turn off and unplug the power to your cable or DSL broadband modem. This is required. In some cases, you may need to turn it off for up to five minutes.




## Step 3

Use the Ethernet cable to connect your modem to the port labelled **INTERNET** on the router.




#### Step 4

Plug in and turn your modem back on and wait approximately one minute before proceeding.




#### Step 5

Connect the supplied power adapter to the router and a power outlet, press the power button, and wait approximately one minute until the LED indicator on the front of the device changes from orange to solid white.




#### Step 6

If you are configuring the router wirelessly from a PC, connect to the Wi-Fi network printed on the label attached to the bottom of your router or on the Quick Installation Card.



If you are configuring the router from a PC with a wired Ethernet connection, plug one end of an Ethernet cable into the port labeled 1 on the back of the router, and the other end into the Ethernet port on your computer.



### Step 7

If you are connecting to a broadband service that uses a dynamic connection (not PPPoE), you may be online already. Try opening a web browser and connecting to a website. If the website does not load, proceed to **Setup Wizard** on page 13.




# Setup Wizard

The setup wizard is designed to guide you through a step-by-step process to configure your new DIR-X3260 and connect to the Internet via a wireless setup process.

If this is your first time installing the router, open your web browser and enter **http://dlinkrouter.local/** in the address bar. Alternatively, enter the IP address of the router (default: **http://192.168.0.1**).


If this is your first time logging in to the page and no connection has been established, then log in with the password shown on the device label or Quick Install Guide.

Agree to the Terms of Use and Privacy Policy before proceeding.




Follow the on-screen instructions to configure your new D-Link router and connect to the Internet.

Click **Next** to continue.



Please wait while your router detects your Internet connection type.



If the router does not detect a valid Internet connection, a list of connection types to choose from will be displayed. Select your Internet connection type (this information can be obtained from your Internet Service Provider).

Click **Next** to continue.

### Configure Your Internet Connection

Please select your Internet connection type below:

- ☒ **DHCP Connection (Dynamic IP Address)**  
 Choose this option if your Internet connection automatically provides you with an IP Address. Most Cable Modems use this type of connection.
- ☐ **Username/Password Connection (PPPoE)**  
 Choose this option if your Internet connection requires a username and password to get online. Most DSL modems use this type of connection.
- ☐ **Static IP Address Connection**  
 Choose this option if your Internet Service Provider provided you with IP Address information that has to be manually configured.

Back
Next

If the router detected or you selected **PPPoE**, enter your PPPoE username and password. If you do not have this information, please contact your ISP.

Click **Next** to continue.

**Note:** *Make sure to remove all other existing PPPoE software from your computer. The software is no longer needed and will not work through a router.*

### PPPoE

To setup this Internet connection, you will need to have a User Name from your Internet Service Provider. If you do not have this information, please contact your ISP.

Username:

Password:

Back
Next

If the router detected or you selected **Static**, enter the IP and DNS settings supplied by your ISP. If you do not have this information, please contact your ISP.

Click **Next** to continue.

**Static IP**



Internet      DIR-X5460      Wi-Fi Client

To set up this connection you will need to have a complete list of IP information by your Internet Service Provider. If you have a Static IP connection and do not have this information, please contact your ISP.

IP Address:

Subnet Mask:

Gateway Address:

Primary DNS Address:

Secondary DNS Address:

Back Next

Type in a **Wi-Fi Network Name** and **Wi-Fi Password** to setup your Wi-Fi network. Your wireless clients will need to have this passphrase to be able to connect to your wireless network.

Click **Next** to continue.

**Note:** The router's Smart Connect feature presents a single wireless network. When connecting clients to an extension network, they will be automatically added to the best band, either 2.4 GHz or 5 GHz. To disable the Smart Connect feature and individually configure 2.4 GHz and 5 GHz networks, refer to **Wireless** on page **54**.

**Wi-Fi Settings**



Internet      DIR-X5460      Wi-Fi Client

To setup a Wi-Fi network you will need to give your Wi-Fi network a name(SSID) and password.

Wi-Fi Network Name:

Wi-Fi Password:

Back Next

In order to secure the router's configuration access, please enter a password. You will be prompted for this password every time you want to use the router's web configuration utility.

Click **Next** to continue.

### Device Admin Password



Internet      DIR-X5460      Wi-Fi Client

By default, your new D-Link device does not have a password configured for administrator access to the Web-based configuration utility. To secure your new device, please create a password below.

Device Admin Password:

[Back](#) [Next](#)

Select your time zone from the drop-down menu.

Click **Next** to continue.

### Time Zone



Internet      DIR-X5460      Wi-Fi Client

Some essential features require you to set a time zone to work properly. Please select your time zone from the drop-down menu.

Time Zone:

[Back](#) [Next](#)

Keeping your router's firmware up-to-date provides you with the latest protection and new features over the air. Choose whether to keep your device up-to-date automatically or to manage the device updates by yourself.

Click **Next** to continue.

Install Updates Automatically



Allow your device to automatically update to make sure you are always enjoying the latest features and improvements.

☒

Keep my device up to date automatically.

☐

I want to manage the device updates myself.

Back

Next

You will be presented with a summary of your settings.

Click **Next** to finalize the settings or **Back** to make changes.

Summary

  
Internet

  
DIR-X5460

  
Wi-Fi Client

Below is a summary of your Wi-Fi security and device password settings. Please note down your settings and click "Next".


|                        |                   |
|------------------------|-------------------|
| Connection Type:       | Dynamic IP (DHCP) |
| Wi-Fi Network Name:    | RouterName        |
| Wi-Fi Password:        | AStrongPassword   |
| Device Admin Password: | DevicePassword1   |

Back

Next

Please wait while the device settings are saved.

Do not turn off or unplug your router during this time.




Your new settings have been saved and your router is now configured.

Click **OK** to close the Setup Wizard.

Congratulations, your device has been successfully configured!

You can log in to the configuration utility by inputting the Admin Password.





# Configuration

To access the configuration utility, open your web-browser and enter **http://dlinkrouter.local./** or you may also connect by typing the IP address of the router (by default this is **http://192.168.0.1**) in the address bar.

Enter your password. If you previously followed the setup wizard, please use the admin password you entered during the wizard. Otherwise, log in with the password shown on the device label or Quick Install Guide.


**Note:** *If you cannot remember your password and cannot log in, use a paperclip to press the recessed **Reset** button on the back of the device for longer than 10 seconds to restore the router to its default settings.*



The router's home page will open displaying its current connection status.

The bar at the top of the page has quick access to **Settings**, **Features** and **Management** functions. You can quickly jump back Home at any time.


**Note:** *The system will automatically log out after a period of inactivity.*




# Home

The Home page displays the current status of the router in the form of an interactive diagram. You can click each icon to display information about each part of the network at the bottom of the screen. The menu bar at the top of the page will allow you to quickly navigate to other pages.

The Home page displays whether or not the router is currently connected to the Internet.



If it is disconnected, click **Click to repair** to bring up the setup wizard, refer to the **Setup Wizard** on page **13** for more information.



# Internet

To bring up more details about your Internet connection, click on the **Internet** icon.

Click **IPv4** or **IPv6** to see details of the IPv4 connection and IPv6 connection respectively.

Click **Release IP Address** to disconnect from the Internet. If you do this and wish to reconnect, click **Renew**.

To reconfigure the Internet settings, refer to **Internet - IPv4** on page 27




# DIR-X3260

Click on the **DIR-X3260** icon to view details about the router and its wireless settings.

Here you can see the router's current Wi-Fi network name and password, as well as the router's MAC address, IPv4 address, and IPv6 address.

To reconfigure the network settings, either click **Go to settings** on the lower left, or click **Settings** (at the top of the page) and then **Network** on the menu that appears. Refer to **Network** on page 61 for more information.

To reconfigure the wireless settings, either click **Go to settings**, on the lower right, or click **Settings** (at the top of the page) and then **Wireless** on the menu that appears. Refer to **Wireless** on page 54 for more information.



## Connected Clients

Click on the **Connected Clients** icon to view details about the connected clients to the router and their wireless settings.

On this page you can see all the clients currently connected to the router, and their IP addresses.

To edit each client's settings, click the pencil icon on the client you want to edit.



| Edit Rule                    |                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Name</b>                  | Enter a custom name for this client.                                                                                                                                                                                                                                                                                                                                                                                                            |
| <b>Vendor</b>                | Displays the vendor of the client.                                                                                                                                                                                                                                                                                                                                                                                                              |
| <b>MAC Address</b>           | Displays the MAC address of the client.                                                                                                                                                                                                                                                                                                                                                                                                         |
| <b>IP Address</b>            | Displays the current IP address of the client.                                                                                                                                                                                                                                                                                                                                                                                                  |
| <b>Reserve IP</b>            | Enable to reserve an IP address for the client.                                                                                                                                                                                                                                                                                                                                                                                                 |
| <b>IP Address (Reserved)</b> | Specify an IP address for the router's DHCP server to assign.                                                                                                                                                                                                                                                                                                                                                                                   |
| <b>Parental Control</b>      | Enable Parental Control for the client to specify whether it is allowed network access.                                                                                                                                                                                                                                                                                                                                                         |
| <b>Schedule</b>              | Use the drop-down menu to select the time schedule that the Parental Controls will be enabled for. The schedule may be set to Always OFF meaning that the client will always be blocked from accessing the network, or you can create your own schedules in the Schedules section to specify the times that the client is allowed to access the network. Refer to <b>Time &amp; Schedule - Schedule</b> on page <b>81</b> for more information. |

Click **Save** when you are done.

Edit Rule

Name:

08626PCWIN10

Vendor:

D-Link International

MAC Address:

c8:d3:a3:03:43:86

IP Address:

192.168.0.106

Reserve IP:

Enabled

Remaining: 24

IP Address (Reserved):

Parental Control:

Enabled

Schedule:


Always OFF

Save

# Settings Wizard

In the Settings menu on the bar at the top of the page, click **Wizard** to open the setup wizard. This is the same wizard that appears when you start the router for the first time. Refer to **Setup Wizard** on page **13** for details.

**Note:** *When the Wizard is opened, the router will disconnect from the internet.*



# Internet - IPv4

In the Settings menu on the bar at the top of the page, click **Internet** to see the Internet configuration options for the IPv4 connection details.

To configure the IPv6 Internet and network connection details, click the **IPv6** link. Refer to **Internet - IPv6** on page 37  
To configure the VLAN connection details, click the **VLAN** link. Refer to **Internet - VLAN** on page 52

Click **Save** at any time to save the changes you have made on this page.

**My Internet Connection is**

Choose your Internet connection type from the drop-down menu. You will be presented with the appropriate options for your connection type.

For **IPv4 - Dynamic IP (DHCP)** refer to page 28

For **IPv4 - Static IP** refer to page 29

For **IPv4 - PPPoE** refer to page 30

For **IPv4 - PPTP** refer to page 32

For **IPv4 - L2TP** refer to page 34

For **IPv4 - DS-Lite** refer to page 36



## IPv4 - Dynamic IP (DHCP)

Select **Dynamic IP (DHCP)** to obtain IP address information automatically from your Internet Service Provider (ISP). Select this option if your ISP does not specify an IP address to use. Click **Save** at any time to save the changes you have made on this page.

### Advanced Settings...

|                             |                                                                                                                                                                                                                           |
|-----------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Host Name</b>            | The host name is optional but may be required by some ISPs. Leave it blank if you are not sure.                                                                                                                           |
| <b>Primary DNS Server</b>   | Enter the primary DNS server IP address assigned by your ISP. This address is usually obtained automatically from your ISP.                                                                                               |
| <b>Secondary DNS Server</b> | Enter the secondary DNS server IP address assigned by your ISP. This address is usually obtained automatically from your ISP.                                                                                             |
| <b>MTU</b>                  | Maximum Transmission Unit - you may need to change the MTU for optimal performance with your ISP.                                                                                                                         |
| <b>MAC Address Clone</b>    | The default MAC address is set to the Internet port's physical interface MAC address on the router. You can use the drop-down menu to replace the Internet port's MAC address with the MAC address of a connected client. |

The screenshot shows the D-Link web interface for the DIR-XS460 router. The top navigation bar includes 'Home', 'Settings', 'Features', and 'Management'. The 'Settings' tab is active, and the breadcrumb trail is 'Settings >> Internet >> IPv4'. The 'Internet' section is titled 'Internet' and includes a globe icon and a note about configuring the Internet Connection type. Below this, there are tabs for 'VLAN', 'IPv6', and 'Save'. The 'My Internet Connection is:' dropdown menu is set to 'Dynamic IP (DHCP)'. To the right of this dropdown is a link for 'Advanced Settings...'. Below the dropdown, there are input fields for 'Host Name', 'Primary DNS Server', 'Secondary DNS Server', 'MTU' (set to 1500), and 'MAC Address Clone'. The 'MAC Address Clone' dropdown menu is set to '<< MAC Address'.

# IPv4 - Static IP

Select **Static IP** if your IP information is provided by your Internet Service Provider (ISP). Click **Save** at any time to save the changes you have made on this page.

- IP Address

Enter the IP address provided by your ISP.
- Subnet Mask

Enter the subnet mask provided by your ISP.
- Default Gateway

Enter the default gateway address provided by your ISP.
- Primary DNS Server

Enter the primary DNS server IP address assigned by your ISP.

D-Link

DIR-X5460 HW-A1 FW:1.00

Home

Settings

Features

Management

Internet

Use this section to configure your Internet Connection type. There are several connection types to choose. If you are unsure of your connection method, please contact your Internet Service Provider. Note: If using the PPPoE option, you will need to remove or disable any PPPoE client software on your computers.

Settings>>Internet>>IPv4

VLAN

IPv6

Save

My Internet Connection is:

Static IP

IP Address:

Subnet Mask:

Default Gateway:

Primary DNS Server:

Advanced Settings...

## Advanced Settings...

- Secondary DNS Server

Enter the secondary DNS server IP address assigned by your ISP.
- MTU

Maximum Transmission Unit - you may need to change the MTU for optimal performance with your ISP.
- MAC Address Clone

The default MAC address is set to the Internet port's physical interface MAC address on the router. You can use the drop-down menu to replace the Internet port's MAC address with the MAC address of a connected client.

Advanced Settings...

Secondary DNS Server:

MTU:

1500

MAC Address Clone:

<< MAC Address

COPYRIGHT © 2016 D-Link

# IPv4 - PPPoE

Select **PPPoE** if your ISP provides and requires you to enter a PPPoE username and password in order to connect to the Internet. Click **Save** at any time to save the changes you have made on this page.


- Username

Enter the username provided by your ISP.
- Password

Enter the password provided by your ISP.
- Reconnect Mode

Select either **Always on**, **On Demand**, or **Manual**.
- Maximum Idle Time


Configurable when **On Demand** is selected. Enter a maximum idle time during which the Internet connection is maintained during inactivity. To disable this feature, select **Always on** as the reconnect mode.



## Advanced Settings...

- Address Mode

Select **Static IP** if your ISP assigned you the IP address, subnet mask, gateway, and DNS server addresses. In most cases, select **Dynamic IP**.



| Advanced Settings... - Dynamic IP |                                                                                                                                                                                                                           |
|-----------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Address Mode                      | Shows your chosen address mode.                                                                                                                                                                                           |
| Service Name                      | Enter the ISP service name (optional)                                                                                                                                                                                     |
| Primary DNS Server                | Enter the primary DNS server IP address assigned by your ISP.                                                                                                                                                             |
| Secondary DNS Server              | Enter the secondary DNS server IP address assigned by your ISP.                                                                                                                                                           |
| MTU                               | Maximum Transmission Unit - you may need to change the MTU for optimal performance with your ISP.                                                                                                                         |
| MAC Address Clone                 | The default MAC address is set to the Internet port's physical interface MAC address on the router. You can use the drop-down menu to replace the Internet port's MAC address with the MAC address of a connected client. |

Advanced Settings...

Address Mode:

Dynamic IP

Service Name:

Primary DNS Server:

Secondary DNS Server:

MTU:

1492

MAC Address Clone:

<< MAC Address

| Advanced Settings... - Static IP |                                                                                                                                                                                                                           |
|----------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Address Mode                     | Displays your chosen address mode.                                                                                                                                                                                        |
| IP Address                       | Enter the IP address provided by your ISP.                                                                                                                                                                                |
| Service Name                     | Enter the ISP service name (optional)                                                                                                                                                                                     |
| Primary DNS Server               | Enter the primary DNS server IP address assigned by your ISP.                                                                                                                                                             |
| Secondary DNS Server             | Enter the secondary DNS server IP address assigned by your ISP.                                                                                                                                                           |
| MTU                              | Maximum Transmission Unit - you may need to change the MTU for optimal performance with your ISP.                                                                                                                         |
| MAC Address Clone                | The default MAC address is set to the Internet port's physical interface MAC address on the router. You can use the drop-down menu to replace the Internet port's MAC address with the MAC address of a connected client. |

Advanced Settings...

Address Mode:

Static IP

IP Address:

Service Name:

Primary DNS Server:

Secondary DNS Server:

MTU:

1492

MAC Address Clone:

<< MAC Address

# IPv4 - PPTP

Choose **PPTP** (Point-to-Point-Tunneling Protocol) if your Internet Service Provider (ISP) uses a PPTP connection. Your ISP will provide you with a username and password. Click **Save** at any time to save the changes you have made on this page.

**PPTP Server** Enter the PPTP server IP address provided by your ISP.

**Username** Enter the username provided by your ISP.

**Password** Enter the password provided by your ISP.

**Reconnect Mode** Select either **Always on**, **On Demand**, or **Manual**.

**Maximum Idle Time** Configurable when **On Demand** is selected. Enter a maximum idle time during which the Internet connection is maintained during inactivity. To disable this feature, select **Always on** as the reconnect mode.

The screenshot shows the 'Internet' configuration page of a D-Link router. The breadcrumb trail is 'Settings > Internet > IPv4'. There are tabs for 'VLAN', 'IPv6', and a 'Save' button. The 'My Internet Connection Is:' dropdown is set to 'PPTP'. Below this, there are input fields for 'PPTP Server:', 'Username:', and 'Password:'. The 'Reconnect Mode:' dropdown is set to 'Always on'. A link for 'Advanced Settings...' is at the bottom right.

## Advanced Settings...

**Address Mode** Select **Static IP** if your ISP assigned you the IP address, subnet mask, gateway, and DNS server addresses. In most cases, select **Dynamic IP**.

This screenshot shows the 'Advanced Settings...' section. It contains three dropdown menus: 'Address Mode:' set to 'Dynamic IP', 'Primary DNS Server:' set to 'Dynamic IP', and 'Secondary DNS Server:' set to 'Static IP'. A link for 'Advanced Settings...' is at the top right.

Advanced Settings... - Dynamic IP

Address Mode

Shows your chosen address mode.

Primary DNS Server

Enter the primary DNS server IP address assigned by your ISP.

Secondary DNS Server

Enter the secondary DNS server IP address assigned by your ISP.

MTU

Maximum Transmission Unit - you may need to change the MTU for optimal performance with your ISP.

Advanced Settings...

Address Mode:Dynamic IP

Primary DNS Server:

Secondary DNS Server:

MTU:1400

Advanced Settings... - Static IP

Address Mode

Displays your chosen address mode.

PPTP IP Address

Enter the IP address provided by your ISP.

PPTP Subnet Mask

Enter the subnet mask provided by your ISP.

PPTP Gateway IP Address

Enter the gateway IP address provided by your ISP.

Primary DNS Server

Enter the primary DNS server IP address assigned by your ISP.

Secondary DNS Server

Enter the secondary DNS server IP address assigned by your ISP.

MTU

Maximum Transmission Unit - you may need to change the MTU for optimal performance with your ISP.

Advanced Settings...

Address Mode:Static IP

PPTP IP Address:

PPTP Subnet Mask:

PPTP Gateway IP Address:

Primary DNS Server:

Secondary DNS Server:

MTU:1400

## IPv4 - L2TP

Choose **L2TP** (Layer 2 Tunneling Protocol) if your Internet Service Provider (ISP) uses a L2TP connection. Your ISP will provide you with a username and password. Click **Save** at any time to save the changes you have made on this page.

**L2TP Server** Enter the L2TP server IP address provided by your ISP.

**Username** Enter the username provided by your ISP.

**Password** Enter the password provided by your ISP.

**Reconnect Mode** Select either **Always on**, **On Demand**, or **Manual**.

**Maximum Idle Time** Configurable when **On Demand** is selected. Enter a maximum idle time during which the Internet connection is maintained during inactivity. To disable this feature, select **Always on** as the reconnect mode.

The screenshot shows the 'Internet' configuration page for a D-Link router. The breadcrumb trail is 'Settings > Internet > IPv4'. There are tabs for 'VLAN', 'IPv6', and a 'Save' button. The 'My Internet Connection is:' dropdown is set to 'L2TP'. Below this, there are input fields for 'L2TP Server:', 'Username:', and 'Password:'. The 'Reconnect Mode:' dropdown is set to 'On demand'. The 'Maximum Idle Time:' is set to '5 minutes'. An 'Advanced Settings...' link is at the bottom right.

### Advanced Settings...

**Address Mode** Select **Static IP** if your ISP assigned you the IP address, subnet mask, gateway, and DNS server addresses. In most cases, select **Dynamic IP**.

This screenshot shows the 'Advanced Settings...' section. It includes an 'Address Mode:' dropdown set to 'Dynamic IP'. Below it are fields for 'Primary DNS Server:' and 'Secondary DNS Server:', both of which have a dropdown menu showing 'Dynamic IP' and 'Static IP' options.

Advanced Settings... - Dynamic IP

Address Mode

Shows your chosen address mode.

Primary DNS Server

Enter the primary DNS server IP address assigned by your ISP.

Secondary DNS Server

Enter the secondary DNS server IP address assigned by your ISP.

MTU

Maximum Transmission Unit - you may need to change the MTU for optimal performance with your ISP.

Advanced Settings...

Address Mode:Dynamic IP

Primary DNS Server:

Secondary DNS Server:

MTU:1400

Advanced Settings... - Static IP

Address Mode

Shows your chosen address mode.

L2TP IP Address

Enter the IP address provided by your ISP.

L2TP Subnet Mask

Enter the subnet mask provided by your ISP.

L2TP Gateway IP Address

Enter the gateway IP address provided by your ISP.

Primary DNS Server

Enter the primary DNS server IP address assigned by your ISP.

Secondary DNS Server

Enter the secondary DNS server IP address assigned by your ISP.

MTU

Maximum Transmission Unit - you may need to change the MTU for optimal performance with your ISP.

Advanced Settings...

Address Mode:Static IP

L2TP IP Address:

L2TP Subnet Mask:

L2TP Gateway IP Address:

Primary DNS Server:

Secondary DNS Server:

MTU:1400

# IPv4 - DS-Lite

**DS-Lite** is an IPv6 connection type. After selecting DS-Lite, the following parameters will be available for configuration. Click **Save** at any time to save the changes you have made on this page.

## Advanced Settings...

**DS-Lite** Select **DS-Lite DHCPv6 Option** to let the router allocate the AFTR IPv6 address automatically. Select **Manual Configuration** to enter the AFTR IPv6 address manually.

## Advanced Settings... - DS-Lite DHCPv6 Option

- B4 IPv4 Address** Enter the B4 IPv4 address value used here.
- WAN IPv6 Address** Once connected, the WAN IPv6 address will be displayed here.
- IPv6 Default WAN Gateway** Once connected, the IPv6 WAN default gateway address will be displayed here.

## Advanced Settings... - Manual Configuration Option

- AFTR IPv6 Address** Enter the AFTR IPv6 address used here.
- B4 IPv4 Address** Enter the B4 IPv4 address value used here.
- WAN IPv6 Address** Once connected, the WAN IPv6 address will be displayed here.
- IPv6 WAN Default Gateway** Once connected, the IPv6 WAN default gateway address will be displayed here.

D-Link  
DIR-X3460 HW:V1 FW:1.00

Home | Settings | Features | Management

Internet

Use this section to configure your Internet Connection type. There are several connection types to choose. If you are unsure of your connection method, please contact your Internet Service Provider. Note: If using the PPPoE option, you will need to remove or disable any PPPoE client software on your computers.

Settings>>Internet>>IPv4

VLAN

IPv6

Save

My Internet Connection is: DS-Lite

Advanced Settings...

DS-Lite Configuration: DS-Lite DHCPv6 Option

B4 IPv4 Address: DS-Lite DHCPv6 Option

WAN IPv6 Address: Manual Configuration

IPv6 WAN Default Gateway: Not Available

Advanced Settings...

DS-Lite Configuration: DS-Lite DHCPv6 Option

B4 IPv4 Address: 192.0.0.

WAN IPv6 Address: Not Available

IPv6 WAN Default Gateway: Not Available

Advanced Settings...

DS-Lite Configuration: Manual Configuration

AFTR IPv6 Address:

B4 IPv4 Address: 192.0.0.

WAN IPv6 Address: Not Available

IPv6 WAN Default Gateway: Not Available

# Internet - IPv6

In the Settings menu on the bar at the top of the page, click **Internet** to see the Internet configuration options for the IPv4 connection details, then click the **IPv6** link to access the configuration options for the IPv6 connection details.

To configure the IPv4 Internet and network connection details, click the **IPv4** link. Refer to **Internet - IPv4** on page 27  
To configure the VLAN connection details, click the **VLAN** link. Refer to **Internet - VLAN** on page 52

Click **Save** at any time to save the changes you have made on this page.

**My Internet Connection is**

Choose your Internet connection type from the drop-down menu. You will be presented with the appropriate options for your connection type.

For **IPv6 - Auto Detection** refer to page 38


For **IPv6 - Static IPv6** refer to page 40

For **IPv6 - Auto Configuration (SLAAC/DHCPv6)** refer to page 42

For **IPv6 - PPPoE** refer to page 45


For **IPv6 - 6rd** refer to page 49

For **IPv6 - Local Connectivity Only** refer to page 51



# IPv6 - Auto Detection

Select **Auto Detection** to automatically detect the IPv6 connection method used by your Internet Service Provider (ISP). If Auto Detection fails, you can manually select another IPv6 connection type. Click **Save** at any time to save the changes you have made on this page.





### IPv6 DNS Settings

**DNS Type** Select either **Obtain DNS server address automatically** or **Use the following DNS address**.

**Primary DNS Server** If you selected **Use the following DNS address**, enter the primary DNS server address.

**Secondary DNS Server** If you selected **Use the following DNS address**, enter the secondary DNS server address.



### LAN IPv6 Address Settings


**Enable DHCP-PD** Enable or disable DHCP Prefix Delegation.

**LAN IPv6 Link-Local Address** Displays the router's LAN link-local address.

*If **Enable DHCP-PD** is disabled, these additional parameters are available for configuration:*

**LAN IPv6 Address** Enter a valid LAN IPv6 address.

**LAN IPv6 Link-Local Address** Displays the router's LAN link-local address.



Advanced Settings... - Address Autoconfiguration Settings

- Enable Automatic IPv6 Address Assignment

Enable or disable the Automatic IPv6 Address Assignment feature.
- Enable Automatic DHCP-PD in LAN

Enable or disable DHCP-PD for other IPv6 routers connected to the LAN interface.
- Autoconfiguration Type

Select **SLAAC+RDNSS**, **SLAAC+Stateless DHCP**, or **Stateful DHCPv6**.

If you selected **SLAAC+RDNSS** or **SLAAC+Stateless DHCP** as the Autoconfiguration Type:

- Router Advertisement Lifetime

Enter the router advertisement lifetime (in minutes).

If you selected **Stateful DHCPv6** as the Autoconfiguration Type:

- IPv6 Address Range (Start)

Enter the starting IPv6 address for the DHCP server's IPv6 assignment.
- IPv6 Address Range (End)

Enter the ending IPv6 address for the DHCP server's IPv6 assignment.

Advanced Settings...

ADDRESS AUTOCONFIGURATION SETTINGS

Enable Automatic IPv6 Address Assignment: Enabled

Enable Automatic DHCP-PD in LAN: Enabled

Autoconfiguration Type: SLAAC+Stateless DHCP

Router Advertisement Lifetime: 60 minutes

Advanced Settings...

ADDRESS AUTOCONFIGURATION SETTINGS

Enable Automatic IPv6 Address Assignment: Enabled

Enable Automatic DHCP-PD in LAN: Enabled

Autoconfiguration Type: SLAAC+RDNSS

Router Advertisement Lifetime: 60 minutes

Advanced Settings...

ADDRESS AUTOCONFIGURATION SETTINGS

Enable Automatic IPv6 Address Assignment: Enabled

Enable Automatic DHCP-PD in LAN: Enabled

Autoconfiguration Type: Stateful DHCPv6

IPv6 Address Range (Start): 1

IPv6 Address Range (End): 99

# IPv6 - Static IPv6

Select **Static IP** if your IPv6 information is provided by your Internet Service Provider (ISP). Click **Save** at any time to save the changes you have made on this page.

- Use Link-Local Address

Enable or disable link-local address use.
- IPv6 Address

Configurable when **Use Link-Local Address** is disabled. Enter the address supplied by your ISP.
- Subnet Prefix Length

Configurable when **Use Link-Local Address** is disabled. Enter the subnet prefix length supplied by your ISP.
- Default Gateway

Enter the default gateway for your IPv6 connection.
- Primary DNS Server

Enter the primary DNS server address.
- Secondary DNS Server

Enter the secondary DNS server address.

## LAN IPv6 Address Settings

- LAN IPv6 Address

Enter the LAN (local) IPv6 address for the router.
- LAN IPv6 Link-Local Address

Displays the router's LAN link-local address.

D-Link  
DIR-X5460 HW:V1 FW:1.00

Home | Settings | Features | Management

IPv6

All of your IPv6 Internet and network connection details are displayed on this page.

Settings>>Internet>>IPv6

VLAN | IPv4 | Save

My Internet Connection is: Static IPv6

Use Link-Local Address: Disabled

IPv6 Address:

Subnet Prefix Length:

Default Gateway:

Primary DNS Server:

Secondary DNS Server:

LAN IPv6 ADDRESS SETTINGS

LAN IPv6 Address: /64

LAN IPv6 Link-Local Address: FE80::5263:4CFF:FE72:50

Advanced Settings...

Advanced Settings... - Address Autoconfiguration Settings

- Enable Automatic IPv6 Address Assignment

Autoconfiguration Type
- Enable or disable the Automatic IPv6 Address Assignment feature.

Select **SLAAC+RDNSS**, **SLAAC+Stateless DHCP**, or **Stateful DHCPv6**.

If you selected **SLAAC+RDNSS** or **SLAAC+Stateless DHCP** as the Autoconfiguration Type:

- Router Advertisement Lifetime

Enter the router advertisement lifetime (in minutes).

If you selected **Stateful DHCPv6** as the Autoconfiguration Type:

- IPv6 Address Range (Start)

IPv6 Address Range (End)

IPv6 Address Lifetime
- Enter the starting IPv6 address for the DHCP server's IPv6 assignment.

Enter the ending IPv6 address for the DHCP server's IPv6 assignment.

Enter the IPv6 address lifetime (in minutes).

Advanced Settings...

ADDRESS AUTOCONFIGURATION SETTINGS

Enable Automatic IPv6 Address Assignment: 

Enabled

Autoconfiguration Type: 

SLAAC+Stateless DHCP

Router Advertisement Lifetime: 

30

 minutes

Advanced Settings...

ADDRESS AUTOCONFIGURATION SETTINGS

Enable Automatic IPv6 Address Assignment: 

Enabled

Autoconfiguration Type: 

SLAAC+RDNSS

Router Advertisement Lifetime: 

30

 minutes

Advanced Settings...

ADDRESS AUTOCONFIGURATION SETTINGS

Enable Automatic IPv6 Address Assignment: 

Enabled

Autoconfiguration Type: 

Stateful DHCPv6

IPv6 Address Range (Start): 

fff::00

IPv6 Address Range (End): 

fff::00


IPv6 Address Lifetime: 

10080



 minutes

# IPv6 - Auto Configuration (SLAAC/DHCPv6)

Select **Auto Configuration** if your ISP assigns your IPv6 address when your router requests one from the ISP’s server. Some ISPs require you to adjust settings on your side before your router can connect to the IPv6 Internet. Click **Save** at any time to save the changes you have made on this page.



| IPv6 DNS Settings    |                                                                                                        |
|----------------------|--------------------------------------------------------------------------------------------------------|
| DNS Type             | Select either <b>Obtain DNS server address automatically</b> or <b>Use the following DNS address</b> . |
| Primary DNS Server   | If you selected <b>Use the following DNS address</b> , enter the primary DNS server address.           |
| Secondary DNS Server | If you selected <b>Use the following DNS address</b> , enter the secondary DNS server address.         |



| LAN IPv6 Address Settings                                                                          |                                               |
|----------------------------------------------------------------------------------------------------|-----------------------------------------------|
| Enable DHCP-PD                                                                                     | Enable or disable prefix delegation services. |
| LAN IPv6 Link-Local Address                                                                        | Displays the router’s LAN link-local address. |
| If <b>Enable DHCP-PD</b> is disabled, these additional parameters are available for configuration: |                                               |
| LAN IPv6 Address                                                                                   | Enter a valid LAN IPv6 address.               |
| LAN IPv6 Link-Local Address                                                                        | Displays the router’s LAN link-local address. |



Advanced Settings... - Address Autoconfiguration Settings

**Enable Automatic IPv6 Address Assignment** Enable or disable the Automatic IPv6 Address Assignment feature.

If **Enable DHCP-PD** is enabled in the previous LAN IPv6 Address Settings:

**Enable Automatic DHCP-PD in LAN** Enable or disable DHCP-PD for other IPv6 routers connected to the LAN interface.

**Autoconfiguration Type** Select **SLAAC+RDNSS**, **SLAAC+Stateless DHCP**, or **Stateful DHCPv6**.

If you selected **SLAAC+RDNSS** or **SLAAC+Stateless DHCP** as the Autoconfiguration Type:

**Router Advertisement Lifetime** Enter the router advertisement lifetime (in minutes).

If you selected **Stateful DHCPv6** as the Autoconfiguration Type:

**IPv6 Address Range (Start)** Enter the starting IPv6 address for the DHCP server's IPv6 assignment.

**IPv6 Address Range (End)** Enter the ending IPv6 address for the DHCP server's IPv6 assignment.

Advanced Settings...

ADDRESS AUTOCONFIGURATION SETTINGS

Enable Automatic IPv6 Address Assignment: ☒ Enabled

Enable Automatic DHCP-PD in LAN: ☒ Enabled

Autoconfiguration Type: SLAAC+Stateless DHCP

Router Advertisement Lifetime: 30 minutes

Advanced Settings...

ADDRESS AUTOCONFIGURATION SETTINGS

Enable Automatic IPv6 Address Assignment: ☒ Enabled

Enable Automatic DHCP-PD in LAN: ☒ Enabled

Autoconfiguration Type: SLAAC+RDNSS

Router Advertisement Lifetime: 30 minutes

Advanced Settings...

ADDRESS AUTOCONFIGURATION SETTINGS

Enable Automatic IPv6 Address Assignment: ☒ Enabled

Enable Automatic DHCP-PD in LAN: ☒ Enabled

Autoconfiguration Type: Stateful DHCPv6

IPv6 Address Range (Start): ::::: 00

IPv6 Address Range (End): ::::: 00

Advanced Settings... - Address Autoconfiguration Settings

**Enable Automatic IPv6 Address Assignment** Enable or disable the Automatic IPv6 Address Assignment feature.

If **Enable DHCP-PD** is disabled in the previous LAN IPv6 Address Settings:

**Autoconfiguration Type** Select **SLAAC+RDNSS**, **SLAAC+Stateless DHCP**, or **Stateful DHCPv6**.

If you selected **SLAAC+RDNSS** or **SLAAC+Stateless DHCP** as the Autoconfiguration Type:

**Router Advertisement Lifetime** Enter the router advertisement lifetime (in minutes).

If you selected **Stateful DHCPv6** as the Autoconfiguration Type:

**IPv6 Address Range (Start)** Enter the starting IPv6 address for the DHCP server's IPv6 assignment.

**IPv6 Address Range (End)** Enter the ending IPv6 address for the DHCP server's IPv6 assignment.

**IPv6 Address Lifetime** Enter the IPv6 address lifetime (in minutes).

Advanced Settings...

ADDRESS AUTOCONFIGURATION SETTINGS

Enable Automatic IPv6 Address Assignment: ☒ Enabled

Autoconfiguration Type: SLAAC+Stateless DHCP

Router Advertisement Lifetime: 30 minutes

Advanced Settings...

ADDRESS AUTOCONFIGURATION SETTINGS

Enable Automatic IPv6 Address Assignment: ☒ Enabled

Autoconfiguration Type: SLAAC+RDNSS

Router Advertisement Lifetime: 30 minutes

Advanced Settings...

ADDRESS AUTOCONFIGURATION SETTINGS

Enable Automatic IPv6 Address Assignment: ☒ Enabled

Autoconfiguration Type: Stateful DHCPv6

IPv6 Address Range (Start): ff::00

IPv6 Address Range (End): ff::00

IPv6 Address Lifetime: 10080 minutes

## IPv6 - PPPoE

Select **PPPoE** if your ISP provides and requires you to enter a PPPoE username and password in order to connect to the Internet. Click **Save** at any time to save the changes you have made on this page.

- PPPoE Session** Create a new PPPoE session.
- Username** Enter the username provided by your ISP.
- Password** Enter the password provided by your ISP.
- Address Mode** Select either **Dynamic IP** or **Static IP**.
- IP Address** Configurable if Static IP is chosen. Enter the IP address provided by your ISP.
- Service Name** Enter the ISP service name (optional).
- Reconnect Mode** Select either **Always On** or **Manual**.
- MTU** Maximum Transmission Unit - you may need to change the MTU for optimal performance with your ISP.

The screenshot shows the D-Link web interface for the DIR-X5460 router. The top navigation bar includes 'Home', 'Settings', 'Features', and 'Management'. The main heading is 'IPv6' with a sub-note: 'All of your IPv6 Internet and network connection details are displayed on this page.' Below this, there's a breadcrumb trail: 'Settings > Internet > IPv6'. There are tabs for 'VLAN' and 'IPv4', and a 'Save' button. The configuration fields are as follows:

- My Internet Connection is: **PPPoE** (dropdown)
- PPPoE Session: **Create a new session** (dropdown)
- Username:
- Password:
- Address Mode: **Dynamic IP** (dropdown)
- Service Name:
- Reconnect Mode: **Always on** (dropdown)
- MTU:  bytes

| IPv6 DNS Settings    |                                                                                                        |
|----------------------|--------------------------------------------------------------------------------------------------------|
| DNS Type             | Select either <b>Obtain DNS server address automatically</b> or <b>Use the following DNS address</b> . |
| Primary DNS Server   | If you selected <b>Use the following DNS address</b> , enter the primary DNS server address.           |
| Secondary DNS Server | If you selected <b>Use the following DNS address</b> , enter the secondary DNS server address.         |

IPv6 DNS SETTINGS

DNS Type: Obtain a DNS server address automatically

IPv6 DNS SETTINGS

DNS Type: Use the following DNS address

Primary DNS Server:

Secondary DNS Server:

| LAN IPv6 Address Settings                                                                          |                                               |
|----------------------------------------------------------------------------------------------------|-----------------------------------------------|
| Enable DHCP-PD                                                                                     | Enable or disable prefix delegation services. |
| LAN IPv6 Link-Local Address                                                                        | Displays the router's LAN link-local address. |
| If <b>Enable DHCP-PD</b> is disabled, these additional parameters are available for configuration: |                                               |
| LAN IPv6 Address                                                                                   | Enter a valid LAN IPv6 address.               |
| LAN IPv6 Link-Local Address                                                                        | Displays the router's LAN link-local address. |

LAN IPv6 ADDRESS SETTINGS

Enable DHCP-PD: Enabled

LAN IPv6 Link-Local Address: FE80::EB6:D2FF:FE93:7CD8

Advanced Settings...

LAN IPv6 ADDRESS SETTINGS

Enable DHCP-PD: Disabled

LAN IPv6 Address: /64

LAN IPv6 Link-Local Address: FE80::EB6:D2FF:FE93:7CD8

Advanced Settings...

Advanced Settings... - Address Autoconfiguration Settings

**Enable Automatic IPv6 Address Assignment** Enable or disable the Automatic IPv6 Address Assignment feature.

If **Enable DHCP-PD** is enabled in the previous LAN IPv6 Address Settings:

**Enable Automatic DHCP-PD in LAN** Enable or disable DHCP-PD for other IPv6 routers connected to the LAN interface.

**Autoconfiguration Type** Select **SLAAC+RDNSS**, **SLAAC+Stateless DHCP**, or **Stateful DHCPv6**.

If you selected **SLAAC+RDNSS** or **SLAAC+Stateless DHCP** as the Autoconfiguration Type:

**Router Advertisement Lifetime** Enter the router advertisement lifetime (in minutes).

If you selected **Stateful DHCPv6** as the Autoconfiguration Type:

**IPv6 Address Range (Start)** Enter the starting IPv6 address for the DHCP server's IPv6 assignment.

**IPv6 Address Range (End)** Enter the ending IPv6 address for the DHCP server's IPv6 assignment.

Advanced Settings...

ADDRESS AUTOCONFIGURATION SETTINGS

Enable Automatic IPv6 Address Assignment: ☒ Enabled

Enable Automatic DHCP-PD in LAN: ☒ Enabled

Autoconfiguration Type: SLAAC+Stateless DHCP

Router Advertisement Lifetime: 30 minutes

Advanced Settings...

ADDRESS AUTOCONFIGURATION SETTINGS

Enable Automatic IPv6 Address Assignment: ☒ Enabled

Enable Automatic DHCP-PD in LAN: ☒ Enabled

Autoconfiguration Type: SLAAC+RDNSS

Router Advertisement Lifetime: 30 minutes

Advanced Settings...

ADDRESS AUTOCONFIGURATION SETTINGS

Enable Automatic IPv6 Address Assignment: ☒ Enabled

Enable Automatic DHCP-PD in LAN: ☒ Enabled

Autoconfiguration Type: Stateful DHCPv6

IPv6 Address Range (Start): ::::: 00

IPv6 Address Range (End): ::::: 00

Advanced Settings... - Address Autoconfiguration Settings

- Enable Automatic IPv6 Address Assignment

Enable or disable the Automatic IPv6 Address Assignment feature.
- If **Enable DHCP-PD** is disabled in the previous LAN IPv6 Address Settings:

Autoconfiguration Type

Select **SLAAC+RDNSS**, **SLAAC+Stateless DHCP**, or **Stateful DHCPv6**.
- If you selected **SLAAC+RDNSS** or **SLAAC+Stateless DHCP** as the Autoconfiguration Type:

Router Advertisement Lifetime

Enter the router advertisement lifetime (in minutes).
- If you selected **Stateful DHCPv6** as the Autoconfiguration Type:

IPv6 Address Range (Start)

Enter the starting IPv6 address for the DHCP server's IPv6 assignment.

IPv6 Address Range (End)

Enter the ending IPv6 address for the DHCP server's IPv6 assignment.

IPv6 Address Lifetime

Enter the IPv6 address lifetime (in minutes).

Advanced Settings...

ADDRESS AUTOCONFIGURATION SETTINGS

Enable Automatic IPv6 Address Assignment: ☒ Enabled

Autoconfiguration Type: SLAAC+Stateless DHCP

Router Advertisement Lifetime: 30 minutes

Advanced Settings...

ADDRESS AUTOCONFIGURATION SETTINGS

Enable Automatic IPv6 Address Assignment: ☒ Enabled

Autoconfiguration Type: SLAAC+RDNSS

Router Advertisement Lifetime: 30 minutes

Advanced Settings...

ADDRESS AUTOCONFIGURATION SETTINGS

Enable Automatic IPv6 Address Assignment: ☒ Enabled

Autoconfiguration Type: Stateful DHCPv6

IPv6 Address Range (Start): ffff:00

IPv6 Address Range (End): ffff:00

IPv6 Address Lifetime: 10080 minutes

# IPv6 - 6rd

In this section the user can configure the IPv6 **6rd** connection settings. Click **Save** at any time to save the changes you have made on this page.

- Assign IPv6 Prefix

Currently unsupported.
- Primary DNS Server

Enter the primary DNS server address.
- Secondary DNS Server

Enter the secondary DNS server address.
- 6rd Manual Configuration

Enable Hub and Spoke Mode

Enable this option if you want to minimize the number of routes to the destination by using a hub and spoke method of networking.

6rd Configuration

Choose the **6rd DHCPv4 Option** to automatically discover and populate the data values, or **Manual Configuration** to enter the settings yourself.

If you selected **Manual Configuration** as the 6rd Configuration:

6rd IPv6 Prefix

Enter the 6rd IPv6 prefix and mask length supplied by your ISP.

WAN IPv4 Address

Displays the router's IPv4 address.

6rd Border Relay IPv4 Address

Enter the 6rd border relay IPv4 address settings supplied by your ISP.
- 
- 
- 
- D-Link DIR-X3260 User Manual
- 49


LAN IPv6 Address Settings

|                             |                                                            |
|-----------------------------|------------------------------------------------------------|
| LAN IPv6 Address            | Displays the router’s LAN IPv6 Address link-local address. |
| LAN IPv6 Link-Local Address | Displays the router’s LAN link-local address.              |




Advanced Settings... - Address Autoconfiguration Settings

|                                          |                                                                                       |
|------------------------------------------|---------------------------------------------------------------------------------------|
| Enable Automatic IPv6 Address Assignment | Enable or disable the Automatic IPv6 Address Assignment feature.                      |
| Autoconfiguration Type                   | Select <b>SLAAC+RDNSS</b> , <b>SLAAC+Stateless DHCP</b> , or <b>Stateful DHCPv6</b> . |




If you selected **SLAAC+RDNSS** or **SLAAC+Stateless DHCP** as the Autoconfiguration Type:

|                               |                                                       |
|-------------------------------|-------------------------------------------------------|
| Router Advertisement Lifetime | Enter the router advertisement lifetime (in minutes). |
|-------------------------------|-------------------------------------------------------|



If you selected **Stateful DHCPv6** as the Autoconfiguration Type:

|                            |                                                                        |
|----------------------------|------------------------------------------------------------------------|
| IPv6 Address Range (Start) | Enter the starting IPv6 address for the DHCP server’s IPv6 assignment. |
| IPv6 Address Range (End)   | Enter the ending IPv6 address for the DHCP server’s IPv6 assignment.   |
| IPv6 Address Lifetime      | Enter the IPv6 address lifetime (in minutes).                          |




# IPv6 - Local Connectivity Only

**Local Connectivity Only** allows you to set up an IPv6 connection that will not connect to the Internet. Click **Save** at any time to save the changes you have made on this page.




## Advanced Settings... - IPv6 ULA Settings

- Enable ULA** Click here to enable Unique Local IPv6 Unicast Addresses settings.
- Use Default ULA Prefix** Enable this option to use the default ULA prefix.
- ULA Prefix** Configurable if you disable Use Default ULA Prefix. Enter your own ULA prefix.



## Advanced Settings... - Current IPv6 ULA Settings

- Current ULA Prefix** Displays the current ULA prefix.
- LAN IPv6 ULA** Displays the LAN's IPv6 ULA.



## Internet - VLAN

In the Settings menu on the bar at the top of the page, click **Internet** to see the Internet configuration options for the IPv4 connection details, then click the **VLAN** link to access the configuration options for the VLAN connection details.


VLAN allows for services such as Triple-Play to be used, and divides a network into segments that can only be accessed by other devices in the same VLAN.

To configure the IPv4 Internet and network connection details, click the **IPv4** link. Refer to **Internet - IPv4** on page 27

To configure the IPv6 Internet and network connection details, click the **IPv6** link. Refer to **Internet - IPv6** on page 37

Click **Save** at any time to save the changes you have made on this page.

**Status** Click to enable or disable the Triple-Play VLAN feature. More configuration options will be available if the Status is enabled.



If Triple-Play Status is **Enabled**:

**Priority ID** Enable or disable traffic priority ID for the Internet, IPTV, and VoIP VLANs. If Priority ID is enabled, Priority ID options are available for configuration. Select a priority ID from the drop-down menus to assign to the corresponding VLAN. Higher priority ID traffic takes precedence over traffic with a low priority ID tag.

**VLAN TAG** Enable VLAN TAG to enter VLAN ID, as provided by your ISP


**Internet VLAN ID** Enter the VLAN ID for your Internet connection, as provided by your ISP.

**IPTV VLAN ID** Enter the VLAN ID for your IPTV service, as provided by your ISP.

**VOIP VLAN ID** Enter the VLAN ID for your VoIP network, as provided by your ISP.

Interface Traffic Type Setting

**LAN Port 1-4** From the drop-down menu, you can select the type of connection (Internet, IPTV, or Voice over IP) coming from the WAN connection to each interface on the router.



# Wireless

In the Settings menu on the bar at the top of the page, click **Wireless** to see your wireless network settings for your DIR-X3260.

Click **Save** at any time to save the changes you have made on this page.

Smart Connect

Status

Enable or disable the Smart Connect Feature. When enabled, only a few configuration options are available to simplify configuration.

If Smart Connect is Status is **Enabled**:

Wireless

Wi-Fi Name (SSID)

Create a name for your wireless network using up to 32 characters.

Password

Create a password to use for wireless security. Wireless clients will need to enter this password to successfully connect to the network.

Smart Connect

Status: 

Enabled

Wireless

Wi-Fi Name (SSID): RouterName

Password: AStrongPassword

[Advanced Settings](#)

Wireless - Advanced Settings...

- Security Mode

Choose **None** or **WPA/WPA2-Personal** (recommended).
- DFS Channel

DFS enables you to use more channels to help find one with the least interference. However, please note that when using DFS, the router must scan for radar signals for a minute before using a channel, and will change channels automatically if radar signals are detected.
- Transmission Power

Select the desired wireless transmission power.
- Schedule

Use the drop-down menu to select the time schedule that the rule will be enabled for. The schedule may be set to Always Enable, or you can create your own schedules in the Schedules section. Refer to **Time & Schedule - Schedule** on page **81** for more information.

Security Mode:

WPA/WPA2-Personal

DFS Channel:

Disabled

Transmission Power:

High

Schedule:

Always Enable

+

Smart Connect

**Status** Enable or disable the Smart Connect Feature. When disabled, 2.4GHz and 5GHz configuration options become available.

If Smart Connect is Status is **Disabled**:

2.4GHz / 5GHz

**Status** Enable or disable the 2.4GHz / 5GHz wireless network.

**Wi-Fi Name (SSID)** Create a name for your wireless network using up to 32 characters.

**Password** Create a password to use for wireless security. Wireless clients will need to enter this password to successfully connect to the network.

Smart Connect

Status: 

Disabled

2.4GHz

Status: 

Enabled

Wi-Fi Name (SSID): 

RouterName

Password: 

AStrongPassword

5GHz

Status: 

Enabled

Wi-Fi Name (SSID): 

RouterName

Password: 

AStrongPassword

2.4GHz - Advanced Settings...

- Security Mode

Choose **None** or **WPA/WPA2-Personal** (recommended).
- 802.11 Mode (2.4GHz)

Select the desired wireless networking standards to use. The available options for the 2.4 GHz wireless network are **Mixed 802.11b/g/n**, **Mixed 802.11g/n**, or **802.11n only**.
- Wi-Fi Channel

Select the desired channel. The default is **Auto** (recommended).
- Transmission Power

Select the desired wireless transmission power.
- Channel Width (2.4GHz)

Select **Auto 20/40** if you are using both 802.11n and non-802.11n devices, or select **20 MHz** if you are not using any 802.11n devices.
- HT20/40 Coexistence (2.4GHz)

Enable or disable HT20/40 Coexistence.
- Visibility Status

The default setting is **Visible**. Select **Invisible** if you do not want to broadcast the SSID of your wireless network.
- Schedule

Use the drop-down menu to select the time schedule that the rule will be enabled for. The schedule may be set to **Always Enable**, or you can create your own schedules in the **Schedules** section. Refer to **Time & Schedule - Schedule** on page **81** for more information.

2.4GHz

Status: Enabled

Wi-Fi Name (SSID): RouterName

Password: AStrongPassword

Advanced Settings...

Security Mode: WPA/WPA2-Personal

802.11 Mode: Mixed 802.11b/g/n

Wi-Fi Channel: Auto

Transmission Power: High

Channel Width: Auto 20/40 MHz

HT20/40 Coexistence: Enabled

Visibility Status: Visible

Schedule: Always Enable

5GHz - Advanced Settings...

- Security Mode

Choose **None** or **WPA/WPA2-Personal** (recommended).
- 802.11 Mode (5GHz)

Select the desired wireless networking standards to use.  
The available options for the 5 GHz wireless network are **Mixed 802.11a/n/ac/ax**, **Mixed 802.11a/n/ac**, **Mixed 802.11n/ac**, **Mixed 802.11a/n**, **802.11ac only**, **Mixed 802.11a only**, or **802.11n only**.
- Wi-Fi Channel

Select the desired channel. The default is **Auto** (recommended).
- DFS Channel

DFS enables you to use more channels to help find one with the least interference. However, please note that when using DFS, the router must scan for radar signals for a minute before using a channel, and will change channels automatically if radar signals are detected.
- Transmission Power

Select the desired wireless transmission power.
- Channel Width (5GHz)

Select **Auto 20/40/80** if you are using 802.11ac, 802.11n, and 802.11a devices, select **Auto 20/40** if you are using 802.11n and 802.11a devices, or select **20 MHz** if you are using 802.11a devices.
- Visibility Status

The default setting is **Visible**. Select **Invisible** if you do not want to broadcast the SSID of your wireless network.
- Schedule

Use the drop-down menu to select the time schedule that the rule will be enabled for. The schedule may be set to **Always Enable**, or you can create your own schedules in the **Schedules** section. Refer to **Time & Schedule - Schedule** on page **81** for more information.

5GHz

Status: 

Enabled

Wi-Fi Name (SSID): 

RouterName

Password: 

AStrongPassword

Advanced Settings...

Security Mode: 

WPA/WPA2-Personal

802.11 Mode: 

Mixed 802.11a/n/ac/ax

Wi-Fi Channel: 

Auto

DFS Channel: 

Disabled

Transmission Power: 

High

Channel Width: 

Auto 20/40/80 MHz

Visibility Status: 

Visible

Schedule: 

Always Enable

Wi-Fi Protected Setup

The easiest way to connect your wireless devices to the router is with Wi-Fi Protected Setup (WPS).

**WPS-PBC Status**    Enable or disable WPS-PBC (Push Button Configuration) functionality.



# Guest Zone

In the Settings menu on the bar at the top of the page, click **Wireless** to see your wireless network settings for your DIR-X3260. Then click the link to **Guest Zone** to configure your guest zone settings.


The **Guest Zone** feature will allow you to create temporary zones that can be used by guests to access the Internet. These zones will be separate from your main wireless network. You may configure different zones for the 2.4 GHz and 5 GHz wireless bands.

Click **Save** at any time to save the changes you have made on this page.

If Smart Connect is Status is **Enabled** in the previous Wireless settings:

| Wireless             |                                                                                                                                                                                                                                                                                               |
|----------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Status               | Enable or disable the Guest Zone feature. The status is disabled by default.                                                                                                                                                                                                                  |
| Wireless Name (SSID) | Create a name for your wireless network using up to 32 characters.                                                                                                                                                                                                                            |
| Password             | Create a password to use for wireless security.                                                                                                                                                                                                                                               |
| Schedule             | Use the drop-down menu to select the time schedule that the rule will be enabled for. The schedule may be set to <b>Always Enable</b> , or you can create your own schedules in the <b>Schedules</b> section. Refer to <b>Time &amp; Schedule - Schedule</b> on page 81 for more information. |

| Home Network Access  |                                                                                                                               |
|----------------------|-------------------------------------------------------------------------------------------------------------------------------|
| Internet Access Only | Enabling this option will confine connectivity to the Internet, preventing guests from accessing other local network devices. |




# Network

In the Settings menu on the bar at the top of the page, click **Network** to change the local network settings of the router and to configure the DHCP settings.

Click **Save** at any time to save the changes you have made on this page.

| Network Settings  |                                                                                                                                                                                                                                                     |
|-------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| LAN IP Address    | Enter the IP address of the router. The default IP address is <b>192.168.0.1</b> . If you change the IP address, once you click <b>Save</b> , you will need to enter the new IP address in your browser to get back into the configuration utility. |
| Subnet Mask       | Enter the subnet mask of the router. The default subnet mask is <b>255.255.255.0</b> .                                                                                                                                                              |
| Management Link   | The default address to access the router’s configuration is <b>http://dlinkrouter.local/</b> . You can replace <b>dlinkrouter</b> with a name of your choice.                                                                                       |
| Local Domain Name | Enter the domain name (optional).                                                                                                                                                                                                                   |
| Enable DNS Relay  | Disable to transfer the DNS server information from your ISP to your computers. If enabled, your computers will use the router for a DNS server.                                                                                                    |



| DHCP Server           |                                                                                                                                                                                                                                                              |
|-----------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Status                | Enable or disable the DHCP server.                                                                                                                                                                                                                           |
| DHCP IP Address Range | Enter the starting and ending IP addresses for the DHCP server's IP assignment. <b>Note:</b> <i>If you statically assign IP addresses to your computers or devices, make sure the IP addresses are outside of this range or you may have an IP conflict.</i> |
| DHCP Lease Time       | Enter the length of time for the IP address lease in minutes.                                                                                                                                                                                                |
| Always Broadcast      | Enable this feature to broadcast your network's DHCP server to LAN/WLAN clients.                                                                                                                                                                             |

Advanced Settings...

DHCP Server

Status: ☒ Enabled

DHCP IP Address Range: 192.168.0.  to 192.168.0.

DHCP Lease Time:  minutes

Always Broadcast: ☐ Disabled  
(compatibility for some DHCP Clients)

| Advanced Settings...   |                                                                                                                                        |
|------------------------|----------------------------------------------------------------------------------------------------------------------------------------|
| WAN Port Speed         | You may set the port speed of the Internet port to <b>10 Mbps</b> , <b>100 Mbps</b> , <b>1000 Mbps</b> , or <b>Auto</b> (recommended). |
| UPnP                   | Enable or disable Universal Plug and Play (UPnP). UPnP provides compatibility with networking equipment, software, and peripherals.    |
| IPv4 Multicast Streams | Enable to allow IPv4 multicast traffic to pass through the router from the Internet. This is enabled by default.                       |
| IPv6 Multicast Streams | Enable to allow IPv6 multicast traffic to pass through the router from the Internet. This is enabled by default.                       |

Advanced Settings

WAN Port Speed:  ▼

UPnP: ☒ Enabled

IPv4 Multicast Streams: ☒ Enabled

IPv6 Multicast Streams: ☒ Enabled

## D-Link Cloud

In the Settings menu on the bar at the top of the page, click **D-Link Cloud** to see your D-Link Cloud Service details. This page lists whether you are registered with D-Link Cloud Service and email address associated with the account. Use the D-Link Wi-Fi app to find out more about D-Link Cloud's features.

  
DIR-X5460 HW:A1 FW:1.00

Home | Settings | Features | Management



## D-Link Cloud

D-Link Cloud Service enables third-party service integration for your device through the cloud. Please view your account information that is currently associated with your device's D-Link Cloud account. To find out more about D-Link Cloud's features, simply download the D-Link Wi-Fi App from the App Store or Google Play™ to your mobile device.

Settings>>D-Link Cloud

### D-Link Cloud Registration

D-Link Cloud Service: Registered

D-Link Cloud Account: youremailaddress@email.com

# Features

## QoS Engine

In the Features menu on the bar at the top of the page, click **QoS Engine** to configure connected clients Internet access priority.


Click **Save** at any time to save the changes you have made on this page.

- Management Type

Use the drop-down menu to select the Management Type that the rule will be enabled for. This may be set to **Off** or **Manage By Device**.
- Download Speed (Mbps)

Set the download speed based on your ISP subscription plan in order to adjust the QoS engine.
- Upload Speed (Mbps)

Set the upload speed based on your ISP subscription plan in order to adjust the QoS engine.



This **Quality of Service (QoS) Engine** will allow you to prioritize particular clients over others, so that those clients receive higher bandwidth. For example, if one client is streaming a movie and another is downloading a non-urgent file, you might wish to assign the former device a higher priority than the latter so that the movie streaming is not disrupted by the traffic of the other devices on the network.

Under **Connected Clients**, you will see device cards representing each connected client. If some are off-screen, you can use the < and > buttons to scroll through the cards.


A maximum of **one** device can be assigned **Highest** priority.

A maximum of **two** devices can be assigned **High** priority.

A maximum of **eight** devices can be assigned **Medium** priority.

If no devices are explicitly assigned a priority, they will all be treated with equal priority. If some devices are not assigned a priority and others are, the unassigned devices will be treated with the lowest priority.

To assign a priority level to a device, drag the device card from the All Devices list over an empty slot and release the mouse button. The card will remain in the slot. If you want to remove a priority assignment from a device and return it to the All Devices list, click the cross icon in the top right of the device card.



## Firewall Settings - Advanced

In the Features menu on the bar at the top of the page, click **Firewall** to configure the router's firewall settings. The firewall feature protects your network from malicious attacks over the Internet.

To configure the IPv4 firewall rules, click the **IPv4 Rules** link. Refer to **Firewall Settings - IPv4/IPv6 Rules** on page 68

To configure the IPv6 firewall rules, click the **IPv6 Rules** link. Refer to **Firewall Settings - IPv4/IPv6 Rules** on page 68

Click **Save** at any time to save the changes you have made on this page.

**Enable DMZ** Enable or disable Demilitarized Zone (DMZ). This completely exposes the client to threats over the Internet, and is not recommended in ordinary situations.


**DMZ IP Address** If you enabled DMZ, enter the IP address of the client you wish to expose, or use the drop-down menu to quickly select it.

**Enable SPI IPv4** Enabling Stateful Packet Inspection (SPI) helps to prevent cyber attacks by validating that the traffic passing through the session conforms to the protocol.

**Enable Anti-spoof Checking** Enable this feature to help protect your network from certain kinds of "spoofing" attacks.


**IPv6 Simple Security** Enable or disable IPv6 simple security.

**IPv6 Ingress Filtering** Enable or disable IPv6 ingress filtering.



## Advanced Settings... - Application Level Gateway (ALG) Configuration

- PPTP** Allows multiple machines on the LAN to connect to their corporate network using the PPTP protocol.
- IPSec (VPN)** Allows multiple VPN clients to connect to their corporate network using IPSec. Some VPN clients support traversal of IPSec through NAT. This Application Level Gateway (ALG) may interfere with the operation of such VPN clients. If you are having trouble connecting with your corporate network, try turning this ALG off. Please check with the system administrator of your corporate network whether your VPN client supports NAT traversal.
- RTSP** Allows applications that uses Real Time Streaming Protocol (RTSP) to receive streaming media from the Internet.
- SIP** Allows devices and applications using VoIP (Voice over IP) to communicate across NAT. Some VoIP applications and devices have the ability to discover NAT devices and work around them. This ALG may interfere with the operation of such devices. If you are having trouble making VoIP calls, try turning this ALG off.



# Firewall Settings - IPv4/IPv6 Rules


In the Features menu on the bar at the top of the page, click **Firewall** to configure the router’s firewall settings, then click the **IPv4 Rules** link or the **IPv6 Rules** link to configure what kind of traffic is allowed to pass through the network.

To configure the Firewall Advanced settings, click the **Advanced** link. Refer to **Firewall Settings - Advanced** on page 66

Click **Save** at any time to save the changes you have made on this page.

To begin, use the drop-down menu to select whether you want to **ALLOW** or **DENY** the rules you create. You can also choose to turn filtering **OFF**.

If you wish to remove a rule, click on the trash can icon in the Delete column. If you wish to edit a rule, click on the pencil icon in the Edit column. If you wish to create a new rule, click the **Add Rule** button.



If you clicked on **Edit** or **Add Rule**, the following options will appear:

- Name**

Enter a name for the rule.
- Source IP Address Range**

Enter the source IP address range that the rule will apply to. Using the drop-down menu, specify whether it is a **WAN** or **LAN** IP address.
- Destination IP Address Range**

Enter the destination IP address range that the rule will apply to. Using the drop-down menu, specify whether it is a **WAN** or **LAN** IP address.
- Protocol & Port Range**

Select the protocol of the traffic to allow or deny (**Any**, **TCP**, or **UDP**) and then enter the range of ports that the rule will apply to.
- Schedule**

Use the drop-down menu to select the time schedule that the rule will be enabled for. The schedule may be set to **Always Enable**, or you can create your own schedules in the **Schedules** section. Refer to **Time & Schedule - Schedule** on page **81** for more information.

Create New Rule

Name:

Source IP Address Range:

WAN

Destination IP Address Range:

LAN

Protocol & Port Range:

TCP

Schedule:

Always Enable

Apply


# Port Forwarding

In the Features menu on the bar at the top of the page, click **Port Forwarding** to specify a port or range of ports to open for specific devices on the network. This might be necessary for certain applications to connect through the router.

To configure the Virtual Server settings, click the **Virtual Server** link. Refer to **Port Forwarding - Virtual Server** on page 72


Click **Save** at any time to save the changes you have made on this page.

If you wish to remove a rule, click on the trash can icon in the Delete column. If you wish to edit a rule, click on the pencil icon in the Edit column. If you wish to create a new rule, click the **Add Rule** button.



If you clicked on **Edit** or **Add Rule**, the following options will appear:

- Name** Enter a name for the rule.
- Local IP** Enter the IP address of the computer on your local network that you want to allow the incoming service to. Alternatively, select the device from the drop-down menu.
- TCP Port** Enter the TCP ports that you want to open. You can enter a single port or a range of ports. Separate ports with a comma (for example: 24,1009,3000-4000).
- UDP Port** Enter the UDP ports that you want to open. You can enter a single port or a range of ports. Separate ports with a comma (for example: 24,1009,3000-4000).
- Schedule** Use the drop-down menu to select the time schedule that the rule will be enabled for. The schedule may be set to **Always Enable**, or you can create your own schedules in the **Schedules** section. Refer to **Time & Schedule - Schedule** on page **81** for more information.



The screenshot shows a 'Create New Rule' dialog box with a close button (X) in the top right corner. It contains the following fields and controls:

- Name:** A text input field.
- Local IP:** A text input field next to a dropdown menu showing '<< Computer Name'.
- TCP Port:** A text input field.
- UDP Port:** A text input field.
- Schedule:** A dropdown menu currently set to 'Always Enable'.
- Apply:** A blue button at the bottom right.


# Port Forwarding - Virtual Server

In the Features menu on the bar at the top of the page, click **Port Forwarding** then click the **Virtual Server** link to configure its settings and specify a single public port on your router for redirection to an internal LAN IP address and Private LAN port. This might be necessary for certain applications to connect through the router.

To configure the Port Forwarding settings, click the **Port Forwarding** link. Refer to **Port Forwarding** on page 70

Click **Save** at any time to save the changes you have made on this page.

If you wish to remove a rule, click on the trash can icon in the Delete column. If you wish to edit a rule, click on the pencil icon in the Edit column. If you wish to create a new rule, click the **Add Rule** button.



If you clicked on **Edit** or **Add Rule**, the following options will appear:

- Name** Enter a name for the rule. Alternatively, select the protocol/ Application Name from the drop-down menu.
- Local IP** Enter the IP address of the computer on your local network that you want to allow the incoming service to. Alternatively, select the device from the drop-down menu.
- Protocol** Select the protocol of the traffic to allow or deny (**TCP, UDP, Both, or Other**).
- Protocol Number** If you entered **Other** above, enter the protocol number.
- External Port** Enter the public port you want to open.
- Internal Port** Enter the private port you want to open.
- Schedule** Use the drop-down menu to select the time schedule that the rule will be enabled for. The schedule may be set to **Always Enable**, or you can create your own schedules in the **Schedules** section. Refer to **Time & Schedule - Schedule** on page **81** for more information.

The screenshot shows a 'Create New Rule' window with the following fields:

- Name:** A text input field.
- << Application Name:** A dropdown menu.
- Local IP:** A text input field.
- << Computer Name:** A dropdown menu.
- Protocol:** A dropdown menu with 'TCP' selected.
- External Port:** A text input field.
- Internal Port:** A text input field.
- Schedule:** A dropdown menu with 'Always Enable' selected.
- Apply:** A button at the bottom right.


## Website Filter

In the Features menu on the bar at the top of the page, click **Website Filter**. The website filters feature allows rules to be set that restrict access to a specified web address (URL) or blocks specified keywords in the URL. You can use Website Filter to restrict access to potentially harmful and inappropriate websites.

Click **Save** at any time to save the changes you have made on this page.

To begin, use the drop-down menu to select whether you want to **ALLOW** or **DENY** the access to the listed sites.

If you wish to remove a Website URL/Domain, click on the trash can icon in the Delete column. If you wish to list a new site to allow or deny access to, click the **Add Rule** button.




# Static Route - IPv4

In the Features menu on the bar at the top of the page, click **Static Route** to define custom routes, controlling how data traffic is moved around your network.

To configure the Static Route IPv6 settings, click the **IPv6** link. Refer to **Static Route - IPv6** on page 76

Click **Save** at any time to save the changes you have made on this page.

If you wish to remove a route, click on the trash can icon in the Delete column. If you wish to edit a route, click on the pencil icon in the Edit column. If you wish to create a new route, click the **Add Route** button.



If you clicked on **Edit** or **Add Rule**, the following options will appear:

- Name** Enter a name for the rule.
- Destination Network** Enter the IP address of packets that will take this route.
- Mask** Enter the subnet mask of the route.
- Gateway** Enter your next hop gateway to be taken when this route is used.
- Metric** Enter a route metric value ranging from **0** to **15**. This value indicates the cost of using this route.
- Interface** Select the interface that the IP packet must use to transit out of the router when this route is used.

A screenshot of the 'Create New Route' form in the D-Link web interface. The form has a title 'Create New Route' and a close button (X) in the top right corner. It contains several input fields: 'Name', 'Destination Network', 'Mask', 'Gateway', 'Metric', and 'Interface'. The 'Interface' field is a dropdown menu currently showing 'WAN'. An 'Apply' button is located at the bottom right of the form.