

FCC Warning

This device complies with Part 15 of the FCC Rules.
Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

The user is cautioned that changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

INSTRUCTION SHEET FOR 48413 WRIST WALKIE TALKIE

1. Open the battery door and insert the LR44 & LR41 button cells according to the diagram shown.
2. Push the "Power" button on the right hand side of the walkie talkie downwards to turn on the walkie talkie.
3. Press the "Talk" button, now the walkie talkie is in TX status, & can communicate with another walkie talkie.
4. If necessary, plug in the mono headphone to the "SPK" position for listening.
5. To adjust the time of the watch, use the "Set Up" and "Mode" buttons on the LCD panel.

CAUTION

To ensure proper function and battery leakage:

- Do not mix old and new button cells.
- Do not mix alkaline, standard button cells.
- Button cells are to be inserted with the correct polarity.
- Only button cells of the same or equivalent type as recommend are to be used.

USER MANUAL

WARNING : Adjustment to this unit or replacement of any transmitter component (crystal, semiconductor, etc.) to this unit could result in a violation of the rules.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ☐ Reorient or relocate the receiving antenna.
- ☐ Increase the separation between the equipment and receiver.
- ☐ Connect the equipment into an outlet on a circuit different from that to which the receiver is needed.
- ☐ Consult the dealer or an experienced radio/TV technician for help.

SAFETY INFORMATION

Your wireless hand-held portable transceiver contains a low power transmitter. When the Push-to-Talk (PTT) button is pushed it sends out radio frequency (RF) signals. In August 1996, the Federal Communications Commissions (FCC) adopted RF exposure guidelines with safety levels for hand-held wireless devices.

IMPORTANT: To maintain compliance with the FCC's RF exposure guidelines hold the transmitter and antenna at least 1 inch (2.5 centimeters) from your face and speak in a normal voice, with the antenna pointed up and away from the face. If you wear the handset on your body while using the headset accessory, use only the supplied belt clip for this product and when transmitting, take it out of the belt to ensure that the antenna is at least 1 inch (2.5 centimeters) from your body.

Use only the supplied antenna. Unauthorized antennas, modifications, or attachments could damage the transmitter and may violate FCC regulations.