


User's Manual

TX-300V Studio Transmitter



PHONAK


communication systems

Phonak Communications AG
Laenggasse 17
3280 Murten
Switzerland

T +41 (0) 26 672 96 72
F +41 (0) 26 672 96 77
info@phonakcom.ch
www.phonakcom.ch

TX-300V Studio Transmitter Package Contents

- TX-300V Studio Transmitter
- Power Supply
- User's Manual
- Telescoping Antenna Radials (2)
- Antenna Mounting Assembly
- 50 Ohm Coaxial Cable (7.6m)



Phonak Part Number

116-1938

Optional Accessories

Rack Mount Kit
(part number 116-1940, see page 14)




Table of Contents

Specifications.....4

Block Diagram5

Quick Reference6

Setup Instructions7

Operating Instructions.....9

Audio Control.....9

RF Reception Maximization Strategies.....10

Troubleshooting.....11

Compliance Notice12


Warranty13

Optional Accessories.....14

Specifications


RF	Frequency Accuracy	/-.005% stability 0 to 50C
	Transmitter Stability	50 PPM
	Output Power	50mW, 100mW, 300mW (Actual power for each frequency set by Phonak)
	Antenna	Dipole Antenna (Included with Transmitter)
	Antenna Connector	BNC
	Compliance	FCC Part 15, Industry Canada, RoHS
Audio	System Distortion	<2% total harmonic distortion (THD) at 80% deviation
	Audio Input 1	Rear panel, Female-XLR and phone combo connector, balanced, 0/-55 dBu (line/mic) nominal input level adjustable
	Audio Input 2	Rear panel, (2) Phono connectors, unbalanced, -10/+10 dBu nominal input level adjustable, +30 dBu maximum, impedance 100k ohms
	Combined Audio Output (Mix)	Rear panel, (2) Phono connectors, unbalanced, 0 dBu nominal output level, +19 dBu maximum, impedance 10 ohms
	Headphone Output	Front panel, (1) 3.5 mm connector, unbalanced, adjustable output level
Controls	Front Panel	Power, Test Tone on/off, Channel up/down, Input Level, Mix Level, Contour, Headset Level
	Rear Panel	Input 1 Level (Line, Mic, Mic-Phantom Power), Input 2 Level (-10/+10 dBu), RF Power (low, mid, high)
	Internal Adjustments	Compression ratio for audio processor
	Programming	Processing on/off
Indicators	Input 1 and Input 2, Mix VU Meters	8 Green, 2 Red
	Processing	Indicated by a green LED when on
	RF Power	Indicated on the LCD Display
	Power	Red LED illuminates when the unit is powered up
	LCD Display	Channel designation, lock status, RF Power Level, programming
	Test Tone	Red LED illuminates when test tone enabled
Power	Power Supply Type	In-line power supply
	Power Supply Input	115/230VAC, 50/60Hz
	Power Supply Output	12VDC, 1.3 A
	Power Supply Connector	5.0 mm (.02 in) 2.5 mm (OD x .01 in) ID, barrel type
	Compliance	CE, UL
Physical	Dimensions W x D x H	20.3 x 20 x 4.45 cm (8.0 x 8.0 x 1.75 in)
	Unit Weight	1.4 kg (3.0 lbs)
	Unit Weight with Power Supply	2.0 kg (4.4 lbs)
	Shipping Weight	2 kg (5.0 lbs)
	Rack Mounting	½ rack unit, optional rack mount not included. Order Phonak part number 116-1940
Environmental	Temperature - Operation	-10 C (14 F) to +40° (140 F)
	Temperature - Storage	-20 C (-4 F) to +50° (122 F)
	Humidity	0 to 95% relative humidity, non-condensing

TX-300V Block Diagram




Quick Reference

TX-300V Front Panel: Controls & Displays



TX-300V Back Panel: Connections & Settings



TX-300V Studio Setup Instructions

1 Unpack the Product

Remove outer packaging and plastic cover. Inspect for physical damage.

2 Mount in Rack (if necessary)

If rack mounting the unit, install the optional rack mount kit (part 116-1940) according to the instructions included with the kit, then install the TX-300V in the rack.



Rack Mount with dual unit installed




Rack Mount with single unit installed

3 Connect Power

Plug the power supply into the power connector on the back panel, then plug the power supply into an outlet.

Use only the original power supply:
- AC Adaptor, Input: 115/230VAC,
50/60Hz and Output: 120VDC, 1.3A,
Model SP48-151000A



4 Set RF Power

Set the RF POWER switch on the back of the unit to Full, $\frac{1}{2}$ or $\frac{1}{4}$ (Level is indicated on the LCD display). The amount of transmitted RF power that you will need depends on your application. If you are operating multiple transmitters in the same environment, it is best to set the transmitter's output power to its lowest level to reduce the possibility of interference.



Full Power



$\frac{1}{2}$ Power




$\frac{1}{4}$ Power

5 Connect Audio Inputs


The TX-300V has two audio input options: Input 1 and Input 2. Input 1 is a balanced connection using either an XLR or phono connector. Input 2 has two unbalanced mixing phono connectors. Use Input 1 if you are using a microphone or if you have a balanced connection such as from a professional audio mixer (you can also use Input 1 for unbalanced connections). Use Input 2 to connect to an unbalanced audio source.

Input 1

Connect the audio source(s) to one or both audio input connections. Input 1 offers a choice of a balanced XLR or phono connector.




Plug your microphone into Input 1 and move the input select switch to Mic (for dynamic microphones) or Mic + PH Power (for condenser microphones).



Input 2

Plug your unbalanced audio source into Input 2 and select the audio level switch for -10dBu or +10dBu, to match the audio level coming from your equipment.




TX-300V Setup Instructions continued

6 Antenna Installation

Your TX-300V Studio Transmitter Set includes a remote antenna that features two adjustable-length radials. Extending these radials to the correct length is extremely important for the system to achieve maximum transmission range.

Use the following process to determine how long to set your antenna radial lengths:

- 1) Determine the average of the highest and lowest frequencies you will use with this transmitter. (Example: If you are going to use 182.50 MHz and 186.250 MHz then take the average of $182.50 + 186.250$ and then divide by 2 = 184.375MHz).
- 2) Divide 7500 by the average frequency (in MHz), then subtract 5 from this result. The solution to this equation is the length in centimeters to set your radials to. (Example: $7500/184.375=40.68$. $40.68-5= 35.68\text{cm}$ radial length).
- 3) Extend the two adjustable length radials to the calculated length (Example: 40.68 centimeters). Screw the two radials to the antenna mounting assembly.
- 4) Install the antenna mounting assembly in desired location, preferably high on a wall, away from any metal objects and with minimal obstructions between antenna and location of receivers and orient ground side downward as indicated on the plastic housing.
- 5) Connect the RG 58, 50 Ohm coaxial cable to the BNC connectors on the antenna and on the transmitter.




TX-300V Operating Instructions

1 Power Unit On

Turn power on by pressing the power button.

2 Select a Channel

Select the transmit channel by pressing the channel select UP and DOWN buttons.




3 Lock on Channel

Once you determine your transmit channel, you can lock the transmitter on that channel. To lock a channel, hold the Channel Select "Up" button for 3 seconds until the padlock icon appears on the display. To unlock, repeat this process and the padlock icon will disappear.



4 Test Tone (if necessary)


To broadcast a test tone, press the test tone button. This helps to test receivers when no audio source is available.



2 Adjust Contour

Adjust the Contour knob counterclockwise if your audio source is mostly voice. Adjust the knob clockwise if your audio source is mostly music.

The Contour knob adjusts the relative equalization of the unit. This equalization boosts or cuts frequencies above 5 kHz.



3 Adjust Mix Level

Adjust the mix level until the right VU meter occasionally illuminates the red LED. This is the level adjustment for the combined output from Input 1 and Input 2.



4 Process Mode

Process mode is used for Audio Gain Control (AGC). With the process mode enabled, the TX-300V will automatically adjust for inconsistent signal input levels by raising or lowering the signal level accordingly to provide a consistent sound output level. This feature should be used in applications where a consistent sound level is important and the input levels vary substantially. Typically you would not want to engage the Process Mode when a speaker's emphasis is critical to the message they are conveying.

Your TX-300V has been shipped to you with process mode enabled. To enable or disable process mode hold the channel select "Down" button for 8 seconds while the unit is on. After 8 seconds the unit will go into program mode and the program (PGM) icon will appear on the LCD.




Once in the program mode, the Process feature can be toggled on and off by pressing the channel select "Up" button.



TX-300V Audio Control

1 Adjust Audio Input Level

Adjust the input knob counterclockwise to add gain to Input 1. This will decrease gain to Input 2. Adjust input knob clockwise to add gain to Input 2. This will decrease gain to Input 1. If you have two audio sources connected to both Input 1 and 2, adjust the level of one input using the VU meter, then adjust the output level of the other audio source. Adjust the input level until the left VU meter(s) occasionally illuminate the red LEDs. Illumination of the red LEDs indicates the unit is in limiting. Limiting is required so that the unit does not over-modulate the transmitter. If you don't want any audio limiting to occur, make sure the red LEDs never illuminate. If you want a highly limited signal, turn the audio gain up so the red LEDs illuminate often.



RF Reception Maximization Strategies

For proper and dependable operation, Phonak receivers need to receive a strong and consistent signal from the originating transmitter. The following strategies should be used to maximize this signal:

1. When designing and installing your system, keep in mind that the location of the transmitting antenna is critical to maximize broadcast range.
2. Eliminate or minimize obstructions between the transmitter and receiver(s).
3. Minimize the distance between the transmitter and receiver(s).
4. Move the transmitting antenna away from metal or conductive objects.
5. Place the transmitting antenna as high as possible.
6. Orient the transmitting antenna vertically.
7. Position the RF Power switch on the back of the TX-300V to full RF Power, unless lower power is necessary (see page 7).
8. Extend radials to the correct length for selected frequencies (see page 8).

CAUTION: When installing antennas, ensure the antenna is clear of power lines.

TX-300V Troubleshooting

The TX-300V has no power

Make sure the power transformer is connected to a power source and is connected to the jack marked "Power Input". Make sure the POWER button is pressed in.

There is no audio or the audio level is too low

Make sure that your audio source is properly connected to Input 1 and/or Input 2. The Input 1 or Input 2 switches must be in the correct position for the appropriate input level. For example: if you are using the output of a mixer on Input 2, the switch should be in the -10dBu position. If it were to be in the +10dBu position, the level would be too low. Also, check the Input knob to ensure it is properly adjusted. You should be able to see the VU meter deflect on Input 1 or Input 2 corresponding with the input level of the audio source. You can listen to the audio source by connecting a headset to the front panel jack and adjusting the Monitor volume control.

If the level of audio into the transmitter is low and can't be corrected using the level input switches, the audio processor can be turned on to boost the signal (see page 7 to set, page 9 for description of Process Mode).

The audio is distorted

Check to make sure you have the input level select switches in the proper position. You may be providing too much audio level for the input stage to handle.

There is hum in the audio

Make sure you have properly grounded the audio source to the TX-300V. Check the connections from the audio source to the TX-300V. If you can, try to use a balanced audio source - this will reduce the chance of creating hum. Connect a ground wire from the TX-300V to ground and/or to the ground of the source audio.

There is a tone

The Test Tone button has been pressed (its LED light is on). Push the Test Tone button to turn off the tone.

The Audio Input 1 sounds "tinny"

If you are using an unbalanced audio source, make sure Pin 3 on the XLR or the ring on the phone plug is grounded.

I can pick up the signal on the receiver, but it sounds like it's not tuned in

Check to make sure the transmitter and receiver are on exactly the same channel. It's a good idea to lock the channels once they have been set. To lock the TX-300V, press the UP button for a 3 seconds.

End users are adjusting the unit

First, lock the channel by pressing and holding the channel select UP button for 3 seconds. Consider removing the Input, Mix Level and Contour knobs. You can order a rack mount kit part number 116-1940 from Phonak which offers a security cover that will limit access to the unit.

Compliance Notice

Declaration of Conformity / Compliance Notice

Phonak Communications AG, Laenggasse 17, CH-3280 Murten confirms that the Studio Transmitter TX-300V corresponds to the standards EN 300 422, EN 300 454, EN 301 489-1/-9 and FCC 47 C.F.R. Part 74, including all necessary annexes.

Please check with your local Phonak distributor, if you need a license from your local regulatory agency to operate the system.

This transmitter may only be used to provide auditory assistance to persons in studio, stage and entertainment settings and persons with hearing disabilities. Two-way voice communications and all other types of uses not mentioned above are expressly prohibited.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate Phonak equipment.

Recycling



The symbol with the crossed out disposal bin indicates that equipment shall not be treated as household waste. Please hand over your old or unused equipment to the applicable collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative effects on the environment and human health.

Warranty

Phonak offers you a comprehensive global warranty which becomes effective on the date of purchase. Please ask your local Phonak distributor about the details and duration. This warranty covers any repairs due to defects in material and/or workmanship. The warranty does not cover damage from improper handling or care, exposure to chemicals, immersion in water or undue stress. Damage caused by third parties or non-authorized service centers renders the Phonak warranty null and void. This warranty does not include any service performed by a local distributor in their office.

Serial number: _____

Date of purchase: _____

Contacting Phonak

Address: Phonak Communications AG
Laenggasse 17
3280 Murten
Switzerland


Web Site: www.phonakcom.ch

Email: techsup@phonakcom.ch

Phone: +41 (0) 26 672 96 72

Fax: +41(0) 26 672 96 77

Rack Mount Kit



116-1940 Rack Mounting Kit

Includes components for single and dual rack configuration and a security cover



PHONAK

communication systems

Phonak Communications AG

Laenggasse 17
3280 Murten
Switzerland

T +41 (0) 26 672 96 72
F +41 (0) 26 672 96 77
info@phonakcom.ch
www.phonakcom.ch