

Znode

USER INSTRUCTIONS

DESCRIPTION:


The Znode is designed to receive signals from LRS 2.4 GHz devices and "retransmit" them.

ZNODE SPECIFICATIONS

- Required voltage: 110/120V outlet with 5Vdc power supply.
- Operating Frequency: 2.4GHz to 2.475GHz
- Transmit Power: 100 mw
- Transmit Range: 300'

INCLUDED ITEMS:

- Znode
- 5VDC Power Supply
- 2.4 GHz Antenna



CONNECTING THE ANTENNA:

The antenna should be placed on the SMA connector on the Znode and tightened into place (see picture)

POSITIONING AND INSTALLING THE ZNODE:

Notes:

- Metal surfaces and thick walls will reduce the signal strength.

The Znode operates at its best when installed at the "fringe" of your area. This means you should get it as far from the T750x transmitter or WIN application as possible but still be able to communicate with the T750x or WIN application.

1. Set T750X or WIN application into Associate Mode.
2. Connect the 5VDC power supply into the Znode.

3. Press the button on the side of the Znode once.
4. The LED will begin to flash. The green LEDs will flash to show that the Znode connected to the T750X or WIN application.
5. The green LED will flash once every 5 seconds to show it is connected.

Note: If the Znode does not connect, repeat the process.

To re-associate a Znode:

1. Press and hold the button on the side of the Znode for 5 seconds.
2. The LED will now be RED.
3. Put the T750x or WIN application into Associate mode.
4. Press the button on the side of the Znode once.

TROUBLESHOOTING:

My LED is displaying RED all the time?

The Znode is currently waiting to be associated to a T750x or WIN application. Make sure the T750x or WIN application is in Associate Mode, then press the button on the side of the Znode once.

CUSTOMER SUPPORT

Should you have any questions, please contact us:

LRS Customer Service Department
800.437.4996 or 214.553.5308

LRS Australia
 +61 (02) 995 5700
www.lrsaustalia.com.au

LRS Brazil
 5511 41528416
www.lrspager.com.br

LRS Canada
 877.607.7243
www.lrscanada.ca

LRS Colombia
 (+57) 1 - 7592452
www.lrscolombia.com

LRS Europe GmbH
 +49 531 310542 0
www.lrs.eu.com

LRS Middle East Ltd
 +9613 81 82 84
www.lrs-lb.com

LRS South Africa
 +27 21 422 4975
www.lrssa.com

LRS United Kingdom
 +44(0)1782 537000
www.lrspagers.co.uk

WARRANTY

Any rechargeable pager left off charge for more than 30 days is not covered under the standard warranty.

FCC ID: M74TX-ZNODE

This device complies with Part 15 of the FCC Rules. Operation is subject to the following

two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device is designed to operate and should be placed in an area with a minimum separation distance to nearby persons of at least 20 Centimeters.

Any modifications to the unit, unless expressly approved by Long Range Systems LLC could void the user's authority to operate the equipment.



Long Range Systems, LLC
4550 Excel Parkway, Suite 200, Addison, TX 75001
www.pager.net • 214.553.5308

030414