

FCC Certifications

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Shielded interface cables must be used in order to comply with emission limits.

You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

CE Mark Warning

This is a Class B product. In a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures.

All trademarks and brand names are the property of their respective proprietors.

Specifications are subject to change without prior notification.

AboCom

IP Sharing + Fast EtherSwitch For Cable/

xDSL Modem

(CAS1040)

User Guide

Table of Content

INTRODUCTION	1
SAMPLE APPLICATION	2
FEATURES.....	2
PARTS NAMES AND FUNCTIONS.....	3
SYSTEM REQUIREMENTS	4
FACTORY DEFAULT SETTINGS	5
PASSWORD	5
LOCAL AND GLOBAL PORT ADDRESSES	5
INFORMATION FROM ISP	5
CONFIGURATION VIA GUI	6
<i>How to start</i>	6
<i>Management</i>	7
<i>Local Port</i>	8
<i>Global Port</i>	10
<i>Virtual Server</i>	11
<i>Packet Filters</i>	12
CONFIGURATION VIA WEB.....	16
MANAGEMENT	16
LOCAL PORT.....	17
GLOBAL PORT	19
VIRTUAL SERVER	21
PACKET FILTER	22
ADVANCED SETTINGS	24
NETWORK STATUS	25
CONFIGURATION VIA TERMINAL Commands.....	27
<i>How to start Telnet</i>	27
<i>Starting the Configuration</i>	27
TERMINAL COMMAND.....	29
SESSION	30
SHOW	30
USER	31
FILTER	31
<i>MAC address filter:</i>	32
<i>IP address filter :</i>	32
<i>Port Filter</i>	33
PASSWD	34
PING.....	34

TRACERT	35
RELEASE	35
RENEW	36
SET	36
CONNECT	37
DISCONNECT	38
STATUS	38
VSERV.....	39
ROUTE	39
WANTEL.....	40
UPGRADE	40
FIRMWARE UPGRADE	42
UPGRADING THE FIRMWARE	42
CHANGING PASSWORD	43
FROM GUI.....	43
FROM TERMINAL	43
FORGOT YOUR PASSWORD?	44
PPP OVER ETHERNET (PPPOE)	45
WHAT IS PPPOE?	45
HOW CAN I KNOW I AM USING PPPOE?	45
CHECKING PPPOE CONNECTIONS	45
1. For GUI Setup program	45
2. Checking PPPoE status through Terminal Mode.....	45
FAQ.....	46
FACTORY RESET	46
IP ADDRESS CONFLICT.....	47
MY INTERNET APPLICATION WON'T WORK.....	47
CAN NOT ACCESS THE INTERNET	49
DIAGNOSIS	51
<i>TCP/IP Network Diagnosis</i>	<i>51</i>
<i>ISP Connectivity Checkup</i>	<i>53</i>
<i>Internet Connectivity Checkup</i>	<i>53</i>
GETTING TECHNICAL SUPPORT	54
APPENDIX A SPECIFICATIONS.....	55
APPENDIX B SUPPORTED INTERNET APPLICATIONS.....	56

INTRODUCTION

The BroadBand IP Gateway + Fast EtherSwitch is an integrated Internet IP sharing device with a built-in 4-port 10/100Mbps N-Way Fast Ethernet switch. It is the perfect solution to connect a small group of PCs to a high-speed broadband Internet connection. Multiple users can have high-speed Internet access simultaneously via one single IP address (Internet account) of the Cable/xDSL modem.

This product also serves as an Internet firewall, protecting your network from being accessed by outside users. All incoming data packets are monitored and filtered. It can also be configured to block internal users from accessing to the Internet.

This device provides an easy-to-setup GUI program for Windows 95/98/ME/NT/2000. Thanks to both DHCP client and DSCP server, which complete the network configuration automatically. The built-in 4-port Fast Ethernet Switch lets users plug the network cable into the device without buying additional Hub/Switch. With the functions of the IP Share, you can enjoy the true Plug & Play installation.

In addition, the unit is equipped with an Incoming Mail Indicator, which will lit green when there is e-mail waiting to be retrieve at the mail server.

Sample Application




Figure 1: Small Office/ Home Office Setup


Features

- For Internet connection.
- Supports VPN (PPTP pass thru).

- Supports PPPoE.
- Supports Internet applications such as Web, ICQ, FTP, Telnet, E-Mail, News, NetMeeting, PCAnyWhere, mIRC , CuSeeMe, AoE...etc.
- Natural firewall keeps hackers out.
- DHCP server allocates up to 128 client IP addresses.
- DHCP client to get global IP address automatically.
- 4 ports 10/100Mbps N-Way Fast Ethernet Switch
- Virtual server.
- Rich packet filters.
- Static routing.
- Support Proxy-DNS.
- Easy setup by Windows GUI program and Telnet through network.
- Flash memory for firmware upgrade.

Parts Names and Functions

LED Indicators on the Front Panel



Ports on the Rear Panel




Figure 2: LED Indicators and Ports

	LED Indicator	Color	Status	
			Solid	Flashing
①	Power /Error	Green /Red	Turns solid green when power is applied to this device. Turns solid red when the device is not working properly.	N/A.
②	Internet	Orange (10M)	Connected and linked to a Cable/xDSL Modem. Glows orange with 10Mbps Internet	Receiving/ Sending data

		Green (100M)	connection; green with 100Mbps. ¹	
③	Local 1	Green /Orange	Turns green when connecting to a 100Mbps Fast Ethernet connection.	Receiving/ Sending data
④	Local 2			
⑤	Local 3		Turns orange when connecting to a 10Mbps Ethernet connection.	
⑥	Local 4			
⑦	Have Mail	Green	N/A.	Incoming mail(s).

Table 1: LED Indicators

	Port/button	Functions
a	5V DC	Connects the power adapter plug.
b	Internet	Connects to a Cable/xDSL modem with 10Mbps or 10/100Mbps connection dependent on your purchased model.
c	MDIX\MDI	Press this button to select Internet port wiring scheme (MDIX or MDI).
d	Local (1-4)	Four RJ-45 dual-speed (10/100Mbps) auto-sensing ports for connecting with either 10Mbps or 100Mbps Ethernet connections.
e	MDIX\MDI	Press this button to select Local 4th port wiring scheme (MDIX or MDI).

Table 2: Connections Ports

System Requirements

Your system must meet the following requirements to use the product's Setup program. If you are using a Unix or apple based system, telnet should be used to configure the product.

This product's GUI setup interface requires

1. Windows 95, 98, ME, NT or 2000.
2. IE 4.01 or above.

Note: Telnet setup is operating system independent.

¹ The Internet LED indicator will glow only orange if the model you purchased is with 10M WAN port.

FACTORY DEFAULT SETTINGS

Password

The default setting for password has been left blank in the factory. When using Telnet to configure the device, press **Enter** to login the configuration for the first time. It is recommended that you set a password for security and management purpose.

If you forgot the password, you can reset the device to factory setting. Refer to the section titled “**Factory Reset**” for details.

Local and Global Port Addresses

The LAN parameters of the product are pre-set in the factory. The default values are shown below.

Local Port		Global Port
IP address	192.168.1.254	DHCP client function is <i>enabled</i> to automatically get the Global port configuration from ISP.
Subnet Mask	255.255.255.0	
DHCP server function	Enabled	
IP addresses for distribution to PCs	128 IP addresses continuing from 192.168.1.1 to 192.168.1.128	

Table 3: Local and Global Port Addresses

Information from ISP

If your ISP (Internet Service Provider) assigns you the IP address *dynamically*, skip this step. If you have a static address from your ISP, gather the information as illustrated in the following table and keep it for reference.

	IP address
ISP-assigned IP address	Ex. 203.66.81.201
Subnet mask	Ex. 255.255.255.0
Gateway	Ex. 203.66.81.254
DNS server #1	Ex. 203.66.81.251
DNS server #2	Ex. 203.66.81.252

Table 4: ISP Assigned Addresses

CONFIGURATION VIA GUI

How to start

1. For the first time installation, insert the setup diskette in the floppy drive, in Windows, run **setup.exe** at the diskette's root directory.




Figure 3

2. After installing the setup program, go to **Start→ Programs→IP Share Setup**.




Figure 4

3. When the opening screen appears, you will be prompted a list of the current active devices. Click to select the device you want to configure.




Figure 5