

User Manual

Model name: 7700

Trand name: doppio

FCC ID:N2GDPSQUARE

Contents

1. Getting to know your phone	1	4.1 View a contact.....	3
1.1 Your Phone	1	4.2 Adding a new contact.....	3
1.2 Installing SIM card and battery.....	1	5. Call logs.....	3
1.3 Installing Storage card	1	5.1 Missed calls	3
1.4 Battery charging.....	1	5.2 Dialed calls.....	3
1.5 Power on/ off.....	1	5.3 Received calls.....	3
1.5.1 Power on	1	5.4 Rejected calls.....	3
1.5.2 Power off.....	1	5.5 Delete all	3
2. Using Call Function.....	2	5.6 Call timers	3
2.1 Making a call	2	5.7 GPRS counter.....	4
2.2 Answering or rejecting a call	2	6. Settings.....	4
2.2.1 Answer a call	2	6.1 Phone settings	4
2.2.2 Reject a call.....	2	6.1.1 Date & time	4
2.3 Adjusting call volume	2	6.1.2 Language settings	4
2.4 Ending a call	2	6.1.3 Auto power on/off.....	4
3. Message.....	2	6.1.4 Power management	4
3.1 Write message	2	6.1.5 Restore factory settings.....	4
3.1.1 New SMS	2	6.2 Display	4
3.1.2 New MMS.....	2	6.2.1 Animation effect.....	4
3.2 Inbox	2	6.2.2 Wallpaper settings	4
3.3 Outbox	2	6.2.3 Contrast.....	4
3.4 Drafts	2	6.2.4 Keypad backlight time	4
3.5 Sentbox.....	2	6.2.5 Auto keypad lock	4
3.6 Templates.....	3	6.3 Security	4
3.7 Broadcast message	3	6.3.1 PIN	4
3.8 Voice mail server.....	3	6.3.2 Phone locked.....	5
4. Contacts.....	3	6.3.3 Modify the cellphone password	5
		6.3.4 Privacy Protection	5

6.3.5 Lock screen by end-key	5	11.7 Unit conversion	8
6.3.6 Mobile tracker	6	11.8 Backup	9
6.3.7 Blacklist	6	11.9 Ebook	9
6.4 Call settings	6	11.10 Bluetooth	9
6.4.1 Call divert	6	11.11 FlashLight	9
6.4.2 Call waiting (Need network support) ..	6	12.Audio	9
6.4.3 Call barring	6	13.Services	9
6.4.4 Hide ID (Need network support)	6	13.1 Input URL	9
6.4.5 Others	6	13.2 Bookmarks/ history	9
6.5 Connections	7	13.3 Offline pages	9
7.Application	7	14.Camera	9
7.1 Java application	7	15.Safety Precaution	10
7.2 Games	7	15.1 Usage environment	10
7.3 Facebook	7	15.2 Emergency calls	10
8.Multimedia	7	15.3 Password access	11
8.1 Analog TV	7	15.3.1 Phone password	11
8.2 Video recorder	7	15.3.2 PIN code	11
8.3 Image viewer	7	15.3.4 PUK code	11
8.4 Video	7	15.4 Cautions for battery charging	11
8.5 FM radio	7	15.5 Cautions for battery usage	12
8.6 Sound recorder	8	15.6 Cautions for spare parts usage	13
9.Profiles	8	15.7 Other safety information	13
10.My files	8		
11.Organizer	8		
11.1 Calendar	8		
11.2 Alarm	8		
11.3 Calculator	8		
11.4 World clock	8		
11.5 Timer	8		
11.6 Stopwatch	8		

1. Getting to know your phone

1.1 Your Phone

1.2 Installing SIM card and battery

- (1) Hold on **【End Key】** for about three seconds to switch off the phone.
- (2) Remove the battery cover.
- (3) Remove the battery.
- (4) Follow the sign for SIM on the phone to install SIM. Please make sure that the golden contacts of the card face into the phone and the notched corner has the same direction with the card slot, then push the other side of the card gently until it fixes itself in the card slot.
- (5) Replace the battery with its golden contact part facing the set phone battery contact piece, and then replace the battery cover.

1.3 Installing Storage card

- (1) Hold on **【End Key】** for about three seconds to switch off the phone.
- (2) Remove the battery cover.
- (3) Remove the battery.
- (4) Follow the arrow direction of the T-Card slot cover, push the T-Card into the slot, make

sure that the gold contacts of the card face upwards, until the card fixes itself in the card slot.

1.4 Battery charging

Charged by the travel charger

- (1) Install the battery correctly into the phone.
- (2) Insert the lead of the travel charger to connecting slot of the phone, and then connect the charger to a standard power socket.

When charging is complete, unplug the charger from the standard power socket first, and then disconnect the phone and charger.

1.5 Power on/ off

1.5.1 Power on

Hold on **【End Key】** for three seconds to switch on the phone.

1.5.2 Power off

Hold on **【End Key】** for three seconds to switch off the phone.



Warning:

Don't switch the phone on in areas where wireless phone usage is prohibited or where it may cause interference or danger, and also make sure that you haven't activated the function "Auto power on/off".

2. Using Call Function

2.1 Making a call

(1) On the Home Screen, input the area code and phone number.

2.2 Answering or rejecting a call

2.2.1 Answer a call

When there is an incoming call, you can press **【Left Soft Key】** to answer.

2.2.2 Reject a call

When there is an incoming call, you can press **【End Key】** to reject it.

2.3 Adjusting call volume

During a call, you can press **【Up/Down Key】** to adjust the earphone volume.

2.4 Ending a call

Press **【End Key】** to end the call.

3. Message

3.1 Write message

3.1.1 New SMS

Enter the main menu and select **[Message→Write message→New SMS]** to edit a new SMS directly.

After writing an SMS, select **<Send>** to send the message.

3.1.2 New MMS

Enter the main menu and select **[Message→Write message→New MMS]** to create a new MMS.

3.2 Inbox

Store all received SMS and MMS.

3.3 Outbox

Store all SMS and MMS failed to be sent.

3.4 Drafts

Save edited SMS and MMS haven't sent.

3.5 Sentbox

Store all the SMS and MMS successfully sent out. If you want the sent messages be saved automatically, please select

[Message→Settings→Save sent messages→Save].

3.6 Templates

While editing messages, you can directly cite the preset common phrases. Select <**Edit**> to set the common phrases by yourselves.

3.7 Broadcast message

You can receive broadcast text messages with various contents via network service, such as news, weather or traffic information. For more details, please consult your network operator.

3.8 Voice mail server

This function works like an answering machine, which can transfer a missed call to your personal voice mail, allowing the caller to leave a voice message and notify you by an SMS. Voice Mail is a part of the bundled software provided by network operator, therefore, you need to register to active this function, and manually set the phone. Please contact with your network operator for more details.

4. Contacts

4.1 View a contact

Enter the phonebook, the phone is defaulted to show contact list with all entries.

4.2 Adding a new contact

On the Contacts list, select<**Options**→**New**>to create a new contact.

- ❖ **Phone:** You can input the contact name, mobile phone, home phone, etc. You can also set special ring for the contact entry.
- ❖ **SIM:** The input record will be saved to SIM, with each name one phone number.

5. Call logs

Enter the main menu, and then select [**Call logs**] to enter the call list.

5.1 Missed calls

Display recent calls unpicked up.

5.2 Dialed calls

Display recent calls dialed.

5.3 Received calls

Display recent calls received.

5.4 Rejected calls

Display recent calls rejected.

5.5 Delete all

Delete all the call entries.

5.6 Call timers

Select the desired SIM Card, and then you can view all relevant information about the SIM Card.

5.7 GPRS counter

You can view the detail about GPRS flowrate.

6. Settings

6.1 Phone settings

6.1.1 Date & time

- ❖ **Set time:** Directly input the time or press 【Up /Down Key】 to set it.
- ❖ **Set date:** Directly input the date or press 【Up /Down Key】 to set it.

6.1.2 Language settings

You can select the language you want.

6.1.3 Auto power on/off

You can set the phone to switch on/off at a scheduled time.

6.1.4 Power management

Display the battery capacity.

6.1.5 Restore factory settings

Reset all parameter values into default status. Please enter the privacy preserving password (Initial password is 1234) to resume factory setting.

6.2 Display

6.2.1 Animation effect

You can select the preset animation or others as the power on/off animation for your phone.

6.2.2 Wallpaper settings

Select the default or other pictures as the wallpaper of the phone.

6.2.3 Contrast

Press 【Left /Right Key】 to adjust the contrast.

6.2.4 Keypad backlight time

Select the desired keypad light time.

6.2.5 Auto keypad lock

After activating this function, the phone will be locked automatically if the time you set is arrived, so as to avoid error operations.

- ❖ **Manual lock keypad:** On the Home screen, press 【Left Soft Key】, then press 【# Key】 to lock the keypad manually.
- ❖ **Manual unlock keypad:** On the Home screen, press 【Left Soft Key】, then press 【# Key】 to unlock the keypad manually.

6.3 Security

6.3.1 PIN

PIN code is the personal identification number for SIM card. It never be modified, the initial

password set by network operator should be 1234 or 0000. If activated the power-on PIN code, then you have to input the PIN password each time you switch the phone on. You can modify the PIN code to prevent your SIM card being used by others.



Caution:

If you input your PIN code incorrectly three times in succession, the SIM card will be locked automatically, and prompting to enter PUK code to unlock it. Therefore, please do remember the PIN code, if you modify it.

PUK code is made up by 8 digits, unmodifiable. When the phone is locked by PIN code, please enter correct PUK code to unlock the phone. If you incorrectly input the PUK code ten times in succession, then the SIM card cannot be used any more. Some PUK codes are provided together with the SIM card, some should be gained from the network service provider. If you don't know the PUK code while your PIN code is locked, please never input the code casually. In this case, please call the hotline of the service provider for your SIM card, after simply checking about the user identity, you can gain the PUK code for free to unlock your phone.



Caution:

Please be careful when use this function. If you forget PUK code, please consult your network operator. If you incorrectly input the PUK code ten times in succession, the SIM card will be scrap.

6.3.2 Phone locked

After activated this function, you should input password each time you switch the phone on. The defaulted password is "1234".

6.3.3 Modify the cellphone password

You can change the phone password.

The defaulted password is "1234".

6.3.4 Privacy Protection

Secured by phone password, the phone will be protected from other unauthorized users. When password function has been activated for call logs or message, you have to enter correct password on corresponding main menu or sub-menu. The defaulted password is "1234".

6.3.5 Lock screen by end-key

Once activated this function, when the backlight is on, press【End Key】to turn off the backlight and auto lock the keypad.

6.3.6 Mobile tracker

When the Mobile tracker is on, once your SIM card is replaced, the phone will automatically send stolen information to the prior SIM card.

6.3.7 Blacklist

He or she can't call you if you set the blacklist status to on and add his or her number to blacklist.

6.4 Call settings

6.4.1 Call divert

Based the set diverting conditions, incoming calls will be forwarded into voice mail or other numbers.

6.4.2 Call waiting (Need network support)

- ❖ **Activate:** If you set the function on, the network will alert you that there is an incoming call. You can keep current call and answer another one.
- ❖ **Off:** Cancel call waiting function, then the new incoming calls won't be answered while you're on the phone already.
- ❖ **Check status:** Select it to view current status of this function.

6.4.3 Call barring

This function helps you to restrict the incoming and outgoing calls.



Caution:

1. Some network operators forbid the function. For more details, please contact your network service provider.
2. The network operator will provide you the initial network password while you apply for this service.

6.4.4 Hide ID (Need network support)

- ❖ **Hide ID:** While calling, the recipient won't see your phone number.
- ❖ **Display own ID:** While calling, your phone number will be visible for the recipient.
- ❖ **Display ID by network:** While calling, whether your phone number will be visible or not for the receiver depends on the network presetting.

6.4.5 Others

❖ Call time minute reminder

If you activate the function, an elapsed time reminder will be heard at the set second of every minute during your call, so that you may end the call timely to save the phone fare.

❖ Auto redial

If you set this function on, the phone will redial the number after an unsuccessful call.

❖ **Vibration when connected**

The phone will vibrate to prompt you when the recipient answers your phone.

❖ **Reply SMS after reject**

You can select whether to reply an SMS after rejecting a call.

❖ **Auto record voice call**

To record the call automatically.

6.5 Connections

Through this function, you can select network and set preferred network.

7. Application

7.1 Java application

7.2 Games

For specific operation, please refer to **Help** option of the game.

7.3 Facebook

8. Multimedia

8.1 Analog TV

Pull the antenna, enter the main menu, and select [**Multimedia**→**Analog TV**] to enter the TV function.

- ❖ Press【Left/Right Key】to switch between last or next channel
- ❖ Press 【Up/ Down Key】 to adjust the volume
- ❖ Press 【OK Key】 to display on full screen

8.2 Video recorder

Enter the main menu, and select [**Multimedia**→**Video recorder**] to enter the video preview screen, and press 【OK Key】 to start recording the video.

8.3 Image viewer

The function provides a prompt access to view the photos and pictures.

8.4 Video

Enter the Main menu, and click [**Multimedia**→**Video**].

- ❖ Press 【OK Key】 to play or pause
- ❖ Press 【Up/Down Key】 to adjust the playing volume
- ❖ Press【Left/Right Key】to skip to last /next one

8.5 FM radio

Enter the Main menu, then select [**Multimedia**→**FM radio**].

- ❖ Press 【OK Key】 to play or pause

❖ Press **【Left/Right Key】** to adjust the radio frequency.

❖ Press **【Up/Down Key】** to adjust the playing volume

8.6 Sound recorder

Enter the main menu, select **[Multimedia → Sound recorder]**, and select **<Record>** to start recording. After ceasing the recording, the recorded file will be automatically save in the folder **[Audio]**, select **<Options→Record file list>** to check.

9. Profiles

The mobile phone provides multiple user profiles, so that you can customize some settings to adapt to the specific events and environments.

Customize the user profiles according to your preference and then activate the user profiles. The user profiles fall into five scenarios: **Normal, Silent, Meeting, Indoor, Outdoor.**

10. My files

This menu allows you to manage files stored in the phone or storage card.

11. Organizer

11.1 Calendar

Once you enter this menu, there is a monthly-view calendar for you to keep track of important appointments, etc.

11.2 Alarm

On the Home Screen, press **【Left Soft Key】** to enter the main menu, and select **[Organizer→Alarm]**, then you can set the alarm name, time, ring and mode.

11.3 Calculator

Directly input numbers, press **【Navigation Key】** to select your desired operation symbols (+, -, /, X). Press **【OK Key】** to get the answer.

11.4 World clock

This function allows you to check the standard time in different areas of the world.

11.5 Timer

Select **<Start>** to countdown.

11.6 Stopwatch

Select **<Start>** to start.

11.7 Unit conversion

This function enables you to convert one unit to another unit.

11.8 Backup

11.9 Ebook

You can view file in TXT format by Ebook and copy the TXT file to the **[Ebook]** folder in the phone or memory card from your PC.

11.10 Bluetooth

With Bluetooth, you can make a wireless connection to other compatible devices, such as mobile phones, headsets and car kits. You can use the Bluetooth to send images, video clips, music, sound clips and notes, and transfer files from your compatible pc.

11.11 FlashLight

You can use this function to turn on/off the flashlight.

12. Audio

Enter the main menu, and select **[Audio]** to enter the Audio Player screen:

- ❖ Press **【OK Key】** to play or pause
- ❖ Press **【Left/Right Key】** to skip to last /next one
- ❖ Press **【Up/Down Key】** to adjust the playing volume

13. Services

13.1 Input URL

Enter the wanted website, and select **<OK>** to connect it.



Caution:

1. Your network service provider may not support some functions. In order to ensure the browser work normally, please confirm first that your SIM card supports and have the Internet function activated.
2. If you browse the web page, flowrate fee will be charged.

13.2 Bookmarks/ history

- ❖ **Bookmarks:** Save the common visited website into the Favorites, and marked by simple names. Select one saved name, then the corresponding web will be connected.
- ❖ **History:** Saves the websites you visited before.

13.3 Offline pages

After saving a website as snapshot, you can browse the website while offline.

14. Camera

Enter the main menu, and select **[Camera]** to enter the camera preview screen, press **【OK**

Key】 to take a photo.

15. Safety Precaution

15.1 Usage environment

Please remember to obey relevant rules and regulations whenever use your phone. This will prevent bad effect from you and the environment.

- ❖ Switch off your phone near explosive places, such as gas station, bunkers, chemical factories or blasting scene, and adhere to any safety signs and instructions there. Breaking any rules may cause explosion or injury.
- ❖ Phone using in plane will interfere with the flight operation and bring dangers. Therefore, please do switch off your phone before boarding, and make sure it is power off during the whole flight.
- ❖ Please keep the phone in its special bracket while you're driving. Please don't put it on a seat or in places where it could fall off when the car encounters collision or break. In order to ensure safe driving and avoid road accidents, please don't use the phone when driving. If you must use it, please use the phone's hands-free asset or park at roadside before making or answering a call.
- ❖ Please put the phone away from the high temperature environment, for explosion might

be caused when the battery is of excess high temperature.

15.2 Emergency calls

As the phone uses a radio signal, wireless and ground communication network and personal settings functions like other phones, it is impossible to ensure your phone can be connected successfully in any situation, so please don't rely purely on your phone as the only means of notification in cases of emergency (such as medical first aid).

Make an emergency call

If your phone is switched off, please turn on your phone and check whether the network signal is strong enough.

- (1) Input the local first aid number correctly (such as 911), different areas have different first aid numbers.
- (2) Please press **the call key** to call.



Caution:

While making an emergency call, you should try best to provide all important information precisely. At this time, the phone may be the only communication tool, so don't end the call without permission.

15.3 Password access

Your phone and SIM card can be protected by a password to prevent others using them illegally.

15.3.1 Phone password

This protects your phone from unauthorized users. You can set the preset password when you use it for the first time. After using it, please modify your phone password as soon as possible and keep it secret.

15.3.2 PIN code

This is personal identification code, which is used to protect the SIM card from unauthorized users. Generally, the PIN code and SIM card will be provided together. After activating the PIN code, you need to input correct password each time you switch the phone on to ensure normal usage.



Caution:

If you input your PIN code incorrectly for three times in succession, the SIM card will be locked. You need to enter the PUK code to unlock it. (If you don't have a PUK code, please contact your network operator or SIM card retailer for this information. Please don't input any characters).

15.3.4 PUK code

This is used to unlock the PIN code. Usually the PUK code and SIM card are provided together. If you don't have it, please contact with your network operator or SIM card retailer. SIM Card won't be used any more, if you incorrectly input the PUK code ten times in succession. In that case, please apply a new SIM card from your network operator. PUK code is unmodifiable.

15.4 Cautions for battery charging

The phone provides power by using a lithium battery. The standby time and call time will be influenced by the system's environment and phone settings.

- ❖ Please use the approved battery and charger designated for this product. The company will take no responsibility for damage caused by unauthorized battery or charger.
- ❖ The battery icon will start scrolling when the phone is charged in power-on-state.



Caution:

1. If there is no battery left at all, then the battery icon will appear after 2-3 minutes of charging. The battery charging time depends on the status of the phone (whether switched on, making a call), usually, it will take about 2-5 hours.
 2. To make the new battery achieve its best capacity, please charge and discharge the phone for twice or three times. Please charge the new battery over 10 hours for the first several times.
- ❖ Don't use wet hands to touch the battery or charger while charging in order to avoid danger.
 - ❖ Try not to use the phone while charging.
 - ❖ The battery icon stops scrolling while the battery is full, and then you can disconnect the phone from the charger adapter.

15.5 Cautions for battery usage

The battery usage depends on the network, phone setting and usage situation.

- ❖ Never use any damaged battery.
- ❖ The phone will consume a little power if it is near network station. Therefore, the call and

standby time depends greatly on the signal strength of honeycomb network and the parameters set by network operator.

- ❖ The battery charging time lies on the remnant power, and the type of the battery and charger. When the operation time (talk time and standby time) is noticeably shorter than normal, it is time to replace with a new battery.
- ❖ Only use batteries and charges authorized for this device, otherwise, explosion might be caused. Please disconnect the charger while unused. Do not leave the battery connected to a charger over one week, for overcharging may shorten the life length.
- ❖ Do not connect the anode and cathode of a battery inversely.
- ❖ Do not leave the battery in places with over-high or over-low temperature, otherwise, the battery capacity will be reduced and battery life will be shortened. Always try to keep the battery in room temperature.
- ❖ Do not short-circuit the battery. This may damage the electronic core or internal protected circuit. If you keep the unused battery in the pocket or bags, metal objects (eg. coin, clip or pen, etc) inside might have the anode directly contacted with the cathode

of the battery and caused accidental short circuit. Therefore, please carefully and separately store the battery.

- ❖ Don't burn your phone battery or treat it as common rubbish. Please adhere to the local environmental policy in order to avoid endangering life and causing environmental damage, and recycle your batteries in time.
- ❖ If your phone, battery or other charging device is accidentally penetrated by water, you must not put it inside any calefaction equipment (such as drier, microwave oven etc.) to dry it. The phone or other products may go wrong, and may even cause the phone, battery or other charging device to burn, expand and explode.
- ❖ Please deal with the discarded battery according to the relative introduction.

The company will take no responsibility for any direct or indirect damage caused by user error.

15.6 Cautions for spare parts usage

- ❖ Please put all spare parts (such as SIM card, storage card, battery etc) out of reach of children, in case danger occurs.
- ❖ Please do switch off the phone and unplug the phone and charger before you removing the

battery from the phone.

- ❖ As the phone's spare parts are not waterproof, please keep all spare parts dry.
- ❖ You should pull out the plug of any spare part correctly when you switch off the power, don't drag the power line forcibly.

If the phone, battery, and charger don't operate normally, please contact closest qualified maintenance centres timely.

15.7 Other safety information

- ❖ If you don't use your phone, it's better to switch it off and remove the battery so as to save energy and avoid cellular radiation.
- ❖ Please don't have the volume over loud while using the phone, which might impair your hearing.
- ❖ The unprofessional shouldn't disassemble the terminal and battery of the phone.
- ❖ It is recommended that you should try not to use the holster with magnet button, for the magnet may interfere with the phone signal, and hard iron button may crush the LCD screen. Plastic phone cover will lead to poor volatilization of vapor and have the internal components corrupted, moreover, it can have the phone shell oxidized and faded.

- ❖ If you or your family has a medical record of dizziness or epilepsy, please consult with the doctor first, if you want to play phone games or use the flashlight (the flash doesn't available in all phone models).
- ❖ Please don't put the flashlight too close to the eyes of human beings or animals, as this could do harm to the eyes.
- ❖ Should avoid the phone falling off from high places.

FCC RF EXPOSURE INFORMATION:

WARNING!! Read this information before using your phone

In August 1986 the Federal Communications Commission (FCC) of the United States with its action in Report and Order FCC 96-326 adopted an updated safety standard for human exposure to radio frequency (RF) electromagnetic energy emitted by FCC regulated transmitters. Those guidelines are consistent with the safety standard previously set by both U.S. and international standards bodies. The design of this phone complies with the FCC guidelines and these international standards. Use only the supplied or an approved antenna. Unauthorized antennas modifications, or attachments could impair call quality, damage the phone, or result in violation of

FCC regulations. Do not use the phone with a damaged antenna. If a damaged antenna comes into contact with the skin, a minor burn may result. Please contact your local dealer for replacement antenna.

BODY-WORN OPERATION:

This device was tested for typical body-worn operations with the back of the phone kept 0.5cm from the body. To comply with FCC RF exposure requirements, a minimum separation distance of 0.5cm must be maintained between the user's body and the back of the phone, including the antenna, whether extended or retracted. Third-party belt-clips, holsters and similar accessories containing metallic components shall not be used. Body-worn accessories

that cannot maintain 0.5cm separation distance between the user's body and the back of the phone, and have not been tested for typical body-worn operations may not comply with FCC RF exposure limits and should be avoided.

For more information about RF exposure, please visit the FCC website at www.fcc.gov

Your wireless handheld portable telephone is a low power radio transmitter and receiver. When it is ON, it receives and also sends out radio

frequency (RF) signals. In August, 1996, the Federal Communications Commissions (FCC) adopted RF exposure guidelines with safety levels for hand-held wireless phones. Those guidelines are consistent with the safety standards previously set by both U.S. and international standards bodies:

<ANSI C95.1> (1992) / <NCRP Report 86> (1986) / <ICIMIRP> (1996)

Those standards were based on comprehensive and periodic evaluations of the relevant scientific literature. For example, over 120 scientists, engineers, and physicians from universities, government health agencies, and industry reviewed the available body of research to develop the ANSI Standard (C95.1). Nevertheless, we recommend that you use a hands-free kit with your phone (such as an earpiece or headset) to avoid potential exposure to RF energy. The design of your phone complies with the FCC guidelines (and those standards).

Use only the supplied or an approved replacement antenna. Unauthorized antennas, modifications, or attachments could damage the phone and may violate FCC regulations.

NORMAL POSITION:

Hold the phone as you would any other telephone with the antenna pointed up and over your shoulder.

TIPS ON EFFICIENT OPERATION:

For your phone to operate most efficiently:

- Extend your antenna fully.
- Do not touch the antenna unnecessarily when the phone is in use. Contact with the antenna affects call quality and may cause the phone to operate at a higher power level than otherwise needed.

RF Exposure Information:

FCC RF Exposure requirements: The highest reported SAR values for head, body-worn accessory and simultaneous transmission conditions with the minimum separation distance of 0.5cm are 0.527W/kg, 1.114W/kg and 1.161W/kg. This transmitter must not be collocated or operating in conjunction with any other antenna or transmitter.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to

radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Do not use the device with the environment which below minimum -10°C or over maximum 50°C, the device may not work.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.