




BELL® Phones
BY NORTHWESTERN BELL PHONES

Excursion® 39626



Congratulations on your selection of the Excursion® 39626 from Northwestern Bell Phones. This quality 900MHz cordless telephone all digital answering system with speakerphone and intercom, like all Genuine BELL® products, has been designed to give you many years of continuous service and represents the best value for your money. It requires little maintenance and is easy to setup and operate.

OWNER'S MANUAL#39626VER. 10148A-1

PAGE: 0

English version

39626 English I/B version 10148A-1

IMPORTANT SERVICE INFORMATION

Read this manual before attempting to setup or use this instrument. It contains important information regarding safe installation and use. Keep this manual for future reference. Also save the carton, packing and proof of purchase to simplify and accelerate any needed action. If you need assistance or service, call (800) 888-8990 between 8:00 a.m. and 4:30 p.m. Pacific Standard Time, Monday through Friday. You can also visit our web site at: <http://www.nwbphones.com> for technical support and information on our other products.



WARNING


To prevent fire or shock hazard, do not expose this product to rain or any type of excess moisture. If accidentally dropped into water, the AC adapter should immediately be unplugged from the wall along with the telephone line cord.




THIS SYMBOL IS INTENDED TO ALERT THE USER OF THE PRESENCE OF IMPORTANT OPERATING AND MAINTENANCE (SERVICING) INSTRUCTIONS IN THE OWNER'S MANUAL.

39626 English I/B version 10148A-1


CARTON CONTENTS




HANDSET




BASE UNIT




RECHARGEABLE Ni-Cd
BATTERY PACK




AC ADAPTER
(AC9V, 500mA)




TELEPHONE
LINE CORD
(Short & Long)




WALL MOUNT
BRACKET



USER'S MANUAL



WARRANTY CARD



ACCESSORY
ORDER FORM

10148A-1

2

OWNER'S MANUAL#39626VER. 10148A-1

PAGE: 2 English version

39626 English I/B version 10148A-1



SAVE THESE INSTRUCTIONS

IMPORTANT SAFETY INSTRUCTIONS

When using your telephone equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

1. Read and understand all instructions.
2. Follow all warnings and instructions marked on the product.
3. Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.
4. Do not use this product near water, for example, near a bathtub, wash bowl, kitchen sink, or laundry tub, in a wet basement or near a swimming pool.
5. Do not place this product on an unstable cart, stand, or table. The product may fall, causing serious damage to the product.
6. Slots and openings in the cabinet at the back or bottom are provided for ventilation, to protect it from overheating. These openings should never be blocked or covered. The openings should never be blocked by placing the product on the bed, sofa, rug, or other similar surface. This product should never be placed near or over a radiator or heat register. This product should not be placed in a built-in installation unless proper ventilation is provided.
7. This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your dealer or local power company.
8. Do not allow anything to rest on the power cord. Do not locate this product where the cord will be abused by persons walking on it.
9. Do not overload wall outlets and extension cords as this can result in the risk of fire or electric shock.
10. Never push objects of any kind into this product through cabinet slots as they may touch dangerous voltage points or short out parts that could result in a risk of fire or electric shock. Never spill liquid of any kind on the product.
11. To reduce the risk of electric shock, do not disassemble this product, but take it to a qualified service contractor when some service or repair work is required. Opening or removing covers may expose you to dangerous voltages or other risks. Incorrect reassembly can cause electric shock when the appliance is subsequently used.
12. Unplug this product from the wall outlet and refer servicing to qualified service personnel under the following conditions:
 - A. When the power supply cord or plug is damaged or frayed.
 - B. If liquid has been spilled into the product.
 - C. If the product has been exposed to rain or water.
 - D. If the product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions. Improper adjustments of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to normal operation.

39626 English I/B version 10148A-1

- E. If the product has been dropped or the cabinet has been damaged.
- F. If the product exhibits a distinctive change in performance.
- 13. Avoid using a telephone (other than a cordless type) during an electrical storm.
There may be a remote risk of electric shock from lightning.
- 14. Do not use the telephone to report a gas leak in the vicinity of the leak.

BATTERY SAFETY INSTRUCTION



CAUTION :

To reduce the risk of fire or injury to persons, read and follow these instructions:

1. Use only the following type and size of battery pack:
 - a. For Handset:
 - Cordless Telephone Battery Pack
 - DC3.6V, 600mAh, Ni-Cd Battery Pack
 - Model No.: NT60AAS3BML
 - b. For Base Unit:
 - 1.5V Carbon Zinc or Alkaline, AAA size Batteries (4 Pieces)
2. Do not dispose of the battery in a fire. The cell may explode. Check with local codes for possible special disposal instructions.
3. Do not open or mutilate the battery. Released electrolyte is corrosive and may cause damage to the eyes or skin. It may be toxic if swallowed.
4. Exercise care in handling the battery in order not to short the battery with conducting material such as rings, bracelets and keys. The battery or conductor may overheat and cause burns.
- 5a. For the Handset: Recharge only the battery provided with or identified for use with this product. The battery may leak corrosive electrolyte or explode if it is not the correct type.
- 5b. For the Base Unit: Do not attempt to recharge the battery identified for use with this product. The battery may leak corrosive electrolyte or explode.
6. Do not attempt to rejuvenate the battery provided with or identified for use with this product by heating them. Sudden release of the battery electrolyte may occur causing burns or irritation to eyes or skin.
7. When inserting the batteries into this product, the proper polarity or direction must be observed. Reverse insertion of batteries can cause charging that may result in leakage or explosion.
8. Remove the batteries from this product if the product will not be used for a long period of time (several months or more) since during this time the battery could leak in the product.
9. Discard "dead" batteries as soon as possible since "dead" batteries are more likely to leak in a product.

39625 English I/B version 10148A-1

10. Do not store this product, or the battery provided with or identified for use with this product, in high-temperature areas. Batteries that are stored in a freezer or refrigerator for the purpose of extending shelf life should be stabilized at room temperature prior to use after cold storage.
11. Disconnect telephone lines before installing batteries.
12. For the Base Unit: Charge the batteries provided with or identified for use with this product only in accordance with the instructions and limitations specified in this manual.
13. For the Base Unit: Observe proper polarity orientation between the batteries and battery charger.

SAVE THESE INSTRUCTIONS



INSTALLATION PRECAUTIONS

1. Never install telephone wiring during a lightning storm.
2. Never install telephone jacks in wet locations unless the jack is specifically designed for wet locations.
3. Never touch uninsulated telephone wires or terminals unless the telephone line has been disconnected at the network interface.
4. Use caution when installing or modifying telephone lines.



FCC NOTICE

The FCC requires that you be advised of certain requirements involving the use of this telephone.

1. This telephone is Hearing Aid Compatible.
2. This equipment complies with Part 68 of the FCC rules. On the bottom of this equipment is a label that contains, among other information, the FCC registration number and Ringer Equivalence Number (REN) for this equipment. If requested, provide this information to your telephone company.
3. The REN is useful to determine the quantity of devices you may connect to your telephone line and still have all of those devices ring when your number is called. In most, but not all areas, the sum of the RENs of all devices should not exceed five (5.0). To be certain of the number of devices that you may connect to your line, as determined by the REN, you should call your local telephone company to determine the maximum REN for your calling area.
4. If your telephone causes harm to the telephone network, the telephone company may discontinue your service temporarily. If possible, they will notify you in advance. But if advance notice is not practical, you will be notified as soon as possible. You will be advised of your right to file a complaint with the FCC.

39626 English I/B version 10148A-1

5. Your telephone company may make changes to its facilities, equipment, operations or procedures that could affect the proper operation of your equipment. If they do, you will be given advance notice so as to give you an opportunity to maintain uninterrupted service.
6. If you experience trouble with the telephone, please contact VTC Service & Manufacturing Co., Inc. at (800) 888- 8990 or write to: VTC Customer Service, 16988 Gale Ave., City of Industry, CA 91745 for repair/warranty information. The telephone company may ask you to disconnect this equipment from the network until the problem has been corrected or you are sure that the equipment is not malfunctioning.
7. This equipment may not be used on coin service provided by the telephone company. Connection to party line service is subject to state tariffs. (Contact your state public utility commission or corporation commission for information).
8. **WARNING:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found, comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in residential installation. This equipment generates, uses and can radiate radio frequency energy. If not install and used in accordance with the instruction, may cause harmful interference to radio communications. However, there is no guarantee that interference will no occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measure:

- Reorient and relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver needed.
- Consult the dealer of an experienced radio / TV technician for help.

Some cordless phones operate at frequencies that may cause interference to nearby TVs and VCRs; To minimize or prevent such interference, the base of the cordless phone should not be placed near or on top of a TV or VCR. If interference is experienced, moving the cordless telephone farther away from the TV or VCR will often reduce or eliminate the interference.

Changes or modifications not expressly approved in writing by Northwestern Bell Phones may void the user's authority to operate this equipment.

39626 English I/B version 10148A-1

TABLE OF CONTENTS

IMPORTANT SERVICE INFORMATION.....	1
CARTON CONTENTS	2
IMPORTANT SAFETY INSTRUCTIONS	3
BATTERY SAFETY INSTRUCTION.....	4
INSTALLATION PRECAUTIONS.....	5
FCC NOTICE	5
EXCURSION® 39625 CONTROLS DIAGRAM	9
CONTROLS' LOCATION AND FUNCTION.....	10
HANDSET CONTROLS - Cordless Telephone.....	10
HANDSET CONTROLS - Answering System.....	11
BASE UNIT CONTROLS - Cordless Telephone.....	12
BASE UNIT CONTROLS - Answering System.....	13
MOUNTING POSITION	14
DESKTOP USE.....	14
WALL USE.....	14
CONNECTING THE HEADSET.....	15
POWER INSTALLATION.....	15
INITIAL SETUP.....	17
SETTING THE DAY AND TIME.....	17
TONE / PULSE SETTING.....	17
SETTING THE BASE UNIT RINGER ON / OFF.....	18
TELEPHONE OPERATION.....	18
TO PLACE A CALL USING THE HANDSET.....	18
TO PLACE A CALL USING THE BASE UNIT.....	18
TO RECEIVE A CALL USING THE HANDSET	18
TO RECEIVE A CALL USING THE BASE UNIT	18
HANDSET LAST NUMBER REDIAL.....	19
BASE LAST NUMBER REDIAL.....	19
MEMORY DIALING (10 - Memory).....	19
MIXED MODE DIALING.....	20
PAUSE FUNCTION.....	20
FLASH FUNCTION.....	20
CHANNEL SELECTION (60 Channels).....	20
OUT OF RANGE WARNING.....	21
LOW BATTERY WARNING.....	21
PAGING FUNCTION.....	21
INTERCOM FUNCTION.....	21

39626 English I/B version 10148A-1

ANSWERING MACHINE OPERATION.....	22
VOICE MENU SYSTEM.....	22
TIME / DAY STAMP.....	23
SETTING ANSWER ON / OFF.....	23
SETTING THE RINGS SWITCH (2 / 4 / TS).....	23
SETTING THE ICM REC SWITCH.....	23
MAILBOXES	24
OUTGOING MESSAGES (OGMs).....	24
RECORDING THE OGM.....	25
CHANGING THE OGMs.....	25
CHECKING THE OGMs.....	26
RECORDING A MEMO.....	26
PLAYING BACK MESSAGES / MEMOS.....	26
ERASING MESSAGES.....	27
MEMORY FULL DETECTION	27
CALL SCREENING / AUTO DISCONNECT.....	28
TWO - WAY RECORDING.....	28
VOX (VOICE ACTIVATED) DETECTION.....	28
REMOTE OPERATION	29
USING THE REMOTE OPERATION FUNCTION.....	29
REMOTE COMMANDS.....	29
Voice Help Menu.....	29
Stop Function.....	30
Changing the Password.....	30
Setting the Day and Time.....	30
Setting the Answer Mode to On.....	30
Setting the Answer Mode to Off.....	30
OGM Recording.....	30
OGM Playback.....	31
Recording a MEMO.....	31
Play Messages / Memos.....	31
Playback Options.....	32
Room Monitoring.....	32
IMPROVING CORDLESS RECEPTION.....	33
MAXIMIZING BATTERY LIFE.....	33
MAINTENANCE.....	33
TROUBLESHOOTING.....	34
TECHNICAL INFORMATION	36
GLOSSARY.....	37

10148A-1


8

OWNER'S MANUAL#39626VER. 10148A-1


PAGE: 8 English version

39626 English I/B version 10148A-1


EXCURSION® 39626 CONTROLS DIAGRAM




BASE UNIT (Rear View)



BASE UNIT (Side View)



CONTROLS' LOCATION AND FUNCTION



(Figure 1)

HANDSET CONTROLS - Cordless Telephone


1. **Antenna**
2. **RING ON / RING OFF Switch:** Turns the handset ringer ON or OFF.
3. **TALK Button:** Press to answer an incoming call or to place a call. Press to end a call.
4. **INTCOM (Intercom) Button:** This button allows a two-way conversation with another person at the base unit.
5. **MEMO (Memory) Button:** Used to store up to 10 telephone numbers into memory and you can then dial any of the stored phone numbers.
6. **TONE (*) Button:** Used to temporarily change the dialing mode from pulse to tone for rotary service user. Provides tone function to access special services such as phone banking services.
7. **FLASH Button:** Momentarily hangs up the phone to regain dial tone or access custom calling features such as Call Waiting or Three- Way Calling provided by your local phone company.
8. **RE/PA (Redial / Pause) Button:** Automatically dials the last number called up to 32 digits. Also used to insert a four-second delay in the dialing sequence. (For use in PABX or long distance services.)
9. **SCAN Button:** Allows you to change channels if the current channel is noisy or having interference from other sources.
10. **Charge Contacts:** Used for charging the handset battery.

39626 English I/B version 10148A-1

11. **Microphone:** Used for speaking with callers, recording OGMs and memo messages remotely.
12. **Headset Jack:** For headset connection at hands free conversation.
13. **VOL (Volume) Button:** Allows you to select the handset volume to either low or high.
14. **IN USE / BATT LOW LED Indicator:** Flashes when an incoming call is received and during intercom conversation. During TALK mode, this LED indicator remains lit steadily. The BATT LOW LED blinks when the handset battery power is low.
15. **Retainer Slot:** It allows the handset to hang on the base unit.
16. **Receiver:** Allows you to hear calls, messages, and the voice menu prompts from the handset.

HANDSET CONTROLS - Answering System


1. **PASSWORD Button:** Press to change password for remote operation.
2. **MEMO REC Button:** Press to record MEMO in mailboxes.
3. **REC OGM Button:** Press to record outgoing messages (OGMs).
4. **PLAY Button:** Press to playback messages.
5. **PREV Button:** Press to skip to the previous message during playback.
6. **STOP Button:** Press to stop current activity.
7. **REMOTE Button:** Allows you to access most of the Excursion's functions away from the base unit using the handset.



(Figure 2)

8. **ERASE Button:** Press to erase messages.
9. **OGM Button:** Press to playback outgoing messages (OGMs).
10. **RPT Button:** Press to repeat the message being played.
11. **ANS. OFF Button:** Press to deactivate answer function.
12. **HELP Button:** Press to access voice help menu.
13. **SKIP Button:** Press to skip to the next messages during playback.
14. **ANS. ON Button:** Press to activate answer function.
15. **MONITOR Button:** Press to listen to the surrounding where the base is located.
16. **TIME / DAY Button:** Press to set the day and time stamp.

39626 English I/B version 10148A-1




(Figure 3)

BASE UNIT CONTROLS - Cordless Telephone

1. **9VAC Adapter Jack:** A jack located on the rear side of the base unit used for connecting the AC adapter to the base unit.
2. **TEL LINE Jack:** Accepts line cord to make connection with modular type telephone outlet.
3. **ICM REC (NORMAL / ANNC ONLY) Switch:** NORMAL setting allows callers to leave messages up to two minutes each. ANNC ONLY setting announces OGM only, and will hang up unless caller enters a password within seven seconds.
4. **RINGS Switch:** Selects the number of rings before the Excursion® 39625 automatically answers the call and used to activate the Toll Saver (TS) feature.
5. **RINGER OFF / ON Switch:** Turns the base ringer ON or OFF.
6. **TONE / PULSE Switch:** Allows you to select the appropriate dialing service. TONE for tone dialing or PULSE for rotary service.
7. **Telephone Keypad:** Allows you to make a call depending on pressed button during speaker phone mode.
8. **Charge Terminals:** Used for charging handset battery.
9. **VOLUME (LOW / HIGH) Control:** Adjusts the base unit speaker volume level.
10. **Microphone:** Used to receive an audio signals during conversation at intercom and speakerphone mode and during recording at answering system mode.
11. **SPK (Speakerphone) Button:** Press for hands-free telephone conversion and dialing from base unit.
12. **REDIAL Button:** Automatically dials the last number called.
13. **FLASH Button:** Momentarily hangs up the phone to regain dial tone or to access custom calling features such as Call Waiting or Three-Way Calling provided by your local phone company.

39626 English I/B version 10148A-1

14. **PAUSE Button:** Used to insert a four-second delay in the dialing sequence (For use in PABX on long distance service).
15. **INT(Intercom) Button:** Allows a two-way conversation with another person at the handset unit. Press to page the handset.
16. **MEMORY Button:** Used to store up to 10 telephone numbers into memory or to call any of the stored phone numbers.
17. **TONE(*) Button:** Used to temporarily change the dialing mode from pulse to tone rotary service user. Provides tone function to access special services such as phone banking services.
18. **Antenna :** Raise for better reception.
19. **CHARGE LED Indicator:** Lights up steadily when the handset is being charged on the base .
20. **IN USE / BATT LOW / INTCOM LED Indicator:** Lights up steadily when the phone is being used and when at intercom mode. Flashes when paging the handset and likewise, when the back-up battery power is low.
21. **Retainer Tab:** Allows the handset to hang on the base unit at wall mount position.



(Figure 4)

BASE UNIT CONTROLS - Answering System

1. **MAIL 1, MAIL 2 LED Indicators:** Lights up to indicate the presence of message(s) and flashes to indicate it is active and ready to operate.
2. **MESSAGE CENTER LED Indicator:** Lights up to indicate that there is message(s) on the message center. Flashes to indicate it is active and ready to operate.
3. **MAIL 1, MAIL 2 Buttons:** Press to play the message(s) on the desired mailbox. Press and hold to record the outgoing message (OGM) on the selected mailbox.
4. **REPEAT Button:** Replays the current message playing.
5. **PREV Button:** Press to skip to the previous message during playback.
6. **MEMO REC Button:** Press to record MEMO in mailboxes.
7. **REC OGM Button:** Records and plays the outgoing message which the callers hear upon dialing the Excursion® 39625.
8. **ANS. OFF Button:** Press to deactivate answer function.
9. **ERASE Button:** Allows you to erase a single message or all messages in order to conserve message space in memory.
10. **ANS. ON Button:** Press to activate answer function.

39626 English I/B version 10148A-1


11. **SKIP Button:** Skips current message playback forward to the next message.
12. **MESSAGE CENTER / PLAY Button:** Press to play the message(s) on the message center.
13. **Digital LED Display:** A two-digit LED display to indicate the number of messages and system status. Also displays the current channel number while in TALK mode.

Code	Function
00-59	Message / Timer count
--	Answer OFF
1r	Memo Recording
2r	Two-way Recording
Ao	Answer Only
An	Answer Calls
SP	Speakerphone Mode
In	Intercom Mode
rc	Remote Control
FU	Memory Full
ER	Erasing Message
OP	OGM Playback

MOUNTING POSITION

DESKTOP USE:

1. Install and attach the wall mount bracket onto the bottom of the base at the position as shown in Figure 5.
2. Connect the telephone line cord to the TEL LINE jack on the rear of the base unit and connect the opposite end to the telephone modular jack.




(Figure 5)

WALL USE :

A. WITH A STANDARD AT&T OR GTE MODULAR WALL JACK

1. Install the wall mount bracket at the position as shown in Figure 6.
2. Connect the short telephone line cord to the TEL LINE jack on rear of the base unit.
3. Connect the opposite end of the telephone line cord to the modular wall jack.
4. Align the wall mounting slots with the studs located on the modular wall plate and slide the base down to lock in place.



(Figure 6)


39626 English I/B version 10148A-1

NOTE: If you do not have a standard modular wall jack, find a qualified technician to mount one on the wall.

B. WALL MOUNTING (No Standard Wall Jack)

Drill two holes with a vertical distance between the two marked positions of $3\frac{15}{16}$ " (100 mm) as shown in Figure 7.


1. Drive a screw into each of the holes. Tighten them to the end of the screw line, only leaving the smooth part of the screw head outside the wall.
2. Hang the unit onto the screws, then slide it down firmly to fasten the base securely.



(Figure 7)

BELT CLIP INSTRUCTION


- Clamp the belt clip at the back of the handset as shown in Figure 8.



(Figure 8)

CONNECTING THE HEADSET

For hands free conversation, a headset (not included) is connected to the headset jack as shown in Figure 9. The handset receiver and microphone are disabled when the headset is connected.



(Figure 9)

Press the TALK button or appropriate line to answer or place a call using the headset. Refer to the manufacturer's headset manual for more details.


POWER INSTALLATION BASE UNIT POWER CONNECTION



CAUTION:

You must use a Class II, 120 VAC Input / 9VAC Output adapter that delivers at least 500 milliampere. The plug must correctly fit the machine's AC adapter jack.

1. Plug the AC adapter into a standard AC outlet.
2. Insert the small plug into the AC adapter jack on the rear of the base as shown in Figure 10. Upon power-up, the digital LED display will show "--". After 10 seconds, three tones will be emitted and announce: *"Answering machine is on. Please change the time and record your announcement."*



(Figure 10)


BATTERY INSTALLATION (Handset)



CAUTION:

Use only the Nickel Cadmium (Ni-Cd) battery type included with this unit. Use of other battery type may cause injuries or damage.

1. Remove the battery compartment cover of the handset.
2. Connect the rechargeable Ni-Cd battery as shown on Figure 11.



(Figure 11)


39626 English I/B version 10148A-1

3. Insert the Ni-Cd battery into the battery compartment of the handset.
4. Slide the battery compartment cover firmly in its closed position.

BATTERY INSTALLATION (Base Unit)

1. Using a screwdriver, remove the screw securing the battery cover.
2. Remove the battery compartment cover of the base unit.
3. Connect 4 AAA size 1.5V alkaline batteries (not included) into the battery compartment .
4. Screw back the cover of the battery compartment.

NOTE: The 4 AAA 1.5V alkaline batteries serve as the backup power for saving messages and system settings in the event of a power failure.




(Figure 12)

INITIAL SETUP

Before you can use your cordless telephone, the handset must be charged for at least 12 hours. See charging instruction on MAXIMIZING BATTERY LIFE section of this manual.

SETTING THE DAY AND TIME

1. After 12 hours, remove the handset from the base unit.
2. Press the REMOTE button on the handset. The Excursion® 39625 will prompt "You have no new message. For help, press 9," followed by a long beep. (Figure 13)
3. Press 2. The unit will announce the default setting of day "Monday" and time "12 A.M.". The unit will prompt "Please enter new day:"
4. After hearing a long beep, enter the new day (Monday = 1, Tuesday =2, Wednesday =3, etc.). The unit will then prompt "Please enter new time:"
5. After hearing a long beep, enter the new hour (01-12).
6. After two beeps, enter the new minute (00-59).
7. After two beeps, press * for AM, or press # for PM. The unit will announce the new day and time followed by a long beep and will prompt "Please enter the next command".



(Figure 13)

39626 English I/B version 10148A-1

B. IF THE HANDSET IS OUT OF THE BASE

1. Press the TALK button on the handset. The unit will scan for a clear channel until the IN USE LED indicator lights up.
2. Start your conversation.
3. To end your conversation, either press the TALK button or place the handset on the base unit. The base IN USE LED indicator will turn off.


TO RECEIVE A CALL USING THE BASE UNIT

1. When the phone rings, press the SPK button. The Digital Display will show "SP."
2. Start your conversation.
3. To end your conversation, press SPK button again.

HANDSET LAST NUMBER REDIAL

A. AFTER HEARING A BUSY TONE WHEN PLACING A CALL

1. If you get a busy tone, press handset TALK button to hang up.
2. Press the handset TALK button again and listen for a dial tone.
3. Press the handset RE/PA button. This will automatically redial the last telephone number you called (Up to 32 digits).




(Figure 18)

B. WHEN THE HANDSET IS AT CHARGING MODE OR STANDBY MODE

1. Press the TALK button on the handset and listen for a dial tone.
2. Press the RE/PA button. This will automatically redial the last telephone number you called (Up to 32 digits).

BASE LAST NUMBER REDIAL

1. If you get a busy tone, press SPK button to hang up.
2. Press the SPK button again and listen for a dial tone.
3. Press REDIAL button. This will automatically redial the last telephone number you called (Up to 32 digits).




(Figure 19)

MEMORY DIALING (10-Memory)

You can store up to 10 telephone numbers (up to 16 digits each) into memory and you can then dial any of the stored phone numbers.

A. STORING TELEPHONE NUMBERS INTO MEMORY FROM THE HANDSET

1. Make sure that the handset is in the standby mode. The base and handset IN USE / BATT LOW LED indicator should be OFF.
2. Press and release the MEMO button. The handset will beep once.
3. Enter the telephone number you want to store (maximum of 16 digits). A key tone is heard for every key pressed.
4. Press the MEMO button once again.
5. Press a number (0 through 9) where you want to store the phone number. You will hear a long beep to confirm that the number was properly stored.
6. Repeat procedures 1 to 5 to store other telephone numbers.



(Figure 20)


39626 English I/B version 10148A-1

- Press the REMOTE button to exit the REMOTE mode. Otherwise, the REMOTE function will turn off automatically indicated by three beeps and will prompt "End of remote" if not in use for 10 seconds.

tone / PULSE SETTING


Select the appropriate dialing service by moving the TONE/PULSE switch on the side of the base unit:

- TONE for Tone service, or
- PULSE for Rotary service.



SETTING THE BASE UNIT RINGER ON / OFF


- Set the ringer switch at the side of the base unit to "OFF" position. The ringer is deactivated. The base will not ring while receiving an incoming call.
- Set the ringer switch to "ON" position. The ringer is activated. The unit will ring while receiving an incoming call.



TELEPHONE OPERATION


TO PLACE A CALL USING THE HANDSET

- Press the TALK button on the handset. The handset IN USE / BATT LOW LED indicator will flash while the unit auto-scans and will light steadily when it finds a clear channel. The base IN USE LED indicator will also light steadily when the handset is in use.
- Listen for a dial tone.
- Dial the telephone number.
- When finished with your call, press the talk button or place the handset on the base unit. The base IN USE indicator will turn off.



TO PLACE A CALL USING THE BASE UNIT

- Press the SPK button on the base unit. The Digital LED Display will show "SP.".
- Listen for a dial tone.
- Dial the telephone number.
- When finished with your call, press the SPK button again.



TO RECEIVE A CALL USING THE HANDSET

NOTE: If you are expecting an incoming calls, the RINGER OFF / ON switch on the handset and base must be set to RING ON position.


A. IF THE HANDSET IS ON THE BASE

- Since the Excursion® 39625 features "Auto-Answer," simply pick up the handset from the base cradle when the phone rings. The IN USE LED indicator will turn on.
- Start your conversation.
- To end your conversation, either press the TALK button or place the handset on the base unit. The base IN USE LED indicator will turn off.

39626 English I/B version 10148A-1

B. STORING TELEPHONE NUMBERS INTO MEMORY FROM THE BASE UNIT

1. Make sure that the base unit is in the standby mode. The base and handset IN USE / BATT LOW LED indicator should be OFF.
2. Press and release the MEMORY button. The base unit will beep once.
3. Enter the telephone number you want to store (maximum of 16 digits). A key tone is heard for every key pressed.
4. Press the MEMORY button once again.
5. Press a number (0 through 9) where you want to store the phone number. You will hear a long beep to confirm that the number was properly stored.
6. Repeat procedures 1 to 5 to store other telephone numbers.



(Figure 21)

C. RECALLING A TELEPHONE NUMBER FROM MEMORY ON HANDSET

1. Press the TALK button.
2. Press the MEMO button.
3. Select and press one of the keypad buttons (0 to 9). The stored telephone number will be dialed automatically.

D. RECALLING A TELEPHONE NUMBER FROM MEMORY ON BASE UNIT

1. Press the SPK button on the base unit.
2. Press the MEMORY button on the base unit.
3. Select and press one of the keypad buttons (0 to 9). The stored telephone number will be dialed automatically.

E. CHANGING STORED PHONE NUMBERS

- Follow the steps described in "Storing Telephone Numbers into Memory." The new phone number will automatically replace the previous one.

MIXED MODE DIALING (Temporary Pulse to Tone Dialing)

1. If you only have pulse (rotary dialing) service in your area and want to access Tone services (Bank by Phone, etc.), ensure that the Tone / Pulse switch is set to the Pulse position.
2. Press the TONE (*) button once to switch from Pulse to Tone dialing temporarily. Pulse dialing mode resumes when the call is ended.

PAUSE FUNCTION

- In some cases, such as PABX or long distance service, a pause may be needed in the dialing sequence. Pressing the handset RE/PA button or base PAUSE button inserts a four-second delay between dialed numbers.
- Each four-second pause occupies one digit of the available 16 digits per memory location.

FLASH FUNCTION

- Used to access custom calling features such as Call Waiting or Three-Way Calling provided by your local phone company. Flash can also be used to restore a dial tone to make a new call.