

|                                   |                                       |      |
|-----------------------------------|---------------------------------------|------|
| Document No.<br><b>5AX000XX00</b> | Title<br><b>Product Specification</b> | Page |
| Background                        | <b>Passive Entry System</b>           |      |

## 1.Preface

This document describes the requirements and operation of the Passive Entry System. However, this document is especially for the Entry system ECU (acronym for Electric Control Unit) and the FOB.

The FOB consists the following functionality for passive access and active access:

- Door unlocking / locking (however, only for request by means of switch operation)
- Trunk unlocking / locking (however, only for request by means of switch operation)
- LF decoding
- RF encoding
- Communication data encryption (cryptograph, anti-collision, rolling code and stuff)

And the entry system ECU consists of the following functionality:

- Door unlocking / locking
- Trunk unlocking / locking
- Engine start (/ stop)
- LF encoding
- RF encoding
- Communication data encryption (cryptograph, anti-collision, rolling code and stuff)
- LF antenna unit control
- Communication with the node ECUs connected to the body bus (e.g. CAN, J1850, customer dependent bus)

As a further function, both the FOB and the entry system ECU provides the following function:

- Learning mode for programming the manufacturing data and stuff
- Data locking and password protection
- Diagnostic (based upon ISO9141 if required)

|                                   |                                       |      |
|-----------------------------------|---------------------------------------|------|
| Document No.<br><b>5AX000XX00</b> | Title<br><b>Product Specification</b> | Page |
| Background                        | <b>Passive Entry System</b>           |      |

## 2.Passive Access Entry Functionality


A proximity sensor located on, for example the door handles, mirrors and trunk lid will be used for proximity check if user is in neighborhood of the vehicle. The switch input will trigger for unlocking and open the doors and trunk.



**Figure 1**

### 2.1.Door Unlocking

- User pull / touch the door handle (sensing of door handle switch).
- ECU sends LF-challenge via exterior antenna.
- FOB sends RF-response to the ECU.
- Door unlocking status is engaged.
- Doors are opened.



**Figure 2**

|                                   |                                       |      |
|-----------------------------------|---------------------------------------|------|
| Document No.<br><b>5AX000XX00</b> | Title<br><b>Product Specification</b> | Page |
| Background                        | <b>Passive Entry System</b>           |      |

## 2.2.Engine Start

- User pushes / operate the engine start button / knob.
- ECU sends LF-challenge via interior antenna.
- FOB sends RF-response to the ECU.
- Immobilizer ECU receives and authorize the response.
- Engine controller ECU receives the authorization for engine strat.
- Start the engine.



**Figure 3**

## 2.3.Engine Stop

- User pushes / operate the engine stop button / knob.
- ECU communicates with the other ECU for engine start request.
- Engine controller ECU receives the request.
- Stop the engine



**Figure 4**

|                                   |                                       |      |
|-----------------------------------|---------------------------------------|------|
| Document No.<br><b>5AX000XX00</b> | Title<br><b>Product Specification</b> | Page |
| Background                        | <b>Passive Entry System</b>           |      |

#### **2.4.Door Locking (Push switch)**

- User closes the door and pushes the switch (sensing of door locking switch).
- ECU sends LF-challenge via exterior antenna.
- FOB sends RF-response to the ECU.
- Door locking status is engaged.
- Doors are locked.
- (Indicates the door locking status by means of Flasher / Buzzer or stuff)



**Figure 5**

|                                   |                                       |      |
|-----------------------------------|---------------------------------------|------|
| Document No.<br><b>5AX000XX00</b> | Title<br><b>Product Specification</b> | Page |
| Background                        | <b>Passive Entry System</b>           |      |

### **3.Active Access Entry Functionality**

#### **3.1.Door Unlocking**

Same functionality as the current one.

#### **3.2.Engine Start**

This function does not effect on the active entry system.

#### **3.3.Engine Stop**

This function does not have influencei on the active entry system.


#### **3.4.Door Locking**

Same functionality as the current one.

|                                   |                                       |      |
|-----------------------------------|---------------------------------------|------|
| Document No.<br><b>5AX000XX00</b> | Title<br><b>Product Specification</b> | Page |
| Background                        | <b>Passive Entry System</b>           |      |


## 4.Entry System Options

### 4.1.System Schematic




## 4.2.Modules

### 4.2.1.FOB ECU



### 4.2.2.Entry System ECU




|                                   |                                       |      |
|-----------------------------------|---------------------------------------|------|
| Document No.<br><b>5AX000XX00</b> | Title<br><b>Product Specification</b> | Page |
| Background                        | <b>Passive Entry System</b>           |      |

## 5.System Characteristics

### 5.1.Antenna Areas

Exterior operating range: 0.8m to 1.5m  
 Interior operating range: Only inside the car

Number of the exterior excitors : max. 5 (min. 2), however, it is depending on the type of the vehicle.  
 Number of the interior excitors: 1 (1-Dimension) or 2 (2-Dimension required)



**Figure 6**

Exterior antenna functionality:

- Unlock / lock doors and trunk.
- Activate / deactivate alarm system.
- Activate immobilizer


Interior antenna functionality:

- Deactivate immobilizer
- Engine start

|                                   |                                       |      |
|-----------------------------------|---------------------------------------|------|
| Document No.<br><b>5AX000XX00</b> | Title<br><b>Product Specification</b> | Page |
| Background                        | <b>Passive Entry System</b>           |      |

## 5.2.Exciter Locations

Exterior exciters: 2 doors and 1 trunk  
Interior exciters: 1 driver's sheet  
2 column / shift lever (X-Y 2-Dimension)



**Figure 7**


Antenna location can be different among of type of the vehicle (e.g. coupe, sedan, mini and stuff).

|                                   |                                       |      |
|-----------------------------------|---------------------------------------|------|
| Document No.<br><b>5AX000XX00</b> | Title<br><b>Product Specification</b> | Page |
| Background                        | <b>Passive Entry System</b>           |      |

### 5.3.Switch Input Locations (Door handle, Touch sensor)

There are some kind of sensors, for instance the door handle contact switch and touch sensor, will be used as a triggering for unlocking and open the door.

Switch inputs: 2 doors and 1 trunk



**Figure 8**

Switch inputs can be different among of type of the vehicle (e.g. coupe, sedan, mini and stuff).

|                                   |                                       |      |
|-----------------------------------|---------------------------------------|------|
| Document No.<br><b>5AX000XX00</b> | Title<br><b>Product Specification</b> | Page |
| Background                        | <b>Passive Entry System</b>           |      |

## 6. Electrical Characteristics

### 6.1. FOB

- ASK / FSK modulation
- Operating supply voltage 2.1V to 4.0V (3.0V Battery)
- Operating supply current < 7mA
- Stand-by current < 10.0uA
- Operating ambient temperature -20°C to +60°C
- Antenna direction 3-Dimension (X, Y, Z), to be considered
- Battery life 2 Years (Low battery indication is considered)

### 6.2. Entry System ECU

- Operating supply voltage 10.5V to 16.0V
- Operating supply current < 15mA (20mA to 30mA)
- Stand-by current < 2mA
- Operating ambient temperature -40°C to +85°C

|                                   |                                       |      |
|-----------------------------------|---------------------------------------|------|
| Document No.<br><b>5AX000XX00</b> | Title<br><b>Product Specification</b> | Page |
| Background                        | <b>Passive Entry System</b>           |      |

### **FCC WARNING**

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### **NOTICE**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.