

EXHIBIT H – User Manual (DRAFT COPY)

FCC ID 070-UPP

Phoenix

Counter/Classifier

Field Unit Instruction Manual

Diamond Traffic Products
P.O. Box 1455
76433 Alder Street
Oakridge, OR 97463

Version: 2.12 & 2.21

Revised: 12/22/95

Table of Contents

I. Introduction	1
I.a. How To Use This Manual	2
I.b. Communication With The Phoenix	2
I.c. System Components	3
I.d. Features not available from the keypad	4
I.e. Loop Board Monitoring	5
I.f. Counter Firmware Configuration	5
II. Modes, Sensors, And How To Use Them.	7
II.a. The Four Basic Storage Modes	7
II.b. Sensors and Sensor Modes.	7
II.c. Raw Storage and Specific Functions	10
II.d. Binned Storage and Specific Functions	12
II.e. Count Storage and Specific Functions	13
II.f. Sensor Storage and Specific Functions	14
III. Hardware	15
III.a. Keypad	15
III.b. LCD Display	16
III.c. Serial Port	16
III.c.1. Using the Phoenix With a Modem	17
III.d. Sensors	19
III.d.1. Road Tubes	19
III.d.2. Inductive Loops	20
III.d.3. Piezo Electric & Resistive Sensors	21
III.d.4. Remote Input	21
IV. Keypad Operation	23
IV.a. How To Use The Menus	23
IV.b. The Two Main Menus	24
IV.b.1. Not Collecting Data Menu	24
IV.b.2. Collecting Data Menu	24

IV.c. Start Collecting	25
IV.c.1. Questions Asked With Any Storage Mode:	25
IV.c.2. Lane Grouping Questions	26
IV.c.3. Questions Asked With Raw Storage Mode	27
IV.c.4. Questions Asked With Binned Storage Mode	28
IV.c.5. Questions Asked With Count Storage Mode	30

Table of Contents (continued...)

IV.c.6. Questions Asked With Sensor Storage Mode	31
IV.c.7. Final Start Questions	31
IV.d. Delete Files	32
IV.e. Show Status	33
IV.f. Test Sensors	34
IV.g. Time of Shut down	36
IV.h. Configure System	36
IV.i. View Lane Totals	38
IV.j. Cold Restart	38
IV.k. Stop Collecting	39
IV.l. Monitor Lanes	39
IV.l.1. Monitoring Raw or Binned Data Collection	39
IV.l.2. Monitoring Count Data Collection	40
IV.l.3. Monitoring Sensor Data Collection	40
V. Keypad Operation Examples.	41
V.a. Configuring the System	42
V.b. Collecting Raw Data	43
V.c. Collecting Binned Data	45
V.d. Collecting Count Data	48
V.e. Collecting Sensor Data	50
V.f. Monitoring Traffic & Viewing Status	52
V.g. Stopping Collection	54

V.h.	File Deletion	55
V.i.	Collecting Data Using Lane Grouping	56
VI.	TAM Interface.	57
VI.a.	Using TAM Cards	57
VI.b.	Transferring TAM Data to your PC.	58
VI.c.	TAM as extended memory for your counter.	59
VI.d.	Retrieving data from a counter with your TAM	60
	VI.d.1. Copy File To TAM 61	
	VI.d.2. Erase TAM Card 62	
VI.e.	TAM as a counter programmer (Autostart)	62

Table of Contents (continued...)

VII.	In-Day Times	63
VIII.	Call-Back System	65
	Appendix A. Trouble shooting	67
	Appendix B. Memory Usage	68
	Appendix B.1. Raw Data Collection	68
	Appendix B.2. Binned Data Collection.	69
	Appendix B.3. Count Data Collection	70
	Appendix B.4. Sensor Data Collection.	70
	Appendix C. Plugs & Connectors.	71
	Appendix D. Default Bin Tables.	76
	Appendix E. Road Tubes Problems & Solutions.	78
	Appendix E.1. Missed Axles	78
	Appendix E.2. Extra Axles	80
	Appendix E.3. Bad Speed and/or Length	81
	Appendix E.4. SnMis (Sensor Miss) for Entire Vehicle	81
	Appendix E.5. One vehicle shown as two	81
	Appendix E.6. Two vehicles shown as one	82

Changes to the Phoenix Firmware:

This section documents the differences between the various versions of the Phoenix Counter/Classifiers. If you have used a previous version, you can simply refer to the list of changes below to determine what has changed.

Note that some version numbers are skipped. This happens when a new version is created for R&D or testing purposes and is not released generally to our customers. In addition, a version number might be skipped if it simply fixes some minor bug in the firmware.

■ VERSION 1.00

Initial release of firmware (derived from Unicorn Firmware V1.30).

For the sake of brevity, versions 1.01 to 1.49 have been removed.

■ VERSION 1.50

Added code to support the new Power Imp.

Increase size of TAM Code to 12K (to handle autostarting) and reduced allowable system memory to 16K.

■ VERSION 1.52

Made changes to support revised TAM Card Hardware.

■ VERSION 1.53

Extended delay times when initializing modems. This is done to support slower (and less expensive) modems.

■ VERSION 1.54

Added option to turn off modem initialization. All modems are then treated as dumb modems.

Removed the Alt + 9 option from the counter keypad to set battery warning and offset voltages. This is now done using TrafMan (Alt + F10 from the main linked screen).

■ VERSION 1.55

Added option to scroll display to see other spacings when monitoring Raw or Binned data (use Right or Left arrows from keypad to see other spacings).

Added support of Daylight Savings Adjustment time (set using TrafMan).

Added sensor info to monitor count data enquire so TrafMan can set piezo levels while monitoring count.

■ VERSION 1.58

Changed default modem initialization (second line) so that the &D1 is changed to &D2.

Fixed bug causing lost data when memory became full.

■ VERSION 1.60

Added Pacing Delay & XON/XOFF Support.

Increased size of Site ID from 10 characters to 15 characters.

■ VERSION 1.61

Fixed timing bug created by version 1.60.

■ VERSION 1.62

Fixed modem communication bugs including failure to recognize smart modems, failure to leave the "Setting Modem" screen, and failure to reset the modem properly.

■ VERSION 1.63

Same as version 1.62 except the letter of the version is now reported by TrafMan (instead of just the version number). You DO NOT need to update to version 1.63 if you have version 1.62.

Letter version "z" has also been created which adds In-Day Times (see Appendix F).

■ VERSION 1.64

Adds in the View Lane Totals function to all storage modes (Raw, Binned, Count, & Sensor). Note that you can only view these totals using TrafMan.

■ VERSION 2.00

This is a major new release of the firmware which has the following new features and changes:

- In-Day Times are now part of all versions (see section VII).
- Counter now contains a built in serial number which is included with all data files stored (see section I.d.).
- Fixed problem with hundredths of a second value on Raw and Sensor data.
- Counter now supports Lane Grouping (see section IV.c.2) for Binned and Count data.
- Counter now monitors the loop board(s) and if used and collecting data will check to insure that the loops are functioning. If they are not, then they are automatically restarted and retuned. See section I.e. for more information.
- You can now set the Battery Warning Voltage from the Configure System Option (section IV.h.).
- You can now View Lane Totals from the counter keypad (section IV.I.).
- Counter now has an optional Call-Back system which can make the counter call you up and warn you when one or more lanes goes down. See section VIII for more information.
- Counter program code is now broken up into three parts: EPROM Code, TAM Code, and RAM Code. These three separate programs work together to make the counter operate. See section I.f. for more information on how these three programs work.
- The TAM Interface has been improved to work with more types of TAM cards and has also become more reliable. A bug has been fixed which allows you to overwrite the end of a TAM card.

■ VERSION 2.01

Fixed problem when monitoring Raw or Binned data with TraMan, the length of the vehicle was shown as "= <x>" instead of "Length = <x>" (<x> represents the length value).

■ VERSION 2.02

Fixed problem when SnMis Storage Mode was set to Disabled, the SnMis were still being displayed.

■ VERSION 2.03

Fixed bug with converting SnMis #3 to a vehicle when in Pres-Axle-Pres mode and the SnMis #3 To Vehicle option is enabled.

■ VERSION 2.04

Fixes a problem with Lane Grouping that caused counter to stop collecting data when grouping was enabled and at least two groups were selected.

■ VERSION 2.05

Cold Re starting counter will now also re set the Which Loop Boards Installed value. This allows the user to remotely re-enable loop boards that have shut down.

■ VERSION 2.08

Changed counter so that while loading new TAM or RAM code all external interrupts are disabled. This prevents any corruption of the TAM or RAM code during upload.

Added code to initialize Piezo Sensitivity levels on power up. This prevents the piezos from tripping during the Self Test due to being uninitialized.

Removed all I/O Wait States to speed up data processing.

Added command to allow setting of the Day Light Savings Time Adjust value without having to stop collection first.

■ VERSION 2.10

Fixed bug that occurred when using Pres-Axle-Pres and the SnMis #3 To Vehicle option. Counter will now correctly report the vehicle.

■ VERSION 2.12

See 2.21 description below.

■ VERSION 2.20

This is a major release of the firmware. This version increases the Phoenix counter capability to a full 8 lanes of classification and 16 lanes of count. Because of this, all directional lanes for Raw and Binned data collection are now the actual lane number + 8 (instead of + 4). For example, Lane #1 opposite direction traffic will be stored in Lane #9 (instead of Lane #5). See section II.b for more information on directional traffic.

Other 2.20 Changes:

- Fixed bug that displayed SnMis #25 (or SnMis #/ on counter screen) when using Pres-Axle-Pres or Axle-Pres-Axle mode with directional traffic and the center sensor would be hit without any other sensor. Counter now correctly displays a SnMis #0.

■ VERSION 2.21

This version fixes a bug which causes the counter to fail during file movement in heavy traffic. NOTE: Version 2.12 is also available which has this same fix but without the other 2.20 changes. You do not need 2.21 if you have 2.12.

I. Introduction

Thank you for purchasing Diamond Traffic Products Phoenix Traffic Classifier Field Unit. You have purchased one of the finest traffic classification counter available to day. This manual describes the operation and programming of the Phoenix Field Unit. Please be sure you have read and understood this manual completely before attempting operation.

What is a "Phoenix Field Unit"?

The Phoenix is a data gathering instrument for use in the field. By using the Phoenix and one of several possible combinations of sensors, traffic data and vehicle classification can be recorded and later retrieved. Speed, Length, and Number of Axles are just a few types of data which can be gathered with this use in instrument.

For the unit itself, the welded aluminum case is durable, light, and weather resistant. The interior keypad & display are both sealed to prevent moisture from damaging them. In addition, a rubber seal is installed around the lid to further protect the unit from the weather.

The case also contains a lid securing mechanism and aluminum carrying handle. The right side of the case normally contains two or four Airswitches, a Battery Charger/Solar Input plug, and the Serial Interface plug. Optionally, the right side can also be fitted for loops inputs, piezo inputs, and/or a remote input.

Inside the case is the heart of the unit, the microprocessor. Several electronic printed circuit boards contain the microprocessor, backup battery, charger network, memory, and all other support circuitry for the unit. In addition, the case can contain the boards for any options which are customer ordered, such as Loop Detector Boards, Piezo Boards, TAM Memory Card Interface board, and Expanded Memory.

Some Tips to Prolong the Life of Your Phoenix

- Always dry the unit out completely after removing from the field.
- Always push on the dust caps onto unused plugs.
- Keeping the battery fully charged will prolong its service life. Recharge battery every six weeks when not in use.
- Disconnect the serial interface plug if serial communication is not required. This will substantially prolong battery life.
- Avoid placement of unit in drainage ditches or areas prone to flooding.
- Do not attempt service without qualified personnel. The components of the Phoenix are very static sensitive, and boards can be damaged by improper handling. All hardware is covered in the Phoenix Hardware Manual.

I.a. How To Use This Manual

This manual completely describes the use of the Phoenix. The only thing not covered in this manual is programming & retrieving data from the serial port with a PC Computer. This is covered in the TrafMan Software Instruction Manual.

Do I Have To Read The Whole Manual?

Anybody using a Phoenix should read all of Section I, II, and III of this manual. This will familiarize you with the basic equipment provided, what types of data you can collect, and what type of sensors can be used. From that point there are three methods of operation:

- Method 1 - To operate the Phoenix entirely from its built in key pad.
All setup and configuration can be done from there. A computer and/or TAM must be used to retrieve the data once it has been collected. If this is the method you want to use, first read section IV.a and IV.b, then read Section V for an example which matches your application. Section VI will describe using the TAM interface, if installed.
- Method 2 - To operate the Phoenix only from a computer (using the TrafMan Software).
All setup and configuration can be done from a computer (in addition to retrieving the collected data). If this is the method you want to use, simply refer to the TrafMan Software Manual for more information. Use this field unit manual for clarification and technical information on the Phoenix.
- Method 3 - To operate the Phoenix using both a computer and its built in key board.
This is the most common method since you might not be able to always have a computer with you, and becoming familiar with the keypad operation is always useful. We suggest that you first attempt to run the counter using the built in keypad (first read section IV.a and IV.b then follow the examples in section V.) After collecting some data with the Phoenix, move on to using the TrafMan Software to collect your data. From that point, read through the rest of the TrafMan Software Manual for more information on controlling the counter through a computer.
See section VI for a complete description on using the TAM interface, if installed.

I.b. Communication With The Phoenix

Communicating with the Phoenix is done through the built in Keypad/Display, or through the serial port to an IBM PC compatible computer. A communications software package is normally provided for use with the large variety of IBM PC compatible computers available on the market today. This extensive software package (called the TrafMan Software) allows such advanced features as:

- "Pop-Up" windows and "User-Friendly" menus.
- Complete Database functions with viewing and editing of all collected data.
- XMODEM transfers for data file retrieval, with later file format conversion utilities.
- Data File Print outs with daily and hourly summaries.
- Complete monitoring and configuration.

To learn more about using this program, refer to the TrafMan Software Instruction Manual. Note that Phoenix serial access is not restricted to use with any particular type of computer. Any computer which supports a standard serial communications (RS232) will suffice. The TrafMan Software Disk contains a documentation file for computer programmers for programming from the serial port (SERIAL.DOC).

I.c. System Components

To operate your Phoenix counter/classifier you will need the following:

- Phoenix Field Unit Instruction Manual.
- TrafMan Software Disk & TrafMan Software Instruction Manual.
- A Battery Charger or Solar Charging Panel.
- A Serial Interface Cable.

Optional Items Include:

- A Modem Interface Cable.
- One or more TrafMan Enhancement Modules (such as the TrafPrint Enhancement).
- A Remote Airswitch Cable.
- An Inductive Loop Cable.
- One or more TAM Cards.

Additional Equipment Required To Use The Phoenix Counter:

You must have the following equipment to use the Phoenix. All of this equipment can be purchased from Diamond Traffic Products as well as from several other sources:

- Sensors. You must have the appropriate type and quantity of sensors (Loop, Tube, Piezo, etc.) If using tubes, you will need nails and road tube grips to install road tubes.
- A Computer. Ideally, this would be one of the many IBM-PC type computers available and you could use the TrafMan Software. It is possible to use an other type of computer, but it will require someone with technical knowledge and computer programming skill for the type of computer you wish to use.
- A Modem. This is required if you plan to install the Phoenix in a permanent station where communication over a phone line is required. There are several modems available, each with their own advantages and disadvantages. You MUST purchase a Hayes Compatible Modem. We also recommend a modem that is programmable (sometimes called a Smart Modem). The Phoenix will work with most non-programmable modems as well, but you may not be able to take advantage of some features of the counter. See Section III.c.1 for more information.
In addition, Appendix A of the TT-Link Software Manual contains detailed instructions for using a modem with any of Diamond Traffic Products counters.

I.d. Features not available from the keypad

The Phoenix has several features which are not available directly from the counter keypad. Some of these features only relate to serial port use and therefore are not needed from the keypad. Other features would require too much internal firmware to access and use from the keypad and therefore are only accessible through the serial port.

The following features are available in the Phoenix but can only be set and/or used from the serial port using the TrafMan software package.

■ Data Retrieval

The most important serial counter function, the retrieval of collected data. This is normally done using the TrafMan and/or the Remote software programs. See the appropriate manual for more information.

■ Passwords

The counter allows you to enable/disable password access and to set your own password (the default is "PASS").

■ Modem Initialization

You can customize the initialization string that is sent to the modem. See appendix A of the TT-Link software manual for more information on modem initialization lines.

■ Daylight Savings Time Adjust

You can either manually or automatically have TrafMan set the Phoenix to handle daylight savings time changes. The Phoenix will change the time and adjust data appropriately.

■ TAM Card Reader

As described in Section VI, many functions are available when the counter is configured as a TAM Card Reader.

■ Battery Offset Voltage, SnMis #3 To Vehicle, & No Modem Initialization

These specialized functions, not commonly used, are all accessible from a special TrafMan Hidden Menu which is called up using the Alt + F10 key from the main counter link screen. The counter must not be collecting data to set these functions.

■ XON/XOFF and Pacing Delay

These two specialized modem functions can only be set from TrafMan using the serial port. See appendix A of the TT-Link software manual for more information.

■ In-Day Times

In-Day times are specific time periods inside of a 24 hour period in which you want to collect data, and all other times will be excluded. What this basically does is make the counter create a new data file several times during the day. For example, if you selected two In-Day Times of 0600-1200 and 1600-1800, then the counter would create two files per day, each containing data for the appropriate time period. See section VII for more information on In-Day Times.

■ Counter Serial Number

The counter now contains a built-in firmware serial number. This serial number, usually set by us at the factory, is included with all data files so that which counter collected the data can be easily identified. You can optionally set your own serial number using the Alt + F10 function from the main counter link screen in the TrafMan software.

■ Counter Call-Back

The counter has an optional Call-Back function which allows you to program the counter with a phone number for it to call if a lane should go down. After making the call, the counter will connect to a remote PC running the TT-Link Software and then is sure to report telling you the Site, Time, Date, and Lane(s) which failed. See section VIII for more information on counter Call-Back.

I.e. Loop Board Monitoring

The counter has a built in function to insure that your loop boards do not fail. Basically, when you use loops for data collection, the counter checks every five minutes to see if any loop activations have occurred. If they have not, then the counter goes to a special function which sends a command to the loop board to see if it is responding. If it is not, then the loop board is restarted and all loops are retuned for proper operation.

Why, you may ask, should a loop board ever fail? Generally this is caused by one of two things:

- **Lightning Strike**

Some times if a lightning strike is close enough to the loops in the road a large static charge can be transmitted through the loops into the loop board circuitry. The loop board has several electronic protections against this and it will probably not cause any damage (unless the lightning is very close), it may cause the loop board to lock up or shut down. The loop board monitoring function will detect the loop board failure and will restart the loops between 5 and 10 minutes later.

- **Other Electrical Noise**

Similar to a lightning strike, other sources of strong electronic signals can cause the loop board to have problems. For example, a strong C.B. broadcast from an illegal transmitter. The loop boards in your counter are the best available but it is possible for strong electrical interference to cause premature shutdown. Once again, the loop board monitoring function will detect and correct this occurrence.

Chances are you have not ever experienced any problem with your loop boards. The loop board monitoring function has been added into the firmware to make sure you never do.

I.f. Counter Firmware Configuration

Although not essential to know, it will help you understand your traffic counter if you know how the internal programming works inside your counter. If you are not interested in this information feel free to skip this section.

There are three separate programs which operate inside the Phoenix. The first (and most important one) is the EPROM. This is a physical Integrated Circuit (IC) inside your counter which is programmed by us at the factory and installed in your counter. Whenever you turn the counter on, the microprocessor inside the counter starts running the program contained inside this chip. The very first screen that appears on the display of the counter will show you the name and version number of this EPROM (for example: Phoenix V2.00a).

The EPROM contains all of the really important programming such as the vehicle classification routines and the routines that store data into memory. You may at some time want to perform an upgrade of this EPROM to add new features to your counter or to fix bugs found in the programming of the EPROM. This is done by taking your counter apart, removing the old EPROM, and installing a new EPROM that you get from Diamond.

The second program inside your Phoenix is called the RAM Code. This is an auxiliary program which resides in the changeable memory (called RAM Memory) and is only used when you perform various non-essential tasks such as using the Show Status option or Viewing Lane Totals. The EPROM automatically knows how and when to run this program based upon what options you select.

A copy of the latest RAM Code is always contained in the TrafMan subdirectory on your hard drive of your PC in a file named `RAM.HEX`. Whenever you link to a counter, TrafMan will check to make sure that the version of the RAM Code inside the counter is at least equal to the version of the RAM Code that is contained on disk. If it

is not, then TrafMan automatically upgrades your Phoenix to the latest version. This is much easier than changing EPROMS because it is all done automatically for you without any disassembly.

The third and final program inside your counter is called the TAM Code. This program is only present in machines which have a TAM Card Interface installed. This program is very similar to the RAM Code in that it resides in RAM Memory and can be upgraded by TrafMan whenever you link to the counter. The latest version of the TAM Code is always in your TrafMan directory in a file called `TAM.HEX`.

The TAM Code is used to control all of the functions of the TAM Card Interface. It contains all of the programming to read, write, identify, and erase TAM Cards. It also contains all of the code to turn the counter into a TAM Card Reader (see section VI). A copy of the TAM Code is also contained in the first 12K of every TAM Card. You can instantly update a counter's TAM Code by simply plugging in a TAM Card which has the latest version of the TAM Code on it.

The EPROM knows how and when to use the TAM Code. In most cases you will never be aware when you are in the EPROM, RAM Code, or TAM Code. All three programs work together to provide a seamless and fully functioning traffic counter environment.

II. Modes, Sensors, And How To Use Them

This section of the manual discusses the various ways the Phoenix can collect data, and what type of sensors are required to collect each type of data. Please read this section carefully. The Phoenix is a very sophisticated counter/classifier with many options. Reading and understanding this section first will greatly simplify operation later.

II.a. The Four Basic Storage Modes

Before attempting to use your Phoenix, you should first become familiar with the four fundamental modes of operation. The mode that you select determines the type of data that will be collected, and whether the information will be combined with other entries or stored individually.

- | | |
|--------|---|
| Raw | - This mode will store each individual vehicle in memory as it passes by. The following information about each vehicle can be stored in memory: time, speed, number of axles, spacing between each axle, over all length, and bin classifications. |
| Binned | - This mode is the conventional classifier storage mode. Each vehicle is analyzed and given 5 different bin numbers. Each bin # represents a category the vehicle belongs to. The 5 bins are Axle Class, Speed Class, Length Class, Gap Class, & Headway Class. The parameters for determining what types of vehicles belong to each bin # can be changed by the user, with the most commonly used values being built into the Phoenix. Users specify a time interval, such as every 15 minutes, in which the total number of vehicles for each bin will be stored in memory. |
| Count | - The count mode is one of the simplest modes of operation. It is used when just a vehicle count is desired. When using Tubes or Piezo Sensors, the Phoenix provides the total number of axles detected, optionally divided by two. When using Loops, the Phoenix will give the number of vehicles. Users specify a time interval, such as every hour, in which these total counts will be stored in memory. |
| Sensor | - Sensor mode stores individual sensor pulses into memory with an accurate time stamp. This mode bypasses the Phoenix regular data analysis routines and allows users to get an exact copy of what the counter saw on the roadway. Other software, such as TrafMan, can then be used to analyze this data into other forms as the user requires. |

II.b. Sensors and Sensor Modes

The Phoenix supports Road Tube Airswitches, Inductive Loops, Remote Inputs, Piezo Resistive Inputs, and Piezo Electric Inputs. Road Tubes, Remote Inputs, and Piezo Sensors are considered "axle" sensors, since they are activated by individual axles. Inductive Loops are considered "presence" sensors, since they become active by the presence of a vehicle passing over, and become un-active when the vehicle leaves. The Remote Input will support any type of sensor which will give a momentary switch closure.

Since there are variations with each sensor (for example, Inductive Loops will have slightly different amounts of inductance), the Phoenix performs automatic tuning of all sensors except for Piezo Electric and Piezo Re-

sistive. These the user must tune during setup using the Phoenix Keypad or a PC Computer and the TrafMan software. See section III.d.3. for more information.

When in Raw storage or Binned storage modes, four types of sensor arrangements (sensor modes) may be selected:

- Axle-Axle - Two axle sensors, such as two tubes.
- Pres-Pres - Two presence sensors, such as two loops.
- Axle-Pres-Axle - Two axle sensors and one presence sensor.
- Pres-Axle-Pres - Two presence sensors and one axle sensor.

In Count storage mode, you can select either a Presence Sensor or an Axle Sensor. In Sensor storage mode, you can select either a Presence Sensor, an Axle Sensor, or both.

The way the sensors are divided up among the lanes depends on the storage mode (Raw, Binned, etc.) and the sensor mode (Axle-Axle, Pres-Pres, etc.). Table 1 shows the divisions of the sensors.

Table 1				
Count Storage & Sensor Storage			Raw Storage & Binned Storage	
Lane Number	Axle (Tubes)	Pres (Loops)	Axle (Tubes)	Pres (Loops)
#1	1	1	1 & 2	1 & 2
#2	2	2	3 & 4	3 & 4
#3	3	3	5 & 6	5 & 6
#4	4	4	7 & 8	7 & 8
#5	5	5	n/a	9 & 10
#6	6	6	n/a	11 & 12
#7	7	7	n/a	13 & 14
#8	8	8	n/a	15 & 16
#9	n/a	9	2 & 1 (Directional)	2 & 1 (Directional)
#10	n/a	10	4 & 3 (Directional)	4 & 3 (Directional)
#11	n/a	11	6 & 5 (Directional)	6 & 5 (Directional)
#12	n/a	12	8 & 7 (Directional)	8 & 7 (Directional)
#13	n/a	13	n/a	10 & 9 (Directional)
#14	n/a	14	n/a	12 & 11 (Directional)
#15	n/a	15	n/a	14 & 13 (Directional)
#16	n/a	16	n/a	16 & 15 (Directional)

Sensor and Count modes always use the same lane number as sensor number for input to that lane. Raw and Binned modes will always use two inputs for each lane, with the sensors numbers shown in the table.

Raw and Binned modes are the classification modes, so they can also take advantage of two slightly more complicated sensor modes, "Axle-Pres-Axle" and "Pres-Axle-Pres". The first and last sensors, either the two Axle or the two Pres, are ALWAYS the same as shown in Table 1. The difference comes in the middle sensor.

To increase the capabilities of the Phoenix, the middle sensor used comes from a sensor not normally used with a lane you are configuring. Table 2 shows the configuration for these two modes.

Table 2 - Configuration of Three Sensor Lanes								
Mode	Lane 1	Lane 2	Lane 3	Lane 4	Lane 5	Lane 6	Lane 7	Lane 8
Axle	#1	#3	#5	#7				
Pres	#1	#2	#3	#4	n/a	n/a	n/a	n/a
Axle	#2	#4	#6	#8				
Pres	#1	#3	#5	#7	#9	#11	#13	#15
Axle	#1	#2	#3	#4	#5	#6	#7	#8
Pres	#2	#4	#6	#8	#10	#12	#14	#16

NOTE: The Phoenix currently only supports 8 Axle Sensor inputs so you can not enable Axle-Pres-Axle or Axle-Axle modes for lanes 5-8.

Sensor Conflicts

The system works AS LONG AS THERE IS NEVER ANY CONFLICT BETWEEN LANES FOR SENSORS. This can occur if you use different axle configurations on different lanes and you are using "Axle-Pres-Axle" or "Pres-Axle-Pres" on the higher numbered lane. Still confusing? Hang in there, it gets simpler. Let's try an example.

Example 1: Suppose you selected Pres-Pres for lane #1 and Axle-Pres-Axle for lane #2. According to Table 1 (for lane#1) and Table 2 (for lane#2).

Table 3 - Example 1		
Mode	Lane 1	Lane 2
Pres-Pres	Pres 1, Pres 2	-----
Axle-Pres-Axle	-----	Axle 3, <u>Pres 2</u> , Axle 4

In this case, Pres 2 (underlined) is specified for BOTH lanes 1 and 2!. This situation is referred to as a SENSOR CONFLICT and is automatically detected by the software. If a conflict occurs, the Phoenix will not allow you to start collecting until the conflict is resolved.

Now, for further example, suppose you chose Axle-Pres-Axle for lane #1 and Pres-Pres for lane #2, according to the same tables.

Table 4 - Example 2		
Mode	Lane 1	Lane 2
Axle-Pres-Axle	Axle 1, Pres 1, Axle 2	-----
Pres-Pres	-----	Pres 3, Pres 4

Now, there is no conflict and the system can operate. When the system does detect a sensor conflict with another lane (and note that the higher number lane will always be the lane in conflict, so lane #1 will never be in conflict since it is the lowest lane number), you will receive an error message and the software will not continue operation.

The Phoenix also contains many advanced sensor analysis routines to improve data accuracy, including examining both sets of axle and presence sensors, the tossing out of too short spacings (for example: eliminating a road tube bounce, which can cause a false count), and the determination of missed axles.

II.c. Raw Storage and Specific Functions

In this mode, an individual record is kept for each vehicle encountered. Any combination of one to eight lanes (depending on how many and what type of sensor input boards are installed) can be enabled. If any lane is configured for directional mode (the ability to classify traffic in either direction), an additional lane of traffic data is created. For example, if lane #1 is enabled and is configured in directional mode, the counter would create lane #9 for vehicles traveling in the opposite direction on lane #1.

Physical Lane	Opposite Direction Lane
Lane #1	Lane #9
Lane #2	Lane #10
Lane #3	Lane #11
Lane #4	Lane #12
Lane #5	Lane #13
Lane #6	Lane #14
Lane #7	Lane #15
Lane #8	Lane #16

Note that the directional lane is not an actual separate lane - it is the same physical lane but simply traffic moving in the opposite direction. It is recommended that the directional option be used whenever the possibility of two-way traffic exists, such as a one-lane road or an area on a two-lane highway where there is much passing of slower vehicles, thereby using the oncoming lane.


Four separate modes of Raw storage are available. Lanes are not individually set, all lanes will be in the same mode.

Normal	- This is a straight raw vehicle mode which will store lane number, time, speed, number of axles, and spacing between each axle.
Enhanced	- This data is in the same format as Normal with the exception that speed is now calculated to tenths of a MPH (or KPH) and the overall vehicle length axle is added to the record.
Raw with Bins	- The data is the same as Normal except the Speed, Axle, Length, Gap, and Headway bin numbers are stored with each record. This format does not store the data in binned format, but will tell you which bin a vehicle would have gone into if you were binning.
Enhanced with Bins	- This format is a combination (as the name implies) of Enhanced and Raw with Bins. The data is now Enhanced and stored with the bin numbers.

There is some give and take with the modes. Enhanced Raw will give a more precise records than Normal Raw; however, more memory space is used. The same comment goes for Raw with Bins - more memory to keep track of which bin it would have gone in. Appendix B gives an approximation of the number of vehicles which can be stored in memory depending upon which mode you choose.

While in Raw Storage, the user can select any of the four Sensor Modes (Axle-Axle, Pres-Pres, etc.) for each lane. The system will ask the user for Sensor Spacing and the Loop Length (if using presence). The maximum sensor spacing is 99.9 feet, and the maximum loop length is 25.5 feet.

Raw Storage also supports "Lane Overlap". If axle sensors are used to collect data from two lanes of traffic, the lanes can be configured as shown in the figure below. Note that the shorter tube is in the near lane (lane #1), and is activated first by oncoming traffic. This configuration will allow you to collect data from two lanes using 4 road tubes where one set of tubes crosses both lanes.



As is shown, lane overlap can support lanes which vehicles are going same or opposite direction.

IMPORTANT NOTE: You must make sure that for each road tube pair that the longer tube is always equal to or longer than the shorter tube in the pair when measured from the edge of the pavement closest to the counter. For example, when doing Same Direction road tube 3 (of pair 1 & 3) must be equal to or longer from the edge of the pavement to the counter than road tube 1 is from the edge of the pavement to the counter. The same is true for pairs 2 & 4. In the Opposite Direction, the pairs change to 1 & 4 and 2 & 3 where road tube 4 must be longer from the edge than road tube 1 and road tube 3 must be longer than road tube 2.

Raw data is stored in a straight fashion. As vehicles are detected and the information (speed, length, etc.) is gathered, the data is stored sequentially in memory in one long record. During collection, or during testing, the Phoenix will allow you to monitor any or all lanes.

II.d. Binned Storage and Specific Functions

Binned storage is very similar to Raw storage in that you can have any combination of lanes and each lane can be enabled for directional operation giving additional lanes of directional traffic. Binned Storage supports the same sensor modes and lane configurations.

The difference in the modes is the method of storage. In Raw storage, the Phoenix stores all data in chronological order as the vehicles are detected and data is registered (speed, length, etc.). Binned Storage sorts and classifies the data into separate categories or "bins". The vehicle is then added to the correct Bin #. In this fashion, you can retrieve totals for various types of vehicles.

There are five basic bin types:

- Axle - Data is binned by Number of Axles and Spacing Classification (for example: Scheme-F).
- Speed - Data is binned by the individual vehicles speed.
- Length - Data is binned by the individual vehicles over all length.
- Gap - Data is binned by the distance between vehicles, from the tail of the first to the nose of the second.
- Headway - Binned by the time vehicles are going in the same direction, from the nose of the first to the nose of the second.

Each lane can also be enabled to do two dimensional binning of either "Speed by Length", "Speed by Axle", or both. This modes create a table giving you individual speed bins for each vehicle type or for each vehicle length category.

The bins are compiled over a user specified time length, or "record interval". Up to five separate start times and sampling lengths are available (within a 24 hour period) for use. This allows specific sample periods to be adjusted according to the time of day. An example would be to select 15 minute intervals from 00:00 until 09:00, one hour intervals from 09:00 to 15:00 (3pm), 15 minute intervals from 15:00 to 19:00 (3pm to 7pm), and 1 hour intervals for the remainder of the day.

Each category or "Bin" has been pre-defined as to what it represents. For example, Axle Bin #1 is for motorcycles, Speed Bin #1 is for vehicles traveling between 1 and 19.9 MPH. While these bins have been pre set to be the most common categories, you may change the type and number of bins for each binning mode. See the TrafMan Software Instruction Manual for more information on modifying these bin definitions to your own specific needs.

Binned Storage also supports the "Lane Overlap" function. Refer to the previous section, "Raw Storage and Specific Functions" for a detailed explanation.


II.e. Count Storage and Specific Functions

In Count storage mode, the only information stored is the number of vehicles that have been detected in each lane. Up to 16 lanes are supported (depending on the number and type of sensor input boards installed) in this mode. Normally, each lane will use only one sensor to collect the count. When a Road Tube or Piezo Sensor is used as the lane sensor, the count may be divided by two. Since loop sensors hold presence for the duration of a vehicle, the divide by two option is not used with loops.

Storage of the counts is performed in the same manner as outlined above for Binned data (i.e. using "record intervals").


There are two specialized sensor configurations for Count data when two axle sensors are used (normally road tubes), they are Lane Subtraction and Directional.

Lane Subtraction- This mode is used when you want to get individual lane count from two different lanes of traffic from one side of the road. The road tube attached to Lane 1 (or any other ODD numbered lane) is laid out across both lanes. The road tube attached to Lane 2 (or the next even numbered lane) is laid out across one lane. The Phoenix will subtract the even lane's from the odd lane's count to obtain the proper directional count for the odd numbered lane.



Directional

- This mode is used for counting two-way traffic on a narrow road. A road tube pair (such as 1-2 or 3-4) are laid out across both lanes of a road tube one foot apart. The Phoenix will determine (from the order of activation) the proper directional count for each lane.



You can monitor any or all lanes during collection or testing, with the system showing you the current lane totals for the record interval.

II.f. Sensor Storage and Specific Functions

Sensor Data Storage is a new, extremely flexible mode of storing traffic data. Data is stored sequentially when a sensor is activated, allowing custom software to organize the data in a way tailor made for the user.

Sensor Data Storage stores the simplest form of data. Inside the Phoenix is a timer that counts down (starting from 16,777,216) at the rate of 10.695 kHz (10,695 cycles/second). When this 24-bit timer counts down to zero, it recycles to 16,777,215. At the rate of 10.695KHz, the time it takes to revolve through the counter is 16777215/10695 or about 26 minutes. When a sensor is activated, the counter stores the lane, time, type of sensor, and the timer reading. When the sensor is activated again, it stores the lane, time, type of sensor, and the new timer reading. The counter will store an "A On" for an axle strike, a "P On" for a presence sensor turning on, or a "P Off" for a presence sensor turning off.

Example:

Let's say we have two Presence Sensors in a road, 10 feet from leading edge to leading edge. In the Phoenix, we turn on Lane #1 and Lane #2 and select Pres as the sensor.

A record of strikes might appear as such -

```
1:14:38:56 (3369138) P On
2:14:38:56 (3367017) P On
1:14:38:56 (3366577) P Off
2:14:38:56 (3364057) P Off
```

Now, what this means is that the Presence Sensor in Lane 1 was activated at 14:38:56 (2:38pm + 56 seconds) when the timer was at 3,369,138. Lane 2 was activated with a Presence On when the timer was at 3367017. Lane 1 lost presence of a vehicle when the timer was at 3366577. Lane 2 lost presence of a vehicle when the timer was at 3364057.

The question you might ask now is, "OK, so what's the point?". Well, we know:

- The distance (10 feet)
- The time from activating the first to activating the second, which is $3369138 - 3367017 = 2,121$ timer cycles.

Since we know the timer is running at 10,695 cycles/second, we can divide the number of cycles by the cycles/second rate and get the amount of time, or $2,121/10,695 = .198317$ seconds. Now, since distance = rate X time, then rate = distance/time, or $10 \text{ feet}/.198317 \text{ seconds} = @50.42 \text{ feet/second}$. Using some conversions, this comes out to about 34.4 Mph. (if it's a 25mph zone, someone is speed ing!).

Since you know the loop length, and have calculated the vehicle speed, you could also calculate the length of the vehicle. This is the exact process the Phoenix uses in Binned and Raw modes.

If you were using tubes, you could calculate speed, number of axles, axle length between individual axles, and over all axle length. Combine the two (use the option of Axle-Pres-Axle or Pres-Axle-Pres) and you can calculate everything the tubes can plus over all vehicle length. Quite a bit of information from a few timer counts.

As with the other storage modes, during testing or collection you can monitor any or all lanes.

III. Hardware

This section describes the hardware components associated with the Phoenix system.

III.a. Keypad

The Phoenix contains a built-in 16-key keypad. With this keypad and the built-in LCD display (section III.b.) you can completely program and operate the Phoenix.

When the ALT key is held down while you are pressing an other key, an alternate set of keys is available to the user. The table below shows the alternate keys.

Table 1 - Alternate Keypad Entry												
	0	1	2	3	4	5	6	7	8	9	Clear	⊗
ALT	ABC	DEF	GHI	JKL	MNO	PQR	STU	VWX	YZ[-./	Abort	A...

Note that if the ALT key is continuously held and the number key is pressed, again, the letter will scroll through the following possibilities of letters:

ABCDEFGHIJKLMNOPQRSTUVWXYZ [] ^abcdefghijklmnopqrstuvwxyz
 pqrstuvwxyz { | } ! " # \$ % & ' () * + , - . / 0 1 2 3 4 5 6 7 8 9 : ; ? @

For example, if you wanted the letter "W" you would hold down on "ALT" and then press the "7" key. Note that "V" appears in the space, as Table 1 shows. While still holding the "ALT" key, press the "7" key again, and the letter "W" will appear. Release the "ALT" key and the letter remains. You can also press the right and left arrow keys (while the ALT key is down) to scroll through the alphabet.

The rest of the keys are explained below:

- ENTER - Used as a means of indicating to the Phoenix that an option is complete, and ready to be acted upon.
- CLEAR - Used as means of backing up one question in a menu.
- SPACE - TAM KEY. At any main menu, pressing this key activates the TAM interface. Also, when the counter is first powered up the user can press this key to start the TAM Memory Card Reader System. See section VI for a detailed description of the TAM interface.
When not at main menu, the SPACE key inserts a space at the current location of the command line and will also allow scrolling through options in ascending or descending.
- [- This key allows viewing/selection of options in ascending or descending. Also used as a non-destructive backspace key when entering a line of data.
- ⊗ - This key allows viewing/selection of options in ascending or descending. Also used to move non-destructively one position to the right when entering a line of data.
- ALT - Used only in conjunction with other keys; ALT allows existing keys to perform alternate functions. Use of the ALT key is similar to the SHIFT key on a typewriter keyboard, in that the ALT key must be pressed and held for the duration of the associated keypress.

III.b. LCD Display

The Phoenix is equipped with a two-line LCD display (Liquid Crystal Display). Each line displays up to 16 letters or numbers. This display is used in conjunction with the keypad to program and operate the Phoenix. You will see various questions and information displayed at different times. Please refer to the appropriate section of this manual for more information on specific questions and displays.

The LCD type of display used in the Phoenix consumes very little power, thereby minimizing battery drain during setup and monitoring procedures. To further save battery power, the Phoenix will turn off power to the display when data collection is active and the display is not being used.

Road dust will inevitably cover the display from time to time, and the display will need to be brushed off. When cleaning the display, it is best to attempt blowing off as much dust as possible before wiping the surface with a soft damp cloth. This method limits the chances of scratches being caused by the abrasive found in the dust.

III.c. Serial Port

The serial port is used for the retrieval of traffic data that has been collected by the Phoenix. All serial devices are connected to the Phoenix through the Serial Port plug (located on the right side of the case). Note that the Phoenix can be completely programmed and operated from the serial port.

The serial port supports Baud Rates from 300 Baud to 19200 Baud. It does "auto baud" detection on all incoming data, and automatically matches itself to the speed of the incoming data.

The retrieval of data must be done through the serial port (unless a TAM Card used), and the method of transfer is 1K XMODEM with CRC error checking. An automatic switch to 128 Byte XMODEM transfer occurs when the system gets 10 or more errors (indicating a noisy line, which will transfer faster with smaller blocks).

There are two common types of devices which connect to the Serial Port: Computers and Modems.

■ Computers

This is the most common type of serial device. You will need to connect a computer to the Phoenix to retrieve your data. You can also completely program and configure your Phoenix using a computer and the included TrafMan Software (see appropriate manual). Note that any computer with a standard RS232 serial port plug may be connected.

■ Modems

Modems are used to provide a telephone link-up to the Phoenix. Modems are particularly useful if the site is a permanent location and there is access to a phone line. Modems provide a means of retrieving data over a telephone, thereby eliminating the need to send an operator to the site. The Phoenix is fully operable over a modem, and all functions are available (if the proper security password is specified). The Phoenix supports baud rates from 300 to 19,200 with a modem. See the Section III.c.1 for more information.

III.c.1. Using the Phoenix With a Modem

All Phoenix counters come fully operable with a modem. You will also need some kind of telephone communication package to access the counter through the modem. There are two pieces of software available from Diamond Traffic Products which give you this ability plus many other features; they are TrafMan Modem Enhancement Package and the Traffic TallyLink Software. See the appropriate manual for more information.

In addition to a software package, you will also need a modem and a Modem Interface Cable (available from Diamond Traffic Products). When choosing a modem, follow the below guidelines:

- If your site is AC powered, buy an AC powered Hayes Compatible Smart Modem. If your site is battery or solar powered, buy either a Line Powered Hayes Compatible Smart Modem or a Battery Powered Hayes Compatible Smart Modem.
Note that some line powered modems are not "Smart Modems" (i.e. programmable modems), and we recommend you purchase a "Smart Modem". The Phoenix will work with a "Dumb Modem" (i.e. non-programmable), but you may not be able to take advantage of all of the features of the Phoenix. If you buy a battery powered modem, the Phoenix can be configured to provide the correct battery voltage to the modem from its Battery Charger Plug. Contact us for exact details and pricing.
- We recommend you purchase a 2400 Baud Modem. You may use slower or faster speed modems, but slower modems will dramatically decrease the speed of data transfer and a faster modem may cause problems with line noise. Also, as a general rule of thumb, the faster the modem, the more power it will consume.
The Phoenix is fully compatible with MNP protocol and can be easily configured to accept 9600 or 4800 baud transfers. See the TT-Link Software Manual or the TrafMan Modem Enhancement Software Manual for more detailed information regarding the use of advanced modems.
- If your sites are in a lightning storm area, we strongly recommend you purchase a line surge suppressor between your modem and the telephone line.

Standard Modem Hook Up (1200 Baud Smart Modem):

- 1) Turn off the power to both the Phoenix and the Modem.
- 2) Connect the Phoenix to the Modem using the Modem Interface Cable.
- 3) Turn on the Modem.
- 4) Turn on the Phoenix. The counter screen should display (after the self test):

```
Phoenix   Vx.xx
<Setting Modem>
```

Counter is now initializing modem. The counter will perform this step every time you hang up after a connection & automatically at midnight and 2pm of each day. NOTE: x.xx is the current Phoenix version number.

- 5) If everything is done correctly, the Phoenix will configure the modem and adjust it properly. The screen will read:

```
Phoenix   Vx.xx
<Smart Modem>
```

Counter is now ready to accept incoming calls. You can still use the counter keypad by pressing the ENTER key. Press the CLEAR key to return to this screen. NOTE: x.xx is the current Phoenix version number.

- 6) If a non-programmable (i.e. "Dumb") modem has been connected, your smart modem is not functioning, or you have incorrectly connected the cables, the screen will instead show:

```
Phoenix   Vx.xx
<Dumb Modem>
```

If the counter is connected to a dumb modem, it is now ready to accept incoming calls. You can still use the counter keypad by pressing the ENTER key. Press the CLEAR key to return to this screen. NOTE: x.xx is the current Phoenix version number.

If the counter displays this when connected to a smart modem, then something is not working properly.

Connecting to a modem other than a 1200 Baud Modem

The Phoenix defaults to work with a 1200 baud modem, if you want it to accept higher speed calls (such as from a 2400 baud modem) or you are connecting a slower speed modem (such as a 300 baud modem), you must perform the following steps:

- 1) Disconnect any serial or modem cable from Phoenix.
- 2) Select the Configure System Option from the Not Collecting Data Menu.
- 3) Press ENTER until the following option screen appears:

```
Select Baud For
Modem? 1200
```

- 4) Using the Arrow Keys, select the speed of transfer you want to be able to call the counter at. Make sure it is not faster than the modem can handle.
- 5) Keep pressing ENTER until you return to the menu.
- 6) Follow the steps under Standard Modem Hook Up.

Notes about switch settings

If you are using a non-programmable dumb modem, all configuration of it is usually done through switch settings. Follow the below guidelines when setting these switches.

- 1) DTR Status (sometimes called Data Terminal Ready) should be in the Hang Up when Toggled setting.
- 2) DCD Status (sometimes called Data Carrier Detect) should be in the Reflect Actual State position (not always "on" or always "off").

If you are using a Smart Modem, switch settings are not normally important because the Phoenix will re-initialize the modem to the correct settings with software.

III.d. Sensors

A Phoenix can not do anything for you unless it can receive signals from traffic. Some form of sensor must be used to transfer a vehicle passing by to a form of data the Phoenix can use. Variations include Road Tubes, Inductive Loops, Piezo Electric, Tape Switches, Infra-Red, etc.. The Phoenix supports any type of sensor with any type of data collection, thus selecting a sensor is largely a matter of personal preference and/or matching existing equipment.

III.d.1. Road Tubes

Road Tubes (or just "Tubes") refer to hollow rubber tubes usually ranging from 20 to 60 feet in length. These Tubes are stretched across the roadway so that oncoming vehicle traffic drives over them. This generates a sound-wave (or an "air impulse") which travels down the tube and allows the electronics of the Phoenix to determine that a vehicle axle has passed.

Tubes offer the advantage of being easily movable, quick to install, inexpensive, and capable of detecting individual axles of a vehicle. Their disadvantages include rapid wear, hard to secure for long periods, and drivers noticing the tubes and possibly changing speed, lanes, etc..

Follow these guide lines when using Tubes with the Phoenix:

- The counter will work with road tubes between 20' and 100' long. Shorter lengths are generally more accurate so use shorter lengths when possible.
- If collecting Raw or Binned data, make sure each lane's tubes (two per lane) are the SAME LENGTH. Also, try to stretch the tubes the same amount when securing them to the roadway.
- Make sure the Tubes are placed as squarely as possible to the oncoming traffic (so that both wheels of a vehicle strike the tube simultaneously).
- After each use, check the tubes for punctures or other damage.
- Plug the end of the with a suitable device to keep dirt out.

How to connect the Tubes to a Phoenix when collecting Raw or Binned Data:

- Get two equal length road tubes for each lane desired.
- Install one road tube perpendicular to the direction of traffic across a single lane of traffic. You can string road tubes across multiple lanes using the "Lane Overlap" function or the "Directional" mode. This is fully covered under Section II.c.).
- Install the second road tube perpendicular to the direction of traffic from 1 to 25 feet from the first (12 feet) recommended.
- Connect the road tube which will be hit first by oncoming traffic into the 1st Input Nozzle for the particular lane you are using.
- Connect the road tube which will be hit second by oncoming traffic to the 2nd Input Nozzle for the particular lane you are using.

How to connect Tubes to a Phoenix when collecting Count Data:

- Install a road tube perpendicular to oncoming traffic across a single or dual (or more) lane of traffic.
- Connect the road tube to the Nozzle on the Phoenix for the lane you are using.
- If you are using at least two lanes and you want to use Lane Subtraction or Directional function, you may want to read about these functions in Section II.e for more information on how to correctly install and connect tubes.

How to connect Tubes to a Phoenix when collecting Sensor Data:

- Install a road tube perpendicular to oncoming traffic across one or more lanes.
- Connect the road tube to the Nozzle on the Phoenix for the lane you are using.
- Note that the Sensor mode simply stores times when this sensor is activated, placement of it is up to you.

FOR IMPORTANT INFORMATION REGARDING TUBES AND POTENTIAL ERRORS, SEE APPENDIX - E.

III.d.2. Inductive Loops

This type of sensor is made of multiple turns of wire buried under the roadway, whether pavement, gravel, or dirt. Perhaps the most common usage of Loops to day is with Traffic Signals.

Advantages of loops are: They are permanent so they do not need to be installed each time they are used. They do not wear and are usually undetectable by oncoming traffic. Their disadvantages include: They lack the ability to discern individual vehicle axles. They are somewhat more susceptible to external factors, such as vehicle height and metal content. They are also slightly more complex to install and configure.

How To Use Loops With A Phoenix:

- Loops should be installed in the center of the desired lane of traffic and be no smaller than four feet by four feet (six foot by six foot loops are recommended).
- If you plan on using loops to collect Raw or Binned data, be sure that each loop of a lane (two per lane) is the SAME dimensions. The leading edge from the first loop to the leading edge of the second loop should be 5 to 25 feet (16 feet recommended).
- Connect loops to the Phoenix Loop Plug exactly the same as you would tubes (first loop goes to Loop #1 connection, second loop goes to Loop #2 connection, etc.). Refer to Appendix C for more information on what color wires of the loop harness go to which loop.

III.d.3. Piezo Electric & Resistive Sensors

Piezo Axle Sensors combines the permanent advantages of Loops with the individual axle detection abilities of Tubes. In addition, there are also some non-permanent Piezo strip sensors available. A Piezo sensor is a "Axle" sensor for setup and configuration purposes.

How to use Piezos with the Phoenix

- Install the piezos perpendicular to the oncoming traffic in a single lane.
- Connect to the appropriate piezo input connector for the lane you are using.
- The Phoenix defaults with the sensitivity of the Piezo Detection circuitry set to the most common value (75%). It may be necessary, however, to adjust this setting to accommodate more or less sensitive piezos. Follow the steps below to adjust this setting.
 - Bring the Phoenix to the Site you want to set it up at.
 - Connect all piezos to be used to the Phoenix.
 - Set the counter up to collect COUNT data (regardless which type of data you plan to eventually collect). See section V.d. for a step-by-step example of this.
 - Enable all of the lanes which have piezos connected to them.
 - When you get to the "Testing Lanes" screen, stop and wait for vehicles to cross each of the sensors. Ideally, you want several different types of vehicles to cross each of the piezo sensors so that you can verify that the sensors are counting trucks and small cars accurately.
 - If one of the piezos seems to be undercounting or overcounting, you should adjust its sensitivity level. This is done by holding the ALT key down and then pressing the number key corresponding to the sensor number. For example, press ALT + 1 to adjust piezo input #1. After pressing ALT and a number key, another screen will appear allowing you to set the piezo level. Use numbers 1-9 to select levels from 10% to 90%. Press the 0 key to select 100% sensitivity (i.e. maximum). Use the LEFT and RIGHT arrow keys to decrease/increase the level in smaller increments. Press the ENTER key when finished. See section IV.F for more detailed information.
 - Once all piezos have been set, return to the main menu (ALT + CLEAR) and then proceed to setup the counter to collect the type of data you desire. Note that you do not have to set the counter to collect Count data to set the piezo sensitivity levels, it is simply the easiest mode to use to determine if a sensor is overcounting or undercounting. You can also tell us in the Raw or Binned modes if vehicles show extra axles, missed axles, or you get a lot of SnMis.

III.d.4. Remote Input

The remote input connector is a direct input plug to the counter. The Phoenix has a 8 channel open collector input which allows user to directly connect ANYTHING to the Phoenix you want to use which provides a momentary switch closure or other open collector type output. Examples would be: Tape Switches, Foot Mats, or Infra-Red Detectors. See Appendix C for information on remote harness wire colors.

The signal to the counter through the remote plug should be:

- Noise free.
- The pulse width should be about 10ms. Longer is allowed providing it is very clean.

< < This page intentionally left blank > >

IV. Keypad Operation

This section describes the full operation of the Phoenix Field Unit using the built in keypad. For information on operations using the Serial Port, please refer to the TrafMan Software Instruction Manual.

Note that virtually all features of the Phoenix can be controlled with the keypad. The only exception is that of Data Retrieval, in which case you must use the Serial Port or a TAM Card.

IV.a. How To Use The Menus

The Phoenix menu structure has been designed to take full advantage of the system's capabilities with minimal effort and confusion of the operator. The menu system has been designed so that only those options which may be needed at any particular point are available. Selection of an option from within a menu is a simple matter of using the arrow keys. Press the direction you wish to go (either right arrow for forward through the menus or left arrow for backwards through the menus) and then press the ENTER key to activate that option. The menu will automatically roll-over at the end, so by pressing one direction or the other the desired option will always appear.

An alternate method of selection is to type the number which corresponds to the desired option. Each option has a number to which it may be referenced directly. These numbers are located on the inside of the Phoenix lid. This method has the benefit of skipping all other options by proceeding immediately to the one specified. Press ENTER to activate the option once it has been selected.

Different options under either menu will ask different questions based upon the Data Storage and Sensor Modes selected. For example, if you have selected Sensor Data Storage using Axle Sensors, the Phoenix will not ask you questions about time in intervals or loop lengths. The options have been optimized to allow the quickest possible installation and configuration.

Aborting an option is done by pressing the CLEAR key. This backs the Phoenix up one questions per keypress until you return to the one of the menus. If you press CLEAR at the menu when data collection has started, the Phoenix will be placed into a special mode and the LCD display will go blank. At this point, the Phoenix will turn off the display to save power. Note that the counter continues to collect data in this mode.

You can turn the display on the counter back on at any time by pressing the ENTER key. Make sure you press the CLEAR key from the menu before you leave the counter to help save on battery power. You cannot tell the Phoenix to turn off the display unless it is collecting data.

Serial Cable Connection

If a serial or modem cable is connected, the counter will instantly switch from the menu to a screen which shows "<Serial Active>" or "<Setting Modem>". If you want to use the regular keypad menu after a serial or modem cable is connected, simply press ENTER and you will be returned to the menu and ALL SERIAL PORT INPUT IS IGNORED! Press the CLEAR key from the menu when you are finished and the counter will return to the "<Serial Active>" or "<Setting Modem>" state.

IV.b. The Two Main Menus

The Phoenix has two basic main menus that appear depending on whether you are collecting data or not.

IV.b.1. Not Collecting Data Menu

This menu appears when you turn on the counter and are ready to collect data. It has the following options:

- | | |
|-------------------|---|
| Start Collecting | - The main option. It will ask a series of questions to determine the lanes and format for data collection. Once completed, it allows you to test your configuration, and then start collecting data. Once this option is finished, you will be in the Collecting Data menu (see next section, IV.b.2). |
| Delete Files | - Used to delete any files currently in memory. If no files are in memory, Phoenix will display "No Files In Memory" if selected. |
| Show Status | - Displays current memory usage & availability, number of files in memory, loop boards in stalled (if any), piezo boards in stalled (if any), current time and date, and a battery voltage. |
| Test Sensors | - Can be used to test any connected sensors. This function will tune any connected loops to the system, and then give a graphical representation of activations. |
| Time of Shut down | - Displays the Time and Date the system was last shut down (power turned off, not stopped collecting). |
| View Lane Totals | - This option displays the total number of vehicles (Raw & Binned) or sensor activations (Count & Sensor) from the last Start to Stop Collection. |
| Configure System | - Configure System allows the user to configure options such as Storage Mode, Date and Time Formats, File Handling, Speed and Length Formats, and Maximum Allowable Axle Spacings, etc.. |
| Cold Restart | - Cold Restart will completely restart the counter. All files, configurations, and setups will be erased. The option has a confirmation to avoid accidental data loss. |

IV.b.2. Collecting Data Menu

After the Phoenix has been configured and data collection started, the collecting data menu is used. To reach the menu, press the ENTER key from sleep mode. To return to sleep mode, press the CLEAR key. The collecting data menu contains the following options:

- | | |
|-------------------|--|
| Stop Collecting | - Closes the current file and stop collection of data. The option has a confirmation to avoid accidental file closure. |
| Delete Files | - Same as option in Not Collecting data menu. |
| Show Status | - Same as option in Not Collecting data menu. |
| Monitor Lanes | - Allows monitoring of Traffic Data while collecting. As vehicles are detected, the data will appear on the display, while concurrently being stored in the open file. |
| Time of Shut down | - Same as option in Not Collecting data menu. |
| View Lane Totals | - Same as option in Not Collecting data menu. |

IV.c. Start Collecting

The Start Collecting option asks many questions, many depending on what type of hardware you have inside your Phoenix as well as what type of Storage Mode you plan on using. Press the "1" key from the menu and the display will show:

```
SELECT OPTION:
Start Collecting
```

Press ENTER to begin the start collecting option.

Note that pressing the CLEAR key will back you up one question. Holding down the ALT key and pressing the ENTER key will skip all questions and immediately begin Testing Lanes under the current Start Collecting Options. This is useful to collect data under previously entered setup conditions.

Before you use the Phoenix to actually start collecting data, verify the following things:

- The battery is fully charged (or will last as long as you plan on collecting data).
- You have enough free memory in the counter to hold all of the data you plan on collecting. Use the Show Status option to verify the amount of free memory. Appendix B contains tables which will give you an idea of how much memory you need for different collection options and modes.
- You have used the configure system option to tell the counter what type of data you want to collect (Raw, Binned, Count, or Sensor). Note that if you have previously set the counter, you will not need to Configure System again as long as you plan to collect the same type of data.

IV.c.1. Questions Asked With Any Storage Mode:

```
Site: (15 chars)
_____
```

Enter the current site, up to 15 characters long. You should always enter a site, to help distinguish between different data collection sessions. Note that the full alphabet plus numbers and punctuation can be used. NOTE: This is the only place you can see the full 15 characters of the Site ID. In all other places only the first 10 characters are shown.

```
Info: (1st Line)
_____
```

Enter in the first line of information, up to 15 characters long. This Info line is provided in addition to the Site string and can be left blank if desired.

```
Info: (2nd Line)
_____
```

A second line of Info which is also optional.

```
Set The Current
Time: hh:mm:ss
```

Enter the correct time, in military format. If the time shown is correct, simply press ENTER to accept it and go on.

```
Set The Current
Date: mm/dd/yy
```

Enter the correct date. If the date is correct, simply press ENTER to continue. Note that the format may also be DD-MM-YY or YY-MM-DD depending on the date format you selected in Configure System option.

```
Set The Current
Day Of Week? DAY
```

Enter the correct day of the week by pressing the arrow keys and toggling through the standard weekdays. Choices are Sun, Mon, Tue, Wed, Thu, Fri, or Sat.

With Raw or Binned Storage:

```
Select   1 2 3 4
Lanes :  n n n n
```

If 1-2 loop boards.

```
Select  12345678
Lanes : nnnnnnnn
```

If 3-4 loop boards.

With Count or Sensor Storage:

```
Select  12345678
Lanes : nnnnnnnn
```

First Screen.

```
Select  9.....16
Lanes : nnnnnnnn
```

Second Screen. Displayed only if 3-4 loop boards installed.

Enter the enabled lanes by pressing the corresponding number below the lane. For example, pressing the 1 will toggle lane 1 on and off. You must enable at least one lane before proceeding. If no lanes are selected, the Phoenix will display an error message and will not allow the user to go any farther until at least one lane is enabled.

IV.c.2. Lane Grouping Questions

The Phoenix has the ability to group lanes together inside of the counter prior to storing them in memory. You could, for example, group lanes 1 through 4 together and store only their summed values in memory. This has the advantage of reducing the amount of memory that is being used, and the disadvantage of eliminating the individual lane totals.

Lane Grouping Questions are only asked if you are in Binned or Count mode and you have selected Yes for the Ask For Lane Grouping question in the Configure System option.

```
Select Number Of
Groups? x
```

Select from 0 to 4 groups. Selecting 0 disables lane grouping. Selecting 1 puts all lanes into one group. Selecting 2 or more causes the counter to ask questions where you specify which lanes go into which groups.

If you select 2 or more groups, the counter asks you the following question for each group:

```
Group #y Lanes:
(lanes)
```

Where y is the group number and (lanes) is which lanes are currently assigned to this group. To assign a lane to this group, simply press the number key corresponding to the lane number. To unassign a lane to this group, press the number key again. You assign and unassign lanes 11 -16 using the ALT + 1-6 (ALT + 1 for Lane 11). 0 is used for Lane #10. Note: You must assign at least one lane to each group. You can not assign lanes to the group which have already been assigned to a lower numbered group.

Lane grouping is only visible when you retrieve the collected data. Monitoring the lanes and all other functions are not affected by lane grouping. Lane grouping does not affect the type of data collected (such as Axle Classification or Speed Classification) but simply adds several lanes classification values together to look as if all vehicles were in a single lane.

IV.c.3. Questions Asked With Raw Storage Mode

The following questions are asked for each lane you have enabled.

Info For Lane #n _____	Enter the appropriate information for this lane, up to 15 characters. This Info is normally used to indicate lane direction.
Directional Mode For Lane #n: No	Use if the arrows keys to toggle between Yes and No. If it is enabled, a directional lane is created (see Section II).
Info For Lane #n _____	Used if directional has been created. If directional mode has not been enabled, this will not be asked.
Lane #n Sensors > Axle-Axle	Select the Sensor Mode you wish to use. Options in Raw Mode are Axle-Axle, Pres-Pres, Axle-Pres-Axle, and Pres-Axle-Pres. Important - this question will only be asked if you have at least one loop board installed. If you do not, the Phoenix assumes Axle-Axle sensors (Tubes, Remotes, or Piezo Sensors).
Lane #n Sensor Spacing: nn.n'	Set this value to indicate the spacing in between your sensors. This can be set from 5.0 feet to 99.9 feet. See Section III (Sensors) for recommended spacing.
Loop Length For Lane #n: nn.n'	This question is asked if you selected any form of Pres in your Sensor selection. You must enter the Length of the loop used for this lane. If you have entered Pres-Pres, it is the length of the Second Loop. The Phoenix uses this information in calculating vehicle length.
Select Raw Type: nnnnnnnnnnnnnn	Use the arrow keys to select which type of Raw Data you wish to collect (Section II). Options are Normal Raw Data, Enhanced Raw, Raw with Bins, and Enhanced & Bins. Press ENTER to select.

The system will now go into a lane test. If you have loops connected, the system will give the message "Tuning Loops" and then "Waiting For Any Vehicle...". Each lane may now be tested, with the data displayed on the LCD display as vehicles are registered. Note - If you have selected a Sensor Mode which uses a loop and no loops are connected, or if there is a failure in a loop, the system will display "Unconnected Loop Check:nnnn" with n being the loop (or loops) which you have requested for use but is not detectable by the Phoenix. At that point, connect up the missing loops and press ENTER to try again.

From here, the system asks the final start questions.

IV.c.4. Questions Asked With Binned Storage Mode

The program asks the following questions for each lane you have enabled.

Info For Lane #n _____	Enter the appropriate information for this lane, up to 15 characters. This Info is normally used to indicate lane direction.
Directional Mode For Lane #n: No	Use the arrow keys to toggle between Yes and No. If it is enabled, a directional lane is created (see Section II).
Info For Lane #n _____	Used if a directional has been enabled. If directional mode has not been enabled, this will not be asked.
Lane #n Sensors > Axle-Axle	Select the Sensor Mode you wish to use. Options in Binned Mode are Axle-Axle, Pres-Pres, Axle-Pres-Axle, and Pres-Axle-Pres. Important - this question will only be asked if you have at least one loop board installed. If you do not, the Phoenix assumes Axle-Axle sensors (two Tubes or two Piezo Sensors).
Lane #n Sensor Spacing: nn.n'	Set this value to indicate the spacing in between your sensors. This can be set from 5.0 feet to 99.9 feet. See Section III (Sensors) for recommended spacing.
Loop Length For Lane #n: nn.n'	This question is asked if you selected any form of Pres in your Sensor selection. You must enter the Length of the loop used for this lane. If you have entered Pres - Pres, it is the length of the Second Loop. The Phoenix uses this information in calculating vehicle length.

The following questions ask which bins you want to enable for data collection. At least one bin must be enabled. All bins may be enabled; however, it is suggested the user read Appendix B (Memory Usage) to determine if enough memory is available.

Collect Axle Bins? No
Collect Speed Bins? No
Collect Gap Bins? No
Collect Headway Bins? No
Collect Length Bins? No

Collect Speed By
Axle Bins? No

Collect Speed By
Length Bins? No

Select Yes or No for each of these options to turn on or off the type of data collection..

No. of Different
Intervals? x

Select how many different interval lengths (1-5) during the day the Phoenix will use when collecting data.

If only one different interval is selected, the Phoenix asks:

Record Interval
Length: hh:mm

Enter the length of the record interval you want to use.

If more than one interval is selected, the Phoenix will ask the following questions for each interval:

Int Start: nn:nn
#n Length: nn:nn

The first interval defaults to start at 00:00 (midnight) and cannot be changed. The Phoenix will ask for length and time of start for each successive interval.

The Phoenix will now display the message "Tuning Loops" followed by "Waiting for Any Vehicle". Once a vehicle has passed and the data viewed is correct, press ENTER to continue.

From here, the final start questions are asked.

IV.c.5. Questions Asked With Count Storage Mode

The following questions are asked for each lane you have enabled.

Info For Lane #n _____	Enter the appropriate information for this lane, up to 15 characters. This Info is normally used to indicate lane direction.
Select Lane #n Sensor: Axle	Choices are Axle or Pres. This question is only asked if you have a loop board installed in the counter.

If you are setting an odd Numbered Lane, the counter asks:

Select Lane #n Mode: Normal	Choices depend on Lane Sensor. If Axle, choices are Normal, Direction, or Subtract. If Pres, choices are Normal or Direction. Selecting anything other than Normal will indicate that you are using this lane in conjunction with the next lane to get count. This causes the counter to automatically configure the next lane to be the same as this lane.
--------------------------------	---

If you selected an Axle Sensor:

Divide Lane #n Count By 2: No	Select Yes or No to automatically divide the total count by two.
----------------------------------	--

After the lanes have been entered, the following questions are asked:

No. of Different Intervals? x	Select how many different interval lengths (1-5) during the day the Phoenix will use when collecting data.
-------------------------------	--

If only one different interval is selected, the Phoenix asks:

Record Interval Length: hh:mm	Enter the length of the record interval you want to use.
----------------------------------	--

If more than one interval is selected, the Phoenix will ask the following questions for each interval:

Int Start: nn:nn #n Length: nn:nn	The first interval defaults to start at 00:00 (midnight) and cannot be changed. The Phoenix will ask for length and time of start for each successive interval.
--------------------------------------	---

After entering the interval information, the Phoenix will display "Tuning Loops" (if some loops have been selected) and then show a test screen. As data is collected, the count for each lane entered will be shown. Note that the Phoenix is not collecting and storing data at this point - it is testing the lanes for proper setup. Press ENTER to continue.

The system will now ask the final start questions.

IV.c.6. Questions Asked With Sensor Storage Mode

The following questions are asked for each lane enabled:

Info For Lane #n _____	Enter the appropriate information for this lane, up to 15 characters. This Info is normally used to indicate lane direction.
Lane #n Sensor Type: Axle Only	Enter the sensor type for lane #n. Options are Axle Only, Pres Only, or Axle+Pres.

The screen will display "Tuning Loops" if loops are selected, and then "Waiting For Any Sensor". The system is not collecting and storing data - it is for the user to confirm lane setup and configuration. Once several sensors have been activated and the data is satisfactory, press ENTER to continue.

IV.c.7. Final Start Questions

Select Mode To Start? Now	You can choose between Now, Midnight, or Date/Time options of starting. If you choose Date/Time, the system will request entering a time and a month/day to start.
Select Mode To Stop? Never	You can choose between Never, 24 Hours, Date/Time. Never will continuously run until manually shut down (or out of memory), 24 hours will simply run for 24 hours from the time of start, and if you select date/time the Phoenix will request entering a time and a month/day to stop.
-SETUP COMPLETE- Press Enter Key	The counter is now ready to start.

Once the ENTER key is pressed the system goes into sleep mode (the display will blank), and has started collecting data. If you press ENTER again, the system will wake up and you will be placed in the not collecting data menu.

Note about selecting any start time other than Now:

The counter will go ahead and put you in the Collecting Data Menu, even though you may have selected to start collecting at midnight or at some future time and date. This condition is called the "Pre set Mode", since the counter has been pre set to start collecting at a future time.

While in Pre set Mode, no file is open nor is any data being stored in memory. You can still monitor collection, however, to verify the sensor configuration is working.

Note about collecting Binned or Count data:

These two modes both use record intervals. The Phoenix will NOT start collecting data until the beginning of the next even record time. For example: The record interval is 15 minutes, you tell the counter to start Now when it is 10:53:00. The counter will not start until 11:00:00.

While the counter is waiting for the start of a new interval, it is also in Pre set Mode (see above).

IV.d. Delete Files

The delete files option allows you to delete any or all files in the current memory. Press "2" from the menu and the display will show:

```
SELECT OPTION:
Delete Files
```

Press ENTER to begin deleting files.

If there have been no files created in memory, the counter shows:

```
No Files In
Memory.
```

If files have been created, the display will show:

```
(n) Delete What
Files? All Files
```

"n" is the number of files currently resident in memory. By pressing the arrow keys the options of All Files, Single, or Retrieved may be selected.

If "All Files" is selected, the display will show:

```
DELETE ALL FILES
You Sure? No
```

This message is the safety for deleting files. Use the arrow keys to toggle the answer to Yes.

If "Single" is selected, the display will show:

```
# 1: _____ n
mmmmmm mm/dd/yy
```

n is the designator for whether the file has been retrieved (Yes or No). mmmmm is the file size. # 1 is the file number. mm/dd/yy is the starting date of the file. To select the file to be deleted, use the arrow keys to toggle from file to file. Once the file has been selected, press ENTER. The display will show:

```
DELETE FILE #n
You Sure? No
```

This is the safety for file deletion. Toggle to Yes using the arrow keys. Pressing ENTER will delete the file. If the file is deleted, the display will show the next file. Note that all files following the deleted file will be automatically renumbered down to keep file number continuity.

If "Retrieved Files" is selected, and no files have been retrieved, the display will show:

```
There Are No
Retrieved Files.
```

If files have been retrieved, the display will show:

```
DELETE FILES
You Sure? No
```

Use the arrow keys to toggle to Yes to delete the files.

IV.e. Show Status

The Show Status option allows display of the Phoenix System Status. This should always be performed prior to Starting Collection to ensure correct time/date and that there is enough memory free to collect files. From the menu, press "3" and the display will show:


```
SELECT OPTION:
Show Status
```

Press ENTER to show system status.

First, the counter displays the amount of memory in the system

```
Total Mem: mmmmmm
Mem Left : nnnnnn
```

Displays the total amount of memory in your counter, and how much is left for use.

Next, how many files are in the memory is displayed:

```
Memory Holds n
Data File.
```

"n" = number of files.

```
No Files In
Memory.
```

If there are not any files.

Next, if there aren't loop boards installed, the display will show:

```
No Loop Boards
Installed
```

If loop boards are installed, the display will show:

```
Loop Board xxxxx
Installed
```

Where xxxxx will be which loop boards are installed (1-4).

Next, the Piezo Board status will show:

```
No Piezo Board
Installed
```

If no piezo inputs

```
x Input Piezo
Board Installed
```

"x" is number of piezo inputs available (0, 4, or 8).

Next, the TAM Interface status screen will show:

```
No TAM Interface
Installed
```

```
TAM Interface
Installed.
```

Next, the current time and date is shown:

```
Time: hh:mm:ss
Date: dd/mm/yy
```

The current time and date are displayed. Note that the date will be displayed in the currently selected format.

Last, the battery condition is displayed:

```
Current Battery
Voltage = xx.x
```

This screen shows the current voltage on the battery, to the nearest tenth of a volt.

IV.f. Test Sensors

The Test Sensors option is for testing sensors and system response. Press "4" from the menu and the display will show:

```
SELECT OPTION:
Test Sensors
```

Press ENTER to begin testing sensors

If no loop boards are installed in the counter, the display shows:

```
Testing Sensors:
Axle: _____
```

The display is automatically set for eight axle sensors, and will indicate when a respective sensor has been activated.

For example, if sensor two is activated, the display will temporarily show:

```
Testing Sensors:
Axle: _2_____
```

The display will show sensors as they are activated, and then return to the blank state.

If any loop boards are installed, the display will show:

```
Axle: _____
Pres: <$B0> <$B0>
```

If 1-2 Loop
Boards

```
Axle: _____
Pres: <$B0> <$B0> <$B0>
```

If 3-4 Loop
Boards

```
Axle: _____
Pres: <$B0> <$B0> <$B0> <$B0>
```

Axle sensors are displayed above, presence sensors are displayed below. What is put in for the "<\$B0> <\$B0> <\$B0> <\$B0> <\$B0> <\$B0> <\$B0> <\$B0>" depends upon how many loops are connected. Each "<\$B0>" is for a given loop; a square designates a connected loop, a square with the top bar missing designates no loop is connected. Presence in the loop is designated by the square being replaced with the loop number.

Press the "9" key at any time to retune the loops after you connect or disconnect loops. ENTER or CLEAR takes you out of the testing screen and back to the main menu.

If you have a Piezo Board Installed:

The Phoenix will allow you to set Piezo Sensitivity Levels from the Testing Sensors screen. These sensitivity levels control how much force is required to trigger a Piezo Electric or Piezo Resistive sensor. Levels are set in a range from 0% to 100% with 100% being the most sensitive (i.e. requires the least force to trip the sensor). Each piezo has its own sensitivity level which can be set differently from all others.

To set a particular Piezo Sensitivity level, hold down the ALT key and press a number key from 1 to 8 corresponding to the Piezo Level you want to set. An other screen will appear as below:

Piezo Trip Level
 Input #x: yy%

"x" is the piezo input number and "yy" is the current level.

At this point use the following keys to set a new level:

- 0-9 - Sets level to a value from 10% to 100% (0 key sets 100%, 1-9 sets 10% to 90%).
- CLEAR - Exits piezo sensitivity setting screen.
- ENTER - Exits piezo sensitivity setting screen.
- Left
Arrow - Decreases sensitivity a small percentage at a time.
- Right
Arrow - Increases sensitivity a small percentage at a time.
- ALT + 1-8 - Switches to a different Piezo Sensor.

IV.g. Time of Shutdown

Time of shut down will give the last shut down time of the system. Press the number "5" from the menu and the display will show:

```
SELECT OPTION:
Time of Shutdown
```

Press ENTER to see the time of shut down.

```
Time: hh:mm:ss
Date: dd/mm/yy
```

The last time and date of shut down are displayed. Note the date will be displayed in the format selected in the configure system option.

Note that the time of shut down is either the time YOU turned the power off on the counter or the time the counter shut itself off due to a weak battery. It is NOT the time the counter stopped collecting data.

IV.h. Configure System

Configure system will set the system configuration for installation. Press the number "6" from the menu and the display will show:

```
SELECT OPTION:
Configure System
```

Press ENTER to begin system configuration.

```
Select Storage
Mode: Binned
```

This asks which storage mode you require. The choices are Raw, Binned, Count, or Sensor.

```
Select Format Of
Dates: MM/DD/YY
```

This asks which format you require for the date. Options are: MM/DD/YY, DD-MM-YY, and YY-MM-DD.

```
Erase First File
When No Mem? No
```

This asks if you want to continue collecting data when the memory is full, or should the counter delete the oldest file to make space for new data. If you select No the Phoenix will stop collecting when the memory is full. The default for this option is Yes if a TAM interface is installed.

```
Verify Power Off
Option: Disabled
```

If the Phoenix is collecting data, is in sleep mode, and if it receives a signal to shut down, enabling this option (Enabled) will cause the counter to display a message to the user requiring the user press the ENTER key to shut down. If the user does not press the ENTER key, the Phoenix will continue to collect data.

Enabling this option can help to avoid false shut downs due to circumstances such as static electricity (i.e. lightning). Note that if the battery voltage is below 5.8 volts (See "Show Status"), the Phoenix will ignore the option and power down anyway.

```
Create New Files
When? Manually
```

The user may select to create new files Manually, Daily, or Weekly. Manually means that the counter will only create a file when you specifically tell it to.

Daily means the counter will create a new file each day at mid night.
Weekly means the counter will create a new file once per week.

If you select Weekly files, you will be asked:

Starting Day Of
Weekly File? Sun

Select the day of the week that should become the FIRST day of your weekly file. Choices are Sun, Mon, Tue, Wed, Thu, Fri, or Sat.

Select Baud For
Modem? 1200

This option tells the counter the baud rate a modem connected to it can send/receive data at. For example, if you are connecting a Hayes Smartmodem 2400 to the counter you should set this value to 2400. YOU HAVE TO CALL THE COUNTER AT THIS RATE! You can change the rate for future calls by using a communication package like TrafMan and programming the counter to accept future calls at a different rate. Your choices are 300, 600, 1200, 2400, 4800, 9600, and 19200.

Ask For Lane
Grouping? No

This option enables or disables the Lane Grouping Function. If you select No, then Lane Grouping is disabled and the counter will not ask questions pertaining to it in the Start Collecting option (see IV.c.2).

The following configuration questions are only asked if either Binned or Raw Storage has been selected:

Speed and Length
Format? U.S.

Requests either U.S. feet and MPH, or Metric centimeters and KPH Format.

SnMis Storage
Mode: View Only

This option is used to select what the counter should do with sensor misses in formation. Sensor misses occur when a vehicle does not cross both sensors (see lid in instructions on Phoenix field unit for a description of each sensor miss code).

View Only will display sensor misses on the screen when monitoring, but not store these misses to memory.

View & Store displays the misses and stores them for later retrieval into memory. Note that storing sensor misses in memory does use up memory that could be used for data.

Disabled causes the counter to ignore sensor misses.

Maximum Axle
Spacing: 35.0'

This option determines the longest spacing between any two axles to be allowed when collecting Raw or Binned data using two axle sensors. The counter uses this length to determine where the end of a vehicle is, and the start of a new vehicle begins. Most trucks do not exceed 35' between axles, and most vehicles do not travel closer than 35' to each other. You should change this value if you have many tailgating vehicles which have short axle spacings (such as rush hour car traffic), or if you have trucks with very long spacings between axles.

Note that the longer the spacing, the greater the chance two vehicles close to each other will be counted as one long vehicle.

The following question is always asked regardless of storage mode:

```
Battery Warning
Voltage: x.x
```

Select at what voltage you want the counter to warn you about the battery being low. Use the left arrow key to decrease the voltage or the right arrow key to increase the voltage.

IV.i. View Lane Totals

This option allows you to view the total amount of vehicles (Raw and Binned Storage Modes) or sensor activations (Count and Sensor Storage Modes) that have occurred from the last time you Started collection to the last time you Stopped Collection.

When you select this option, a screen will appear similar to the following:

```
Lane a:      x
Lane b:      y
```

If two or more
lanes enabled.

```
<< Lane Total >>
Lane a:      x
```

If only one lane is
enabled.

a and b are the lane numbers of enabled lanes and x and y are the total vehicles or sensor activations. If you are collecting data then the totals will update as vehicles cross the sensors. To view additional enabled lanes, press the <Enter> key. To back up to view previous lanes, press the <Clear> key.

If you use a pre set time (such as Start At Midnight) then these lane totals will reset at end of the pre set time. Also, using In-Day times will reset the lane totals at the beginning of each In-Day period. Daily or Weekly files does not reset the lane totals.

IV.j. Cold Restart

Cold restart will perform the same function as removing backup power. The system will restart with ALL memory clean. Note that time and date, along with ALL configuration parameters WILL BE LOST. Don't use this option if the system contains any data which has not been retrieved for use. ALL DATA WILL BE LOST.

Press 7 from the menu and the screen will show:

```
SELECT OPTION:
Cold Restart
```

Press ENTER to select the option.

```
Sure You Want To
Restart? No
```

If you are SURE you want to do this, use the arrow keys to toggle to Yes. Press ENTER.

```
Phoenix   Vn.nnt
<Cold Restart>
```

"n.nn" is the version of the interior firmware. The "t" is the setup type (usually a 'A').

```
SELECT OPTION:
Start Collecting
```

The system has now been completely reset to the factory defaults.

IV.k. Stop Collecting

Stopping data collection is the only way to return to the Start Collecting Data menu. Press 1 from the menu and the display will show:

```
SELECT OPTION:
Stop Collection
```

Press ENTER to select the option.

```
Sure You Want To
Stop? No
```

Use the arrow keys to toggle to Yes. Pressing ENTER will close the current file.

```
File Number #n
Is Now Closed.
```

"n" is the file number. Pressing ENTER again will return the user to the Start Collecting Data menu.

IV.I. Monitor Lanes

Monitor Lanes allows the real-time monitoring of lanes. This option is intended for the user to monitor traffic to ensure the installation is working properly. Press 4 from the menu and the display will show:

```
SELECT OPTION:
Monitor Lanes
```

Press ENTER to select the option.

IV.I.1. Monitoring Raw or Binned Data Collection

```
Waiting For Any
Vehicle...
```

The counter displays this when first waiting for a vehicle.

As a vehicle crosses the installation, the display will show the vehicle as it crosses.

```
1: 10:00:00 2ax
30mph      12.8'
```

Indicates a vehicle passed in lane 1 at 10 o'clock. It had 2 axles, was going 30 miles per hour, and the spacing from the first to the second axle was 12.8 feet. Note that only the first axle spacing is displayed regardless of how many axles the vehicle has (you can view other spacings using the arrow keys, see below).

If you are collecting Binned data, the axle spacing will be replaced by one or more bin classification numbers that the vehicle matched.

While monitoring, you may press the following keys:

- 1-8 - Tells the counter to only display the lane number you press.
- 0 - Tells the counter to display all lanes.
- CLEAR - Aborts and returns to the menu.
- SPACE - Freezes the display. This allows you to view a vehicle for a longer period of time. Press SPACE again to un-freeze the display.
- ALT 1-8 - You can set piezo sensitivity levels with these keys. See section IV.f for information.
- | ⊗ - Allows you to see other spacings. Press either arrow keys and the screen will change to show up to 6 spacings. Press either arrow key again and the screen will return to the original display. These keys work even when the Freeze Key (Space) has been pressed.

If an asterisk character appears before the lane number, this indicates that collection has not actually started yet, and the vehicles shown are not being stored in memory.

IV.I.2. Monitoring Count Data Collection

```
L:xxxxxx L: xxxxxx
L:xxxxxx L: xxxxxx
```

The counter displays the first four count lanes you have enabled. Note the counter only displays the lanes you have enabled.

While monitoring data collection, the following keys can be used:

- 0 - If just Testing Lanes (i.e. from the Start Collecting option) this key zeroes all totals.
- ALT 1-8 - You can set piezo sensitivity levels with these keys. See section IV.f for information.
- CLEAR - Aborts and returns to the menu.
- SPACE - Toggles the screen to show other enabled lanes (if more than four are enabled).

An asterisk on the screen indicates that data collection has not started yet.

IV.I.3. Monitoring Sensor Data Collection

```
Waiting For Any
Sensor...
```

This is displayed first when the counter is waiting for a sensor pulse.

Each sensor which is activated will be displayed as:

```
L: HH:MM:SS.00
13223455 P On
```

L is the lane #; HH:MM:SS is the time. 13223455 is the count on the 24 bit internal clock. P On indicates that a presence sensor (such as a loop) was turned On.

While monitoring, you may press the following keys:

- 1-8 - Tells the counter to only display the lane number you press.
- 0 - Tells the counter to display all lanes.
- CLEAR - Aborts and returns to the menu.
- ALT 1-8 - You can set piezo sensitivity levels with these keys. See section IV.f for information.
- SPACE - Freezes the display. This allows you to view a sensor pulse for a longer period of time. Press SPACE again to un-freeze the display.

If you see an asterisk in front of the lane number, this indicates that data collection has not yet begun.

V. Keypad Operation Examples

The following sections give seven examples using the keypad of the Phoenix. The first six give examples of setting up the counter to collect Raw Data, Monitoring Data, Stopping Collection, and Collecting Binned, Count and Sensor Mode data. The last one is an example of Deleting Files.

Note that these examples are not complete descriptions. You should refer back to section IV for more in-depth information.

As the examples are worked through, files will be created in memory. The last example will show how to delete any or all selected files. If you get lost or a step is missed, simply return to the beginning.


Important

In many cases the Phoenix will skip certain questions during setup if there is only one possible answer for it. For example, the Phoenix will not ask questions pertaining to presence sensors if you do not have a loop board installed in your counter, therefore the only selection you can make is Axle Sensors.

These examples assume that you DO NOT have a loop board. If your counter does have a loop board, some questions will appear that are not shown here. In that case, read through the appropriate section of the manual for more information on how to answer these questions.

Example Site

The following diagram gives you an example site setup. It will be used as reference in the examples that follow.



Scenario: Two Road Tubes are installed in State Highway 58.

V.a. Configuring the System

This section is an example of configuring the system. Once the system is configured, it does not need to be done again unless a cold restart is done or the mode of collection (Raw, Binned, Count, or Sensor) needs to be changed. It can be used for each example that follows this one to change the storage mode. It is recommended to try variations on configuring the system in a test environment to familiarize one self with the Phoenix further.

Turn on the power switch. System will self test and then show:

SELECT OPTION: Start Collection	Press "6".
SELECT OPTION: Configure System	Press ENTER key.
Select Storage Mode: Binned	Select the required mode (Raw, Binned, Count, or Sensor) by using the arrow keys; press ENTER. Which mode you select depends on which of the following examples you are following.
Select Format Of Dates: MM/DD/YY	Select this format by pressing ENTER, or select a different format with the arrow keys and then press ENTER.
Erase First File When No Mem? No	Since we want the counter to stop when memory is full, press ENTER to select No.
Verify Power Off Option: Enabled	Press ENTER to leave this option enabled.
Create New Files When? Manually	Press ENTER to leave at Manually.
Select Baud For Modem: 1200	Press ENTER to leave at 1200.
Ask For Lane Grouping? No	Press ENTER to leave at No.

If you selected Count or Sensor mode for the first question, the next three questions are skipped.

Speed And Length Format: U.S.	Press ENTER for U.S. (i.e. MPH and Feet).
SnMis Storage Mode: View Only	Press the ENTER key to see Sensor Misses on the screen, but not to store them in memory.

Maximum Axle
Spacing: 35.0'

Press ENTER to keep the default value.

Battery Warning
Voltage: 5.8v

Press ENTER to keep the default value.

SELECT OPTION:
Configure System

The menu has rotated through the Configure System Option and returned to the Starting Collection Menu. Now that the system is configured, press 1.

SELECT OPTION:
Start Collecting

You are now ready to continue with one of the collecting data examples.

V.b. Collecting Raw Data

This section will give an example of collecting Raw Data. Use Example V.a first to configure the system to collect Raw Data. After that example, the display should show:

SELECT OPTION:
Start Collecting

Press ENTER.

Site (15 chars):

Note the blinking cursor on the character line. Use the keypad (Section III.a) to enter in a site ID, for example: HWY 58

Site:HWY 58_____
(Up to 10 chars)

Press ENTER when done.

Info: (1st Line)

Optionally enter a line of information, for example: System Test

Info: (1st Line)
System Test____

Press ENTER when done.

Info: (2nd Line)

Optionally enter a second line of information. Press ENTER when done.

Set The Current
Time: 00:10:15

Note the position of the cursor in the first digit of the time. Start entering the time with hour, minute, and then second. For example, 15:30:00 would be 3:15 pm and zero seconds. Press ENTER when done.

Set The Current Date: 01/01/91	Note once again the position of the cursor & that the date is in the format set in Configure System. Enter the date, and press ENTER.
Set The Current Day Of Week? Sun	Use the arrow keys to toggle to the correct day. Press ENTER when done.
Select 1 2 3 4 Lanes: n n n n	Press the number on the keypad which corresponds to the lanes you want to enable. For this example, press 1.
Select 1 2 3 4 Lanes: Y n n n	Press ENTER.
Info For Lane #1 _____	Use the keypad to enter the direction or some other piece of information about the lane, for example: Eastbound
Info For Lane #1 Eastbound_____	Press ENTER when done.
Directional Mode For Lane #1: No	Since it is a two lane highway with a good chance of vehicles passing, press the right arrow key to toggle the option to Yes. Press enter when done.
Info For Lane #9 _____	Since we created a directional lane, we can now enter information about that lane. For example: Westbound Pass
Info For Lane #9 Westbound Pass_	Press ENTER when done.
Lane #1 Sensor Spacing: 10.0'	Since our example road tubes are at 12.0', type 1,2,0 and press ENTER.
Select Raw Type: Normal Raw Data	Press the arrow to change the option to Enhanced Raw Data (Section II.c). Press ENTER.
Waiting For Any Vehicle....	At this point, the next vehicle to cross the loops will show as a test vehicle. The first vehicle to cross in lane #1 will show something like.
1:14:54:30 2ax 55.4mph 9.0'	The asterisk () means no data is being stored yet. Wait for vehicles in both lanes two pass, and if data is correct, press ENTER.
Select Mode To Start? Now	Since we want to start collection right now, Press ENTER.

```
Select Mode To
Stop? Never
```

Since we are running a test file, Press ENTER.

```
-SETUP COMPLETE-
Press Enter Key
```

Press the ENTER key. The counter is now collecting data as vehicles pass.

Raw data collection has started. After a few vehicles have passed you may want to try the Stop Collection example and then retrieve the data following the instructions in the TrafMan Software Instruction Manual.

V.c. Collecting Binned Data

This section will give an example of collecting Binned Data. Use Example V.a first to configure the system to collect Binned Data. After that example, the display should show:

```
SELECT OPTION:
Start Collecting
```

Press ENTER.

```
Site (15 chars):
_____
```

Note the blinking cursor on the character line. Use the keypad (Section III.a) to enter in a site ID, for example: HWY 58

```
Site:HWY 58_____
(Up to 10 chars)
```

Press ENTER when done.

```
Info: (1st Line)
_____
```

Optionally enter a line of information, for example: System Test

```
Info: (1st Line)
System Test_____
```

Press ENTER when done.

```
Info: (2nd Line)
_____
```

Optionally enter a second line of information. Press ENTER when done.

```
Set The Current
Time: 00:10:15
```

Note the position of the cursor in the first digit of the time. Start entering the time with hour, minute, and then second. For example, 15:30:00 would be 3:15 pm and zero seconds. Press ENTER when done.

```
Set The Current
Date: 01/01/91
```

Note once again the position of the cursor, and that date is in the format set in the "Configure System" option. Enter the current date, and press ENTER.

```
Set The Current
Day Of Week? Sun
```

Use the arrow keys to toggle to the correct day. Press ENTER when done.

Select 1 2 3 4 Lanes: n n n n	Press the number on the keypad which corresponds to the lanes you want to enable. For this example, press 1.
Select 1 2 3 4 Lanes: Y n n n	Press ENTER.
Info For Lane #1 _____	Use the keypad to enter the direction or some other piece of information about the lane, for example: Eastbound
Info For Lane #1 Eastbound_____	Press ENTER when done.
Directional Mode For Lane #1: No	Since it is a two lane highway with a good chance of vehicles passing, press the right arrow key to toggle the option to Yes. Press ENTER when done.
Info For Lane #9 _____	Since we created a directional lane, we can now enter information about that lane. For example: Westbound Pass
Info For Lane #9 Westbound Pass_	Press ENTER when done.
Lane #1 Sensor Spacing: 10.0'	Since our example road tubes are at 12.0', type 1,2,0 and press ENTER.
Collect Axle Bins? No	Change this to "Yes" by pressing arrow key and then press ENTER.
Collect Speed Bins? No	Press the arrow key to toggle to "Yes". Press ENTER.
Collect Gap Bins? No	Leave this at no by pressing ENTER.
Collect Headway Bins? No	Leave this at no by pressing ENTER.
Collect Length Bins? No	Leave this at no by pressing ENTER.
Collect Speed By Axle? No	Leave this at no by pressing ENTER.

Collect Speed By Length? No	Leave this at no by press ing ENTER.
No. of Different Intervals: 1	For this example, two intervals will be set: The first from midnight to 05:00 to early morning traffic, and the second from 05:00 up to mid night for daytime traffic. You may set up different intervals, just follow the same basic steps. Press "2", then press ENTER.
Int Start: 00:00 #1 Length: 00:15	Note the cursor is positioned in the second line, showing 00:15. This is the length of the interval starting at 00:00 (mid night). Change this interval length to 1 hour by pressing 0,1,0,0. Press ENTER when done.
Int Start: 00:00 #2 Length: 00:15	Note the cursor is blinking on the first line. Enter 05:00 for the time to start the second time period. Press ENTER again to leave the intervals at 00:15. The final result is that our time intervals for binned data will be 1 hour from mid night to 5am, and 15 minute for the rest of the day.
Waiting For Any Vehicle....	At this point, the next vehicle to cross the loops will show as a test vehicle. The first vehicle to cross in lane #1 will show something like.
1:14:54:30 2ax 55mph A#2 S#6	The asterisk () means no data is being stored yet. Wait for vehicles in both lanes two pass, and if data is correct, press ENTER.
Select Mode To Start? Now	Since we want to start collection right now, Press ENTER.
Select Mode To Stop? Never	Since we are running a test file, Press ENTER.
-SETUP COMPLETE- Press Enter Key	Press the ENTER key. The counter is now collecting data. Note that it will not start until the beginning of the next even interval (if past 05:00, the next even 15 minutes).

Binned data collection has started. After a few record intervals have passed you may want to try the Stop Collection example and then retrieve the data following the instructions in the TrafMan Software Instruction Manual.

V.d. Collecting Count Data

This section will give an example of collecting Count Data. Use Example V.a first to configure the system to collect Count Data. After that example, the display should show:

SELECT OPTION: Start Collecting	Press ENTER.
------------------------------------	--------------

Site (15 chars): _____	Note the blinking cursor on the character line. Use the keypad (Section III.a) to enter in a site ID, for example: HWY 58
Site:HWY 58_____ (Up to 10 chars)	Press ENTER when done.
Info: (1st Line) _____	Optionally enter a line of information, for example: System Test
Info: (1st Line) System Test_____	Press ENTER when done.
Info: (2nd Line) _____	Optionally enter a second line of information. Press ENTER when done.
Set The Current Time: 00:10:15	Note the position of the cursor in the first digit of the time. Start entering the time with hour, minute, and then second. For example, 15:30:00 would be 3:15 pm and zero seconds. Press ENTER when done.
Set The Current Date: 01/01/91	Note once again the position of the cursor, and that date is in the format set in the "Configure System" option. Enter the current date, and press ENTER.
Set The Current Day Of Week? Sun	Use the arrow keys to toggle to the correct day. Press ENTER when done.
Select 12345678 Lanes : nnnnnnnn	Press the number on the keypad which corresponds to the lanes you want to enable. For this example, press 1 & 2.
Select 12345678 Lanes: Ynnnnnnn	Press ENTER.
Info For Lane #1 _____	Use the keypad to enter the direction or some other piece of information about the lane, for example: Westbound
Info For Lane #1 Westbound_____	Press ENTER when done.
Select Lane #1 Mode: Normal	Since we have set our road tubes up for lane subtraction, change this to Subtraction with the arrow keys and press ENTER.
Info For Lane #2 _____	Use the keypad to enter the direction or some other piece of information about the lane, for example: Eastbound

Info For Lane #2 Eastbound_____	Press ENTER when done.
No. of Different Intervals: 1	For this ex am ple, one in ter val length will be set. Press "1", then press ENTER.
Record Interval Length: 00:15	Change this in ter val length to 1 hour by press ing 0,1,0,0. Press ENTER when done.
Testing Lanes..* 1: 0 2: 0	At this point, the next ve hi cle to cross the road tubes will show as a test ve hi cle. The first ve hi cle to cross in the east bound lane will show:
Testing Lanes..* 1: 0 2: 1	The as ter isk (*) means no data is be ing stored yet. Wait for ve hi cles in both lanes to pass, and if count is cor rect, press ENTER.
Select Mode To Start? Now	Since we want to start col lec tion right now, Press ENTER.
Select Mode To Stop? Never	Since we are run ning a test file, Press ENTER.
-SETUP COMPLETE- Press Enter Key	Press the ENTER key. The coun ter is now col lect ing data.

Count data col lec tion has started. Note that the coun ter will not ac tu ally be gin stor ing record in ter vals un til the be gin ning of the next re cord pe riod. In this ex am ple, the next even hour (11:00:00). After a few re cord in ter vals have passed you may want to try the Stop Col lec tion ex am ple and then Re trieve the data fol low ing the in struc tions in the TrafMan Software In struc tion Man ual.

V.e. Collecting Sensor Data

This sec tion will give an ex am ple of col lect ing Sen sor Data. Use Ex am ple V.a first to conf ig ure the sys tem to col lect Sen sor Data. Af ter that ex am ple, the dis play should show:

SELECT OPTION: Start Collecting	Press ENTER.
Site (15 chars): _____	Note the blink ing cur sor on the char ac ter line. Use the key pad (Sec tion III.a) to en ter in a site ID, for ex am ple: HWY 58
Site:HWY 58_____ (Up to 10 chars)	Press ENTER when done.

Info: (1st Line) _____	Optionally enter a line of information, for example: System Test
Info: (1st Line) System Test_____	Press ENTER when done.
Info: (2nd Line) _____	Optionally enter a second line of information. Press ENTER when done.
Set The Current Time: 00:10:15	Note the position of the cursor in the first digit of the time. Start entering the time with hour, minute, and then second. For example, 15:30:00 would be 3:15 pm and zero seconds. Press ENTER when done.
Set The Current Date: 01/01/91	Note once again the position of the cursor, and that the date is in the format set in the "Configure System" option. Enter the current date, and press ENTER.
Set The Current Day Of Week? Sun	Use the arrow keys to toggle to the correct day. Press ENTER when done.
Select 12345678 Lanes : nnnnnnnn	Press the number on the keypad which corresponds to the lanes you want to enable. For this example, press 1 & 2.
Select 12345678 Lanes: YYnnnnnn	Press ENTER.
Info For Lane #1 _____	Use the keypad to enter the direction or some other piece of information about the lane, for example: TWO LANES
Info For Lane #1 TWO LANES_____	Press ENTER when done.
Info For Lane #2 _____	Use the keypad to enter the direction or some other piece of information about the lane, for example: ONE LANE
Info For Lane #2 ONE LANE_____	Press ENTER when done.
Waiting For Any Sensor....	At this point, the next vehicle to cross the tubes will show as a sensor activation and will look something like:
1:14:54:30.00 8944123 A On	The asterisk () means no data is being stored yet. Wait for sensor activations in both lanes, and if data is correct, press ENTER.

```
Select Mode To
Start? Now
```

Since we want to start collection right now, Press ENTER.

```
Select Mode To
Stop? Never
```

Since we are running a test file, Press ENTER.

```
-SETUP COMPLETE-
Press Enter Key
```

Press the ENTER key. The counter is now collecting data as vehicles pass.

Sensor data collection has started. After a few vehicles have passed you may want to try the StopCollection example and then retrieve the data following the instructions in the TrafMan Software Instruction Manual.

V.f. Monitoring Traffic & Viewing Status

This section gives an example of monitoring traffic while the Phoenix is collecting data. This does not affect data collection - it allows the user to monitor the Phoenix to ensure that the system is functioning properly as the user has set it up.

To start, you will need a Phoenix which has been installed and is collecting data. If you have followed any of the last 4 examples, it will work fine. If not, follow one of the examples for installation and return to this section.

While collecting, the screen is normally blank indicating the counter is in a special "Sleep" mode, press ENTER to wake it up and the display will show:

```
SELECT OPTION:
Stop Collecting
```

Press the 4 key.

```
SELECT OPTION:
Monitor Lanes
```

Press ENTER to select option.

The next screen depends on the type of data you are collecting, for Raw and Binned you will see:

```
Waiting For Any
Vehicle....
```

When the next vehicle data is collected, the display will show the vehicle on the screen.

If you are collecting Count data, your screen will show something like:

```
Monitoring Lanes
1: 134 2: 99
```

The actual lane numbers and totals depend on your current setup. As each sensor is activated the new totals for that lane are displayed.

If you are collecting Sensor data, the Phoenix will show:

Waiting For Any
Sensor....

When the next sensor is activated, the display will show the sensor on the screen.

When finished monitoring, press the ENTER or CLEAR key to return to the menu.

SELECT OPTION:
Monitor Lanes

Use the arrow keys (or press "3") to scroll to the "Show Status" option.

SELECT OPTION:
Show Status

Press ENTER.

Total Mem: 68536
Mem Left: 68084

Note the above memory messages will depend upon how much memory is installed in your system and how much has been used. Refer to Appendix B for memory usage information. Press ENTER.

File #1 is Open
Site:Hwy_58____

This shows that the file is active and collecting data. Press ENTER.

No Loop Boards
Installed

This tells you that there is no loop board installed in the system. Press ENTER.

4 Input Piezo
Board Installed

This tells you that there is a four input Piezo board installed in your counter. Press ENTER.

TAM Interface
Not Installed

This tells you that there is no TAM (Take Away Memory) board installed in the system. Press ENTER.

Time: 10:25:34
Date: 07/15/92

Show the current time and date. Press ENTER again.

Current Battery
Voltage = 6.2v

This is the battery voltage status message. It will tell you if your battery is getting to low. Press ENTER.

SELECT OPTION:
Show Status

You have completed the Show Status Option. Press CLEAR. The display will go blank. The Phoenix is still collecting data and is now in a low power sleep mode.

V.g. Stopping Collection

This section gives an example of Stopping data collection. For information on file retrieval, please read the TrafMan Software Manual. Note that the counter must be setup to start data collection before you can stop collecting.

While collecting, the screen is normally blank indicating the counter is in a special "Sleep" mode, press ENTER to wake it up and the display will show:

SELECT OPTION:
Stop Collecting

Press ENTER.

Sure You Want
To Stop? No

Press either arrow key to toggle to "Yes". Press ENTER.

File Number #1
Is Now Closed.

Note that the file # is the current active file. If you were using Raw Data and you have gone by the examples in this manual, it should show File #1. If you have collected other data files, the file # shown will vary depending upon how many times you have started new files. Press ENTER.

SELECT OPTION:
Start Collecting

Note that the Phoenix has automatically returned to the Not Collecting Menu from where you started the examples. However, if you select the "Show Status" option and ENTER through the messages, you will note that there are now files recorded in memory.

These files can be retrieved by the TrafMan Software. Power may now be turned off to the unit without losing any data stored in the files.

V.h. File Deletion

If all the examples have been followed, several files will have been created in memory. To remove unwanted files, use the Delete File Option, available from either while collecting or when not collecting.

If the system is in sleep mode, press ENTER to wake the counter up. The display will show:

SELECT OPTION: Stop Collecting	Press the arrow keys (or press "2") until the display shows:
SELECT OPTION: Delete Files	Press ENTER to select the option.
(4) Delete What Files? All Files	This shows there are 4 files in memory. Press the arrow keys until the option "Single" appears and press ENTER.
# 1:HWY_58_____ n 2176 03/17/92	This shows file #1 Site ID is HWY 58. The n means the file has not been retrieved by a PC Computer. 2176 is the file size in bytes, and 3/17/92 was the date the file was collected. By pressing the arrow keys, different files showing the same information will appear in the display. Select #1, and press ENTER.
Delete File #1 You Sure? No	Press the arrow key to toggle to "Yes". Press ENTER.
Wait, Deleting	This will appear while the counter is deleting the file.
# 1:TEST_____ n 12176 03/21/92	This shows that the next file (the old file #2) has become file #1 after you deleted the old file #1. You can go ahead and delete more files, or press CLEAR to backup one step.
(3) Delete What Files? Single	Note the number of files have changed. Press CLEAR again.
SELECT OPTION: Delete Files	You are now back at the original menu you started with.

V.i. Collecting Data Using Lane Grouping

This section will show you how to enable the Lane Grouping function to collect Grouped Count Data on four lanes. To collect grouped binned data, simply change the storage mode. First, follow example V.a to configure the system to collect count data. Stop When you get to the following question in the Configure System option.

Ask For Lane
Grouping? No

Press right arrow to select Yes then press ENTER to continue. Follow through the remainder of V.a. to finish the system configuration.

Now that Lane Grouping has been enabled, go to example V.d. (collecting Count Data) and follow all instructions until you get to the following screen, then follow the below instructions:

Select 12345678
Lanes : nnnnnnnn

Press the number on the keypad which corresponds to the lanes you want to enable. For this example, press 1,2,3, & 4.

Select 12345678
Lanes: YYYynnnn

Press ENTER.

Select Number Of
Groups? 0

This question allows you to select the number of groups. Press 2.

Select Number Of
Groups? 2

Press ENTER to continue.

You will next need to assign the lanes you want to be long to each group.

Group #1 Lanes:
(none)

Press 1 and 2 to assign lanes 1 and 2 to Group #1.

Group #1 Lanes:
1,2

Press ENTER

Group #2 Lanes:
(none)

Press 3 and 4 to assign lanes 3 and 4 to Group #2.

Group #2 Lanes:
3,4

Press ENTER to continue. Go back to the V.d. to finish out starting the counter to collect count data.

That's it. When data collection is finished and you retrieve the data from this counter you will actually end up with only two lanes of data (Lanes #1 and #2). Lane #1 (which is actually Group #1) will contain the combined totals of physical Lane #1 and #2 data. Lane #2 (which is actually Group #2) will contain the combined totals of physical Lane #3 and #4.

VI. TAM Interface

The Unicorn/Phoenix/Pegasus series of traffic counters all support an optional TAM (Take Away Memory) Interface Board. This "interface" consists of a plug in slot on the face panel of the counter and one or more TAM Cards.

The TAM Interface is used to provide a very fast and simple way of retrieving data from your traffic counters, and to allow easy and quick programming of the traffic counter. The TAM interface eliminates the need for the user to bring a laptop or ROVER to the field because all collected data can be stored on the credit card sized TAMs, and then brought back to the office for use by your PC.

There are three distinct uses for a TAM Card, listed below:

- As extended memory for the traffic counter.
- As a data retrieval system for retrieving data after it has been collected by a counter.
- As a on-site counter programmer (i.e. Autostart!).

Each of these three uses is described below, as well as a overview of using TAM Cards and a description of how to transfer data stored on the TAM card into your PC.

VI.a. Using TAM Cards

A TAM Card is nothing more than a Flash Memory Card that has been customized programmed at the Diamond Traffic Products factory for use in our traffic counters. The TAM card slot in the panel of the counter is PCMCIA type II slot and is designed to support many new types of cards that will be available in the future.

There are many different sizes of TAM cards available, ranging from 256k to 8Meg. The counter will automatically identify the size of any card inserted and treat it appropriately. You CAN NOT purchase any Flash Memory card and use it with the traffic counter. You MUST purchase all memory cards to be used with Diamond counters from Diamond Traffic Products. This is because Diamond screens all memory cards and then preprograms the qualifying cards for our customers. The traffic counter will simply ignore any card that did not come from Diamond Traffic Products.

Although the memory cards are solid state and generally very durable, please follow all cautionary measures as printed on the back of the cards. At a minimum, you can expect to fill your card and then erase it ten thousand times before it fails.

To insert a TAM card into the counter:

Orient the TAM card so that looking at the end of the card the write protect switch is closest to the eject button. Slide the card into the slot and press down firmly until you feel a definite stop. The green light should blink and the eject button should be out as high as the TAM card.

To remove a TAM card from the counter:

Push the eject button down and then remove the TAM. NEVER, EVER, REMOVE A TAM WHEN THE GREEN LIGHT IS ON! You might ruin the TAM and have to send it back to the factory.

VI.b. Transferring TAM Data to your PC

The next two sections, VI.c. and VI.d, cover how to put data collected by a traffic counter onto a TAM card. This section covers how to get this data off of the TAM and into your PC. To do this you will need to use your counter as a TAM Memory Card Reader.

Basically, you will need to have a traffic counter in the office of the PC you plan to transfer the data to. This counter will become the TAM Memory Card Reader. Note that the counter can serve double duty as a regular traffic counter and a reader, it just has to be in the office when TAM cards need to be read. Any traffic counter that has a TAM Interface can serve as a TAM Memory Card Reader.

To turn any counter into a TAM Memory Card Reader, simply turn the counter off (if it was on) then turn it on and press the SPACE key during the Self Test. The counter screen will change to show:

TAM Memory Card
Reader Vx.xx...

x.xx is the current TAM Card Reader version number. After a short pause, the counter will show (if you don't already have a TAM Card Inserted):

Insert TAM Card
Into Slot...

Insert a TAM Card and the screen will display:

Execute TrafMan
Link Up...

At this point, you need to execute (run) the TrafMan Software and select the Counter function from the main menu. TrafMan will recognize the counter as a TAM Memory Card Reader and let you link to it. TrafMan will allow you to retrieve data from the TAM Card, put in other TAM Cards, erase TAM Cards, set up a TAM card as an Autostart Card, plus a whole host of other features. See the TrafMan Software Instruction Manual for more information.

After becoming a TAM Memory Card Reader, you can return the counter to its regular operating mode by pressing the CLEAR key on the counter keypad, or turn the counter off/on.

IMPORTANT NOTE ABOUT TAM CARDS & EPROM VERSIONS: The TAM Card and the EPROM Version inside your traffic counter must be compatible in order for the TAM Card to function. In compatible versions can cause your counter to lock up, erase data, or a variety of other problems. If you have an incompatible card and/or EPROM, please contact Diamond Traffic Products for upgrade information.

You can determine what version you have by turning on the counter (which will show you the counter version) and then pressing the <Space> key during self test to see what version of the TAM Card Reader you are. Refer to the table below for version compatibility:

Unicorn Version	Pegasus Version	Phoenix Version	Compatible With TAM Card Version
1.80	1.00	1.50	1.30
1.81-1.92	1.10-1.12	1.51-1.62	1.60
2.00-2.12			2.00-2.05
2.20-2.21			2.10

VI.c. TAM as extended memory for your counter

The counter comes default with 68K of data storage. If you plan on collecting a lot of traffic data between retrievals, your counter may run out of memory and stop collecting. To prevent this, you can dramatically increase the amount of memory by inserting a TAM card prior to starting collection.

If a TAM card is inserted into the counter PRIOR to collection being started, the counter will enter a special mode in which it will automatically copy out all files to the TAM Card whenever a file is closed. Generally, users will enable Daily Files and enable Erase First File When No Memory from the Configure System menu when using this mode.

If Daily Files and Erase First File When No Memory is enabled, then the counter will close the current file at midnight and open a new file. When the current file is closed, the counter will copy it to the TAM card and mark it as retrieved. When the counter runs out of memory, it will start erasing the oldest data to make room for the new data. In this case, the oldest data will be files that are already copied to the TAM and therefore not needed.

For example:

- 1) Joe Traffic sets up a Phoenix by the road side. He is going to collect a lot of data before returning to the site, so he knows that he will need a TAM Card to extend the memory.
- 2) Joe goes into the Configure System option and enables Daily Files and Erase First File When No Memory.
- 3) Joe goes into Start Collecting and sets up the counter to collect his data. When he gets to the "—SETUP COMPLETE—Press Enter Key" screen, he inserts a TAM card, watches the green light flash, and presses ENTER.
- 4) Joe closes the counter up and leaves for 15 days.
- 5) Joe returns to the site, opens the counter up and uses the monitor lanes function to insure everything is working properly. Joe uses the show status option to check the battery level and decides he has enough juice to run another 15 days, but he wants the first 15 days now.
- 6) Joe pops out the TAM card (that contains the first 15 days) and inserts a new TAM Card to store the data for the next few days.
- 7) Joe hands the first TAM Card to his boss and promptly receives a raise for such commendable work!

Joe did everything correctly. The most important thing to remember about using TAM Cards as extended memory is that the counter will only transfer FILES to the TAM card, so you must enable daily or weekly file creation to have data transferred automatically to the counter. If, when Joe returns, he opens up the counter and selects Stop Collection, the counter will immediately transfer the last file to the TAM Card.

Note that Joe did not have to wait until the very end of the Start Collecting process to insert a TAM Card. The card can be inserted any time BEFORE collecting starts (including before the counter is started).

Joe can insert/remove TAM cards at any time while collecting as long as a file is not closed when a TAM card is out (if Joe removed the card at 11:59pm and did not insert another until 12:02am). If this happens, the counter will no longer copy files out to the TAM.

VI.d. Retrieving data from a counter with your TAM

As described in the previous section, you plug a TAM card into your counter and have the counter transfer data to the TAM as each file is created. Alternatively, you can use the TAM Card to retrieve files from a counter any time after it has been collected.

The SPACE key on the counter keypad is used to access a variety of TAM functions, and will work when any of the following screens are displayed on the counter:

```
SELECT OPTION:
(any option)
```

```
Phoenix Vx.xx?
<(any mode)>
```

Pressing the SPACE key will, providing you have the TAM interface hardware, cause the following series of screens to appear:

```
Insert TAM Card
Into Slot...
```

If you press <Enter> key before inserting a TAM Card, you can see what version of the TAM Card Reader you have. See section VI.b to determine version compatibility between the TAM Card and your counter EPROM.

This screen appears any time a TAM Card is not inserted. Press the <Clear> key to return to the screen you were at prior to pressing the <Space> key. Insert a TAM card to continue.

```
<aaaaa> <ss> TAM
<mm> Free <x>F
```

<aaaaa> is the manufacturer of the TAM card. <ss> is the size of the TAM card. <mm> is the amount of memory left on the TAM card. <x> is the number of data files stored on the TAM card.

This screen is the TAM STATUS SCREEN. This is a very important screen because it tells you all about the TAM card that is currently inserted. You should use this screen to verify that the TAM card you are inserting has enough memory available for the use you intend. In addition, you can verify that the TAM card is operating correctly. NOTE: It is normal for the first 12K of an erased TAM to be used.

Press <Enter> or <Space> to continue.

```
No Unretrieved
Files In Counter
```

```
Unretrieved Data
Files In Mem:<x>
```

<x> is the number of unretrieved files in the counter memory.

The counter is telling you if you have any unretrieved data files in the memory of the counter. The counter assumes that you will want to transfer any unretrieved data files to the TAM card, so it is informing you if there are any.

If you have any unretrieved files in memory, the following screen will appear after you press <Enter>:

```
Copy Unretrieved
Data to TAM? Yes
```

Press <Enter> to select, <Space> or arrow keys to toggle choice between Yes and No.

Select yes to copy all of the unretrieved data files to the TAM card. Select no to not copy the files. If you select yes, the screen will change to show:

```
Copying Files
To TAM...
```

This will appear while the copy is going on. The green light will also be on during the copy.

If the TAM Card does not have enough memory left to hold the file, then the following message will appear:

```
TAM Card Is Out
Of Memory!
```

After all of the unretrieved files have been copied (if any), the counter will present you with the TAM Functions Menu. The screen will change to show:

```
SELECT FUNCTION:
(function)
```

Use the arrow keys to select a function, press <Enter> to select it. You can press <Clear> at any time to backup to previous screens. Press <Alt> + <Clear> to return completely out of the TAM Functions.

The options available under this menu are as follows:

```
Copy File To TAM
Erase TAM Card
Quit Functions
```

The Quit Functions option simply returns you out of the TAM Functions Menu (same as <Alt> + <Clear>). The other options are described below.

VI.d.1. Copy File To TAM

This function is used to copy a file out of the memory of the counter and onto the TAM card. It does not matter if the file has already been copied or if the file has been retrieved. After selecting this option, the following screen will appear:

```
ff:ssssssssss rt
zzzzzz dddddd
```

ff is the file number. ssssssssss is the Site ID of that file. r is the retrieved flag (Y if retrieved, N if not). t is the type of data (R-Raw, B-Binned, C-Count, S-Sensor). zzzzzz is the size. dddddd is the start date.

For example, the following screen shows file #3 has a site ID of "Hello", has never been retrieved, is binned data, is 1300 bytes long, and data collection started on March 3rd, 1993.

```
#3:Hello_____ nB
1300 03/03/93
```

To copy this file to the TAM Card, press the <Enter> key. To select other files, press the arrow keys. To return to the TAM Functions Menu, press <Clear>.

If the TAM Card does not have enough memory left to hold the file, then the following message will appear:

```
TAM Card Is Out
Of Memory!
```

VI.d.2. Erase TAM Card

This function will erase a TAM Card thereby removing all files stored on the card. Normally, users will use the TrafMan Software to do this function but it might be necessary for a user in the field to need to erase a TAM.

The TAM card will also maintain a flag on each file it contains as to whether or not the data has ever been retrieved from the TAM Card and into your PC. If the TAM card contains data files that have never been retrieved, the display will show:

```
Not All TAM Data
Retrieved! <ff>F
```

<ff> is the number of files on the TAM card that have not been retrieved.

Press <Enter> to continue, press <Clear> to abort. If you press <Enter>, the screen will show:

```
Sure You Want To
Erase TAM? No
```

Use the arrow keys to toggle the answer between Yes and No. Press <Enter> to select, <Clear> to abort erase.

During the erase, the counter screen will change to show:

```
Erasing TAM Card
<x>% Done
```

The <x> represents what portion of the erase has been completed (from 0 to 100 per cent). Time to erase a typical 256K TAM is about 50 seconds. Larger TAMs require multiples of 50 seconds. For example a 512K size TAM requires twice as much time as 256K, or about 1 minute and 40 seconds.

Erasing a TAM does use up some battery power. Erasing one 256K TAM in 50 seconds is equivalent to running the counter for about 20 minutes in normal operation.

REMEMBER: NEVER REMOVE A TAM CARD WHEN THE GREEN LIGHT IS ON!

VI.e. TAM as a counter programmer (Autostart)

A TAM card can be configured to automatically set some or all of the counters operating parameters when it is inserted and the power is turned on. This is called Autostarting the counter and the TAM card used to do this is called an Autostart Card. This is very useful to setup a counter quickly when a known type of data/configuration is to be used.

You must use the TrafMan Autostart Creation function to setup a TAM Card to be an Autostart card. Refer to the TrafMan Software Instruction Manual for more information. Note that setting a TAM card to be an Autostart card in no way interferes with the TAM cards ability to retrieve data from the counter. All other TAM card features are supported even if the TAM is configured to be an Autostart card.

The autostart feature only works when an Autostart TAM card is inserted in the counter and the counter is then turned on. Inserting an Autostart card any time after a counter is on will have no affect. You will know the counter is autostarting when the green light blinks twice on power up (instead of once).

VII. In-Day Times

The Phoenix has a special function called In-Day Times. In-Day Times are time periods in the day that you wish to Start and Stop collecting data. This is similar to the Daily Files function except you can Start and Stop collection several different times during a 24 hour period. The basic purpose of this function is to handle very large data collection requirements where you only have memory enough in the counter to store part of a day, and you want to transfer the data to a TAM card several times during the day.

A day can have up to four Start/Stop periods. You do not need to collect data during the entire day nor do you need to make sure that these periods of collection follow each other exactly. For example, you could collect data from 8am to noon, and then from 4pm to 8pm. The rest of the day no data would be collected and the counter is considered to be in the Pre Set Mode (see section IV.c.6).

In-Day times will work with any type of data collection (Raw, Binned, Count, or Sensor). If collecting Binned or Count data and you do not specify an In-Day Stop Time at the end of an interval, then you will lose the data of the current interval unless the next In-Day Start time is the same as the current In-Day stop time.

For example, suppose you are collecting Binned data in 1 hour intervals and you have specified an In-Day period from 10:00 to 11:30 and a second In-Day Period from 11:30 to 14:00. The counter will close the current file at 11:30 and then open a new file immediately because the next In-Day period starts at 11:30. The current binned data interval (which is from 11:00 to 11:59) will be preserved and will be written to the second file as its first interval even though the file was opened at 11:30. This is identical to retrieving the open file data when it is in the middle of an interval.

On the other hand, had you specified the second period to start at 12:00. Then all of the data from the 11:00 to 11:59 interval will be lost and the first interval written to the new file will start at 12:00.

You should be aware that In-Day times do not take affect until the counter first begins data collection according to the Start Mode (which can be Now, Midnight, or at a Date & Time). Until the very first file is opened according to all other counter settings, the In-Day Times will have no affect.

To Setup a Counter to use In-Day Times:

- 1) Link to the counter with TrafMan (version 3.50 or later) and go to the main link screen. You will see a new option called Set In-Day Times on the menu.
- 2) Select the Configure System option and setup all counter system parameters.
- 3) Select the Set In-Day Times function and select the number (0 to 4) and the times of all In-Day Time periods. Note that you must enter the times in order from the earliest to the latest.
- 4) Select the Start Collecting function and setup, test, and begin data collection.

That's it. After the very first file is opened the counter will then begin to check the In-Day Time settings to see if any specific time periods in the day have been tagged for data collection.

To use a TAM card in conjunction with the In-Day Times:

Because the In-Day Times function operates just like the Daily Files Function, each time a file is closed and a TAM card has been inserted at the beginning of data collection, then the newly closed file will be copied out onto the TAM card. As time goes on and memory fills, the "Erase First File When No Mem" function will start erasing earlier files that have already been copied to the TAM to make room for new files.

The field user simply has to go to the site, remove the TAM card that is inserted into the counter, and then insert a blank replacement card. The TAM card that was in the counter is then returned to the office where it can be read and erased for future use.

VIII. Call-Back System

The Phoenix has a function which allows the counter to actually call up a remote computer with a modem and make a report if a particular lane goes down. This could happen if a sensor fails (such as a loop) or there is some sort of other problem which causes the system to stop collecting data properly.

The counter determines if a lane has gone down based upon the number of SnMis (Sensor Misses) that are continuously detected. You can set the number of these SnMis that occur in a row (such as 15) to trigger the counter to make a call back and report the failure.

The remote computer should be a PC compatible computer that is connected to a Hayes compatible smart modem. You will also need to have TT-Link installed on the computer (or any similar communication program, such as Procomm).

Note that the Call Back function only operates when the counter setup as follows:

- It is in Raw or Binned data collection mode.
- It is connected to a Smart Modem.
- It is not currently being used, either with the keyboard or through the serial port.
- The # Of SnMis To Call Back question is greater than zero (see below).
- The Call Back Dial Command starts with a "AT" (see below).
- It is collecting data.

If any of the above are not true, the the Call-Back system is disabled.

Follow the below steps to setup your counter to perform Call-Backs:

- 1) Link to the computer using TrafMan V3.50 or later.
- 2) At the main link screen, press <Alt+F10>.
- 3) You will see two questions that pertain to the Call Back Function. These are "Call Back Dial Command?" and "# Of SnMis To Call Back?".
- 4) Move the cursor to the Call Back Dial Command question. You must enter in a valid dial command for the modem that is connected to the counter. In most cases, this will be something like "ATDT <phone number>".
- 5) Move the cursor to the # Of SnMis To Call Back question. The default, zero, disables the Call-Back system. Enter in any other number up to 250 to specify the number of SnMis that must occur on a lane in a row before the call-back system is triggered.
- 6) Press <Enter> until you have returned to the main counter link screen, then press <Esc>.
- 7) If not connected to a smart modem, then follow all steps to setup counter to work with a smartmodem.
- 8) Start the counter collecting data.

That's it. The counter will do a Call-Back the next time a lane gets the correct amount of SnMis in a row.

Follow the below steps to setup your computer to receive Call-Backs:

- 1) Connect your computer to a smart modem that is connected to an outside line.
- 2) Run the TT-Link Software.
- 3) At the main console screen, press <F2> to setup the serial protocol.
- 4) Select the COM port and Baud Rate that the counter(s) will be calling to make the Call-Back report.
- 5) Type "AT" and press <Enter>. If you are communicating to the modem, you should receive a "OK" or "O" as a response. If you do not, then either the modem is not working, you have not connected the modem properly, or you have selected the wrong COM Port or Baud rate.
- 6) Type "ATS0=1" and press <Enter>, this is the universal AT Command which tells your modem to answer the phone when it rings and try to link to a remote modem.
- 7) Press <Alt+C> to clear the screen.

You are now ready to receive incoming Call-Backs. Optionally, you can store the Call-Back reports on disk by pressing the <PgDn> key, selecting ASCII, and then entering the name of the file to store the reports to.

What Happens When A Counter Decides To Make A Call-Back?

The counter will display the following first message on the screen and then issue the Call-Back Dial Command to the modem. After the dial command is sent, the counter displays the second message and waits for a carrier to be detected (will wait up to two minutes).

Calling To Make
SnMis Report...

Waiting For Host
Modem To Answer

If, after two minutes, no carrier is detected. Then the counter will go back and reissue the dial command and wait again for a remote carrier. This will go on for up to three attempts before the counter gives up trying to communicate to a remote computer. If a remote carrier is detected, the counter displays the first message shown below, sends the Call-Back report, and then displays the second message shown below while hanging up the modem. After the modem is disconnected, the counter returns to the <Smart Modem> screen and waits for an other lane to fail or for the user to access the serial port or keyboard.

Sending Failure
Report To PC...

Now Hanging Up
Modem...

The failure report will be in the following format:

```
Phoenix <version> SnMis Call Back (Ser#:<ser #>) For Site: <site>
Time: <current time> Date: <current date>
--> SnMis Failure On Lane #<lane #>
```

Note that if you call up and communicate with the counter or you use the counter's keyboard, then the Call-Back system is reset and you will be re-called if a lane fails again. The counter presumes you will solve the problem while you are using it (either with the keypad or through the serial port).

IX. Appendix

Appendix A. Trouble shooting

This Section is intended as a guide towards installation trouble shooting. It is in no way intended for the service or repair of any type of Phoenix system.

Some basic problems can always occur during operation. Generally, they will be some smaller error in setup or sensor installation. Listed are some basic problems and possible solutions. If you can not solve an installation problem, or if you find a new solution to an old problem, please call Diamond Traffic Products. We are glad to help solve any type of installation problem or receive new installation information.

Problem	- Tubes are installed to collect Raw or Binned data, but errors keep occurring in data collection.
Solution	- Are the tubes the same length? Are they stretched tight (both the same amount if using two tubes per lane) across the road way? Are there holes in the tubes (you can check this by plugging the tube and putting it under water)? Is the end of the tube which is not being connected plugged properly?
<hr/>	
Problem	- I've installed loops in the road, but I am not getting axle counts. Why?
Solution	- The loops will not detect individual axles. They are Presence Sensors which will let the Phoenix know if a vehicle is present only. Tubes or Piezo Sensors must be used for axle counting. If you are not equipped for tubes, and you need axle counting capability, contact Diamond Traffic Products.
<hr/>	
Problem	- I've installed tubes to collect raw vehicle data, but I keep getting errors. I check the "Test Sensor" option, and the tubes are functioning.
Solution	- Are the tubes in the correct order? Remember - the tubes must be connected in sequence depending on your lane assignment and configuration. Check the Tables in Section II. a for confirmation. You may have a lane installed backwards. Another possible problem is bi-directional traffic. Do you have the Directional Option enabled?
<hr/>	
Problem	- I have installed a Phoenix in a busy road way. The counter has stopped collecting data when I arrive. Everything seems to be working.
Solution	- Check the Show Status option. Is the memory full? You may need to retrieve the data from the counter more often.
<hr/>	

Appendix B. Memory Usage

Each mode uses a different amount of memory for storing traffic data. This appendix is intended to give the user an approximation of how long a Phoenix Field Unit may collect data before retrieval must be performed. Note that this is only a guide - it is recommended to retrieve data as often as is practical from the units, and deleting retrieved files from the memory (unless Erase First File When No Mem is enabled). Different configurations may store different amounts of data. For example, the amount of memory to store a single 2 axle vehicle in Raw Mode is 7 bytes if you are using axle sensors, and 7 if you are using presence sensors (loops). A 5 axle vehicle in the same mode will take 13 bytes if you are using axle sensors, but still seven if you are using presence sensors (the individual axle lengths are not stored since loops can not see the individual axles).

The following tables give you formulas for calculating how much memory any particular storage mode might take. Simply find the table that most closely matches your application, and follow the steps described.

Appendix B.1. Raw Data Collection

Raw data stores each individual vehicle in memory, therefore the amount of memory used is directly dependent on how many vehicles pass the sensors. An other important factor is the number of axles per vehicle (more axles require more memory).

Generally, you can use the average of 2.75 axles per vehicle for most highways. If your site differs from this, you may wish to increase or decrease the numbers given below.

To calculate how many vehicles you can store with the Phoenix follow the below steps:

- Calculate the base average number of bytes per vehicle using the chart below:

SENSOR CONFIGURATION	NORMAL RAW DATA	ENHANCED RAW DATA	RAW DATA WITH BINS	ENHANCED & BINS
Axle-Axle Axle-Pres-Axle Pres-Axle-Pres	8.5	12.5	13.5	17.5
Pres-Pres	7	9	12	14

- Divide the Total Memory of your counter minus 2000 (for overhead) by the base number of bytes from the chart above. The total amount of memory in your counter can be found using the Show Status option (a standard Phoenix comes with 68536, which gives about 7800 vehicles for Normal Raw Data, Axle-Axle sensors).

Appendix B.2. Binned Data Collection

Binned data stores data as the total number of vehicles in each bin category every record interval. The three most important factors are: Which bin categories are enabled, What are the record interval lengths, and How many lanes are enabled.

Follow the steps outlined below to calculate how long your Phoenix can collect data with any given setup:

- Using the table below, calculate the base number of bytes in a single record period, for a single lane. This is done by adding up all the different modes you have enabled (Axle, Speed, Length, etc.). The table gives two values, the first is the default number if you have not modified the bin table configuration, the second is a formula you can use to calculate the number if you have put in your own bin table specifications.

Note that "SnMis Bins" are created if you select "View&Store" from the "SnMis Storage Mode?" question in the Configure System option.

Axle Class	Speed Class	Length Class	Gap Class	Headway Class	Speed x Length	Speed x Axle	SnMis Bins
26	32	26	16	16	416	416	8
2 x Bins	2 x Bins	2 x Bins	2 x Bins	2 x Bins	(2xSpd Bin) xLength Bin	(2xSpd Bin) xAxle Bin	

- For example, if you were collecting Axle & Speed classification, your base number of bytes would be $26 + 32 = 58$ Bytes.
- Take your base number of bytes and multiply it by the number of enabled lanes (including directional lanes). Thus, if you had lane 1 enabled with directional, you would have two enabled lanes. This number is the **BASE NUMBER FOR ALL LANES**.
- Adjust the base number for all lanes by adding 1 for each type of classification you have enabled, except SpeedxLength and SpeedxAxle. If you enabled SpeedxLength, add in the number of Length Bins. If you enabled SpeedxAxle, add in the number of Axle Bins.
For example, if you enabled Axle, Speed, and SpeedxAxle classification, you would add $1 + 1 + 13 +$ base number for all lanes = **TOTAL NUMBER OF BYTES PER RECORD INTERVAL**.
- The next step is to take the total number of bytes in your Phoenix, subtract 2000 (for overhead), and divide it by the total number of bytes per record interval. This gives you the **NUMBER OF RECORD INTERVALS THE MEMORY WILL HOLD**. Total number of bytes in your Phoenix can be determined by using the Show Status option. A standard Phoenix contains 68632 bytes.
- Next, multiply the total number of record intervals the memory will hold by the record interval length (in minutes). This gives you the total length of time, in minutes, the Phoenix will operate.
- You are basically done. You can calculate number of hours by dividing the time in minutes by 60, or the number of days by dividing the time in minutes by 1440.

The above system works only if you do not have different record interval lengths during the day.

Appendix B.3. Count Data Collection

Count data stores the total number of vehicles (if using a presence sensor) or the total number of axles that crossed the sensors for a given time period. The two factors to consider are: How many lanes are enabled, and What is the record interval length.

Follow the steps outlined below to calculate how long a Phoenix will collect count data:

- Multiply the total number of enabled lanes by 2.
- Add one to the number. This is the TOTAL NUMBER OF BYTES PER RECORD INTERVAL.
- The next step is to take the total number of bytes in your Phoenix, subtracting 2000 (for overhead), and divide it by the total number of bytes per record interval. This gives you the NUMBER OF RECORD INTERVALS THE MEMORY WILL HOLD. Total number of bytes in your Phoenix can be determined by using the Show Status option. A standard Phoenix contains 68632 bytes.
- Next, multiply the total number of record intervals the memory will hold by the record interval length (in minutes). This gives you the total length of time, in minutes, the Phoenix will operate.
- You are basically done. You can calculate number of hours by dividing the time in minutes by 60, or the number of days by dividing the time in minutes by 1440.

The above system works only if you do not have different record interval lengths during the day.

Appendix B.4. Sensor Data Collection

Sensor data storage will store in memory each individual sensor activation. Therefore, the more sensor activations you have, the quicker memory will run out.

Follow the steps outlined below to calculate how many sensor activations can be stored in the memory of the Phoenix.

- Find out the total amount of memory in the Phoenix. This can be determined using the Show Status option. A standard Phoenix contains 68632.
- Subtract from the total amount of memory 2000 bytes, for overhead.
- Divide by 8. This will be the amount of sensor activations which can be stored in memory. A standard Phoenix will hold about 8300 sensor activations.

Appendix C.Plugs & Connectors

This section describes the physical hardware connections for connectors on the Phoenix. Note that the Unicorn, Phoenix, & Pegasus all use identical and interchangeable (in most cases) connectors.

Phoenix/Unicorn/Pegasus 25 Pin Female Serial Interface Cable	
Phoenix/Unicorn/Pegasus 9 Pin Connector	25 Pin Female Sub-D Connector
#1 - Receive Data (RXD)	#2 - Transmit Data (TXD)
#2 - Carrier Detect (DCD)	#20 - Data Terminal Ready (DTR)
#3 - Data Terminal Ready (DTR)	#6 - Data Set Ready (DSR) #8 - Carrier Detect (DCD)
#4 - Ready To Send (RTS)	#5 - Clear To Send (CTS)
#5 - Serial Port Enable (ENA)	#1 - Frame Ground (GND)
#6 - Signal Ground (GND)	#7 - Signal Ground (GND) (Shield)
#8 - Transmit Data	#3 - Receive Data (RXD)
#9 - Clear To Send (CTS)	#4 - Ready To Send (RTS)

NOTE: On the Phoenix/Unicorn/Pegasus 9 Pin Connector, pin #7 is not used, pins #3 and pin #6 get two wires, and pins #5 and #6 are shorted to gether.

Phoenix/Unicorn/Pegasus 9 Pin Female Serial Interface Cable	
Phoenix/Unicorn/Pegasus 9 Pin Connector	9 Pin Female Sub-D Connector
#1 - Receive Data (RXD)	#3 - Transmit Data (TXD)
#2 - Carrier Detect (DCD)	#4 - Data Terminal Ready (DTR)
#3 - Data Terminal Ready (DTR)	#6 - Data Set Ready (DSR) #1 - Carrier Detect (DCD)
#4 - Ready To Send (RTS)	#8 - Clear To Send (CTS)
#5 - Serial Port Enable (ENA)	#5 - Signal Ground (GND)
#6 - Signal Ground (GND)	(Shield)
#8 - Transmit Data	#2 - Receive Data (RXD)
#9 - Clear To Send (CTS)	#7 - Ready To Send (RTS)

NOTE: On the Phoenix/Unicorn/Pegasus 9 Pin Connector, pin #7 is not used, pin #3 gets two wires, and pins #5 and #6 are shorted to gether.

Phoenix/Unicorn/Pegasus 25 Pin Male Modem Interface Connector	
Phoenix/Unicorn/Pegasus 9 Pin Connector	25 Pin Male Sub-D Connector
#1 - Receive Data (RXD)	#3 - Receive Data (RXD)
#2 - Carrier Detect (DCD)	#8 - Carrier Detect (DCD)
#3 - Data Terminal Ready (DTR)	#20 - Data Terminal Ready (DTR)
#5 - Serial Port Enable (ENA)	#1 - Frame Ground (GND)
#6 - Signal Ground (GND)	#7 - Signal Ground (GND) (Shield)
#8 - Transmit Data	#2 - Transmit Data (TXD)

NOTE: On the Phoenix/Unicorn/Pegasus 9 Pin Connector, pins #9 and #4 are shorted to gether and have no wires inserted, pin #5 and #6 are shorted to gether, pin #7 is not used, the RTS (#4) and CTS (#5) wires from the 25 Pin Sub-D are soldered to gether and then sealed with heat shrink tubing, and pin #6 gets two wires.

Phoenix/Unicorn/Pegasus 9 Pin Male Modem Interface Connector	
Phoenix/Unicorn/Pegasus 9 Pin Connector	9 Pin Male Sub-D Connector
#1 - Receive Data (RXD)	#2 - Receive Data (RXD)
#2 - Carrier Detect (DCD)	#1 - Carrier Detect (DCD)
#3 - Data Terminal Ready (DTR)	#4 - Data Terminal Ready (DTR)
#5 - Serial Port Enable (ENA)	Shield
#6 - Signal Ground (GND)	#5 - Signal Ground (GND)
#8 - Transmit Data	#3 - Transmit Data (TXD)

NOTE: On the Phoenix/Unicorn/Pegasus 9 Pin Connector, pins #9 and #4 are shorted to gether and have no wires inserted, pins #5 and #6 are shorted to gether, pin #7 is not used, and RTS (#7) and CTS (#8) wires from the 9 Pin Sub-D are soldered to gether and then sealed with heat shrink tubing.

Phoenix/Unicorn/Pegasus External Loop Harness Cable	
Loop Input Number	Wire Pair
#1	Green/Black
#2	White/Black

#3	Red/Black
#4	Blue/Black

Phoenix/Unicorn/Pegasus Remote Airswitch Harness Cable		
Name	Wire Color	Pin Number
Input #1	White	A
Input #2	Green	B
Input #3	Black	C
Input #4	Yellow	D
Input #5	Red	G
Input #6	Orange	H
Input #7	Blue	J
Input #8	Brown	K
6 Volts Output	Red	E
Ground	Black	F

NOTE: The Pegasus and Unicorn only support up to 4 inputs.

Phoenix 8 Input Resistive Harness Cable		
Name	Wire Color	Pin Number
Input #1	White	A
Input #2	Green	B
Input #3	Yellow	D
Input #4	Orange	H
Input #5	Brown	K
Input #6	Blue	J
Input #7	Red	G
Input #8	Black	C
Common	Bare Wire	E
N/C	N/C	F


Phoenix 8 Input Piezo Electric Harness Cable		
Name	Wire Color	Pin Number
Input #1	White	A
Input #2	Green	B
Input #3	Yellow	D
Input #4	Orange	H
Input #5	Brown	K
Input #6	Blue	J
Input #7	Red	G
Input #8	Black	C
N/C	N/C	E
Ground	Bare Wire	F

Phoenix/Unicorn/Pegasus 4 Input Piezo Electric Harness Cable	
Piezo Electric Input Number	Wire Pair (Black is Ground)
#1	Red/Black
#2	White/Black
#3	Green/Black
#4	Blue/Black

Phoenix/Unicorn/Pegasus 4 Input Resistive Harness Cable	
Piezo Electric Input Number	Wire Pair (Black is Common, not Ground!)
#1	Red/Black
#2	White/Black
#3	Green/Black
#4	Blue/Black

Phoenix/Unicorn/Pegasus 7 Pin Power Connector		
Pin Number (see diagram below)	Internal Wire Color (external color may differ)	Function
#1	N/A	None
#2	N/A	None
#3	Green	AC Input #1
#4	Blue	Solar/12VDC Input
#5	White	User Voltage Output (6V)
#6	Green	AC Input #2
#7	Black	Ground

The following diagram shows the pin numbers of the Phoenix/Unicorn/Pegasus 7 Input Connector. The orientation of the diagram is as if you were looking directly at the connector from the outside of the box.



Appendix D.Default Bin Tables

This appendix describes the default bins categories that are used with the Phoenix. These "Bins" are used to to tal up all ve hi cles meet ing a pre de ter mined set of cri te ria. Note that this in for ma tion is ONLY used if you con fig ure the Phoe nix to col lect data in its Binned Mode. Raw, Sen sor, and Count Modes do not bin data.

Default Axle Bin Classification Table (Scheme-'F')		
Bin Number	Axle Range	Bin Category Name
#1	2	Motorcycles
#2	2-4	Pas sen ger Cars (w/wo trail ers)
#3	2-5	Other two axle, 4 tire ve hi cles (w/wo trailer)
#4	2-3	Buses
#5	2-5	Two axle, six tire, sin gle trailer trucks
#6	3	Three axle, sin gle unit trucks
#7	4	Four axle, sin gle unit trucks
#8	3-4	Four or less axle, sin gle trailer trucks
#9	5	Five axle, sin gle trailer trucks
#10	6-10	Six or more axle, sin gle trailer trucks
#11	5	Five axle, multi-trailer trucks
#12	6	Six axle, multi-trailer trucks
#13	7-13	All Other Ve hi cles

Default Speed & Length Bin Classification Table		
Bin Number	Speed Range	Length Range
#1	0.0 - 19.9 mph	0.0 - 5.9 feet
#2	20.0 - 24.9 mph	6.0 - 10.0 feet
#3	25.0 - 29.9 mph	10.1 - 14.9 feet
#4	30.0 - 34.0 mph	15.0 - 19.9 feet
#5	35.0 - 39.9 mph	20.0 - 24.9 feet
#6	40.0 - 44.9 mph	25.0 - 29.9 feet
#7	45.0 - 49.9 mph	30.0 - 39.9 feet
#8	50.0 - 54.9 mph	40.0 - 49.9 feet
#9	55.0 - 59.9 mph	50.0 - 59.9 feet
#10	60.0 - 64.9 mph	60.0 - 69.9 feet
#11	65.0 - 69.9 mph	70.0 - 79.9 feet
#12	70.0 - 74.9 mph	80.0 - 89.9 feet
#13	75.0 - 79.9 mph	All Other Lengths
#14	80.0 - 84.9 mph	
#15	85.0 - 89.9 mph	
#16	All Other Speeds	

Default Gap and Headway Bin Classification Table		
Bin Number	Gap Bin Time	Head way Bin Time
#1	00:00:03.00	00:00:03.00
#2	00:00:10.00	00:00:10.00
#3	00:00:15.00	00:00:15.00
#4	00:00:20.00	00:00:20.00
#5	00:00:30.00	00:00:30.00
#6	00:01:00.00	00:01:00.00
#7	00:02:00.00	00:02:00.00
#8	All Other Gaps	All Other Head ways

Appendix E. Road Tubes Problems & Solutions

This appendix discusses the various problems that road tubes can cause. Road tubes present their own unique set of problems for automatic vehicle classifiers & counters. Being aware of these potential problems before installing your road tubes can greatly reduce the frequency of these problems.

This appendix divides each problem (or “error”) into a separate section, and then lists the known causes of the problem.

Appendix E.1. Missed Axles

Missed axles are the most frequent errors seen. They are caused, very simply, by the hardware (airswitch) inside the counter not reporting an activation of the road tube when there is one. Some of the reasons for this are as follows:

- **Speed and Spacing.**

The airswitch in the Phoenix is undoubtedly the best in the business, however, even it is limited to 30 activations per second, or about 33ms per activation. If a second strike of the road tube occurs faster than 33ms, then the airswitch will not report the second activation.

Does this ever happen? Yes, take for example a car towing a 2 axle travel trailer at 65mph. A travel trailer typically has a spacing of 2.5ft between axles, and 65mph is about 95 feet per second. Therefore, how long does it take between the first road tube hit by the travel trailer, and the second. This is $(2.5\text{ft}/(95\text{ft/sec})) = 26\text{ms}$. The airswitch would not report the second axle of the travel trailer and this axle would be missed by the Phoenix.

- **Lifted wheels.**

Some trucks have an optional axle which may be raised slightly off the ground (to save on tread wear). The Phoenix will probably miss it, but sometimes it can show up as an error if human observation data is being compared to the counter and the observer is not aware that the wheel is lifted.

- **Bouncing Vehicles.**

Although uncommon, roads with dips or other irregular surface features can cause some truck axles to bounce slightly. This can occasionally lead to missed axles. Note that the Phoenix looks at both sets of road tube activations, so this problem is minimized.

- **Improper Road Tubes or Installation.**

The type, length, and method of installation of your road tubes can lead to increasing the number of missed axles; Always plug the end of with a suitable device (unless the road tube is shorter than 25 feet, and then DON'T plug it); always plug the road tube onto the counter nozzle all the way; always use an approved brand, size, and type of material for all of your road tubes; don't over stretch the road tubes because the diameter shrinks the more you stretch it.

- **Weak Signal With Longer Road Tubes.**

Very simply, the longer the road tube, the farther the “sound” of an axle striking the road tube has to travel. Make sure you use road tube lengths as recommended in the next section.

■ Sound Wave Interference.

To understand why this is a problem, you should understand that the Phoenix airswitch (like all airswitches) uses a "sound wave" to detect an axle hit. This wave is very similar to a water wave, in that it starts at a point and moves down the road tube to the round piezo disk sensor in the airswitch. It travels down the road tube at the speed of sound, which is about 767 MPH at 20 degrees Celsius, or 1125 feet per second. The force of this "wave" of sound bends the piezo disk in the counter which causes a voltage spike to be generated. It is this voltage spike which the Phoenix detects as an axlestrike on the road tube.

The following example shows how very close axle hits (such as with tandem axles on a truck) can actually interfere with each other and cause a missed axle.

- 1) Assume you have a 50' road tube stretched across a single lane of traffic. The road tube has been stretched 50" to make it tight. The end of the tube on the roadway is plugged and the other end is plugged into a Phoenix.
- 2) A 5 axle single trailer truck traveling 55mph crosses the road tube.
- 3) The first axle is detected with no problem.
- 4) The second axle (the first axle of first tandem pair) hits the road tube. This causes FOUR sound waves to be generated, TWO from each tire.
- 5) The Left Tire will send two sound waves from it (1 in each direction) and the Right Tire will send two waves from it as well. The sound waves look something like the following:

— < A o B > ——— < C o D > — (to Phoenix)

Each Letter represents a sound wave and the arrow next to the letter shows the direction the sound wave is traveling.

- 6) At this point the following things will happen: Sound "A" will travel to the end of the road tube and be absorbed by the plug. Sound "B" and "C" will travel towards each other, collide, and be seriously weakened. Sound "D", however, will be uninhibited and travel down the road tube towards the airswitch on the Phoenix.

Since all of the sound waves except "D" have been destroyed, we will only talk about sound wave "D" for the rest of this section, and it will be called the Wave.

- 7) The road tube has been stretched about 50", so it is now 54.16' long. Presuming the truck is in the center of the lane (lane being 12' feet wide) and the truck is 8 feet wide, the Wave should start at the 44' mark.
- 8) The Wave will travel down the road tube towards the Phoenix and contact the airswitch in about 39ms (ms stands for milli seconds, or thousandths of a second).
- 9) After the Wave hits the airswitch, it will bounce back and return up the road tube towards the vehicle. Thus, we have a weakened returning wave going back up the road tube.
- 10) The next axle on the truck hits the road tube about 56ms after the first (a 4.5ft spacing typical, on a 55mph vehicle). Once again, another Sound Wave "D" is generated and travels down the road tube towards the airswitch.
- 11) At this point we have the following:

— D2 > ——— < D1 ——— Phoenix

One wave traveling down, and one weaker wave returning. They will, of course, collide into each other at some point in the road tube, weakening both waves so that the second wave is too weak to register as an axle strike.

The question then becomes, if this is causing missed axles, why does a shorter road tube work better? If you take a 30' road tube, stretch it 50". Sound Wave "D" will start at about the 24' mark, and therefore will take only 21ms to reach the airswitch. Similarly, Sound Wave "D" will only take 21ms to return to the starting point (at the 24' mark). This makes the total time only 42ms for the first Sound Wave "D" to strike the airswitch and return to the starting point.

This time is BEFORE the 56ms time it takes for the next axle to hit. Therefore, the first Sound Wave "D" is past the point of origin and can not interfere with the next axle strike.

In summary, you are better off using shorter road tubes for faster speed vehicles. You are also better off using shorter road tubes for vehicles which have closer axle spacings (such as truck tandem axles).

To minimize missing axles and maximize accuracy we suggest using the following road tube lengths:

Speed	Road Tube Length
0-25mph	60 ft
26-35mph	50 ft
36-45mph	40 ft
46+	30 ft

While a shorter road tube at faster speeds is always more accurate, we do not suggest using road tubes shorter than 30' due to the potential damage to an airswitch by very strong "sounds" (or signals).

Appendix E.2. Extra Axles

This error, while not frequent, does happen. It is almost always a problem with the actual road tube installation, or with the road surface. Causes of extra axles are listed below:

■ Road Tube Bounce (Slap).

Since the road tubes are made of flexible rubber, they move when they are hit. Depending on how tightly they are stretched, how far apart the anchors to the roadway are, and how heavy the vehicle crossing the tubes is, the road tube may move only slightly, or may move a lot. When a tire hits the road tube normally, the airswitch is activated by the sound of that tire. If the road tube is moved a lot, it will return quickly enough to its original position and may "Slap" the road tube with enough force to actually "sound" like an other axle.

This error is minimized by the fact that the airswitch will not re-activate for at least 33ms, and the road tube should be stabilized by then (but not always). You can also help this problem by taping the road tube to the road at short intervals along its length.

■ Rutted Pavement.

DO NOT INSTALL ROAD TUBES OVER BADLY RUTTED PAVEMENT. This will cause the road tube to bounce wildly when driven over by heavy vehicles. If you must install the road tubes in rutted pavement, tape them down heavily.

■ Road Tubes Not Perpendicular to Traffic.

This error (usually only at slow speeds) is caused by a vehicle not hitting the road tubes squarely. If the vehicle is going slow enough, the left tire (or tires) and the right tire (or tires) will cause an individual activation. This problem is most commonly seen in intersections, where vehicles are turning across the road tubes at slow speeds.

Appendix E.3. Bad Speed and/or Length

This problem is infrequent, but can occur sometimes when the counter misses axles. For example, assume a 2 axle, 8 foot axle spacing, vehicle traveling 60 mph crosses two road tubes spaced 8 feet apart. The spacings and timings occurred as below:

- 1) Road Tube #1 hit by first axle at 10:00:00.00000.
- 2) Road Tube #2 and #1 hit almost simultaneously by first and second axles at 10:00:00.09090.
Counter missed the Road Tube #2 hit (for whatever reason).
- 3) Road Tube #2 hit by second axle at 10:00:00.18181.

Since the counter waits for the first hit on #1, and the first hit on #2 to determine the speed, the speed will be determined by the second road tube #2 hit. This gives $(8\text{ft}/.18181\text{sec}) = 44\text{ft/sec}$, or 30mph. This is only 1/2 the actual vehicle speed! Since the speed is calculated wrong, the counter will also give an incorrect length value for the vehicle.

Note that this error is really caused by a missed axle, the only difference is the Phoenix was still able to create a vehicle from the data, so it gave the values it could.

Appendix E.4. SnMis (Sensor Miss) for Entire Vehicle

Like the previous error, this problem only occurs as a result of missed axles. "SnMis" (for sensor miss) is the Phoenix's way of indicating that it did not have enough sensor data, or got sensor data not in the right order, to make a vehicle. Once a sensor miss occurs, the Phoenix blocks out all further sensor activations on that lane for 1 second.

- SnMis #0 occurs only with Axle-Pres-Axle or Pres-Axle-Pres combinations. This error indicates an improper sequence of sensor activations or missing one or more activations.
- SnMis #1 is that the counter only got a road tube 1 strike, with no further road tube activations. This can happen if a vehicle hits the first road tube, but misses the second, while changing lanes.
- SnMis #2 is that the counter only got a road tube 2 strike, without first getting a road tube 1 strike. This, like SnMis #1, can happen if a vehicle crosses into the lane but misses road tube #1.
- SnMis #3 is an overspeed or underspeed vehicle, and can optionally be used to indicate vehicles which only hit road tube 1 and road tube 2 once, with no further activations. Note that the counter will normally turn these types of activations into two axle vehicles with the axle length equal to the sensor spacing.

Appendix E.5. One vehicle shown as two

This error is normally caused by a vehicle with an axle spacing greater than the maximum axle spacing setting in the configure system option. The counter defaults to 35.0'. This value can be increased or decreased.

If you increase this value, you run the risk of counting vehicles traveling close together as one vehicle (two tailgating cars become one vehicle, usually turned into a four axle Scheme-F Class #8).

This error can also be caused by missed axles. The Phoenix only resets its time-out value after each axle hit, if you miss some and the counter does not reset its value, then the vehicle will be ended prematurely.

Appendix E.6. Two vehicles shown as one

This error, similar to the previous error, is caused by two vehicles traveling close enough together to be counted as one. Any vehicles closer than the maximum axle spacing value will be counted as one vehicle.

You can decrease the Maximum Axle Spacing value to correct for this problem.

Appendix E.7. Road Tube Setup That Does Not Cause Errors

The following section describes various road tube issues which do not cause errors. This is included to dispel any suspicions about these issues causing problems.

- Coiled road tubes.

The effect of coiled road tubes versus non-coiled road tubes does not have a noticeable effect.

Index

C

Computer, 3

Counter

Communicate To, 2

How To Operate, 2

System Components, 3

F

Firmware

Changes To, iv-vi

M

Modem, 3

Interface Cable, 3

S

Sensors, 3

T

Table Of Contents, i-iii

Tips To Prolong Life, 1

TrafMan, 2

W

What To Read, 2