



3Com 3108 Wireless Telephone Guide

3C10408A
WL-108

NBX® Networked Telephony Solutions
System Release 6.0

Part Number 900-0338-01 Rev AB
Published August 2006

<http://www.3com.com/>



3Com Corporation
350 Campus Drive
Marlborough, MA
01752-3064

Copyright © 1998–2006, 3Com Corporation. All Rights Reserved. No part of this documentation may be reproduced in any form or by any means or used to make any derivative work (such as translation, transformation, or adaptation) without written permission from 3Com Corporation.

3Com Corporation reserves the right to revise this documentation and to make changes in content from time to time without obligation on the part of 3Com Corporation to provide notification of such revision or change.

3Com Corporation provides this documentation without warranty, term, or condition of any kind, either implied or expressed, including, but not limited to, the implied warranties, terms, or conditions of merchantability, satisfactory quality, and fitness for a particular purpose. 3Com may make improvements or changes in the product(s) and/or the program(s) described in this documentation at any time.

If there is any software on removable media described in this documentation, it is furnished under a license agreement included with the product as a separate document, in the hardcopy documentation, or on the removable media in a directory file named LICENSE.TXT or !LICENSE.TXT. If you are unable to locate a copy, please contact 3Com and a copy will be provided to you.

UNITED STATES GOVERNMENT LEGENDS:

If you are a United States government agency, then this documentation and the software described herein are provided to you subject to the following:

United States Government Legend: All technical data and computer software is commercial in nature and developed solely at private expense. Software is delivered as Commercial Computer Software as defined in DFARS 252.227-7014 (June 1995) or as a commercial item as defined in FAR 2.101(a) and as such is provided with only such rights as are provided in 3Com's standard commercial license for the Software. Technical data is provided with limited rights only as provided in DFAR 252.227-7015 (Nov 1995) or FAR 52.227-14 (June 1987), whichever is applicable. You agree not to remove or deface any portion of any legend provided on any licensed program or documentation contained in, or delivered to you in conjunction with guide.

Unless otherwise indicated, 3Com registered trademarks are registered in the United States and may or may not be registered in other countries.

3Com, the 3Com logo, and NBX are registered trademarks of 3Com Corporation. NBX NetSet and pcXset are trademarks of 3Com Corporation.

Other brand and product names may be registered trademarks or trademarks of their respective holders.

CONTENTS

ABOUT THIS GUIDE

- Conventions 8
- Documentation 8
 - Comments on the Documentation 9

GETTING STARTED

- Package Contents 11
- Powering the Phone On and Off 12
- About Power-Saving Mode 12
- Care and Maintenance 12

3COM 3108 WIRELESS TELEPHONE

- WLAN Operation – Placing a Call via a SIP Proxy Server 13
 - 3108 Wireless Telephone Physical Description 14
 - Built-in Features 15
 - Expanded Feature Support 16
 - Product Specifications 16

LEARNING TO USE YOUR PHONE

- Checking Connection Status 19
- Making a Call 20
- Answering a Call 20
- Adjusting the Volume 20
- Using the Keypad Lock Feature 21
- Using the Icons 21
- Using the Keypad 22
 - Numeric Mode 22
 - Text Mode 22
- Using LED Status Indicators 24

Storing Names and Numbers in Your Phonebook 24

INITIAL HANDSET CONFIGURATION

Configuration Overview 25
Entering the Network Profile Settings 26
Entering the SIP Account Settings 28
Activating a Network Profile 30

PERSONALIZING YOUR PHONE

Setting the Time and Date 31
Setting the Ring Mode and Ring Tone 33
Setting a Wallpaper Image 34
Adjusting the Backlight 35

CALLING FEATURES

Viewing Recent Calls 37
Returning an Unanswered Call 37
Transferring a Call 38
Using the Call Mute 38
Using Call Waiting 39
Using Call Forwarding 39

MENUS

Phonebook 41
Call Log 42
E-mail 43
Speed Dial 46
Profile 46
Settings 47
Tools 53

WEB CONFIGURATION

Accessing the Web Configuration Utility 56

Checking Wireless Network Status	56
Editing Names and Numbers in Your Phone Book	56
Wireless Network Settings	57
SIP Settings	58
Phone Settings	59
E-mail Settings	60
Upgrade Software	60
Upgrade Bootcode	61
Debug Statistics	61
Reboot Phone	62
Password	62
Logout	62

TROUBLESHOOTING

Unable to Connect to the Network	63
Unable To Register With The SIP Server	63

REGULATORY INFORMATION

Caution: Exposure to Radio Frequency Radiation	65
US – Radio Frequency Requirements	66
USA-Federal Communications Commission (FCC)	66
Manufacturer's Declaration of Conformity	67
Canada – Industry Canada (IC)	67
Industry Canada (IC) Emissions Compliance Statement	68
Safety Compliance Notice	68
Europe – EU Declaration of Conformity	68
Europe - Declaration of Conformity in Languages of the European Conformity	69
Europe - Restrictions for Use of 2.4 GHz Frequencies in European Community Countries	70
Brazil RF Compliance	70
Korea RF Compliance	71

INDEX

ABOUT THIS GUIDE

This guide is intended for anyone using the 3Com 3108 Wireless Telephone. It describes how to unpack, set up and operate the Wireless Telephone. It also includes information for the Wireless Telephone installer or network administrator on how to configure the initial handset parameters required for connection to the network and wireless, Session Initiation Protocol (SIP), VoIP operation.

This book covers these topics:

- Chapter 1: [Getting Started](#)
- Chapter 2: [3Com 3108 Wireless Telephone](#)
- Chapter 3: [Learning to Use Your Phone](#)
- Chapter 4: [Initial Handset Configuration](#)
- Chapter 5: [Personalizing Your Phone](#)
- Chapter 6: [Calling Features](#)
- Chapter 7: [Menus](#)
- Chapter 8: [Web Configuration](#)
- Chapter 9: [Troubleshooting](#)
- Appendix A: [Regulatory Information](#)

Conventions

[Table 1](#) defines some commonly used words and phrases in this guide.

Table 1 Common Terms

Term	Definition
Auto Attendant	The set of voice prompts that answers incoming calls and describes actions that a caller or user can take to access individual services.
Administrator	The person who is responsible for maintaining your telephone system.
Receptionist	The person who answers the majority of incoming telephone calls. In some business environments, this person may be a switchboard operator.
User	A person who has a single telephone.

[Table 2](#) lists conventions that are used throughout this guide.

Table 2 Icons

Icon	Type	Description
	Information note	Information that describes important features or instructions.
	Caution	Information that alerts you to potential loss of data or potential damage to an application, system, device, or network.
	Warning	Information that alerts you to potential personal injury.

Documentation

When using the 3Com 3108 Wireless Telephone with the 3Com NBX Network Telephony System, the following additional documents are helpful:

- *3Com NBX Feature Codes Guide for SIP Telephones*. This guide describes the NBX features that are accessible on VoIP telephones connected to the NBX system running in SIP mode.
- *3Com NBX Administrator's Guide*. This guide describes how to configure and manage NBX systems.

The NBX Resource Pack DVD contains many guides to the NBX products and their related 3Com applications.

Comments on the Documentation

Your suggestions are important to us. They help us to make the 3Com documentation more useful to you.

Please send your e-mail comments about this guide or any of the 3Com NBX documentation and Help systems to:

Voice_TechComm_Comments@3com.com

Include the following information with your comments:

- Document title
- Document part number (found on the front or back page)
- Page number



As always, please address all questions regarding NBX hardware and software to your 3Com NBX Voice-Authorized Partner.

1

GETTING STARTED

As soon as you receive your 3Com 3108 Wireless Telephone package, you can unpack the contents, install the battery, and plug in the AC power adapter to begin charging the battery. This chapter describes these steps and the basic care and operation of your phone. It covers these topics:

- [Package Contents](#)
- [Installing and Charging the Battery](#)
- [Powering the Phone On and Off](#)
- [About Power-Saving Mode](#)
- [Care and Maintenance](#)



The initial handset parameters and network service must be configured before you can use your Wireless Phone to make or receive any calls. For details, see [Chapter 4: Initial Handset Configuration](#).

Package Contents

The 3Com 3108 Wireless Telephone ships with the following contents:

- One 802.11b/g WLAN, VoIP handset
- One CD-ROM with user's manual
- One Li-ion battery
- One AC power adapter

Installing and Charging the Battery

The new battery in your Wireless Telephone is shipped partially charged. Before you can use your phone, you need to install and charge the battery.

To install and charge the battery:

- 1 Remove the rear cover on the handset (See [Figure 1](#) on page [page 14](#).)
- 2 Insert the battery in the compartment so that the metal contacts on the battery and handset are aligned.
- 3 Replace the rear cover of the handset.
- 4 Plug the AC power adapter into the USB Data Cable slot on the bottom of the handset. (See [Figure 2](#) on page [page 15](#).)
- 5 Plug the other end of the power adapter into the appropriate AC outlet.



For first time usage, you should charge the battery for at least 8 hours. While the phone is charging, you can still do phone operations according to the instructions in this guide. The battery charging status is accurate only after uninterrupted charging/ discharging. The battery can get warm during charging. This is not a malfunction. If the battery is completely exhausted, you need to charge the battery for approximately three hours (with the phone powered off) to reach full capacity.

Powering the Phone On and Off

You use the same key to power the phone on and off.

To power On the phone — press and hold the  **Power** key.

To power OFF the phone — press and hold the  **Power** key.

About Power-Saving Mode

To minimize power consumption, the LCD display automatically goes dim after 15 seconds (default setting) without any operations. You can change this setting to **30 Seconds** or **Always On**. For details, see **LCD Off Time** in the [“Settings”](#) menu described on [page 47](#).

To reactivate the LCD display, press any key.

Care and Maintenance

Note the following tips to keep your phone in proper operating condition:

- Keep your phone and accessories away from dusty, wet or dirty areas.
- Do not put your phone or accessories in extremely hot or cold areas.
- Do not use harsh chemicals, cleaning solvents, or strong detergents to clean your phone or accessories.

2

3Com 3108 WIRELESS TELEPHONE

This chapter describes the basic operating principles, controls, features, and specifications of the 3Com 3108 Wireless Telephone. It covers these topics:

- [3108 Wireless Telephone Physical Description](#)
- [Built-in Features](#)
- [Expanded Feature Support](#)
- [Product Specifications](#)

WLAN Operation – Placing a Call via a SIP Proxy Server

The 3Com 3108 Wireless Telephone is a Session Initiation Protocol (SIP)-based wireless Voice over Internet Protocol (VoIP) telephone. SIP is an internationally recognized standard (IETF RFC 3261) for implementing VoIP. You can make and receive VoIP calls as long as your Wireless Telephone is registered with a SIP proxy server and you are operating it within range of an IEEE 802.11b/g enabled wireless network (WLAN). The SIP proxy server can belong to a wireless Internet Telephony Service Provider (ITSP) or corporate VoIP PBX system, such as the 3Com NBX® System.

When using your 3108 Wireless telephone to make and receive VoIP telephone calls, you do not need to know if the recipient's connection type is an IP, cellular, or land line based service. Your Wireless phone can call any land line or mobile telephone that a traditional PSTN telephone can connect to as well as the IP telephone network. Calls received from VoIP telephones work exactly as you would expect from the traditional telephone service.



The initial handset parameters and network service must be configured before you can use your Wireless Phone to make or receive any calls. For details, see [Chapter 4: Initial Handset Configuration](#).


3108 Wireless Telephone Physical Description

[Figure 1](#) and [Figure 2](#) show the location of buttons, controls, and other key components of the 3108 Wireless Telephone.

Figure 1 3108 Wireless Telephone — Open, Front, and Back Views



- | | | |
|------------|---------------|------------------------|
| 1. Speaker | 3. Keypads | 5. Antenna |
| 2. Display | 4. Microphone | 6. Battery Compartment |

Figure 2 3108 Wireless Telephone — Side, Top, and Bottom Views

- | | |
|---------------------------|-------------------------|
| 7. Volume adjustment keys | 9. Strap eyelet |
| 8. Earphone jack | 10. USB Data cable slot |

Built-in Features The 3Com 3108 Wireless Telephone has the following built-in features:

- Pixel-based display — Intuitive access to calling features
- Nine configurable speed dials
- Comfort noise generation (CNG), voice activity detection (VAD) and adaptive jitter buffer
- RF and battery level indication
- Local phone book
- External 2.4GHz antenna
- USB charger interface
- Multi-chords melody
- ABS+PC plastic housing
- Color LCD with backlight
- Simple keypad with backlight
- Remote firmware (FW) upgrading via Wi-Fi

- Special keypads: Redial, Hold & Volume control
- SIP v2 signaling protocol, RFC-3261
- POP3/SMTP E-mail access
- SMS (optional, by system default)
- Enhanced security based on WEP/WPA/WPA2
- Support WMM for QoS operation
- Embedded Site-Survey to ease WLAN search

Expanded Feature Support

Because it is based on standard SIP VoIP protocols, your 3108 Wireless Telephone can support additional features offered through the wireless Internet Telephony Service Provider (ITSP) or corporate VoIP PBX system to which it subscribes. For example, when used with the 3Com NBX system, the 3108 Wireless Telephone supports additional features such as, call pickup and do not disturb, through feature codes. The *NBX Feature Codes Guide for SIP Telephones* describes how the 3108 Wireless Telephone and generic IP telephones interact with the NBX system. This guide is available through the NBX NetSet utility.

Product Specifications

The 3Com 3108 Wireless Telephone specifications are listed in [Table 3](#).

Table 3 3Com 3108 Wireless Telephone Specifications

Item	Description
CPU	BCM1160
Flash Memory	NOR 16MB
SRAM Memory	12MB
Wireless LAN Standard Compliance	IEEE802.11b/g 2.4GHz
Wireless Frequency Range	Approx. 2.400~2.497GHz
Output Power	Max. 13dBm @802.11g Max. 17dBm @802.11b
Data Transmission Rate	1, 2, 5.5, 11Mbps up to 54Mbps
WLAN Network Architecture Type	Infrastructure
Operation Distance	Indoor: 20~50m Outdoor: ~250m (@11Mbps, in line of sight area)

Table 3 3Com 3108 Wireless Telephone Specifications (continued)

Item	Description
Channel Support	Japan: 802.11b 14 (1~13 or 14 th)
Modulation Technology	DSSS OFDM
LCD	1.8i Color LCD, 128x160 pixel, 65k colors
Antenna Type	External antenna
Battery	Li-ion 1000 mAh
Dimension	112.9mm (L) x 48.7mm (W) x 27.3mm (H)
Weight	Approx. 106g

3

LEARNING TO USE YOUR PHONE

This chapter describes how to use the basic features of your 3Com 3108 Wireless Telephone. It covers these topics:

- [Checking Connection Status](#)
- [Making a Call](#)
- [Answering a Call](#)
- [Answering a Call](#)
- [Using the Keypad Lock Feature](#)
- [Using the Icons](#)
- [Using the Keypad](#)
- [Using LED Status Indicators](#)
- [Storing Names and Numbers in Your Phonebook](#)



The initial handset parameters and network service must be configured before you can use your Wireless Phone to make or receive any calls. For details, see [Chapter 4: Initial Handset Configuration](#).

Checking Connection Status

The connection status lets you check if your handset is within range of the WLAN network and is properly registered with the SIP proxy server for VoIP operation.

When your Wireless phone is powered on, you can check your phone's connection status by pressing .

For **Wireless Status** you can view the following information:

- BSSID
- IP Address
- MAC Address

For **SIP Status** you see the following information:

- SIP Server
- User Agent
- Status

Making a Call

There are two ways to make a call when your phone is in standby:

- Dial the number for the extension you want and press .
- Or, press  to display your Phonebook.

Press  to search for the desired Phonebook entry and press .

Answering a Call

When you receive a call, your phone rings and/or vibrates and displays an incoming call message.

Table 4 Answering a Call


Buttons	Description
 or 	Accept and pick up the phone call.
 or 	Reject the incoming phone call.

Adjusting the Volume

To increase or decrease the handset volume, press the volume adjustment keys located on the left-side of the handset (up or down).



The volume adjustment level is indicated on the display.



Using the Keypad Lock Feature

You can use the Keypad lock feature to avoid unintentional pressing of keys. There are two ways to **activate** the keypad lock function:

- In Standby, press and hold .
- Or, select **Menu** and go to **Settings > Keypad > Key Lock**.
- Select OK to activate Key Lock.

To release the keypad lock, press and hold .

Using the Icons

The Wireless phone's display uses different icons to inform you of various capabilities, features, and calling status. These icons are described in [Table 5](#).



Table 5 3108 Wireless Telephone Display Icons

Icon	Description
	Signal Strength — Indicates the received wireless signal strength. The greater the number of bars, the stronger the signal
	Message — Indicates when you have received new messages.
	In Call / Call Forward — Appears when you are on a call/forwarding the call.
	Network Encryption — Indicates when network encryption is set.
	SIP Registered/ Not Registered — Indicates when you are registered/unregistered to SIP server.
 	Ring Mode — Appears for Silent, Ring, Vibrate, and Ring+Vibrate. For details, see "Setting the Ring Mode and Ring Tone" on page 33 .
	Alarm — Pops up when you set an alarm to ring at a specified time.
	Battery Level — Indicates the level of the battery charge. The more bars you see, the more power you have remaining.

Using the Keypad

The Wireless phone's keypad allows you to dial phone extensions and enter characters for messages and Phonebook names. You can use the keypad to enter any combination of numbers and text (letters and special symbols, including punctuation marks).

The procedures for entering numbers and text are described in the following sections.

Numeric Mode

Numeric mode enables you to enter the digits, ***** and **#** characters indicated on the keys to dial or save as a character string, such as a phone number entry in your Phonebook. Simply press the keys according to the digits/characters you want.

To delete digits/characters, press the  key.

Text Mode

Text mode is indicated by the appearance of **ABC** in the lower left corner of your phone's display. When entering text, start by pressing the key labeled with the character you prefer:

- Once for the first character;
- Twice for the second character and so on.

This method is called multi-tap typing.

For example, you have to press the **5** key twice to display the character "**K**," the **3** key five times to display the character "**e**," and the **6** key five times again to display "**n**."

The cursor moves to the right each time you press a key. When entering the same letter twice or a different letter, wait momentarily for the cursor to move to the right, and then enter the next character.

You can insert a space between words/letters by pressing the **0** key.

To delete characters, press the  key.

The keys you press for the available characters are described in [Table 6](#).

Table 6 Available Characters in Text Mode

Key	Characters in the Order Displayed
0	space
1	" ' [] < > () { }
2	ABCabc
3	DEFdef
4	GHIghi
5	JKLjkl
6	MNOmno
7	PQRSpqrs
8	TUVtuv
9	WXYZwxyz
*	* . + - / , ; = ? !
#	# @ \$ % & \ ^ _ ` ~

Switching Between Numeric and Text Mode

When the Wireless phone is initially powered up and operating in standby, the keypad is in numeric mode. At other times, such as when entering information in Phonebook, you can press



to toggle between Numeric mode, indicated by the appearance of **0-9**, **0-9*#** or **IP** in the lower left corner of the display, and Text mode, indicated by **ABC**. To type a character string that contains both digits and letters, you enter the digits or letters by manually switching to either Text or Numeric input modes before pressing the appropriate key.

Using LED Status Indicators

You can view phone status by determining the color and pattern of the LED indicators located on the front of the 3108 handset.

These LED indicators and their status are described in [Table 7](#).

Table 7 LED Status Indicators

LED Indicator	Status	Description
Lighting seven colors	Continuously rotating	When receiving an incoming call
Blue	Blinking	When there is an unanswered call
		When a new e-mail is received
Red	Blinking	When the phone is powered on and the battery is charging
	Solid	When the phone is powered off and the battery is charging
Green	Blinking	When the phone is powered on and the battery is fully charged
	Solid	When the phone is powered off and the battery is fully charged
Magenta	Blinking	Acts as a warning message, indicating that the battery is in low level

Storing Names and Numbers in Your Phonebook

You can store up to 200 entries of name and phone number information in your Phonebook.

To add a Phonebook entry:

- 1 Select **Menu** and go to **Phonebook > Option > New**.
- 2 Press  to enter the appropriate **Name, Number, E-mail, and Ring Tone**, and to optionally set the **Speed Dial**.



Press  to switch between *Numeric* and *Text* input modes as needed. The selected text input method indicator shows at the bottom left of the screen. (Text mode: ABC or Numeric mode: 0-9*#).

- 3 After completing your entry, press  **OK** to confirm your settings:

4

INITIAL HANDSET CONFIGURATION



This chapter is intended to assist the Wireless Telephone Installer or person responsible for adding VoIP devices to the network.

Before you can operate the 3Com 3108 Wireless Telephone, you must configure the parameters in the handset that allow the telephone to communicate with the wireless network (WLAN) and SIP proxy server. These settings require detailed information about the network to which this handset is assigned. At a minimum, you will need to enter the IP address and SIP registration settings for the handset. You may also need to modify other settings in the handset that are required by the WLAN. Additionally, the network administrator will need to configure the device settings that are required by the wireless Internet Telephony Service Provider (ITSP) or a corporate VoIP PBX system, such as the 3Com NBX® System.

This chapter covers the following topics:

- [Configuration Overview](#)
- [Entering the Network Profile Settings](#)
- [Entering the SIP Account Settings](#)
- [Activating a Network Profile](#)

Configuration Overview

The 3108 Wireless Telephone's Profile menu allows you to view and modify the handset parameters through the handset's built-in menu interface. Menu selections are displayed on the handset's LCD display.

Before you can use your phone, you will need to enter the profile menu and create a network profile. You can create up to six different network profiles, although you can activate only one profile at a time.



First Step: You are required to set a password for the profile menu. A pop-up message displays on the screen **“No Password! Please Create a New Password.”** After the profile menu’s password is set, you need to enter the configured password to enter the profile menu.

The next step after creating a network profile is to specify the parameters for the SIP account that you will associate with this network profile. You can create up to six different SIP Accounts. To complete your profile configuration, you must activate the network profile. These tasks are described in the remaining sections of this chapter.

Entering the Network Profile Settings

To configure a network profile:



- 1 Press  **Menu** and then press  to select **Profile**.
- 2 Enter the Profile menu’s password.
- 3 Press  to select the **Network Profile** menu option and then select the profile you want to edit from the list.



*If you are setting up a new profile, select an unused profile from the list (for example, <profile>). Press  and select **Rename** to give an appropriate name to the profile.*

- 4 To edit the settings for the selected network profile, press  and select **edit**. The Network Profile settings are located in the submenus for Wireless, IP, Account Choice, Hotspot Choice, and NAT.
- 5 Edit your **Wireless Settings** as necessary. [Table 8](#) describes the available options.

Table 8 Wireless Settings

Setting	Description
ESSID	Stands for Extended Service Set Identifier. Specifying the ESSID is how you make sure that you connect to your wireless network instead of your neighbor’s network by mistake. You can either manually input the New ESSID or select Site Survey to check all available networks. For example: Default.
Data Rate	Select a specific data rate 1 Mb/s, 2 Mb/s, 5.5 Mb/s, 6 Mb/s, 9 Mb/s, 11 Mb/s or set as Auto .

Table 8 Wireless Settings (continued)

Security	Acts as your usage permission passport. This is an effective way to achieve data security. Your network provider should inform you about the authentication types for the access point encryption modes. Options include: Open (no security) ■ WEP (select WEP-64 or WEP-128 bit) (Network dependent) Setting WEP as Security, you can define the WEP Key Index from One to Four in Key Index. You can set the WEP key to ensure data transmission from wireless access points in Key. ■ WPA-PSK (select either WPA-PSK TKIP, which automatically changes the keys at a preset time interval, making it much more difficult for hackers to find and exploit them, or WPA-PSK AES as advanced encryption standard) (Network dependent). You can set the key to ensure data transmission from wireless access points in Key. ■ WPA2-PSK (select WPA2-PSK TKIP or WPA2-PSK AES) (Network dependent). You can set key to ensure data transmission from wireless access points in Key. ■ WPA (select WPA TKIP or WPA AES) (Network dependent). ■ WPA2 (select WPA2 TKIP or WPA2 AES) (Network dependent). You can set the key to EAP (MD5, GTC, MSCHAPv2, LEAP, TLS or TTLS), Identity, User Name, Password, CA Cert., User Cert. and Private.
----------	--

6 Edit your **IP Settings** as necessary. [Table 9](#) lists the available options.

Table 9 IP Settings

Setting	Description
Fixed IP	Enter your IP Address , IP Netmask , IP Gateway , Primary DNS and Secondary DNS .
DHCP	The default setting; to confirm, press . 
PPPoE	Enter User Name and Password .

7 Edit your **Account Choice** as necessary. Press  to set the associated SIP Account.



If you have not yet set up your SIP account, before you can activate this network profile, you will need to return to the Account Choice menu option and specify the particular SIP account you want to associate with this profile.

- 8 Edit your **Hotspot Choice** as necessary. To select the specific Hotspot or Off, press



- 9 Edit your **NAT Settings** as necessary. Contact your network service provider for details. [Table 10](#) shows the available options.

Table 10 NAT Settings

Setting	Description
NAT Solution	Press  to select Disable , SIP PING or STUN .
NAT Timer	You can set from 0 to 65535 sec.
STUN Address	See your network service provider.
STUN Port	See your network service provider.

Entering the SIP Account Settings

The SIP account parameters enable your Wireless phone to register with the designated SIP proxy server for VoIP operation. To enter your SIP account parameters:

- 1 Press , select **SIP Account**, and then press  **Select**.
- 2 Press  and select the SIP account you want to edit.



*If you are setting up a new SIP account, select an unused account from the list (for example, **<SIP Account>**). Press  and select **Rename** to give an appropriate name to the account.*

- 3 Press  **Option** to **Edit**.
- 4 Edit the following settings as necessary:
- **Phone Number:** Numbers are given by the network provider. For example: 2005.

- **Auth. ID:** Enter your authorized user ID, for example: 0233.
- **Auth. Password:** Enter your authorized password.
- **SIP Domain:** Enter the Session Initiation Protocol domain name for the phone.
- **Proxy Address:** Enter the address of SIP server, for example: 192.168.0.1.



To enter the decimal character (.) for the IP address, press the * key while in Text mode.

- **Advanced:** [Table 11](#) lists the Advanced settings you can configure.

Table 11 Advanced SIP Parameters

Setting	Description
Proxy Port:	The port number of SIP server.
Outbound Address:	Outbound proxy address.
Outbound Port:	Outbound proxy port.
Local Port:	Local port number.
Reg. Timer (sec):	Registration refreshing interval.
Codec:	Compressed audio format.
Pkt Time (ms):	Audio transmitting interval.
OutBand DTMF:	The working of out-of-band dual-tone multifrequency.

- 5 Press



to confirm your settings.



After defining the SIP Account settings, you must associate the SIP account with a particular network profile in order for the Wireless phone to use these settings. To do this, you name the specific SIP account in the **Account Choice** menu option of the active Network Profile. For details, see “Entering the Network Profile Settings” earlier in this chapter.

Activating a Network Profile

Your Wireless Telephone can have up to six different network profiles defined to support connections to different WLANs and/or SIP proxy servers.



Only one network profile in your Wireless telephone can be active at a time.

Follow these steps to activate the network profile you require for operating your Wireless Telephone:

- 1 Press  **Menu** and then press  to select the **Profile**.
- 2 Enter the profile's password.
- 3 Select **Network Profile** to display the list of network profiles
- 4 Select the Network Profile you want to make active.
- 5 Press  **Select** and ensure that **Auto Detect** is set to **On**.
- 6 Select **Move** and press  to move the profile you want active to the top of the list.
- 7 Press  **Back** and then select **Network Profile** again. The active profile in the list is indicated by check mark next to it. (If the profile has **Auto Detect** set to **Off** the displayed icon will be indicated as .)

Return to **Menu** and go to **Tools > Restart**. Press  **OK** to restart the phone.

5

PERSONALIZING YOUR PHONE

This chapter covers the following topics:

- [Setting the Time and Date](#)
- [Setting the Ring Mode and Ring Tone](#)
- [Setting a Wallpaper Image](#)
- [Adjusting the Backlight](#)

Setting the Time and Date

You must set the time and date to fully use your phone features.

Set the time:

- 1 Select **Menu** and go to **Settings > Clock > Time**.
- 2 Set the time as described in [Table 12](#).

Table 12 Setting the Time

Press	To
0-9	Enter the time directly
	Scroll right or left to change hours/minutes/seconds
	Scroll up or down to change the time and to choose AM or PM if time format is set to 12 hour.
	Confirm your time setting

Set the Time Format

- 1 Select Menu and go to **Settings > Clock > Time Format**.
- 2 Set the time format as described in [Table 13](#).

Table 13 Setting the Time Format

Press	To
	Scroll up or down to choose 12-Hour or 24-Hour
	Confirm your time format setting

Set the Date

- 1 Select **Menu** and go to **Settings > Clock > Date**.
- 2 Set the date as described in [Table 14](#).

Table 14 Setting the Date

Press	To
0-9	Enter the date directly
	Scroll right or left to change years/months/days
	Scroll up or down to increase or decrease the date
	Confirm your date setting

Set the Date Format

- 1 Select Menu and go to **Settings > Clock > Date Format**.
- 2 Set the date format as described in [Table 15](#).

Table 15 Setting the Date Format

Press	To
	Scroll up or down to choose YY/MM/DD or MM/DD/YY
	Confirm your date format setting

Setting the Ring Mode and Ring Tone

Your phone rings or vibrates to alert you of an incoming call or other event. The Ring Mode and Ring Tone settings allow you to personalize this alert.

Set the Ring Mode

- 1 Select **Menu** and go to **Settings > Sound Settings > Ring Mode**.
Choose from the following options:
 - **Silent** — Neither rings nor vibrates.
 - **Ring** — Rings using the selected ring melody.
 - **Vibrate** — Vibrates but does not ring.
 - **Ring + Vibrate** — First rings and then starts to vibrate.
- 2 Press  to confirm your setting.

Set the Ring Tone

- 1 Select **Menu** and go to **Settings > Sound Settings > Ring Tone**.
You can select from 17 different melodies.
- 2 Press  to set the Ring Tone melody as described in [Table 16](#).

Table 16 Setting Ring Tone Melody

Press	To
	Scroll up or down to select a ring melody from the list
	Play the selected melody
	Set your ring tone melody

Setting a Wallpaper Image

You can set a picture as a background image or wallpaper in your phone's standby display.

There are five built-in pictures for you to select from for the background image.

- 1 Select **Menu** and go to **Settings > Display Setting > Wallpaper**.
- 2 Select a background image and set the Wallpaper as described in [Table 17](#).

Table 17 Setting the Wallpaper

Press	To
	Scroll up or down to different wallpaper
	View the selected background image
	Set your wallpaper

Adjusting the Backlight

You can adjust the brightness of the display for different lighting conditions.

- 1 Select **Menu** and go to **Settings > Display Settings > LCD Brightness**.
- 2 Set the brightness as described in [Table 18](#).

Table 18 Setting the LCD Brightness

Press	To
	Increase or decrease the LCD lighting level
	Set your display lighting level

6

CALLING FEATURES

This chapter covers the following topics:

- [Viewing Recent Calls](#)
- [Returning an Unanswered Call](#)
- [Transferring a Call](#)
- [Using the Call Mute](#)
- [Using Call Waiting](#)
- [Using Call Forwarding](#)

Viewing Recent Calls

Your phone keeps track of the calls you recently received and dialed, even if the calls did not connect.

View recent calls:

- 1 Select **Menu** and go to **Call Log > Missed Calls/Dialed Calls/Received Calls**.



- 2 Press the D-pad to view the name and/or the numbers, if available, with the time and date when the call was received.

When viewing the Call Log, you can also redial the number by pressing this key:



Returning an Unanswered Call

This feature provides an indication about the last phone call(s) you received, but did not answer, so that you may return the call(s).

Your phone keeps a record of your missed calls, and displays:

- The  (missed call) indicator
- **X Missed Calls**, where **X** is the number of unanswered calls

To return a missed call:

- 1 Select  and go to **Call Log > Missed Calls**.
- 2 Press to view the name and the numbers, if available, with the time and date when the call was received. You can also redial the number by pressing the  key.

Transferring a Call

When you are on a call, you can transfer this call (either announced or unannounced) to another party.

[Table 19](#) shows the sequence of steps involved in a call transfer.

Table 19 Transferring a Call

Press	To
	Put the active call on Hold.
Keypad keys and 	Dial the third-party's number and place a new call.
	Complete the transfer.
While third-party is connected	

Using the Call Mute

While you are on a call, you can turn off your microphone so that the peer party does not hear your voice.

Table 20 Using the Mute Control

Press	To
	Toggle mute on and off to block or allow sound to be heard through your phone's microphone.

Using Call Waiting

Call Waiting provides an alert tone when you are on an active call and you receive a second incoming call.

To activate Call Waiting:

- 1 Select **Menu** and go to **Settings > Call Settings > Call Waiting**.
- 2 Press  to select **On** and then press  to activate **Call Waiting**.

[Table 21](#) describes how to use Call Waiting when you are on an active call.

Table 21 Using Call Waiting

Press	To
	Answer the new call
 (again)	Toggle between the calls
	End the call on talk



*If **Call Waiting** is set to **Off**, there is no alert tone, and the second incoming call will be rejected.*

Using Call Forwarding

You can forward a call to another extension based on different conditions:

- **Forward Number** — Transfers the call to the designated extension under specified conditions.
- **Forward All** — Transfers all calls to the designated extension under any conditions.
- **No Answer** — Diverts the call to the designated extension after 18 seconds when the call is unanswered.
- **Busy** — Transfers the call to the designated extension when your line is busy or the call is rejected.

When Call Forwarding is active, an icon  appears on the screen.

To activate any of the call forwarding functions:

- 1 Select **Menu** and go to **Settings > Call Settings > Call Forward**.
- 2 Press  to select **On** and then press  to activate **Call Forward**.

To deactivate **Call Forward**, press  to select **Off**.

- 3 Press  to return to menu.



To deactivate the set of Call Forward functions, go to **Settings > Call Setting > Call Forward**. Choose **Cancel All** and press  **Select**.

7

MENUS

This chapter describes each of the functions you can access through the Wireless phone's built-in menu interface. It covers the following topics:

- [Phonebook](#)
- [Call Log](#)
- [E-mail](#)
- [Speed Dial](#)
- [Profile](#)
- [Settings](#)
- [Tools](#)

Phonebook

This section describes how to manage the information stored in your Phonebook.

After storing entries in your Phonebook (see [“Storing Names and Numbers in Your Phonebook”](#) on [page 24](#)), you can search for a particular entry and view its details.

The entries are listed in alphabetical order. After finding the appropriate name,

press  to view the details.

[Table 22](#) describes each of the menu options you have for Phonebook entries.

Table 22 Using Your Phonebook

Feature	Description
Search	Phonebook > Search Press  to Search and press  Select. You are asked to enter the name. Press  OK to find the requested entry.
Edit	Phonebook > Edit Press  to scroll the list and then press  Edit. You can modify the Name, Number, E-mail, Ring Tone, and Speed Dial settings for the selected entry. Press  OK to confirm your settings.
Delete	Phonebook > Delete Press  to scroll the list and then press  to Delete. A pop-up message "Delete?" appears on the screen. Press  OK or  Back to cancel the deletion and return to the menu.
New	Phonebook > New Press  Edit and enter the desired Name, Number, E-mail, Ring Tone, and Speed Dial settings for the new entry.

Call Log

Call Log allows you to view and manage the entries for missed, dialed, and received calls.

[Table 23](#) describes each of the menu options you have for managing Call Log entries.

Table 23 Using the Call Log

Feature	Description
Missed Calls	Call Log > Missed Calls Press  to Save, Delete Record or Delete All Received calls. You can also redial the number by pressing the  key.
Dialed Calls	Call Log > Dialed Calls Press  to Save, Delete Record or Delete All Dialed calls. You can also redial the number by pressing the  key.
Received Calls	Call Log > Received Calls Press  to Save, Delete Record or Delete All Received calls. You can also redial the number by pressing the  key.
Delete All	Call Log > Delete All You can remove all records (missed, dialed and received) from the Call Log. A pop-up message “Delete All?” appears on the screen. Press OK or Back to cancel the deletion and return to the menu.

E-mail

Using the E-Mail feature, you can receive or send text messages through an established e-mail account.

Receiving or sending e-mail is based on POP3 and SMTP system design. To use this feature, you must have an e-mail account (a specific username and password) from your e-mail service provider. The maximum storage size is 500 total messages for Inbox, Outbox and Draft combined.

To limit power consumption, the phone does not automatically scan mail in mailboxes.

To configure an e-mail account, go to the **E-mail** menu and enter the information requested for setting up an account using the Account Settings selection. [Table 24](#) describes the account setting entries and how to use your phone’s e-mail capabilities.

Table 24 Setting Up and Using E-mail

Feature	Description
---------	-------------

Table 24 Setting Up and Using E-mail (continued)

Account Settings	From Account Settings, the following options are available: ■ Account Name: enter a name for the activated account. ■ Your Name: enter the name to be displayed as the sender name. ■ Mail Address: enter your e-mail address. ■ POP3 Address: enter your e-mail address. ■ POP3 User ID: enter your e-mail ID. ■ POP3 Password: enter your e-mail password of 1 to 20 characters. ■ SMTP Address: enter your SMTP address. ■ SMTP User ID: enter your SMTP user ID. ■ SMTP Password: enter your SMTP password of 1 to 20 characters. Advanced: ■ Reply Address: can be either in English or IP address. ■ POP3 Port: provided by your network service provider. (default: 110) ■ SMTP Port: provided by your network service provider. (default: 25) ■ Signature: enter your signature according to your preference. ■ Reserve Mail: you can store your mails on the server
Write New	Writing new mail, you can Preview the subject, recipients and content; fill in the Subject, add the Recipients (either Input Address directly or Add By the Phonebook), write the Content, and then you can either Save To Draft or Send the Mail. While editing, press  to switch the input method (ABC or 0-9).
Receive	A pop-up message “Receive Mail?” on the screen indicates you have mail waiting. Press  OK to receive new mail.

Table 24 Setting Up and Using E-mail (continued)

Inbox	Allows you to access your e-mail Inbox and read the e-mail messages you've received. Press  to select the mail you want to read and then press  View. Details (From, Date, Recipients, Subject and Content) are indicated. You can also press  Option to Reply, Reply with Log (reply with the original content), Forward, Preview the detail, read the Subject, set the Recipients, write the Content, Save To Draft, Send Mail, Delete the mail, or Clear all mail in the Inbox.
Outbox	Allows you to view a list of the e-mail messages you've sent. Press  to select the mail you want to read and then press  View. Details (From, Date, Recipients and Subject) are indicated. From the outbox, you can also Forward mail, Preview the detail, read the Subject, set the Recipients, write the Content, Save To Draft, Send Mail, Delete mail, or Clear all mail in the Outbox.
Draft	Allows you to retrieve e-mail messages you previously saved as drafts. When you select this menu option, the list of all e-mail messages you saved as a draft appears. Press  to select the mail you want to read and then press  View. Details (From, Date, Recipients and Contents) are indicated. You can also Edit (either Preview the detail, read the Subject, set the Recipients, write the Content, Save To Draft or Send Mail) or Delete the mail or Clear all mail in the Draft box.

Speed Dial

You can assign up to nine Speed Dials for single-key dialing of commonly used numbers. You can assign an entry you saved in your Phonebook a unique speed dial number (1-9) in phone memory. [Table 25](#) shows the two ways to assign a Speed Dial, either through the Phonebook or by directly assigning a key to a Speed Dial.

Table 25 Assigning Speed Dials

Feature	Description
Phonebook	Select the entry to which you want to assign the speed dialing number. Press  Option to set the key from the Phonebook > Edit > Speed Dial. Set the speed dial key from the 1 to 9 key, and press  Set.
Speed Dial	Select the key to which you want to assign the speed dialing number. Press  Option and select an entry you want to assign from the Phonebook. Press  Set to set the speed dial key to the number you selected.

Profile

[Table 26](#) shows the options you have for Profile settings.

Table 26 Profile Settings

Feature	Description
Network Profile	For details, refer to “Entering the Network Profile Settings” on page 26 .
SIP Account	For details, refer to “Entering the SIP Account Settings” on page 28 .
Roaming	Profile > Roaming ■ Roam Metric (you can set from 0 to -99). ■ Roam Delta (you can set from 0 to 99). ■ Nprobes (you can set from 100 to 1). ■ Active Time (you can set from 1000 to 1). ■ Home Time (you can set from 1000 to 1).

Table 26 Profile Settings

Profile Password	Profile > Profile Password You can change your profile password. First enter the “Old Password” and then enter the “New Password.” Press  OK to set the new password.
Hotspot	Profile > Hotspot Press  to select one of five hotspots and then press  Set to enter the hotspot name and password.
Secure Setup	Profile > Secure Setup Press  Yes to activate SES (security easy setup) or  Back to menu.

Settings

[Table 27](#) describes each of the phone features you can access through the Settings menu.

Table 27 Phone Settings

Feature	Description
Language	Settings > Language You can set the display language, for example: English or Japanese. Press  Set to confirm your setting or press  Back to return to the previous menu.

Table 27 Phone Settings (continued)

Clock	Settings > Clock There are six options included in Clock menu: Settings > Clock > Time This option enables you to adjust the current time. Press  and enter the appropriate time with numeric keys. Press  OK to confirm your setting or press  Back to menu. Settings > Clock > Date This option enables you to adjust the current date. Press  and enter the appropriate date with numeric keys. Press  OK confirm your setting or press  Back to menu. Settings > Clock > Time Format You can set the desired display format (12-Hour or 24-Hour) for the time. If 12-Hour is set as Time Format, the correspondent format (AM/PM) appears on the screen. Settings > Clock > Date Format You can set the display format (YY/MM/DD or MM/DD/YY). Settings > Clock > Time Zone You can set the time zone of your location to count the time difference when you travel around the world. Settings > Clock > Daylight Savings You can set Off or On if the daylight saving time is needed. Settings > Clock > Network Time You can set Off or On for Network Time. If the network time is set On, then select a Time Server from the list displayed.
-------	---

Table 27 Phone Settings (continued)

Alarm Clock	Settings > Alarm Clock This option enables you to set the alarm to ring at a specific time. Alarm Time: Press  and enter the appropriate time with numeric keys. Press  OK to confirm your setting. Mode: Press  and to activate the alarm Once, Daily or Weekly and then press  Set to confirm your setting. To cancel the alarm clock, select Off and then press  Set to confirm your setting.
-------------	---

Table 27 Phone Settings (continued)

Call Settings	Settings > Call Settings Three options are included in Call Settings: Settings > Call Settings > Call Waiting For details, refer to <i>Using Call Waiting</i> on page 36. Settings > Call Settings > Call Forward For details, refer to <i>Using Call Forwarding</i> on page 37. Settings > Call Settings > Block Caller ID This feature allows you to hide your phone number to the calling party. Press  to select On or Off. Settings > Call Settings > Refuse Private This feature allows you to refuse calls that have caller ID blocked. Press  to select On or Off to activate/deactivate. Settings > Call Settings > Beep Notification This feature allows you to set Off or On for beep awareness at the 50 seconds for every 1 minute interval. Press  Set to confirm your setting. Or press  Back to the menu. Settings > Call Settings > Hold Transfer This feature allows you to transfer your call via SIP server or DTMF Flash. Press  to select SIP or DTMF Flash. Settings > Call Settings > Regional Tone This feature enables you to set a specific call progressing tone. Press  to select North America or Japan.
---------------	---

Table 27 Phone Settings (continued)

Speed Dial	Settings > Speed Dial There are three options for you to choose: Disable: Deactivate the speed dial function. Ask: Press and hold the numeric key (for example, 1) the screen will display the numbers and then press  to make the call. Dial: Press and hold the numeric key (for example, 1) to make the call directly.
Sound Settings	Settings > Sound Settings Four options are included in Sound Settings: Settings > Sound Settings > Speaker Volume You can adjust the speaker volume through the menu or by using the 5-way navigation key. To increase the volume, either press  or . To decrease the volume, press either  or . Press  OK to confirm your setting and then press  Back to menu. Settings > Sound Settings > Ring Tone Settings > Sound Settings > Ring Mode You can select the preferred Melody and/or set the Ring Volume and Ring Mode in the Ring Tone menu. For details, refer to "Setting the Ring Mode and Ring Tone" on page 33. Settings > Sound Settings > Warning Tone You can either turn On or Off the warning tone. Press  Set to confirm your setting.

Table 27 Phone Settings (continued)

Display Settings	Settings > Display Settings Settings > Display Settings > Wallpaper For details, refer to “Setting a Wallpaper Image” on page 34. Settings > Display Settings > Greeting This option enables you to set welcome words as greeting and to be displayed when the phone is powered on. Settings > Display Settings > LCD Off Time You can select the period of time the LCD is on. The backlight turns on when you press a key and turns off when there is no activity for the specified time period. You can either select LCD off time as Always On, 15 Seconds or 30 Seconds. Settings > Display Settings > LCD Brightness For details, refer to “Adjusting the Backlight” on page 35. Settings > Display Settings > Config. Tip This feature allows you to view all the settings you’ve set. When scrolling over a setting, a small window indicates the value.  Press  to select On or Off to activate/deactivate.
Keypad	Settings > Keypad Three options included in Keypad: Settings > Display Settings > Keypad Lock Key lock is used to prevent unintentional pressing of keys. Press  OK to process the action or press  Back to the menu. Settings > Display Settings > Key Tones You can activate the tone that the phone sounds when you press a key. To activate the key tone, press  to select Click Tone. To deactivate the key tone, select Tone Off. Settings > Display Settings > Key Backlight You can activate (set as On) the key backlight when you press a key.

Tools

[Table 28](#) describes each of the options you have through the Tools menu.

Table 28 Tools Options

Feature	Description
Signal Quality	Tools > Signal Quality Displays the status of current wireless connection, including ESSID, BSSID, Channel, Rate, RSSI, Noise and Security.
Site Survey	Tools > Site Survey Lists all available networks. You can see all listed networks (sites) information. Press  Renew to rescan the networks. Press  Detail to check the details.
Statistics	Tools > Statistics You can check the following information: IP Statistics, RTP/RTCP, Encoding and Decoding. To refresh the information, press  to Renew .
Battery	Tools > Battery You can see Charger Status and Voltage level.
Ping	Tools > Ping You can test connectivity with a network host.
Version	Tools > Version You can view information for Bootcode, Firmware, Build Time and RAM Size.
Back to Default	Tools > Back to Default You can either Clear the original data recorded in Phonebook , E-mail or Others . You can also remove All settings on your phone and reset factory defaults. A confirmation message appears on the screen before the change. Press  OK to proceed or  Back to exit to the menu.
Restart	Tools > Restart A confirmation message appears. Press  OK to power your phone off and on, or press  Back to return to the menu.

8

WEB CONFIGURATION

The 3108 Wireless Telephone includes a built-in Web Configuration utility that allows you to easily view and edit your telephone settings from your PC.

This chapter covers the following topics:

- [Accessing the Web Configuration Utility](#)
- [Checking Wireless Network Status](#)
- [Editing Names and Numbers in Your Phone Book](#)
- [Wireless Network Settings](#)
- [SIP Settings](#)
- [Phone Settings](#)
- [E-mail Settings](#)
- [Upgrade Software](#)
- [Upgrade Bootcode](#)
- [Debug Statistics](#)
- [Reboot Phone](#)
- [Password](#)
- [Logout](#)

Accessing the Web Configuration Utility

To access the Web Configuration utility, your Wireless phone must have an IP address and WLAN connection. The PC used to view the Web Configuration utility must be connected to this same network.

- 1 In Standby, press  **Status** to view your Phone Status — **IP Address**. A connected IP address is indicated (for example, 172.16.140.174).
- 2 Enter the phone's IP address in your PC's Web browser (for example, <http://172.16.140.174>).
- 3 Enter the Logon ID and password to access the Web Configuration utility. (The initial default settings for logon ID and password are: **admin** and **admin**, respectively.)

Checking Wireless Network Status

By selecting **Current Status**, you can view your phone's **ESSID**, **BSSID**, **IP address** and **MAC address** settings for the wireless network.



Editing Names and Numbers in Your Phone Book

Using **Phone Book** in Web Configuration, you can add, store, edit or remove all recorded entries.

To create a new entry:

- 1 Select **New** and then enter the **Name** (20 characters as max. length), **E-mail**, **Ring Tone**, **Number** and/or set the **Speed Dial** (1 to 9).
- 2 Select Save to add the new entry to your Phonebook.

To edit an existing entry:

- 1 In the Name column, double-click the entry you want to edit.
- 2 Make any changes you need.
- 3 After editing an entry, you can **Save**, **Delete**, **Cancel** or **Reset** the entry.




You can delete all the recorded entries by pressing **Clear All**. A confirmation message appears on the screen. Press **OK** to confirm your setting. All entries are then removed from the Phone Book.

Wireless Network Settings

Select **Wireless Network Settings** to display your Network Profile List. From this list you can **Configure** or **Remove** a network profile.

To configure a network profile:

- 1 Select the profile entry and click **Configure** to enter the sub-menu.



[Table 29](#) describes the settings that you can configure for a Network Profile.

Table 29 Network Profile Settings

Setting	Description
Network Profile Name:	Enter the network profile name.
ESSID:	Stands for Extended Service Set Identifier. Specifying the ESSID is how you make sure that you connect to your wireless network instead of your neighbor's network by mistake. You can either manually input the New ESSID or select Site Survey to check all available networks. For example: Default.
Data Rate:	It can be set as Auto, 1Mbps/s, 2Mbps/s, 5.5Mbps/s, 6Mbps/s, 9Mbps/s, 11Mbps/s, 12Mbps/s, 18Mbps/s, 24Mbps/s, 36Mbps/s, 48Mbps/s or 54Mbps/s.
Security:	Options include: OPEN, WEP-64, WEP-128, WPA-PSK TKP, WPA, PSK AES, WPA2-PSK TKP, WPA2-PSK AES, WPA TKIP, WPA AES, WPA2 TKIP, WPA2 AES
IP Setting:	Select one of the following: DHCP, Fixed IP or PPPOE.
NAT Setting:	Select one of the following: Disable, SIP PING or STUN. You can also set NAT timer.

- 2
- Select **Save** to confirm your settings. Alternatively, you can select **Cancel** to leave the settings unchanged, or **Reset** to remove the settings.
- 3
- Edit the Certification settings (CA Cert./ User Cert./ Private Key) as needed.
- 4
- Edit your SIP Account Choice setting as needed.

SIP Settings

Select **SIP Account Settings** to display the SIP Account List. From this list you can **Configure** or **Remove** a SIP Account.

To configure a SIP Account:

- 1 Select the account entry and click **Configure** to enter the sub-menu.

- 2 Edit the following SIP Account settings as needed: SIP Account Name, Phone Number, Authentication ID, Authentication Password, SIP Domain, Proxy Address, Outbound Address, Local Port, Register Timer(sec), Codec (Auto/G.711u/G.711a/ G129A), Pkt Time(ms)(Default, 20,30,40,50,60,70,80), OutofBand DTMF (Off/On).
- 3 Select **Save** to confirm your settings. Alternatively, you can select **Cancel** to leave the settings unchanged or **Reset** to remove the settings.

Phone Settings

This section describes the phone settings you can view or edit. [Table 30](#) describes the settings that you can configure for a Network Profile.

Table 30 Phone Settings

Setting	Description
Clock:	Three options can be set: Time Zone, Daylight Savings and Network time.
Call Settings:	You can set Call Waiting, Forward Number, No Answer, Block Caller ID, Beep Notification, Hold Transfer, Forward All, Busy, Refuse Private and Regional Tone in Call Settings.
Sound Settings:	You can set Speaker Volume, Ring Volume, Warning Tone, Melody and Ring Mode in Sound Settings.
Display Settings:	You can set LCD Off Time or Wallpaper in Display Settings.

E-mail Settings

This section helps you to manage your e-mail account.

- 1 To adjust your e-mail account, click **Configure** to enter the sub-menu.
- 2 The following options are listed: Account Name, Your Name, Mail Address, POP3 Address, POP3 User ID, POP3 Password, POP3 Port, SMTP Address, SMTP User ID, SMTP Password, SMTP Port, Reply Address and Signature.
- 3 You can also **Remove** or **Activate** one of up to five e-mail accounts.

Upgrade Software

This option enables you to upgrade your phone's software. The 3108 Wireless Telephone is shipped with firmware already installed. To upgrade your firmware:

- 1 Click **Browse** and find the new firmware image on your network or on a CD.
- 2 Click **Upgrade**. Be sure to wait at least 3 minutes for the upgrade process to complete.

The screenshot shows the 'WI-FI Phone' web interface. On the left is a navigation menu with links: [Current Status](#), [Phone Book](#), [Wireless Network Settings](#), [SIP Settings](#), [Phone Settings](#), [E-mail Settings](#), and [Upgrade Software](#). The 'Upgrade Software' link is highlighted with a mouse cursor. The main content area is titled 'Upgrade Software' and contains the following fields and buttons:

- Active:** A text box containing 'RRP881t_FW_1.00.19.bin Fri Jul 14 15:53:19 2006'.
- Inactive:** A text box containing 'RRP881t_FW_1.00.19-pre1.bin Thu Jul 6 13:32:17 2006'.
- New Image:** An empty text box followed by a 'Browse...' button.
- A note: 'Note: Please wait for 3 minutes to complete upgrading.'
- At the bottom are two buttons: 'Upgrade' and 'Reset'.

Upgrade Bootcode

This option enables you to upgrade your phone's bootcode (starting system).



CAUTION: Do not interrupt a boot code upgrade operation.

The screenshot shows a web interface for a 'WI-FI Phone'. On the left is a sidebar with links: [Current Status](#), [Phone Book](#), [Wireless Network Settings](#), [SIP Settings](#), [Phone Settings](#), and [E-mail Settings](#). The main content area has a blue header with the text 'WI-FI Phone'. Below the header, the 'Upgrade Bootcode' section is highlighted. It contains a caution message: 'Caution: Interruption of upgrading may cause system failure.' Below this, there are two input fields: 'Current version:' with the value '1.00.04' and 'Bootcode Image:' which is empty. To the right of the 'Bootcode Image' field is a 'Browse...' button. At the bottom of the section are two buttons: 'Upgrade' and 'Reset'.


Debug Statistics

Detailed information about Debug Statistics is listed.

Information includes: **Wireless Network Status** (ESSID, BSSID, IP address, MAC address), **WL Info** (rssi is, noise is, No scan in progress, current mac channel, target channel, Receive, Transmit), **RTP Stats** (igrRtpPkt, igrRtpByte, egrRtpByte, egrRtpCumLostPkt, egrRtpNoProfDiscPkt, igrRtpPkt, egrRptJitter, igrRtpLatency), **PVE Stats** (peakHoldingTime, packetCount, addTailCount, reorderCount, overrunCount, duplicateCount, outOfRangeCount, tooLateCount, cantDecodeCount, ajcUnderrunCount, ajcDeleteCount, ajcRepeatCount, ajcResyncCount, ajcPhaseJitterCount, inactiveFrameCount, activeFrameCount, sidFrameCount, toneRelayCount) and **PVE State** (timer, expectedTimestamp, lastArrivalTime, lastArrTimeStamps, lastReleaseTimestamp, actualHoldTime, currentHoldTime, minHoldTimeTracker, masHoldTimeTracker, releaseBump, underrunDuration, actionPendingTimer, currentDec, timerLastArrival, currentEnc, currentEncPktTime, currentEncPktSize).

Reboot Phone

After upgrading software, you need to reboot the phone (power off and on) to activate all new settings.



Password

You can change the current password for the Web Configuration utility by using this feature.

Logout

To exit the web configuration, select Logout.

9

TROUBLESHOOTING

This appendix contains troubleshooting suggestions for identifying and solving common network connection and SIP registration problems. For additional assistance, see your network administrator.

Unable to Connect to the Network

If upon power up, your phone displays the message “No Network,” check the following:

- Check the signal strength on your phone’s display. Make sure that you are within range of the WLAN signal transmitter.
- Select  **Status** and check to see if your phone’s wireless settings are correct. If your phone is configured to obtain its IP address from a DHCP server, check that it has received its IP address. If you need to modify your phone’s wireless settings, see “[Entering the Network Profile Settings](#)” on [page 26](#).
- If you have multiple network profiles configured for your phone, verify that the correct network profile is active. See “[Activating a Network Profile](#)” on [page 30](#).

Unable To Register With The SIP Server

If upon power up, your Wireless phone shows a network connection, but displays the message “No Service,” check the following:

- Select  **Status** and check to see if your phone’s SIP settings are correct. If you need to modify any of these settings, see “[Entering the SIP Account Settings](#)” on [page 28](#).
- If you have multiple network profiles configured for your phone, verify that the correct network profile is active. See “[Activating a Network Profile](#)” on [page 30](#).
- Make sure the SIP account is properly defined and that this SIP account name appears in the Account Choice option of the active

network profile. See “[Entering the Network Profile Settings](#)” on [page 26](#).

A

REGULATORY INFORMATION

The 3Com 3108 Wireless Telephone, (3C10408A, WL-108) must be installed and used in strict accordance with the manufacturer's instructions as described in the user documentation that comes with the product. This device complies with the following radio frequency and safety standards.



This product contains encryption. It is unlawful to export out of the U.S. without obtaining a U.S. Export License.

This product does not contain any user serviceable components. Any unauthorized product changes or modifications will invalidate 3Com's warranty and all applicable regulatory certifications and approvals.

This device has been designed to operate with the antennas listed below, and having a maximum gain of [3.41] dB. Antennas not included in this list or having a gain greater than [3.41] dB are strictly prohibited for use with this device. The required antenna impedance is [50] ohms.

**Caution: Exposure to
Radio Frequency
Radiation**

The highest SAR value for this model WL-108 was tested by DASY4, considering handset use in contact with the body, and is in compliance with FCC SAR limits.

This equipment doesn't include any accessories and complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be carried with a minimum distance 1.5cm (1 inch) between the antenna and your body, when handset is not in use.

The installer of this radio equipment must ensure that the antenna is located or pointed such that it does not emit RF field in excess of Health Canada limits for the general population; consult Safety Code 6, obtainable from Health Canada's website www.hc-sc.gc.ca/rpb.

This product has been tested and complied with the standard EN50360 and EN50361.

US – Radio Frequency Requirements

This device must not be co-located or operated in conjunction with any other antenna or transmitter.

USA-Federal Communications Commission (FCC)

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy. If not installed and used in accordance with the instructions, it may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by tuning the equipment off and on, the user is encouraged to try and correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the distance between the equipment and the receiver
- Connect the equipment to outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

The user may find the following booklet prepared by the Federal Communications Commission helpful:

The Interference Handbook

This booklet is available from the U.S. Government Printing Office, Washington, D.C. 20402. Stock No. 004-000-0034504.

3Com is not responsible for any radio or television interference caused by unauthorized modification of the devices included with this 3Com 3108 Wireless Telephone, (3C10408A, WL-108), or the substitution or attachment of connecting cables and equipment other than specified by 3Com.

The correction of interference caused by such unauthorized modification, substitution or attachment will be the responsibility of the user.

**Manufacturer's
Declaration of
Conformity**

3Com Corporation
350 Campus Drive
Marlborough, MA 01752-3064, USA
(800) 527-8677
Date: Aug. 15, 2006

Declares that the Product:
Brand Name: 3Com Corporation
Model Number: WL-108
Equipment Type: 3Com 3108 Wireless Phone



3Com 3108 Wireless Telephone
Model WL-108

**Canada – Industry
Canada (IC)**

This device complies with RSS 210 of Industry Canada.

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of this device."

L' utilisation de ce dispositif est autorisée seulement aux conditions suivantes: (1) il ne doit pas produire de brouillage et (2) l' utilisateur du dispositif doit être prêt à accepter tout brouillage radioélectrique reçu, même si ce brouillage est susceptible de compromettre le fonctionnement du dispositif.

The term "IC" before the equipment certification number only signifies that the Industry Canada technical specifications were met.

To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (EIRP) is not more than that required for successful communication. To prevent radio interference to the licensed service, this device is intended to be operated indoors and away from windows to

provide maximum shielding. Equipment (or its transmit antenna) that is installed outdoors is subject to licensing.

Pour empêcher que cet appareil cause du brouillage au service faisant l'objet d'une licence, il doit être utilisé à l'intérieur et devrait être placé loin des fenêtres afin de fournir un écran de blindage maximal. Si le matériel (ou son antenne d'émission) est installé à l'extérieur, il doit faire l'objet d'une licence.

**Industry Canada (IC)
Emissions Compliance
Statement**

This Class B digital apparatus complies with Canadian ICES-003.

AVIS DE CONFORMITÉ À LA RÉGLEMENTATION D'INDUSTRIE CANADA

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

**Safety Compliance
Notice**

This device has been tested and certified according to the following safety standards and is intended for use only in Information Technology Equipment which has been tested to these or other equivalent standards:

- UL Standard 60950-1
- CAN/CSA C22.2 No. 60950-1
- IEC 60950-1
- EN 60950-1

**Europe – EU
Declaration of
Conformity**

EU Declaration of Conformity



This equipment may be operated in							
AT	BE	CY	CZ	DK	EE	FI	FR
DE	GR	HU	IE	IT	LV	LT	LU
MT	NL	PL	PT	SK	SI	ES	SE
GB	IS	LI	NO	CH	BG	RO	TR

Caution: NO! Country Code selection feature to be disabled for products marketed to the US/CANADA.

Intended use: IEEE 802.11b/g radio device

To ensure product operation is in compliance with local regulations, select the country in which the product is installed. Refer to 3Com 3108 Wireless Telephone Guide (3C10408A, WL-108).

Europe - Declaration of Conformity in Languages of the European Conformity

Declaration of Conformity in Languages of the European Conformity

Česky [Czech]	3Com Coporation tímto prohlašuje, tímto prohlašuje, že tento RLAN device je ve shodě se základními požadavky a dalšími příslušnými ustanoveními směrnice 1999/5/ES..
Dansk [Danish]	Undertegnede 3Com Corporation erklærer herved, at følgende udstyr RLAN device overholder de væsentlige krav og øvrige relevante krav i direktiv 1999/5/EF.
Deutsch [German]	Hiermit erklärt 3Com Corporation, dass sich das Gerät RLAN device in Übereinstimmung mit den grundlegenden Anforderungen und den übrigen einschlägigen Bestimmungen der Richtlinie 1999/5/EG befindet.
Eesti [Estonian]	Käesolevaga kinnitab 3Com Corporation seadme RLAN device vastavust direktiivi 1999/5/EÜ põhinõuetele ja nimetatud direktiivist tulenevatele teistele asjakohastele sätetele.
English	Hereby, 3Com Corporation, declares that this RLAN device is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.
Español [Spanish]	Por medio de la presente 3Com Corporation declara que el RLAN device cumple con los requisitos esenciales y cualesquiera otras disposiciones aplicables o exigibles de la Directiva 1999/5/CE.
Ελληνική [Greek]	ΜΕ ΤΗΝ ΠΑΡΟΥΣΑ 3Com Corporation ΔΗΛΩΝΕΙ ΟΤΙ RLAN device ΣΥΜΜΟΡΦΩΝΕΤΑΙ ΠΡΟΣ ΤΙΣ ΟΥΣΙΩΔΕΙΣ ΑΠΑΙΤΗΣΕΙΣ ΚΑΙ ΤΙΣ ΛΟΙΠΕΣ ΣΧΕΤΙΚΕΣ ΔΙΑΤΑΞΕΙΣ ΤΗΣ ΟΔΗΓΙΑΣ 1999/5/EK.
Français [French]	Par la présente 3Com Corporation déclare que l'appareil RLAN device est conforme aux exigences essentielles et aux autres dispositions pertinentes de la directive 1999/5/CE.
Italiano [Italian]	Con la presente 3Com Corporation dichiara che questo RLAN device è conforme ai requisiti essenziali ed alle altre disposizioni pertinenti stabilite dalla direttiva 1999/5/CE.
Latviski [Latvian]	Ar šo 3Com Corporation deklarē, ka RLAN device atbilst Direktīvas 1999/5/EK būtiskajām prasībām un citiem ar to saistītajiem noteikumiem.
Lietuvių [Lithuanian]	Šiuo 3Com Corporation deklaruoja, kad šis RLAN device atitinka esminius reikalavimus ir kitas 1999/5/EB Direktyvos nuostatas.
Nederlands [Dutch]	Hierbij verklaart 3Com Corporation dat het toestel RLAN device in overeenstemming is met de essentiële eisen en de andere relevante bepalingen van richtlijn 1999/5/EG.
Malti [Maltese]	Hawnhekk, 3Com Corporation, jiddikjara li dan RLAN device jikkonforma mal-htigijiet essenzjali u ma provvedimenti oħrajn rilevanti li hemm fid-Dirrettiva 1999/5/EC.
Magyar [Hungarian]	Alulírott, 3Com Corporation nyilatkozom, hogy a RLAN device megfelel a vonatkozó alapvető követelményeknek és az 1999/5/EC irányelv egyéb előírásainak.

Polski [Polish]	Niniejszym 3Com Corporation oświadcza, że RLAN device jest zgodny z zasadniczymi wymogami oraz pozostałymi stosownymi postanowieniami Dyrektywy 1999/5/EC.
Português [Portuguese]	3Com Corporation declara que este RLAN device está conforme com os requisitos essenciais e outras disposições da Directiva 1999/5/CE.
Slovensko [Slovenian]	3Com Corporation izjavlja, da je ta RLAN device v skladu z bistvenimi zahtevami in ostalimi relevantnimi določili direktive 1999/5/ES.
Slovensky [Slovak]	3Com Corporation týmto vyhlasuje, že RLAN device spĺňa základné požiadavky a všetky príslušné ustanovenia Smernice 1999/5/ES.
Suomi [Finnish]	3Com Corporation vakuuttaa täten että RLAN device tyypinen laite on direktiivin 1999/5/EY oleellisten vaatimusten ja sitä koskevien direktiivin muiden ehtojen mukainen.

A copy of the signed Declaration of Conformity can be downloaded from the Product Support web page for the 3C10408A at <http://www.3com.com>.

Also available at http://support.3com.com/doc/WL-108_EU_DOC.pdf

**Europe - Restrictions
for Use of 2.4 GHz
Frequencies in
European Community
Countries**

- This device may be operated indoors or outdoors in all countries of the European Community using the 2.4GHz band: Channels 1 – 13, except where noted below.
- In Italy the end-user must apply for a license from the national spectrum authority to operate this device outdoors.
- In Belgium outdoor operation is only permitted using the 2.46 – 2.4835 GHz band: Channel 13.
- In France outdoor operation is only permitted using the 2.4 – 2.454 GHz band: Channels 1 – 7.

Brazil RF Compliance

Este produto está homologado pela ANATEL, de acordo com os procedimentos regulamentados pela Resolução 242/2000, e atende aos requisitos técnicos aplicados.

Opera em caráter secundário, isto é, não tem direito a proteção contra interferência prejudicial, mesmo de estações do mesmo tipo, e não pode causar interferência a sistemas operando em caráter primário.

Para maiores informações, consulte o site da ANATEL – www.anatel.gov.br

Korea RF Compliance This device may cause radio interference during its operation. Therefore service in relation to human life security is not available.

INDEX

Numbers

- 3108 Wireless Telephone
 - display icons 21
 - graphic showing open, front, and back views 14
 - graphic showing side, top, and bottom views 15
 - initial configuration of 25
 - VoIP operation 13
- 3Com NBX System 25

A

- Account Choice 27
- administrator, definition 8
- Auto Attendant, definition 8
- Auto Detect 30
- available characters in text mode 23

B

- battery
 - charging 11
 - compartment for 14
 - installing 11
 - level indicator 21
 - type of 17

C

- call forwarding 39
- call log 37
 - menu 42
- call mute 38
- call transfer 38
- call waiting 39
- connection status 19
- conventions, documentation 8

D

- date setting 32
- debug statistics 61

- deleting characters 22

E

- earphone jack
 - location of 15
- E-Mail menu 43
- e-mail settings 60
- encryptionSee security 27
- entering digits, *, and # characters 22
- entering letters and special characters 22
- Extended Service Set Identifier (ESSID) 26

H

- Hotspot Choice 28

I

- icons
 - 3108 Wireless Telephone display 21
- Internet Telephony Service Provider (ITSP) 25
- IP settings 27

K

- keypad lock 21

L

- LCD brightness setting 35
- LED indicators 24
- logging out 62

N

- NAT Settings 28
- network profile 57, 59
 - activating 30
 - configuring 26
 - renaming 26
- Network Profile menu 26
- no network messageSee unable to connect to the network 63

no service messageSee unable to register with the
SIP server 63
numeric modeSee entering digits, *, and #
characters 22

P

password
for Profile menu 26
phone settings 59
phonebook
accessing from the Web Configuration utility 56
menu 41
storing entries in 24
using to make a call 20
power key 12
Profile menu 25, 46

R

rebooting phone 62
receptionist
definition 8
ring mode setting 33
ring tone setting 33

S

security 27
Session Initiation Protocol 13
Settings menu 47
SIP account 28, 58
associating with network profile 28
configuring 28
renaming 28, 29
SIPSee Session Initiation Protocol 13
Site Survey 26
speed dial
assigning an entry to 46
Speed Dial menu 46
switching between text and numeric modes 23

T

text modeSee entering letters and special
characters 22
time setting 31
Tools menu 53

U

unable to connect to the network 63
unable to register with the SIP server 63

upgrading bootcode 61
upgrading software 60
USB Data Cable slot
location of 15
plugging AC power adapter into 12
user, definition 8

V

VoIP 13, 28
volume adjustment keys
location of 15
use of 20

W

wallpaper setting 34
Web Configuration utility
accessing 56
changing password for 62
using to view current status 56
wireless network settings 57