



SENTINEL-SENSE MPR-2010BR

Installation & Operation Manual-041318



COPYRIGHT ACKNOWLEDGEMENTS

The contents of this document are the property of Applied Wireless Identifications Group, Inc. (AWID) and are copyrighted. All rights reserved. Any reproduction, in whole or in part, is strictly prohibited. For additional copies of this document please contact:

AWID

18300 Sutter Blvd

Morgan Hill, CA 95037

<http://www.AWID.com>

The information contained herein has been carefully checked and is believed to be accurate, no responsibility is assumed for inaccuracies. AWID reserves the right to make changes without prior notice. This document is not covered by any warranty either expressed or implied. Any comments, corrections or additions to the contents of this document should be directed to AWID at the above address.

Copyright 2006 AWID, Printed in USA.

All other trademarks are the property of their respective owners.

FCC COMPLIANCE

This equipment has been tested and found to be in compliance with the limits for FCC Part 15, Class A digital device. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with instruction manual, may cause harmful interference with radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

The users are prohibited from making any change or modification to this product, any modification to this product shall voids the user's authority to operate under FCC Part 15 Subpart A Section 15.21 regulations.

"This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference and, (2) this device must accept any interference received, including interference that may cause undesired operation."

INDUSTRY CANADA COMPLIANCE

Operation is subject to the following two conditions: (1) this device may not cause interference and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

CAUTION:



Reader should be positioned so that personnel in the area for prolonged periods may safely remain at least 20 cm (8 in) in an uncontrolled environment from the reader's surface. Observe FCC OET Bulletin 56 "Hazards of radio frequency and electromagnetic fields" and Bulletin 65 "Human exposure to radio frequency electromagnetic fields."

Table of Contents

1	INTRODUCTION.....	5
1.1	Special Features:	5
2	SPECIFICATIONS.....	6
2.1	Channel Frequency Table.....	6
2.2	Input and Output Interfaces & Connector Pin Assignment.....	6
2.2.1	Connector Pin Assignment	6
2.3	Measuring Read Distance.....	7
3	INSTALLATION & OPERATION GUIDELINES	7
3.1	Site Survey.....	7
3.2	Preferred Reader Installation Practices	7
3.3	Mounting Preference.....	8
3.4	General Wiring Requirements.....	8
3.5	Wiring Diagrams	8
3.6	Grounding.....	9
4	INSTALLATION PROCEDURE	9
4.1	Parts List.....	9
4.2	Preparation for Installation	9
4.2.1	Bench Top Verification.....	9
4.2.2	Aiming of Antenna	9
4.2.3	Mounting Considerations	10
4.3	Installation Steps.....	11
5	SOFTWARE PROGRAMMING AND SYSTEM OPERATION NOTES.....	11
5.1	System Operation	11
5.1.1	Running a Custom Software Application or the AWID Demo Program.....	11
5.1.2	Operating Modes	11
5.2	Users Note	12
6	MPR SERIAL COMMUNICATION PROTOCOL.....	12

NOTE: READ AND USE THIS MANUAL

FAILURE TO FOLLOW THE INSTALLATION GUIDE MAY RESULT IN POOR PERFORMANCE OR EVEN CAUSE PERMANENT DAMAGE TO THE READER, THUS VOIDS THE PRODUCT WARRANTY.

1 INTRODUCTION

AWID's Sentinel-Sense MPR-2010BR is a long-range (12 to 15 feet) Radio Frequency IDentification (RFID) reader with RS-232 I/O that works with most leading UHF passive tags. This reader comes with a unique combination of long read range, small size, and low power consumption. It has an internal power converter, allowing it to work with a wide range of supply inputs without affecting its performance. Its primary applications are asset management and tracking, and fleet management applications.

The MPR-2010BR readers are delivered with the following components and accessories:

- ❑ MPR-2010BR, firmware version 3.xxM
- ❑ CD containing interface document and demo SW
- ❑ Power supply – PS9-2A-SW, 50-60 Hz and 110 to 220 VAC

In order to control the MPR-2010BR reader you will need the following:

- ❑ PC running Windows¹ 98 or higher, CD-ROM drive and one RS-232 serial port.
- ❑ Host software (AWID's demo software or your own custom software).
- ❑ RFID Tags (EPC C1 Gen 1 & 2, ISO Type B, etc)

1.1 SPECIAL FEATURES:

- Multi-Protocol: EPC C0², C1³ Gen 1 & 2, ISO Type B, EPC V1.19 Rev.2
- Thin passive tags with long-range performance
- High performance circular polarized antenna
- RS-232 data input/output
- Splash proof design for indoor or outdoor applications
- UV stabilized housing

¹ Though MPR-2010BR can also be controlled from a non-Windows programming platform, AWID demo and FW upgrade programs are applications to run in Windows.

² Both 64- and 96-bit

³ Both 64- and 96-bit

2 SPECIFICATIONS

Input voltage	+7.0 VDC to +15 VDC
Input current	1.0 A (7.0 V) to 0.40 A (15 V) typical
Protocol language	ISO Type B, EPC Class 1 Gen 1 & 2, EPC Class 0, EPC V1.19 Rev.2
Read range	Depends on type & size of labels used
Output power	1.0 Watt into 6 dB antenna
Transmit frequency	902-928 MHz
Receiver frequency	902-928 MHz (Amplitude Modulated)
Hopping channels	50 Channels
Channel spacing	500 kHz
Hopping sequence	Pseudo random
Operating temperature range	-30° C to +65° C (-22° F to 149° F)
Color	Beige
Output data formats	RS-232
Dimension	8X9.5X1.125 inches (20X24X2.86 cm)
Weight	

2.1 CHANNEL FREQUENCY TABLE


Frequency range: 902 ~ 928 MHz

Minimum number of frequency channels: 50

CH	902~928	MHz	CH	902~928	MHz	CH	902~928	MHz	CH	902~928	MHz	CH	902~928	MHz
8	905.11	MHz	18	907.57	MHz	28	910.03	MHz	38	912.49	MHz	48	914.95	MHz
9	905.35	MHz	19	907.82	MHz	29	910.28	MHz	39	912.74	MHz	49	915.20	MHz
10	905.60	MHz	20	908.06	MHz	30	910.52	MHz	40	912.98	MHz	50	915.45	MHz
11	905.85	MHz	21	908.31	MHz	31	910.77	MHz	41	913.23	MHz	51	915.69	MHz
12	906.09	MHz	22	908.55	MHz	32	911.02	MHz	42	913.48	MHz	52	915.94	MHz
13	906.34	MHz	23	908.80	MHz	33	911.26	MHz	43	913.72	MHz	53	916.18	MHz
14	906.58	MHz	24	909.05	MHz	34	911.51	MHz	44	913.97	MHz	54	916.43	MHz
15	906.83	MHz	25	909.29	MHz	35	911.75	MHz	45	914.22	MHz	55	916.68	MHz
16	907.08	MHz	26	909.54	MHz	36	912.00	MHz	46	914.46	MHz	56	916.92	MHz
17	907.32	MHz	27	909.78	MHz	37	912.25	MHz	47	914.71	MHz	57	917.17	MHz

2.2 INPUT AND OUTPUT INTERFACES & CONNECTOR PIN ASSIGNMENT

2.2.1 Connector Pin Assignment



<u>Pin</u>	<u>Function</u>	<u>Pin</u>	<u>Function</u>
1	Ground	6	+7V/+15V
2	RS232 Tx	7	+7V/+15V
3	RS232 Rx	8	Data 0
4	Enable RFID	9	Data 1
5	Ground	10	Ext Data in

2.3 MEASURING READ DISTANCE

Make sure you know the tag types. For certain readers and tags, user must also be mindful of the tag's orientation and the reader's antenna orientation, what mounting surface the tags are designed for and how the tags are supposed to be mounted. Any departure from its intended purpose will drastically affect the reader's ability to energize the tag and its read range.

When measuring the reader's read range, make sure that the tag is properly oriented to the reader antenna, and for optimum performance, be sure the operator's finger is not within three (3) inches of the tag's antenna surface.

3 INSTALLATION & OPERATION GUIDELINES

3.1 SITE SURVEY

Always conduct a site survey before starting installation. Avoid any possible sources of interference. For best result, use a spectrum analyzer with a wideband antenna and set the spectrum analyzer in Max Hold mode to gain measurement of the maximum signal strength on the airwave. If the MPR-2010BR reader is not installed properly, the performance will be degraded. Listed below are steps that should be followed during installation:

- Do not install reader in an area where sources of broadband noise may exist. Avoid mounting the reader facing a cellular phone tower or in close proximity to the base station of a 900 MHz wireless telephone.
- Keep all of the reader wiring a safe distance from all other wiring, including, but not limited to, AC power, computer data wiring, and telephone wiring, and wiring to electrical locking devices.
- Avoid operating the reader in close proximity to other 900 MHz wireless local area networking (WLAN) equipment. It should be noted that MPR-2010BR readers are known to work in electromagnetic crowded areas, such as trade shows.

3.2 PREFERRED READER INSTALLATION PRACTICES

- Avoid mounting the under direct sunlight. Exposure to direct sunlight may cause the reader to operate at a temperature above the 65 degrees Celsius upper limit.

- Make sure that the supply voltage of the reader is within specification
- Use cables with over-all shield (screen)
- For best results, avoid bundling data cable with AC power and computer cables
- Use the largest wire gauge where feasible
- Use dedicated power supply, where necessary
- Use Single Point Grounding, and avoid ground loops

3.3 MOUNTING PREFERENCE

MPR-2010BR has a uni-directional antenna with an antenna beam width of about 60-70 degrees. The radiation pattern is an oval-shaped beam, which should be aimed toward where the transponders will pass.

3.4 GENERAL WIRING REQUIREMENTS

All the reader wiring should be continuously shielded. AWID recommends using #24 AWG up to #22 AWG, longer distances and higher current consumption on the power supply line will require larger gauge wires. PG I/O output are standard access industry Wiegand drivers, which is capable of 500 feet driving distance.


TABLE 3.4-1: Data Line's Wiring Requirement

WIRE SIZE	#22 AWG (0.6 mm Dia.)	#24 AWG (0.5 mm Dia.)
RS-232	50 ft (15 meters)	50 ft (15 meters)

3.5 WIRING DIAGRAMS

See section 2.2 for pin assignment for the RS-232 connector.

MPR-2010BR's RS-232 interface is a short distance serial interface, a full command set for the standard serial interface is not necessary, therefore only transmit, receive and ground wires are used. Sense input is an enable input, which is traditionally used to activate the RF energy of the reader and to start the read functions.



3.6 GROUNDING

Grounding is critical for proper operation of MPR-2010BR. When installing the reader, it is crucial to assure that the earth ground is the best ground available. If you elect to use the 120 VAC power ground, conduct a test by measuring its resistance relative to a known good ground, such as a cold water pipe or structural steel that is in direct contact with the ground. The resistance should be less than 50 ohms.

4 INSTALLATION PROCEDURE

This section provides information on installation and operation of MPR-2010BR readers.

4.1 PARTS LIST

Verify that all items listed below are present before starting the installation.

- | | |
|---|-------|
| a. Sentinel-Sense MPR-2010BR | Qty=1 |
| b. Documentation and Demo Program CD | Qty=1 |
| c. Power supply – PS9-2A-SW, 50-60 Hz and 110 to 220 VA | Qty=1 |
| d. LRMB – Reader mounting bracket (Optional) | |

4.2 PREPARATION FOR INSTALLATION

Familiarize yourself with the connectors and pin out assignment of each I/O connectors as shown in section 2.2.1.

4.2.1 Bench Top Verification

It is always a good idea to verify system operation before committing to a full-scale installation. The following are the necessary steps to test the reader's operation in a static environment.

- ☐ Connect MPR-2010BR to the RS-232 port of a PC
- ☐ Connect the power jack from the wall plug power supply to MPR-2010BR.
- ☐ Power up PC
- ☐ Install demo software on PC
- ☐ Activate demo software and verify performance of the reader.
- ☐ Select COM port 1 on top page then click "Connect". Follow with some commands.
- ☐ Place the RFID tags at the exact same locations as the final configuration
- ☐ Measure tag's read distance and confirm that read distance is correct.

4.2.2 Aiming of Antenna

Antenna Pattern for MPR-2010BR

MPR-2010BR comes with a circular polarized antenna to ensure reading tag with random orientation. Most circular polarized antenna has a horizontal to vertical differential of up to 3 dB, this will cause the antenna pattern to deviate from a true circle. AWID's antenna has a horizontal to vertical differential of typically less than 0.5 dB, making its pattern as near to a circle as possible.




Figure 3 - MPR 2010BR Antenna Pattern

- Antenna pattern measurements represent both horizontal and vertical polarized planes of the read area transmitted by the reader.
- In the drawing above, R = approximately 12 feet to 15 feet for MPR-2010BR with Alien free space tags.
- Antenna pattern can be affected by RFI and other environmental conditions.

4.2.3 Mounting Considerations

Antenna Mounting Bracket

Also available from AWID is an optional antenna-mounting bracket (part # LRMB) that provides antenna tilt adjustment and pan adjustment. Photo at right shows how the reader is mounted onto the LRMB.



4.3 INSTALLATION STEPS

- 1) Check to ensure that all connections are secure. Make sure all wires through the cable clamps are anchored properly. Avoid dangling wires that may become a safety hazard.
- 2) Mount the Reader using the two recessed threaded holes to fasten to reader on the desired mounting surface. Please note that the threaded inserts are closed-ended, the user must select screws with the exact length to ensure proper tightening of the mounting screws. In cases where the reader aiming is critical, please order antenna-mounting bracket (P/N LRMB) from AWID. This mounting bracket provides pan/tilt adjustment for the reader. Users can also drill holes through the plate as required.
- 3) Adjust the position or the angle of the reader so that the tags are detected and read at the desired distance from the reader.

5 SOFTWARE PROGRAMMING AND SYSTEM OPERATION NOTES

5.1 SYSTEM OPERATION

5.1.1 Running a Custom Software Application or the AWID Demo Program

If AWID Demo Program is not used, it is expected user will launch a Custom Software Application developed using the *MPR Serial Communication Protocol* to issue commands as defined by the protocol to reader.

5.1.2 Operating Modes

Typical operating modes for MPR-2010BR readers can be grouped into the following:

Search Mode

This mode is used when operator or user is not certain what family of tags is placed on the items to be tracked. Since most tags are deterministic in nature, reader must cycle through each and every protocol, issue a protocol specific inquiry, to hail and to wait for a response from tags of that specific protocol. Therefore, if there are many different protocols, for an untrained observer, the reader response will appear sluggish.

Mixed Mode

This mode assumes the user is aware of the types of protocol in use, and furthermore, the user made a determined effort to operate the reader in a mixed protocol mode. In this mode, the user can decide how many and which specific protocols to be selected. Once Mix Protocol Mode is selected, the reader will routinely cycle through each protocol, dwell long enough for the reader to wait for a response and then move on to the next protocol. It should be noted that in a mixed protocol mode, the tag must have sufficient time to respond to the reader, and therefore, it can only be used on a conveyor belt arrangement, with specific speed restrictions.

Single Protocol Mode

Single protocol is the normal mode of operation, where the protocol type is known and many tags are expected to pass through the readers.

5.2 USERS NOTE**For System Integrators and/or Software Developers**

System Integrators and/or Software developers should get familiar with the MPR Serial Communication Protocol specifications for developing applications that control MPR-2010BR readers.

For Custom System Users

For custom system user, please refer to your host software user guide for information regarding system and software operations

For Demo Software Users

If you are using the AWID demonstration software application which is .NET based with easy-to-follow GUI operations, simply select the COM port for which the reader is configured then click *Connect* should get you started.

6 MPR SERIAL COMMUNICATION PROTOCOL

See *MPR Serial Communication Protocol* – Doc# 041300