



Spectra Engineering Pty Ltd
ABN 65 057 696 438

9 Trade Road
Malaga
Western Australia 6090

Tel: +61-8-92482755 Fax: +61-8-92482756

email: info@spectraeng.com.au

web: www.spectraeng.com.au

Manual Revision 4.0 May 2000

In order to continually improve our products, Spectra Engineering Pty Ltd reserves the right to alter, without notice and at any time, the equipment and specifications described in this document.

All performance figures quoted are typical and are subject to normal manufacturing and service tolerances.

The purchaser is warned that statements made in this document may be inaccurate due to typographical or other errors or subsequent modifications of the product. While every care has been taken in the creation of this document, no warranty of accuracy or reliability is given in any advice or information contained in this document. The responsibility for any loss or damage whatsoever arising in any way or any representation, act or omission whether express or implied (including responsibility to any person by reason of negligence) is not accepted by Spectra Engineering Pty Ltd or any director, officer, agent or employee of Spectra Engineering Pty Ltd.

Copyright © Spectra Engineering Pty Ltd 1997-2000.

This work is copyright. Other than as permitted by Law, no part of it may be reproduced, stored in a retrieval system or transmitted in any form or by any process without prior written permission.

FCC Interference Warning

Note: The equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial or residential environment. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with this instruction manual, may cause harmful interference to radio communication.

Record Of Changes

Any changes to this manual are recorded on this list. Replacement pages may be issued to you by Spectra Engineering from time to time. If any updates are issued, you will also receive a replacement for this page.

Date	Version	Chapter Changes	Pages Changed
May 1997	1.0	All - Initial Release	All
July 1997	1.1	MX800 Software	Software Only
Aug. 1997	1.2	DIP switch settings	Appendix C
		MX800 Configuration guide	Appendix D
Jan. 1998	1.3	Additional features added	
April 1998	2.0	General Revision	All
May 1998	2.01	Minor corrections	i,ii,iii,10,15
May 1998	2.02	Master doc	All
Oct 1998	2.03	Minor Corrections	i,ii,9,27,29,30,35
April 1999	3.0	Local control features added	All
Dec. 1999	3.1	Options chapter added	All
June 2000	4.0	Document reformatted	All
Aug 2000	4.01	MX800 Configuration Guide	70

SAFETY SUMMARY

Although there are no dangerous mains voltages present within the equipment, the following general safety precautions as would normally apply, should be observed during all phases of operation, service and repair of this equipment.

AROUND THE EQUIPMENT

To minimize any possible shock hazard from an external power supply or lightning strike, the chassis or equipment cabinet must be connected to an electrical ground. Provide adequate ventilation around the rear of the equipment.

DO NOT OPERATE IN AN EXPLOSIVE ATMOSPHERE

Do not operate the equipment in the presence of flammable gases or fumes. Operation of any electrical equipment in such an environment constitutes a definite safety hazard.

DO NOT ATTEMPT INTERNAL SERVICE WHILE TRANSMITTING

Thermal or RF burns may result from touching certain components within the power amplifier module while transmitting or operating the transmitter.

DO NOT SUBSTITUTE PARTS OR MODIFY THE EQUIPMENT

Because of the danger of introducing additional hazards, do not install substitute or lower voltage parts to the equipment. Return to your authorized distributor.

EXERCISE CAUTION AND CORRECT DISPOSAL OF RF POWER DEVICES

Most RF power transistors and some RF power hybrids contain Beryllium Oxide. Although they are normally safe, if physically damaged toxic dust may be released. Consult your local authority for correct disposal thereof.

WARRANTY CONDITIONS & PRECAUTIONS

The following conditions are not covered by the warranty of the MX800. Please ensure that the MX800 is not subject to;

1. Over voltage or Reverse Power Supply Voltage.
2. Operation in locations subject to abnormal environmental conditions such as extreme temperatures or ingress of moisture.
3. Operation of the MX800 Transmitter output into an open or short circuit or an incorrectly terminated load.

Table of Contents

1.	General Description.....	1
1.1	Physical Description	3
1.1.1	Front Panel.....	3
1.1.2	Rear Panel.....	6
1.1.3	Side Panel.....	7
1.2	Module Functional Description	7
1.2.1	Exciter Module	7
1.2.2	Receiver Module.....	8
1.2.3	Power Amplifier Module	8
1.2.4	Micro Controller Board.....	8
2.	Installation and Operation.....	11
2.1	Installation	11
2.2	Operation	11
2.2.1	MXTOOLS Utility.....	12
2.2.2	Setting to Work	13
2.2.3	Adjustments.....	18
3.	Options.....	19
3.1	T01 Programmable Channel Spacing	19
3.2	T02 Programmable CTCSS encoder/decoder.....	19
3.3	T03 Programmable DCS/CTCSS encoder/decoder.....	19
3.4	T04 Balanced and Isolated VF	20
3.5	T05 Balanced and Isolated VF plus E&M.....	21
3.6	T06 Simplex Changeover Relay	22
3.7	T07 Turn Around Mixer	22
3.8	T08 VF Delay	22
3.9	T09 CTCSS Suppression Upgrade Filter.....	23
3.10	T10 Low Standby Current Mode	24
3.11	T11 Combined Options.....	25
3.12	T12 External Reference Oscillator Input	25
3.13	T13 Local Speaker and Mic.....	26
3.14	T14 Local Channel Change	27
3.15	T15 RF and Line FFSK Modems	27
3.16	T16 1PPM Frequency Stability 12.5 kHz, N to X Bands	27
3.17	T17 1PPM Frequency Stability 25 kHz, R to X Bands	27
3.18	T18 Extended Temperature Range	27
4.	Technical Description.....	29
4.1	Exciter Module	29

4.2	Receiver Module.....	30
4.3	Power Amplifier Module.....	32
4.4	Micro Controller Board	32
4.4.1	Overall Radio Management.....	33
4.4.2	TX Signal Processing.....	34
4.4.3	RX Signal Processing	35
4.4.4	RF Power Control.....	35
4.4.5	User Interface.....	36
5.	Alignment and Testing	37
5.1	Transceiver Setup, Calibration and Alignment.....	37
5.1.1	Sending Model Number and Serial Number to the Radio.....	37
5.1.2	Sending Configuration Information.....	38
5.1.3	Sending Channel Information.....	38
5.1.4	Setting Alignment Channel	38
5.1.5	Power Calibration	39
5.1.6	RSSI Calibration.....	39
5.1.7	Temperature Calibration.....	39
5.1.8	TX Power Setup.....	39
5.1.9	Peak Deviation and Modulation Balance Alignment....	40
5.1.10	TX Centre Frequency Alignment	42
5.1.11	TX Line Input Level and Nominal Deviation Alignment.....	42
5.1.12	RX Line Output Level Adjustment.....	44
5.1.13	TX VF Loop Back Level.....	44
5.1.14	Mute Threshold Setting.....	44
5.2	Module Level Test Procedures	45
5.2.1	Exciter Module	45
5.2.2	Receiver Module	46
5.2.3	Power Amplifier Module.....	48
5.2.4	VCO Board	49
5.2.5	Microcontroller Module	50
6.	MX800 Base Station Fault Finding Procedure	51
6.1	MX800 Base Station.....	51
6.1.1	Transmitter Section.....	51
6.1.2	Receiver Section.....	52
6.2	Microcontroller PCB	52
6.3	Receiver Module.....	52
6.3.1	VCO Locking	52
6.3.2	RX Front End.....	53
6.3.3	IF Section.....	53
6.4	Exciter Module	53

6.4.1	VCO Locking	53
6.4.2	RF Power.....	54
6.5	Power Amplifier	54
7.	Appendices.....	55
7.1	MX800 Interface Connections.....	55
7.1.1	CN1 DB15 Female Line I/O Connector	56
7.1.2	CN2 DB9 Female Monitor Connector.....	58
7.1.3	CN3 DB25 Female Digital I/O Connector	59
7.1.4	CN4 DB9 Male RS232 Connector	60
7.1.5	CN6 Simplex Relay/External Reference	60
7.1.6	CN7 RX Input.....	60
7.1.7	CN8 TX Output	60
7.1.8	CN9 RJ45.....	60
7.1.9	CN5 DC Power Input	61
7.2	MX800 Specifications	62
7.2.1	Operating Frequency Bands.....	62
7.2.2	General.....	63
7.2.3	Transmit.....	64
7.2.4	Receive.....	65
7.2.5	Ancillaries.....	66
7.3	Channel Select DIP Switch Settings.....	66
7.4	MX800 Model Number Configuration Guide	70
8.	Drawings.....	71