

INDEX

GENERAL FEATURES	1
UNPACKING	2
GETTING READY	2
DESCRIPTION	2
OPERATION	3
FUNCTION MODE	4
RECHARGING THE BATTERY	5
SPECIFICATIONS	5

GENERAL FEATURES

General Features

- Ultra compact design & size
115x53x28mm, 138g only
- 38 CTCSS
- Button Lock
- Scan & Priority Scan
- Beep on/off
- Talking range to 4 miles
- Transferable by cloning
- Clear voice transmission and reception
- Rugged construction

Red on	Transmitting, charging
Blinking	Low battery alert
Green on	Receiving, recharging finished
Blinking	Different sub-tone when

	receiving
Red, green both on	Abnormal charging

• **up/down button**

You can select the audio volume (0~15), the channel and the function mode on or off with this button.

• **function button**

Press to go function mode (refer to next page).

• **monitor button**

Press to monitor. Holding down over 2 seconds keeps monitoring on. Press monitor button again to stop.

• **enter button**

Press to finalize setting.

• **PTT(push to talk) button**

Hold down to transmit, release to receive.

• **LCD display panel**

• **speaker**

• **microphone**

Talk 5• in distance during transmitting.

• **antenna**

• **external audio/microphone and adapter socket**

• **belt clip release tab**

• **battery pack cover**

• **cover lock screw**

• **belt clip**

• **hand strap**

OPERATION

1. Power turn on/off and volume control

Press power on/off button• 0.5 second to turn power on, press 0.5 second again to power off. Press up/down button• to increase or reduce the audio volume (00 ~ 15). Holding down up/down button• makes to move fast.

2. Transmit

Choose the channel as you desire. Hold down the PTT button• and talk to microphone• in 5• distance. The LED•(power button) lights red on transmitting. Release the PTT button to stop transmitting.

3. Receive

Choose the channel as you desire. The LED• lights green on receiving. In case the signal doesn't match sub-tone, the green light blinks.

4. Monitor

Press the monitor button• to monitor. Holding down monitor button over 2 seconds keeps monitoring function on. Press the monitor button shortly again to stop.

FUNCTION MODE

1. Channel select

If you press the function button• once, the channel number in LCD blinks. Then, select the channel wanted by pressing

up/down button•. Press the enter button• to finalize or press the function button• to go on next mode



2. Sub-tone select

During the sub-tone number blinking, select the sub-tone wanted by pressing up/down button•. It has from 01 ~ to 38.



3. Scan

During the scan sign blinking, press the up button• to upward scan or press the down button• to downward scan. The transceiver stops scanning after detecting a signal and remains on the same channel until the signal drops out for 2 seconds. Press the up/down button• to go on scanning even if it remains on the same channel for receiving. Press the PTT button• to stop.



4. Priority scan

During number blinks. Then press the up/down button• to priority scan sign blinking, press the up/down button• to choose on or off. When you choose `on`, the channel select the channel wanted.



This function scans selected channel when the radio is standing by on the other channel.

5. Button lock

During button lock sign blinking, press the up/down button• to choose on or off. This function prevents from changing the channel by unintended pressing of the up/down button

(only PTT button and power button work).

6. Beep tone

During beep tone sign blinking, press the up/down button• to choose on or off.



7. Power save

During power save sign blinking, press the up/down button• to choose `00`, `01`, `02`. 00: no power saving, 01: normal power saving, 02: strong power saving.



8. Squelch level

During squelch level sign blinking, press the up/down button• to select squelch level (00 ~ 15). Select the lower number for easy opening, select the higher number for hard opening as circumstance condition (it set 08 in producing)



RECHARGING THE BATTERY

1. Battery (Ni-MH)

Voltage		DC 7.5V
Duty time (5-5-90)	HM-650	Over 8 hrs

2. Charger

Input power		Free voltage (AC90~250V)
Charging time	HM-650	Appr. 1.5 hrs
Operating temperature		0°C~55°C

Connect the charger to electric power supply (free voltage AC 90~250 V). Turn the transceiver off and put into front pod of the charger. The red light turns on during rapid charging and the green light turns on during trickle charging. When you put two batteries at same time, the rapid charging charges first then the trickle charging starts.

LED

Red	On	Charging
Green	On	Fully charged

Low battery alert

LCD shows battery condition (••••).

The indicate LED•(power button) will blink red, if the battery falls below a low voltage level, LCD shows "oFF".

SPECIFICATIONS

		ARH-222	ARH-444	ARH-465	ARH-446
Dimension (HxWxD)		115x53x28mm (650 mAH Battery)			
Weight (With Battery)		138g (215g)			
Operating Voltage		DC 7.5V			
Operating Temp.		-20 ~ 60•			

Battery Life (5:5:90) 650mAH Battery		8 hrs			10hrs
Channels		22	16	16	8
Privacy Codes		38 CTCSS			
Band Width		25KHz	12.5KHz	25KHz	12.5KHz
Frequency Range	Tx	222MHz	444MHz	462.5625 ~467.725 MHz	446.0~44 6.1MHz
	Rx	222MHz	444MHz	462.5625 ~462.725 MHz	446.0~44 6.1MHz
FM Hum & Noise	Tx	-40 dB			
	Rx	-40 dB			
Rx Sensitivity		-119 dBm (0.25uV)			
Rx Spurious Response		-60 dB			
Rx Selectivity		-60 dB			
Rx Intermodulation		-60 dB			
Tx Power		2W			0.5W
Tx Spurious Rejection		-60 dBc			
Frequency stability		±5 ppm			

Accessories

Desk Rapid / Trickle Charger (SMPS)	ACR-650/1.5 hrs
650 mAH Ni-MH Battery	HM-650
APE-10	Earpiece with PTT MIC

USER'S MANUAL

ARH Series

ARH-446 (PMR446)
ARH-465 (GMRS)
ARH-444 (Semi LMR)
ARH-222 (Semi LMR)
ARH-448 (FRS)

Airtech Information & Communication Co., Ltd.
#101-807 Techno Park Complex, 364, Samjung-Dong, Ojung-
Gu, Puchon, Korea Zip: 421-150
Tel: 82 32 234 2345 / Fax: 82 32 234 2350
URL: <http://www.airtech21.com>
E-mail: sales@airtech21.com