


Instruction Manual for the use and the maintenance of the Radio Remote Control

Original instructions



Part C: SIDEKICK SK4 Transmitting Unit

AIR SERIES



WARNING

THIS PART OF THE MANUAL CONSISTS OF: Part C - Information, instructions and warnings for the SIDEKICK SK4 Transmitting Unit. The Manual consists of Part A – General, Part B – Conformity and Frequencies, Part C – Transmitting Unit, Part D – Receiving Unit, Part E – Battery and Battery Charger, plus the Technical Data Sheet.

THIS MANUAL, INCLUDING ALL PARTS THEREOF, AND ALL INSTRUCTIONS CONTAINED HEREIN, MUST BE READ CAREFULLY AND UNDERSTOOD BEFORE INSTALLING, USING, MAINTAINING OR REPAIRING THE AUTEC RADIO REMOTE CONTROL.

FAILURE TO READ AND COMPLY WITH ALL APPLICABLE WARNINGS AND INSTRUCTIONS OR ANY ONE OF THE LIMITATIONS NOTED IN THIS MANUAL CAN RESULT IN SERIOUS BODILY INJURY OR DEATH, AND/OR PROPERTY DAMAGE.

THE AUTEC RADIO REMOTE CONTROL IS NOT A STANDALONE PRODUCT AND IS INTENDED ONLY AS A COMPONENT ON A MACHINE:

- **ON WHICH AND WHERE THE USE OF A RADIO REMOTE CONTROL IS APPROPRIATE,**
- **THAT CAN BE OPERATED SAFELY AND IN ACCORDANCE WITH ALL APPLICABLE LAWS, REGULATIONS AND STANDARDS BY SUCH REMOTE CONTROL.**

ACCORDINGLY, IT IS THE RESPONSIBILITY OF THE MACHINE MANUFACTURER ON WHICH THE AUTEC REMOTE CONTROL IS INTENDED TO BE INSTALLED, to perform an in-depth and accurate risk assessment to determine if the Autec Radio Remote Control is suitable for operating a Machine in conditions of safety and operational effectiveness, taking into account the conditions of use, the intended uses and the reasonably foreseeable incorrect ones, so that the installation, maintenance and use of the Autec Radio Remote Control, and all its components, are performed only and entirely in compliance with this Manual and in accordance with all local regulations, safety standards and regulations (referred to herein as "Laws, Regulations and Standards").

With reference to the USA market the Laws, Regulations and Standards include all safety rules and regulations of the Occupational Safety & Health Administration (OSHA) (<http://www.osha.gov>), all federal, state and local laws, regulations and building and electrical codes, and all applicable standards, including but not limited to ANSI Standards.

It is also the responsibility of the Manufacturer and of the design professionals of the Machine on which the Autec Radio Remote Control is to be installed and used to be certain that the structure, condition, organization and markings of the Machine as installed at the facility is appropriate for and will allow for the safe and reliable use and control of the Machine through the Autec Radio Remote Control interface.

IT IS THE RESPONSIBILITY OF THE OWNER AND FACILITY OPERATOR, AND THEIR DESIGN PROFESSIONALS, that the installation, maintenance and operation of the Autec Radio Remote Control and all of its components are done solely and completely in accordance with this Manual, and with all applicable Laws, Regulations and Standards, even local. It is also the responsibility of the Manufacturer of the Machine on which the Autec Radio Remote Control is to be installed and used, and their design professionals, to be certain that the structure, condition, organization and markings of the Machine as installed at the facility is appropriate for and will allow for the safe and reliable use and control of the Machine through the Autec Radio Remote Control interface.

ONLY QUALIFIED AND PROPERLY TRAINED PERSONNEL SHOULD BE PERMITTED TO OPERATE OR USE THE AUTEC RADIO REMOTE CONTROL AND THE MACHINE OPERATED BY OR THROUGH THE AUTEC RADIO REMOTE CONTROL. ONLY QUALIFIED AND PROPERLY TRAINED PERSONNEL SHOULD BE PERMITTED TO BE IN THE VICINITY OF MACHINE OPERATED BY OR THROUGH THE AUTEC RADIO REMOTE CONTROL.

FAILURE TO PROPERLY INSTALL, OPERATE, MAINTAIN AND SERVICE THE AUTEC RADIO REMOTE CONTROL CAN RESULT IN SERIOUS BODILY INJURY OR DEATH AND/OR PROPERTY DAMAGE. Refer to this Manual and each of its Parts for further assistance or contact Autec. Autec is not responsible for and shall not be held liable for any installation of the Autec Radio Remote Control not performed by Autec or for any use of the Autec Radio Remote Control not in complete compliance with, and/or not maintained in complete compliance with, all Autec instructions and warnings and all applicable Laws, Regulations and Standards, even local.

Autec is not responsible for and shall not be held liable for any alteration or modification of the Autec Radio Remote Control, or the use of non-Autec components or products used with or incorporated into the Autec Radio Remote Control.

IT IS THE RESPONSIBILITY OF THE OWNER AND FACILITY OPERATOR, AND THEIR DESIGN PROFESSIONALS, to be certain that the Autec Radio Remote Control is properly maintained and serviced at all times in compliance with all Autec instructions and warnings, and with all applicable Laws, Regulations and Standards, even local.

IT IS THE RESPONSIBILITY OF THE OWNER AND FACILITY OPERATOR, AND THEIR OFFICERS, MANAGERS AND SUPERVISORS, to be certain that all Users of the Autec Radio Remote Control and that all Persons who are or will be working with or near the Machine operated by or through the Autec Radio Remote Control are fully and properly educated and trained by qualified Personnel in the proper and safe use of the Autec Radio Remote Control and of the Machine, including without limitation complete familiarity with and understanding of Autec warnings and instructions, and all applicable Laws, Regulations and Standards, even local, and that such Users and other Persons do in fact at all times operate or work with the Autec Radio Remote Control safely and ONLY in compliance with Autec instructions and warnings and with all applicable Laws, Regulations and Standards, even local. FAILURE TO DO SO CAN RESULT IN SERIOUS BODILY INJURY OR DEATH AND/OR PROPERTY DAMAGE.

IT IS THE RESPONSIBILITY OF THE OWNER AND FACILITY OPERATOR, AND THEIR OFFICERS, MANAGERS AND SUPERVISORS, to be certain that the areas in which the Machine operated by or through the Autec Radio Remote Control is located and operates are clearly delineated and marked in accordance with all Autec warnings and instructions, and all applicable Laws, Regulations and Standards, even local, and otherwise sufficient to alert and warn ALL PERSONS that the Machine is operated by or through a Radio Remote Control, and prohibiting any unauthorized access thereto. FAILURE TO DO SO CAN RESULT IN SERIOUS BODILY INJURY OR DEATH AND/OR PROPERTY DAMAGE.

FAILURE TO OPERATE THE AUTEC RADIO REMOTE CONTROL SAFELY AND IN COMPLIANCE WITH AUTEC INSTRUCTIONS AND WARNINGS AND WITH APPLICABLE LAWS, REGULATIONS AND STANDARDS, EVEN LOCAL, AND/OR PERMITTING USERS OR OTHER PERSONS NOT PROPERLY TRAINED IN THE SAFE AND PROPER USE OF THE SYSTEM, OR THE MACHINE ON WHICH IT IS INSTALLED, CAN RESULT IN SERIOUS BODILY INJURY OR DEATH AND/OR PROPERTY DAMAGE.

INDEX

1	Information on the use of instructions	7
1.1	Structure of the Instruction Manual	7
1.2	Caption and terminology	9
1.3	Symbols	9
1.4	To whom the instructions are addressed	10
1.5	Instruction storage	10
1.6	Intellectual property	10
2	Brief product presentation	11
2.1	Series, Radio Remote Control and Unit	11
2.2	Conformity with standards	11
2.3	Contacts and useful addresses	11
2.4	Warranty	11
2.5	Technical assistance and spare parts	11
3	Description of the Transmitting Unit	12
4	Technical data	13
5	Technical Data Sheet	13
6	Plates	14
6.1	Plates on the SK4 Transmitting Unit in a Radio Remote Control	14
6.2	Plates on the SK4 Transmitting Unit in a "Take & Release" Radio Remote Control	14
6.3	Plates on the SK4 Transmitting Unit in a "Multi Units" or "Multi Receiver" Radio Remote Control	15
7	Light signals	16
7.1	Red LED [A] and green LED [B]	16
7.2	Green CHARGE LED [D] and red CHARGE LED [E]	18
8	General operating instructions	19
8.1	START pushbutton/selector	19
8.2	STOP pushbutton	19
8.3	Recharging the SK4 Transmitting Unit's battery	19
8.4	ID internal tx memory	20
8.5	Starting up the Radio Remote Control	21
8.6	Command activation	22
8.7	G-Sense function	22
8.8	Using the Transmitting Unit while recharging	24
8.9	Radio link interruption	25
8.10	Transmitting Unit automatic switch off	25
8.11	Switching off the Transmitting Unit	26
8.12	"Data Feedback" function	26
8.13	BACK-UP UNIT	27
9	Instructions for the User	28
9.1	Usage restrictions	28
9.2	User behaviour	28
9.3	Belt or harness	29
10	Maintenance	32
11	Malfunction signalled by the Transmitting Unit	32
12	Decommissioning and disposal	34

1 Information on the use of instructions



Before reading this part of the Manual, you must read and understand the general part (Part A) of the Manual provided with the Radio Remote Control.

1.1 Structure of the Instruction Manual

The Manual for the use and maintenance of Autec Air series Radio Remote Controls consists of different parts, that altogether form the Manual; the Manual must be read carefully, understood and applied by the Radio Remote Control's Owner, User and by all those Persons that, for any reasons, may operate with the Radio Remote Control or with the Machine where it is installed. The following table describes the structure of the Instruction Manual for the use and the maintenance of the Radio Remote Control.

Part	Title	Contents
A	General part	- General information regarding the series, - directions for risk assessment of the "Machine+Radio Remote Control" system, - warnings for installation of the Radio Remote Control, - warnings for use and maintenance of the Radio Remote Control, - instructions for correct transportation and storage of Radio Remote Control.
B	Conformity and frequencies	- Operating frequency bands of the Radio Remote Control, - conformity and law references of the Radio Remote Control.
C	Transmitting Unit	Description and instructions concerning the Transmitting Unit, including: - description of operation, - commands, - light signals, - malfunctions, - additional instructions to the general part.
D	Receiving Unit	Description and instructions concerning the Receiving Unit, including: - description of operation, - light signals, - malfunctions, - additional instructions to the general part.
E	Battery and Battery Charger	Description, warnings and instructions concerning batteries and Battery Chargers, including: - description of operation, - light signals, - malfunctions, - instructions for the User.

Usage and maintenance instructions are supplemented by the Radio Remote Control's Technical Data Sheet, that:

- describes the Transmitting Unit's configuration,
- indicates the relation between commands sent by the Transmitting Unit and those available on the Receiving Unit.

Usage and maintenance instruction as a whole are to be considered as an integral part both of the Autec Radio Remote Control and of the Machine, system, device or Machinery system where the Radio Remote Control is installed.


The Manufacturer of the Machine on which the Autec Radio Remote Control is installed, and the Owner and User of the Machine, must make sure that the Instruction Manual and all of its parts are included in the Instruction Manual of the Machine.



The CD attached to each Instruction Manual includes the translations of the Manual.

Act as follows to identify the single Manual parts in the relevant language in the CD:

- identify the correct section depending on the Radio Remote Control serial number,
- choose the desired language,
- select the single parts of the Manual: refer to the code name provided on the cover of each part.



1.2 Caption and terminology



Contact Autec if any of the instructions, symbols, warnings or images are not clear and understandable, or if you have doubts or questions.

In this part of the Manual, the terms listed below have the same meaning explained in the corresponding paragraph of the general part (Part A):

- **Unit**
- **Radio Remote Control**
- **Transmitting Unit**
- **Receiving Unit**
- **Machine**
- **Manufacturer**
- **Installer**
- **User**
- **Maintenance Technician**
- **Manual or Instruction Manual**
- **Installation Manual**
- **Person**
- **Owner**

Functions indicated for the Manufacturer, the Installer, the User and the Maintenance Technician may be performed by a single Person, if he/she has the needed competence and undertakes the resulting responsibilities. Each Person must be aware of the instructions contained in the Manual, depending on the activity they carry out.

For example, if a Manufacturer is also the Installer, and/or Maintenance Technician, he must also know and follow the instructions specifically addressed to those Persons. The same applies, for example, if a User is also the Manufacturer and/or the Installer.

1.3 Symbols



This symbol identifies the parts of text in the Manual that must be read with special attention.



This symbol identifies the parts of text in the Manual containing warnings, information and/or instructions that are particularly relevant with regards to safety; failure in understanding them may cause hazards for People and/or property.

1.4 To whom the instructions are addressed

Addressees of instructions are listed in the paragraph with the same title in the general part: please refer to that part.

1.5 Instruction storage

Regulation for the storage of instructions are described in the paragraph with the same title in the general part: please refer to that part.

1.6 Intellectual property

Restrictions connected to intellectual property are described in the paragraph with the same title in the general part: please refer to that part.

2 Brief product presentation

2.1 Series, Radio Remote Control and Unit

The object of this part of the Manual is the SIDEKICK SK4 Transmitting Unit of an Autec Air series' Radio Remote Control.

Autec Air series' Radio Remote Controls are designed to be used on Machines and provide a command interface to their command and control system, to be used from an appropriate distance and position.

2.2 Conformity with standards

The conformity of Radio Remote Controls with standards and with working requirements and conditions in the single Countries is provided in the related specific part "Conformity and frequencies" (Part B) of the Manual.

2.3 Contacts and useful addresses

The Radio Remote Controls are produced by Autec srl – Via Pomaroli, 65 – 36030 Caldogno (VI) – ITALY.

You can find contacts for Autec, its distributors, dealers and authorized service centres on the website www.autecsafety.com.

2.4 Warranty



General warranty conditions are indicated both in the relevant sheet provided together with this documentation, and in the specific page on the website www.autecsafety.com.

2.5 Technical assistance and spare parts

If you need technical services and/or spare parts, please refer to contacts provided in the website www.autecsafety.com.

When applying for technical service to Autec, its distributors, dealers and authorized service centres, the Radio Remote Control's serial number is required; you can find it on the identification plate on the Transmitting Unit and/or on the Receiving Unit.

3 Description of the Transmitting Unit



A	LEDs
B	CHARGE LED
C	Actuators (selectors or pushbuttons)
D	START actuator
E	Connector for the Unit's recharge
F	STOP pushbutton
G	Technical data plate
H	Transmitting Unit identification plate
J	Radio Remote Control identification plate
K	DIP switches
L	Connector for "ID internal tx memory"

4 Technical data

Power supply (battery AIRBM3V7L)	3.7V---
Antenna	internal
Housing material	PA 6 (20%fg)
Protection degree	IP65 (NEMA 4)
Dimensions	138x60x118mm (5.43x2.36x4.65In)
Weight	450g (0.992Lb)
Run time at 20°C (68°F)	>16h

5 Technical Data Sheet

The Radio Remote Control 's Technical Data Sheet:

- describes the Transmitting Unit's configuration,
- indicates the relation between commands sent by the Transmitting Unit and those available on the Receiving Unit.

The Technical Data Sheet must be filled in, checked and signed by the Installer, who is responsible for correct wiring.

A Technical Data Sheet must always be kept together with this Manual: if you need to use the Technical Data Sheet for administrative purposes (tests, check, etc.), make a copy of it.

 WARNING	The wiring of the Receiving Unit's outputs must always reflect the wiring indicated in the Technical Data Sheet.
--	--

6 Plates

The following instructions refer to the plates on different types of Radio Remote Controls where the SK4 Transmitting Unit may be used.

6.1 Plates on the SK4 Transmitting Unit in a Radio Remote Control

Plate	Position	Content
Radio Remote Control identification plate	Behind the belt on the back side of the Transmitting Unit	Radio Remote Control serial number (S/N)
Transmitting Unit identification plate	Behind the belt on the back side of the Transmitting Unit	Manufacturing year, bar code and Transmitting Unit identification number (TU ID)
Technical data plate	Back side of the Transmitting Unit	MODEL, TYPE and main Transmitting Unit technical data, marking and possible Radio Remote Control marks


6.2 Plates on the SK4 Transmitting Unit in a "Take & Release" Radio Remote Control

Plate	Position	Content
Radio Remote Control identification plate	Behind the belt on the back side of the Transmitting Unit	Radio Remote Control serial number (S/N)
Transmitting Unit identification plate	Behind the belt on the back side of the Transmitting Unit	Manufacturing year, bar code and Transmitting Unit identification number (TU ID)
Technical data plate	Back side of the Transmitting Unit	MODEL, TYPE and main Transmitting Unit technical data, marking and possible Radio Remote Control marks

6.3 Plates on the SK4 Transmitting Unit in a "Multi Units" or "Multi Receiver" Radio Remote Control

Plate	Position	Content
Radio Remote Control identification plate	Behind the belt on the back side of the Transmitting Unit	Radio Remote Control serial number (MULTI S/N)
Transmitting Unit identification plate	Behind the belt on the back side of the Transmitting Unit	Manufacturing year, bar code and Transmitting Unit identification number (TU ID)
Technical data plate	Back side of the Transmitting Unit	MODEL, TYPE and main Transmitting Unit technical data, marking and possible Radio Remote Control marks

7 Light signals



The SK4 Transmitting Unit always has a green LED [B] and a red LED [A] that provide information regarding the Radio Remote Control.

Symbol	Meaning
	This symbol identifies the red LED [A].
	This symbol identifies the green LED [B].



The meaning of signals provided by the LEDs identified with "C" are explained in the "Data Feedback" function part (see paragraph 8.12). The meaning of LEDs related to the "Data Feedback" function are decided and established by the Machine Manufacturer depending on the Machine's functions for which he wants to receive information.

The SK4 Transmitting Unit always has a green CHARGE LED [D] and a red CHARGE LED [E] that provide information during the Unit's recharge process.

7.1 Red LED [A] and green LED [B]

The meaning of red LED [A] and green LED [B] signals is described in the following tables; possible actions to carry out are given in chapter 11.



The meaning of the red and green LED signals cannot be modified.

Signal	Meaning
The green LED [B] is off.	The Transmitting Unit is off.
The green LED [B] is lit with a steady light.	The Transmitting and Receiving Unit do not communicate.
The green LED [B] repeats the sequence: two blinks and a pause.	The working range of the remote control has been exceeded for more than 20 seconds.
The green LED [B] repeats the sequence: three blinks and a pause.	The Receiving Unit does not communicate with the transmitting Unit. If the Transmitting Unit communicates with the Receiving Unit, it is possible to send commands.
The green LED [B] blinks fast.	The Transmitting and Receiving Unit communicate. It is only possible to send commands after activating the START actuator.
The green LED [B] blinks slowly (one blink per second).	It is possible to send commands.

Signal	Meaning
The red LED [A] is off.	The Transmitting Unit works correctly.
The red LED [A] is steady on during start up.	The STOP pushbutton is pressed or damaged.
The red LED [A] blinks twice per second during start up.	At least one of the commands that were checked at start-up is enabled or damaged (see Technical Data Sheet).
The red LED [A] blinks three times per second during start up.	The battery is flat.
The red LED [A] is steady on for two seconds during start up.	The Transmitting Unit does not work correctly.
The red LED [A] blinks slowly (one blink per second).	The battery has less than 2h run time.
The red LED [A] blinks fast.	The battery has a 10min run time.

Signal	Meaning
The green [B] and red [A] LEDs are steady on during start up.	A wrong "ID internal tx memory" has been inserted in the Transmitting Unit, or this is a "BACK-UP UNIT".
The green [B] and red [A] LEDs blink 3 times per second during start up.	"ID internal tx memory" is damaged.
The green LED [B] is lit with a steady light and the red LED [A] blinks two times per second during start up.	The START actuator is activated.
The green [B] and red [A] LEDs blink alternating.	30 s left before the Transmitting Unit automatically switches off.
The green LED [B] repeats the sequence: 3 blinks and a pause, and the red LED [A] is steady on during start up.	The UNPAIR procedure has been carried out.

7.2 Green CHARGE LED [D] and red CHARGE LED [E]

The meaning of green CHARGE LED [D] and red CHARGE LED [E] signals is described in the following table. They only illuminate when the Transmitting Unit is being recharged.

	The meaning of the red and green CHARGE LED signals cannot be modified.
---	---

Signal	Meaning
The green CHARGE LED [D] is steady on.	The Transmitting Unit is under charge and charging has been completed.
The red CHARGE LED [E] is steady on.	The Transmitting Unit is under charge and charging has not been completed yet.

8 General operating instructions

8.1 START pushbutton/selector

The START pushbutton/selector is used to:

- start the Radio Remote Control (see paragraph 8.5),
- activate the horn when the Radio Remote Control is started.

8.2 STOP pushbutton

When the STOP pushbutton is activated, the Machine stops and the Transmitting Unit switches off. To start the Radio Remote Control again and enable it to control the Machine after the STOP pushbutton has been pressed, you need to:

- make sure that the working and usage conditions are safe,
- pull or turn the STOP pushbutton in the arrow direction (shown on the button) to unlock it,
- start the Radio Remote Control following the procedure described in paragraph 8.5.



The STOP pushbutton should be pressed when it is necessary to stop the Machine immediately whenever a dangerous condition occurs.

The Machine Manufacturer and/or the Installer must provide the User with the instructions and warnings concerning possible risks that may originate from the Machine stop (by way of example: movement inertia, swinging load...).

8.3 Recharging the SK4 Transmitting Unit's battery

The SK4 Transmitting Unit contains a rechargeable battery (AIRBM3V7L); the provided battery is already partially charged.

To recharge the SK4 Unit you must only use the cable supplied by Autec: connect it to a power supply source providing the values given in the technical data that are indicated in "Part E" of the Manual.

To use the SK4 Unit and its battery correctly, "Part E" of the Manual shall be fully understood and kept into account; this part specifically refers to the recharging device and to the battery, and it contains instruction for their use, storage and maintenance.

8.5 Starting up the Radio Remote Control

Starting up the Radio Remote Control consists in establishing a radio link between the Transmitting Unit and the Receiving Unit.

 WARNING	The Radio Remote Control start up is protected by a PIN code to prevent unauthorised use of the Machine. To activate the Radio Remote Control, enter the PIN code following the procedure described in paragraph 8.5.1.
---	---

The PIN code is not a sequence of numbers, but it consists in the sequential activation of actuators.

	Commands associated to the actuators that are activated while inserting the PIN code are not sent to the Machine.
---	--

8.5.1 Start up through PIN code

When the Receiving Unit is correctly powered on, perform the following procedure; activate each actuator within 3 seconds after releasing the previous one:

1. enable START and keep it enabled until the green LED illuminates;
2. activate the commands corresponding to PIN code in the correct sequence (PIN 1, PIN 2 and PIN 3 given in the Technical Data Sheet).
 - a. PIN 1 shall not be included in the start up procedure if it corresponds with START.
 - b. PIN 3 shall not be included in the start up procedure if it corresponds with START.
3. enable START and keep it enabled until the green LED blinks fast,
4. release START.

When the green LED blinks slowly, the Radio Remote Control is active and it can send commands and activate the Machine.

Note: default PIN code set by AUTECH is:

- PIN 1=START.
- PIN 2=S0 (see Technical Data Sheet).
- PIN 3=START.

	Autec will set a customized PIN code only upon request by the Machine Manufacturer or the Installer.
---	---

8.5.2 Procedure to modify the PIN code

The Transmitting Unit activates only when the PIN code is entered.

The PIN code can be modified to limit the use of the Radio Remote Control.

To modify the PIN code, perform the following procedure with the Transmitting Unit switched off and the STOP pushbutton released.

1. Enable S0 and START and keep them enabled until the green LED blinks (1 blink per second).
2. Activate the commands of the PIN code sequence provided in the Technical Data Sheet.
3. Activate command S1 (see Technical Data Sheet) repeatedly until LED 2 illuminates.
4. Activate command S2 (see Technical Data Sheet) to confirm your selection (green LED blinks twice per second). You can choose the 3 pushbuttons you want to set as PIN code amongst all the pushbuttons on the Unit. If you want to start the Radio Remote Control with:
 - a single-command PIN code: enable START as PIN 1 and PIN 3;
 - two-command PIN code: enable START as PIN 1 or PIN 3.
5. Activate the command you want to allocate as PIN 1 (LED 1 and green LED are steady on).
6. Activate the command you want to allocate as PIN 2 (LED 2 and green LED are steady on).
7. Activate the command you want to allocate as PIN 3 (LED 3 and green LED are steady on). PIN code is saved automatically.

8.6 Command activation

When the Radio Remote Control is started, it is possible to activate movements, functions and commands on the Machine by acting on the related pushbuttons or switches, whose functions and symbols are decided by the Manufacturer and/or the Installer. To identify the relation between the actuators and the corresponding Machine movements, the Machine Manufacturer and/or the Installer shall provide relevant instructions and the User shall be properly trained.

8.7 G-Sense function



The Transmitting Unit is equipped with a G-Sense function only upon request of the Machine Manufacturer and/or of the Installer, who are responsible for deciding how the G-Sense function will activate.

The G-Sense function activates for the following reasons:

- **No movement:** the function activates when the Transmitting Unit remains static (acceleration lower than 0.5g) for more than 4 minutes.
- **Tilt:** the G-Sense function activates when the Transmitting Unit is tilted by at least 50° for at least 4 minutes.

Autec sets the G-Sense function so that when the sensor activates, one of the following situations occurs:

- the Transmitting Unit switches off,
- all the Radio Remote Control's commands are deactivated, except one particular Machine function, which is activated at the same time (e.g. horn).



The Machine Manufacturer and/or the Installer have the responsibility to decide the behaviour of the G-Sense function. Before using the Machine, the User must be aware of the expected behaviour and make sure that it works correctly.

8.8 Using the Transmitting Unit while recharging

The SK4 Unit may or may not be enabled to control the Machine while the Unit itself is being charged.

This activation depends on the "Charger Plug Enable" setting. Autec sets this function only upon request by the Installer and under his own responsibility.

Check the Technical Data Sheet to know if this setting is enabled.

8.8.1 "Charger Plug Enable" setting is enabled



When the "Charger Plug Enable" setting is enabled and the Radio Remote Control is started, the SK4 Unit can always send commands. In this case, the Stop function is always available.

If the SK4 Unit is used non-stop (Radio Remote Control always started and Unit always under charge), switch off the Transmitting Unit at least every 24 hours.



The Unit's recharge may not end (the green CHARGE LED may not illuminate) when all following conditions occur:

- the Transmitting Unit is being charged,
- the "Charger plug Enable" setting is active,
- the Radio Remote Control is started.

This is due to the permanent current absorption of the working Transmitting Unit.

8.8.2 "Charger Plug Enable" setting is not enabled

When the "Charger Plug Enable" setting is not enabled, it is not possible to start the Radio Remote Control while recharging the Unit. Therefore, the SK4 Unit cannot control the Machine and the Stop function is not available. In this case, when you need to recharge the battery, make sure that the Machine is in safety conditions, so that it cannot generate hazards.

8.9 Radio link interruption

When the radio link is incorrect or interrupted, the automatic stop function activates (see paragraph "Control devices" in the Instruction Manual's general part).

The green LED of the Transmitting Unit signals this interruption by switching from slow blinking to one of the following statuses (see chapter 11):

- fast blink;
- on with steady light;
- two blinks and a pause;
- three blinks and a pause.

8.10 Transmitting Unit automatic switch off

The Transmitting Unit automatically switches off when:

- the Unit is out of battery power (see paragraph 8.10.1),
- the Radio Remote Control is not used for a certain time (see paragraph 8.10.2).
- the Transmitting Unit crashes or is falling (see paragraph 8.10.3).

To start the Radio Remote Control, see paragraph 8.5.

8.10.1 Transmitting Unit out of battery power

If the Transmitting Unit is not sufficiently charged, it will show it:

- The red LED blinks slowly (one blink per second): the battery has less than 2 hour run time starting from the first signal.
- The red LED blinks fast: the battery has a 10 minute run time from the first signal, after which the Transmitting Unit automatically switches off.

Recharge the Transmitting Unit (see paragraph 8.3).

8.10.2 When the Transmitting Unit is not used

If the Transmitting Unit remains started with no enabled commands, it will automatically switch off after a predetermined time frame. This time frame is specified in the Technical Data Sheet (SWITCH-OFF).

Before the Transmitting Unit switches off automatically, the green and red LEDs blink alternating for 30 seconds.

Activating any actuator corresponding to a movement command reduces the predetermined automatic switch-off time (SWITCH-OFF) to zero.



Setting or removal of the automatic switch off time (SWITCH-OFF) is done by Autec and decided by the Machine Manufacturer or by the Installer, depending on the operation and functions they need on the Machine.

8.10.3 Crash or fall

The Transmitting Unit automatically switches off when it hits or impacts with something, with a movement of at least 30 centimetres and with an acceleration higher than 2g.

The Transmitting Unit automatically switches off when it falls from higher than 1 meter.

8.11 Switching off the Transmitting Unit

 WARNING	Switch off the Transmitting Unit when not actively using the Radio Remote Control to operate the Machine, or when work is otherwise interrupted, even for short periods. Do not leave the Machine in dangerous conditions (even when recharging the Unit). FAILURE TO DO SO CAN RESULT IN SERIOUS BODILY INJURY OR DEATH AND/OR PROPERTY DAMAGE.
--	--

An intentional switch off of SK4 Transmitting Unit occurs after pressing the STOP pushbutton.

8.12 "Data Feedback" function

The User receives information and/or signals concerning some particular situations and the movements of the controlled Machine by means of the "Data Feedback" function. The "Data Feedback" function works with LEDs: specific Machine conditions (e.g. load limits, limit switch) may be signalled by the illumination of the LEDs. The signalled conditions depend on the settings chosen by the Person who installed the Radio Remote Control on the Machine. Pay particular attention to LED indications during normal Radio Remote Control operation: they can be helpful to evaluate the Machine's working status.

 WARNING	Any information signalled by LEDs for the "Data Feedback" function can never be considered or used as a safety signal or for legal metrology. When operating and moving the Machine, remember that the Radio Remote Control does not intervene autonomously when potential hazardous situations are signalled.
--	--

	If the green LED repeats the sequence "three blinks and a pause", there is no information and/or signals coming from the "Data Feedback" function. In this case, bring the Transmitting Unit closer to the Receiving Unit until the green LED blinks slowly.
---	---

8.13 BACK-UP UNIT

If the Transmitting Unit cannot be used, it can be replaced with a Transmitting Unit called "BACK-UP UNIT"; you need to ask for it to Autec.

It is identical to the Unit that can no longer be used; the only difference is the presence of the plate "BACK-UP UNIT" on the Transmitting Unit.



Insert in the "BACK-UP UNIT" the "ID internal tx memory" of the Transmitting Unit that cannot be used any longer and perform the address storage procedure described below.



As required by standard IEC 60204-32, each Radio Remote Control is uniquely identified through a serial number. Therefore, upon replacement of the Unit, the serial number of the Transmitting Unit to be replaced must be marked on the "BACK-UP UNIT", so that all Units belonging to the Radio Remote Control will show the same serial number.

Autec cannot be held responsible if the serial number of the Transmitting Unit to be replaced has not been marked on the "BACK-UP UNIT".

Address storage

With fully charged battery and "ID internal tx memory" in the "BACK-UP UNIT", perform this procedure:

1. enable the START actuator and keep it enabled until the green and red LEDs illuminate;
2. wait until the green LED blinks slowly;
3. within 3 seconds, activate in sequence the pushbuttons corresponding to PIN 1, PIN 2 and PIN 3 that compose the PIN code given in the Technical Data Sheet.

If the PIN code is incorrect, the red LED illuminates and the Transmitting Unit switches off. In this case, the storage procedure shall be repeated.

If the PIN code is correct, the green LED turns steady on and the Transmitting Unit switches off: this indicates that the address has been stored in the "BACK-UP UNIT". It is now possible to start the Radio Remote Control and control the Machine with the "BACK-UP UNIT" Transmitting Unit.

9 Instructions for the User

The chapter "Instructions for the User" in "Part A" of the Instruction Manual contains the warnings for the use that add to those provided in this chapter. Therefore, please refer to that part of the Manual.

The following instructions refer to general usage situations for the SK4 Transmitting Unit, and indicate how user should or should not behave when using the Unit: these do not cover any possible risk situation and/or drawback that may depend on specific applications of Autec Radio Remote Controls.

However, instructions given in the following paragraphs do not replace nor complete the instructions that must be provided to the User by the Manufacturer of the Machine where an Autec Radio Remote Control (to which the SK4 Transmitting Unit belongs) is installed.

9.1 Usage restrictions

	If the Radio Remote Control User wears electronic devices (by way of example: pacemaker, implantable cardiac defibrillator, hearing aids), the Transmitting Unit must be kept at least 15 cm away from those devices when in use.
---	---

9.2 User behaviour


Besides the instructions contained in the General Part (Part A) of the Instruction Manual, when using the SK4 Transmitting Unit, the User must:

- observe and comply with all instructions and warnings provided by the Machine Manufacturer;
- observe and comply with all instructions and warnings provided by the Installer;
- observe and comply with all instructions and warnings provided by the Person responsible for the Machine commissioning or making the Machine available for work;
- observe and comply with all instructions and warnings provided in the Radio Remote Control Manual;
- observe and comply with all applicable Laws, Regulations and Standards, even local.
- follow and put into practice the working instructions he received, and/or those he must be aware of because of his work and his tasks;
- avoid using the Radio Remote Control if he has not been properly trained and prepared, and if he has not been qualified for its use by the Person responsible for the work;
- make sure that the Transmitting Unit and the Receiving Unit are whole and work perfectly;
- make sure that the Machine reacts correctly to the commands activated by the Autec Radio Remote Control;
- not perform any operation if the tests mentioned in the previous two points did not give positive results;


- make sure that the Radio Remote Control operation and the consequent Machine movement occur in safety conditions, to prevent hazards to people and/or property;
- adopt the necessary caution to avoid that the Machine operation causes dangerous situations of any type; to this end, the User's physical and health status shall be taken into account too;
- avoid leaving the Transmitting Unit unattended or in such a condition that it may be damaged, tampered with, operated by people who are not qualified or by the movement of people and/or objects (by way of example due to: fall, movement, contact);
- operate the Transmitting Unit by holding it correctly in his hands, so that he can activate the Machine movements correctly and in safe conditions and monitor its light signals;
- keep at a safe distance from any risk situations originating from the use of the Machine where the Autec Radio Remote Control is installed;
- avoid doing anything else while using the Radio Remote Control, such as, by way of example, operate other Machines and/or other devices, eat and/or drink, use communication devices (phone, radio phone, etc.), keyboards, computers, IT devices or AV equipment, or carry out any other action that may pose the User in the situation not to be able to correctly control the Transmitting Unit and/or the Machine;
- activate immediately, and anyway in safe conditions, the stop devices available on the Transmitting Unit and/or on the Machine, in case dangerous situations occur, even if they do not depend on the use of the Machine;
- use the Transmitting Unit in such a way as to avoid contact with objects and/or People, fall and loss of control.
- use the Transmitting Unit with supports such as belts, pouches and the like, which are provided with the Radio Remote Control.
- not modify or tamper with the Transmitting Unit, its components and/or its commands;
- not modify the indications and/or meaning and/or abbreviations and/or symbols and/or original stickers on the Transmitting Unit's panel.

9.3 Belt or harness






The SK4 Transmitting Unit always comes with a waist belt: the User must mount the belt on the Transmitting Unit and use it as explained in the figures below.



1




2

**3****4****5****6****7**



The User must wear the Radio Remote Control with the belt as shown in the photo below, to avoid its fall, loss, loss of control, accidental contact and improper use.



If the Transmitting Unit and the belt are used in a different way from the one described in the above mentioned figure, this constitutes improper use and may lead to damage to the Transmitting Unit, to the User, to people and/or property.



Replace the belt or harness if it is damaged or worn.

10 Maintenance

Instructions for correct Radio Remote Control maintenance are described in the chapter "Maintenance" included in "Part A" of the Instruction Manual. Therefore, please refer to that part of the Manual.

11 Malfunction signalled by the Transmitting Unit

The table below lists malfunctions that are signalled by LEDs on the Transmitting Unit while it is not being charged, and the solution to those malfunctions.

If the problem persists after attempting the suggested solution, contact the support service of the Machine Manufacturer.

Signals	Possible reason	Solutions
The green LED is lit with a steady light or it repeats the sequence: three blinks and a pause.	The Transmitting and Receiving Unit do not communicate.	Bring the Transmitting Unit closer to the Receiving Unit until the green LED blinks fast (if the signal doesn't change, check that the Receiving Unit is powered), then enable and disable the START actuator. When the START actuator is disabled, the green LED starts blinking slowly (it is possible to send commands).
The green LED repeats the sequence: two blinks and a pause.	The working range of the Radio Remote Control (see paragraph "Technical data" in the general part of the Instruction Manual) has been exceeded for more than 20 seconds.	Bring the Transmitting Unit close to the Receiving Unit, then enable and disable the START actuator. When the START actuator is disabled, the green LED starts blinking slowly (it is possible to send commands).
The green LED blinks fast.	Temporary loss of radio link.	Bring the actuators related to movement commands to the rest position, then enable and disable the START actuator. When the START actuator is disabled, the green LED starts blinking slowly (it is possible to send commands).
The green LED blinks slowly (one blink per second).	The Receiving Unit may not work correctly.	See "Malfunctions signalled by the Receiving Unit" in "Part D" of the Manual.

Signals	Possible reason	Solutions
The red LED is steady on during start up	The STOP pushbutton is pressed or damaged.	Unlock the STOP pushbutton.
The red LED blinks twice per second during start up.	At least one of the pushbuttons is pressed or damaged.	Bring the pushbuttons to the rest position.
The red LED blinks three times per second during start up.	The Unit is discharged.	Recharge the Unit.
The red LED is steady on for two seconds during start up.	The Transmitting Unit does not work correctly.	Contact the support service of the Machine Manufacturer.
The green and red LEDs are steady on during start up.	A wrong "ID internal tx memory" has been inserted in the Transmitting Unit.	Use the correct "ID internal tx memory".
	You're using a "BACK-UP UNIT" with the "ID internal tx memory" of the Transmitting Unit that has been replaced.	Store the address in the "BACK-UP UNIT" (see paragraph 8.13).
The green and red LEDs blink three times per second during start up.	"ID internal tx memory" is damaged.	Contact the support service of the Machine Manufacturer.
The green LED is lit with a steady light and the red LED blinks two times per second during start up.	The START actuator is activated.	Disable the START actuator.
The green LED repeats the sequence: 3 blinks and a pause, and the red LED is steady on during start up.	The UNPAIR procedure provided in the document "Menu of Transmitting Unit (MTU)" has been carried out.	Perform the ALIGNMENT procedure.

12 Decommissioning and disposal

Instructions for correct decommissioning and disposal of Radio Remote Controls are described in chapter "Decommissioning and disposal" in "Part A" of the Instruction Manual. Therefore, please refer to that part of the Manual.



Via Pomaroli, 65 - 36030 Caldogno (VI) - Italy
Tel. +39 0444 901000 - Fax +39 0444 901011
info@autecsafety.com - www.autecsafety.com

MADE IN ITALY