

PM08

User Manual

2. Beginning Use

Statement: The software updates sporadically since we continuously devote to product quality improvements. When operation for the product(s) your purchased differs from that described in this manual, please follow your product(s).

2.1 Charge the battery

PM08 comes with a built-in polymer rechargeable battery and is designed to use only manufacture-specified original batteries and accessories. When the battery is low, please charge it timely.

Charge by Charger

Plug one terminal of the charger into the power adapter socket, and the other to the power jack of the device to charge it.

2.2 Use the storage card

Insert the storage card

The storage card slot is on the right panel, just insert the TF Flash card with its gold contacts facing down and push it in until it clicks into place.

Browse files in the storage card

To browse the files in the storage card, do one of the following:

- run "File Manager" to view files in the storage card
- you can also install and run any other third party file browser applications

Remove the storage card

Simply push the storage card in to eject it from its slot.

To avoid data loss or damage, please stop using files/ programs in the storage card before removing the T-Flash card, and then tap **Settings> Storage> Unmount SD card** to remove it safely.

[Note]:

1. Make sure the location and direction of the storage card is correct when inserting, otherwise it is easy to cause damage/destroy to the storage card.
2. To avoid incompatibility or unrecognized of the storage card, major brands of storage card are recommended.

2.3 Hot plug of storage card

Please do not hot plug the storage card when using or browsing its files.


For example, when you are running the Music/Video Player/ Gallery, the storage card may damage if you push out the storage card directly and the running program will stop automatically to protect the device. As for details of inserting/removing storage card, see **2.2 Use the storage card**.

2.4 Power on/off

1. **Power on:** press down the Power Button to turn on the device when the battery is full enough
2. **Power off:** press down the Power Button for about 8 seconds and then a menu with options will popup, select **Power Off** to turn off the device
3. **Screen Lock:** tap Settings>Security>Screen lock and a menu with options will popup, select a screen lock pattern to shutdown the screen to save battery life. Press down the Power Button again to activate the locked Home Screen. After unlocking, the device will resume the screen before locking the screen.

2.6 GPS Info

Tap  in the Home screen and the tap the GPS Info icon  to enter the following interface:



[Note]: you can enter the above screen by tapping Navi> GPS Info.

To reset the GPS satellite receiver, you can tap  and a dialog box will popup as follows:



Tap “Yes” to finish reset and tap “Cancel” to exit.

2.7 About Device

View the device status such as the network type, battery power level, and network name. You can also check the battery use of individual applications or view the legal information and software version of your PM08.

FCC Statement:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.