



58kHz StealthPad™ Deactivator Installation Manual

Version: 2004 November

**Manual Part number: WG-STP-IM November
(110204B)**

WG SECURITY PRODUCTS INC.

3031 Tisch Way, Suite 602, San Jose, CA 95128 (USA)

Tel: 408-241-8000 ▪ Fax: 408-241-8082

For technical support in your country, visit our web site at www.wgsppi.com.

WARRANTY DISCLAIMER

WG Security Products Inc. makes no representation or warranty with respect to the contents hereof and specifically disclaims any implied warranties of merchantability or fitness for any particular purpose. Further, WG Security Products Inc. reserves the right to revise this publication and make changes from time to time in the content hereof without obligation of WG Security Products Inc. to notify any person of such revision or changes.

Technical Support Contact Information	
North America South America	Tel: 818-763-9186 Fax: 818-255-0514 Email: svc@sensorsense.com
Rest of World	Tel: 408-241-8000 Fax: 408-241-8082 Email: support@wgspi.com

CRITICAL NOTE

As specified by FCC Regulations 15.21, any changes or modifications not expressly approved by the party responsible for compliance of this equipment, will void the user's permission and authority to operate this equipment.

TABLE OF CONTENTS

OVERVIEW.....	1
System Description	1
Features	1
Specifications	2
PRE-INSTALLATION GUIDE	3
CAD Dimensions.....	3
Flush Mount Cut Out Suggestion	6
Installation Site Power Supply Check.....	6
INSTALLATION.....	7
Parts List	7
Deactivator Components and Connections	9
Socket Connections Notice.....	10
Power Cord Notices	11
North American Power Supply Cords	11
International Power Supply Cord	11
Fuse replacement	12
QUICK START INSTRUCTIONS	13
General Setup and Use	13
Recorded Media Products Deactivation	14
LED Error Indicators Description	15
IR REMOTE CONTROL KEYPAD DESCRIPTION	16
TUNING PROCEDURES & TIPS	17
REMOTE CONTROL PROGRAMMING	18

OVERVIEW

System Description

StealthPad is a distance deactivator providing excellent deactivation reliability and high throughput. The StealthPad can be easily installed on the counter top or flush mount with our mounting tray. StealthPad deactivates AM labels up to 10 cm (4 in.) above the surface of the pad at a high throughput speed.



Double Resonant Labels



StealthPad Antenna



StealthPad Control Box

Features

- **Compactness**
Its small footprint makes the antenna especially attractive in small counter tops.
- **Proximity Deactivation**
The StealthPad offers distance deactivation, making it perfect for both source tagged and retailer tagged merchandise.
- **Compact Size**
The compact size of the deactivation antenna allows StealthPad to easily be integrated into a counter application.
- **Integrated Audible and Visual Notification.**
Label deactivation notification is built into the StealthPad.
- **LAN Accessible**
StealthPad includes the remote access capability via WG's optional EASNet™ software for a variety of remote controls and data mining.

Specifications

Electrical

Primary Input.....115±10%Vac, 60Hz
230±10%Vac, 50Hz
Rated Current5A

Transmitter Output1.6ms burst
Transmitter Current.....3A peak (nominal)
Operating Frequency58kHz

Mechanical

StealthPad Antenna

Length188.1mm (7.4")
Width170mm (6.7")
Depth.....80.4mm (3.2") (Include bottom feet)
Weight.....3kg (6.6 lbs)

StealthPad Control Box

Length275mm (10.8")
Width190mm (7.5")
Depth.....140mm (5.5") (Include rubber feet)
Weight.....3kg (6.6 lbs)

StealthPad Mounting Tray

Length322mm (12.7")
Width307mm (12")
Depth.....57mm (2.2")
Weight.....0.24kg (0.53 lbs)

Environmental


Operating Temperature...0 to 49°C (32°–120°F)
Relative Humidity:0 to 85% non-condensing

PRE-INSTALLATION GUIDE


CAD Dimensions

Flush Mount Tray



All dimen:




StealthPad Antenna (All dimensions are in millimeters)



StealthPad Control Box (All dimensions are in millimeters)



Flush Mount Cut Out Suggestion



Installation Site Power Supply Check


IT'S RECOMMENDED TO HAVE ALL STEALTHPADS ON THE SAME POWER PHASE, otherwise you need to adjust B sync value step by step to find a best position to sync different StealthPads connected to power source with difference phase.

IT'S RECOMMENDED HAVING ENOUGH CURRENT SUPPLY FOR STEALTHPADS IF THERE ARE MULTIPLE STEALTHPADS SHARING ONE POWER SUPPLY. The rated current for StealthPad is 5A but the suggested current draw for one StealthPad is 7-8A for better performance, so a 15A power box will better serve 2 StealthPads instead of 3 or more.

IT'S RECOMMENDED HAVING GOOD GROUNDING FOR POWER SUPPLY OF STEALTHPAD. (Some time the poor grounding and high noise from power supply will decrease the sensitivity or detection range, check Noise entry D1 and D2, a value over 6-7 will be considered as big noise)


INSTALLATION

Parts List




<u>Part Name</u>	<u>Order Number</u>
StealthPad for 110VAC power voltage	WG STP-1
Antenna	WG STP-AT-1
Control Box (different than for FastPad)	WG STP-CB-1
StealthPad for 220VAC power voltage	WG STP-2
Antenna	WG STP-AT-2
Control Box (different than for FastPad)	WG STP-CB-2
StealthPad Flush Mounting Tray	WG STP-FMT
StealthPad Lock Key (the same as before)	WG-STP-KEY


CONTROL BOX FRONT VIEW



CONTROL BOX SIDE VIEW




CONTROL BOX BACK VIEW




Deactivator Components and Connections

As shown in Figure 1, the deactivator consists of a detect/deactivator antenna pad, power and control box. The cables used and connections are shown in the following diagram. The antenna pad can be installed flush to the counter with the flush mount kit.




Socket Connections Notice

To secure good contact and proper connections from the antenna pad to control box, please make sure the cable sockets are firmly connected and the pins are aligned correctly.



Incorrect pin mapping and loose contact of the connections will lead system to mal-functions!



Procedures:


1. First insert the connector of antenna pad into the socket of the control box, turn around until the **inner key** is captured by the **inner slot**
2. Secondly turn around the outer case of the antenna pad connector until the three **outer slots** capture the three **outer keys** on control box socket

Power Cord Notices

North American Power Supply Cords


This equipment is supplied with an external power line at one end and a molded receptacle terminal block at the other end. Conductors are color coded white (neutral), black (line) and green or green/yellow (ground).

Operation of this equipment at voltages exceeding 130 vac will require power supply cords that comply with NEMA configurations.




International Power Supply Cord

This equipment is supplied with an external power line at one end and a molded receptacle terminal block at the other end. Conductors are CEE color-coded—light blue (neutral), brown (line) and green/yellow (ground). Other IEC 320 C-13 type power supply cords can be used if they comply with the safety regulations of the country in which they are installed.



We recommend that you use a CE approved power cord H05 VV-F or H05 VVH2-F2 (Refer to the Electrical code which governs your country for installation of an Anti-Theft Unit to the Main power Supply)

Fuse replacement



Equipment shall be electrically disconnected from the branch-circuit supply when replacing the fuse.

WARNING – TO REDUCE THE RISK OF DAMAGE. REPLACE ONLY WITH SAME TYPE AND RATING OF FUSE.

QUICK START INSTRUCTIONS


General Setup and Use

Equipment must be electrically disconnected from the power supply before connecting the antenna with the control box.

Connect deactivation antenna to the control box as noted in the section named “Deactivator Components and Connections”.

Make sure the connectors are firmly attached to the sockets.

When all connections are ready, connect power and toggle the power switch. The power LED will come on to indicate the unit is active.



Detection Range (Adjustable)

DR Labels

Vertical 10cm (4 in)
Horizontal 15cm (5.9 in)

Deactivation

DR Labels

Vertical 10cm (4 in)
Horizontal 15cm (5.9 in)

Recorded Media Products Deactivation



Low Power Deactivation is strongly recommended for magnetic media products such as pre-recorded audio tapes, video tapes, floppy disks, etc. Use the remote control to set StealthPad to low power deactivation mode.

Instructions:

1. Access to Programming Mode
 - Press [PSW]
 - Input password (default is 68 unless previously changed).
 - Press [CON] to enter programming mode.
2. Set TX OFF to enable low power deactivation mode
 - Press [Tx OFF]
 - Input 1 to enable low power deactivation.
 - Press [CON] to accept the parameter.
3. Save to control box Flash ROM
 - Press [SA]
 - Input 1.
 - Press [CON] to accept the parameter.
 - Press [EX] to exit programming mode.

Deactivation Range Change!


When setting StealthPad to low power deactivation mode for media products deactivation, the active distance for deactivation is shortened accordingly. You must now place the label closer to deactivation antenna surface to ensure complete deactivation.

DR labels

Vertical Deactivation	2cm (1 in)
Horizontal	4cm (1.5 in)

LED Error Indicators Description

CONTROL BOX - FRONT VIEW



LED Definitions


- L4 (Yellow) = Program Running Indicator
- L3 (Green) = Over-voltage Detection
($115 \pm 10\% \text{Vac}$, 60Hz and $230 \pm 10\% \text{Vac}$, 50Hz)
- L2 (Red) = Overheat Detection
- L1 (Blue) = Continuous 250 times Operation Counting

Error Types

Note: If any of following errors occurs, the corresponding LED will turn on and StealthPad will lock up. Turn the power switch off/on to reset the unit.

- **[Red]** = Deactivating coils have overheated. Allow the unit to cool down and reapply power.
- **[Green]** = Over-voltage detection of the power source (10% tolerance: $115 \pm 10\% \text{Vac@60Hz}$ and $230 \pm 10\% \text{Vac@50Hz}$). Remove power until the power source is brought within required limits.
- **[Red]** and **[Yellow]** = 250 times continuous deactivation count has been reached. This typically occurs when the system false-alarms (e.g. carelessly leaving a hard tag on the deactivation pad will cause false alarms). In order to prevent system overheating from false alarms, ensure there are no hard tags on the pad, thereby eliminating false alarms, and then allow the system to cool down before reapplying power.
- **[All LEDs On]** = Deactivator coils current has exceeded the limit. Reapply power to the unit.

IR REMOTE CONTROL KEYPAD DESCRIPTION



Control Keys Description & Default Parameters Table

Key ID	Button	Parameters Description	Default Value	Valid Range	Page
	PSW	Activates the Control Box IR Receiver	NA	NA	15
B	SYN	Sync Adjustment	1	0 to 99	16
H	MIN	Minimum Signal Adjustment (Sensitivity adjustment)	3	0 to 8	19
D	NSE	Noise Display (2 channels)	NA	0 to 8	17-18
E	DFT	Return to Default Settings	0	0 to 1	19
F	TX OFF	Media Products Deactivation	0	0 to 1	19
L	ARM RST	Alarm Count Reset	0	0 to 1	20
P	PC	Password change	68 (*Note)	0 to 99	20
S	SA	Save Parameters to Flash ROM	NA	NA	20-21
	CON	Confirm Parameters Input	NA	NA	
	EX	Exit	NA	NA	

** NOTE: The default password (68) can be changed with the PC button. Thereafter the system will use the new number as the default password. The new password will remain saved even after power off. THIS IS A NON-RECOVERABLE ACTION. KEEP THE NEW PASSWORD IN A SAFE LOCATION IN CASE YOU FORGET IT.*

TUNING PROCEDURES & TIPS

There are two main potential problems that will affect StealthPad's functioning and performance.

Problem #1

The deactivator's detection range does not match the deactivation range.

If the detection range is too short (low sensitivity for the receiver), it will decrease the system's deactivation distance. But if the detection range is bigger than the deactivation range, it will cause false deactivation.

Normally the StealthPad deactivates labels 10cm above the antenna surface in all label orientations, so please tune Minimum Signal Adjustment to set the deactivator to the appropriate detection range. This adjustment is described under the heading "Key ID H" on page 19.

Problem #2


The deactivator exhibits false alarms (or causes other systems to do so) without tags or labels in the detection zone.

Usually interference is caused by a phase difference between different AM products at different locations. In this case, try to hunt on an appropriate B value (sync value), eliminating cross talk with nearby AM systems.

Exercise patience in trying every 5 increments of the B value, checking the noise value after confirmation. If other AM systems burst transmissions come into the StealthPad tag signal window, you will get a very high noise value (e.g. 6-8). Continue increasing the B value until you get a relatively small noise value (e.g. 1-3) and continue to monitor it until you have confirmed that other AM systems can successfully function without false alarms.

StealthPad has a totally adjustable sync value from 0 - 99, each step equaling 34µs, with a total adjustable Tx delay from 0 – 3.366ms. (Refer to page 16, under the heading "Key ID B Sync Adjustment").


REMOTE CONTROL PROGRAMMING




Point the IR Remote Control to the Interface Window at one side of the Control Box to operate the infrared communicator.

The panel normally displays the alarm count when not receiving any control signals from remote control. The alarm count is displayed as in the above picture – total count is 116 in this example. The number indicates the number of times the deactivator has detected labels.


Press [PSW] button to activate the remote control, and then enter the password (factory default is 68).




Input the number 68 (or the new password if you have changed it). Press [CON] to instruct the Control Box to accept the password.



Note: Entering the wrong password input will disable the panel from further instructions. Exit and re-press PSW to enter the correct password (see the picture below). After THREE successive attempts with the wrong password the remote control will be completely disabled. At this point you must turn the unit on/off and begin again.



When the correct password is verified, the LEDs will display as per the following picture and wait for configuration type input.




Key ID “B” - Sync Adjustment (range: 0-99; increment: 1)

This adjustment sets the time from zero crossing point to the start point of burst transmission. It is used for eliminating cross talk between different systems. In most cases the default b-1 value will achieve system stability with respect to other AM products.

Press [SYN] and the LEDs will display as shown below.


Input the number for the parameter.

Press [CON] to see the noise conditions.



Note: The adjustable range is 0-99 (0 – 3.366ms), with each increment equaling 34μs. (34μs x 99 total increments = 3366μs = 3.366ms)

Under this mode, you can also see the different noise condition at a different phase. If there is a phase problem, other AM systems' burst transmission will interfere with StealthPad's receiver, and you will see a large noise indication in D1, D2.



Key ID “D” - Noise Condition Display

(Valid parameters: 1,2,3,4 - see configuration table below)


The LEDs display the signal level number, with a level range from 0-8.

Note: When in the noise condition display mode, the alarm will be deactivated until you exit this mode.


Press [NSE] and the LEDs will display as shown below.

Input a number for the parameter.

Press [CON] to accept the parameter.



After confirmation, the panel will display a different signal or noise level from the specific antenna channel.



Noise Condition Display Configuration Table

Value	Function Description	Detection Purpose
0	Shut down tag or noise window display.	
D1	Tag window display for channel 1.	Detect tag by antenna CH1.
D2	Tag window display for channel 2.	Detect tag by antenna CH2.
D3	Average noise window display for channel 1.	Monitor long time average noise received by antenna CH1.
D4	Average noise window display for channel 2.	Monitor long time average noise received by antenna CH2.

Note: D3/D4 indicate the average noise level and also the weighted Minimum Signal Adjustment value. It gets the MAX value between average noise and MIN value. Therefore, if MIN (H value) is increased to be bigger than the average noise level, D3/D4 will indicate only H value instead of average noise value.

Key ID “H” - Minimum Signal Adjustment (valid range: 0-8, increment 1)


Lowering this number will increase the label detection sensitivity of the StealthPad, but will also increase the risk of false deactivation. Vice versa, raising it will decrease the sensitivity or detection range to adapt to deactivation range.

While there are two antenna channels, StealthPad has only one H value adjustment, and it will apply to both of the antenna channels for minimum signal adjustment.

Press [MIN]. The LEDs will display as shown as below

Input number for the parameter.

Press [CON] to accept the parameter.

**Key ID “E” – Load Default Settings (default value: 0; valid range: 0-1)**

Value	Action
0	Initial state, no meaning
1	Load default settings

Input value 1 will load the default settings (refer to the Default Parameters Table on page 10).

Key ID “F” – Low Power Deactivation Settings
(default value: 0; valid range: 0-1)



Low Power Deactivation is strongly recommended for magnetic media products such as pre-recorded audio tapes, video tapes, floppy disks, etc.

Value	Action
0	Normal deactivation strength
1	Low power deactivation for media products

Press [Tx OFF]
Input number for the parameter.
Press [CON] to accept the parameter.

(Inputting “1” will lower the deactivation power for magnetic media products)

Key ID “L” – Alarm Count Reset (default value: 0; valid range: 0-1)

Value	Action
0	Initial state, no meaning
1	Reset alarm count

Press [ARM RST]
Input number for the parameter.
Press [CON] to accept the parameter.

(Inputting “1” will reset alarm count to 0)

Key ID “P” - Password Change (default value: 68; valid range: 0-99)

The password can be changed in this mode from the factory default to your choice. Press the confirm button after input to activate the password.

Note: If you change from the default password, save the new one in a safe place because if you forget it there will be no way to access the unit.

Exit Button

Press [Exit] to return to Alarm counter display status.


Save Button

This button will save all current parameters to Flash ROM, so when power is shut down the parameters will be saved. Next time the system reboots it will load all the parameters from Flash ROM.

Press [Save]. The LEDs will display as shown below.

Input 1

Press [CON] to accept the current parameters.



Important Safeguards and Regulatory Notices

Information on the following pages provides important safety guidelines for both Operator and Service Personnel. Specific warnings and cautions will be found throughout the manual where they apply, but may not appear here. Please read and follow the important safety information, noting especially those instructions related to risk of fire, electric shock or injury to persons.

WARNING

Any instructions in this manual that require opening the equipment cover or enclosure are for use by qualified service personnel only. To reduce the risk of electric shock, do not perform any servicing other than that contained in the operating instructions unless you are qualified to do so.

Symbols and Their Meanings



The exclamation point within an equilateral triangle alerts the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the equipment.



The fuse symbol indicates that the fuse referenced in the text must be replaced with one having the ratings indicated.

Danger

Electrical potential is still applied to some internal components even when the power switch/breaker is in the off position. To prevent electrical shock when working on this equipment, disconnect the AC line cord from the AC source before working on any internal components.

A residual voltage may be present immediately after unplugging the system due to slow discharge of large power supply capacitors. Wait 30 seconds to allow capacitors to discharge before working on the system.

Warnings

Heed all warnings on the unit and in the operating instructions.

Do not use this equipment in or near water.

Disconnect AC power before installing any options.

The attachment plug receptacles in the vicinity of the equipment are all to be of a grounding type, and the equipment grounding conductors serving these are to be connected to earth ground at the service equipment.

This equipment is grounded through the grounding conductor of the power cord. To avoid electrical shock, connect the power cord to the equipment and plug it into a properly wired receptacle before connecting the equipment inputs and outputs.

Route power cords and other cables so that they are not likely to be damaged.

Do not wear hand jewelry or watches when troubleshooting high current circuits, such as the power supplies.

During installation, do not use the door handles or front panels to lift the equipment as they may open abruptly and injure you.

To avoid fire hazard, use only components of the specified type, voltage and current rating as referenced in the appropriate parts list.

Always refer fuse replacement to qualified service personnel.

To avoid explosion, do not operate this equipment in an explosive atmosphere unless it has been specifically certified for such operation.

Have qualified personnel perform safety checks after any completed service.

Risk of electric shock is present. A grounded circuit conductor (neutral) is provided with over current protection. Test all components before touching.

Cautions

To prevent damage to equipment when replacing fuses, locate and correct the trouble that caused the fuse to blow before applying power.

Verify that all power supply lights are off before removing the power supply or servicing equipment.

Use only specified replacement parts.

Leave the base of the system clear for air exhaust cooling and to allow room for cabling. Slots and openings in the system are provided for ventilation. Do not block them.

To prevent damage to this equipment read the instructions in this document for proper input voltage range selection.

Circuit boards in this equipment are densely populated with surface mount and ASIC components. Special tools and techniques are required to safely and effectively troubleshoot and repair modules that use SMT or ASIC components. For this reason, service and repair of products incorporating surface mount technology are supported only on a module exchange basis. Customers should not


attempt to troubleshoot or repair modules that contain SMT components. It assumes no liability for damage caused by unauthorized repairs. This applies to both in- and out-of-warranty products.

Power Cord Notices

North American Power Supply Cords


This equipment is supplied with an external power line at one end and a molded receptacle terminal block at the other end. Conductors are color coded white (neutral), black (line) and green or green/yellow (ground).

Operation of this equipment at voltages exceeding 130 VAC will require power supply cords which comply with NEMA configurations.



International Power Supply Cord

This equipment is supplied with an external power line at one end and a molded receptacle terminal block at the other end. Conductors are CEE color coded—light blue (neutral), brown (line) and green/yellow (ground). Other IEC 320 C-13 type power supply cords can be used if they comply with the safety regulations of the country in which they are installed.



Before You Install

Introduction

Congratulations on your purchase of one of the finest EAS systems on the market. This is the Installation Instructions manual.

Receiving Inspection

Inspect all shipping containers for any signs of damage. If any is found, notify the shipping company. If there is no obvious damage, continue with the unpacking instructions.

Unpacking Instructions

Place the containers on a flat level surface with enough room to move the container around as needed. Remove all the remaining manuals. Compare the manuals against the Inventory sheet and make a note of any discrepancies.

Carefully remove the contents of container and place on a flat level surface. Compare the contents with the Part List to ensure that there no missing items. Make a note of any discrepancies.

Equipment Inspection

Inspect all equipment for damage. Items to specifically check, and damage to look for, are listed below:

All connectors for bent or broken pins

Cables for crimped or broken wires

Plastic housing for any obvious signs of damage

If any damage is found, contact Customer Service at the telephone number in the front of this manual. If any item is damaged, DO NOT make any power or signal connections to the unit unless otherwise advised to do so by Customer Service.