



**WMTS T1 Access
Concentrator**

V3000

**System Configuration
Guide**

Network Release 3.6

Manual Version: 1.1.15

Copyright and Trademark Information:

© 2005 Vyvo Inc. All rights reserved.

Vyvo Inc. reserves the right to alter the equipment specifications and descriptions in this publication without prior notice. No part of this publication shall be deemed part of any contract or warranty unless specifically incorporated by reference into such contract or warranty.

The information contained herein is merely descriptive in nature, and does not constitute a binding offer for the sale of the product described herein. Any use of the Vyvo Inc. logo or trademarks is forbidden without prior written approval from Vyvo Inc.

All trademarks mentioned herein are the property of their respective owners.

Table Of Contents

Table Of Contents	3
Installation and Safety Information	7
Chapter 1. System Configuration Introduction	10
1.1 Overview	10
1.2 Equipment Capabilities	13
1.3 WMTS	13
1.4 Modems	16
1.4.1 Modems with DOCSIS and IP only	16
1.4.2 Modems with DOCSIS, IP and E1/T1	17
1.4.3 Modems with DOCSIS, IP and PSTN	18
1.4.4 Modems with DOCSIS and IP Only With Built in UHF Radio	19
1.5 Modem Capabilities Matrix	20
Chapter 2. Configuration Overview	21
2.1 Network Servers	21
2.1.1 DHCP Server	21
2.1.2 TFTP Server	21
2.1.3 Time-of-Day (TOD) Server	21
2.2 RF Link Layer	21
2.3 DOCSIS Layer	22
2.4 IP Layer	23
2.5 E1/T1 Layer	24
2.6 Configuration Tools and Files Matrix	26
Chapter 3. The Modem Initialization Process	28
3.1 Modem Initialization Sequence	28
3.1.1 Power-On Self Test	28
3.1.2 Downstream Synchronization	29
3.1.3 Obtaining Upstream Parameters	29

3.1.4	Ranging	29
3.1.5	Establish IP Connectivity	29
3.1.6	Establish Time of Day	30
3.1.7	Transfer Operational Parameters	30
3.1.8	Registration	30
3.1.9	Baseline Privacy Initialization (BPI)	30
Chapter 4.	Overview of the WMTS and Modem Configuration	31
Chapter 5.	Adding a Modem to the WMTS	34
5.1	Editing the Modem Configuration File	35
5.1.1	Setting the Upstream Channel	35
5.1.2	Setting the Downstream Frequency	38
5.1.3	Setting Concatenation and Fragmentation Capabilities	39
5.1.4	Setting Upstream QoS (Class of Service) for IP Data	40
5.1.5	Setting Additional Downstream and Upstream Channels	41
5.1.6	Setting the Maximum Number of CPEs	42
5.2	DHCP Settings for the Modem	43
5.2.1	IpLease DHCP Server: Editing and running the CM.SRC File	43
5.2.2	Windows 200x Server Edition: Modifying the DHCP Options	48
5.3	Configuring the WMTS	57
5.3.1	Setting the WMTS Upstream Parameters	57
5.3.2	Setting the WMTS Downstream Parameters	60
5.4	Setting the Modem's Downstream Frequency	62
5.5	Verifying the Modem Downstream and Upstream Status	69
5.6	Using an HTTP Connection to View Modem Operation	71
5.6.1	Viewing the internal modem HTML pages:	71
5.6.2	Viewing the Connection Page	73
5.6.3	Viewing the Software Page	74
5.6.4	Viewing the Security Page	75
Chapter 6.	Configuring a T1 Connection	76
6.1	Configure the Modem for T1 Operation	77
6.2	Adding the T1 modem to the WMTS T1 Interface and Assign Port(s) ..	85

Chapter 7. Setting the WMTS IP Address	93
Chapter 8. Installing Vyvo Servers for WMTS Operation	106
8.1 Installing The Time Server:	106
8.2 Installing the Pumpkin TFTP Server:	106
8.3 Installing IPLease DHCP Server:	109
8.3.1 dhcpsvr.ini	109
8.3.2 cm.src	110
8.3.3 Dhcpgen	112
8.3.4 DhcpSvr:	115
Chapter 9. Maintenance and Troubleshooting	116
9.1 Introduction	116
9.2 Troubleshooting the RF Frontend	116
9.2.1 General	116
9.2.2 Checking the Downstream	117
9.2.3 Checking the Upstream	118
Chapter 10. Troubleshooting The Subscriber Site	119
10.1 Post-Registration Verification	119
10.2 Physical Layer Troubleshooting	119
10.3 IF Layer Troubleshooting	119
10.4 Troubleshooting the NMS	120
10.5 Repairs Safety	121
Appendix A. WMTS US Port Mapping	122
Appendix B. Checking the WMTS Version	123
Appendix C. Installing and Uninstalling the NMS	126
C.1 First Time Installation	126
C.2 Launching the Vyvo NMS	126
C.3 Installation Upgrade	126
C.4 Uninstalling the NMS	127
Appendix D. Launching the Vyvo Configuration Tool	128

D.1 The Vyvo Configuration Tool Menu (exploded view)	129
D.2 Launching the Vyvo Configuration Tool from the “Start” Menu	130
D.3 Launching the Vyvo Configuration Tool from the NMS	133
Appendix E: Vyvo Configuration Tool – Additional Functions	136
E.1 Adding and Deleting a Modem	136
INDEX	137

Installation and Safety Information

The following information is provided to ensure safe operation of this equipment. Vyyo assumes no liability in the event that the customer fails to comply with the following safety precautions and warnings.

System Power-on

AC System Power

AC System

The WMTS power supplies are factory wired for 115 ~ 220 VAC (2 X 200W). A power cords are provided to connect the unit to the power source. To operate the WMTS, turn ON the power switch at the rear panel.

Warning!

Set the fuse selector on the rear panel to the proper position (110V or 220V), before plugging in the power cord, or turning on the WMTS.

DC System Power

DC System

1. When connecting DC power lines make sure to connect Ground line first.
2. When disconnecting DC power lines – make sure to disconnect ground last.
3. External Circuit Breaker (DuPole) should be used before connection/removal of the power cable to/from the WMTS.
4. FUSE Replacement – Make sure to use same type and value fuse !

Note that UL requires use of AC ceramic high breaking capacity 10Amp fuse.

Earthing

General

The minimum cross sectional area of the protective earthing should be 1mm² .

T1 Cable

General

T1 cable to be used with WMTS T1 ports is only 26AWG communication cable (the common cable for this application).

Repairs Safety

General

1. Repairs of WMTS should take place only in Vyvo company service laboratories or in other Vyvo formally approved distributors service laboratories.
 2. In case of field handling - Disconnect the unit from power supply for safest repair.
 3. 2. In case of a -48VDC operated WMTS, the External Circuit Breaker (Du Pole) must be used before connection/removal of the power cable to/from the WMTS.
-

Safety Summary

Warnings:

Carefully connect units to the supply circuit so that wiring is not overloaded. For DC system connect Ground first (or remove Ground last for disconnect).

Read the installation instructions before connecting the system to its power source.

Secure all power cabling when installing this unit.

Do not touch the power supply when power cord is connected. For systems with a power switch, line voltages are present within the power supply, even when the power switch is off and the power cord is connected. For systems without a power switch, line voltages are present within the power supply when the power cord is connected

The device is designed to work with TN power systems

Before working on equipment that is connected to power lines, remove jewelry (including rings, necklaces, and watches). Metal objects will heat up when connected to the power and ground. This can cause serious burns or weld the metal object to the terminals

Repairs of WMTS should take place only in Vyvo company service laboratories or in other Vyvo formally approved distributors service laboratories. In case of field handling our general SAFETY warning is to disconnect the unit from power supply for safest repair.

Chapter 1. System Configuration Introduction

This guide is intended as a practical aid for the Technicians, Operators and Field Service Engineers responsible for quickly configuring Vyvo systems at most common installations. It is not intended as a substitute for a detailed reference manual.


NOTE: Throughout this manual the terms modem and WMU are used interchangeably. The term "WMU" refers to "Wired/wireless Modem Unit". In some instances the actual modem model (V280, V311, etc.) may be used if the information is specific to that modem.

The term "WMTS" is used interchangeably with "XMTS". XMTS is an acronym for "Xtend Modem Termination System". Both terms appear in the software and were derived from the term "CMTS", "Cable Modem Termination System".

The term "WMU" will appear in the software occasionally. It is an acronym for "Wireless Modem Unit" and is used interchangeably with "CM" (Cable Modem).

1.1 Overview

The system acts as an RF bridge between a network, typically the Internet or the Public Switched Telephone Network (PSTN) (at the head end) and customer equipment at the other end of the RF link.



It may be visualized as a three layer protocol stack. The highest layer may be any one of the following: IP, E1/ T1 or PSTN.


All systems include the IP capability, which is required for network management. The E1/T1 capability requires an additional plug-in card at the WMTS

(Cable/Wireless Modem Termination System) end and an E1/T1 capable cable/wireless modem at the downstream end.


The data from the IP, E1/T1, or PSTN layer are encapsulated as DOCSIS frames which in turn are converted into RF signals and sent over the air or via an HFC (Hybrid Coax Fibre) plant between the WMTS and modem.

Important Note: *connectivity MUST be obtained at each layer, beginning with the lowest (RF link) in order to establish full communication.*

The following diagram illustrates this in the form of a three layer protocol stack:



This illustration shows how a complete system is connected:



Connection Legend:

Blue = 100BaseT Ethernet

Green = RF Coaxial cable

Black = T1/E1

Grey = RJ-11

There are different configuration requirements for each layer and different software tools accomplish this task. The configuration of the RF link is typically unique to each installation with the particular downstream and upstream frequencies, modulations and bandwidths being the critical parameters that must be set on the modem and WMTS.

Whereas there is no set standard for implementing an RF link, DOCSIS is a fully specified protocol as are the upper layers (IP, E1/T1 or PSTN). The following sections will describe the currently available system components (equipment) then detail how to configure each of them in turn.

1.2 Equipment Capabilities

There are several different modems available, the simplest being the DOCSIS modems with IP-only capability. All of the other modems use these as their foundation.

The WMTS used at the head end is the other major component. There is only one basic configuration, which is augmented with additional plug-in cards to accommodate E1/T1 and PSTN capabilities.

NOTE: The term WMTS was originally conceived as "eVyyoed" CMTS for use in a cable plant, hence the "X". This was followed by WMTS in which the "W" indicates a "wireless" CMTS. For practical purposes these terms are interchangeable and in some places the software uses the term "WMTS" when referring to any one of these systems.

1.3 WMTS

The basic WMTS is a chassis with a power supply and a mid-plane PCI bus that accommodates plug-in cards at the front and rear. Two redundant power supply cards are provided at the right end of the front of the chassis.

The minimum required hardware configuration for an IP-only system consists of one "HOST" card and three "Universal" cards. One Universal card acts as a "Control and Forward" (C&F) card, one as the "Upstream" digital card and one as the "Downstream" digital card. These latter two cards are attached to RF cards in the rear slots.

E1/T1 capability may be added by replacing the Host card with a Master4 card, and adding one or two E1/T1 interface cards in the rear slots to provide 12 or 24 E1/T1 ports, respectively. An DS3 version of the Master4 card which allows 28 T1 connections is also available. This card has two coax connectors (one for receive and one for transmit) in place of the E1/T1 interface cards.

The HOST or Master4 card serves as the PCI bus arbiter and provides the system clock and timing. When the WMTS boots, the Master4 card initializes, then identifies the C&F card. The C&F card then directs the configuration and downloading of relevant application software. The C&F card is connected through a 100 BaseT Full Duplex connection to the switch or router and used to transport data (including management packets) through the system.

All Universal cards are the physically identical: the card attached to each of them in the rear slots and the application downloaded during initial startup determine the function of the card (Upstream, Downstream or Control & Forward).

In the rear slots, one Downstream and one Upstream RF interface card are required. Each of these corresponds to its companion Universal card. The “Quad” downstream card has four RF connectors and provides four downstream channels. The “Hex” upstream card has six RF connectors and provides six upstream channels.

Note: *All Downstream cards have a fixed output frequency of 44 MHz which must be converted up per the local requirements.*

Upstream cards may be configured to receive any frequency from 5-65 MHz



Figure 1-1. The WMTS Chassis with (from left to right) Upstream card, Downstream card, Control and Forward card, MASTER4 card, and Power Supplies shown.

The WMTS is mounted in a standard 19” by 6U high rack-mounted chassis. The chassis has a fan tray above the unit, bringing the total height required

in the rack, to 8U. The eight bay chassis contains eight slots in the front, six slots in the rear, and a mid-plane card in between, used to interface the cards. Blank panels cover unused slots.

A standard 33 MHz, 32 bit Compaq PCI bus is used to transfer traffic and data between the system cards. The power supplies, Master4 card and the universal cards are inserted in the front slots of the chassis. The Quad Downstream, Hex Upstream, and E1/T1 cards are inserted in the rear slots of the chassis.

The ON/OFF power switch and the fuse are located in the rear of the power supply.




Figure 1-2. Midplane Cutaway View of WMTS; Universal Card Shown in Cutaway attached to an RF card.

1.4 Modems

1.4.1 Modems with DOCSIS and IP only

The V280 is Vyö's "IP-only" modem. It uses an RJ45 connector (shown below) on the rear panel to provide IP connection to the customer's equipment. The V280 supports up to 63 data users simultaneously and provides privacy, authentication, service classification, prioritization, and traffic shaping.

The USB connector is not supported at this time. Check with Customer Support for updates as they become available if you need this capability.



Figure 1-3. V280 Rear Panel



Figure 1-4: V280 Front panel

Hyperterm (a Windows terminal application which permits either a serial or direct IP connection and is used in the following examples) or Telnet may be used to connect the modem to a computer to configure parameters in the modem, such as the downstream receive frequency. Any equivalent software utilities may be used.

A basic WMTS unit (without E1/T1 capability) is all that is required at the head end to complete an IP connection.

1.4.2 Modems with DOCSIS, IP and E1/T1

The V311 is a V280 modem (to provide the DOCSIS layer) with one E1/T1 interface (via an RJ45 connector on the front panel) added. In addition to IP connectivity, it supports circuit switched E1/T1 applications. It has one 100 BASE-T port for IP data and one E1/T1 port which can support up to 32/24 time slots.

The E1/T1 application supports framed or unframed E1/T1 services. In the case of unframed configuration, all 32/24 time slots (including time slot 0) are delivered over the air.

In the case of framed E1/T1 configuration, a full or fractional E1/T1 (any number up to 31/23 time slots) can be delivered.

The V311 modem is shown in this image:



Figure 1-5: V311 Modem

The V312 is identical to the V311 but has two E1/T1 interfaces instead of one.

The WMTS at the head end requires one or two E1/T1 interface cards (plugged into the rear slots, with the second E1/T1 card attached to the first one as a daughter board) to work with the V311 or V312. The E1/T1 connection will be terminated at one of the ports on this (rear) E1/T1 interface card(s). In addition, a separate software load is required.

All modems have four LED indicators, described below.




Figure 1-6. LED Indicators

LED Indicator	Function
POWER	- On = Power On - Off = Power Off - Flashing = Fatal Error
STATUS	- On = User has access to the Internet - Off = User has no access to the Internet
RF LINK	When Status LED is Off: - RF On = The downstream link is operational - RF Off = The modem has not yet begun downstream acquisition, or The downstream link is idle, or There is a problem with data reception - RF Flashing = Downstream link is being acquired When Status LED is On: - RF Flashing = Data is transferring in either in the Upstream or Downstream direction
LAN& USB	- On = The LAN link is operational - Off = The LAN link is not operational - Flashing = Data is transferring to or from the LAN

Table 1.1 LED Indicators, Functions, and Conditions

1.4.3 Modems with DOCSIS, IP and PSTN

The V313 is a V280 (for the DOCSIS layer) with a PSTN interface added: this physical interface (provided with the V313) comprises four RJ45 connectors, each of which connects to a special cable terminated in four RJ11 connectors, allowing a total of sixteen PSTN devices to be connected.

The WMTS at the head end requires an E1/T1 card and a V5.2 AN stack (additional software available from Vyvo) to work with this unit. If you plan to deploy the V313 please contact your Vyvo representative.

1.4.4 Modems with DOCSIS and IP Only With Built in UHF Radio

The V284 modem is a basic V280 modem integrated with a built-in UHF radio that provides an upstream RF output in the 710-716 MHz range. Internally the V284 has a factory set intermediate frequency of 44MHz which is converted up to yield an appropriate upstream frequency (This is preset at the factory for 700MHz in the United States).

The downstream frequency ranges from 740-746MHz. Note that the RF setup of this radio requires appropriate preplanning owing to the complexity introduced by the internal UHF radio. Please reference the UHF System Installation Guide and/or your local system engineer.



Figure 1-7: V284 Modem

1.5 Modem Capabilities Matrix

Modem Model	Modem Hardware	Connectivity	Additional WMTS Cards required	Description
V280	V280	IP	none	The basic DOCSIS modem
V311	V280 plus E1/T1 card	IP, E1/T1	E1/T1 interface card and Master4 card	A V280 modem with one E1/T1 interface (one RJ48 connector on the front which can handle one E1 or T1 line)
V312	V280 plus E1/T1 card	IP, E1/T1	E1/T1 interface card and Master4 card	A V280 modem with two E1/T1 interfaces (two RJ48 connectors on the front which can handle one E1 or T1 line each)
V313	V280 plus internal PSTN card	IP, PSTN	E1/T1 interface card and Master4 card with additional V5.2 AN stack	A V280 modem with a built-in PSTN interface (four RJ45 connectors each of which attaches to four RJ11 POTS connectors)
V284	V280 plus internal UHF radio	IP	none	A V280 modem with an internal UHF radio for communication in the 700MHz range – special RF configuration is necessary. Please see the UHF System Installation Guide.

Chapter 2. Configuration Overview

This section of the System Configuration Guide features a short overview of each component/layer of the System including the WMTS and the modems. The last section is a summary presented as a matrix that shows the relationships between the various tools and files. The components and layers are described below.

- Network Servers
 - DHCP Server
 - TFTP Server
 - Time of Day (ToD) Server
- RF Link Layer
- DOCSIS Layer

2.1 Network Servers

The following servers are required for successful completion of modem initialization. They will be accessed by the modem and the WMTS at specific points during the registration and installation process.

2.1.1 DHCP Server

This server binds the modem's MAC address to both its Network IP address and its configuration (or "boot") file, which contains several important system specific parameters required for the modem to communicate with the WMTS. Viewing this information can help in troubleshooting any problems which may occur.

2.1.2 TFTP Server

This server downloads the selected configuration file to the modem during the registration process when the modem requests it. It also downloads files and configuration information to the WMTS. This information is used for initial (first time) startup and for troubleshooting.

2.1.3 Time-of-Day (TOD) Server

This server provides the Time of Day to the modems and the WMTS. It allows the WMTS and the modem to coordinate their timing.

2.2 RF Link Layer

This network layer is unique for each installation and depends on the available frequencies, the frequency plan, the specific hardware used for the installation, and other factors.

Your System Engineer must develop a detailed system plan that accounts for each of these variables. This plan must include the assignments of downstream frequencies, modulations (and other RF parameters) and upstream channel IDs assigned to the various modems deployed in the network. If the modems are to be used with E1/ T1 connections, all related parameters, especially QoS (Quality of Service, also referred to as Class of Service) parameters, also need to be defined (these are discussed later in this document.)

NOTE: The methods to define these factors are unique to each customer and are outside the scope of this document. They are part of the site preparation and pre-planning, including any “overbooking” scheme that may be desired. Please consult your Vyvo representative or system integrator for assistance.

The Downstream and Upstream frequencies, modulations and bandwidths MUST be pre-determined in order to proceed with the configuration of the WMTS and the modems. Each modem must be assigned to a specific WMTS Upstream Channel (the upstream channel is referenced by its Channel ID which identifies the physical port.) The Upstream channel must be configured for a specific frequency, modulation and bandwidth or symbol rate.

NOTE: The WMTS must be configured to use the correct Upstream and Downstream parameters. This is done using the Vyvo Configuration tool.

It also recommended that each modem is assigned to a particular Downstream channel (or set of channels.) The modem can use Downstream channel discovery, however; it is typically not used since it takes much longer to discover the correct frequencies.

Using pre-determined frequencies also allows greater control over the RF frequency assignments and can distribute network bandwidth more efficiently. A range of frequencies can be defined in the modem configuration file to cover all customer assigned bands and to minimize future re-configuration.

NOTE: The modem’s Downstream frequency is preset at the factory but may be changed on the modem by using a direct Telnet connection. See [Section 5.4 Setting the Modem’s Downstream Frequency](#) for details.

2.3 DOCSIS Layer

The most important items that must match are:

The WMTS Downstream Frequency and the modem Downstream Frequency

The WMTS Upstream Channel ID and the modem Upstream Channel ID (their associated parameters must also match.)

First, the modem searches for a signal at its preprogrammed Downstream Frequency. Once having locked to that downstream channel, the modem receives upstream channel descriptors (UCDs) from the WMTS that describe the available upstream channels.

*NOTE: The WMTS must be configured to construct the UCDs so that they correspond to the site preplan. Use the **Vyyo Configuration Tool** to accomplish this if any changes are required.*

The modem then enters a protocol exchange that requires data be transmitted from the modem to the WMTS via an Upstream Channel using its associated Channel ID (designating the physical interface on the RF Interface card), and the correct frequency, modulation and bandwidth or symbol rate.

*NOTE: A modem configuration file which respecifies these parameters is downloaded to the modem after “ranging” (described below) is complete . This file is also referred to as the modem “boot” file. All further communication done by the modem uses the parameters specified in this file. The modem configuration file is modified using the **CMconfigFileEditor** tool.*

This protocol exchange allows the modem to ‘range’ (adjust its timing and power level so that it can work successfully with all of the other modems on line at this time.). After the ranging is finished, the modem has successfully established physical layer and Link or MAC layer connectivity with the WMTS. The WMTS is now capable of sending MAC layer packets such as DHCP and ARP requests required to complete the registration process.

2.4 IP Layer

Your System Engineer must devise a Network IP Plan. This is required in order to assign IP addresses to the WMTS and all the modems on the network. It must include the IP address of all the servers as well as the network mask and other network parameters.

After connectivity is established at the DOCSIS layer (discussed in Section [2.3 DOCSIS Layer](#)), the modem is assigned to an IP address by using DHCP (Dynamic Host Control Protocol.) If using the ipLease tool as the DHCP Server, this is usually a static IP address defined in the DHCP setup file (CM.SRC.) This file binds the modem's MAC address to a particular fixed IP address. If using Windows 2000 Server Edition this binding is accomplished using its DHCP Administrative Tool, which may be installed at the user's option using the “netsh” command (follow the instructions provided with your server).

The DHCP server grants the “lease” on the IP address to the modem (i.e., tells the modem which IP address to use). The granted IP address is for SNMP connectivity within the Vyyo system; it is not offered as a public IP address to Vyyo equipment. However, if desired this can be done using the customer PC or Router as the modem will behave as Layer 2 bridge device.

For the ipLease DHCP Server tool, the CM.SRC file is an ASCII text file that may be edited using any text editor (such as Notepad). This document describes the configuration process using the ipLease tool. The changes are similar for other DHCP servers. Note that if another operating system, such as the Windows 200x Server, is used a DHCP server is often included. Check with your Vyvo representative to make sure the DHCP server is compatible.

*NOTE: Before the modem can acquire an IP address, the WMTS must be configured with its own IP address. This procedure is described later in this document in the section entitled Setting the WMTS IP Address. The WMTS IP address is specified in a different configuration file (regtree.rtr) which may be edited using the **XmtsConfigurationFileEditor** tool.*

After the modem successfully receives its IP address it contacts the TOD server to establish the time of day. Next, it contacts the TFTP server to download the modem configuration file, which specifies the final DOCSIS parameters for the modem. This file is also referred to as the modem "boot" file. All further communication done by the modem uses the parameters specified in this file. This file may cause the modem to change frequencies or reboot in order to reset some of its configuration parameters. The modem will acquire this file every time it is reset or restarted. Configuration changes to the modem configuration file (profile) will be done from the Operation center with out the need to visit the modem remote location for any setup change; These changes may include encryption, QoS., IP filters, downstream channel parameters. etc....

*NOTE: the modem configuration file is modified using the **CMconfigFileEditor** tool..*

During the final phase of the DOCSIS registration process, the modem sends a registration message to the WMTS confirming that the configuration file was received. The WMTS retrieves a copy of the configuration file from the configuration file server TFTP root repository directory. The WMTS then compares the file from the server with the data from the modem to ensure that the modem will only use services for which it was authorized. The modem is then finally allowed to transmit real user data into the network, but only after the modem's configuration file values are crosschecked by the WMTS.

At this point, a data only modem will be successfully connected to the system.

2.5 E1/T1 Layer

After IP connectivity is established, E1 or T1 connectivity may be established. Note that in addition to installing an E1/T1 card into the WMTS chassis, E1 and T1 each require that different firmware be loaded into both the WMTS and the modem.

The E1/T1 configuration will require appropriate changes to the modem configuration file in addition to setting those configuration parameters used for a

standard IP-only modem. The same modem configuration file may be used for several modems provided the Downstream frequencies and the Upstream Channel ID are the same (i.e., same “profiles”).

The WMTS E1/T1 configuration needs to be modified appropriately for every E1/T1 modem installed on the network. This is done using the Java™-based Vyyo Configuration tool. This tool configures the E1/T1 port on the modem to be connected (“bound”) to the correct E1/T1 port on the E1/T1 card plugged into the WMTS.

After this tool is used to bind the E1/T1 ports together and the standard modem provisioning is done, the installation is complete and the E1/T1 services in the modem are ready to be activated.

2.6 Configuration Tools and Files Matrix

Tool	Configured File or Device	Description
CMconfigurationFileEditor	Modem Configuration file (e.g., "MIC_xxx.cfg", where xxx is some unique number.)	This file downloads to a modem during the registration process. It contains all the parameters required for the modem's operation in the DOCSIS network: upstream and downstream frequencies, QoS, etc. It is also call the modem "boot" file.
XmtsConfigurationFileEditor (any standard ASCII text file editor may also be used to edit the text version of the file)	Regtree.txt Regtree.rtr (downloadable version of the text file)	Regtree.txt contains the permanent IP address of the WMTS. This tool is a convenient way to edit the more common items in the file. However, when editing the WMTS IP address you must use a standard text editor. The Regtree file may be saved in either text or downloadable format using this tool.
SETIP.BAT	Regtree.txt	This batch file is used to convert the text version of the Regtree file to the downloadable format (Regtree.rtr). It calls RTR2TXT.EXE and RECFMT.EXE to do the conversion.
RTR2TXT.EXE	Regtree.rtr	This tool is used to convert the Regtree.rtr file to a standard text file (Regtree.txt)
XmtsConfig	WMTS	Used to assign a temporary IP address to the WMTS and to download files to the WMTS. Specifically it must be used to download the compiled version of the Regtree.txt file to the WMTS. This is primarily used during initial setup.

Vyvo Configuration Tool	WMTS MIB database	This is a standalone JAVA based tool that can be accessed from the NMS. It is used to modify and configure the WMTS operating parameters.
NMS (Castlerock)	WMTS or Modem MIB values (Typically for viewing only.)	A general purpose Network Management System for operating the network; also used to launch the Vyvo Configuration tool.
Any ASCII text editor, e.g., Notepad	CM.SRC	Used with ipLease (the DHCP server) to bind a modem's MAC address to its network IP address and its modem configuration file (downloaded during modem initialization) as well as other network parameters needed to configure the modem.
DHCPGen	CM.SRC	Converts the file to a format that ipLease can use
DHCP Server	modem	Sends the modem its network IP address and the name of its modem configuration file as well as other information needed to setup IP connectivity.
TOD Server	modem	Used to set the time of day in the modem and the WMTS
TFTP Server	modem and WMTS	Used to send the modem configuration or "boot" file to the modem during initialization; also used to load the WMTS application and configuration files
Telnet	Modem	Used to set the downstream frequency that the modem will scan to listen to the WMTS. Also used to set the RF offset if required.

Chapter 3. The Modem Initialization Process

To understand the configuration process, it is useful to understand the detailed steps the modem goes through during its initialization.

When the modem is first powered up, it must go through a fixed sequence of steps before it can exchange data with the network. To be successful, this requires the modem and the WMTS to be configured with various parameters.

These parameters should be defined in a Network RF Plan and a Network IP plan set up by your System Engineer. The three Network Servers (TOD, DHCP, and TFTP) must be installed and operational. The WMTS must be configured with the correct software and an IP address.

The modem's RF parameters must also be correctly configured with the proper software and its RF parameters must be set correctly. When all of this is done, the modem is ready to initialize itself when placed at the customer's premise.

Finally, after initialization, the modem's E1/T1 port must be "bound" (configured to connect) to the correct E1/T1 port on the WMTS. This step may be done last or pre-configured before the modem is at the customer's premise.

The following sections provide an overview of the modem initialization process.

3.1 Modem Initialization Sequence

All modems proceed through the following sequence of steps, each of which is described in more detail below. The completion of these steps establishes connectivity at the DOCSIS and IP layers. Connectivity for additional layers, e.g., E1/T1, may then be established for the V311 and V312 modems. The steps are:

- Power-On Self Test
- Downstream Synchronization
- Obtain Upstream Parameters
- Ranging
- Establish IP Connectivity
- Establish Time of Day
- Transfer Operational Parameters
- Registration
- Baseline Privacy Initialization

3.1.1 Power-On Self Test

The modem performs a self-check to ensure that its hardware is working properly.

3.1.2 Downstream Synchronization

The modem listens for downstream transmissions from the WMTS (which are broadcast at frequent intervals for exactly this purpose) according to its pre-configured or default frequency plan. This may be a single fixed frequency or a sequence of frequencies, depending on the Network RF Plan and/or the internal programming of the modem.

If the modem is programmed for a single fixed downstream frequency and fails to receive an WMTS downstream transmission after three attempts it switches to its additional backup frequencies. See Setting the Modem's Downstream Frequency for a description of how to set these parameters.

Synchronization is obtained when the modem locks onto the WMTS downstream signal and is able to recognize downstream SYNC messages which are periodically broadcast: these are crucial to calculating the time slots available for upstream transmission.

3.1.3 Obtaining Upstream Parameters

The modem must now wait to collect all the Upstream Channel Descriptors (UCDs) for all upstream channels that are connected to the current downstream channel.

3.1.4 Ranging

The modem then sends a "ranging request" message on one or more of the Upstream frequencies, corresponding to a UCD, at different power levels in an attempt to establish communication with the WMTS. Eventually the WMTS decodes a ranging request from the modem and sends a ranging response.

Ranging is now complete. Whenever the modem needs to send MAC layer data for IP to the WMTS it sends a "request" to the WMTS. The WMTS schedules a time slot for the modem and sends a "grant" message back to the modem that contains all the necessary information telling the modem when it can transmit data. A similar method is used to send E1 or T1 data except that the request sets up periodic time slots that the modem uses to transmit data.

3.1.5 Establish IP Connectivity

The modem uses the "request-grant" ("best effort") mechanism to send a standard DHCP request to the Network DHCP server. The server will recognize the modem via its MAC (Ethernet) address and assign it a temporary IP address. This response also contains the default gateway and the IP subnet mask. The IP addresses of the TFTP and ToD servers, and the name of the modem configuration file are also included. The response also includes the local time offset from Universal Coordinated Time (UTC).

Once the modem receives this response it sets its IP address to the designated value and uses the default gateway to talk to devices using its IP stack.

3.1.6 Establish Time of Day

The modem uses the ToD server address(es) just received to send a Time of Day request to the ToD server(s). This is combined with the time offset received in the DHCP response to calculate the current local time. The Time of Day is used by both the modem and the WMTS to timestamp logged events (accessible via the Network Management System).

3.1.7 Transfer Operational Parameters

The modem then requests the TFTP server to send the configuration (or “boot”) file named in step (5) above during the establishment of IP connectivity. If the boot file specifies a different upstream channel and/or downstream frequency, the modem must repeat its initial ranging using this new upstream channel and/or downstream frequency.

3.1.8 Registration

In order to forward traffic into the network the modem must be “registered” with the WMTS. To register, the modem sends the WMTS its class of service (also called QoS for Quality of Service) and any other operational parameters it received in the configuration file as part of a Registration Request. As part of the registration process the modem calculates Message Integrity Check (MIC) values using the parameters specified in its configuration file. This must match the values given for those parameters in the configuration file itself.

3.1.9 Baseline Privacy Initialization (BPI)

If the modem is enabled to run BPI then encryption and decryption keys are established. All further data to or from the modem is now encrypted. The keys have a lifetime and are automatically reset to new values after a specified period which may be set by the operator using the NMS.

NOTE: BPI is required in order to support E1/T1

Chapter 4. Overview of the WMTS and Modem Configuration

This section provides an overview of the steps and tools necessary to configure both sides of the communications link (WMTS and modem) required to add a data modem or the data portion of a new E1/T1 modem to the network. Several different tools and files are used as described below.

1. Make sure that the three required servers are installed and operational: DHCP, ToD and TFTP. For details see Chapter 8, Installing Vyvo Servers for WMTS Operation. The failure of the modem to establish communication with any of these three servers will prevent the modem from completing the registration process.
2. Review the Network IP Plan and use it to assign an IP address to the WMTS, then make it permanent by following the procedure in the section Setting the WMTS IP Address.
3. Verify that the right software version is loaded into the WMTS as described in Appendix B. See the “readme” notes in the distribution software for the version number.
4. Review the RF plan for the network and configure the WMTS upstream and downstream channels accordingly using the procedures in Setting the Upstream Channel. It may not be necessary to configure new upstream and downstream channels when adding a modem; but if required, the Vyvo Configuration tool can be used to modify these parameters.
5. Review the RF Plan to find out which downstream frequency(ies) and upstream channel ID(s) the modem will use to communicate with the WMTS. Use the CMConfiguration Editor (CMConfigFileEditor.exe) to edit the modem configuration file that will be downloaded to the modem during the modem initialization sequence to reflect these choices and other needed parameters (e.g., QoS or Class of Service, Max Number of CPE, BPI Enable/Disable – required for E1/T1, etc.). If you know in advance that this modem will be used for an E1/T1 connection then additional edits may be made at this time as described in Chapter 6, Configuring a T1 Connection.

NOTE: One modem configuration file may be used for several modems if the same upstream channel ID and downstream channel are used by all the modems (i.e., same “profile”); thus, this step may not be required every time a new modem is added to the system.

6. .

NOTE 1: Five T1s per 3.2MHz upstream channel using 16QAM modulation is the hard limit for the current system. Attempting to configure more T1s on an upstream channel than it can support will cause the modem initialization to fail. Consult your system engineer for advice on the maximum number of modems per upstream channel ID.

7. Use the appropriate DHCP tool for your system to bind the modem's MAC address to its IP address and modem configuration file. If **ipLease** is used, edit and compile the CM.SRC file as needed. If Windows 200x Server Edition is used then set these values using the graphical user interface. These procedures are described in section 5.2.2, Windows 200x Server Edition: Modifying the DHCP Options

NOTE: this step is ALWAYS required when adding a modem

8. Use the modem's Telnet server interface to set the modem to a permanent downstream frequency as described in Setting the Modem's Downstream Frequency. Having a permanent (fixed) downstream frequency (or set of frequencies) expedites the modem initialization process since the modem does not have to scan multiple downstream frequencies to find one being transmitted from the WMTS. This does, however, require some pre-planning of the network to pre-allocate different downstream frequencies to specific modems. Ask your System Engineer for details.

NOTE: this step is ALWAYS required when adding a modem with a fixed permanent downstream frequency

9. If a T1 connection is being setup then use the procedures in Configuring a T1 Connection. Configure the WMTS upstream channel ID for E1/T1 operation and bind the WMTS upstream channel ID to the modem E1/T1 interface and to bind the modem's E1/T1 interface to a particular port on the E1/T1 card plugged into the WMTS (use the Vyyo Configuration tool for this procedure.)


NOTE: the Vyyo Configuration tool binding operation will ALWAYS be required when adding a T1 modem. This step can be done after the modem is installed at the customer's site.

10. Install the modem at the customer site and connect it to the RF equipment, provide power to the modem and turn it on.

NOTE: This step is ALWAYS required when adding a modem

11. If the modem is already on and its modem configuration file has been changed (to bind the E1/T1 ports), then the modem must be rebooted; although this happens automatically when the DHCP lease expires, it is more efficient to simply power cycle the modem (unplug and replug the power connector or switch the modem OFF then ON) to restart the modem initialization sequence.
12. If desired, connect the modem's internal Telnet server to a local computer system to observe the process on site and verify that the modem is working correctly.

The POWER and STATUS LEDs should be lit and the LAN & USB, and RF Link LEDs should be flashing (one at a time) with activity:



If the Power, Status, RF Link, and LAN/USB LEDs are lit, then the modem has been successfully installed. If one or all of the lights remains unlit, see Chapter 9, Maintenance and Troubleshooting

Chapter 5. Adding a Modem to the WMTS

*NOTE: These instructions are required for all modems.
If you are adding a T1 modem then you must also
perform the step in Chapter 6, Configuring a T1
Connection to finish the installation.*

Use the instructions in this chapter to setup a data modem or the data portion of an E1/T1 modem and configure the WMTS to communicate with it over IP.

This chapter covers the following topics:

1. Section 5.1 Editing the Modem Configuration File describes the steps necessary to setup the modem configuration file.
2. Section [5.2 DHCP Settings for the Modem](#) explains how to set (bind) the modem's IP address and configuration file using either ipLease or the Windows 200x Server Edition DHCP Server. explains how to set (bind) the modem's IP address and configuration file using either ipLease or the Windows 200x Server Edition DHCP Server.

3. DHCP Settings for the ModemSection [5.3 Configuring the WMTS](#) describes how to configure the WMTS upstream, downstream and QoS parameters. This is done using the Vyyo Configuration Tool. Instructions for performing these changes are shown in [Configuring the WMTS](#).
4. Section [5.4 Setting the Modem's Downstream Frequency](#) describes how to set the modem downstream initial receive frequency via the modem's internal Telnet server.
5. Section [5.5 Verifying the Modem Downstream and Upstream Status](#) describes how to use the modem's internal Telnet server to view the modem's downstream and upstream status (current values) and verify correct operation.

5.1 Editing the Modem Configuration File

You will need to edit the modem configuration file to set the WMTS downstream frequency, upstream channel ID, concatenation and fragmentation capabilities, and QoS. This file will be downloaded to the modem during its initialization sequence.

NOTE: *A separate modem configuration file is required for each set of upstream and downstream channels. Any modem may use any configuration file and the same file may be used by many modems; typically only five T1 modems are assigned to a single 3.2MHz upstream channel.*

5.1.1 Setting the Upstream Channel

Open the **CMConfigFileEditor** to edit the modem configuration file to set the Downstream Frequency and Upstream Channel ID.

Note: *If using ipLease, the modem configuration file is bound to the modem's MAC address in the CM.SRC file. If using Windows 200x Server Edition bring up the DHCP Administrative Tool to find the configuration file to the mode:*

*Programs->Administrative Tools->DHCP
For more detailed information, see section 5.2.2,
Windows 200x Server Edition: Modifying the DHCP
Options*

From the main screen shown below select "General Parameters" and then choose "Upstream Channel ID".

System Configuration Guide

Right-click on “Upstream Channel ID” and select “MODIFY” to display the popup window in which you may set the value of the Upstream Channel ID.

Note: *The detailed parameters for each upstream channel must be set in accordance (see [Setting the Upstream Channel](#)) with the overall Network RF Plan – contact your system engineer for assistance. The Channel ID is the identifier for the physical RF port on the RF cards plugged into the rear of the WMTS. The ports are numbered as follows:*

Channel ID = card slot number + port number

*Where the card slot number is zero for the leftmost upstream card (as viewed from the front of the WMTS) and increases by the ifIndex of the card times eight for each additional card. The if index of the card can be found in the ifTable. **Please contact Vyyo for the exact details of this configuration.** Typically, the ifIndex increases from left to right by 1 for each card, from 0 to n, where n is the rightmost card. The ports are numbered from bottom to top on each card starting with one. Thus, the first card has ports numbered from 1 to 6 (since the Hex upstream card only has six ports even though a maximum of 8 are allowed) and the second card has its ports numbered from 9 to 14, etc. Contact Vyyo for Details.*

NOTE 2: See [Setting the Upstream Channel](#) to set the receive frequency of an upstream channel.

System Configuration Guide




Figure 5-1: Setting Upstream Channel ID

5.1.2 Setting the Downstream Frequency

In the following example, the Downstream Frequency is changed to 743 MHz.

1. From the main screen shown below select “General Parameters” and then choose “Downstream Frequency”.
6. Right-click on “Downstream Frequency” and select “MODIFY” to display the popup window in which you may set the value of the downstream frequency in Hertz (note the six zeroes).

NOTE: This value will be specified by your system engineer.




Figure 5-2 Setting Downstream Frequency

5.1.3 Setting Concatenation and Fragmentation Capabilities

1. Select “Modem Capabilities” and enable “Concatenation” and “Fragmentation” by setting them to “1” (select each one then right-click to view the “Set Value” dialog box, enter the value “1” then click “OK”).

NOTE: These should always be used unless specified otherwise by your system engineer.




Figure 5-3. Setting the Concatenation Value




Figure 5-4. Setting the Fragmentation Value

5.1.4 Setting Upstream QoS (Class of Service) for IP Data

1. Select “Class of Service Parameters”
2. Right-click on “Maximum Upstream Rate” to display a selection of QoS profiles.
3. Choose the profile that is appropriate for the installation being done. Your system engineer can provide assistance based on the Network RF & IP Plan.
4. Select a profile in the left side of the popup window to display its corresponding parameters on the right side.




Figure 5-5. Setting Upstream QoS

5.1.5 Setting Additional Downstream and Upstream Channels

Use the “Vendor Specific Parameters” option to set additional downstream frequencies and upstream channels. Your system engineer should tell you if this is necessary. First enter the Frequency of the Additional Downstream Channel in Hertz and then enter the associated upstream channel ID (ID of additional Upstream channels). To add more downstream and upstream frequencies right click on the “Vendor Specific Parameters” option and select “Duplicate” to bring up another screen and enter the desired values.

A Downstream Scan Plan value of ‘9’ indicates that the downstream channel is set to a permanent fixed frequency (the advantage is that the modem initializes faster and doesn’t interfere unnecessarily with other traffic on the network).




Figure 5-6: Using Vendor Specific Parameters to set additional DS/US pairs

5.1.6 Setting the Maximum Number of CPEs

It is advisable to set the maximum number of CPEs at this time by selecting and entering the desired value on the following screen:




Figure 5-7: Setting the maximum number of CPEs

5.2 DHCP Settings for the Modem

The DHCP Server provides the IP address for the modem and also specifies which modem configuration file will be downloaded to the modem. In the following two sections, instructions are provided for setting up two different DHCP Servers: the ipLease DHCP Server and the Windows 200x Server Edition DHCP Server. Either of these (or any other) DHCP server may be used (but not multiple ones at the same time).

5.2.1 IpLease DHCP Server: Editing and running the CM.SRC File

Note: This section applies only if your configuration uses ipLease™ (purchased separately) as the DHCP server.

Bind the modem MAC Address to its IP Address and modem configuration file by editing the CM.SRC file.

1. Locate the **CM.SRC** file – it is usually in the DHCP tool directory. In this example we are using ipLease as our DHCP server.
2. Open the **CM.SRC** file using any text editor.

Tip: Use Windows Notepad to edit this file.





Figure 5-8. Location of CM.SRC file

System Configuration Guide

3. This section of CM.SRC shows IP addresses of all the servers and their associated parameters. See the comments on each line of the file shown for details. Your system engineer can tell you how to configure these addresses.



```
cm.src - Notepad
File Edit Format Help
;
;
; -----
; AddressGroups section.
;
[AddressGroups]
ServerLocal=                */your server configuration*/
;Group1=

[ServerLocal]
AddressBase=10.10.10.0      */the server network identification*/
SubnetMask=255.255.255.0    */ the server subnet mask*/
HostNameMethod=Normal
RangeInclude1=1 240        */how many consecutive IP address the server will assign starting from 10.10.10.1*/
RangeExclude1=1 2          */how many consecutive IP address the server will exclude starting from 10.10.10.1 and*/

OptGroup=MinimalOpts

; Note: *all* IP addresses that the server will manage must be
; included in some address group, like [ServerLocal]. This rule
; means that you must include IP addresses intended for *static*
; leases (permanent associations of machines with their IP
; addresses) in an address group here. You will indicate the
; static nature of the lease in the per-host option groups
; below.
;
; -----
; Address-related option groups.
;
[MinimalOpts]
oDomainName=vyvo.co.il     */the server domain name*/
oRouter=10.10.10.1          */the modem router or gateway IP address*/
oDNSServer=194.90.1.5       */the modem DNS server*/
oAddrLeaseTime=720000       */the DHCP server lease time in seconds*/
oSubnetMask=255.255.255.0   */the modem subnet mask*/
oTimeOffset=7200
oTimeServer=10.10.10.1      */the modem time server IP address*/
oLogServer=10.10.10.201     */the modem log server*/
bpNextServer=10.10.10.1     */the modem TFTP server IP address*/
;bpBootFile=mfc1_ipf.cfg

; 36000 seconds equates to ten hours. If you are managing
; leases for many "floating" notebook computers, please
; consider reducing the lease time to an hour or two. It
; could save you some trouble explaining how to release an
; old lease on another network to your colleagues.
;
; -----
;
```

Figure 5-9: Server Configuration Info on CM.SRC file

System Configuration Guide

4. In the [Hosts] section of CM.SRC shown below, four modems are defined. You may add additional modems here. If they are not defined here they will be ignored in the next section.




Figure 5-10. CM.SRC File Format

5. Add the configuration parameters for each modem as shown below. Note that even though each modem has a unique bpBootFile filename this is not typical. This file is the modem's configuration file. The same modem configuration file may be used for many modems if they use the same upstream and downstream channels.

NOTE: a line that starts with a semicolon ";" is interpreted as a comment and therefore is ignored by the compiler

System Configuration Guide




Figure 5-11. Defining and Naming Installed Modems

NOTE: This file (CM.SRC) must be compiled by executing the command "dhcpgen cm" from the directory in which the file is located. Before compilation, the DHCP Server must be shut down. After compilation the command "dhcpsvr" must be executed from the same directory to read the compiled files and restart the ipLease DHCP server.

6. If the ipLease DHCP server is running it must be shutdown in order to reconfigure the IP addresses given in the CM.SRC file. Simply click on the "SHUTDOWN" button in the upper right pane of the ipLease application window.

System Configuration Guide





Figure 5-12: DHCP Server Shutdown in ipLease™

System Configuration Guide

- Now change directories to the ipLease directory (in a DOS window) and type "dhcpgen cm" to generate the machine-readable files for the ipLease DHCP server. The output should indicate "successful" as shown below. If not, check to make sure you have shutdown the iplease server or that you have not mistyped something in the CM.SRC file.



```
C:\WINNT\system32\cmd.exe
C:\Uyyo>cd tools
C:\Uyyo\Tools>cd servers
C:\Uyyo\Tools\Servers>cd iplease
C:\Uyyo\Tools\Servers\iplease>dhcpgen cm
ipLease(TM) DHCP Gen Version 1.30 started at 10/23/2004 9:05:04
Copyright (C) 1999 Billiter Consultants. All rights reserved.
This version supports a maximum of 1024 leases.
DHCP Gen serial E94099E13AD216B2
Default lease time = 5432
HRDefaults option group created
AddressGroup ServerLocal created on network number 10.10.10.0
with 238 addresses.
Now sorting the lease pool
Host option group lab1 created for Chaddr 00103D1283EB000000000000000000000
as a static (manual) lease for IP address 10.10.10.10
Host option group lab2 created for Chaddr 00103D12023300000000000000000000
as a static (manual) lease for IP address 10.10.10.11
Lease data base generation was successful.
238 addresses were created.
Of these, the count dedicated for static leases is 2.
C:\Uyyo\Tools\Servers\iplease>
```

- Restart the ipLease server. After compilation the command "dhcpsvr" must be executed from the same directory to read the compiled files and restart the ipLease DHCP server.

5.2.2 Windows 200x Server Edition: Modifying the DHCP Options

Note: This section applies only if your configuration uses Microsoft Windows 200x Server Edition as the DHCP server.

Bind the modem MAC Address to its IP Address and modem configuration file by entering the appropriate information in popup windows. First bring up the DHCP Administrative Tool by clicking on the "Start" button on the main windows screen then choosing "Administrative Tools" and finally "DHCP". See the following screen shots:

- Locate and open the DHCP program by using:
Start->Programs->Administrative Tools->DHCP

The DHCP window should open on the desktop as shown in Figure 5-14:
Expand "Reservations"

System Configuration Guide




Figure 5-13: Navigate to the DHCP program

2. Expand the tree in the left window pane and expand “Reservations” to view all the modems to which DHCP is leasing IP addresses

System Configuration Guide




Figure 5-14: Expand “Reservations”

3. Now click “New Reservation” on the “Action” menu (or right-click on “Reservations” and select “New Reservation”)




Figure 5-15: Make a “New Reservation” using DHCP

System Configuration Guide

4. Enter the required information (see your system engineer for details) and click the “Add” button.

NOTE: Make sure to select the “DHCP only” radio button under “Supported Types”.




Figure 5-16: Enter the information for the new reservation

System Configuration Guide

- Now select the new reservation and right-click on the newly added modem then select “Configure Options” to choose the modem configuration file that will be downloaded to this modem. Observe that five Options are shown in the right pane of the main window. These are the default values.:




Figure 5-17: Navigate to the “Configure Options” action

System Configuration Guide

6. Select the “General” tab in the popup window, scroll down to item “067” and check (and select) the “Bootfile Name” checkbox to enter or change the “boot” or modem configuration file name.

NOTE: Any of the other options may be changed using this same procedure. These values must match the physical setup of the network (as per the Network IP and Network RF plans) to make the system work. If this DHCP server is already in operation the default values should be correct.




Figure 5-18: Enter the “boot” file name

System Configuration Guide

TIP: You may verify that the modem properties have been set correctly. Select the modem and right-click to display the action popup window; then select “Properties” to display and allow you to verify the modem information entered previously.




Figure 5-19: Navigate to the Properties display for the selected modem

System Configuration Guide

Tip: The modem information is displayed in this popup window.




Figure 5-20: View the Properties for the selected modem

5.3 Configuring the WMTS

NOTE: Before you can perform this procedure you must have previously edited the `regtree.txt` file, compiled it and downloaded it to the WMTS to set its IP address. See [Chapter 7. Setting the WMTS IP Address](#).

This section assumes that you have previously installed NMS Version 7. See [Installing and Uninstalling the NMS](#) for brief instructions.

The upstream and downstream channels of the WMTS must be configured before a modem can communicate with the WMTS. This is done using the Vyvo Configuration Tool. Before proceeding, launch the Vyvo Configuration Tool as described in [Launching the Vyvo Configuration Tool](#).

5.3.1 Setting the WMTS Upstream Parameters

1. Expand the WMTS tree in the left pane of the Vyvo Configuration Tool and select the Upstream Channel ID you wish to configure using the mouse. The Channel ID refers to the physical port on the upstream RF card that you are configuring. This connection is described in [WMTS US Port Mapping](#). In this example upstream channel 1 is selected and all of its parameters are displayed in the right pane of the window.

You may change the frequency the modem is told by the WMTS to transmit on (labeled “Tx Frequency”), the receive frequency that the upstream RF port expects to receive the modem’s signal on (this is labeled “Rx frequency”), its bandwidth, modulation, and the associated downstream channels, antenna diversity and admin status as needed.

These parameters are transmitted by the WMTS as part of the upstream channel descriptor (UCD) sent during the DOCSIS modem initialization process. These parameters should be determined by the system engineer responsible for the RF planning and are outside the scope of this manual.

System Configuration Guide




Figure 5-21: Selecting and Setting Upstream Channel Parameters

NOTE: For Data Service Type, “Best effort channel” or “CIR channel” are typically used for a data-only modem. An “E1 channel” must be used when the modem supports E1/T1 connections and data. These settings correspond to the desired SLA (Service Level Agreement.)

The “Tx backoff” settings control the scheduling algorithms used in the upstream channel. The default values should be used unless your system engineer has indicated otherwise.

Ensure that the “Optimize channel parameters” box is checked. This causes the WMTS to maximize the efficiency of the channel usage for the different types of modems assigned to it.

System Configuration Guide

- Click on the Update button at the bottom left of the screen to save the new settings. Click "OK" when the following confirmation popup window appears.




Figure 5-22: Confirm the Update

- You have now completed configuring the upstream channel. For a summary of all of the upstream channels click on the "Upstream" item in the left pane of the window.




Figure 5-23: Viewing the WMTS Upstream Channels Summary

5.3.2 Setting the WMTS Downstream Parameters

1. Select the WMTS Downstream Channel you wish to configure from the left side of the window. In this example downstream channel 1 is selected and all of its parameters are displayed in the right pane of the window.

Bandwidth, modulation, and other parameters can be changed. Typically the default values should be used with “Optimize channel parameters” unless your system engineer indicates otherwise.

These parameters should be determined by the system engineer responsible for the RF planning and are outside the scope of this manual.




Figure 5-24: Select the downstream channel and change its parameters

System Configuration Guide

- To permanently save the configuration to the WMTS click on the “Update” button. Press the “OK” button on the popup window to confirm the update.




Figure 5-25: Confirm the Update

- You have now completed configuring the downstream channel. For a summary of all the downstream channels click on the “Downstream” item in the left pane of the window.




Figure 5-26: Viewing the WMTS Downstream Channels Summary

5.4 Setting the Modem's Downstream Frequency

This section provides details on how to set the downstream frequency that the modem listens on to begin its initialization sequence. Setting this value greatly reduces the time it takes for a modem to complete its initialization sequence.

NOTE: the downstream frequency that is set using this technique will not be saved in the modem until the modem completes registration.

1. Connect a computer to the RJ45 modem connector using a standard RJ45 patch cable.
2. Make sure your computer's IP address is set to 192.168.100.xxx, where "xxx" is any value from 2 to 254. The subnet mask should be 255.255.255.0. You may use any utility software on your computer that allows you to set these values.
3. All modems include a Telnet server with a fixed IP address of 192.168.100.1. Follow the screens below to set the modem Downstream Frequency and view the Downstream and Upstream settings.

The modem Telnet server has multiple levels of access privileges:

User – the standard level which permits viewing information

Operator – permits changing the downstream frequency

Note: *The modem will accept typed settings while simultaneously displaying and scrolling through feedback information or messages. This behavior does not affect setup. At present there is no procedure to turn off the streaming messages issued by the modem.*

4. Enter the password (obtained from your system engineer or a Vyvo representative) on this screen.

System Configuration Guide




Figure 5-27: Log In to the Vyvo WMU Telnet Server

System Configuration Guide

5. This screen will be displayed after the password is correctly entered:




Figure 5-28: Successful Telnet Login

System Configuration Guide

6. Type “su operator”, then press return. Now enter the operator’s password (obtain this from your system engineer or a Vyvo representative) to access the DOCSIS control commands.

Note: Return to user mode from operator mode at any time by typing “su user” – no password is required to return to user mode.





Figure 5-29: Switching to the Operator's Permission Level

System Configuration Guide

7. Change to the DOCSIS Control subdirectory by typing “cd docsis”:



```
v280 - HyperTerminal
File Edit View Call Transfer Help

login: vyvo
password:

WARNING: It is possible to crash the system, cause a deadlock,
or cause the connection to be shut down via Telnet.
Run commands with caution!

Console now switched to Telnet session...

CM> su operator
Please Enter Password: *****

Set 'operator' access rights success.
CM> cd docsis


Instance: Console Thread (0x8073eac4)
Active Command Table: CM DOCSIS Control Thread Commands (docsis_ctl)
CM-App -> docsis_ctl
CM/DocsisCtl>
```

Figure 5-30: The “cd docsis” Command

System Configuration Guide

8. Type "goto_ds xxxxxxxx" to set the Downstream Frequency, where "xxxxxxx" is the frequency in Hertz.

NOTE: Your system engineer should provide you with this value. This will now be the permanent fixed frequency at which the modem will listen for a broadcast from the WMTS. After a maximum of 30 seconds, the modem LEDs should light up and remain lit. This indicates that the modem has locked on to the Downstream channel, is operating on the appropriate Upstream channel, and is authorized for operation on the WMTS.



```
v280 - HyperTerminal
File Edit View Call Transfer Help

CM> cd docsis

Instance: Console Thread (0x8073eac4)
Active Command Table: CM DOCSIS Control Thread Commands (docsis_ctl)
CM-App -> docsis_ctl
CM/DocsisCtl> goto_ds 743000000

Instance: DOCSIS Control Thread (0x8054ee6c)
Moving to Downstream Frequency 743000000 Hz.
BcmCmDocsisStatusEventCodes::kCmIsNotOperational
BcmCmDocsisStatusEventCodes::kCmIsNotOperational
VendorCtrl: HFC down
0x000cef5e ['CmBpiManagerThd' id=0x807c3340] BcmDocsisCmHalIf::SelectActiveBpiKey: (DOCSIS CableModem HalIf) WARNING - BPI is now disabled!
0x000cef5e ['IGMP Thread' id=0x807baad0] BcmIgmpThread::Stopping Igmp Thread... (IGMP Thread)
CamDeleteAddress: Deleted address from cam segment 0

CM/DocsisCtl> Deleting DOCSIS 1.0 CoS Settings for SID 0x202
0x000cf026 ['CmDocsisCtlThread' id=0x807bed50] BcmDocsisCmHalIf::DeleteAllServiceFlows: (DOCSIS CableModem HalIf) Deleting all Upstream and Downstream ServiceFlows, along with associated Classifiers and PHS rules...
Stopping DHCP/ToD/TFTP (client requested)...
ToD successfully acquired; we will update ToD in 21600 seconds...
The ToD thread was stopped.
DHCPc: Releasing the lease with client id htype=1, value=00:10:3d:13:8c:20


Connected 0:03:14 Auto detect TCP/IP SCROLL CAPS NUM Capture Print echo
```

Figure 5-31: Setting the Frequency to 743 Mhz (or 743000000, i.e., six zeroes)

System Configuration Guide

- To view the “operator” commands type “?”. The following figure shows the “operator” commands.

*NOTE: to get help on a particular command type “help
<command>”*



The screenshot shows a HyperTerminal window titled "v280 - HyperTerminal". The menu bar includes File, Edit, View, Call, Transfer, and Help. The toolbar contains icons for file operations and terminal functions. The main text area displays the following output:

```
Instance: Console Thread (0x8073eac4)
Active Command Table: CM DOCSIS Control Thread Commands (docsis_ctl)
CM-App -> docsis_ctl
CM/DocsisCtl> ?

Instance: Console Thread (0x8073eac4)

!           ?           REM           cd           dir
exit        find_command help         history     instances
ls          man         pwd         sleep       su
system_time usage

-----
bpiShow     dload         dsdiag      goto_ds      igmpShow
ip_initialize ip_show       log_messages modem_caps
rate_shaping_enable rng_rsp      scan_stop   showFlows
state        stop_download ucdShow     ucddiag      usdiag
-----
[dsxTest]

CM/DocsisCtl>
```


The status bar at the bottom shows "Connected 0:20:23" and several buttons: Auto detect, TCP/IP, SCROLL, CAPS, NUM, Capture, and Print echo.

Figure 5-32: Executing the “?” command to view the Operator commands

5.5 Verifying the Modem Downstream and Upstream Status

1. View the downstream status after the modem has successfully completed registration by typing “dsdiag” to verify that the change took effect and the modem is operating correctly: “QAM = LOCKED” and “FEC = LOCKED” should appear as the last two lines. You must have “operator” access rights to do this.

NOTE: this will only happen if the modem is in a place where it can establish RF connectivity to the WMTS, e.g., hooked up to the cable plant.



```
CM/DocsisCtl> dsdiag

Instance: DOCSIS Control Thread (0x8054ee6c)

*****
DOWNSTREAM STATUS
*****
Tuner Frequency = 743000000 Hz
Carrier Offset = -25 KHz
Symbol rate = 5056941 sym/sec
SNR = 38 dB
QAM Mode = QAM64
Tuner AGC = 0x973f2e20
IF AGC = 0x38000000
Power Level = 13 dBmV
QAM = LOCKED
FEC = LOCKED
*****

CM/DocsisCtl>
```

Figure 5-33: Viewing the Modem Downstream Status

System Configuration Guide

2. View the Upstream Status after the modem has successfully completed registration by typing “usdiag” to verify that the modem is operating correctly. The parameters should be stable. You must have “operator” access to do this.




Figure 5-34: Viewing the Modem Upstream Status

The modem has now established IP connectivity with the WMTS.

5.6 Using an HTTP Connection to View Modem Operation

You may also view this information using an HTTP browser such as Internet Explorer. All modems include an HTTP server at the same address as the Telnet server. If the modem does not yet have an IP address assigned and operating (i.e., completed registration), set your browser to browse the URL <http://192.168.100.1/> to get the status information.

Note: In order to use this facility, you must be connected to the same LAN to which the modem is connected. This would be 192.168.0.xxx with a subnet mask of 255.255.255.0 in the initial case.

5.6.1 Viewing the internal modem HTML pages:

1. Open the Web Browser application that is installed on your system.




Figure 5-35: Opening a Browser Window to view modem activity

11. Type **http://192.168.100.1/** into the Address field at the top of the Browser window and press "Enter".




Figure 5-36: Entering the modem IP address into the Browser Window

System Configuration Guide

12. Obtain the Operator user name and password from your System Administrator or an authorized Vyvo representative. Enter the user name and password in the appropriate fields, and click the **OK** button. The **Vyvo Connection** page opens.



Figure 5-37: Entering the modem user name and password

System Configuration Guide

13. Each informational page consists of two sections: A **Menu** box at the left, which enables you to navigate between pages, and a **Data** area at the right, which shows information specific to the system.

The screenshot shows a web browser window with the address <http://192.168.100.1/RgConnect.asp>. The page features the Vyyo logo and a left-hand menu with options: Status (highlighted), Software, Connection, and Security. The main content area is titled 'Status' and contains a 'Connection' section with the text: 'This page displays information on the status of WAN connection.'

Startup Procedure

Procedure	Status	Comment
Downstream Channel	Locked	
Connectivity State	OK	Operational
Boot State	OK	Operational
Configuration File		
Security	Enabled BPI	

Downstream Channel

Lock Status	Locked	Modulation	QAM64
Channel ID	1	Symbol rate	5056941
Acquire Downstream Frequency	N/A	Downstream Power	-2.5 dBmV
SNR	34.2 dB		

Upstream Channel

Lock Status	Locked	Modulation	QAM16
Channel ID	1	Symbol rate	2560 Ksym/sec
Upstream Frequency	N/A	Upstream Power	55.3 dBmV

CM IP Address Duration Expires

---	D: -- H: -- M: -- S: --	---
-----	-------------------------	-----

Current System Time: WED DEC 24 15:16:47 2003

5.6.2 Viewing the Connection Page

To view the Connection page click the “Connection” option on the Menu box.




Figure 5-38: Selecting the Browser Connection option

System Configuration Guide

The browser displays the Connection page which has five areas of information:

- Startup Procedure
- Downstream Channel
- Upstream Channel
- Assigned IP Address of the Modem
- Current System Time from the ToD Server.

Startup Procedure			
Procedure	Status	Comment	
Downstream Channel		Locked	
Connectivity State	OK	Operational	
Boot State	OK	Operational	
Configuration File			
Security	Enabled	BPI	
Downstream Channel			
Lock Status	Locked	Modulation	QAM64
Channel ID	1	Symbol rate	5056941
Acquire Downstream Frequency	N/A	Downstream Power	-2.5 dBmV
SNR	34.2 dB		
Upstream Channel			
Lock Status	Locked	Modulation	QAM16
Channel ID	1	Symbol rate	2560 Ksym/sec
Upstream Frequency	N/A	Upstream Power	55.3 dBmV
CM IP Address	Duration	Expires	
---	D: -- H: -- M: -- S: --	----- --(--)-----	
Current System Time: WED DEC 24 15:16:47 2003			

Figure 5-39: Viewing the Browser Connection page

5.6.3 Viewing the Software Page

To view the Software page click the **Software** option on the Menu box.




Figure 5-40: Selecting the Browser Software option

System Configuration Guide

The Software page displays modem Information and Status data.

Information	
Standard Specification Compliant	DOCSIS 1.0/1.1
Hardware Version	6048
Software Version	2.9.1v1.3.6
Cable Modem MAC Address	00:10:3d:13:7d:04
Cable Modem Serial Number	32002
CM certificate	Not Installed
Status	
System Up Time	0 days 00h:00m:48s
Network Access	Allowed
Cable Modem IP Address	10.10.10.1

Figure 5-41: Viewing the Browser Software page

5.6.4 Viewing the Security Page

To view the Security page click the **Security** option on the Menu box.





Figure 5-42: Selecting the Browser Status option

The browser displays the **Security** page.

A screenshot of the Security configuration page. It features two text input fields for 'Password' and 'Re-Enter Password', both containing masked characters. Below these is a radio button group for 'Restore Factory Defaults (user name and password)' with 'Yes' and 'No' options; the 'No' option is selected. An 'Apply' button is located at the bottom center of the form.

You use the Security page if you wish to change your login password. To change your Password, enter a new Password in the **Password** field, and enter it again for verification in the **Re-Enter Password** field.

If you want to return to the factory default password, select the **Yes** option and click **Apply**.

Chapter 6. Configuring a T1 Connection

NOTE: *the data connection for the E1/T1 modem must be setup as previously described in Chapter 5, Adding a Modem to the WMTS*

Three separate tools are necessary to configure a T1 connection:

The **CMConfigFileEditor** is used to set the modem QoS (also referred to as Class of Service) in the modem configuration file downloaded during the modem initialization phase.

The **NMS** (Castlerock SNMPc) tool is the Network Management System used to monitor and reconfigure the network on an ongoing basis. It accesses a MIB database stored in the WMTS as well as a local version residing in the controlling computer. It is used here to set specific WMTS parameters by launching the Vyyo Configuration tool.

The Java™-based **Vyyo Configuration Tool** is necessary to set the E1/T1 parameters of the WMTS when adding a new modem to the network.

These tools may be used as directed in any order. They are described in the following sequence:

1. The **CMConfigFileEditor** is used to modify the modem configuration file for T1 operation by adding a second Class of Service (the first Class of Service was used for the data only connection). Instructions are also given for setting/checking the upstream and downstream parameters (which may have been previously set when configuring the modem for data only operation).
2. The **NMS** tool is used to launch the Vyyo Configuration Tool to set the WMTS upstream parameters, specifically the QoS (Quality of Service) which is another name for the Class of Service. For older systems, Instructions for using the Synoptics interface are given in Chapter 10, **Error! Reference source not found..**
3. The **Vyyo Configuration Tool** is required to bind the T1 ports of the modem to the T1 ports of the WMTS.

6.1 Configure the Modem for T1 Operation

In this section instructions are provided for using the **CMConfigFile Editor** to edit the modem configuration file which will be downloaded to the modem. When the edits on the following pages are complete, copy or move the modem configuration file to the directory being used by the TFTP Server (usually this will be something like "C:\vyyo\mic"). You may also save it directly to the TFTP directory using the "Save" menu option of the **CMConfigFile Editor**.

NOTE: This file name must be bound to this modem's MAC address by using the appropriate DHCP tool for the particular system being used (Edit the CM.SRC file if ipLease is being used. If the Windows 200x Server Edition DHCP Administrative tool is being used then set the "bpBootfile" name to the name of the modem's configuration file).

1. Set the Downstream Frequency by selecting "General Parameters" then double clicking on the "Downstream Frequency (Hz)" parameter as shown. This is the frequency which the modem will use to receive (downstream) transmissions from the WMTS. This procedure for configuring the downstream channels is described in [Setting the Downstream Frequency](#).




Figure 6-1: Set the Downstream Frequency Value

- Set the upstream channel ID using the same procedure. This is the channel ID the modem will use to transmit upstream data to the WMTS. The channel ID parameters are sent by the WMTS when it broadcasts UCDs during the Obtaining Upstream Parameters phase (immediately after the Downstream Synchronization phase) of the modem initialization process. This procedure for configuring the downstream channels is described in [Setting the WMTS Upstream Parameters](#).




Figure 6-2. Set the Upstream Channel ID

System Configuration Guide

5. Create a second Class of Service (aka. QoS or Service ID). Select and right-click “Class of Service”, then select the “Duplicate” option. This is necessary to add the “Voice” (or “WAN”) service for the T1 connection.

NOTE: the first Class of Service was created previously for the data only connection. This second Class of Service is specifically for the T1 connection so make sure it is setup that way. The same upstream channel is used for both.




Figure 6-3. Duplicating the QoS Value

System Configuration Guide

6. Observe that a second Class of Service has been added in the left column of the window.
7. Select this second Class of Service, then right-click on the Maximum Upstream Rate parameter and select “Modify” from the popup menu.




Figure 6-4. Modifying the Upstream Bit Rate Value

System Configuration Guide

- Now select “WAN Service/2048k” from the “Parameter” pane of the popup window.




Figure 6-5. Choosing an Upstream Bit Rate Parameter

- The corresponding parameters will appear on the right side of the popup window.

System Configuration Guide

- Now select “WAN Service/2048K” in the left pane of the popup window and then Click the “OK” button.




Figure 6-6. Choose Profile Setting

- The display will return to the main window showing the new values set above, as shown in Figure 6-7.




Figure 6-7.

12. Select “Modem Capabilities” and turn on “Concatenation” and “Fragmentation” by setting them to “1” (select each one then right-click to popup the “Set Value” window) and clicking the “OK” button.




Figure 6-8. Setting Concatenation Value




Figure 6-9. Setting Fragmentation Value

Vyvo Installation Guide

- The display will return to the main window. The modem configuration file is now configured for T1 operation. You should save this file. This filename will be bound to the modem MAC address using the DHCP Server tool as described in [IpLease DHCP Server: Editing and running the CM.SRC File](#). The same modem configuration file may be used for several modems provided the Network RF Plan allows for this; see your system engineer for details.




Figure 6-10. Main WMU Configuration File Editor Window

6.2 Adding the T1 modem to the WMTS T1 Interface and Assign Port(s)

NOTE: The WMTS Upstream and Downstream parameters must be configured prior to performing this procedure. In particular the Upstream “Voice Service Type” must be set to “WAN” for an E1/T1 channel. See [Configuring a T1 Connection](#). This is done using the Vyvo Configuration Tool. Before proceeding, launch the Vyvo Configuration Tool as described in [Launching the Vyvo Configuration Tool](#).

1. Expand the WMTS tree in the left pane of the main Vyvo Configuration Tool window. Then expand “Modems” to obtain a more informative version of the window. If the modem is already connected, the tool will detect it automatically and it will appear in the list under “Modems->E1/T1” or “Modems->Data” by its MAC address; in this case skip to Step 4. Otherwise you must add the modem to the list by continuing this procedure.




Figure 6-11: Expand the WMTS Tree

2. Select the “Insert” menu option and choose “Modem”




Figure 6-12: Insert Modem

3. A popup window will appear to allow you to enter the modem type. From the pulldown menu select “E1/T1 Modem”.





Figure 6-13: Select E1/T1 Modem

4. Confirm your selection




Figure 6-14: Confirm modem selection

Vyyo Installation Guide

5. A new modem icon will appear on the WMTS tree window pane. Enter the last three bytes of the Vyyo modem MAC address and press the “Update” button then press “OK” on the popup window which confirms the “success” of the update.

Note: The first three bytes of the Vyyo MAC address (the vendor ID) are displayed both in the navigation tree on the left and in the data entry window on the right.




Figure 6-15: Vyyo Modem Configuration Information




Figure 6-16: Update Success Confirmation

Vyyo Installation Guide

6. Enter the desired modem parameters and add the E1/T1 configuration for the modem by clicking on the “Add E1/T1 Link” button. You may cross connect an E1/T1 modem to another E1/T1 modem – see [Appendix E: Vyyo Configuration Tool – Additional Functions](#) for this procedure.

NOTE: Do this process once for the V311 modems and twice for the V312 modems (the latter have two active E1/T1 ports).

NOTE: the modem does not need to be active on the network to perform this procedure as this is strictly a configuration procedure. However, the modem will not appear under its IP address unless it is already on the network as a data modem, i.e., the DOCSIS IP portion of the initialization has been successful.




Figure 6-17: Adding a new E1/T1 configuration for a modem

Vyvo Installation Guide

- When this screen appears, select the desired port on the WMTS E1/T1 interface card using the drop-down menu. This binds the T1 port on the modem to its corresponding T1 port on the WMTS E1/T1 interface card (inserted into the rear of the WMTS chassis).

Other parameters may be changed from the defaults shown in this screenshot to create a “fractional T1” connection: the Framing parameter must be set to ESF Framing or D4 Framing, and then you may set the desired Time Slots range. Make sure that both the WMTS and Modem port status are enabled.

The screenshot shows the 'Vyvo Configuration' application window. On the left is a tree view with folders: Vyvo, XMTS_10.10.10.202, Modems, DATA, E1/T1, POTS, Interfaces, Channels, and General. Under 'E1/T1', there are three entries: '10.10.10.4 (00:10:3D:14:3E:A0)', '10.10.10.5 (00:10:3D:14:3E:BC)', and 'Port 1 (00:10:3D:12:7D:49)'. The 'Port 1' entry is selected. The main area is titled 'T1 Connection Configuration' and is divided into two panels: 'XMTS Port' and 'Modem Port'. The 'XMTS Port' panel has fields for IP Address (10.10.10.202), Port Number (1), Status (Enabled), Distance (0), Haul (short), LBO (0 dB), Loop Back (No Loop), Coding (B8ZS), and checkboxes for Grooming and Enable Traps. The 'Modem Port' panel has fields for MAC Address (00:10:3D:12:7D:49), Port Number (1), Status (Enabled), Distance (0), Haul (short), LBO (0 dB), Loop Back (Unknown), Coding (B8ZS), Connector (RJ48), and a checked 'Enable Traps' checkbox. Below these panels are 'Framing' (Unframed), 'Signaling' (None), 'Signaling Time Slot' (24), and 'Time Slots' (1 to 24). At the bottom is a 'Compression' dropdown (None) and a checked 'Framing Bit' checkbox. A table at the bottom shows 'XMTS' and 'Modem' rows with columns for time slots 1 through 24, all containing a checkmark. At the bottom of the window are 'Update', 'Refresh', and 'Line Status' buttons. Annotations include: 'Select the desired WMTS port using the pull down menu' pointing to the Port Number dropdown; 'Select the port – all assigned ports will appear (only 1 in this example)' pointing to the tree view; 'Click the “Update” button when done' pointing to the Update button; and 'To make this a fractional T1 connection select the specific T1 slots you wish to use by setting the Framing parameter and choosing the Time slot range' pointing to the Framing and Time Slots settings.

Select the desired WMTS port using the pull down menu

Select the port – all assigned ports will appear (only 1 in this example)

Click the “Update” button when done

To make this a fractional T1 connection select the specific T1 slots you wish to use by setting the Framing parameter and choosing the Time slot range

Figure 6-18: Updating the Port Data

Vyvo Installation Guide

- Now click on the “Update” button and press “OK” when the confirmation popup window appears. Select “Refresh Modems” from the File menu to refresh the modem icons (the new modem icon should change to green).






Figure 6-19: Updating the system for the new modem

Vyvo Installation Guide

- This screen will show the new modem and its connection to WMTS port 1 (in the Connections Table at the bottom). Note that the color of the modem in the left window pane has now changed from red to green (if the modem is online).




Figure 6-20: Viewing the new modem's E1/T1 interface information

Vyyo Installation Guide

10. For a summary of all modems and E1/T1 ports select the “E1/T1 Interfaces” item on the navigation tree in the left window pane




Figure 6-21: Viewing the E1/T1 Interfaces

At this point you have successfully connected the E1/T1 modem to the system and data should be flowing between the modem and the WMTS.

Chapter 7. Setting the WMTS IP Address

Note: Prior to performing this procedure the WMTS must be connected to the “download” computer serial port via the lower COM port (COM2) on the WMTS Control and Forward card.

The WMTS must also be connected to the same LAN subnet as the computer using its RJ45 connector on the same (Control and Forward) card.

Tip: The procedure used to download the Regtree file via the LAN connection may also be used to download other files to the WMTS, such as new versions of the software.

First, the **XmtsConfig.exe** tool is used to set a temporary IP address for the WMTS. This IP address allows the WMTS to appear on the LAN subnet and communicate with the servers (which are on the same network). The serial port connection is used to set the temporary IP address and the LAN connection is used to perform the actual download (via the temporary IP address previously set using the serial port connection). After the modified version of Regtree (containing the PERMANENT IP address of the WMTS) is downloaded and the WMTS is restarted, the WMTS will be accessible via its PERMANENT IP address.


Next, we will be modifying regtree.txt to contain the permanent WMTS IP address, then compiling regtree.txt into regtree.rtr and downloading it. The download is made by specifying regtree.rtr in the “Version File” field of the **XmtsConfig.exe** tool and making sure that regtree.rtr (the compiled version of regtree.txt) is copied into the TFTP file transfer folder.

1. Locate the file “regtree.txt” and open it using a standard text editor such as Notepad (do not use the XmtsConfigFileEditor for this as it does not allow editing of the necessary entries). There may be several versions of the Regtree file available (e.g., “regtree_data.txt”, “regtree_t1.txt”, etc.) so ask your system engineer which one to use, then copy and rename it to “regtree.txt” since that is the file which SETIP.bat expects as its input file. Scroll down (or use the “Find” function from the menu) to the entry “**CmtsIPAddress**” which is shown as 10.10.10.210 in this example. The default network address for Vyvo equipment is 10.10.10.xxx. Your system engineer should be able to provide the following information required to configure the WMTS:

- WMTS IP address
 - Gateway computer (used for downloading) IP address
 - Gateway computer subnet mask
 - IP addresses of any other computers that are permitted to access the WMTS remotely
2. Change the “**CmtsIPAddress**” as desired: this is the WMTS’s permanent IP address which will be downloaded later using the XmtsConfig tool.
 3. Change the two lines immediately following this line if necessary: the “**GatewayIPAddress**” (the address of the gateway computer or router) and the “**CmtsSubnetMask**”.
 4. Change **DevNMAccessIP1** and **DevNMAccessCommunity** for remote control as appropriate in Regtree.txt. Up to five IP addresses may be defined here. The first one should be the same as that of the Gateway computer or router used in the previous step. If you wish to add additional remote computers: duplicate the three lines for **DevNMAccessIP1** and **DevNMAccessCommunity1** and **DevNMAccessControl1** for each additional remote computer, change the numbers so that you have **DevNMAccessIP2**, **DevNMAccessCommunity2**, **DevNMAccessControl2** for the second computer and so forth up to the fifth remote computer. Then change the corresponding IP addresses for **DevNMAccessIP2** and so forth.

***Note:** No other edits should be necessary in this file, although the default frequencies for all the upstream and downstream channels are initialized in this file and may be changed if necessary.*

Vyvo Installation Guide



```
regtree.txt - Notepad
File Edit Format Help

ModTrainingLength_1{ 256 }
ModTrainingLength_2{ 256 }
ModTrainingLength_3{ 256 }
ModTrainingLength_4{ 256 }
ModTrainingLength_5{ 256 }
ModTrainingLength_6{ 256 }
}
PreamblePattern{ CC-CC-CC-CC-CC-CC-0D-0D-A9-17-D9-C3-52-2F-B3-86-A4-5F-67-0D-48-BE
DhcpEnable{ 2 }
BPIRequired{ 1 }
FragmentationRequired{ 1 }
ConcatenationEnabled{ 1 }
CmtsIPAddress{ 10.10.10.210 }
GatewayIPAddress{ 10.10.10.201 }
CmtsSubnetMask{ 255.255.255.0 }
WmtsVoIPClassifierDownstreamDataSourceUdpPortLow{ 4000 }
WmtsWanMode{ 2 }
WmtsVoIPClassifierDownstreamDataSourceUdpPortHigh{ 4100 }
WmtsVoIPClassifierDownstreamSignalSourceUdpPort{ 2727 }
WmtsVoIPCallAgent{ 3 }
WmtsUSPacketizationPeriod{ 4 }
WmtsDSPacketizationPeriod{ 1 }
ClockSource{ 6 }
DevNmAccessIp1{ 10.10.10.201 }
DevNmAccessCommunity1{ vyyowmts }
DevNmAccessControl1{ 5 }
```

Figure 7-1. Regtree.txt File Contents

Vyyo Installation Guide

- Now compile **regtree.txt** by executing **SETIP.bat** which should be in the same directory as **regtree.txt**. **SETIP.bat** is a batch file that converts **regtree.txt** from text to a special format read by the WMTS. The resulting file will be named **RegTree.rtr**.




Figure 7-2. Setip.bat

Vyvo Installation Guide

6. Locate the **Regtree.rtr** file and copy it to the directory (download path) that is used by the TFTP server to get the requested download files (the download directory):




Figure 7-3. Regtree.rtr Location in TFTP Root Directory

Vyyo Installation Guide

7. Open the TFTP server: in this example we use Pumpkin.exe. You may bring up the Options dialog window by clicking on the “Options” button. This will allow you to change the download directory.

Note: The file **RegTree.rtr** must be copied to the TFTP server download path, “C:\Vyyo\mic” as shown in this example since this is the directory where the TFTP server finds the requested files to be downloaded. You may change this path to suit your particular directory layout. To save the TFTP server download path as the default value, exit Pumpkin then restart it.




Figure 7-4. PumpKIN TFTP Settings

Vyvo Installation Guide

Note: Observe that *RegTree.rtr* has been copied to the TFTP download directory (*C:\Vyvo\mic*) used in this example:




Figure 7-5. Regtree.rtr, Located in TFTP Root or Specified Download Directory

Vyvo Installation Guide

8. Open the **XmtsConfig.exe** tool to perform the download to the WMTS. This tool is typically located in the "...\\Tools\\XmtsConfig" directory of the released software.
9. When the initial window appears right-click to expose a popup window from which you must select "Activate".
10. This will enable the screen for one minute, after which you must repeat this procedure to re-activate the screen. The one minute timeout prevents accidental downloads and restarts.

NOTE: You may have to "activate" the screen and "connect" (explained in the next step) to the WMTS several times during this procedure.




Figure 7-6. WMTS Configuration Tool

11. After activating this application select 'Connect'. This will open a second small window within which you can choose the type of connection to open (Serial or IP).




Figure 7-7: The “Connect” button

12. Select 'Serial' and the appropriate computer 'Com' port number to which the WMTS is connected. Click on 'Open Port' then select 'Close' to close the small window and return to the main application window.




Figure 7-8: Making the serial connection

- Now enter the TFTP Server IP Address, Subnet mask and Default Gateway. Click the corresponding buttons as you set each of these. Observe that the caption at the top of the XmtsConfig tool indicates "Connected: Com 1" at this time since it is connected via the serial connection. After the IP address has been set, the caption will change to "Connected: Remote 10.10.10.202" in this example (see the next step) to indicate that the LAN connection is active.

NOTE: If the permanent IP address of the WMTS is working you may connect (in the previous step) using it instead of the serial port by choosing "IP" instead of "Serial". The WMTS is shipped with the default IP address of 10.10.10.2. If you do use the IP connection you may skip this step.




Figure 7-9: Setting the WMTS temporary IP address

- Now enter the filename "**regtree.rtr**" in the "Version File" window, then click the "Start Software Download" button. Recall that the regtree.rtr file must be in the TFTP download directory as described in the first part of this procedure. The message below is displayed after the download command is sent to the WMTS – it does *NOT* indicate that the download has occurred. To confirm the download you must observe the indicator LEDs on the WMTS: they should be flashing with activity. You should also monitor the TFTP application window (see next figure) to verify that the download to the WMTS has occurred. When the file transfer is complete, click the "System Restart" button. The WMTS will now reboot and read the new **RegTree.rtr** file to configure itself.




Figure 7-10. WMTS Download of Regtree file




Figure 7-11. TFTP Download Message

15. You have now completed downloading the Regtree file containing the permanent configuration settings for the WMTS.

16. The message in the following figure should display after the System Restart message is sent.




Figure 7-12. System Restart Message

Note: The *XmtsConfig* application does not report if the action is successful, only that the command has been sent.

17. To verify that the download has taken effect you must use the procedure described in [Appendix B. Checking the WMTS Version.](#)

Chapter 8. Installing Vyyo Servers for WMTS Operation

Three servers must be installed before operating the WMTS system.

These servers are in accordance with the DOCSIS standard.

1. Time of Day server
2. TFTP server
3. DHCP server

On the computer connected to the WMTS there is folder named **c:\vyyo\servers**. This software was part of the original software installed from the installation CD. See your system engineer or Vyyo representative for assistance if necessary.

inside this folder you will find three folders, one each for the TOD, TFTP and DHCP servers.

8.1 Installing The Time Server:

18. Go to the TimeSvr folder under c:\vyyo\servers and double click on the application timeserv.exe. The ToD server should now be running.




Figure 8-1 Time Server Status Window

8.2 Installing the Pumpkin TFTP Server:

1. Navigate to the Pumpkin folder at c:\vyyo\servers\pumpkin (or the equivalent on your system)

Vyyo Installation Guide

2. Start the application pumpkin.exe




Figure 8-2. Pumpkin Folder Location

19. Click OK and follow the instructions on screen to install the TFTP server.

20. When done, go to Start→Programs→Accessories→Klever Co→PumKin




Figure 8-3. Location of PumpKIN After Installation

21. The following window appears after the application has started:




Figure 8-4. PumpKIN Status Window

22. Select Options




Figure 8-5. Options Dialog Box

23. Change TFTP filesystem root (download path) to where your modem configuration file will be located. In our case it will be under c:\vyyo\mic.
24. Make sure to select "Read Request Behavior and Write Request Behavior" to Give/Take all files.
25. Click OK
26. You may close this window as Pumpkin will continue to run in the background. The Pumpkin icon will appear on the taskbar (usually at the bottom of the screen) – click on it to bring up the Pumpkin window.

8.3 Installing IPLease DHCP Server:

NOTE: if you are using the DHCP Server program from Windows 200x Server Edition please see [Section 5.2.2 Windows 200x Server Edition: Modifying the DHCP Options.](#)


1. Before you can execute the DHCP application, you need to make sure that your computer IP address is configured statically to 10.10.10.1, subnet mask of 255.255.255.0. These are the defaults, see your system engineer for the addresses corresponding to your Network IP Plan.
2. Go to the folder iplease that is located under c:\vyyo\servers\iplease. In the folder, there are 4 important files that will configure your iplease DHCP server.
 - **dhcpsvr.ini** (the DHCP server configuration file)
 - **cm.src** (the file that contains the information sent to the modems)
 - **dhcpgen.exe** (the application that processes the CM.SRC file into a format readable by the DHCP server)
 - **dhcpsvr.exe** (the DHCP server application)

8.3.1 dhcpsvr.ini

This file sets the computer (DHCP Server) IP address and subnet identification number. These should be set according to your IP address plan set up by your system engineer. You may edit this file using any ASCII text editor, e.g., Notepad.

NOTE: the SubnetNum is actually the network number on which the DHCP server resides – see the comment in the file displayed below.

Vyvo Installation Guide



```

DHCPSPVr.INI - Notepad
File Edit Format Help

PendingTimer=40

; -----
; ServerIPAddr is the internet (TCP/IP) address of this server.
;
; If the machine on which the server will run is multi-homed
; (i.e.: uses more than one adapter to connect to an internet or
; internets), select the address on the network without a
; BOOTP relay agent, or the address on the network with the
; most DHCP client activity. (or flip a coin.) If you run
; BOOTP relay agents on other networks, point them to
; the address you specify here.
;
; Use dotted decimal form and enter exactly one IP address.
ServerIPAddr=10.10.10.1

; -----
; SubnetNum is the network number on which ServerIPAddr resides.
; This is NOT the subnet mask. It IS that mask AND'd with ServerIPAddr.
;
; Use dotted decimal form and enter exactly one network number.
SubnetNum=10.10.10.0

; -----
; Lease file synchronization.
;
; When you generated a new *.lse file, moved it to the server's
; working directory, and told the server its name (using the
; LeaseFileName parm above), it will contain no information
; about old leases the server has been managing. Such "state"
; is in the server's last *.lse file, and the new *.lse
; will need to synchronize with the old when the server first
; starts using the new LeaseFileName. The old file becomes
; the synchronization file, named in the SynchFileName parm
; below.
;
; If you wish the server to synchronize the old and new lease files
; set LeaseSynch=1 below and name the old lease file in
; SynchFileName, otherwise set LeaseSynch=0.
; Note that after a successful synchronization at server
; start time, LeaseSynch=0 will be set here to avoid unintentional
; synchronizations during future restarts and the resulting
; damage to then current leases.
;
; 1=YES, 0 = NO
LeaseSynch=0
SynchFileName=leases2.lse

```

Figure 8-6. DHCPSPVr.ini File


1. Set the computer's DHCP server IP address in the **ServerIPAddr=** field.
27. Set your network identification in the **SubnetNum=xx.xx.xx.xx** field.
28. Save this file after completing your changes

8.3.2 cm.src

The **cm.src** file maps the modem MAC address to an IP address and binds the modem MAC address to a specific modem configuration file. It also provide the default addresses for the gateway, TFTP server and ToD server.

NOTE: The lines beginning with a semicolon “;” are comments

Vyvo Installation Guide



```
cm.src - Notepad
File Edit Format Help

;
;
; -----
; AddressGroups section.
;
[AddressGroups]
ServerLocal=                */your server configuration*/
;Group1=


[ServerLocal]
AddressBase=10.10.10.0      */the server network identification*/
SubnetMask=255.255.255.0   */ the server subnet mask*/
HostNameMethod=Normal
RangeInclude1=1 240        */how many consecutive IP address the server will assign starting from 10.10.10.1*/
RangeExclude1=1 2          */how many consecutive IP address the server will exclude starting from 10.10.10.1 and th

OptGroup=MinimalOpts

; Note: *all* IP addresses that the server will manage must be
; included in some address group, like [ServerLocal]. This rule
; means that you must include IP addresses intended for *static*
; leases (permanent associations of machines with their IP
; addresses) in an address group here. You will indicate the
; static nature of the lease in the per-host option groups
; below.
;
; -----
; Address-related option groups.
;
[MinimalOpts]
oDomainName=vyvo.co.il     */the server domain name*/
oRouter=10.10.10.1          */the modem router or gateway IP address*/
oDNSServer=194.90.1.5       */the modem DNS server*/
oAddrLeaseTime=720000       */the DHCP server lease time in seconds*/
oSubnetMask=255.255.255.0   */the modem subnet mask*/
oTimeOffset=7200
oTimeServer=10.10.10.1      */the modem time server IP address*/
oLogServer=10.10.10.201     */the modem log server*/
bpNextServer=10.10.10.1     */the modem TFTP server IP address*/
;bpBootFile=mic1_ipf.cfg

; 36000 seconds equates to ten hours. If you are managing
; leases for many "floating" notebook computers, please
; consider reducing the lease time to an hour or two. It
; could save you some trouble explaining how to release an
; old lease on another network to your colleagues.
;
; -----
;
```

Figure 8-7. CM.SRC File Format



```
cm.src - Notepad
File Edit Format Help

[Hosts]
lab1=
lab2=
lab3=
lab4=
lab5=
lab6=
lab7=
lab8=
lab9=
lab10=

; Per-Host option groups:
; oClientID or Chaddr must be the first entry for each host.
; Per-host options can be used to override most options in
; the associated address-related options above, but per-host
; options are also frequently used to define static leases.
; Static leases associate a MAC address or a Client Identifier
; permanently with a DHCP client. Two examples follow.
; Note that the StaticIPAddress values (198.180.39.21, and .22)
; below MUST already have been included in an address range, as
; in the ServerLocal section described above.

[lab1]
Chaddr=00103d1283eb
oHostName=WMU #1
StaticIPAddress=10.10.10.10
bpBootFile=mic1.cfg

[lab2]
Chaddr=00103d120233
oHostName=WMU #2
StaticIPAddress=10.10.10.11
bpBootFile=mic1.cfg

[lab3]
Chaddr=00103d1201cd
oHostName=WMU #3
StaticIPAddress=10.10.10.3
bpBootFile=mic1.CFG

[lab4]
```

Figure 8-8. CM.SRC File Format (Continued)

1. Comments in the **cm.src** file are annotated with */
2. After editing the cm.src file, save your changes.

8.3.3 Dhcpgen

Note: Your computer must be configured with the correct IP address, i.e., the same one as in the **dhcpsvr.ini** file. (10.10.10.1 in this example) before using **dhcpgen**

1. **cm.src** must be compiled with **dhcpgen** for use with the IPLease DHCP server. **Dhcpgen** must be run in a DOS window.
2. On the Start Menu, choose **Run...**
3. Type **cmd** and click the OK button.

Vyyo Installation Guide




Figure 8-9. The Run... Dialog Box

29. Navigate to the **IPLease** folder by executing the following command:

```
cd \; cd vyyo; cd servers; cd iplease
```





Figure 8-10: Navigating to the iplease directory

30. Type **dhcpgen cm** and press the Return or Enter key. The second parameter is the name of the .src file the **dhcpgen** will convert (compile) into a format usable by the DHCP server (this is called the ipLease format).

The second to last line informs you if the it has completed successfully. If the compilation reports an error you must re-edit the CM.SRC file and recompile it and repeat this process until it executes successfully. Otherwise the DHCP will not be using the correct data.




```
C:\WINNT\system32\cmd.exe
C:\Uyyo>cd tools
C:\Uyyo\Tools>cd servers
C:\Uyyo\Tools\Servers>cd iplease
C:\Uyyo\Tools\Servers\iplease>dhcpgen cm
ipLease(TM) DHCP Gen Version 1.30 started at 10/23/2004 9:05:04
Copyright (C) 1999 Billiter Consultants. All rights reserved.
This version supports a maximum of 1024 leases.
DHCP Gen serial E94099E13AD216B2
Default lease time = 5432
HRDefaults option group created
AddressGroup ServerLocal created on network number 10.10.10.0
with 238 addresses.
Now sorting the lease pool
Host option group lab1 created for Chaddr 00103D1283EB000000000000000000000
as a static (manual) lease for IP address 10.10.10.10
Host option group lab2 created for Chaddr 00103D12023300000000000000000000
as a static (manual) lease for IP address 10.10.10.11
Lease data base generation was successful.
238 addresses were created.
Of these, the count dedicated for static leases is 2.
C:\Uyyo\Tools\Servers\iplease>
```

Figure 8-11: Successfully compiled CM.SRC file

NOTE: If this is a new installation then the DHCP server should not be running. For existing installations, the ipLease DHCP server must be shutdown as shown in the instructions below.

31. To shutdown the iplease server click on the Shutdown button in the upper right window pane of the application as shown below:



32.

Figure 8-12: ipLease Server Shutdown

8.3.4 DhcpSvr:

After completing section 6.3.3, open the IPLease folder and start **DhcpSvr.exe**. The ipLease application window will be the same as in [Figure 8-12](#) above.

Chapter 9. Maintenance and Troubleshooting

9.1 Introduction

The WMTS is an IP centric two-way RF system, which incorporates various information technologies and RF devices. When the system is not operating properly, the malfunction must be isolated to localize the problem to a single functional area.

The troubleshooting process consists of three basic steps:

- Identifying the problem,
- Diagnosing the problem, and
- Implementing a solution.

To identify a problem, you have to ask two questions:

- 1) When does the problem occur?
- 2) What else is affected?

For example, when none of the modems respond to an SNMP request, it can be assumed that the WMTS or the RF components at the base station are not functioning properly. Try to find out if the problem is on the downstream or upstream path. If only a certain modem does not respond, it can be assumed that the problem relates to the subscriber site, or an NMS software setting for that particular subscriber.

If you have identified the problem, you are ready to diagnose its cause and take the necessary actions to solve the problem.

When implementing solutions, change one thing at a time, if possible. If the first solution does not solve the problem, reverse the change you just made and try another solution. For example, you are experiencing problems in one of the upstream sections. To solve the problem, replace the demodulator card. If the problem still remains, replace the old card and try another solution.

Some of the symptoms can be related to a certain functional area, some not. Use the system block diagram in the next section [Troubleshooting the RF Frontend](#) to relate the problem to a certain area.

9.2 Troubleshooting the RF Frontend

9.2.1 General

The RF frontend contains the upstream and downstream channel converters and amplifiers.

Vyyo Installation Guide

Use a spectrum analyzer and RF power meter to perform tests.

A typical basic RF setup is illustrated in Figure 9-1. Please use the specific block diagram for your system when you are troubleshooting problems

9.2.2 Checking the Downstream

Perform the following steps to isolate a problem on the downstream channel of the RF frontend:

- a. On the transmitter RF power meter -
 - Check the transmit power on the downstream transmitter, to verify the RF output
 - Test the reflected power (SWR), to verify that the transmitter is connected to the coaxial system correctly.
- b. WMTS
 - Measure the output power of the demodulator card. Use a spectrum analyzer tuned to 44 MHz, with a span of 20 MHz. . The power should be 10 dBm $\pm$ 5 dB.

9.2.3 Checking the Upstream

Perform the following to isolate a problem on the upstream channel of the RF frontend:

Measure the output power of the downconverter. Use a spectrum analyzer tuned to the upstream channel IF (about 44 MHz), with a span of 20 MHz.

The following diagram illustrates a basic RF test setup.




Figure 9-1: Basic RF Setup

Chapter 10. Troubleshooting The Subscriber Site

10.1 Post-Registration Verification

When the modem registration process has reached completion, connect the Laptop or PC to the V280 WMU and verify the following items:

	Verification Item	Task
1	Check the IP address.	From the Windows Command Prompt, ipconfig or winipcfg to view the configuration. Open the Web Browser and verify that there is proper Internet access.
2	Perform relevant system speed verification tests.	See your System Administrator to install and use a speed verification utility.

***Note:** BWA system-specific variables can affect all these troubleshooting steps. Consult your System Administrator or Vyvo representative for further troubleshooting guidance and detail.*

10.2 Physical Layer Troubleshooting

If you experience difficulties operating the modem, there may be problems with the modem's physical layer. Inspect the WMU physical layer by means of the following steps:

	Verification Item	Task
2	Power supply connection	Verify that the WMU power supply is connected to the WMU power input.
3	Radio connection	Verify that the RF cable connector is connected to the WMU RF input.
4	Connection to the testing PC	Verify that the WMU Ethernet port LED is illuminated and that the LAN cable is connected to a working Ethernet port on the testing PC.

10.3 IF Layer Troubleshooting

If the modem powers up, but still is not transmitting or receiving a signal, you may need to check the IF Layer.

Use the following steps to troubleshoot the IF layer:

Verification Item	Task
Signal amplitude	Connect the SLM to the IF input cable. Set the SLM to the appropriate known DS frequency and measure the amplitude in dBmV. Verify that the peak amplitude of the IF signal is compliant with the WMU input signal level specification. If no signal is present, verify that the radio transceiver was installed according to the manufacturer's installation procedures.
Transceiver power supply	Verify that the transceiver power supply is operational and connected correctly.

10.4 Troubleshooting the NMS

If the main SNMPc window does not show the three parts of the panned window (left, right and bottom), try to drag the pan bar. If this fails:

Exit SNMPc

1) Rename

<SNMPc directory (default: c:\program files\SNMPc Network Manager)>\SSFAdministrator.ssf
to be <SNMPc directory>\SSFAdministrator.ssf_

2) Reinstall SNMPc

If the SNMPc installation is stuck, restart the computer and try again

If SNMPc gets corrupted (has been installed but fails to work):

Report error messages and other relevant details to Vyyo NMS team

3) Uninstall SNMPc, according to instructions (see Appx C.4, Uninstalling the NMS)

4) Reinstall the NMS according to instructions

5) If a 'low virtual memory' message appears:

Close unneeded applications

6) If the message re-occurs, report to Vyyo NMS team, close the NMS main window and startup the NMS

10.5 Repairs Safety


1. Repairs of WMTS should take place only in VYYO company service laboratories or in other VYYO formally approved distributors service laboratories. In case of field handling our general SAFETY warning is to disconnect the unit from power supply for safest repair.
2. In case of a -48VDC operated WMTS, the External Circuit Breaker (Du Pole) must be used before connection/removal of the power cable to/from the WMTS.

Appendix A. WMTS US Port Mapping

The following figure shows a rear view of the WMTS with several upstream RF cards. The numbering proceeds from right to left and allows for eight channels on each card even if the card does not have eight physical connections. Logical ports are also referred to as “interfaces”.

NOTE: the downstream port mapping is similar except that the first Logical Port is number 2.

WMTS Upstream Port = Logical Port = Interface



WMTS Port	Logical Port
1	34
2	35
3	36
4	37
5	38
6	39
9	42
10	43
11	44
12	45
13	46
14	47
17	50
18	51
19	52
20	53
21	54
22	55
25	58
26	59
27	60
28	61
29	62
30	63

Appendix B. Checking the WMTS Version

The version number may be easily checked by using the **XmtsConfig** tool shown in the figure below: right click on any open area in the main window to display the popup shown, and then click on “Activate” followed by “Connect”. This establishes communication between the XmtsConfig tool and the WMTS. Now click on “Version Check (WMTS)” in the popup window. See [Setting the WMTS IP Address](#) for instructions on using the **XmtsConfig** tool.

1. Right click in the main window on any open space and then click in “Activate” on the popup menu.




Figure B-1: Viewing the XmtsConfig tool-Activate

Vyvo Installation Guide

33. Now click on “Connect” in the main window and when the popup menu appears, verify or set the IP address as needed, and click on “Connect” then “Close”. A message will appear in the main window indicating if the connect command was sent.

NOTE: the “Activate” command automatically closes the WMTS connection after approximately 60 seconds – this may cause a message like “Inconsistent WMTS Version” to appear in the message window. If this occurs just right click and select “Activate” again then “Connect” then “Version Check (WMTS)”.




Figure B-2: Connecting to the WMTS

Vyyo Installation Guide

34. Right click in the open space in the main menu to bring up the popup menu and select “Version Check (WMTS)”. The WMTS version will be shown in the message window.




Figure B-3: Viewing the WMTS Version

Appendix C. Installing and Uninstalling the NMS

C.1 First Time Installation

Follow the steps below to install the NMS. See the NMS SNMPc Version 7.0 Reference Guide for detailed instructions:

Unzip the installation ZIP file

Launch INSTALL.CMD

When Java is installed choose "Typical" (use defaults)

On SNMPc-7 installation choose:


- Server
- No Discovery Seed
- Check the "Start with discovery off"

Note:

When using Windows XP, you must extract the installation zip file. Don't run the install from within the zip file.

C.2 Launching the Vyvo NMS

The NMS is launched automatically when you start SNMPc. You may use the "Start" menu to do this



C.3 Installation Upgrade

Run install.cmd after you unzip the installation files

On the SNMPc installation wizard, choose "Upgrade SNMPc"

C.4 Uninstalling the NMS

The main steps in uninstalling the NMS based on SNMPc 7.0 are as follows. See the NMS SNMPc Version 7.0 Reference Guide for detailed instructions:


1. Shutdown the SNMPc manager
2. Stop the Data Collection Service
3. Shutdown the SNMPc NMS
4. Shutdown the SNMPc Server
5. Remove the SNMPc application
6. Remove Java™ Runtime Environment if desired
7. Reboot

Appendix D. Launching the Vyvo Configuration Tool

The Vyvo Configuration Tool is used to configure the WMTS and there are two ways to launch the Vyvo Configuration Tool. You may use either one, depending on whether or not the NMS (SNMPc) is up and running. If you just need to configure the WMTS it is easier to launch the Vyvo Configuration Tool from the Windows “Start” menu. If you are already working with the NMS you may launch the Vyvo Configuration Tool for a particular WMTS on the network – there is a small advantage in doing this since you will not have to add (“Insert”) the WMTS to the Vyvo Configuration Tool because the IP address of the WMTS is passed directly to it upon invocation.

D.1 The Vyyo Configuration Tool Menu (exploded view)

The following exploded view of the Vyyo Configuration menu shows all the main menu options and their second level options.



D-1: The Vyyo Configuration Tool Menu (exploded view)

D.2 Launching the Vyvo Configuration Tool from the “Start” Menu

1. From the “Start” menu select and click on “Configure WMTS”




Figure D-2: Using the “Start” menu to launch the Vyvo Configuration Tool

35. You must now add the WMTS by selecting the “Insert” menu option then choosing “WMTS” from the drop down menu




Figure D-3: Adding (Inserting) the WMTS

36. Insert the WMTS IP address and click “OK”




Figure D-4: Inserting the WMTS IP address

Vyyo Installation Guide

37. The Vyyo Configuration Tool will now read data from the WMTS based on the IP address you entered in the previous step




Figure D-4: Reading the WMTS Data

38. Fully expand every level of the WMTS tree to show all the components that may be configured. You may later collapse the tree to display only those with which you are currently working.




Figure D-5: Expand the WMTS Tree

Vyvo Installation Guide

39. This is the fully expanded WMTS tree: you have now launched the Vyvo Configuration Tool and may proceed to perform any of the WMTS configuration procedures




Figure D-6: Fully expanded WMTS tree

D.3 Launching the Vyvo Configuration Tool from the NMS

1. If the NMS is not started, launch it from the “Start” menu




Figure D-7: Launching the NMS from the “Start” menu

2. Expand the Root Subnet tree and the WMTS one level beneath it to reveal an icon and name for the particular WMTS you wish to configure. In this image the WMTS is named “The_WMTS_at_XXX”. Select and double-click on this WMTS name to open it. You may also select and double click the corresponding icon in the right half of the screen window.




Figure D-8: Select and open the WMTS

Vyyo Installation Guide

3. When the picture of the WMTS appears select the “Vyyo WMTS” main menu item and then choose the “Configure” option from the drop down menu. This will launch the Vyyo Configuration tool. The WMTS IP address is automatically passed to the Vyyo Configuration tool if you use this method to launch it. You may now proceed from step (5) of the previous section [D.2 Launching the Vyyo Configuration Tool from the “Start” Menu](#) to expand the WMTS tree and perform any of the WMTS configuration procedures.



Figure D-9: Launching the Vyyo Configuration Tool from the WMTS screen

Appendix E: Vyyo Configuration Tool – Additional Functions

E.1 Adding an E1/T1 Cross Connection

E.2 Adding a DS3 Connection

INDEX

[Hosts] in CM.SRC	43	NMS, Installing	55, 140
Additional Channels, Setting.....	38	NMS, Uninstalling	55, 140
Castlerock SNMPc	79	PSTN.....	7, 15
Checking the WMTS Version.....	137	QoS (Quality of Service, Setting the	37
CM.SRC	40	RegTree.rtr	102
CmtsIPAddress	100	regtree.txt	102
CmtsSubnetMask	100	Repairs	124
Concatenation and Fragmentation, Setting the.....	36	RF Link Layer.....	18
DevNMAccessCommunity	100	SETIP.bat	102
DevNMAccessIP1	100	Status LEDs	30
DHCP Server	18	Synoptics.....	79, 126
DHCP Settings, Modem	32, 40	T1 Connection, Configuring	79
Dhcpgen.....	116	TFTP server	104
dhcpsvr.ini.....	113	TFTP Server	18
DOCSIS	10	TFTP Server, Installing the	110
DOCSIS Layer.....	19	Time Server.....	110
Downstream Frequency, Setting the	35	Time-of-Day (TOD) Server	18
E1/T1	28	Upstream Channel, Setting the.....	28, 32, 33
E1/T1 Layer	21	V280	13
GatewayIPAddress	100	V311	14
HTTP, Using to view modem Operation.....	74	V312	15
Initialization	25	Vyvo Configuration Tool	79
IP Layer.....	20	Windows 200x Server, DHCP Settings29, 33, 46, 113	
IpLease	40, 88	XmtsConfig.exe	106
IPLease DHCP Server, Installing the	113	CMConfigFileEditor	79
Maximum Number of CPEs, Setting.....	39	WMTS	10, 11
Modem Capabilities.....	17	WMTS IP Address, Setting the	100
Modem Downstream and Upstream Status, Verifying	72	WMTS T1 Interface.....	89
Modems	13	WMTS US Port Mapping	136
Network Servers	18	WMTS, Configuring	55
NMS	79		