

OSD(On Screen Display) BUTTONS



: Opens and closes the OSD window.



: Changes audio volume without OSD.



Selects a menu on OSD mode.




: Selects a channel on TV mode without OSD.




Moves to a menu on OSD mode.

MAIN MENU





OSD ADJUSTMENT (PC MODE)

Select PC Monitor





Display Adjustment



- Brightness Adjustment





– Contrast Adjustment



– Color Adjustment









■ Same way for Green, Blue, Flesh Tone adjustment

■ Screen Image Adjustment

- Phase (Noise) Adjustment





- Frequency Adjustment





■ Screen Position Adjustment

– Horizontal Position





– Vertical Position Adjustment







Utility

- H Flip



- V Flip



– Capture

 **Capture**


Yes

No

MOVE
▲
CH
▼

SELECT
VOL ▶

EXIT
MENU /
ENTER



– Factory Preset

 **Factory Preset**


Yes

No



MOVE
▲
CH
▼

SELECT
VOL ▶



EXIT
MENU /
ENTER





– OSD Timeout





- OSD Position Adjustment
- Horizontal Position Adjustment



Vertical Position Adjustment



– Language Selection



– Information

