

Huawei Technologies Co., Ltd.

Administration Building, Huawei Technologies Co.,  
Ltd., Bantian, Longgang District,  
Shenzhen, P. R. China

Postal Code: 518129

Website: <http://www.huawei.com>

BOM: 31033171

|       |       |
|-------|-------|
| 8.4cm | 5.4cm |
|-------|-------|

Airbridge cBTS3612 CDMA Base Station  
On-site Maintenance Manual

Huawei Technologies Co., Ltd.

Airbridge cBTS3612 CDMA Base Station  
On-site Maintenance Manual

Huawei Technologies Co., Ltd.

Airbridge cBTS3612 CDMA Base Station  
On-site Maintenance Manual

Huawei Technologies Co., Ltd.

**Airbridge cBTS3612**  
**CDMA Base Station**  
On-site Maintenance Manual

# Table of Contents

|                                                     |             |
|-----------------------------------------------------|-------------|
| <b>Chapter 1 Daily Maintenance .....</b>            | <b>1-1</b>  |
| <b>1.1 Base Station Configuration .....</b>         | <b>1-1</b>  |
| <b>1.2 Maintenance Instructions .....</b>           | <b>1-8</b>  |
| <b>Chapter 2 General Fault Processing .....</b>     | <b>2-1</b>  |
| <b>2.1 MS Access Network Failure .....</b>          | <b>2-1</b>  |
| 2.1.1 Fault Description .....                       | 2-1         |
| 2.1.2 Troubleshooting .....                         | 2-1         |
| <b>2.2 Software Download Failure .....</b>          | <b>2-9</b>  |
| 2.2.1 Fault Description .....                       | 2-9         |
| 2.2.2 Troubleshooting .....                         | 2-9         |
| <b>2.3 Base Station Initialization Failure.....</b> | <b>2-11</b> |
| 2.3.1 Fault Description .....                       | 2-11        |
| 2.3.2 Troubleshooting .....                         | 2-11        |
| <b>2.4 OML Failure.....</b>                         | <b>2-13</b> |
| 2.4.1 Fault Description .....                       | 2-13        |
| 2.4.2 Troubleshooting .....                         | 2-13        |
| <b>2.5 Abis Signaling Link Failure .....</b>        | <b>2-17</b> |
| 2.5.1 Fault Description .....                       | 2-17        |
| 2.5.2 Troubleshooting .....                         | 2-17        |
| <b>Chapter 3 Component Failure Handling.....</b>    | <b>3-1</b>  |
| <b>3.1 Component Failure Description .....</b>      | <b>3-1</b>  |
| 3.1.1 Component Failure Detection .....             | 3-1         |
| 3.1.2 General Handling Procedure .....              | 3-1         |
| <b>3.2 Handling of Common Board Failure .....</b>   | <b>3-5</b>  |

|                                                         |             |
|---------------------------------------------------------|-------------|
| 3.2.1 Fault Description .....                           | 3-5         |
| 3.2.2 Troubleshooting .....                             | 3-5         |
| <b>3.3 BTS Control Interface Module (BCIM).....</b>     | <b>3-8</b>  |
| 3.3.1 Fault Description .....                           | 3-8         |
| 3.3.2 Troubleshooting .....                             | 3-8         |
| <b>3.4 BTS Control &amp; Clock Module (BCKM) .....</b>  | <b>3-10</b> |
| 3.4.1 Fault Description .....                           | 3-10        |
| 3.4.2 Troubleshooting .....                             | 3-10        |
| <b>3.5 BTS Channel Process Module (BCPM).....</b>       | <b>3-12</b> |
| 3.5.1 Fault Description .....                           | 3-12        |
| 3.5.2 Troubleshooting .....                             | 3-12        |
| <b>3.6 BTS Resource Distribution Module (BRDM).....</b> | <b>3-14</b> |
| 3.6.1 Fault Description .....                           | 3-14        |
| 3.6.2 Troubleshooting .....                             | 3-14        |
| <b>3.7 BTS Transceiver Module (BTRM) .....</b>          | <b>3-16</b> |
| 3.7.1 Fault Description .....                           | 3-16        |
| 3.7.2 Troubleshooting .....                             | 3-17        |
| <b>3.8 BTS High Power Amplifier Unit (BHPA) .....</b>   | <b>3-20</b> |
| 3.8.1 Fault Description .....                           | 3-20        |
| 3.8.2 Troubleshooting .....                             | 3-20        |
| <b>3.9 Receive LNA Distribution Unit (RLDU).....</b>    | <b>3-23</b> |
| 3.9.1 Fault Description .....                           | 3-23        |
| 3.9.2 Troubleshooting .....                             | 3-23        |
| <b>3.10 Power Supply Unit (PSU) .....</b>               | <b>3-25</b> |
| 3.10.1 Fault Description .....                          | 3-25        |
| 3.10.2 Troubleshooting.....                             | 3-25        |
| <b>3.11 The RF Antenna and Feeder .....</b>             | <b>3-27</b> |
| 3.11.1 Fault Description .....                          | 3-27        |
| 3.11.2 Troubleshooting.....                             | 3-27        |

|                  |                                               |            |
|------------------|-----------------------------------------------|------------|
| <b>3.12</b>      | Satellite Antenna and Feeder .....            | 3-28       |
| 3.12.1           | Fault Description .....                       | 3-28       |
| 3.12.2           | Troubleshooting.....                          | 3-28       |
| <b>Chapter 4</b> | <b>Component Replacement .....</b>            | <b>4-1</b> |
| <b>4.1</b>       | Common Procedure of Replacement .....         | 4-1        |
| 4.1.1            | Board Replacement .....                       | 4-1        |
| 4.1.2            | Backplane Replacement .....                   | 4-4        |
| <b>4.2</b>       | Exceptional Procedure of Replacement .....    | 4-8        |
| 4.2.1            | BTS E1 Surge Protector (BESP) .....           | 4-8        |
| 4.2.2            | BTS Control & Clock Module (BCKM) .....       | 4-9        |
| 4.2.3            | BTS Control Interface Module (BCIM) .....     | 4-10       |
| 4.2.4            | BTS Channel Process Module (BCPM) .....       | 4-10       |
| 4.2.5            | BTS Resource Distribution Module (BRDM) ..... | 4-11       |
| 4.2.6            | BTS FAN Module (BFAN) .....                   | 4-11       |
| 4.2.7            | Power Supply Unit (PSU) .....                 | 4-12       |
| 4.2.8            | BTS RF Fan Module (BRFM) .....                | 4-12       |
| 4.2.9            | BTS High Power Amplifier Unit (BHPA).....     | 4-13       |
| 4.2.10           | BTS Transceiver Module (BTRM) .....           | 4-14       |
| 4.2.11           | Receive LNA Distribution Unit (RLDU) .....    | 4-15       |
| 4.2.12           | Duplexer Unit (CDU, DFU, DDU) .....           | 4-16       |
| 4.2.13           | Optical Fiber Replacement .....               | 4-18       |
| <b>Chapter 5</b> | <b>Component Indicators.....</b>              | <b>5-1</b> |
| <b>5.1</b>       | BTS Control & Clock Module (BCKM) .....       | 5-1        |
| <b>5.2</b>       | BTS Control Interface Module (BCIM).....      | 5-2        |
| <b>5.3</b>       | BTS Channel Process Module (BCPM).....        | 5-3        |
| <b>5.4</b>       | BTS Resource Distribution Module (BRDM) ..... | 5-4        |
| <b>5.5</b>       | BTS Transceiver Module (BTRM) .....           | 5-5        |
| <b>5.6</b>       | BTS RF Fan Module (BRFM) .....                | 5-6        |
| <b>5.7</b>       | Receive LNA Distribution Unit (RLDU).....     | 5-7        |

|                                                                                           |            |
|-------------------------------------------------------------------------------------------|------------|
| <b>5.8</b> Power Supply Unit (PSU).....                                                   | 5-7        |
| <b>5.9</b> Base station Power & Lightening protection Lamp Indicator<br>board (BPLI)..... | 5-8        |
| <b>5.10</b> BTS Fan Monitor Module (BFMM) .....                                           | 5-9        |
| <b>Chapter 6 Switches &amp; Interfaces.....</b>                                           | <b>6-1</b> |
| <b>6.1</b> BTS Control Interface Module (BCIM).....                                       | 6-1        |
| <b>6.2</b> Receive LNA Distribution Unit (RLDU).....                                      | 6-3        |
| <b>6.3</b> Cabinet-Top E1 Interface.....                                                  | 6-3        |

# Chapter 1 Daily Maintenance

## 1.1 Base Station Configuration

Base station configuration includes site configuration, antenna and feeder configuration and cabinet configuration. Please refer to Table 1-1 for details about site configuration, Table 1-2 about antenna and feeder configuration, and Figure 1-1, Figure 1-2, Figure 1-3, Figure 1-4 and Table 1-3 about cabinet configuration

**Table 1-1** Site configuration

| Items              | contents | Remarks |
|--------------------|----------|---------|
| Site name          |          |         |
| Site Configuration |          |         |
| Transmission Mode  |          |         |
| Cascading relation |          |         |



**Note:**

1. For the Site configuration, the site type and configuration mode are required to be specified, for example: cBTS3612 S(2/2/2).
  2. If there is a cascading relation among the base stations, specify the name of the stations on the upper level and lower level.
-

**Table 1-2** Antenna and feeder configuration and radio frequency indexes

| Item                                    | Contents |          |          |          |          |          | Remarks |
|-----------------------------------------|----------|----------|----------|----------|----------|----------|---------|
|                                         | Sector 1 | Sector 2 | Sector 3 | Sector 4 | Sector 5 | Sector 6 |         |
| Carrier transmit power                  |          |          |          |          |          |          |         |
| Standing wave ratio                     |          |          |          |          |          |          |         |
| Antenna position angle/down-pitch angle |          |          |          |          |          |          |         |



**Note:**


1. If the station is to be configured as an omni-directional cell, specify the antenna and feeder information in Sector 1.
  2. The carrier transmit power is that measured on top of the cabinet after the station is officially set up and running.
  3. The standing wave ratio is that measured at the RF jumper connector (the end connecting to the CDU or DFU or DDU panel) in the cabinet with a standing wave ratio measurer.
- 

For the cabinet configuration information, please specify in the relevant spaces in Figure 1-1, Figure 1-2, Figure 1-3 and Figure 1-4 the names of the boards and modules (use acronyms wherever possible).

For the baseband subrack of the basic cabinet, specify in the relevant space in Figure 1-2, (baseband subrack in Figure 1-1 can

be left blank). Since the extension cabinet has no baseband subrack, it can be ignored.


Additionally, Table 1-3 also needs to be completed, which is to make supplemental description of some of the boards or modules, switch box can be ignored.




**Figure 1-1** Basic cabinet configuration

|  |   |   |   |   |   |   |   |   |   |   |    |    |    |    |    |    |    |    |    |    |    |    |
|--|---|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|----|----|----|----|
|  | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 |
|--|---|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|----|----|----|----|

**Figure 1-2** Configuration of baseband subrack of basic cabinet



**Figure 1-3** No.1 extension cabinet configuration



**Figure 1-4** No.2 extension cabinet configuration

**Table 1-3** Supplemental description of cabinet configuration

| Item | Contents | Remarks                                                                                                                                                                                                       |
|------|----------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| BCIM |          | Specify whether the DIP switch and jumper are for 120 Ω twisted pair line or for 75 Ω coaxial cable. Specify the DIP switch and jumper's position.                                                            |
| BRDM |          | Detail the optical interface application, for example: which optical interfaces are used, and their relations (including the connection of the BTRM of extension cabinet with the BRDM of the basic cabinet). |
| BTRM |          |                                                                                                                                                                                                               |
| RLDU |          | Specify the location of S/W switch on the panel.                                                                                                                                                              |

## 1.2 Maintenance Instructions

The following steps are for your reference. Generally step 1, 2 and 3 (equipment room environment check, cabinet interior check and dial-up test) are the basic steps required. For a thorough maintenance, you may go through the step 4, 5 and 6 (power supply check, lightening-proof & grounding measures and antenna and feeder check).

## I. Equipment room environment check

**Table 1-4** Equipment room environment check

| Items                         | Instructions                                                                                                                                                      | Caution-demanding issues                                                                                                                                                                                                                                                                                            |
|-------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Anti-theft measures           | Check if there is any sign of burglary or equipment damage                                                                                                        |                                                                                                                                                                                                                                                                                                                     |
| Temperature                   | 1. Check if the air-conditioning is running properly.<br>2. Check the thermometer readings in the equipment room (if there is no thermometer, have one installed) | Temperature range: -5°C ~+50°C                                                                                                                                                                                                                                                                                      |
| Humidity                      | 1. Check if there is any sign of water seepage.<br>2. Check the humidimeter readings in the equipment room (if there is no humidimeter, have one installed)       | Humidity range: 5%~90%.                                                                                                                                                                                                                                                                                             |
| Dust-proof performance        | 1. Check if there is any visible floating dust in the equipment room.<br>2. Open the cabinet door and check the dust filter                                       | Take measures to eliminate the dust source, if the dust filter has collected too many dusts, follow the instructions below to clean or change it.                                                                                                                                                                   |
| Alarm collection device check | According to the actual condition of the alarm collection device, check the alarm performance for access control, temperature, humidity and smoke, etc.           | If the above-mentioned items are monitored by an alarm collection device, when there is a problem with these items but the alarm collection device fails to generate an alarm on it, that device may have run out of order. In such case, please refer to the relevant manuals for proper measures to cope with it. |

## II. Cabinet interior check

**Table 1-5** Cabinet Interior check

| Items           | Instructions                                                                                                                                                                                                                                                                                                                                          | Caution-demanding issues                                                                                                                                                                      |
|-----------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Fans            | 1. Check if the baseband subrack fan is running properly.<br>2. Check if the RF module fan is running properly.                                                                                                                                                                                                                                       | 1. To judge if the parts are working properly, refer to "Chapter 5 Component Indicators".<br>2. If there is anything wrong, please refer to "Chapter 3 Component Failure Handling" for advice |
| Board or module | 1. Check if the indicators of all boards and modules are working properly.<br>2. Check all the RF modules and units (including BTRM, BHPA, RLDU, CDU/DFU/DDU): whether all the modules or units are secured in position, screws in the panels are properly tightened. Make sure the panel is in a seamless contact with the front of cabinet subrack. |                                                                                                                                                                                               |

## III. Dial-up test

**Table 1-6** Dial-up test

| Items                                | Instructions                                                                                                                                                                                                                                                                                      | Caution-demanding issues                                                                                                                       |
|--------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------|
| Dial-up test around the base station | 1. Conduct dial-up tests on the base station in each sector or cell.<br>2. During the dial-up test, move from sector to sector and check if the handoff is successful.<br>3. Check the power indication of the test mobile station, find out if the base station power is up to the requirements. | If you come across a problem during the test, please refer to "Chapter 2 General Fault Processing" and "Chapter 3 Component Failure Handling". |
| Driving test                         | Conduct dialup tests within the coverage area to test the base station covering range as well as the handoff function.                                                                                                                                                                            |                                                                                                                                                |

## IV. Power supply check

**Table 1-7** Power supply check

| Items                        | Instructions                                                                                                                                         | Caution-demanding issues                                                                                                                                                              |
|------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Primary Power Supply (AC/DC) | 1. Use a multimeter to measure the voltage at the power inlet.<br>2. Check the -48V power indicator<br>3. Check the indicator of lightening arrester | 1. Range of input voltage: -40V ~ 60V.<br>2. Normally the power indicators should be on all the time.<br>3. Normally the indicator of lightening arrester should be off all the time. |
| Secondary power supply (PSU) | 1. Check on the maintenance console if there is an alarm for PSU.<br>2. Check the PSU panel indicator                                                | 1. Normally there should be no PSU alarm<br>2. To judge whether the PSU is working properly, refer to "Chapter 5 Component Indicators".                                               |

## V. Lightening-proof and grounding check

**Table 1-8** Lightening-proof and grounding check

| Items   | Instructions                                                                                                                                                                                                                                             | Caution-demanding issues                                       |
|---------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------|
| Outdoor | 1. Check if the grounding clip is connected properly with the grounding devices (such as an iron tower, outdoor cabling rack and outdoor grounding bar, etc.)<br>2. Check if the outdoor grounding bar is connected properly with the grounding objects. | A multimeter can be used to help judge if the grounding is OK. |
| Indoor  | 1. Check if the indoor equipment (such as the cabinet-top PE grounding bar, indoor cabling rack) are connected properly with the indoor grounding bar.<br>2. Check if the indoor grounding bar is connected properly with the grounding objects.         | A multimeter can be used to help judge if the grounding is OK  |

## VI. Antenna and feeder check

**Table 1-9** Antenna and feeder check

| Items              | Instructions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              | Caution-demanding issues                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|--------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Antenna and feeder | <ol style="list-style-type: none"> <li>1. Check on the maintenance console whether there is an alarm related to the antenna and feeder (such as a standing wave ratio alarm).</li> <li>2. Check if the Antenna and feeder is installed and secured properly.</li> <li>3. Check if the position angle of the directional antenna of the RF antenna and feeder is set correctly (If there is a directional antenna).</li> <li>4. Check if the feeder connector is damaged.</li> <li>5. Check if the lightening arrester are damaged (one is in the device box on the antenna rack, the other is at the GPS interface on the top of the cabinet).</li> </ol> | <ol style="list-style-type: none"> <li>1. Antenna and feeder consists of the RF antenna and feeder and satellite antenna and feeder.</li> <li>2. For information about the position angle of the directional antenna, please refer to "1.1 Base Station Configuration".</li> <li>3. Whether the feeder and connector of the RF antenna and feeder are damaged can be detected by the SiteMaster</li> <li>4. Whether there is visible damage to the surface of the lightening arrester.</li> </ol> |

## **Chapter 2 General Fault Processing**

### **2.1 MS Access Network Failure**

When the MS is powered on, it will go through the following processes: system determination substate, pilot channel acquisition substate, sync channel acquisition substate, timing change substate and finally enter the mobile station idle state and receive the correct system message within the specific time. Only after going through all these processes, can the MS access the network and work properly.

#### **2.1.1 Fault Description**

The MS is unable to access the CDMA network after powered on.

#### **2.1.2 Troubleshooting**

First make sure the MS parameters (such as basic frequency, assistant frequency, and SID, NID etc.) have been correctly set, and then go through the following processes one by one to locate and eliminate problems.

##### **I. Check if the BTS is running properly**

As BTS is not running, the MS will not be able to connect to the network. The reasons that BTS is not running could be:

1) The BTS equipment is in a faulty condition, which will result in the BTS start-up failure.

2) The BTS is not configured with correct parameters, which will also result in the BTS start-up failure.

Please refer to “2.3 Base Station Initialization Failure” for fault elimination measures.

## **II. Check if there is anything wrong with the Abis signaling link**

Abis signaling link failure will also result in the MS network connection failure.

1) After the BTS start-up, if the Abis signaling link goes wrong, BSC will be unable to perform logic configuration on BTS, which will result in the MS network connection failure.

2) If the BTS has obtained the correct logic configuration, when the Abis signaling link goes wrong, the BTS will turn off the transmitting signal of the BTRM to which all its sector carrier frequencies correspond. This will result in the MS network connection failure.

Through querying the current alarms of the BTS on the OMC console or BTS local maintenance console, find out if there is an “Abis signaling link failure” alarm.

Please refer to “2.5 Abis Signaling Link Failure” for fault elimination measures.

### **III. Check if the cell has obtained the BSC logical configuration**

1) If the cell has not obtained the logic configuration, i.e. common channels for pilot frequency, synchronization, paging common channels, etc. has not been established or an overhead message update has not been performed, the MS will of course not be able to connect to the network.

Check the configuration progress report for this cell in the “BTS status” window on the OMC console: if there is no such progress reports as “Common channel established successfully” and “Overhead message updated successfully”, that means the logic configuration for this cell has not completed.

2) Sometimes the unavailability of certain physical equipment, or some operation mistakes (such as deleting a device by mistake) will result in the cell being deleted and the MS being unable to connect to the network.

Check the configuration progress report for this cell in the “BTS status” window on the OMC console: if there is a progress report saying “Cell deleted”, that means the cell has been deleted.

If the cell has not obtained the logic configuration, we need to verify the following items by checking the relevant indicators, board status and alarm messages, etc.:

- Whether the BTRM used in this cell is working properly;
- Whether the BCPM used in this cell is working properly;
- Whether the corresponding BRDM is working properly;

- Whether the optical fiber of the BTRM and BRDM is connected properly;
- Whether the BCIM is working properly;
- Whether the Abis signaling link is working properly;
- Whether the BSC is working properly;
- Whether the parameters in the BTS and BSC are in correct corresponding relations.

If there is a problem detected in a certain step, refer to the relevant chapter for proper handling measures, for example, if there is problem with the BTRM, go to “3.7 BTS Transceiver Module (BTRM)” for proper measures.

#### **IV. Cell is blocked**

If we can see from the OMC console that the logic configuration for the cell has been completed, but the MS still can not connect to the network, we can then check whether this cell has been blocked.

When a cell is blocked, the BTS will turn off the transmitting signal of the BTRM, to which the carrier of this cell corresponds, which will result in the MS network connection failure.

We can use command “DSP BTSBRDSTAT” to query the BTRM status on the OMC console and find out if the BTRM to which this cell corresponds is blocked.

If the cell is blocked, the mobile station will not be able to connect to the network until the user unblock the cell.

## **V. Check receiving channel**

If we can see from the OMC console the logic configuration for the cell has been completed, but the MS still can not connect to the network, we can then check whether the receiving channel is working properly.

If the BTS receiving channel is not working properly, it will result in heavy bit errors. As a result, the MS will lose network connection frequently. When the MS switches on, it will send a switch-on registration message to the BTS. Due to the receiving channel failure, the BTS is unable to receive the registration message and thus will not send the response back to the MS, this will result in the MS registration failure. When the registration fails, the MS will enter the system confirmation substate and start recapturing the network, when the network is captured, the MS will again activate the switch-on registration...this will go on and the MS is still unable to connect to the network.

We can use the CDMA test MS to trace the air interface message: if the MS has sent the registration message and does not receive the BTS response, the BTS inverse receiving channel must be faulty.

If there is a problem with the receiving channel, we can go through the following steps as well as checking the relevant indicators, board status and alarm messages, etc. to locate it:

- Whether the CDU (or DFU, or DDU), RLDU and BTRM are secured in place, or whether the panel screws are all tightened;
- Whether the antenna and feeder is connected properly;

- Whether the RLDU is power on and works properly;
- Whether the RLDU panel configuration selection switch “S/W” is in the correct position. Refer to “Table 6-2 Description of RLDU switches” for details about it;
- Whether the BTRM is working properly;
- Whether the BCPM is working properly;
- Whether the BTS physical configuration is correct, including the parameters of the cell and inverse searching parameters, etc.

If there is a problem detected in a certain step, refer to the relevant chapter for proper handling measures, for example, if there is problem with the BTRM, go to “3.7 BTS Transceiver Module (BTRM)” for proper handling measures.

## **VI. Check transmitting channel**

The BTRM, BHPA, CDU (or DFU, or DDU) and the antenna and feeder constitute the transmitting channel. The malfunctioning of transmitting channel will result in no BTS signal output or abnormal BTS signal output. In such case, we can still find on the OMC console that the logic configuration for the cell has been completed, but the MS will not be able to connect to the network. We can then go through the following steps as well as checking the relevant indicators, board status and alarm messages, etc. to locate the problem:

- Whether the CDU (or DFU, or DDU), BHPA and BTRM are secured in place, or whether the panel screws are all tightened;

- Whether the transmission driving component of the BTRM is working properly;
- Whether the CDU (or DFU, DDU) is working properly.
- Whether the connection between the BTRM and BHPA is secure;
- Whether the BHPA is working properly;
- Whether the connection between the BHPA and CDU (or DFU, DDU) is secure;
- Whether the feeder connection from the CDU (or DFU, DDU) to the top of the cabinet is secure;
- Whether the feeder connection from the top of the cabinet to the antenna is secure;
- Whether the blind mate in each module of the transmitting channel are secured in place.
- Whether the antenna is installed correctly;
- Whether there is a standing wave ratio alarm;

If there is a problem detected in a certain step, refer to the relevant chapter for proper handling measures, for example, if there is a problem with the BTRM, go to “3.7 BTS Transceiver Module (BTRM)” for proper handling measures.

## **VII. Check cell gain & common channel gain configuration**

If we can see from the OMC console the logic configuration for the cell has been completed, but the MS still can not connect to the network, we can then check whether the gain parameters setting is correct when we configured the cell.

When configuring the cell, we need to configure the sector gain, carrier gain, pilot frequency signal gain, synchronization channel gain

and paging channel gain, etc. If these parameters are not properly set (for example: they are set too low), the MS will not be able to capture the common channel and thus will not be able to connect to the network.

With the help of Abis-interface message tracing tool, find out whether the gain parameters carried in the Abis-Cell Setup message are correct, if not, reconfigure the BSC data configuration table.

### **VIII. Check overhead message**

If we can see from the OMC console the logic configuration for the cell has been completed, but the MS still can not connect to the network, we can then check whether the overhead message is correct.

When the MS enters the idling status, it needs to receive all the overhead message set up by the system, which include at least the following five:

The synchronization message, access parameter message, system parameter message, CDMA channel list message, Neighbor List Message. Other overhead message may vary with the network parameter settings.

If any one of the above system messages is not received, the MS will not be able to connect to the network.

Additionally, the value setting in each of the parameters in the message will directly affect the MS network connection, therefore please be careful.

With the help of the air interface signaling analyzer, it can be determined whether the MS has received all the system messages. Also, check whether the value setting in each of the parameters in the message is correct. If not, modify the BSC parameter configuration table and perform the overhead message update again.

## **2.2 Software Download Failure**

### **2.2.1 Fault Description**

Software download problems includes software download failure, maintenance console prompting failure or there being no correct prompt messages generated.

### **2.2.2 Troubleshooting**

Software download failure may be caused by the following two factors: FTP client login failure and file loading abnormally terminated by the board.

#### **I. FTP client login failure**

1) First check if the BOOTP process of the OMU is running properly:

The OMU requests the BTS IP address via BOOTP. If this process fails, the BTS IP address will not be obtained, and of course it will not be able to log in to the FTP server of BAM. Generally the BOOTP failure may be caused by a blocked link, incorrect routing or

configuration errors, etc. We need to locate and eliminate these problems one by one. Refer to “2.4 OML Failure” for details.

2) The FTP server in the BAM is not configured correctly.

The most critical cause to such problem is the FTP server configuration errors. The FTP server configuration includes the following four items: username, user password, user access path and access authority. Incorrect configuration of any of these four items may lead to user login failure and software loading failure.

The setting of the above four items are shown below:

|                   |                                                                                         |
|-------------------|-----------------------------------------------------------------------------------------|
| Username:         | OMU                                                                                     |
| Password:         | OMU                                                                                     |
| Access path:      | It must include the paths specified in the software uploading and downloading commands. |
| Access authority: | The paths for software uploading must be set as both readable and writable.             |

## **II. File loading terminated abnormally by the board**

All the files should carry the correct file header in the specific format as required. The file ID and file version in the header should match that in the activation commands released by the OMC, otherwise the board may consider the software to be downloaded is not what is expected and thus prompt exceptional errors.

## **2.3 Base Station Initialization Failure**

### **2.3.1 Fault Description**

When the base station is powered on, the system initialization aborts, which leads to the BTS start-up failure.

If such problem occurs, the RUN indicators on some boards will flash rapidly.

### **2.3.2 Troubleshooting**

There are many causes to the BTS initialization failure, and they can be summarized into the following aspects to help us locate them:

#### **I. Link failure**

The precondition of successful BTS initialization is the successful establishment of ATM link between the BCIM in the BTS and the XIE board in the BSC, i.e. the BCIM in the BTS should be able to intercept the link configuration of the XIE board in the BSC and establish the corresponding IMA/UNI. If the data configuration in the BSC is incorrect (or relevant physical link is not configured), the BCIM will not be able to intercept the link configuration and thus lead to the link establishment failure.

What's more, the BOOTP process failure and OML establishment failure will also lead to the BTS initialization failure. Please refer to "2.4 OML Failure" for details.

## **II. Clock failure**

After the BTS successfully establishing the OML, the BSC will release relevant configuration data. At this time some of the boards in the BTS will require correct clock signals to start up properly. As a result, for the initialization failure occurring after the BSC releases the configuration, we need to check the following:

- 1) Whether the BTS clock signal is correct.
- 2) Whether the clock output of the BCKM is correct.
- 3) Whether the connection between the BCKM and the GPS antenna is secure.
- 4) Whether the number of the locked satellites is more than 4.

For the above 1) and 2), please refer to “3.4 BTS Control & Clock Module (BCKM)” for handling advice, for 3), please refer to “3.12 Satellite Antenna and Feeder”. The 4) may be affected by the geographic location, if the GPS satellites are found to be less than 4, the BTS may not be able to receive reliable clock signals.

## **III. Incorrect BCPM data configuration**

BCPM configuration errors will also lead to the BTS initialization failure, thus we should carefully check each of the parameters, such as the BCPM ID, cell parameters and chip parameters, etc. Reconfigure those parameters if necessary.

## **IV. Incorrect BTRM data configuration**

BTRM data configuration error may also lead to the BTS initialization failure, thus we need to carefully check each of the

parameters, such as the BTRM ID, cell ID, cell resource pool ID and optical interface ID, etc. Reconfigure those parameters if necessary.

## **V. Incorrect physical board connection**

Possible cause to BTS initialization failure due to incorrect physical board connection:

1) The boards are not installed properly and need to be corrected;

2) The optical fiber connection fault between the BRDM and BTRM, you may need to refer to “3.2 Handling of Common Board Failure” for proper handling measures.

## **2.4 OML Failure**

### **2.4.1 Fault Description**

After the BTS is powered on, the BOOTP process fails, the attempt to establish OML signaling link of the OMC fails or the OML breaks while the BTS is running.

We can see the alarm “OML Failure” from the BTS maintenance console.

### **2.4.2 Troubleshooting**

The BTS OML connection starts from the BCKM and passes the BCIM, the XIE board of BSC, the CMUX, the LPU board of the switching subrack and the MPU board and ends at the BAM. Any problem in any link of the route may lead to the OML failure.

## **I. Failure in communication link between BCKM and BCIM**

Please refer to “Board Communication Link Failure” in the “3.2 Handling of Common Board Failure”.

## **II. Abnormal IMA group and UNI status**

If E1 connection is used for the physical layer of the OML, we can configure it to IMA or UNI mode according to the actual needs. If IMA link set status or UNI status is not correct, the OML will fail.

Through querying the dedicated status of the board on the BTS maintenance console, we can acquire the IMA link set status or UNI status.

If there is anything abnormal in the IMA link set status or UNI status, we will have to check them one by one:

- Whether E1 link is correct. It can be checked with a loopback test.
- If IMA mode is used, we need to first find out whether the multiple pairs of E1s match each other between the BTS and BSC, i.e. the No.N pair of E1s in the IMA link set at the BSC side matches the No.N pair of E1s in the IMA link set in the BTS (N=1~8).
- Whether the configuration of the MA link set of the BSC and BTS are the same.

## **III. Incorrect VCI configuration in the CMUX of the CDMA BSC Basic Management Subrack (CBMS)**

The precondition of successful establishment OML of the BTS is the successful BOOTP request. BOOTP request package requires

the MAC address field to be unique. If data duplication appears in the VCI information of the CMUX, it will lead to the duplication of MAC address field in the BOOTP request package, and thus result in the BOOTP failure and the OML establishment failure.

Solution: check the BSC configuration and make sure the data are correct and unique.

#### **IV. Incorrect BSC routing information configuration**

The OML of the BTS connects two IP gateways, i.e. the MPU in the switch subrack and the CMUX in the BM subrack in the BSC, and the uplink and downlink routing table information are different. Error in information configuration of any of the gateways will result in the OML establishment failure.

A typical example is that the BTS fails to establish the TCP connection of the OML after BOOTP request is completed successfully.

In such case, please first check the routing information of BAM and see if it can connect to the MPU board of the switch subrack properly; and then check the routing information of the CMUX and see if it can connect downwards to the BTS and upwards to the BAM. If there is an error in the routing information configuration, modify the routing configuration of the switch subrack and the routing information of the CMUX of BSC.

#### **V. Incorrect OMC data configuration**

The OMC plays a role of BOOTP Server and TCP Server during the establishment of OML. During the BOOTP process, it will first

require the OMC to configure the relevant local BOOTP information. This set of BOOTP information should be unique and in conformity with the data configuration in the BSC.

If the OMC has set up incorrect BOOTP information, the MAC field in the BOOTP request package will not match the BOOTP information, which will result in the BOOTP request failure and OML establishment failure.

Solution: Query the BOOTP information of the BTS in the OMC, and compare it with the data configuration in the BSC, change those data that do not match.

## **VI. Remote OMC failure**

The remote OMC plays a role of BOOTP Server and TCP Server during the establishment of OML. Therefore, the remote OMC failure will result in OML failure. The possible OMC failure includes:

1) BAM system collapse or BAM process not started. In such case, BAM process or BAM system must be restarted.

2) The loading process of BAM appears abnormal -- you may need to restart the BAM loading process.

3) BAM bottom-layer communication process (Exchange Server) appears abnormal -- you may need to restart the BAM bottom-layer communication process.

## 2.5 Abis Signaling Link Failure

### 2.5.1 Fault Description

After the BTS start-up, the Abis signaling link between the BTS and BSC can not be established, or there are sometimes broken links when the BTS is running.

From the BTS maintenance console, we can see the alarm “Abis signaling link failure”.

### 2.5.2 Troubleshooting

#### I. Abnormal IMA group or UNI status

Please refer to “2.4 OML Failure” for details.

#### II. Incorrect Abis signaling link parameter configuration

If the IMA link set status and the UNI status are normal, and the BTS has obtained the configuration data, check if the Abis signaling link configuration is correct.

Abis signaling link uses the IPOA mode, which requires configuration of the following parameters: the PVC parameter (VPI and VCI) of the Abis signaling link, the TCP/IP address (IP address, subnet mask and TCP port ID.) We also need to make sure that the PVC used by the Abis signaling link is different from that used by the Abis service.

### **III. BSC failure**

When a BSC failure occurs, the BTS will also generate a “Abis signaling link failure” alarm.

## **Chapter 3 Component Failure Handling**

### **3.1 Component Failure Description**

#### **3.1.1 Component Failure Detection**

In this chapter, we will explain how the failure is spotted. The following sections will provide the failure type definition and solutions for the specific components.

The components here include the baseband board, RF module, power module, antenna and feeder equipment, etc. If something goes wrong with any of them, we can check the relevant alarm boxes, maintenance console and the component indicators for information about the component failure.

#### **3.1.2 General Handling Procedure**

When handling component failure, generally we should go “from outside to inside”. The transmission link check and GPS receiving signal check are external checks while the check on the boards and modules are internal checks. The purpose of making such division is to help us better understand the handling procedure. The external check is actually combined with the internal check.

## **I. External check**

### **1) Power supply**

Mainly check if the - 48 DC power input is normal, see “1.2 Maintenance Instructions” for details.

### **2) Transmission link**

Check if the transmission link between the BCIM of the BTS and the XIE board of the BSC is secure, see “3.3 BTS Control Interface Module (BCIM)” for details.

### **3) GPS receiving signal**

GPS signal is directed into the BCKM and processed by the clock unit after received by the GPS antenna and feeder system, see “3.4 BTS Control & Clock Module (BCKM)” for details.

## **II. Cabinet components**

First check the PSU of the power subrack, and then the boards (including BCIM, BCKM, BCPM, BRDM and BTRM), and finally the RF units (including the BHPA, CDU/DFU/DDU, RLDU and the antenna and feeder system).

### **1) Power supply**

Mainly check the PSU in the power subrack. If a PSU failure is spotted, you should check if the - 48V DC power inlet on top of the cabinet is in normal condition while going through the “3.10 Power Supply Unit (PSU)” for solutions.

## 2) Boards

Check the BCIM and the transmission link - only when these two parts are working properly, can the BTS establish a link with the BSC successfully.

Check the BCKM and the GPS receiving signals - only when these two parts are working properly, can the other BTS boards work normally.

Check if the BCPM is working properly.

Check if the BRDM is working properly – only so, can the BTRM work properly.



### **Note:**

The BTS boards have quite a lot in common, therefore, the problems appearing in these boards may look similar. When locating the board failure, you can first see “3.2 Handling of Common Board Failure” for advice. If the problem still cannot be solved, please turn to other sections in which this board is involved.

---

## 3) RF components

Transmitting channel: the BTRM signal is sent to the CDU (or DFU, DDU) and then sent to the antenna and feeder for transmitting.

Receiving channel: The RF signal, after being received by the antenna and feeder system, is sent to the CDU (or DFU, DDU) and then received and distributed to the relevant BTRM for processing by the RLDU.

Check the BHPA, CDU (or DFU, DDU) and RLDU and the antenna and feeder system in the transmitting and receiving channels. If a problem is spotted, go to the specific section in which that faulty component is described for advice and solutions.

## 3.2 Handling of Common Board Failure

### 3.2.1 Fault Description

Common Board Failure includes:

- Board parameter configuration error;
- Board communication link failure;
- Abnormal board temperature;
- Extraordinary CPU usage;
- Emergency serial link broken;
- Initialization failure of minor board components;
- No signal detected at the optical interface;
- CELL BUS clock missing;
- Abnormally high CELL BUS subrack error rate;
- CELL BUS driving components failure;
- Board reset.

All the above failures will have relevant alarms generated.

### 3.2.2 Troubleshooting

#### I. Incorrect board parameter configuration

After the BOOTP request is successfully completed and the OML with the OMC is successfully established, the BTS will check if a BTS configuration file is locally available. If so, it will issue the configuration data locally, otherwise the BCKM will download the BTS configuration file from the remote OMC.

If the configuration file download fails, the board will not be able to obtain the correct parameter configuration, and thus the BTS will not start up properly. Possible causes of file download failure are:

- 1) Correct file loading information has not been set up in the OMC, or the configuration file is not correct;
- 2) There is no relevant BTS configuration files in the file loading directory in the OMC;
- 3) The OMC FTP Server has not been started or it is not running properly;
- 4) The specific file path, file attributes and user information are not configured correctly in the FTP Server.

In such case, we have to check the above possibilities and eliminate faults one by one (we can perform such operations from the OMC console). For other possible failure causes and solutions, we can turn to “2.2 Software Download”.

## **II. Board communication link failure**

When the board is powered on and the initialization is complete, it (any board other than the BCKM) will send a configuration request to the OMU on the BCKM. After receiving correct configuration, it shall start working. If the ALM and ACT indicators flash at a frequency of 4Hz, there should be a communication link failure between the board and the OMU.

- 1) If there is only one board (for example: BCIM) generating alarm, check if that board is plugged and secured properly and then reset it. If the problem sustains, replace that board.

- 2) If other boards are generating alarms at the same time, there may be a problem with the BCKM, refer to “3.4 BTS Control & Clock Module (BCKM)” for solutions.
- 3) If the problems still can not be solved with the above two steps, there must be something wrong with the backplane of the baseband subrack. Replace it.

### **III. Abnormal board temperature**

If the baseband subrack has an abnormal board temperature, we first need to find out if the baseband subrack fan module is working properly or if the ventilation channel is blocked; If the BTRM has an abnormal temperature, we will have to find out if the BTS RF Fan Module (BRFM) is working properly.

If the problems sustain after we have gone through the above possibilities, it should be the relevant board failure and it needs to be reset or replaced.

### **IV. No signal detected at the optical interface**

Such problem mainly occurs in the BRDM and BTRM. Here we first need to check the relevant optical interface and see if the optical fiber is plugged in properly or if the boards and modules at both sides of the cable are working properly, or if it is damaged or broken. If so, go to the relevant sections in this chapter for solutions. If all other possibilities have been eliminated, there must be something wrong with certain board or module, reset or replace them.

### **V. Other faults**

Other possible common failures include:

Board reset, CPU overusage, emergency serial port link breakage, initialization failure of minor board components, missing CELL BUS clock, abnormally high CELL BUS subrack error rate and CELL BUS driving components failure, etc.

If the above problems occur occasionally or if it lasts for just a short time, we can keep them under monitoring; if they occur frequently (or appear long-lasting) and have seriously impeded the BTS operation, we have to find out if there are other accompanying problems and then go to the relevant sections in this chapter for handling advice and solutions or have the board reset or replaced if necessary.

## **3.3 BTS Control Interface Module (BCIM)**

### **3.3.1 Fault Description**

**I. BTS is unable to establish operation & maintenance link with OMC after power-on**

**II. The operation & maintenance link, signaling link and service link are broken while BTS is running**

### **3.3.2 Troubleshooting**

#### **I. E1 trunk cable failure or incorrect connection**

The E1 trunk cable connection between the BTS and BSC should be correct (when multiple E1s are configured, the connecting

order between the BTS and BSC should be the same), only so can the BTS intercept the IMA/UNI configuration in the BSC.

The E1 trunk cable problem or the connecting order mistakes can be located by the E1 loopback test.

The IMA/UNI configuration can be obtained by querying the dedicated status of the BTS boards.

## **II. BSC interface board (XIE) failure**

If E1 trunk cable is found in good connection and the connecting order is correct after the E1 loopback test, there must be something wrong with the BSC interface board (XIE). Reset or replace the XIE.

## **III. BSC and OMC failure or incorrect configuration**

If we find out the status of the link and the IMA link set of the BCIM are normal by querying the dedicated status of the BTS board while the problem still sustains, it could be the BSC or OMC failure or data configuration errors. Refer to “2.4 OML Failure” and “2.5 Abis Signaling Link Failure” for details.

## **3.4 BTS Control & Clock Module (BCKM)**

### **3.4.1 Fault Description**

**I. Failure in establishing OML between the BTS and OMC**

**II. Failure in establishing Abis signaling link between the BTS and BSC**

**III. Clock failure**

**IV. Other faults**

### **3.4.2 Troubleshooting**

**I. Failure in establishing OML between the BTS and OMC**

The OMU of the BCKM is responsible for establishing OML signaling link with OMC. If the link establishment fails, please refer to “2.4 OML Failure” for handling advice and solutions.

**II. Failure in establishing Abis signaling link between BTS and BSC**

The MC unit of the BCKM is responsible for establishing Abis signaling link with BSC. If the link establishment fails, please refer to “2.5 Abis Signaling Link Failure” for handling advice and solutions.

### **III. Clock failure**

The CLK unit of the BCKM is responsible for receiving and processing the GPS clock signals. Possible clock unit failures include: hardware failure of the clock module, satellite antenna and feeder system failure, failure in reference clock source driving and master clock unlocked, etc.

When the above-mentioned problems arise, check and eliminate the satellite antenna and feeder system failure first, and then reset the BCKM. If the problems sustain, replace that BCKM.

### **IV. Other faults**

The power module failure in the master cabinet and the fan module failure in the baseband subrack are also reported to the BCKM and are grouped into “other faults”. If the fan module in baseband subrack is faulty, replace the fan module. If the power supply module in the master cabinet is faulty, refer to “3.10 Power Supply Unit (PSU)” for handling advice and solutions.

## **3.5 BTS Channel Process Module (BCPM)**

### **3.5.1 Fault Description**

**I. System clock error**

**II. Reverse data error in the gigabit ethernet link**

**III. FPGA status error**

**IV. Internal Error in the Channel processing Chip**

**V. Clock error in the Channel processing Chip**

**VI. Hardware module error in the board**

### **3.5.2 Troubleshooting**

**I. System clock error**

For system clock errors, please refer to the “3.4 BTS Control & Clock Module (BCKM)” for handling advice and solutions.

**II. Reverse data error in the Gigabit Ethernet link**

For reverse data error in the Gigabit Ethernet link, we need to check if the BRDM connecting to the BCPM via the backplane is working properly, please refer to “3.6 BTS Resource Distribution Module (BRDM)” for handling advice and solutions.

### **III. FPGA status error**

For FPGA status errors, reload the FPGA software first. If the problem sustains, it should be the hardware problem in the board. Replace that faulty board.

### **IV. Other faults**

For other faults as well as those still not solved after we going through the above steps, reset the relevant BCPM first. If that still does not work, replace the faulty BCPM.

## **3.6 BTS Resource Distribution Module (BRDM)**

### **3.6.1 Fault Description**

**I. FPGA status error**

**II. The bottom-layer communication link between the BRDM and BTRM is broken**

**III. Abnormal clock signal**

**IV. Hardware failure of the board**

### **3.6.2 Troubleshooting**

**I. FPGA status error**

For FPGA status errors, reload the FPGA software first. If the problem sustains, it should be the hardware problem in the board. Replace that faulty board.

**II. The bottom-layer communication link between the BRDM and BTRM is broken**

If the bottom-layer communication link between the BRDM and BTRM is broken, it may be because the bit error rate (BER) in the communication link is too high, or the board is not working properly.

Pull out and replugin the optical fiber or replace the BTRM. If the fault still remains, , reset or replace the BRDM.

### **III. Abnormal clock signal**

The clock signal needed by the BRDM for controlling the service switching comes from the BCKM. If the problem sustains after the BCKM faults are eliminated, try to load the FPGA logic configuration. If that still does not work, the hardware must be faulty, replace that faulty BRDM.

### **IV. Hardware problems in the board**

For hardware problems in the board, all we can do is to replace that faulty board.

## **3.7 BTS Transceiver Module (BTRM)**

### **3.7.1 Fault Description**

**I. Receiving channel over-excited**

**II. Software phase-lock unlocked**

**III. Abnormal forward link power**

**IV. Alarm on abnormal reverse signal strength**

**V. RS485 link failure alarm**

**VI. Other faults in the BTRM**

Other faults in the BTRM include: transmitting channel clock unlocked, hardware phase-lock unlocked, abnormal  $I_0$  value and the digital down frequency-converter failure.

**VII. BTS RF Fan Module failure**

RF fan module failures include:

the BTS Fan Monitor Module is unable to read the temperature sensor;

the fan is not running properly;

the BTS Fan Monitor Module generates a high-temperature alarm;

and the fan monitoring board is unable to control the fan speed.

## **3.7.2 Troubleshooting**

### **I. Receiving channel over-excited**

Remove the fault according to the following procedures step by step.

- 1) If the problem is caused by the external interference, nothing needs to be done to the BTS, but try to reduce the external interference.
- 2) If the problem is caused by the FPGA logic failure, reset the BTRM.
- 3) Replace the BTRM.

### **II. Software phase-lock unlocked**

Such problem can be solved automatically if it is not caused by hardware failure, and it generally will take 5 minutes. If the problem lasts for a long time, follow the handling process below. Go to next step if the problem cannot be solved with the current one.

- 1) Eliminate the BRDM failure;
- 2) Replace the relevant optical fiber;
- 3) Replace the BTRM.

### **III. Abnormal forward link power**

Abnormal forward link power may yield interference on the adjacent cells. Follow the handling process below. Go to next step if the problem cannot be solved with the current one.

- 1) Check if the BRDM, BCPM or BCKM are secured in place;
- 2) Replace the relevant optical fiber;

- 3) Eliminate the BRDM, BCPM and BCKM faults;
- 4) Replace the BTRM.

#### **IV. Alarm on reverse signal strength indicator abnormal**

Abnormal reverse signal strength may block the reverse service link. Check the antenna and feeder system for possible problem causes.

#### **V. RS485 link failure**

RS485 link failure will block the alarm messages of the fan monitoring board from being reported to the BTRM, and thus result in the closed-loop power control failure. Follow the handling process below. Go to next step if the problem cannot be solved with the current one:

- 1) Reinstall the relevant BHPA after power-off, then power on again;
- 2) Replace the fan monitoring board (or the relevant BTS RF Fan Module);
- 3) Replace the BTRM ;
- 4) Replace the RF backplane.

#### **VI. Other problems with the BTRM**

Other problems with the BTRM include:

Transmitting channel clock unlocked, hardware phase-lock unlocked, abnormal  $I_0$  value and the digital down frequency-converter failure.

If the above problems are not solved after the relevant BTRM has been reset, replace that module.

## **VII. BTS RF fan module failure**

RF fan module failures include:

- The fan monitoring board is unable to read the temperature sensor;
- The fan is not running smoothly;
- The fan monitoring board generates a high-temperature alarm;
- The fan monitoring board is unable to control the fan speed.

Follow the handling process below. Go to next step if the problem cannot be solved with the current one:

- 1) Check if the fan cover is correctly and reliably connected;
- 2) Replace the fan monitoring board or the relevant BTS RF Fan Module.

## **3.8 BTS High Power Amplifier Unit (BHPA)**

### **3.8.1 Fault Description**

#### **I. No RF signal output**

#### **II. Abnormal RF signal output including insufficient output power and excessive output spectrum**

### **3.8.2 Troubleshooting**

#### **I. No RF signal output**

The reasons for no RF signal output in the BTS High Power Amplifier Unit are: self-protection shutdown, module damage and cable/connector connection failure.

##### **1) Self-protection shutdown:**

For self-protection purpose, the BTS High Power Amplifier Unit will automatically shut down in case of Power Amplifier Over-Excited alarm and Module Over-Heated alarm.

##### **a) Power amplifier over-excited alarm:**

The Power Amplifier Over-Excited alarm indicates the electrical level of the input RF signal of the BHPA. When the electrical level of the input RF signal is between +0.5dBm and +1.5dBm, the BHPA will generate the Power Amplifier Over-Excited alarm, but will not automatically shut down; When the electrical level of the input RF signal is greater than +2.5dBm, the BHPA will generate the Power

Amplifier Over-Excited alarm as well as automatically shut down; If the external alarm conditions are eliminated, the BHPA will resume to the normal working status.

b) Power amplifier over-heated alarm:

The Over-Heated alarm indicates the temperature changes of the BHPA. When an Over-Heated alarm is generated, the BHPA will shut down automatically. When the temperature of the BHPA is between 90°C~100°C, the BHPA will also generate an Over-Heated alarm and shut down automatically. The restoration threshold of the Over-Heated alarm is 75°C~85°C.

Find out if there is a Power Amplifier Over-Excited alarm or Module Over-Heated alarm by querying the current alarms from the OMC or BTS local maintenance console.

The fault elimination process should be carried out step by step, go directly to next step if the problem can not be solved:

- Check if the RF output power of the BTRM is too high, if so, decrease it.
- Check if the fan for BHPA is working properly.
- Check if the cable connecting the Power Amplifier module of the BHPA and the RF fan monitoring board are in good condition.

2) Faulty cable/connector connection

BHPA uses blind mate to connect to the BTRM, CDU (or DFU, DDU) and power source via the backplane. Abnormal input/output connection will result in the BHPA having no RF signal output.

The fault elimination process should be carried out step by step, go directly to next step if the problem can not be solved:

- Re-plug the BHPA, make sure it is secured in place and connected to the backplane properly. Tighten the screws;
- Check if the cable on the backplane connecting the BTRM and BHPA, BHPA and the CDU (or DFU, DDU), power source and the BHPA are getting loose or pulled off.

Check if the BHPA module is damaged.

If the BHPA is powered properly, the cable/connector are intact and the signal input is normal while the BHPA still has no RF signal output, the BHPA must be damaged and needs to be replaced.

## **II. Abnormal RF signal output**

The Abnormal RF signal output of the BHPA means the output power is lower than the rated value, the Adjacent Channel Power Ratio (ACPR) of the output signal is above the acceptable level.

The main causes are: 1) the Power Amplifier gain is decreasing; 2) some of the Power Amplifier components are damaged; 3) power output is too high. Abnormal Power Amplifier gain decrease will generate relevant alarms; and if the input/output power is too high, it will cause the Power Amplifier output spectrum to spread and the ACPR to get above the acceptable level.

The gain decrease alarm indicates the working status of the amplification channel of the BHPA. The alarm threshold is 3~6dB of the power-amplification gain decrease. When the BHPA gain decreases up to 6dB, an alarm will be generated; if it drops to 3dB or below, the

alarm will stop. If the power-amplification gain decrease is within 3~6dB, it is a normal situation whether the alarm is generated or not.

We can find out if there is a "Power-amplification gain decrease" alarm by querying the current alarm of the BTS on the OMC or local maintenance console.

The fault elimination process should be carried out step by step, go directly to next step if the problem can not be solved :

- Check if the power output of the BHPA is too high. If so, decrease it;
- Replace the BHPA.

## **3.9 Receive LNA Distribution Unit (RLDU)**

### **3.9.1 Fault Description**

#### **I. Standing wave alarm of antenna and feeder**

#### **II. RLDU failure**

### **3.9.2 Troubleshooting**

#### **I. Standing wave alarm of antenna and feeder**

When the antenna goes wrong, it will cause the standing wave ratio to increase; or if the connection between the antenna and the feeder is abnormal or there is a feeder failure, the standing wave alarm of antenna and feeder will be generated.

The fault elimination process should be carried out step by step, go directly to next step if the problem can not be solved:

- 1) Check if the antenna and feeder are in good condition;
- 2) Check if the CDU (or DFU, DDU) is working properly;
- 3) Check if the cable connecting the CDU (or DFU, DDU) and the RLDU is in good condition;
- 4) Check if the power indicator on the panel of the RLDU is working properly;
- 5) Replace the RLDU.

## **II. RLDU failure**

When there is an alarm generated on RLDU failure, replace the faulty RLDU.

## **3.10 Power Supply Unit (PSU)**

### **3.10.1 Fault Description**

**I. The power module is not working or not working properly**

**II. The power module fan is not running properly**

**III. The voltage of the power output of the power module is too high**

**IV. The voltage of the power input of the power module is too low**

**V. The power module is over-heated**

### **3.10.2 Troubleshooting**

**I. The power module is not working or not working properly**

When the three indicators on the panel of the power module are all flashing or all gone off, it indicates the power module is not working properly and there is an unexpected internal problem, the module needs to be replaced.

**II. The power module fan is not running properly**

When there is problem with the power module fan, the relevant alarm indicator on the module panel will be on and the fan failure will be reported. Replace the fan of the power module.

### **III. The voltage of the power output of the power module is too high**

When the output voltage of the power module is at  $30.5\pm0.5V$ , the module will shut down automatically and the alarm indicator (Alm) on the power module panel will be on. An overvoltage alarm will be reported. Such problem will not be solved automatically, therefore the power module should be replaced.

### **IV. The power module is over-heated**

When the ambient temperature of the power module is too high or the heat dissipating system is not working properly, the power module will be overheated and stop working. The alarm indicator on the module panel will be on and report an overheat alarm. When the temperature decreases to an acceptable level, the module will automatically start working again.

If the ambient temperature is OK and the module fan is running but the module is still too hot, there must be something wrong with the module itself. It will have to be replaced then.

### **V. The voltage of the power Input of the power module is too low**

The input voltage of the power module is a negative value, therefore, when the absolute value of the input voltage is less than  $36.5\pm1V$ , the power module will stop working. The alarm indicator on the module panel will be on and report an undervoltage alarm. When the absolute value of the input voltage is greater than  $38.5\pm1V$ , the power module will resume to normal working status automatically.

## **3.11 The RF Antenna and Feeder**

### **3.11.1 Fault Description**

#### **I. The RF antenna and feeder is not working properly**

### **3.11.2 Troubleshooting**

The RF antenna and feeder failure will generate a standing wave alarm, and there will be no transmit power at the antenna port or the transmit power is too low.

When such a problem occurs, we can check the standing wave ratio and transmit power (including testing the transmit power at the coupling-output port of the CDU (or DFU, DDU) panel: Tx-Test) starting from the antenna port in the CDU (or DFU, DDU) to the antenna in the BTS. Check the following to locate the problems:

- 1) Water infiltration in the antenna and feeder system;
- 2) Antenna, feeder and jumper damaged;
- 3) BTS antenna and jumper disconnected or in poor contact;
- 4) Feeder and jumper disconnected or in poor contact;
- 5) The connection between the cabinet-top jumper and the cabinet-top connector disconnected or in poor contact;
- 6) The connection between the internal cabinet jumper and CDU (or DFU, DDU) disconnected or in poor contact;
- 7) The feeder and jumper connector were not installed correctly.

## **3.12 Satellite Antenna and Feeder**

### **3.12.1 Fault Description**

#### **I. The satellite antenna and feeder is not working properly**

### **3.12.2 Troubleshooting**

When satellite antenna and feeder gets faulty, the alarm of antenna open-circuit or the antenna short-circuit will be generated.

When such problem arises, we need to check if the connectors are fixed tightly and correctly or if the seal is getting loose or missing. Check the following to locate the problems:

- 1) Water infiltration in the antenna and feeder system;
- 2) The antenna, feeder and jumper are damaged;
- 3) The lightning arrester of the satellite antenna and feeder is damaged;
- 4) Satellite antenna and jumper connection disconnected or in poor contact;
- 5) The feeder and jumper connection disconnected or in poor contact;
- 6) The connection between the cabinet-top jumper and the cabinet-top connector disconnected or in poor contact;
- 7) Internal cabinet jumper and SMA connector on the BCKM panel disconnected or in poor contact;
- 8) SMA connector and GPS receiving card disconnected or in poor contact.

## **Chapter 4 Component Replacement**

### **4.1 Common Procedure of Replacement**

#### **4.1.1 Board Replacement**

##### **I. Preparations for Board Removing**

###### **1) Alarm query:**

Before replacing the board, query the BTS alarm from the OMC console and make notes of it. After the board is replaced, query the alarm again and check if the alarm is cleared and if there is a recovery alarm.

###### **2) Version check:**

Before replacing the board, check the version of the board and its software and make notes. Conduct the query again after the board is replaced and check if the version is the expected one.

###### **3) Safety precautions:**

Boards or modules are sensitive to static electricity and can be damaged by them. Therefore, anti-static measures must be taken when handling the board or module, e.g. wear anti-static gloves or wrist strap which should be ensured to be properly grounded.

###### **4) Power supply cut-off:**

Cut off the power supply to the board to be replaced, and resume the power supply after the board is replaced.

The power supply to all the boards in the baseband subrack is controlled by the baseband subrack switch. There are two cases for replacing the boards of baseband subrack:

- Power off the baseband subrack to replace the BCIM or BCKM (when the BTS has only one BCKM equipped).
  - Leave the baseband subrack power on, and replace the BRDM, BCPM and BCKM (when the BTS has two BCKMs equipped - for active/standby purpose).
- 5) Sector carrier blocking:

When replacing the boards of the baseband subrack, we will have to block those sector carriers that would be affected during the replacement process. We can unblock them after the replacement is finished.

If we operate directly on the BTRM power switch, the block/unblock operation can then be skipped.

6) Common tools:

A crosshead screwdriver for driving M3 screws is needed when replacing the boards or modules.

## **II. Board Removing**

- 1) Loosen and remove the screws on the board panel counter-clockwise.
- 2) Hold the board upper and lower handles with both hands, pull outwards and rotate 45 degrees. The board will then be detached from the backplane.
- 3) Pull out the board along the slot and put it into the anti-static bag and keep it in the packing box (DO NOT

touch the surface of the printed circuit board with hands during the process).

### **III. Installation Preparations**

- 1) Wear grounded wrist straps or gloves.
- 2) Before installing a board, take the board out from the anti-static bag and check if there are any damaged or missing components (Do not touch the board surface with bare hands).

### **IV. Board Installation**

- 1) Locate the slot for the board.
- 2) Hold the board handle bar with one hand and plug the board in along the guide slot. Be sure to press it down to the bottom until the board surface aligns with the subrack, press the upper and lower handle bars inwards to lock it up.
- 3) Tighten the screws on the board panel.
- 4) Resume the power supply after the board replacement is finished, check the relevant indicator to see if the board is running properly.

### **V. Replacement Completed**

After the replacement is completed, check the result in the following three aspects:

- 1) Check the relevant indicator status. Refer to “Chapter 6 Component Indicators” for details.
- 2) On the local maintenance console and the OMC remote maintenance console, check if the relevant BTS alarm is

cleared and a recovery alarm is generated at the same time.

- 3) Do a dial-up test with an MS and see if the BTS is working properly.

## **4.1.2 Backplane Replacement**

### **I. Replacement Preparations**

- 1) Safety precautions

Be sure to take anti-static measures when handling the backplane. Follow the operation procedures strictly so as to prevent the static electricity from damaging the board. The backplane replacement must be done with the power off and relevant operation procedures must be strictly followed. Wear anti-static wrist strap or gloves and connect the grounding end with the ground properly (the switch housing).

- 2) Power supply cut-off

Cut off the power supply for the whole BTS cabinet before doing the replacement.

- 3) Common tools

A crosshead screwdriver for driving M3 screws is needed when replacing the backplane.

- 4) Detach the BTS cabinet door
  - Loosen the BTS door screws;
  - Take the door apart from the cabinet;
  - Rest the door in a safe place.
- 5) Take the boards or modules apart from the backplane

Unplug the cables connecting the boards or modules to the backplane and take the boards or modules out.

6) Unplug the backplane cables

Unplug the cables on the back of the backplane, such as the data cable, alarm cable, power cable, etc. Make notes of the cable connection mode and order.

7) Take off the metal shielding (For baseband subrack only)

Before removing the backplane of the baseband subrack, take off the metal shielding. To do this: Unscrew the bolts that fix the shielding to the cabinet. Be sure to keep the bolts safe and do not let them fall into the cabinet, for that may cause short-circuiting.

## II. Remove the backplane

- 1) Loosen and remove the screws that fasten the backplane onto the cabinet. Be careful to keep the screws in a safe place and not to drop the screws in the cabinet, or it may cause a short-circuit.
- 2) Take the backplane down slowly with both hands.



### **Note:**

1. For detaching the backplane from the baseband subrack, remove its metal shielding cover first. Put the shielding cover back when the baseband backplane is installed.
  2. As the backplane is huge in size and rather heavy, to prevent an accident, get some people to help when handling it.
-

### **III. Installation preparations**

Before installing the backplane, take the backplane out from the anti-static packing box. Check whether there are any damages such as damaged cables and short-circuit (Do not touch the backplane surface during the process).

### **IV. Installation of the backplane**

- 1) Align the backplane with the plug subrack, and screw it down tightly.
- 2) Backplane cables

Connect all the cables correctly according to the order you noted when disconnecting them.

- 3) Backplane switch setting

If there are dip switches and jumpers on the backplane, set them back to the original status.

- 4) Affix the backplane nameplate

### **V. Replacement Completed**

- 1) Power on and off the backplane (for the baseband backplane only)

Power on the baseband subrack, if everything on the backplane appears OK, switch off the power.

- 2) Plugging the boards

Plug all the boards or modules back in - be very careful not to damage the backplane slot. Restore all the cables on the board or module.

- 3) Power on the boards or modules and check their working status
- 4) Install the metal shielding cover (for baseband backplane only) and the cabinet doors.
- 5) Use a MS to have a dial-up test and see if the conversation is successful

---

## 4.2 Exceptional Procedure of Replacement

---



### **Note:**

1. This procedure is based on the “4.1.1 Board Replacement”.
  2. As we are going to focus on the parts different from the common replacement procedure, be sure to get familiar with the “4.1.1 Board Replacement” first. Follow the procedure exactly throughout the replacement process.
- 

### 4.2.1 BTS E1 Surge Protector (BESP)

The physical structure and installation position of BESP are rather different from those of the boards in the baseband subrack, therefore, while basically observing the “4.1.1 Board Replacement” (some processes, such as the board removal and installation, are not applicable to BESP and thus, can be handled flexibly), we should also pay attention to the following:

#### **I. The influence on the service**

Replacing a BESP may interrupt all the services transmitted through it.

#### **II. Cut off and resume the power supply**

Before replacing the board, we should toggle off all the switches in the BTS switch box one by one (first the switch for the RF module, then the baseband subrack, then the fan and then the power

module), and then switch off the -48V DC output of the AC/DC power supply.

After the replacement is finished, toggle on all the switches on an order contrary to the switching-off order.

### **III. Take down the BESP**

Unfix the bolts of the semi-sealing cover on the BESP, remove the cover, Unplug the E1 trunk cables of two 25-pin interfaces on the BESP and unscrew the screws at the four corners of BESP to dismount the BESP at the top of the equipment.

### **IV. Install the new BESP**

Install the new BESP at the top of the equipment and fasten the bolts on the four angles of the new BESP, connect the trunk cables at the 25-pin interface. Finally install the semi-sealing cover.

## **4.2.2 BTS Control & Clock Module (BCKM)**

While basically observing the “4.1.1 Board Replacement”, we should also pay attention to the following:

### **I. The influence on the service**

A BTS usually is equipped with two BCKMs, which work in an active/standby mode. When the active board gets out of order, the service will be automatically switched over to the standby board. In such case, the faulty board can be replaced directly. However, if the BTS is equipped with only one BCKM, the replacement of it will interrupt all the BTS services.

## **II. Handling clock cables**

Before replacing the BCKM, disconnect the clock cable from the BCKM. Screw the clock cable back onto the panel of the new BCKM after the replacement is finished.

### **4.2.3 BTS Control Interface Module (BCIM)**

While basically observing the “4.1.1 Board Replacement”, we should also pay attention to the following:

#### **I. The influence on the service**

Replacing a BCIM may interrupt all the services transmitted through it.

#### **II. Handling DIP switch and jumpers**

Before putting on the new BCIM, make sure the setting of the impedance matching jumpers (J6) and DIP switches (S2~S9) is the same as that of the replaced board.

### **4.2.4 BTS Channel Process Module (BCPM)**

While basically observing the “4.1.1 Board Replacement”, we should also pay attention to the following:

#### **I. The influence on the service**

Generally, replacing a BCPM may interrupt all the services transmitted through it. If the BTS is equipped with several BCPMs

and a “daisy chain” between those boards, the service will not be seriously affected.

## **4.2.5 BTS Resource Distribution Module (BRDM)**

While basically observing the “4.1.1 Board Replacement”, we should also pay attention to the following:

### **I. The influence on the service**

Replacing a BRDM may interrupt all the services transmitted through it.

### **II. Handling optical fibers**

Before replacing the BRDM, disconnect the optical fiber cable from the board (make notes of the optical interface to which each optical fiber corresponds). Connect the optical fiber cable back on the new BRDM after the replacement is finished.

Take caution when plugging and unplugging the optical fiber. If the fiber connector has a locker tab, remember to press it down when unplugging the connector.

## **4.2.6 BTS FAN Module (BFAN)**

The physical structure of BFAN is rather different from that of the boards in the baseband subrack, therefore, while basically observing the “4.1.1 Board Replacement” (some processes, such as the board removal & installation and the MS dial-up test, are not applicable to BFAN and thus, can be handled flexibly), we should also pay attention to the following:

## **I. Heat dissipation**

Replacing the BFAN will have some influence on the heat dissipation of the baseband subrack

## **II. Handling screws**

Keep the BFAN fastening screws in a safe place, as they will be used to fasten the new BFAN.

### **4.2.7 Power Supply Unit (PSU)**

The physical structure of PSU is rather different from that of the boards in the baseband subrack, therefore, while basically observing the “4.1.1 Board Replacement” (some processes, such as the board removal & installation and the MS dial-up test, are not applicable to PSU and thus, can be handled flexibly), we should also pay attention to the following:

#### **I. The influence on the power supply**

Since the PSU is configured in a n+1 backup mode, when a PSU is out of service, the power supply to the whole system will not be affected. Thus we don't have to worry about the influence of replacing a PSU on the power supply.

### **4.2.8 BTS RF Fan Module (BRFM)**

The physical structure of BRFM is rather different from that of the boards in the baseband subrack, therefore, while basically observing the “4.1.1 Board Replacement” (some processes, such

as the board removal & installation and the MS dial-up test, are not applicable to BRFM and thus, can be handled flexibly), we should also pay attention to the following:

### **I. The influence on the service**

If a certain BRFM does not work properly, we need to switch it off from the BTS switch box before replacing it (note that a switch serves a group of BHPA, BTRM and BRFM).

### **II. Handling optical fibers**

When putting on the new BRFM, remember to put the optical fiber in the notch in the lower-right corner of the module.

### **III. Handling relevant cables**

When detaching the BRFM, remember to disconnect the cables on it (make notes of the cabling destination so that the cables can be plugged back in correctly). When the new BRFM is installed, connect the cables on it correctly.

## **4.2.9 BTS High Power Amplifier Unit (BHPA)**

The physical structure of BHPA is rather different from that of the boards in the baseband subrack, therefore, while basically observing the “4.1.1 Board Replacement” (some processes, such as the board removal & installation and the MS dial-up test, are not applicable to BHPA and thus, can be handled flexibly), we should also pay attention to the following:

### **I. The influence on the service**

If a certain BHPA does not work properly, we need to switch it off from the BTS switch box before replacing it (note that a switch serves a group of BHPA, BTRM and BRFM)

### **II. The influence on the relevant components**

Before detaching the BHPA, first detach the BRFM to which it corresponds -- see “4.2.8 BTS RF Fan Module (BRFM)” for details about BRFM detachment. When the BHPA is installed, put the corresponding BRFM back.

### **III. Installing BHPA**

When installing the BHPA, make sure the module panel is in a seamless contact with the front edge of the subrack and then tighten the screws, or the RF transmission may not be able to meet the index.

## **4.2.10 BTS Transceiver Module (BTRM)**

While basically observing the “4.1.1 Board Replacement”, we should also pay attention to the following:

### **I. The influence on the service**

If a certain BTRM does not work properly, we need to switch it off from the BTS switch box before replacing it (note that a switch serves a group of BHPA, BTRM and BRFM).

## **II. The influence on the relevant components**

Before detaching the BTRM, first detach the BRFM to which it corresponds -- see “4.2.8 BTS RF Fan Module (BRFM)” for details about BRFM detachment. When the BTRM is installed, put the corresponding BRFM back.

## **III. Handling optical fibers**

Before replacing the BTRM, disconnect the optical fiber cable from the panel (make notes of the optical interface to which each optical fiber corresponds). Connect the optical fiber cable back on the new BTRM after the replacement is finished.

Be careful when plugging and unplugging the optical fiber. If the fiber connector has a locker tab, remember to press it down when unplugging the connector.

## **IV. Installing BTRM**

When installing the BTRM, make sure the module panel is in a seamless contact with the front edge of the subrack and then tighten the screws, or the RF transmission may not be able to meet the index.

### **4.2.11 Receive LNA Distribution Unit (RLDU)**

The physical structure of RLDU is rather different from that of the boards in the baseband subrack, therefore, while basically observing the “4.1.1 Board Replacement” (some processes, such as the board removal & installation, are not applicable to RLDU and

thus, can be handled flexibly), we should also pay attention to the following:

### **I. The influence on the service**

Replacing a RLDU may affect the services transmitted through it. Remember to switch off the RLDU from the BTS switch box before replacing it.

### **II. Handling relevant cables**

Before replacing the RLDU, disconnect the power cables and data cables on the panel. Connect them back properly after the RLDU is installed

### **III. Installing RLDU**

When installing the RLDU, make sure its panel is in a seamless contact with the front edge of the subrack and then tighten the screws, or the RF transmission may not be able to meet the index.

### **IV. Setting the switches**

After installing the new RLDU, the S/W switch setting should be the same as that of the replaced unit.

## **4.2.12 Duplexer Unit (CDU, DFU, DDU)**

cBTS3612 supports 3 types of duplexers Unit, including CDU,DFU, DDU. Their replacement procedures are quite similar. For example, the replacement procedures of CDU will be introduced.

The physical structure of CDU is rather different from that of the boards in the baseband subrack, therefore, while basically observing the “4.1.1 Board Replacement” (some processes, such as the board removal & installation, are not applicable to CDU and thus, can be handled flexibly), we should also pay attention to the following:

### **I. The influence on the service**

Replacing a CDU may affect the services transmitted through it. Remember to switch off the BTRMs that transmit signal via this CDU from the BTS switch box before replacing it.

### **II. Handling relevant cables**

Before replacing the CDU, disconnect the RF cable on its panel (remember to make notes of the matching relation of the main & diversity cables and the corresponding ports). When the replacement is finished, connect the cables back to the panel of the new CDU (in the same way as that of the replaced unit) and make sure the connectors are fixed tightly and in good contact. Do not damage the connectors and be careful to run the cables wisely.

### **III. Detaching and installing the CDU**

The CDU is rather heavy. Please hold it by the bottom with one hand when handling it.

When installing the CDU, make sure its panel is in a seamless contact with the front edge of the subrack and then tighten the screws, or the RF transmission may not be able to meet the index.

## **4.2.13 Optical Fiber Replacement**

### **I. Checking the optical fiber**

Before replacing the optical fiber, check the new fiber carefully in the following ways:

Point one end of the optical fiber cable towards the sunlight and observe the other end. If you can see the bright spots, that cable is OK.

### **II. Plugging & unplugging the optical fiber connectors**

Take special caution when plugging and unplugging the optical fiber. If the fiber connector has a locker tab, remember to press it down when unplugging the connector.

Before replacing the optical fiber, make notes of the optical interfaces on the BRDM and BTRM to which each of the optical fiber cables correspond. Connect the new optical fiber cables to the corresponding interfaces correctly.

### **III. Handling excessive optical fibers**

When there are excessive optical fibers left, coil them up and put them where they should be.

## Chapter 5 Component Indicators

### 5.1 BTS Control & Clock Module (BCKM)

For details about the BCKM indicators, please see Table 5-1.

**Table 5-1** Description of BCKM indicators

| Indicator | Color | Meaning             | Description                                                                                                                                                                                                                                                                                                     | Normal Status               |
|-----------|-------|---------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------|
| RUN       | Green | Status Indicator    | Flashing quickly (at 4Hz): The BCKM is undergoing a power-on initialization or loading software.<br>Flashing slowly (at 0.5Hz): The BCKM is in normal operation.<br>Other: The BCKM is faulty.                                                                                                                  | Flashing slowly (at 0.5 Hz) |
| ALM       | Red   | Alarm indicator     | Flashing quickly (at 4Hz): Critical alarm<br>Flashing slowly (at 0.5Hz): Major alarm<br>Flashing slowly (at 0.25Hz): Minor alarm<br>Off: No alarm                                                                                                                                                               | off                         |
| ACT       | Green | Operation indicator | On: The BCKM is working properly.<br>Flashing quickly (at 4Hz): OML failure.<br>Flashing slowly (at 0.5Hz): Abis signaling link failure.<br>Flashing slowly (at 0.25Hz): Losing satellite signals for more than 24 hours or having not been able to find adequate satellite signals after the initial power-on. | on                          |

## 5.2 BTS Control Interface Module (BCIM)

For details about the BCIM indicators, please see Table 5-2.

**Table 5-2** Description of BCIM indicators

| Indicator | Color | Meaning             | Description                                                                                                                                                                                                      | Normal status              |
|-----------|-------|---------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------|
| RUN       | Green | Status Indicator    | Flashing quickly (at 4Hz): The BCIM is undergoing the power-on initialization or the software download.<br>Flashing slowly (at 0.5Hz): The BCIM is working properly.<br>Other: The BCIM is not working properly. | Flashing slowly (at 0.5Hz) |
| ALM       | Red   | Alarm indicator     | Flashing quickly (at 4Hz): Critical alarm<br>Flashing slowly (at 0.5Hz): Major alarm<br>Flashing slowly (at 0.25Hz): Minor alarm<br>Off: No alarm                                                                | Off                        |
| ACT       | Green | Operation indicator | On: BCIM is working properly.<br>Flashing quickly (at 4Hz): Cell Bus failure.<br>Flashing slowly (at 0.5Hz): IMA link set broken.<br>Flashing slowly (at 0.25Hz): IMA link broken                                | On                         |

## 5.3 BTS Channel Process Module (BCPM)

For details about the BCPM indicators, please see Table 5-3.

**Table 5-3** Descriptions of BCPM indicators

| Indicator | Color | Meaning             | Description                                                                                                                                                                                                      | Normal Status   |
|-----------|-------|---------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------|
| RUN       | Green | Status Indicator    | Flashing quickly (at 4Hz): The BCPM is undergoing the power-on initialization or the software download.<br>Flashing slowly (at 0.5Hz): The BCPM is running properly.<br>Other: The BCPM is not working properly. | Flashing slowly |
| ALM       | Red   | Alarm indicator     | Flashing quickly (at 4Hz): Critical alarm<br>Flashing slowly (at 0.5Hz): Major alarm<br>Flashing slowly (at 0.25Hz): Minor alarm<br>Off: No alarm                                                                | Off             |
| ACT       | Green | Operation indicator | On: The BCPM is working properly.<br>Flashing quickly (at 4Hz): Cell Bus failure.<br>Flashing slowly (at 0.5Hz): Main control signaling link alarm.<br>Flashing slowly (at 0.25Hz): CSM5000 alarm.               | On              |

## 5.4 BTS Resource Distribution Module (BRDM)

For details about the BRDM indicators, please see Table 5-4.

**Table 5-4** Description of BRDM indicator

| Indicator | Color | Meaning             | Description                                                                                                                                                                                                      | Normal Status              |
|-----------|-------|---------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------|
| RUN       | Green | Status indicator    | Flashing quickly (at 4Hz): The BRDM is undergoing the power-on initialization or the software download.<br>Flashing slowly (at 0.5Hz): The BRDM is working properly.<br>Other: The BRDM is not working properly. | Flashing slowly (at 0.5Hz) |
| ALM       | Red   | Alarm indicator     | Flashing quickly (at 4Hz): Critical alarm<br>Flashing slowly (at 0.5Hz): Major alarm<br>Flashing slowly (at 0.25Hz): Minor alarm<br>Off: No alarm                                                                | Off                        |
| ACT       | Green | Operation indicator | On: BRDM is working properly.<br>Flashing quickly (at 4Hz): Cell Bus failure<br>Flashing slowly (at 0.5Hz): FPGA alarm.<br>Flashing slowly (at 0.25Hz): Communication link with BTRM alarm.                      | On                         |

## 5.5 BTS Transceiver Module (BTRM)

For details about the BTRM indicators, please see Table 5-5.

**Table 5-5** Description of BTRM indicators

| Indicator | Color | Meaning             | Description                                                                                                                                                                                                        | Normal Status              |
|-----------|-------|---------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------|
| RUN       | Green | Status indicator    | Flashing quickly (at 4Hz): The BTRM is undergoing the power-on initialization or the software download.<br>Flashing slowly (at 0.5Hz): The BTRM is working properly.<br>Other: The board is not working properly.. | Flashing slowly (at 0.5Hz) |
| ALM       | Red   | Alarm indicator     | Flashing quickly (at 4Hz): Critical alarm<br>Flashing slowly (at 0.5Hz): Major alarm<br>Flashing slowly (at 0.25Hz): Minor alarm<br>Off: No alarm                                                                  | Off                        |
| ACT       | Green | Operation indicator | On: BTRM is working properly and the clock is locked.<br>Flashing slowly (at 0.5Hz): The clock has not been locked yet or can not be locked.                                                                       | On                         |

## 5.6 BTS RF Fan Module (BRFM)

For details about the BRFM indicators, please see Table 5-6.

**Table 5-6** Description of BRFM indicators

| Indicator | Color | Meaning               | Description                                                                                                                                                                                                                                                                                                                                                            | Normal Status |
|-----------|-------|-----------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------|
| TRX       | Green | BTRM alarm indicator  | On: BTRM is on and working properly.<br>Flashing quickly (at 4Hz): BTRM has not been power on or is in the Critical alarm status.<br>Flashing slowly (at 0.5Hz): The BTRM is on but in a major alarm status<br>Flashing slowly (at 0.25Hz): The BTRM is on but in a minor alarm status.<br>Off: Communication between the BTRM and the fan monitoring board is broken. | On            |
| HPA       | Green | BHPA status indicator | On: The BHPA is running properly.<br>Flashing quickly (at 4Hz): BHPA alarm                                                                                                                                                                                                                                                                                             | On            |
| FAN       | Green | Fan status indicator  | On: The fan is running properly.<br>Flashing quickly (at 4Hz): Fan failure alarm.                                                                                                                                                                                                                                                                                      | On            |

## 5.7 Receive LNA Distribution Unit (RLDU)

For details about the RLDU indicators, please see Table 5-7.

**Table 5-7** Description of RLDU indicators

| Indicator | Color | Meaning         | Description                 | Normal Status |
|-----------|-------|-----------------|-----------------------------|---------------|
| POWER     | Green | Power indicator | On: Normal<br>Off: Abnormal | On            |

## 5.8 Power Supply Unit (PSU)

For details about the PSU indicators, please see Table 5-8.

**Table 5-8** Description of PSU indicators

| Indicator | Color | Meaning                      | Description                 | Normal Status |
|-----------|-------|------------------------------|-----------------------------|---------------|
| Vin       | Green | Power input status indicator | On: Normal<br>Off: Abnormal | On            |
| Alm       | Red   | Module fault indicator       | On: Alarm<br>Off: Normal    | Off           |
| Vo        | Green | Power output indicator       | On: Normal<br>Off: Abnormal | On            |



### Note:

Possible Alm alarm causes: input undervoltage, output overvoltage, overheating and the PSU is not plugged in properly.

---

## 5.9 Base station Power & Lightening protection Lamp Indicator board (BPLI)

For details about the BPLI indicators, please see Table 5-9.

**Table 5-9** Description of BPLI indicators

| Indicator | Color | Meaning                       | Description                                                                                               | Normal Status |
|-----------|-------|-------------------------------|-----------------------------------------------------------------------------------------------------------|---------------|
| RUN       | Green | -48V power indicator          | On: The power supply is normal<br>Off: The power supply is abnormal.                                      | On            |
| L-alm     | Red   | Lightening arrester indicator | On: The lightening arrester is not working properly.<br>Off: The lightening arrester is working properly. | Off           |

## 5.10 BTS Fan Monitor Module (BFMM)

For details about the BFMM indicators, please see Table 5-10.


**Table 5-10** Description of BFMM indicators

| Indicator       | Color | Meaning                      | Description                                                                                                                                                                                                                                                                                                                                                                      | Normal Status               |
|-----------------|-------|------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------|
| BFMM Indicators | Green | Operational status indicator | Flashing quickly (at 4Hz): the monitored target is running out of order, such as the fan failure, serial port communication failure and the driving monostable circuit failure, etc.<br>Flashing slowly (at 0. 5Hz): Both the fan monitoring circuit and the monitored target are working properly.<br>On or off: The controlling chip of the BTS Fan Monitor Module has failed. | Flashing slowly (at 0. 5Hz) |

# Chapter 6 Switches & Interfaces

## 6.1 BTS Control Interface Module (BCIM)

The DIP switch and jumpers of the BCIM are shown in Figure 6-1.



**Figure 6-1** DIP switch and jumpers of BCIM

For details about BCIM DIP switch and jumper settings, please see Table 6-1

**Table 6-1** BCIM DIP switch and jumper settings

| Item No. | Function                                                                                                                           | Operation                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|----------|------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| S2~S9    | Impedance (75Ω/120Ω) for E1 interface, balanced mode or unbalanced mode selection.                                                 | <p>The No.1-4 of the DIP switch are all set at "off" position: 120Ω twisted pair line.</p> <p>The No.1-4 of the DIP switch are all set at "on" position: 75Ω coaxial cable, with the coating connected to the PGND.</p> <p>The No.1-2 of the DIP switch are all set at "on" position, No.3-4 at "off" position: 75Ω coaxial cable, the coating is not connected to the PGND.</p> <p>The DIP switch position other than the above mentioned is not defined.</p> |
| J6       | Feedback of the Impedance mode (75Ω/120Ω) for E1 interface, the program will initiate the E1 chip according to this jumper status. | <p>Short-circuiting the No. 2 and No.3: 120Ω configuration mode.</p> <p>Short-circuiting the others or leaving them unconnected: 75Ω configuration mode.</p>                                                                                                                                                                                                                                                                                                   |

## 6.2 Receive LNA Distribution Unit (RLDU)

For details about the RLDU switches, please see Table 6-2.

**Table 6-2** Description of RLDU switches

| Switch name | Function                                                                  | Operation                                                                                                                                                                                                                                                                                                                                                                  |
|-------------|---------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| S/W         | Switching the number of the sector carrier to which the RLDU corresponds. | S/W set to 0:<br>When the BTS sector number is less than or equal to 3, the carrier number of each sector is greater than or equal to 2 but less than or equal to 4, and each sector is equipped with 2 CDUs or 1 CDU & 1 DFU.<br>S/W set to 1:<br>The carrier number of each sector is less than or equal to 2, and each sector is equipped with 1 CDU or 1 DFU or 1 DDU. |

## 6.3 Cabinet-Top E1 Interface

### I. Description of cabinet-top E1 interface

Two transmission cables (corresponding to two BCIMs, each containing 8 E1 trunk cables, which is numbered individually) run from the backplane of the baseband subrack to the cabinet top and connect to the two E1 BESP (facing the cabinet and standing in column) via the DB37 connectors. Generally the BCIM No.0 corresponds to the BESP in the front, and the BCIM No.1 corresponds to the BESP at the back.

Each BESP has two DB25 connectors, and each DB25 connector has 4 E1 trunk cables. According to our actual needs, we

can run E1 trunk cables from one or all of these 4 DB25 connectors to the DDF rack in the cabinet room.

## **II. Caution-demanding issues**

During the BTS capacity expansion or maintenance, we should have a clear idea which DB25 connector is being used. Incorrect cable connection will result in communication failure.

When the number of the E1 trunk cables actually used is less than 4, generally we should use the first DB25 connector of the front BESP (viewing from cabinet front); When the number of the E1 trunk cables actually used is greater than 4, we should pick up the DB25 connectors in a “from-front-to-back” order according to the actual capacity requirements.

# Table of Contents

**Appendix A Common Commands.....A-1**

**Appendix B Abbreviation.....B-1**

# Appendix A Common Commands

In this appendix, we will provide you with a Telnet command list, including the configuration commands, maintenance commands and help commands etc., please see the on-line help for details about how to use these commands.

For remote BTS maintenance, we can use the MML command input tool in the client terminal of the OMC, with which we can view the remote operation commands easily.

| Command             | Function                                         | Classification        |
|---------------------|--------------------------------------------------|-----------------------|
| ADD BTSCPM          | Add BTS BCPM                                     | Configuration command |
| ADD BTSTBTRM        | Add BTS BTRM                                     |                       |
| ADD BTSCCELL        | Add BTS Cell                                     |                       |
| ADD BTSCPL          | Add BTS Resource Pool                            |                       |
| ADD BTSGENBRD       | Add General Board of BTS                         |                       |
| ADD BTSLNK          | Add BTS Transmission Link                        |                       |
| ADD BTSLNKGRP       | Add BTS Transmission Link Group                  |                       |
| ADD BTSTERTFLNK     | Add BTS Terrestrial Traffic Link                 |                       |
| CLR BTSCFG          | Clear the current configuration data of the BTS. |                       |
| CLR BTSMLTRPLNK     | Clear BTS Trunk Transmission Link                |                       |
| DSP BTSCFG          | Display Configuration Commands                   |                       |
| RMV BTSCPM          | RemoveBTS BCPM                                   |                       |
| RMV BTSTBTRM        | RemoveBTS BTRM                                   |                       |
| RMV BTSCPL          | RemoveBTS Resource Pool                          |                       |
| RMV BTSGENBRD       | Remove General Board of BTS                      |                       |
| RMV BTSLNK          | Remove BTS Transmission Link                     |                       |
| RMV BTSLNKGRP       | Remove BTS Transmission Link Group               |                       |
| RMV BTSTERTFLNK     | Remove BTS Terrestrial Traffic Link              |                       |
| SAV BTSCFG          | Save BTS Configuration                           |                       |
| SET BTSCPMMPARA     | Set BCPM miscellaneous parameters.               |                       |
| SET BTSTBTRMPHYINFO | Set BTRM Physical Information                    |                       |
| SET BTSCCLK         | Set BTS Clock Parameters                         |                       |

| Command            | Function                                     | Classification        |
|--------------------|----------------------------------------------|-----------------------|
| SET BTSCPPARA      | Set BTS BCPM Chip Parameters                 | Configuration command |
| SET BTSE1CLKM      | Set E1 Clock Mode                            |                       |
| SET BTSGPSCCLK     | Set BTS GPS Clock Parameters                 |                       |
| SET BTSINFO        | Set BTS Basic Information                    |                       |
| SET BTSMULTDRPLNK  | Set BTS Trunk Configuration                  |                       |
| SET BTSSSECTORPARA | Set BTS Cell Parameters                      |                       |
| SET BTSTERSTGLNK   | Set BTS Terrestrial Signaling Link           |                       |
| STR BTS            | Start BTS                                    |                       |
| BLK BTSCCPM        | Block BTS BCPM                               | Maintenance command   |
| BLK BTSCCELL       | Block BTS Cell                               |                       |
| DEL HISALM         | Delete BTS History Alarm                     |                       |
| DSP BTSCRDSPCSTAT  | Display BTS Board Specific Status            |                       |
| DSP BTSCRDSTAT     | Display BTS Board Status                     |                       |
| DSP BTSCRDVER      | Display BTS Board Version                    |                       |
| DSP BTSCENVPARA    | Display BTS Environment Temperature/Humidity |                       |
| DSP BTSCFRMSTAT    | Display BTS Baseband Subrack Status          |                       |
| DSP BTSCPOWERPARA  | Display BTS Power Supply Module Parameters   |                       |
| DSP BTSCWARNTHD    | Display Alarm Thresholds                     |                       |
| LST CURALM         | List BTS Current Alarm                       |                       |
| LST HISALM         | List BTS History Alarm                       |                       |
| RST BTSCBRD        | Reset BTS Board                              |                       |
| RST BTSCENVBOX     | Reset Environment Alarm Box                  |                       |
| SET BTSCENVPORT    | Set Port Status of Monitor                   |                       |
| SET BTSCPOWEROFF   | Shut Off BTS Power                           |                       |
| SET BTSCWARNTHD    | Set BTS Alarm Threshold                      |                       |
| STP BTSE1TST       | Stop BTS E1 Test                             |                       |
| STP BTSCRESTRC     | Stop BTS Resource Tracing                    |                       |
| STR BTSE1TST       | Start BTS E1 Test                            |                       |
| STR BTSCLPBACKTST  | Start BTS Board Loopback Test                |                       |
| STR BTSCRESTRC     | Start BTS Resource Tracing                   |                       |
| STR BTSCSELFTEST   | Start BTS Board Self Test                    |                       |
| STR E1MATCHTST     | Start BTS E1 Connection Test                 |                       |
| UBL BTSCCPM        | Unblock BTS BCPM                             |                       |
| UBL BTSCCELL       | Unblock BTS Cell                             |                       |
| HELP               | cBTS3612 MML Command Online Help             | Help command          |

## Appendix B Abbreviation

|      |                                                               |
|------|---------------------------------------------------------------|
| Abis | Interface between BSC and BTS                                 |
| AC   | Authentication Center                                         |
| AC   | Alternating Current                                           |
| ALM  | Alarm                                                         |
| ATM  | Asynchronous Transfer Mode                                    |
|      |                                                               |
| BAM  | Back Administration Module                                    |
| BCIM | BTS Control Interface Module                                  |
| BCKM | BTS Control & Clock Module                                    |
| BCPM | BTS Channel Process Module                                    |
| BESP | BTS E1 Surge Protector                                        |
| BFAN | BTS FAN Module                                                |
| BFMM | BTS Fan Monitor Module                                        |
| BHPA | BTS High Power Amplifier Unit                                 |
| CBMS | CDMA BSC Basic Management Subrack                             |
| BPLI | Base station Power & Lighting protection lamp Indicator board |
| BRDM | BTS Resource Distribution Module                              |
| BRFM | BTS RF Fan Module                                             |
| BS   | Base Station                                                  |
| BSC  | Base Station Controller                                       |
| BSS  | Base Station Subsystem                                        |
| BTRM | BTS Transceiver Module                                        |
| BTS  | Base Transceiver Station                                      |
|      |                                                               |
| CDMA | Code Division Multiple Access                                 |
| CDU  | Combining & Duplexing Unit                                    |
| CLK  | Clock                                                         |
| CLPU | CDMA 1X Line Process Unit                                     |
| CMUX | CDMA 1X system MULTipleXer unit                               |
| CXIE | CDMA 1X general ( X ) Interface Equipment                     |
|      |                                                               |
| DC   | Direct Current                                                |
|      |                                                               |
| FPGA | Field Programmable Gate Array                                 |
| FTP  | File Transfer Protocol                                        |
|      |                                                               |
| GPS  | Global Positioning System                                     |

|       |                                |
|-------|--------------------------------|
| IMA   | Inverse Multiplexing for ATM   |
| IP    | Internet Protocol              |
| IPOA  | IP over ATM                    |
| LMF   | Local Maintenance Function     |
| LNA   | Low-Noise Amplifier            |
| CLPU  | CDMA Line Process Unit         |
| MAC   | Medium Access Control          |
| MC    | Message Center                 |
| MMI   | Man Machine Interface          |
| MML   | Man Machine Language           |
| Modem | Modulator-Demodulator          |
| MPU   | Micro Process Unit             |
| MS    | Mobile Station                 |
| NID   | Network Identification         |
| OMC   | Operation & Maintenance Center |
| OML   | Operation & Maintenance Link   |
| OMU   | Operation & Maintenance Unit   |
| PSU   | Power Supply Unit              |
| PVC   | Permanent Virtual Channel      |
| PVP   | Permanent Virtual Path         |
| RLDU  | Receive LNA Distribution Unit  |
| RST   | Reset                          |
| SID   | System Identification          |
| TCP   | Transport Control Protocol     |
| Um    | Interface between MS and BTS   |
| UNI   | User Network Interface         |
| VCI   | Virtual Channel Identifier     |
| VPI   | Virtual Path Identifier        |