



BeamPlex

**BRU-100 and BRU-150
Remote Unit**

Installation and Maintenance Service Utilities

1106333-01
Rev. 3
Nov. 2003

Legal Notices

This document is published in association with the products of BeamReach Networks Incorporated. Due to ongoing product development and improvements, BeamReach Networks makes no representations or warranties with respect to the accuracy or completeness of this document and reserves the right to make changes without notice.

Patents

Products and technologies described herein include those covered by one or more U.S. patents owned by BeamReach Networks Incorporated.

Copyrights

© 2003 BeamReach Networks Incorporated. All rights reserved. No part of this document may be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form without prior written consent from BeamReach Networks Incorporated.

Printed in the United States of America.

Trademarks

BeamPlex and Adaptive MultiBeam OFDM are trademarks of BeamReach Networks Incorporated.

All other brand names are trademarks of their respective holders.

Revision History

Document number 1106333-01

Revision Status	Revision Level	Date	System Release
Pre-Production	Rev 1	April 2003	1.1
Pre-Production	Rev 2	June 2003	1.1
Pre-Production	Rev 3	November 2003	1.1

This document applies to System Software versions subsequent to that which is listed here, unless the document is reissued due to software feature upgrades. The software release notes will indicate the applicable document revision level.

BeamReach Networks
755 North Mathilda Ave.
Sunnyvale, CA 94086
408.869.8700
www.BeamReachNetworks.com

Table of Contents

Chapter 1 – Introduction	1
Overview	2
Scope and Purpose	2
Important Notices	3
Remote Unit Models	3
Remote Unit Service Utilities	5
BRU Installation Tool (BRUIT)	5
BRU Status Monitor	5
BRU-150 Transceiver Features	6
Installation Overview	8
BRU-150 Self-Install Remote Unit	8
BRU-100 Professional Install Remote Unit	8
Reference Documents	9
Chapter 2 – Preparation	11
Service Computer	12
Computer	12
Ethernet Cable	12
IP Address	13
Software	13
Service Utilities	13
Software Image	13
Service Order File	14
BRU-100	14
BRU-150	14
Equipment and Material	17
Chapter 3 – Installation Tool	19
Preface	20
BRU-150 Pre-Configuration	20
Antenna Location	21
Installation Tool Operation	22
Step 1 Physical Installation	22
LAN Connection	23
Step 2 Login	23
Step 3 Status Check	24
BRU Configuration	25
BRU Software Upload	25
Step 4 Antenna Pointing Calculations	27
Calculate Base Station Direction	27
Coordinates	28

Step 5	Antenna Pointing	29
Background Information		29
Working the GUI		30
Signal Strength Details		31
Message Log		32
Step 6	Service Activation	33
Step 7	IP Address	34
Step 8	Installation Status	35
Other Technical Features		36
Default Configuration Button		36
Shortcut Menu		36
Chapter 4	Status Monitor	39
Overview		40
Status Monitor Displays		41
Signal Strength Monitor		41
IP Address Setting		43
Diagnostics		44
Appendix A	Remote Unit Specifications	45
Functional Characteristics		46
User Throughput		46
Radio Characteristics		46
Antenna Characteristics		47
Physical Characteristics		47
Physical Dimensions		47
Environmental Characteristics		47
Regulatory Compliance		48
Index		49

List of Figures

Chapter 1 – Introduction

Figure 1-1 Remote Unit Models 4

Figure 1-2 Transceiver Front Panel 6

Figure 1-3 Transceiver Rear Panel 7

Chapter 2 – Preparation

Figure 2-1 Service Order File Contents 16



Introduction

In This Chapter:

- ▲ [Overview, page 2](#)
- ▲ [Remote Unit Service Utilities, page 5](#)
- ▲ [BRU-150 Transceiver Features, page 6](#)
- ▲ [Installation Overview, page 8](#)
- ▲ [Reference Documents, page 9](#)

This chapter introduces the service utilities for the BRU-100 and BRU-150 Remote Unit. It also provides reference information regarding the installation process.

Overview

This section describes the intended use of this document and introduces the service utilities used for remote unit installation and maintenance.

A remote unit is the subscriber termination equipment for the BeamPlex™ broadband wireless access system. It communicates with its associated base station through an RF signal path; and it communicates with the subscriber's computer through an Ethernet cable.

The service utilities are used to set configuration parameters, initiate the phases of service activation, and monitor the status of a remote unit.

Scope and Purpose

The service utilities are applicable for professional installation and diagnosis of both the BRU-150 and BRU-100 models of remote unit, which are described below. Both models are designed with the same electronics so the service utilities will work with either one of them.



Caution: Read the section [BRU-150 Self-Install Remote Unit](#) on page 8 about required configuration before delivery to the subscriber.

This document is primarily for technicians who perform a manual BRU-150 installation. The BRU-150 is designed for subscriber self-installation. If the subscriber encounters problems during or after self-installation, technicians will use these service utilities to resolve the problems.

For system release 1.1, the existing installation manuals listed in the section [Reference Documents](#) on page 9 accurately describe the physical installation process. However, the BRU-100 documents describe the use of the RIT (Remote Unit Installation Tool) which has now been replaced by the service utilities described here. Installers should use this document for configuring the BRU-100 until the installation manuals have been revised.

Important Notices



Warning: This device is a radio frequency transmitter. It is required to comply with FCC RF exposure requirements for transmitting devices. A minimum separation distance of 8 inches (20 cm) or more must be maintained between the antenna and all persons during device operations to ensure compliance with the FCC's rules for Radio Frequency Exposure. If this minimum distance cannot be maintained, exposure to RF levels that exceed the FCC's limits may result. This equipment must not be co-located with any other transmitting antenna.


Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and the receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
-

Note: Any changes or modifications to this equipment that are not approved by BeamReach Networks could void your authority to operate the equipment if such changes or modifications affect the regulatory compliance specified in [Appendix A](#).

Remote Unit Models

The BeamPlex Broadband Wireless Access System offers two models of remote units for CPE, as shown in [Figure 1-1](#):



BRU-150
Self-install, Indoor Unit

BRU-100
Professional-install, Outdoor Unit




Figure 1-1 Remote Unit Models

Remote Unit Service Utilities

The service utilities are two applets designed to support the installation and maintenance of a remote unit:

BRU Installation Tool (BRUIT)

The installation tool consists of a set of GUI windows that guide the installer through the steps of the configuration and activation process. Latitude/longitude coordinates of the subscriber's premise and compass bearings to the closest base stations are used to accurately point the antenna in areas of difficult reception. The GUI contains a signal strength indicator and other technical displays. Installers can set certain configuration parameters and install software upgrades with this tool.

The BRUIT is used primarily for BRU-100 professional installations. It is also used for onsite technical support if a subscriber encounters problems with either model of remote unit.

BRU Status Monitor

The status monitor displays information about the state of the air link between the remote unit and the base station. It provides a utility to change the IP address in the remote unit, and it performs a basic continuity check between the PC and the remote unit, and between the PC and base station.

The status monitor utility is part of the service utilities, but it was designed for the subscriber and is installed on their computer.

BRU-150 Transceiver Features

This section introduces the physical features of the displays and connections on the BRU-150 Transceiver.

The BRU-150 is designed for the subscriber, so its displays and controls are designed for simple functionality.




Figure 1-2 Transceiver Front Panel




Figure 1-3 Transceiver Rear Panel

Installation Overview

This section overviews the installation steps for the BRU-150 and BRU-100 remote units.

BRU-150 Self-Install Remote Unit

The BRU-150 is designed for the subscriber to self-install the unit. However, for system release 1.1 the configuration process has not been fully automated. You must manually set the Local RUID (remote unit identification) before delivering the unit to the subscriber. This parameter uniquely identifies this remote unit to the base station.

Prior to sending the remote unit to a subscriber, you must determine the Local RUID that will be assigned to this unit. Your company should have developed a plan for Local RUID assignment.

Note: The Local RUID is normally associated with a particular subscriber. You must ensure the correct BRU-150 is being delivered to a subscriber based on the Local RUID assignment.

The Local RUID is configured into the Transceiver of the BRU-150 with the BRUIT (installation tool). At Step 3 in the BRUIT you will open the BRU Configuration window and set a value for the Local RUID.

The subscriber will use the BRU-150 *Installation Quick Guide* to accomplish the installation. If a subscriber is in an area with difficult reception, you may need to make a service call to perform a manual installation using precise antenna-pointing techniques.

BRU-100 Professional Install Remote Unit

The installation process for the BRU-100 is described in detail in the installation documents listed in the following section. The service utilities are used in place of the RIT (Remote Unit Installation Tool) currently described in those documents.

Reference Documents

The following technical publications from BeamReach Networks describe the installation process for the two remote unit models:

- ♦ BRU-150 Installation Quick Guide, 1106333-02
- ♦ BRU-100 Installation and Configuration, 1106138-01
- ♦ BRU-100 Installation Summary, 1106138-03



Preparation

In This Chapter:

- ▲ [Service Computer, page 12](#)
- ▲ [Software, page 13](#)
- ▲ [Equipment and Material, page 17](#)

This chapter describes preparation tasks for the installation of a remote unit.

Service Computer

This section describes the requirement for the service computer that will host the service utilities and be used in the field to install remote units. These requirements also apply to the subscriber's computer.

Computer

The service utilities are designed to run on a computer with a Windows® 2000 or later operating system. For field service, a portable (laptop) computer is used.

The computer must be configured with

- an Ethernet (NIC) card,
- a PPPoE client, and;
- a CD drive.

Ethernet Cable

The service computer connects to the remote unit through an Ethernet cable.

BRU-150

Use a CAT 5 Ethernet straight-thru cable with RJ-45 plug (male) connectors on both ends to connect the computer to a BRU-150 Transceiver.

BRU-100

For the current version of the BRU-100 remote unit, a cable is supplied with the installation kit that mates with the round connector on the Outdoor Unit and has an RJ-45 connector on the other end. You will need this cable and the installation power injector to connect the service computer to the Outdoor Unit. Follow the instructions in the BRU-100 *Installation and Configuration* manual, or the *Installation Summary* guide, using the service computer in place of the RIT.

The next version of the BRU-100 will have a standard RJ-45 jack in place of the round connector, and the installation power injector will not be needed.

IP Address

The service computer must have a static IP address that is compatible with the remote unit's address, which is delivered with the default address of 192.168.1.1. Set the IP address in the service computer as follows:

- ♦ IP address 192.168.1.x

Where X is any number between 2 and 255. If the number you choose causes a conflict with another network device, you will see an error message. If this occurs, try a different number for the X value.

- ♦ Subnet mask 255.255.255.0

Software

This section lists the software files you must load onto the service computer prior to a service call.

Service Utilities

The service utilities are not packaged in an installation shield at this time. The files are delivered in a self-extracting Zip file (`bruit.exe`) on a CD. Create a new directory on the service computer and unzip the files into it. Open the applications by executing these files:

- ♦ `BRU-IT.exe` – BeamPlex Remote Unit Installation Tool
- ♦ `BRU-Mon.exe` – BeamPlex Remote Unit Monitor

You may to create shortcuts to these files for ease of use.

Software Image

You must also download and store the current remote unit *software image file*, which contains updates to the operating system. Step 3 in the installation tool allows you to read the software version currently in the remote unit, and to send a new image file if an update is indicated.

A software image file is provided by BeamReach Networks and should be stored in your system on a TFTP server.

Service Order File

A service order file is generated by the SAM (Service Activation Module) of the BeamPlex Element Management System. The service provider inputs customer data into the SAM for each BRU-100 subscriber.

► BRU-100

For a BRU-100 installation, you must also download a service order file for each subscriber who will receive an installation on the pending service trip. This file contains the subscriber's latitude and longitude estimated coordinates and the coordinates of the closest base stations. This data is retrieved when you enter the customer number in Step 4 of the installation procedure. The customer number is the numeric part of the service order file name. For example, service order file `SO_567891.xml` denotes a customer number of 567891.

► BRU-150

A service order file may not exist for a subscriber with a BRU-150. You will need a file only if you have to perform a manual installation. In this case, there is a default service file included with installation tool that can be used. Its file name is `SO_1467854.xml` and it is in the same directory in the service computer as the installation tool files.

Edit this default file to change the following data:

- BSOC (base station offset code) – The remote unit uses this code to identify a base station.
- Base station coordinates – The latitude/longitude coordinates of the three closest base stations in your service area.

Note: You must obtain the BSOC and coordinates from the engineers that configured the base station.

This XML file can be easily edited with a text editor, such as the Notepad or Wordpad applications that come standard with Windows operating systems.

A portion of the service order file as read by a text editor is shown in [Figure 2-1](#) on page 16. The file contains data on three base stations.

When changing the latitude/longitude coordinates, be sure to maintain the proper format (including quote marks) and the exact number of digits:

Latitude: dd:mm.mmmC

Longitude: ddd:mm.mmmC

Where:

d = degrees

m = minutes

C = compass (N or S latitude; E or W longitude)

An example of 1-degree, 1-minute West is "001:01.000W"

```
<SO SERVICE-ORDER-NUM="1467854"
SUBSCRIBER-NAME=
SUBSCRIBER-ADDRESS=
SUBSCRIBER-PHONE=
STRUCTURE-TYPE=
STRUCTURE-MATERIAL=
STRUCTURE-HEIGHT=
REQUESTED-SERVICE-TYPE="1"
SERVICE-ORDER-STATUS=
ROOF-INSTALL-OK=
RESIDENTIAL-OR-BUSINESS=
SERVICE-ORDER-DATE="
SCHEDULED-INSTALL-DATE=
AVAILABLE-SERVICE-TYPE="Service 1"
SUBSCRIBER-SITE-ELEVATION="23"
EST-SUBSCRIBER-SITE-LATITUDE="37.23.657N"
EST-SUBSCRIBER-SITE-LONGITUDE="122.01.819W"
ABOVE-ROOF-REQUIRED="true"
COVERAGE-SURVEY-REQUIRED="true"
PRIMARY-BASE-ID="1"
PRIMARY-BASE-NAME="Sunnyvale Base"
PRIMARY-BSOC="4"
PRIMARY-BRN-UPPER-CH-ID="39"
PRIMARY-BRN-LOWER-CH-ID="3"
PRIMARY-BASE-LATITUDE="37:23.657N"
PRIMARY-BASE-LONGITUDE="122:01.819W"
PRIMARY-SPREAD-FACTORS="2"
PRIMARY-AVE-FLS-TX-POWER="4"
PRIMARY-BASE-ELEVATION="15"
SECONDARY-BASE-ID="2"
SECONDARY-BASE-NAME="MountainView Base"
SECONDARY-BSOC="4"
SECONDARY-BRN-UPPER-CH-ID="41"
SECONDARY-BRN-LOWER-CH-ID="5"
SECONDARY-BASE-LATITUDE="37:23.280N"
SECONDARY-BASE-LONGITUDE="122:02.980W"
SECONDARY-SPREAD-FACTORS="2"
SECONDARY-AVE-FLS-TX-POWER="4"
SECONDARY-BASE-ELEVATION="20"
TERTIARY-BASE-ID="3"
TERTIARY-BASE-NAME="San Jose Base"
TERTIARY-BSOC="10"
TERTIARY-BRN-UPPER-CH-ID="39"
TERTIARY-BRN-LOWER-CH-ID="3"
TERTIARY-BASE-LATITUDE="37:94.393N"
TERTIARY-BASE-LONGITUDE="122:99.615W"
TERTIARY-SPREAD-FACTORS="2"
TERTIARY-AVE-FLS-TX-POWER="4"
TERTIARY-BASE-ELEVATION="25"/>
```

Figure 2-1 Service Order File Contents

Equipment and Material

The BRU-150 is a subscriber self-install unit and does not require any additional equipment or materials. If a service call is needed to resolve installation problems or reception problems, the following equipment may be needed depending on the specific situation:

- A compass for determining the bearing to a base station from the subscriber's location. The compass should have a bearing ring, which is a ring around the face with graduation marks in degrees.
- A GPS receiver to determine the coordinates of the subscriber's locations. Alternative methods are discussed in the section [Step 4 Antenna Pointing Calculations](#) on page 27.



Installation Tool

In This Chapter:

- ▲ [Preface, page 20](#)
- ▲ [Installation Tool Operation, page 22](#)
- ▲ [Other Technical Features, page 36](#)

This chapter provides operating instructions for the BRU Installation Tool application of the service utilities.

Preface

The procedures in this chapter describe using the installation tool for installing a BRU-150 remote unit.

As discussed in [Chapter 1](#), the BRU-150 is designed for subscriber self-installation. However, some subscribers may be in locations where reception is difficult and they were unable to establish an airlink with the base station. Or the signal strength may be too low to provide adequate service. For these occasions, the installation tool provides a method for precise antenna pointing to acquire the base station signal and to maximize the received signal level.

The installation tool can also be used in place of the RIT for a BRU-100 installation.

The sequential windows in the installation tool GUI contain explanations to guide you through the basic remote unit installation process. Images of those windows are presented in this chapter with special instructions and more technical explanations of the process.

The specific features and capabilities in this utility that do not exist in the subscriber's self-installation process include:

- ◆ Subscriber's location coordinates
- ◆ Direction and distance to the three nearest base stations
- ◆ More details on signal strength and link status
- ◆ Ability to change remote unit configuration
- ◆ Control over with which base station the remote unit connects

BRU-150 Pre-Configuration



Caution: Remember that all BRU-150 remote units must be pre-configured with the Local RUID before being delivered to the subscriber.

As described in the section [BRU-150 Self-Install Remote Unit](#) on page 8, you must manually set the Local RUID (remote unit identification) before delivering any BRU-150 to a subscriber for self-installation. This parameter uniquely identifies this remote unit to the base station. This is accomplished in Step 3 of the installation tool GUI.

Antenna Location

The BRU-150 antenna is designed to be mounted on the inside surface of a window that faces the general direction of a base station. Follow these guidelines for selecting a location at a subscriber premise with difficult reception:

- Locate the antenna as high as possible in the building.
- Select a window that does not have large obstructions such as dense trees or a building close to it.
- Do not mount the antenna in a window that has a metal screen.
- Do not locate the antenna near other sources of electromagnetic radiation, such as computer monitors, televisions, microwave ovens, or wireless telephones.

Per FCC rules, 8 inches (20 cm) or more of separation between the antenna and all persons must be maintained. This refers to the radiating side of the antenna, which faces out the window.


Installation Tool Operation

You must complete the preparation tasks described in [Chapter 2](#) before leaving on a service call.

Refer to the BRU-150 *Installation Quick Guide* for the physical installation.

Open the installation tool by executing the `BRU-IT.exe` file.

Step 1 Physical Installation



This window provides guidance for installing the BRU-150 components. Use the pop-up windows from the **Click Here** buttons, or see the *Installation Quick Guide*.

If you are installing a BRU-100, see the *Installation and Configuration* manual or the *Installation Summary* guide.

► LAN Connection

If the subscriber's computer will be connected to a LAN, first connect the computer directly to the remote unit for set-up. After you complete the installation process a hub or switch can be added. The use of a router is not supported at this time due to addressing conflicts. For system release 1.3, BeamReach will provide instructions for setting the IP address for use on a LAN.

Step 2 Login

Step 2 - BRU Login

STEP 2 - BRU Login

Please login to the BRU by entering the IP address and login password found in the BRU Self Installation Kit. Please take care to enter this information correctly.

IP Address: 192.168.1.1 Password: *****


Note: The default local IP address of the BRU is 192.168.1.1. If this address conflicts with your LAN settings, you can resolve the conflict by changing the IP address once you are logged in. To change the IP address, right click the start bar icon and select 'Change BRU IP address'.

OK Cancel

Both models of remote unit come from the factory with the same default IP address and password:

192.168.1.1 field

Step 3 Status Check



Note: You must enable the **Perform Manual Activation** check box or the utility will revert to the automated self-install routine.

This step reads certain data from the remote unit and displays it in the window. It also initiates a self-test and displays the results.

This step is where you access the BRU Configuration window. See the section [Service Order File](#) on page 14 for a discussion of the BRU Configuration window parameters and the service order file. If the remote unit has failed to connect with a base station, verify the parameter values in the BRU Configuration window as described below.

This step is also where you upload a new software image file. See the section below for instructions.

The **Error Details** and **Help** buttons are not functional at this time.

► BRU Configuration


Step 1 Click the **BRU Config** button to open the configuration window.

Step 2 Verify or change the values of the following parameters:

Parameter	Value
Local RUID	<i>Per your network plan</i>
BSOC	<i>Per your network plan</i>
Lower Channel ID	3
Upper Channel ID	39
Operating Subband	1

Click **Set** after each value that you change.

Step 3 Click **Close** when you are finished.



► BRU Software Upload

Step 1 Determine if the system software needs to be updated.

- Read the **Active Software Version** field in the Step 3 window. In the example shown above, the software version is 1.1.02.13. The **Current SW Version** in the **BRU Configuration** window also displays the software version.
- Look at the name of the image file you downloaded to the service computer ([Software Image](#) on page 13). The file name contains the version number. For example, an image file `odu-1_1_2_14.dnl` would contain software version 1.1.02.14, which is a later version than the one being displayed.


Step 2 If the software needs to be updated, click the **BRU Software Upload** button. A standard Open File dialog appears.

Step 3 Navigate to the new file and click **Open**. The upload process then begins and the status window shown below opens.

The transfer will take a few minutes and the ongoing status will display in the window.

After the upload is complete, the remote unit will automatically reboot to activate the new software. You must log in with the installation tool again to proceed with the installation.

Software Upload
Information



Step 4 Antenna Pointing Calculations

STEP 4 - BRU-150 Antenna Pointing Calculation

Enter the Customer Number (supplied by your service provider): 1467854

Enter the coordinates of your current location (supplied by service provider, GPS or by website lookup):

Latitude(deg.mm.mmm): 37:23.657N
Ex. 37:23.657N

Longitude(deg.mm.mmm): 122:01.819W
Ex. 077:45.234W

Click **Load** to load Network Information.

Browse to the CD-ROM directory and select the file with .xml extension

Click **Calculate** to determine the pointing direction and distance for up to 3 base stations from BRU.

	Code	Direction	Distance
Base1	4	-15	0
Base2	6	232	0
Base3	10	298	0

The direction displayed is in degrees, as would be displayed by a compass (0 degrees is North). The distance is in miles. The code displayed is for information only.

This window locates the closest base stations based on latitude/longitude coordinates. If you know the direction to the base stations (by using a map, for example) you do not have to input coordinates or use the calculated pointing directions. Also see the section [Antenna Location](#) on page 21.

► Calculate Base Station Direction

Step 1

Enter the customer number, which is the numerical part of the file name of the service order. In the example above, the file name is SO_1467854.xml. See the section [Service Order File](#) on page 14 for more discussion. Then click **Load**, which causes the tool to read the data in the service order file.

Tip: Enter a single character into the **Customer Number** field, then click **Load**. An **Open File** dialog appears where you can navigate to the service order file.

Step 2

Enter the coordinates of the subscriber's location. These must be entered in the proper format, as described in the [Coordinates](#) section below. If you need to find these coordinates, see the [Coordinates](#) section.

Tip: If the subscriber coordinates were entered into the service order file, you can leave the latitude/longitude fields blank.

Step 3 Click the **Calculate** button. The tool then uses the latitude/longitude coordinates in the service order for the base station and those entered for the subscriber to derive the **Direction** and **Distance** values in the table at the bottom of the window.

Interpret the table as follows:

Code – Information only. The base station offset code identifies the base station.

Direction – The bearing, in degrees, to the base station. The graduations begin at North (0 degrees) and progress clockwise around the compass.

Distance – The distance to the base station in miles.

Step 4 Use a compass and the **Direction** bearing for **Base1** to find a suitable location for the antenna.

► Coordinates

If you need to determine the latitude/longitude coordinates for the subscriber, they are best derived from a GPS receiver on site.

An alternative is to use a web site that will derive the coordinates from the subscriber's address. One such commercial site is www.maps.com. Zoom in the map and the coordinates are displayed.

Coordinates from a web source may need interpretation. Using maps.com as an example:

Longitude and latitude (in that order) are displayed:

-121.90159 37.39689

Negative values denote West longitude and South latitude.

Positive values denote East longitude and North latitude.

The fractional part of the degree must be converted to minutes and rounded to three decimal points:

$.90159 \times 60 = 54.095$ $.39689 \times 60 = 23.813$

The coordinates 121:54.095W and 37:23.813N can now be entered into the GUI.

Note: The latitude/longitude values must be entered in the exact format and with the exact number of digits shown in the GUI.

Enter latitude/longitude values in this format, where d = degrees and m = minutes:

dd:mm.mmmN (or S) Latitude

Example: 21:02.123S

ddd:mm.mmmW (or E) Longitude

Example: 002:45.500E

Step 5 Antenna Pointing

This step includes the antenna pointing process and establishing the initial airlink with a base station.

► Background Information

Steps 5 and 6 establish the airlink communication channel between the remote unit and the base station. There are four critical processes involved:

- **Synchronization** – Acquire and maintain time and frequency synchronization with the base station.
- **Ranging** – Adjust ODU power levels and transmission intervals so that the time slots carrying data arrive at the base station at the proper time.
- **Registration/Authentication** – Store base station offset code in the remote unit to identify with which base station the remote unit will communicate. Store a database record for this remote unit in the BeamPlex Element Management System (BMS). Associate the remote unit to the base station, then to the BMS.

Synchronization and ranging occur in Step 5, while registration and authentication occur in Step 6. This sequence is divided into two steps so that you can ensure that the unit is receiving an adequate signal level in Step 5 before you begin the registration process. This is important because if you need to establish a link with a different base station after registration, you must manually delete the remote unit from the first base station's database.

► Working the GUI

Approximate Values:

Excellent: -104 dBm
Good: -112 dBm
OK: -122 dBm

STEP 5 - BRU Antenna Pointing And Installation

Signal Strength: 30 and more, 20, 10, 0

Excellent
Good
Ok

Selected Code: Base Code=4
Link Status: Airlink Active[14]
Signal Strength: 29

Signal Strength Details...

Message Status: You are connected over the air now.

Message Log...

	Channel	Direction	Distance
Base1	3.39	1	0
Base2	5.41	249	0
Base3	3.39	315	0

1. Start with Base 1. Select a location for the antenna to be installed. Click Here for tips on antenna placement and mounting method. Ensure that the BRU antenna is pointed in the general direction of the selected base station.

2. Synchronize with the base station by clicking on its button in the table above. Observe Link Status and Signal Strength on the left.

3. When the Link Status changes to 'Signal Locked', adjust the antenna pointing to maximize the Signal Strength reading. The Signal Strength must be atleast > 0 to provide reliable service. For BRU-150 models, the "Synch" light on the front of BRU will also turn green at this point.

4. If you cannot obtain the required signal strength, select a different location and/or different base station and begin Synchronization again by clicking the base station button above.

5. Once BRU is synchronized and the Link Status is 'Signal Locked' with the required signal strength, click Next to proceed.

< Back Next > Cancel Help

Step 1

Hold the antenna (or temporarily install it) at the location determined in Step 4, then click **Base1**.

The **Message Status** box indicates synchronization in progress. When it detects a signal strong enough to register on the **Signal Strength** bar, and light one LED on the transceiver, it locks on to that base station.

The **Signal Strength** bar indicates the received signal level. A level near the **OK** mark is recommended. If the signal level is low, try rotating the antenna slowly while monitoring the **Signal Strength** bar, which refreshes once per second.


If the signal level does not improve, move the antenna to another likely location and click **Base1** again. This restarts the synchronization process.

Tip: If an installation requires repeated attempts at acquiring an adequate signal, you may need to compare the results from different antenna locations and/or different base stations. This is accomplished with the **Signal Strength Details** button. An example of the display window is shown below. This data can be saved as a text file and compared against other attempts.

Step 2 If you do not obtain an adequate signal from **Base1**, repeat this process with **Base2** and then with **Base3** as needed.

Step 3 If no antenna location results in clearly superior signal, then review the signal strength detail reports that were saved, as described above. The next section provides guidance in interpreting the data in those reports.

► Signal Strength Details




Look for the following three data types, listed here in order of importance:

- ♦ RSL (received signal level)
High value preferred. Note that these are negative numbers.
- ♦ SNR (signal/noise ratio)
High value preferred.
- ♦ Est. Path Loss
Low value preferred.

Use your best judgement as to which antenna location and which base station produces the best signal. A signal that registers near the **OK** mark is reliable, but the data rate will likely be 700 Kbps (downlink) as opposed to the maximum rate of 1.5 Mbps.

Note: If an adequate signal for the subscriber's needs cannot be attained after all efforts, a BRU-100 remote unit should be considered for this subscriber.

► Message Log



The message log records the sequence of important events throughout the installation process.

Refer to this log as needed to determine the status of the installation.

Step 6 Service Activation

Step 6 - BRU Service Activation

Signal Strength

30 and more

20

Excellent

Good

Ok

0

Selected Code:

Link Status:

Signal Locked(7)

Signal Strength:

19

Signal Strength Details...

Message Status:

Ranging completed successfully

Message Log...

STEP 6 - BRU Service Activation

Follow the steps below to activate service on your BRU:

1. Make sure that the "Link Status" box displays "Signal Locked" and the signal strength should display atleast > 0.
2. If "Link Status" displays "Signal Locked", press **Activate Service** button to complete the BRU installation. When "Link Status" changes to "Airlink Active", service has been activated.
3. If any step fails to complete, **Click Here** for troubleshooting information.

Follow the instructions supplied by your service provider to install the Broadband Access client software and utilize the service.

< Back Next > Cancel Help

Clicking the **Service Activation** button initiates the registration and authentication routines.


The **Link Status** and **Message Status** fields will indicate when the airlink has been established. The **Airlink LED** on the transceiver illuminates at this point.

Step 7 IP Address

The screenshot shows the 'BRU IP Address Setting' dialog box. On the left, there is a 'Signal Strength' section with a vertical bar scale from 0 to 30 and more. The scale is divided into 'Excellent' (20-30), 'Good' (10-20), and 'Ok' (0-10). Below the scale, there are three fields: 'Selected Code:' with 'Base Code=4', 'Link Status:' with 'Airlink Active(14)', and 'Signal Strength:' with '43'. Below these fields is a 'Signal Strength Details...' button. At the bottom left, there is a 'Message Status:' section with a text box containing 'You are connected over the air now.' and a 'Message Log...' button. On the right, there is a 'STEP 7 - IP Address Setting' section. It contains a text box explaining the default IP address (192.168.1.1) and subnet mask (255.255.255.0). Below this, there are two input fields: 'Enter New IP Address:' with '192.168.1.1' and 'Enter New Subnet Mask:' with '255.255.255.0'. Below these fields are 'Click' and 'Apply' buttons, followed by the text 'to change these settings.' At the bottom right, there is a note: 'You can modify these settings later by right-clicking the start bar icon and selecting "BRU Status" from the pop-up menu.' At the very bottom of the dialog box, there are four buttons: '< Back', 'Next >', 'Cancel', and 'Help'.

As discussed in the section [LAN Connection](#) on page 23, changing the default IP address is normally required only when the remote unit connects to a router.

Step 8 Installation Status



This final window provides a summary of the installation and airlink statistics.

If you enable the **Launch BRU Monitor Client** check box, the status monitor application will open, and the installation tool will close, when you click **Finish**.

Other Technical Features

This section presents two additional features of the BRU-150 that you will use.

Default Configuration Button

There is a default configuration button located behind the front panel of the BRU-150 transceiver, as shown in [Figure 1-2](#) on page 6.

Actuating this button causes the following actions:


- ♦ Cycles power to the transceiver
- ♦ Sets the IP address to the default 192.168.1.1
- ♦ Sets the subnet mask to the default 255.255.255.0
- ♦ Sets the base station offset code to the default -1

Insert a paper clip, or similar object, through the hole in the front panel to actuate the button.

Shortcut Menu

When either the status monitor or installation tool applications are opened, an icon appears in the Windows system tray of the service computer. When you close the application window, the system tray icon still remains and the application runs in the background.

Right-click the system tray icon to access this shortcut menu. Note that the menu commands differ depending on which of the service utilities are open. When the status monitor is open, the `Start BRU-150 Installation` command is not present.



The commands on this menu are described below.

BRU-150 Status	Opens the Status Monitor application.
Start BRU-150 Installation	Opens the installation tool.
Logout from BRU-150	Ends the connection between the service utilities and BRU-150.
Change BRU-150 IP Address	Opens the Status Monitor to the BRU-150 IP Address Setting page.
Reset BRU-150	Cycles power to the BRU-150. Note that cycling power does not accomplish a full reset. Configuration data is stored in non-volatile memory and is not affected by power cycling. Actuating the reset button on the transceiver erases this data.
About BRU-150 Self-Install Software	Standard product splash screen.
Exit	Closes whichever application is open. This command is the only way to completely close the applications.



Status Monitor

In This Chapter:

- ▲ [Overview, page 40](#)
- ▲ [Status Monitor Displays, page 41](#)

This chapter describes the status monitor window of the service utilities.

Overview

The three tabbed pages in the status monitor window provide the following functions:

- **Signal Strength Monitor**
 - Displays the signal strength from the base station
 - Displays base code, link status, and signal strength data
 - Provides links to detailed reports on signal strength and the message log
- **IP Address Setting**
 - Sets a new IP address in the remote unit
- **Diagnostics**
 - Tests connectivity between the host PC and the remote unit, and between the remote unit and the base station.


Open the status monitor by executing the file `BRU-Mon.exe`.

The status monitor is also installed on the subscriber's computer during the installation process. It is intended to provide limited functionality to technically-oriented subscribers. For the less technical subscribers, it is an information source they may be asked to read during a telephone technical support session.

Status Monitor Displays

This section provides details of the GUI displays in the status monitor.

Signal Strength Monitor



This page contains the following features:

- **Login**

Use the remote unit default IP address of 192.168.1.1 to log in.

You do not need to log in if the status monitor is opened after the installation tool and the remote unit have established a connection. The login field will be greyed out.

If the remote unit is reset or power-cycled after establishing the connection, you must log in again.

- **Signal Strength (Bar)**

The graduation numbers on the dynamic bar display are relative, they do not have a unit of measure. The approximate signal levels at the guidance marks are as follows:

0 = Approximately -127 dBm

OK = Approximately -122 dBm

Good = Approximately -112 dBm

Excellent = Approximately -99 dBm

The display's maximum is -80 dBm.

- **Selected Code**

This is the base station offset code, which is a unique identifier the remote unit uses to distinguish one base station from another. The displayed code indicates the base station with which the remote unit is registered.

- **Link Status**

This is the current functional status of the remote unit. The status information is used primarily for technical service calls. A fully functional unit has a status of `Airlink Active (14)`.

- **Signal Strength (Value)**

This field provides a numerical display of the signal strength shown in the dynamic bar display. See the explanation above for Signal Strength (Bar).


- **Signal Strength Details**

This button generates a report containing highly technical data. This is discussed in the section [Signal Strength Details](#) on page 31.

- **Message Log**

This button opens a log of the current session. This is discussed in the section [Message Log](#) on page 32.

IP Address Setting




Use this page to change the IP address in the remote unit, if necessary. The default factory address of 192.168.1.1 will work for a remote unit that is connected directly to the host PC. The address may need to be changed for a LAN connection. See the section [LAN Connection](#) on page 23 for more discussion.

NOTE: The text shown above in this window describes an old default address. This display will be changed in the next release.

The **Signal Strength Details** and **Message Log** buttons are the same as those on the previous page.

Diagnostics



This page allows you test the connectivity from the host PC to the remote unit, and from the host PC to the base station.

In the **Network Health** pane, expand the `Network Connectivity` branch by clicking the + symbol.

Select either the `BRU` or the `Base` sub-branch from the display.

Click the **Test** button then observe the results in the lower panel.

Click the **Clear** button to clear the lower panel display, if desired.

Remote Unit Specifications

In This Appendix:

- ▲ [Functional Characteristics, page 46](#)
- ▲ [User Throughput, page 46](#)
- ▲ [Radio Characteristics, page 46](#)
- ▲ [Antenna Characteristics, page 47](#)
- ▲ [Physical Characteristics, page 47](#)
- ▲ [Physical Dimensions, page 47](#)
- ▲ [Environmental Characteristics, page 47](#)
- ▲ [Regulatory Compliance, page 48](#)

This appendix presents technical specifications for the BRU-100 and BRU-150 Remote Unit. The listed specifications are applicable to both models unless otherwise indicated.

Functional Characteristics

Interfaces:	10/100 Ethernet
Frequency Range:	2305 – 2320 MHz and 2345 – 2360 MHz,
Active Channel Bandwidth:	1.25 Mhz, paired
Access Method:	OFDMA, SDMA
Duplex Method:	TDD
Protocols:	IP, UDP, TCP, PPPoE, SNMP, RTP, FTP, L2TP, IPSec
Air Link Security:	128 bit private key encryption and authentication
Service Rate:	variable from 64 Kbps to 1.5 Mbps
Service Classes:	Best Effort

User Throughput

Bits/symbol	Modulation	Downstream	Upstream
4	32 QAM	1.5 Mbps	1.2 Mbps
3	16 QAM	1.1 Mbps	900 Kbps
2	8 PSK	770 Kbps	600 Kbps

Radio Characteristics

Transmit Power:	+30 dBm average
Active Channel Bandwidth:	1.25 Mhz, paired
Modulation:	OFDM, 32 QAM, 16 QAM, 8 PSK (adaptive)

Antenna Characteristics

	BRU-100	BRU-150
Bore Sight Gain:	18 dBi nominal	11 dBi minimum
Azimuthal Beam width:	20 degrees nominal	90 degrees nominal
Polarization:	Vertical	Vertical
Separation Distance	8 in. (20 cm) Minimum distance between radiating surface and any person, per FCC rules for RF exposure.	

Physical Characteristics

	BRU-100	BRU-150
Antenna Cable:	Cat5 outdoor; Maximum 50 m (150 feet) length	RG-223 Maximum 47 cm (120 in.) length
Power Source:	110-220 VAC 750 mA, 50-60 Hz Power adapter converts to 48 VDC	110-220 VAC 750 mA, 50-60 Hz Power adapter converts to 48 VDC

Physical Dimensions

	BRU-100 (ODU)	BRU-150 (Transceiver)
Height:	39 cm (15.5 in)	22.9 cm (9.0in.)
Width:	39 cm (15.5 in)	11.0 cm (4.3 in.)
Depth:	6.5 cm (2.5 in)	23.2 cm (9.1 in.)
Weight:	4.7 kg (10.5 lb)	1.4 kg (3.1 lb)

Environmental Characteristics

	BRU-100 (ODU)	BRU-150 (Transceiver)
Operating Temperature:	−40°C to +50°C	+5°C to +35°C
Relative Humidity (max, operating):	100%	95%

Regulatory Compliance

Regulatory Compliance: FCC Title 47: Part 15 (class B); Part 27 (WCS bands A and B)

Safety Compliance: UL 60950

Information subject to change without notice.

Index

A

airlink 29
antenna location 21
authentication 29, 33

B

base station offset code 42
bearing 28
BRU Configuration window 24
BRU Installation Tool, introduction 5
BRU-100 defined 3
BRU-150 defined 3
BRUIT *see* BRU Installation Tool
BSOC (base station offset code) 14
button, default configuration 36

C

compass 17
computer requirements 12
configuration window 24
connectivity test 44
coordinates 27
coordinates, finding 28
customer number 14, 27
cycle power 37

D

data rate 32
default configuration button 36
direction to base station 28

E

equipment, installation 17
Ethernet cable 12

F

FCC rules 3, 21
front panel 6

G

GPS 17, 28

H

hub 23

I

installation documents 9
installation overview 8

installation utility

defined 5
open 22
operation of 20

installing components 22

IP address 13, 23, 41
IP address, default 13
IP address, setting 43

L

LAN 23
latitude 27
Local RUID
assignment 8
defined 8
setting 20
login 23, 41
logout 37
longitude 27

M

message log 32

O

operating system 13

P

password 23

R

ranging 29
rear panel 7
registration 29, 33
remote unit, models of 3
reset 41
RIT (Remote Unit Installation Tool) 2, 8
router 23

S

service computer 12
service order
customer number 27
defined 14
editing 14
service utilities
defined 5
installation of 13
installation utility 19
status monitor 40

Index

shortcut menu 36
signal level 30
signal strength
 detail window 31
 in dBm 42
 monitor tool 41
 overview 40
software image file 13, 24
specifications 45

status monitor
 defined 5
 open 40
switch 23
synchronization 29

T

Transceiver
 front panel 6
 rear panel 7

U

upload software 25