



DIMAGE
MN52Z



User Manual

BEFORE YOU START

Declaration of Conformity

Responsible Party: Elite Brands Inc.

Address: 40 Wall St, Flr 61, New York, NY 10005 USA

Company Website: www.elitebrands.com ;
www.minoltadigital.com

For Customers in the U.S.A.

Federal Communication Commission Interference Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

-
- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Radiation Exposure Statement:

These requirements set a SAR limit of 1.6 W/kg averaged over one gram of tissue. The highest SAR value reported under this standard during product certification for use when properly worn on the body is 0.157 W/kg.

About this Manual

Thank you for purchasing this MINOLTA MN52Z Digital Camera. Please read this manual carefully and keep it in a safe place for future reference.

- Elite Brands Inc. reserves all rights of this document. No part of this published manual may be reproduced, transmitted, transcribed, stored in a retrieval system or translated into any language or computer language, in any form, by any means, without the prior written permission of Elite Brands Inc.
- All trademarks mentioned in this manual are used for identification purposes only and are properties of their respective owners and holders.
- This manual provides you with instructions on how to use your new MINOLTA MN52Z Digital Camera. Every effort has been made to ensure that the contents of this manual are accurate; however Elite Brands Inc. reserves the right to make changes without notice.
- Throughout this manual, the following symbols are used to help you locate information quickly and easily:



Indicates useful information.

- The following symbols may be used throughout this manual to facilitate your understanding of how to operate the camera:

[Item properties]:The optional properties in the camera interface are indicated by the [] symbol.

Trademark Information

- Microsoft, Windows and Windows Vista are registered trademarks of Microsoft Corporation in the United States of America and other countries.
- Macintosh, Mac OS, OS X and App Store are trademarks of Apple Inc., registered in the U.S. and other countries.
- Google and Google Play are trademarks of Google Inc.
- USB Type-C is a trademark of USB Implementers Forum.
- QR Code is a trademark of Denso Wave Inc.
- All other trademarks are the property of their respective owners.

SAFETY NOTES

Safety Notes for this Camera

- Do not drop the camera or allow it to hit solid objects.
- Do not attempt to disassemble or repair the camera.
- Do not use or store the camera in dusty places or on a beach to help prevent dust or sand from entering the camera, causing possible damage.
- Do not use or store the camera in a hot environment or in direct sunlight.
- Do not use or store the camera near powerful magnetic fields, such as a magnet or transformer.
- Avoid touching the lens of the camera.
- Do not expose the camera to direct sunlight for a long period of time.
- To prevent the camera from being damaged by moisture, do not use or store the camera in very humid environments, such as in rain or near bodies of water.
- If water accidentally comes in contact with the camera, turn the camera off immediately, remove the battery and the memory card and dry it completely within 24 hours.
- When you take the camera from a cold environment to a warmer environment, condensation may occur. Please wait for a reasonable period of time before you turn the camera on.
- Before you remove the battery and memory card, the camera should be turned off.
- When you clean the body of the camera, do not use abrasive, alcohol-based or organic cleansers or solvents.

-
- Use a professional lens cleaning cloth and appropriate cleaner to wipe and clean the lens.
 - Download your photos and remove the memory card when you are going to store the camera for long periods of time.
 - If this camera is not in use for a long period of time, please keep it in a dry and clean storage location.
 - Our company will not pay compensation for any failure of playback including: pictures or videos damaged or unrecoverable by improper operation.

Safety Notes for Battery

- Please use a battery that is the same type as the one included.
- Please use the attached charger to charge the battery.
- If battery fluid leaks inside the camera, contact our customer service department immediately. If battery fluid leaks onto your skin, rinse your skin immediately with clean water and seek immediate medical attention.
- Disposal of used batteries should be carried out in accordance with your local (national or regional) regulations.
- To prevent the battery from being damaged, do not drop the battery or allow it to hit solid objects or to be scratched by foreign objects.
- Do not let the battery come in contact with metal objects (including coins) to avoid short circuiting, discharging, excessive heat or possible leakage.
- Do not attempt to disassemble the battery.
- Do not expose the battery to water. Always keep the battery contacts dry.
- Do not heat the battery or throw it into a fire to avoid a possible explosion.

-
- Do not store the battery in a hot environment or in direct sunlight.
 - If the battery overheats during charging or use, stop charging or use immediately. Turn off the product, remove the battery carefully, and wait until it cools down.
 - When the camera is stored for a long period of time, remove the battery and keep it in a safe, dry place that is not accessible to infants and children.
 - In colder environments, the performance of the battery could be noticeably reduced.
 - When you install the battery, align the battery markings according to the positive and negative markings inside the camera battery compartment. Never force the battery into the battery compartment.

Safety Notes for SD Memory Card

- We highly suggest buying only well-known, name brand memory cards to ensure peak performance and reliability.
- Format the memory card using the camera before you use it or insert a new one.
- Do not drop the memory card or allow it to hit solid objects to avoid damaging it.
- Do not attempt to disassemble or repair the memory card.
- Do not expose the memory card to water. Always keep it dry.
- Do not remove the memory card when the camera is turned on. Otherwise, the memory card and photo/video files could be permanently damaged.
- Do not directly edit the data on the memory card. Copy the data to your computer before you edit files.
- When the camera is stored for long periods of time, be sure to download your photos and remove the memory card. Store the memory card in a dry environment.

-
- Do not modify the name of the files or folders of the memory card using your computer. Modifying the file names may cause the files to not be recognized on the camera or a possible permanent error may occur.
 - A photo taken with the camera will be stored in the folder that is automatically generated on the memory card. Do not store photos that are not taken using this camera in these folders as the pictures cannot be recognized during playback.
 - When you insert the memory card, make sure the notch of the card matches the markings on the top of the camera card slot.

Other Safety Notes

- Do not disconnect the power or turn the camera off during the update process. Doing so may cause incorrect data to be written and the camera may not power on later.
- Do not hang the neck strap of the camera around the neck of a child.
- When using your camera on an airplane, observe the relevant rules specified by the airline and FAA regulations.
- Due to the limitations of manufacturing technology, the LCD may have a few dead or bright pixels. These pixels do no effect the quality or performance of the camera, photos or video.
- Do not expose the camera's LCD to water. In a humid environment, only wipe it with a soft, dry, cleaning cloth.
- If the LCD is damaged and the liquid crystal comes into contact with your skin, wipe your skin with a dry cloth immediately and rinse it with clean water. If liquid crystal comes into contact with your eyes, wash them with clean water at least for 15 minutes and seek immediate medical attention. If you accidentally swallow liquid crystal, rinse your mouth immediately and seek medical attention.

CONTENTS

BEFORE YOU START	1
------------------------	---

SAFETY NOTES	5
--------------------	---

CONTENTS	9
----------------	---

GETTING READY	13
---------------------	----

Accessories Included	13
----------------------------	----

Installing Lens Cap and Neck Strap ..	14
---------------------------------------	----

Button Overview.....	15
----------------------	----

Installing the Battery and SD Memory Card.....	17
--	----

Charging the Battery	19
----------------------------	----

Turning Camera On and Off	21
---------------------------------	----

How to Take Pictures	22
----------------------------	----

Set your Language, Region and Time	23
--	----

Set your Language, Region and Time after the First Power-On.....	23
--	----

Resetting your Language	24
-------------------------------	----

Resetting Region and Time	25
---------------------------------	----

LCD DISPLAY	27
-------------------	----

Overview of the Screen Icons in Shooting Mode	27
---	----

Overview of the Screen Icons in Movie Mode	28
--	----

Overview of the Screen Icons in Playback Mode.....	29
--	----

BASIC OPERATION	30
-----------------------	----

Using the Mode Dial	30
---------------------------	----

Auto Mode 	30
---	----

Program AE P	31
---------------------------	----

Aperture Priority A	32
----------------------------------	----

Shutter Priority S	32
---------------------------------	----

Manual Mode M	32
----------------------------	----

Movie Mode 	32	Aperture Adjustment	47
Time-lapse Mode 	32	EV Adjustment.....	47
U1/U2 (User Define)		ISO Adjustment.....	48
U1 / U2	33	Shutter Speed Adjustment	48
Scene Mode SCN	36	Using the AE-L/AF-L Key	49
Using the Zoom Function.....	38	Using the C1 Key	50
Using the DISP Key.....	39	Custom Keys Settings	50
During shooting.....	39	Using the Menu Key.....	52
Quick calls.....	40	Time-lapse Photo & Time-lapse Video	53
During playback ().....	41	WDR Video	54
Using the Macro Key	42	Exposure Metering	54
Macro Key Setting.....	42	Focus Area	55
Using the Self-timer Key.....	43	WB	56
Using the Flash Key.....	44	AF Mode	57
Flash Key Setting.....	45	Using the Fast Video Recording Key	58
Using the Burst Key	46	Using Playback Key	60
Burst Key Setting	46	Viewing Photos and Videos.....	60
Using the Aperture Key	47		

Using Zoom Playback (for still pictures only).....	63
Deleting a Photo or Video	64
Single playback	64
Index playback.....	66

USING THE MAIN MENU 70

Capture Menu 	71
Digital Zoom	72
Face Detection	72
OIS (Optical Image Stabilization)	72
WDR (Wide Dynamic Range)	73
Video Menu 	74
Video Size.....	74
Video Bitrate.....	76
Video Format.....	76
Anti-shake.....	76
Photo Menu 	77
Photo Size	77

Quality.....	78
Preview.....	79
AF Assist Beam.....	79
Playback Menu 	80
Protect.....	80
Delete.....	81
General Menu 	82
Beep Sound	82
Screen Brightness.....	83
Power Saver.....	83
Firmware.....	84
Media Menu 	85
Wireless.....	85
Custom File Name	87
New Folder	87
Reset.....	88

CONNECTION SETTINGS 89

Connecting to a Computer.....89

Transferring Files to your
Computer.....89

Viewing Images on Computer 90

APPENDICES 91

Product Specifications 91

Prompts and Warning Messages 95

Troubleshooting 99