

BLUETOOTH REMOTE CONTROL

Quick Instructions

You need to perform Bluetooth pairing to enable the voice function.

Use the remote control 【power key】  to turn on the projector.

Bluetooth pairing

When the projector is turned on to enter the system, press and hold the [Shortcut Center Key]  and [Settings Key]  on the remote control at the same time for more than 2 seconds.

When the indicator light starts to flash, it enters the pairing mode, and the remote control will automatically pair and connect. After the pairing is successful, the system interface will have a corresponding prompt.

If the indicator light goes out and there is no prompt, the pairing fails and you need to pair again.

After the Bluetooth pairing is successful, you can use the voice function.

After successfully pairing, turn on the projector again without repeating pairing, it will automatically pair. If it fails to automatically pair or replace the projector, you need to manually perform the pairing operation again.

LED indicator display.

Touch the button and the LED light will turn on.

Long press the button, the LED light keeps on.

When pairing, the LED light flashes for 0.5 seconds, the pairing successful LED is always on for 2 seconds, and the pairing timeout indicator is off.

When the battery level is less than 10%, the indicator light flashes twice at an interval of 1.5 seconds, and flashes cyclically, with an interval of 0.5 seconds.

When charging, the LED light is a breathing light effect.

FCC statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

- 1) this device may not cause harmful interference, and
- 2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement

This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

IC

The licensed transmitter/receiver contained in this device is compliant with Innovation, Science and Economic Development Canada's RNC for licensed radio devices. The operation is permitted under two conditions:

1. The device must not cause interference;
2. The device must accept any radio interference, even if the interference is likely to compromise its operation.

RF exhibition statement:

The equipment complies with the IC radiation exposure limit established for an uncontrolled environment. This equipment must be installed and used with a minimum distance of 20 cm between the radiator and your body.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

1. L'appareil ne doit pas produire de brouillage;
2. L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Déclaration d'exposition RF:

L'équipement est conforme à la limite d'exposition aux radiations de la IC établie pour un environnement non contrôlé.