

DWL Quick Reference



- 1**  **Service Alert Icon**
 This wheel end took air multiple times
- 2**  **Real Time Alert LED**
 If Constant – Low Flow Rate
 If Flashing – High Flow Rate
 If Off – No Flow
- 3**  **Trip Alert Icon** – This wheel end took air during the trip (resets on power up)
- 4**  **Signal Icon** – This icon indicates the wireless signal strength from the control box
- 5**  **Binding Icon** – This indicates that the warning lamp has connected to a control box
- 6** 
 - Status Code '0'** – The system is operating properly
 - Status Code '1'** – The warning lamp has not communicated with the control box for 15 minutes
 - Status Code '2'** – The system senses low inlet pressure (ball valve at control box may be shut of)

DWL Detailed Reference

On **power up** all Lights (**item 2**) on the Driver Warning Light (DWL) will **blink 3 times**.

Once **communications are established** with the control box The DWL "**Binding Icon**" will turn on (**item 5**).

Signal Icon will appear above the "Binding Icon" icon and will be updated continuously for the first 10 minutes after each power on for **determining signal strength** from the control box (**item 4**).

During **Normal Operation** the lights will be off and the LCD will read "**0**" in the system status section (**item 6**). The DWL cannot respond to flow events if we are not in this state.

If **no communication** has been received from the control box the LCD will read "**1**" in the status section (**item 6**) until communications with the control box are established which can take as long as 2 minutes after a new install but is typically less than 10 seconds.

If **no pressure** exists at the control box the DWL system status will read "**2**" (**item 6**).

On a **low flow event** that has lasted at least 10 seconds the corresponding wheelend **light will turn on continuously** (**item 2**) and the display will show a **yellow persistent block** at that wheel end location indicating flow occurred on this trip (**item 3**). When the flow event goes away the light will turn off but the **yellow block will stay on without power** until the next power up event.

On a **high flow event** that has lasted at least 10 seconds the corresponding wheelend **light will begin blinking** (**item 2**) and the display will show a **yellow persistent block** at that wheel end location indicating flow occurred on this trip (**item 3**). When the flow event goes away the light will stop blinking but the yellow block will stay on without power until the next power up event.

If the system detects that **repeated or severe flow events** are occurring and the system the "**service alert icon**" will turn on and stay on until the system is repaired (**item 1**). The service alert indicator will clear itself after 1-2 days of good conditions on that wheel end. A Stemco HandBat can also be used to clear the service event manually if desired.

Smart Sense Control box Detailed Reference

On **power up** the status light on the flow meter will **blink red 3 times**.

If all is **good** then each channel light will be off and status light will **blink green**.

If **no pressure** exists at the control box the status and individual channel lights will blink **two red quick blinks then 1 long red blink repeated** as long as the system air pressure is low.

If the system detects **flow events on different channels** of varying flow amounts then the corresponding **channel lights will light up** corresponding to the flow conditions on their respective channels.

On a **low flow** event the **red status light will turn on** corresponding to that wheel end and with a short intermittent off blink until the flow event goes away.

On a **high flow** event **the red status light will blink** corresponding to that wheel end in a long on/off pattern until the flow event goes away.

AERIS smart sense debugging techniques using the DWL

1. With the entire system connected apply power. Does the red light on the circuit board blink at power up?

If no then check power connections +12 and Ground continuity to the circuit board and 7 pin connector.

2. After power up works successfully take off the power lead and the light lead and connect them together the Driver Warning Light (DWL) should light up and blink 3 times.

If no then the connection to the light yellow line is not connected or the light is not grounded.

3. If both light and board power up then connect all wires back to the circuit board and verify that system powers up and blinks three times on a power up event both on the circuit board and at the front light on the trailer.

If the lights on the circuit board blink but the light on the trailer does not then you have a control box circuit board problem.

4. If both the light on the trailer and the light on the board blink 3 times next check that the blinking stops or that the light on the front of the trailer goes to a solid on state or consistent blink state or an off state. Those are all three valid states.

If the light on the trailer stops blinking but the DWL display has a status code of "2" this means that pressure has not reached the control box yet. Check that the air control valve is in the on position.

If the control valve is in the on position then the brake system has not received enough air to open the PPV valve yet. Wait for the airbrake tank to fill or check glad hands are connected to the tractor.

5. If the light stays on solid or blinks consistently in timing then the system is taking air. If no hissing is heard coming out of the air connections then the tires are low and simply taking air.

If hissing is coming from an air connection, fix the leak.

6. If the light goes out after 3 blinks but the display has a status code of "1" then communications have not been established yet. Wait 2 minutes and verify that the status has changed to something other than "1"

If the status stays at 1 then no communication is being received at the DWL. Use a HandBat to reset DWL alerts and verify that the top left LED blinks when alerts are reset.

If the light does not blink then the DWL is bad and needs to be replaced.

If the light blinks then there is a circuit board problem in the control box.

7. If a flow event is shown but not on the correct wheel position then verify air hoses in the control box are connected to the correct locations on the manifold
8. If the display has a status code of "0" after power up but the signal strength above the "chain link" icon only shows a single dot instead of any signal bars then check to make sure that the control box is mounted at the front of the axles facing the front of the trailer.
9. If the light goes out after the first 3 blinks and the display has a status code of "0" then all is ok and tires are aired up.

Certifications

FCC (USA)

This unit complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



FCC ID: SRA-830025X

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- „„ Reorient or relocate the receiving antenna.
- „„ Increase the separation between the equipment and receiver.
- „„ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- „„ Consult the dealer or an experienced radio/TV technician for help.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment. The antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter. Users and installers must be provided with antenna installation instructions and transmitter operating conditions for satisfying Rf exposure compliance. Should you need any additional assistance with any problems or issues please contact STEMCO Customer Service at (800) 527-8492.

Industry Canada

IC: 7413A-830025X

NOTICE: This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Cet appareil est conforme avec Industrie Canada RSS standard exempts de licence (s). Son fonctionnement est soumis aux deux conditions suivantes: (1) cet appareil ne peut pas provoquer d'interférences et (2) cet appareil doit accepter toute interférence, y compris les interférences qui peuvent causer un mauvais fonctionnement du dispositif.