

Villa Door Station

User's Manual



Foreword

General

This manual introduces basic operations of the digital door station (hereinafter referred to as "VTO").

Safety Instructions

The following categorized signal words with defined meaning might appear in the manual.

Signal Words	Meaning
 DANGER	Indicates a high potential hazard which, if not avoided, will result in death or serious injury.
 WARNING	Indicates a medium or low potential hazard which, if not avoided, could result in slight or moderate injury.
 CAUTION	Indicates a potential risk which, if not avoided, could result in property damage, data loss, lower performance, or unpredictable result.
 TIPS	Provides methods to help you solve a problem or save you time.
 NOTE	Provides additional information as the emphasis and supplement to the text.

Revision History

Version	Revision Content	Release Date
V1.0.0	First release.	November 2021

Privacy Protection Notice

As the device user or data controller, you might collect the personal data of others such as their face, fingerprints, and license plate number. You need to be in compliance with your local privacy protection laws and regulations to protect the legitimate rights and interests of other people by implementing measures which include but are not limited: Providing clear and visible identification to inform people of the existence of the surveillance area and provide required contact information.

About the Manual

- The manual is for reference only. Slight differences might be found between the manual and the product.
- We are not liable for losses incurred due to operating the product in ways that are not in compliance with the manual.
- The manual will be updated according to the latest laws and regulations of related

jurisdictions. For detailed information, see the paper user's manual, use our CD-ROM, scan the QR code or visit our official website. The manual is for reference only. Slight differences might be found between the electronic version and the paper version.

- All designs and software are subject to change without prior written notice. Product updates might result in some differences appearing between the actual product and the manual. Please contact customer service for the latest program and supplementary documentation.
- There might be errors in the print or deviations in the description of the functions, operations and technical data. If there is any doubt or dispute, we reserve the right of final explanation.
- Upgrade the reader software or try other mainstream reader software if the manual (in PDF format) cannot be opened.
- All trademarks, registered trademarks and company names in the manual are properties of their respective owners.
- Please visit our website, contact the supplier or customer service if any problems occur while using the device.
- If there is any uncertainty or controversy, we reserve the right of final explanation.

Important Safeguards and Warnings

This section introduces content covering the proper handling of the device, hazard prevention, and prevention of property damage. Read carefully before using the device, comply with the guidelines when using it, and keep the manual safe for future reference.

Operation Requirements



- Check whether the power supply is correct before use.
- Do not unplug the power cord on the side of the device while the adapter is powered on.
- Operate the device within the rated range of power input and output.
- Transport, use and store the device under allowed humidity and temperature conditions.
- Do not drop or splash liquid onto the device, and make sure that there is no object filled with liquid on the device to prevent liquid from flowing into it.
- Do not disassemble the device without professional instruction.

Installation Requirements



WARNING

- Strictly comply with the local electric safety code and standards. Make sure the ambient voltage is stable and meets the power supply requirements of the device.
- Do not connect the device to two or more kinds of power supplies, to avoid damage to the device.
- Improper use of the battery might result in a fire or explosion.



- Personnel working at heights must take all necessary measures to ensure personal safety including wearing a helmet and safety belts.
- Do not place the device in a place exposed to sunlight or near heat sources.
- Keep the device away from dampness, dust, and soot.
- Install the device in a well-ventilated place, and do not block its ventilation.
- Use an adapter or cabinet power supply provided by the manufacturer.
- Use the power cords that are recommended for the region and conform to the rated power specifications.
- Make sure the power supply meets the SELV (Safety Extra Low Voltage) requirements, and rated voltage conforms to the IEC60065, IEC60950-1 or IEC62368-1 standard. The requirements of the power supply are subject to the device label.

Table of Contents

Foreword	I
Important Safeguards and Warnings	III
1 Initializing the VTO	1
2 Login and Resetting Password.....	3
2.1 Login.....	3
2.2 Resetting Password	3
3 Home Page	5
4 Local Settings	6
4.1 Basic.....	6
4.2 Video & Audio.....	9
4.3 Access Control Settings	11
4.3.1 Local	11
4.3.2 RS-485.....	12
4.4 System	13
4.5 Security	14
4.6 Onvif User	16
4.7 Upload File	17
5 Household Setting.....	19
5.1 VTO No. Management	19
5.2 VTH Management.....	20
5.3 Personnel Management.....	21
5.4 VTS Management	24
5.5 Status	25
6 Network	26
6.1 Basic.....	26
6.1.1 TCP/IP	26
6.1.2 Port	26
6.1.3 Cloud service	27
6.2 UPnP.....	28
6.2.2 Enabling UPnP Services	28
6.2.3 Adding UPnP Services.....	28
6.3 SIP Server	29
6.4 WiFi	31
6.5 Firewall	31
7 Log Management.....	33
7.1 Call	33
7.2 Alarm	33
7.3 Unlock	33
7.4 Log	34
Appendix 1 Cybersecurity Recommendations	35

1 Initializing the VTO

For first-time login or after resetting the VTO, you need to initialize it on the web.

Step 1 Power on the VTO.

Step 2 Go to the default IP address (192.168.1.108) of the VTO.



Make sure that the IP address of your PC is in the same network segment as the VTO.

Figure 1-1 Device initialization

Device Init

1 One 2 Two 3 Three

Username admin

Password

Low Middle High

Confirm Password

Next

Step 1 On the **Device Init** page, enter and confirm the password, and then click **Next**.



The password must consist of 8–32 non-blank characters and contain at least two types of the following characters: Uppercase, lowercase, numbers, and special characters (excluding ' " ; : &).

Figure 1-2 Set an email address

Device Init

1 One 2 Two 3 Three

Email ☐


(To reset password, please input property or update in time)

Next

Step 2 Select the **Email** checkbox and enter email address for resetting password. This helps you to reset your password when your password is lost or forgotten.

Step 3 Click **Next**.


Figure 1-3 Initialization successful



Step 4 Click **OK** to go to the login page.

Enter username (admin by default) and password to log in to the web page.

Figure 1-4 Login page



2 Login and Resetting Password

2.1 Login

Before login, make sure that the PC is in the same network segment as the VTO.

Step 1 Go to the IP address of the VTO in the browser.



For first-time login, enter the default IP (192.168.1.108). If you have multiple VTOs, we recommend changing the default IP address (**Network > Basic**) to avoid conflict.

Step 2 Enter "admin" as username and the password you set during initialization, and then click **Login**.

Figure 2-1 Login

2.2 Resetting Password

Step 1 On the login interface, click **Forgot Password?**, and then click **Next**.

Figure 2-2 Reset the password

Step 2 Scan the QR code, and then you will get a string of numbers and letters.

Step 3 Send the string to the email: support_gpwd@htmicrochip.com, and then the security code will be sent to the email address configured during initialization.

Step 4 Enter the security code in the input box, and then click **Next**.



- If you did not set an email address during initialization, contact your supplier or customer service for help.
- The security code will be valid only for 24 hours upon receipt.
- If you enter the wrong security code for 5 consecutive times, your account will be locked for 5 minutes.

Step 5 Enter and confirm the new password, and then click **OK**.

3 Home Page

Figure 3-1 Home Page




Table 3-1 Home page introduction

No.	Function	Description
1	General function	: Change the password and your email address. : Go to the home page. : Log out, restart the VTO or restore the VTO to factory settings. If you restore the VTO to factory settings, all data except external storage will be deleted. You can format the SD card to delete the data in it.
2	VTO information	View the information of the VTO and the system.
3	System information	
4	Configuration manager	Export or import VTO configuration or user information.
5	Function	Configure parameters for different functions. Slight difference might be found in the web page and function in different models.

4 Local Settings

This chapter introduces the detailed configuration of the VTO.



Slight differences might be found in different models.

4.1 Basic

Device Properties & Events

Step 1 Select **Local Settings > Basic**.

Step 2 Configure the parameters.

Figure 4-1 Basic

Table 4-1 Basic parameter description

Parameter	Description
Device Type	Select Villa Station or Small Apartment as needed.
Center Call No.	The default phone number for the management center is 888888, and you can set it to any number with up to 9 digits.
Device Name	When other devices are monitoring this VTO, the device name will appear on the monitoring image.
Calling Center Period	Time period in which the management center can be called. Configure the time and enable the function so that you will receive calls only in that period.
Villa Call No.	Used to call VTHs.
No.	Used to differentiate each VTO, and we recommend you set it according to unit or building number, and then you can add VTOs to the SIP server by using their numbers.

Parameter	Description
	 The number cannot be changed when the VTO serves as the SIP server.
Periods in which Calls can be Made	Configure the time if you only want to receive calls from VTH during a specific period.
Group Call	Enable it on the VTO that works as the SIP server, and when a main VTH receives a call, all extension VTHs will also receive the call.
Storage Point	SD card by default.
Total SD Card Capacity	Displays the total and used capacity of the SD card. You can click Format to delete all the data in the SD card.
SD Used Capacity	
Format	
Auto Capture (Unlock)	When the door is unlocked, the VTO will take two snapshots and save them to the SD card.
Auto Capture (Calling)	Take a snapshot and save it in the SD card of the VTO when the VTO is calling.
Upload Video Messages	When enabled: ● If an SD card is inserted in both the VTH and VTO, the video message will be saved both in the SD cards of the VTH and the VTO. ● If an SD card is only inserted in the VTH or the VTO, the video message will be saved only in the SD card of the VTH or the VTO. ● If no SD card is inserted in the VTH or VTO, no video message will be saved.
Auto Recording (Call)	Take recording when the VTO is in a call, and save the recording in the SD card of the VTO.

Step 3 Click **Save**.

Façade Layout



Only the VTO model that with multiple buttons has this web function.

Step 1 Log in to the VTO web page.

Step 2 Select **Local Settings > Basic**.


Step 3 In the **Façade Layout** section, select **Count** types.

Count 1: Can only bind one room number.

Count 2: Can bind two room numbers.

Count 4: Can bind four room numbers.

Figure 4-2 Count



Step 4 Click on the white module, and select the room number from the **Room List** you want to bind.

Figure 4-3 White module






Figure 4-4 Room list



Step 5 Click **Save** to save the selected room number.

Step 6 Click **Confirm** to save all the settings.

Figure 4-5 Confirm



4.2 Video & Audio

Configure the video format and quality, and audio of the VTO.

Step 1 Select **Local Settings > Video & Audio**.

Figure 4-6 Video





Figure 4-7 Audio



Step 2 Configure the parameters, which will take effect upon change.

Table 4-2 Video parameter description

Parameter		Description
Main Stream	Video Format	Select different resolution as needed: ● 720P: 1280 × 720. ● WVGA: 800 × 480. ● D1: 720 × 480. ● CIF: 352 × 288.
	Frame Rate	The range is 1 to 25. The larger the value, the smoother the video, but it requires more bandwidth.
	Bitrate Rate	Include 768 Kbps, 896 Kbps, 1024 Kbps, 1.25 Mbps, 1.5 Mbps, 1.75 Mbps, 2Mbps and 4 Mbps. The larger the value, the better the video quality, but it requires more bandwidth.
	Compression	● H.264. ● H.265.
Sub Stream	Video Format	Select different resolution as needed: ● 1080P: 1920 × 1080. ● WVGA: 800 × 480. ● QVGA: 320 × 240. ● D1: 720 × 480. ● CIF: 352 × 288.
	Frame Rate	The range is 1 to 25. The larger the value, the smoother the video, but it requires more bandwidth.
	Bitrate Rate	Include 224 Kbps, 256 Kbps, 320 Kbps, 384 Kbps, 448 Kbps, 512 Kbps, 640 Kbps, 768 Kbps. The larger the value, the better the video quality, but it requires more bandwidth.
	Compression	● H.264. ● H.265.
Status	Scene Mode	Select from Auto , Disabled , Sunny and Night . Auto is selected by default.
	Compensation Mode	● BLC: Back light compensation. Improve the clarity of the target in the image. ● WDR: Wide dynamic range. Enhance the brightness of dark areas, and reduce the brightness of bright areas to improve the image. ● HLC: High light compensation. Reduce the brightness of the strong spots to improve the overall image.
	Light Mode	Select from NO , NC , Auto and Scheduled . Auto is selected by default.
	Video Standard	Select PAL or NTSC according to your area.  PAL is mostly used in China and Europe, and NTSC primarily in the United States and Japan.
Image	Brightness	The larger the value, the brighter the image.
	Contrast	Larger value for more contrast between bright and dark areas.
	Hue	Make the color brighter or darker. The default value is made by

Parameter		Description
		the light sensor, and we recommend keeping it default.
	Saturation	The larger the value, the thicker the color.
	Gamma	Changes the picture brightness and improves the picture dynamic range in a non-linear way. The larger the value, the brighter the image.
	Gain Adjustment	Amplify the video signal to increase image brightness. If the value is too large, there will be more noise in the image.
	Mirror	Display the image with left and right side reversed.
	Flip	Display the image upside down.
	Display Time	Display the current time and date on the video image.
Audio Control	Voice Prompt Sound	Turn on or off each type of sound.
	Ringback Sound	Adjust the volume as needed.
	Alarm	
	Leave Messages	
	Unlock	
	Audio Collection	
Volume Control	Microphone Volume	
	Speaker Volume	

4.3 Access Control Settings

This section introduces how to configure the two locks connected to the lock port or the RS-485 port of the VTO.

4.3.1 Local

Step 1 Select **Local Settings > Access Control Settings**.

Figure 4-8 Local

WEB SERVICE 2.0

Local Settings Household Setting Network Search Log English

Basic

Video & Audio

Access Control Settings

Local

RS-485

System

Security

Onvif User

Update

Upload File

Legal Info

Local

Unlock Responding Interval 15 Sec.

Unlock Period 2 Sec.

Check Door Signal Before Lock ☐ ON ☒ OFF

Door Sensor Check Duration 30 Sec.

First Unlock Command 123

Door Contact Type ☐ NC ☒ NO

Door Sensor Enable ☒ ON ☐ OFF

Lock ☒ Local ☐ Second Lock

Save Refresh Default

Step 2 Configure the parameters.

Table 4-3 Local access control parameter description

Parameter	Description
Unlock Responding Interval	The door can only be unlocked again after the interval.
Unlock Period	The time during which the lock stays unlocked.
Check Door Signal Before Lock	Select On or Off as needed.
Door Sensor Check Duration	If the door is unlocked longer than the Door Sensor Check Duration, the door sensor alarm will be triggered, and the alarm will be sent to the management center.  You need to install a door contact to configure this parameter.
First Unlock Command	You can connect a third-party phone, such as a SIP phone, to the VTO, and use the command to open the door remotely.
Door Contact Type	● NC: Normally closed. ● NO: Normally open.
Door Sensor Enable	Synchronize door sensor status to indoor monitors (VTHs).
Lock	● Local: local lock. ● Second lock: 485 lock. Select the Lock type to unlock the lock you select.

Step 3 Click **Save**.

4.3.2 RS-485

Select **Local Settings > Access Control Settings**, and then configure the parameters of the lock connected through the RS-485 port.

Figure 4-9 Lock connected through the RS-485 port




Table 4-4 RS-485 description


Parameter	Description
Interface Type	Lock by default.
Unlock Responding Interval	The door can only be unlocked again after the interval.
Unlock Period	The time during which the lock stays unlocked.
Second Unlock Command	You can connect a third-party phone, such as a SIP phone, to the VTO, and use the command to open the door remotely. The default command is 456.
Lock	Local: local lock. Second lock: 485 lock. Select the Lock type to unlock the lock you select.

4.4 System

Configure time parameters, NTP server, and more.

Step 1 Select **Local Settings** > **System**.

Figure 4-10 System



Step 2 Configure the parameters.

Table 4-5 System parameter description

Parameter	Description
Date Format	Select from one of the following: • YYYY-MM-DD • MM-DD-YYYY • DD-MM-YYYY
Time Format	Select from one of the following: • 24-Hour • 12-Hour
System Time	 Changing system time might cause problems on video searching and information publication. Turn off video recording and auto snapshot before changing it.
Time Zone	Configure the time zone as needed.
Sync with PC	Synchronize the VTO system time with your PC.
DST	Daylight saving time. If it is applicable to your area, you need to enable it, and then configure DST type, start time and end time.
DST Type	Select Date or Week as needed, and then configure the specific period.
Start Time	Configure the start time and end time of DST.
End Time	
NTP Enable	Enable NTP and enter the IP address of the NTP server, and then the VTO will synchronize time with the NTP server automatically.
NTP Server	
Port	NTP server port number.
Interval	VTO time update cycle. 30 minutes at most.
Maintenance	Define the time when the VTO will restart automatically. Choose from Never, Monday, Tuesday, Wednesday, Thursday, Friday, Saturday and Sunday.
SSH	You can connect debugging devices to the VTO through SSH protocol.  We recommend turning it off, and turn on security mode and outbound service information protection. See "4.5 Security". Otherwise, the VTO might be exposed to security risks and data leakage.
Emergency Maintenance	Enable it for fault analysis and repair.  This function will occupy 8088 and 8087 ports.
NTP Enable	Enable NTP so that the device time will be automatically synchronized with server.


Step 3 Click **Save**.

4.5 Security

Configure functions that involve device security.

Step 1 Select **Local Settings > Security**.

Figure 4-11 Security



Step 2 Configure the parameters.

Table 4-6 Security parameter description

Parameter	Description
CGI Enable	Enable the use of CGI command.  We recommend you turn it off. Otherwise, the VTO might be exposed to security risks and data leakage.
Mobile Push Notification	Send information to the app on the smartphone.  We recommend you turn it off if you do not need this function. Otherwise, the VTO might be exposed to security risks and data leakage.
Password Reset	If turned off, you will not be able to reset password.
Audio/Video Transmission Encryption	Encrypt all data during voice or video call.  We recommend you turn it on. Otherwise, the VTO might be exposed to security risks and data leakage.
ONVIF On	Allow third-party to pull video stream of the VTO through the ONVIF protocol.  We recommend turning it off. Otherwise, the VTO might be exposed to security risks and data leakage.
RTSP Over TSL	Output encrypted bit stream through RTSP.  We recommend you turn it on. Otherwise, the VTO might be exposed to security risks and data leakage.

Parameter	Description
Outbound Service Information Protection	Protect your passwords.  We recommend you turn it on. Otherwise, the VTO might be exposed to security risks and data leakage.
Multicast/Broadcast Search	Enable it and the VTO will be found by other devices.  We recommend you turn it off. Otherwise, the VTO might be exposed to security risks and data leakage.
Authentication Mode	● Security Mode (recommended): Support logging in with Digest authentication. ● Compatible Mode: Use the old login method.  We recommend you use the security mode. Compatible mode might expose the VTO to security risks and data leakage.
Password Expires in	Select an expiration period as needed.  We recommend you do not use never. The VTO might be exposed to security risks and data leakage if you chose that one.

Step 3 Click **Save**.

4.6 Onvif User


Add accounts for devices to monitor the VTO through the ONVIF protocol.



If you delete an account, it cannot be undone.


Step 1 Select **Local Settings > Onvif User**.

Figure 4-12 Onvif user



Step 2 Click **Add**.

Figure 4-13 Add an ONVIF user




The 'Add' dialog box is a dark-themed window with a close button (X) in the top right corner. It contains three input fields: 'Username', 'Password', and 'Confirm'. The 'Password' and 'Confirm' fields have a small icon on the right side. Below the 'Password' field, there are three buttons labeled 'Weak', 'Medium', and 'Strong'. At the bottom right, there are two buttons labeled 'Save' and 'Cancel'.

- Step 3** Enter the information, and then click **Save**.
ONVIF devices can now monitor the VTO by using the account.

4.7 Update

- Step 1** Select **Local Settings > Update**.
Step 2 Select ways to check the update.
- **Auto Check:** Select the function to check automatically whether there is a new system version.
 - **Manual Check:** Select the function to check whether there is a new system version.

Figure 4-14 Update




4.8 Upload File

Upload audio file to change the sound when calling, unlocking the door, and more.

- Step 1** Select **Local Settings > Upload File**.
Step 2 Select an audio type from the drop-down list, and then click **Browse** to select the audio file as needed.

Figure 4-15 Change the sound prompt




Step 3 Click **Upload**.

4.9 Legal Info

You can view software license agreement, privacy policy, open source software notice in this section.

Figure 4-16 Legal information



5 Household Setting

This chapter introduces how to add, modify, and delete VTO, VTH, VTS, and IPC, and how to send messages from the SIP server to VTOs and VTHs when the VTO works as the SIP server. If you are using other servers as the SIP server, see the corresponding manual for details.


5.1 VTO No. Management

You can add VTOs to the SIP server, and all the VTOs connected to the same SIP server can call each other.

Step 1 Log in to the web page of the VTO that works as the SIP server.

Step 2 Select **Household Setting > VTO No. Management**.

Figure 5-1 VTO management



Step 3 Click **Add**.

Figure 5-2 Add VTO

The 'Add' dialog box contains the following fields: 'No.' (empty), 'Registration Password' (masked with dots), 'Build No.' (empty), 'Unit No.' (empty), 'IP Address' (127.0.0.1), 'Username' (empty), and 'Password' (masked with dots). At the bottom are 'Save' and 'Cancel' buttons.

Step 4 Configure the parameters.



The SIP server must be added.

Table 5-1 Add VTO configuration

Parameter	Description
No.	The VTO number you configured.
Registration Password	Leave it as default.
Build No.	Available only when the platform servers work as the SIP server.
Unit No.	
IP Address	IP address of the VTO.
Username	Username and password used to log in to the web page of the VTO.
Password	

Step 5 Click **Save**.



Click  or  to modify or delete a VTO, or **Clear** to delete all added VTOs, but the one that you have logged in to cannot be modified or deleted.


5.2 VTH Management

You can add room numbers to the SIP server, and then configure the room number on the VTHs to connect them to the network.

Step 1 Log in to the web page of the SIP server.

Step 2 Select **Household Setting > VTH Management**.

Figure 5-3 Room number management



Room No.	First Name	Last Name	Nick Name	Registration Mode	Modify
9901#0				public	 
9901#1				public	 
9901#2				public	 
9901#3				public	 
9901#4				public	 
9901#5				public	 
9901#6				public	 
9901#7				public	 
9901#8				public	 
9901#9				public	 

Step 3 Click **Add**.

Figure 5-4 Add a room number

Step 4 Configure the parameters.

Table 5-2 Room information

Parameter	Description
First Name	Enter the information you need to differentiate each room.
Last Name	
Nick Name	
Room No.	Enter a room number, and then configure the number on a VTH to connect to connect it to the network.
Registration Type	Select public .
Registration Password	Leave it as default.

Step 5 Click **Save**.



Click  or  to modify or delete a room number.

5.3 Personnel Management

Adding personnel information.

Card issuing

Issue an access card to unlock the door of a room.




To use this function, the VTO must have a card reader.

Step 1 Log in to the web page of the VTO.

Step 2 Select **Household Setting > Personnel Management**.

Figure 5-5 Personnel management



Step 3 Click **Add**.

Figure 5-6 Add personnel information


Step 4 Enter the parameters, and then click **Save**.

The personnel information displays on the web page.




For some VTO models, the QR code is embedded in the **Personnel Management** page. Yet for some models, you need to go to **Network > Basic > Cloud Service** to check the QR code.

Figure 5-7 Operation succeed



Step 5 Select  to go to the card issuing window.


Figure 5-8 Card issuing window



Step 6 Click **Issue Card** to issue cards.

The web page displays the countdown prompt (120 s). Once the countdown starts, you need to swipe the card on the card reader of the VTO within this time period. After the swiping, the card number will be automatically recognized by the VTO.

Figure 5-9 Countdown in process



Step 7 Click **Confirm Send Card** after swiping to complete the issuing process.

Other Operations

- Click  to set it to loss, and then the icon changes to . The lost card cannot be used to open the door.
- Click  or  to modify the username or delete the card.


5.4 VTS Management

You can add a VTS to the SIP server, and then it can be used as the management center. It can also manage, call, or receive calls from all the VTOs and VTHs in the network. See the corresponding user's manual for details.

Step 1 Log in to the web page of the VTO that works as the SIP server.


Step 2 Select **Household Setting > VTS Settings**.

Figure 5-10 VTS management



Step 3 Click **Add**.

Figure 5-11 Add VTS

The 'Add' dialog box is shown with a dark background. It has a title bar with 'Add' and a close button. The form contains three input fields: 'VTS No.' with a text input, 'Registration Password' with a password input (masked with dots) and a toggle for visibility, and 'IP Address' with a text input. At the bottom right, there are 'Save' and 'Cancel' buttons.

Step 4 Configure the parameters.

Table 5-3 Add VTS configuration

Parameter	Description
VTS No.	The number of the VTS.
Registration Password	Leave as default.
IP Address	VTS IP address.


Step 5 Click **Save**.

5.5 Status

You can view the online status and IP addresses of all the connected devices.

Log in to the web home page of the SIP server, and then select **Household Setting > Status**.

Figure 5-12 Status



6 Network

This chapter introduces how to configure the network parameters.

6.1 Basic

6.1.1 TCP/IP

You need to configure the TCP/IP information to connect the VTO to the network. The descriptions below are for models with a Wireless LAN card. A Wireless LAN device is optional.

Wireless LAN

Step 1 Log into the VTO web page.

Step 2 Select **Network > Basic**.

Step 3 Configure the TCP/IP parameters in the **WLAN** section.

LAN

Step 1 Log into the VTO web page.

Step 2 Select **Network > Basic**.

Step 3 Configure the TCP/IP parameters in the **LAN** section.

Figure 6-1 Network configuration




Table 6-1 Parameter description

Parameter	Description
IP Address	Your planned IP address for the VTO.
Preferred DNS	The default is 8.8.8.8.
Alternate DNS	The default is 8.8.4.4.
Transmission Mode	- Mode 1: Multicast streaming (UDP). - Mode 2: RTSP streaming (TCP). - It is transmission Mode 1 by default.
DHCP	Enable the function to get the allocated IP address for the VTO.

6.1.2 Port

Figure 6-2 Port

Table 6-2 Parameter description

Parameter	Description
Port	80 by default. If already used, choose any number from 1025 to 65535 as needed. You can enter <i>http://VTO IP address: Port</i> to log in to the VTO.
HTTPS Port	Enable it and click Save . You can now enter <i>https://VTO IP address: HTTPS Port</i> to log in to the VTO.
TCP/UDP Port	Used for accessing the VTO with devices in other networks. See "6.2 UPnP" for details.
Create Server Certificate	The unique digital identification of VTO for the SSL protocol. For first time use or after changing the IP address of the VTO, you need to go through this process. If you delete the certificate that has been created, it cannot be undone.
Download Root CERT	If you are using a PC that has never logged in to the VTO, you need to download the root certificate, double-click to install it, and then you can use the HTTPS function mentioned above. If you delete the certificate that has been installed, it cannot be undone.

6.1.3 Cloud service

Figure 6-3 Cloud service

Enable the **Cloud Service** function, and then you can scan the QR code with your phone to add the VTO to the app on your smartphone.




For some VTO models, the QR code is embedded in the **Cloud Service** module. Yet for some models, you need to go to **Household Setting > Personnel Management** to check the QR code.

6.2 UPnP

When the VTO works as the SIP server, you can configure the UPnP function to allow WAN devices to log in to the VTO.

Figure 6-4 UPnP



Preparation

- Enable the UPnP function on the router, and then configure a WAN IP address for the router.
- Connect the VTO to the LAN port of the router.

6.2.2 Enabling UPnP Services

- Step 1 Select **Network > UPnP**.
- Step 2 Enable the services listed as needed.
- Step 3 Select **Enable**.
- Step 4 Click **Save**.

6.2.3 Adding UPnP Services

- Step 1 Select **Network > UPnP**.
- Step 2 Click **Add**.
- Step 3 Configure the parameters as needed.

Figure 6-5 Add a UPnP service

Table 6-3 Parameter description

Parameter	Description
Service Name	Enter the information as needed.
Service Type	
Protocol	Select TCP or UDP as needed.
Internal Port	Use port number from 1024 through 5000.
External Port	 - Do not use port number 1–1023 to avoid conflict. - If you need to configure this function for multiple devices, make sure that the ports are not the same. - The port number you use must not be occupied. - The internal and external port number must be the same.

6.3 SIP Server

There must be a SIP server in the network for all connected VTOs and VTHs to call each other. You can use a VTO or other servers as the SIP server.

Step 1 Select **Network > SIP Server**.

Step 2 Select a server type as needed.

- The VTO you have logged in as the SIP server:
Enable **SIP Server**, and click **Save**. You can add VTOs and VTHs to this VTO. See the details in "5 Household Setting".



If the VTO you have logged in does not work as the SIP server, do not enable **SIP Server**; otherwise the connection will fail.

- If another VTO works as the SIP server:
Do not enable **SIP server**. Set **Server Type** to **VTO**, configure the parameters, and then click **Save**.

Figure 6-6 VTO as the SIP server

Table 6-4 SIP server configuration (VTO as the SIP server)

Parameter	Description
IP Addr.	Your planned IP address of the VTO.
Port	5060 by default when a VTO works as the SIP server.
Username	Leave it as default.
Password	
SIP Domain	Leave it as default.
SIP Server Username	Username and password used to log into the web page of the SIP server.
SIP Server Password	

- If the platform works as the SIP server:
Set **Server Type** as **DSS Express/DSS Pro**, and configure the parameters, and then enable the **SIP Server**.

Figure 6-7 Platform as the SIP server

Table 6-5 SIP server description (platform as the SIP server)


Parameter	Description
IP Addr.	SIP server IP address.
Port	5080 by default when the platform works as the SIP server.
Username/Password	Leave it as default.
SIP Domain	Leave it as default or null when the platform works as the SIP

Parameter	Description
	server.
SIP Server Username/ Password	Used to log in to the SIP server.
Alternate IP Addr.	The alternate server will be used as the SIP server when Express/DSS stops responding. We recommend you configure the alternate IP address.  - If you enable Alternate Server, the current VTO you have logged in serves as the alternate server. - If you want another VTO serve as the alternate server, you need to enter the IP address of that VTO in the Alternate IP Addr. textbox. Do not enable Alternate Server in this case.
Alternate Username/ Password	Used to log in to alternate server.
Alternate VTS IP Addr.	IP address of the alternate VTS.
Alternate Server	Enable it as needed.

6.4 Wi-Fi

If the VTO supports Wi-Fi function, then configure the parameters here.

Figure 6-8 Wi-Fi



Step 1 Select **Network** > **WiFi**.

Step 2 Set the **WiFi** status to be **on**.

Step 3 Select a region, and all the networks available in this region are displayed.


Step 4 Click  to connect to the network that you chose.

6.5 Firewall

You can enable different firewall types to control network access to the VTO.

Step 1 Select **Network** > **Firewall**.

Figure 6-9 Firewall



Step 2 Select **Type**, and then enable it.

Step 3 Configure the parameters.

Step 4 Click **Confirm**.

Table 6-6 Firewall type description

Type	Description
Network Access	Select either Allowlist or Blocklist , and then add an IP address or segment which is allowed or denied to access the VTO.
PING Prohibited	The VTO will not response to ping to avoid ping attacks.
Anti-semijoin	Protects the VTO performance by blocking excessive SYN packets.
Mode	Allowlist: Devices that have been granted an access. Blocklist: Devices that have been forbidden an access.

7 Log Management


Select **Search Log**. You can search for different logs, and export them to your PC as needed.



If storage is full, the oldest records will be overwritten. Back up the records as needed.


7.1 Call

Figure 7-1 Call




7.2 Alarm

Figure 7-2 Alarm



7.3 Unlock


Figure 7-3 Unlock



7.4 Log

Select time range and type, and then you can see all the log information.

Figure 7-4 Log



Appendix 1 Cybersecurity Recommendations

Mandatory actions to be taken for basic device network security:

1. Use Strong Passwords

Please refer to the following suggestions to set passwords:

- The length should not be less than 8 characters;
- Include at least two types of characters; character types include upper and lower case letters, numbers and symbols;
- Do not contain the account name or the account name in reverse order;
- Do not use continuous characters, such as 123, abc, etc.;
- Do not use overlapped characters, such as 111, aaa, etc.;

2. Update Firmware and Client Software in Time

- According to the standard procedure in Tech-industry, we recommend to keep your device (such as NVR, DVR, IP camera, etc.) firmware up-to-date to ensure the system is equipped with the latest security patches and fixes. When the device is connected to the public network, we recommend enabling the "auto-check for updates" function to obtain timely information of firmware updates released by the manufacturer.
- We suggest that you download and use the latest version of client software.

"Nice to have" recommendations to improve your device network security:

1. Physical Protection

We suggest that you perform physical protection to device, especially storage devices. For example, place the device in a special computer room and cabinet, and implement well-done access control permission and key management to prevent unauthorized personnel from carrying out physical contacts such as damaging hardware, unauthorized connection of removable device (such as USB flash disk, serial port), etc.

2. Change Passwords Regularly

We suggest that you change passwords regularly to reduce the risk of being guessed or cracked.

3. Set and Update Passwords Reset Information Timely

The device supports password reset function. Please set up related information for password reset in time, including the end user's mailbox and password protection questions. If the information changes, please modify it in time. When setting password protection questions, it is suggested not to use those that can be easily guessed.

4. Enable Account Lock

The account lock feature is enabled by default, and we recommend you to keep it on to guarantee the account security. If an attacker attempts to log in with the wrong password several times, the corresponding account and the source IP address will be locked.

5. Change Default HTTP and Other Service Ports

We suggest you to change default HTTP and other service ports into any set of numbers between 1024~65535, reducing the risk of outsiders being able to guess which ports you are using.

6. Enable HTTPS

We suggest you to enable HTTPS, so that you visit Web service through a secure communication channel.

7. MAC Address Binding

We recommend you to bind the IP and MAC address of the gateway to the device, thus reducing the risk of ARP spoofing.

8. Assign Accounts and Privileges Reasonably

According to business and management requirements, reasonably add users and assign a minimum set of permissions to them.

9. Disable Unnecessary Services and Choose Secure Modes

If not needed, we recommend turning off some services such as SNMP, SMTP, UPnP, etc., to reduce risks.

If necessary, it is highly recommended that you use safe modes, including but not limited to the following services:

- SNMP: Choose SNMP v3, and set up strong encryption passwords and authentication passwords.
- SMTP: Choose TLS to access mailbox server.
- FTP: Choose SFTP, and set up strong passwords.
- AP hotspot: Choose WPA2-PSK encryption mode, and set up strong passwords.

10. Audio and Video Encrypted Transmission

If your audio and video data contents are very important or sensitive, we recommend that you use encrypted transmission function, to reduce the risk of audio and video data being stolen during transmission.

Reminder: encrypted transmission will cause some loss in transmission efficiency.

11. Secure Auditing

- Check online users: we suggest that you check online users regularly to see if the device is logged in without authorization.
- Check device log: By viewing the logs, you can know the IP addresses that were used to log in to your devices and their key operations.

12. Network Log

Due to the limited storage capacity of the device, the stored log is limited. If you need to save the log for a long time, it is recommended that you enable the network log function to ensure that the critical logs are synchronized to the network log server for tracing.

13. Construct a Safe Network Environment

In order to better ensure the safety of device and reduce potential cyber risks, we recommend:

- Disable the port mapping function of the router to avoid direct access to the intranet devices from external network.
- The network should be partitioned and isolated according to the actual network needs. If there are no communication requirements between two sub networks, it is suggested to use VLAN, network GAP and other technologies to partition the network, so as to achieve the network isolation effect.
- Establish the 802.1x access authentication system to reduce the risk of unauthorized access to private networks.
- Enable IP/MAC address filtering function to limit the range of hosts allowed to access the device.